


i-Vu® XT BACnet Link (part no. XT-LB) (drv_gen5)

Installation and Start-up Guide





Verify that you have the most current version of this document from **www.hvacpartners.com**, the **Carrier Partner Community** website, or your local Carrier office.

Important changes are listed in **Document revision history** at the end of this document.

©2025 Carrier. All rights reserved.



Contents

| | |
|---|-----------|
| What is the XT-LB? | 1 |
| Critical Product Announcement | 2 |
| Specifications | 2 |
| To mount the XT-LB | 5 |
| Wiring for power | 7 |
| To wire for power | 7 |
| Connecting to the XT-LB through the Service Port | 8 |
| Connecting to the XT-LB through the Gig-E Port | 10 |
| Addressing the XT-LB | 11 |
| To set the IP address | 11 |
| To set an IPv6 address | 13 |
| To set the Port S1 address and baud rate | 14 |
| To set the Port S2 address and baud rate | 15 |
| To set up the Local Network | 15 |
| Wiring for communications | 16 |
| Wiring specifications | 16 |
| To connect the XT-LB to the Ethernet | 17 |
| To wire to a BACnet/ARCNET network | 17 |
| To wire to a BACnet MS/TP network | 18 |
| Find and upload in the I-Vu® interface | 19 |
| Downloading the driver | 19 |
| To stage a driver for later installation | 19 |
| Adjusting driver properties and controller setup through the Service Port or the I-Vu® Interface | 21 |
| Home tabs | 21 |
| Dashboard tab | 21 |
| Diagnostics tab | 22 |
| Connections tabs | 23 |
| Device tab | 23 |
| Gig-E Port using BACnet/IPv4 | 25 |
| Gig-E Port using BACnet/IPv6 | 27 |
| Gig-E Port using BACnet/SC | 29 |
| Gig-E Port using BACnet/Ethernet | 32 |
| Port S1 and Port S2 | 33 |
| Local Network tab | 35 |
| Licensing tab | 38 |
| Advanced tabs | 38 |
| Security tab | 38 |
| Alarms tab | 39 |
| Notification Class tab | 40 |
| Controller Clock tab | 42 |
| Color Cache tab | 43 |
| Diagnostics tab | 44 |
| Network tab | 45 |
| Control Programs tab | 46 |
| Protocols tab | 47 |
| IoT tab | 47 |
| Managing third-party points and feature licenses | 48 |
| To view points, license, and feature status | 48 |
| To generate a requirements file | 48 |
| To download a license | 49 |

| | |
|--|-----------|
| To apply a license to a controller | 49 |
| Troubleshooting..... | 51 |
| LEDs | 51 |
| To get a Module Status report | 53 |
| To get a Device Log | 54 |
| To get the XT-LB's serial number..... | 54 |
| To replace the XT-LB's fuse | 54 |
| To take the XT-LB out of service | 56 |
| Compliance | 57 |
| FCC Compliance..... | 57 |
| CE and UKCA Compliance | 57 |
| Industry Canada Compliance..... | 57 |
| BACnet Compliance..... | 57 |
| Appendix - Module Status field descriptions | 58 |
| Document revision history | 61 |



What is the XT-LB?

The i-Vu® XT BACnet Link (part no. XT-LB) with drv_gen5 driver is a BACnet router that:

- Provides BACnet routing between any supported BACnet communication types
- Runs control programs
- Can have two BACnet/IP networks communicating on the Gig-E port
- Can serve as a BACnet Broadcast Management Device (BBMD) on each of the BACnet/IP networks
- Supports Foreign Device Registration (FDR)
- Supports DHCP IP addressing
- Has built-in network diagnostic capture functionality for troubleshooting
- Has network statistics that can be viewed numerically or as trend graphs
- Works with the i-Vu® v8.5 or later system
- Can serve as both an IP and a serial gateway for third-party protocols



The XT-LB has 4 physical ports for communication with BACnet and/or third-party protocols. For more information on using third-party protocols, see the specific protocol's integration guide.

What is the XT-LB?

| Port | Port type | For routing this type of communication... | At... |
|--------------|------------------------------------|--|--------------------------------|
| Gig-E | 10/100/1000 Mbps Ethernet | BACnet/IP, BACnet/IPv6, BACnet/Ethernet, BACnet/SC | 10, 100, or 1000 Mbps (1 Gbps) |
| S1 | High-speed EIA-485 port | BACnet/ARCNET BACnet/MSTP | 156 kbps 9.6 to 115.2 kbps |
| S2 | Electrically isolated EIA-485 port | BACnet/MSTP | 9.6 to 115.2 Kbps |
| Service Port | 10/100 Mbps Ethernet HTTP/IP | BACnet/IP Service Port | 10 or 100 Mbps |

The XT-LB also has a USB port for recovery.


Critical Product Announcement

Due to the global semiconductor supply chain uncertainty, starting July 2022, the XT-LB no longer supports communication over the ARCNET network. ARCNET-disabled XT-LBs have a serial number starting with the prefix and have an updated label. See To get the XT-LB's serial number.





The XT-LB's driver properties and controller setup pages only show available communication selection options.

Specifications

| | |
|---|---|
| Driver | drv_gen5_< version >.driverx NOTE For the fwex driver instructions, see the <i>i-Vu® XT BACnet Link (part no. XT-LB) (drv_fwex) Installation and Start-up Guide</i> . |
| Maximum number of control programs ¹ | 999 |
| Maximum number of BACnet objects ¹ | 12000 |
| Default number of third-party BACnet integration points | 1500 |
| Default number of FLEX Points ² | 500 |
| Maximum FLEX Points | 5000 |
| ¹ Depends on available memory ² Increase by purchasing FLEXPacks | |
| Power | 24 Vac ±10%, 50–60 Hz, 50 VA 26 Vdc ±10%, 15 W |

| | |
|-----------------------|---|
| Gig-E port | <p>10/100/1000 BaseT, full duplex, Ethernet port for communication with the following BACnet protocols and/or third party protocols:</p> <ul style="list-style-type: none"> • BACnet/IP • BACnet/IPv6 • BACnet/Ethernet • BACnet/SC <p>NOTE For communication with third-party protocols, see the specific protocol's integration guide.</p> |
| Port S1 | <p>For communication with either of the following BACnet protocols:</p> <ul style="list-style-type: none"> • A BACnet ARCNET network at 156 kbps • A BACnet MS/TP network at 9600 to 115200 bps <p>NOTE For communication with third-party protocols, see the specific protocol's integration guide.</p> <p>This port's End of Net? switch can be set to Yes to terminate the network segment.</p> |
| Port S2 | <p>For communication with either of the following:</p> <ul style="list-style-type: none"> • A BACnet MS/TP network at 9600 to 115200 bps • A Modbus serial network at 9600 to 115200 bps <p>This port's End of Net? switch can be set to Yes to terminate the network segment.</p> |
| Service Port | Ethernet port at 10 or 100 Mbps for setting up the controller and troubleshooting through a local connection to a computer. |
| USB port | USB 2.0 host port for device recovery and connecting the Carrier wireless service adapter. |
| Microprocessor | 32-bit ARM Cortex-A8, 600MHz, processor with multi-level cache memory |
| Memory | <p>8 GBs eMMC Flash memory and 512 MB DDR3 DRAM (22 MB available to use). User data is archived to non-volatile Flash memory when parameters are changed, every 90 seconds, and when the firmware is deliberately restarted.</p> <p>NOTE When you change a parameter, you must wait 30 seconds before turning the power off, in order for the change to be saved.</p> |
| Real-time clock | Real-time clock keeps track of time in the event of a power failure for up to 3 days. |
| Protection | <p>Device is protected by a replaceable, fast acting, 250 Vac, 2A, 5mm x 20mm glass fuse.</p> <p>The power and network ports comply with the EMC requirements EN50491-5-2.</p> <p> CAUTION To protect against large electrical surges on serial EIA-485 networks, place a PROT485 at each place wire enters or exits the building.</p> |
| LED status indicators | <ul style="list-style-type: none"> • Tricolor NET LED to show network status • Tricolor SYS LED to show system status • A TX (Transmit) and RX (Receive) LED for the following ports: <ul style="list-style-type: none"> • Gig-E • Port S1 • Port S2 <p>See <i>LEDs</i> (page 51).</p> |

What is the XT-LB?

| | | | |
|--------------------------------|---|---------------------|---|
| Environmental operating range | <div>-40 to 158°F (-40 to 70°C), 10-95% relative humidity, non-condensing</div> <div>NOTES</div> <div><ul style="list-style-type: none">The XT-LB is suitable for installation inside or outside the building envelope.Install in a UL Listed enclosure only.Do not change the position of the power or End of Net switch at temperatures below -22°F (-30C) to ensure proper operation and electrical connectivity.</div> | | |
| Physical | Fire-retardant plastic ABS, UL94-5VA | | |
| Terminal blocks and connectors | Screw-type terminal blocks. 0.2 in (5.08 mm) pitch connectors | | |
| Mounting | 35mm DIN rail mounting or screw mounting | | |
| Overall dimensions | A: | 7.1 in. (18.03 cm) |  |
| | B: | 6.95 in. (17.65 cm) | |
| | Depth: | 2.09 in. (5.31 cm) | |
| Screw mounting dimensions | C: | 6.45 in. (16.38 cm) | |
| | D: | 4.1 in. (10.4 cm) | |
| Weight | 1 lb. 1 oz. (0.482 kg) | | |
| Compliance | <div>United States of America:</div> <div>FCC compliant to Title CFR47, Chapter 1, Subchapter A, Part 15, Subpart B, Class A; UL Listed to UL 916, PAZX, Energy Management Equipment</div> <div>Canada:</div> <div>Industry Canada Compliant, ICES-003, Class A</div> <div>cUL Listed UL 916, PAZX7, Energy Management Equipment</div> <div>Europe:  Mark, UK: </div> <div>EN50491-5-2:2009; Part 5-2: EMC requirements for HBES/BACS used in residential, commercial and light industry environment</div> <div>RoHS Compliant: 2015/863/EU</div> <div>REACH Compliant</div> <div>Australia and New Zealand:</div> <div> C-Tick Mark, AS/NZS 61000-6-3</div> | | |


To mount the XT-LB

The XT-LB must be mounted in a metal enclosure or cabinet which is properly rated for the location where it is being installed.

NOTE We recommend screw mounting when installing in a high temperature and high humidity environment.

DIN rail mount

- 1 Push down and pull out the center tabs shown below to clear the din rail trough on the back of the XT-LB.



- 2 Place the XT-LB on the DIN rail so that the rail is in the trough on the back of the XT-LB.




- 3 Push the center tabs towards the XT-LB until you hear them click.
- 4 Pull gently on the XT-LB to verify that it is locked in place.

Screw Mount

Leave about 2 in. (5 cm) on each side of the XT-LB for wiring.

Insert #6 screws through the mounting holes. Use no more than 8 in.lbs. torque to secure plastic tab to mounting surface.

To mount the XT-LB



| | |
|--------|---------------------|
| A: | 7.1 in. (18.03 cm) |
| B: | 6.95 in. (17.65 cm) |
| C: | 6.45 in. (16.38 cm) |
| D: | 4.1 in. (10.4 cm) |
| Depth: | 2.09 in (5.31 cm) |

Wiring for power



WARNING Do not apply line voltage (mains voltage) to the XT-LB's ports and terminals.





CAUTIONS

- The XT-LB is powered by a Class 2 power source. Take appropriate isolation measures when mounting it in a control panel where non-Class 2 circuits are present.
- Carrier controllers can share a power supply as long as you:
 - Maintain the same polarity.
 - Use the power supply only for Carrier controllers.

To wire for power

- 1 Make sure the XT-LB's power switch is in the **OFF** position to prevent it from powering up before you can verify the correct voltage.



- 2 Remove power from the power supply.
- 3 Pull the red screw terminal connector from the XT-LB's power terminals labeled **24 Vac/Vdc (+/-)**.
- 4 Connect the power supply's wires to the red screw terminal connector.
- 5 Connect an 18 AWG or larger wire from the power supply's negative (-) terminal to earth ground. This wire must not exceed 12 in. (30.5 cm).
- 6 Apply power to the power supply.
- 7 Measure the voltage at the red screw terminal connector to verify that the voltage is within the operating range of 20 to 30 Vac or 23.4 to 30 Vdc.
- 8 Insert the red screw terminal connector into the XT-LB's power terminals.
- 9 To verify the polarity of the wiring, measure the voltage from the negative terminal of the red screw terminal connector to a nearby ground. The reading should be 0V.
- 10 Turn on the XT-LB's power switch.
- 11 Verify that the  LED on top of the XT-LB is on.
- 12 Measure the voltage at the red screw terminal connector to verify that the voltage is within the operating range of 20 to 30 Vac or 23.4 to 30 Vdc.

Connecting to the XT-LB through the Service Port

You can connect the XT-LB to a computer using a wireless or cable connection to the Service Port. This allows you to communicate with the XT-LB through a web browser to:

- View/change XT-LB and network settings. Changes take effect immediately after clicking
- View the XT-LB's Module Status report
- Troubleshoot

Restart 

You can set a site level **Device Password** to restrict access to the Service Port controller setup pages of a device with a drv_gen5 driver. Set up the password in any of the following locations:


- In SiteBuilder, in the site dialog box
- In the i-Vu® interface, on the system level, on the **Devices > Advanced** tab
- If you have multiple sites, in the i-Vu® interface, at the site level > **Properties** page

To connect the XT-LB to a computer using the Carrier wireless service adapter:

- 1 Insert the Carrier wireless service adapter (part# USB-W) into the XT-LB's USB Service Port to communicate with a Wi-Fi-compatible computer.
- 2 Open your computer's wireless network display to view your available wireless networks.
NOTE The XT-LB only supports the 5 GHz band and not the 2.4 GHz band.
- 3 Connect to the wireless network using the network SSID and password that are printed on the Carrier wireless service adapter.
- 4 Open a web browser on the computer and navigate to <https://local.access> or <https://169.254.1.1> to see the controller setup pages.

To connect the XT-LB to a computer using a cable:

- 1 Connect an Ethernet cable from a computer to the XT-LB as shown below.



- 2 Turn off the computer's Wi-Fi if it is on.
- 3 If your computer uses a static IP address, use the following settings:

- Address: 169.254.1.x, where x is 2 to 7
 - Subnet Mask: 255.255.255.248
 - Default Gateway: 169.254.1.1
- 4** If it uses a DHCP address, leave the address as it is.
 - 5** Open a web browser on the computer.
 - 6** Navigate to <https://local.access> or <https://169.254.1.1> to see the controller setup pages.

NOTE The first time you access the XT-LB in the i-Vu® interface after you have changed settings through the Service Port, be sure to upload the changes to the system database. This will preserve those settings when you download memory or parameters to the XT-LB.

Connecting to the XT-LB through the Gig-E Port

Using a computer and an Ethernet cable, you can communicate with the XT-LB through a web browser to:

- Address and configure controllers
- View/change XT-LB and network settings. Changes take effect immediately after clicking
- View the XT-LB's Module Status report
- Troubleshoot

Restart 

To access the controller setup pages through the Gig-E network

- 1 In the i-Vu® interface, on the navigation tree, select the XT-LB.
- 2 Right-click XT-LB, select **Driver Properties** > **Settings** tab > **Advanced** > **Security** tab.
- 3 Enable **Allow Configuration on Gig-E Port** .
- 4 You can set a site level **Device Password** to restrict access to the Service Port controller setup pages of a device with a drv_gen5 driver. Set up the password in any of the following locations:
 - In SiteBuilder, in the site dialog box
 - In the i-Vu® interface, on the system level, on the **Devices** > **Advanced** tab
 - If you have multiple sites, in the i-Vu® interface, at the site level > **Properties** page
- 5 Connect an Ethernet cable from a computer to the Gig-E network that the XT-LB is communicating on.
- 6 Turn off the computer's Wi-Fi if it is on.
- 7 If your computer uses a static IP address, use settings appropriate for the building network.
- 8 If it uses a DHCP address, leave the address as it is.
- 9 Open a web browser on the computer.
- 10 Navigate to `http://<router ip address>`.

NOTE The IP address is preset in the XT-LB for interfacing with the Ethernet network.

NOTE The first time you access the XT-LB in the i-Vu® interface after you have changed settings through the Service Port, be sure to upload the changes to the system database. This will preserve those settings when you download memory or parameters to the XT-LB.

Addressing the XT-LB

| Set this port's address ... | In this location... | See... |
|-----------------------------|---------------------|--|
| IP | Service Port | To set the IP address |
| IPv6 | Service Port | To set an IPv6 address (page 13) |
| Port S1 | Service Port | To set the Port S1 address and baud rate (page 14) |
| Port S2 | Service Port | To set the Port S2 address and baud rate (page 15) |

To set the IP address


You must define the XT-LB's IP addressing (IP address, subnet mask, and default gateway) in the Service Port controller setup pages so that the XT-LB can communicate with the i-Vu Server on the IP network.


Use one of the IP addressing schemes described below with the associated instructions that follow.

| Use a... | If... |
|--|--|
| DHCP IP Address generated by a DHCP server | The IP network uses a DHCP server for IP addressing |
| Custom Static IP Address from your network administrator | <p>You do not use a DHCP server and the answer to any of the following questions is yes. Will the i-Vu® system:</p> <ul style="list-style-type: none"> • Share a facility's existing IP data network? • Have 254 or more devices with static IP addresses? • Be connected to the Internet? • Have at least one device located on the other side of an IP router? • Have any third-party IP devices? |
| Default IP Address that your system creates | The answer to all of the above questions is no. |


NOTE Carefully plan your addressing scheme to avoid duplicating addresses. If third-party devices are integrated into the system, make sure your addresses do not conflict with their addresses.

To set a DHCP IP address

- 1 On the Service Port controller setup, click , select **Modstat** from the drop-down list, find the XT-LB's **Ethernet MAC address**, and write it down.
- 2 On the **Connections** page, under the **Gig-E Port** tab > **Primary BACnet/IP**, select **DHCP** in the drop-down list for **Address Mode**.

- 3 Click .
- 4 Write down the **IP Address**.
- 5 Give the DHCP network administrator the IP address and Ethernet MAC address and ask him to reserve that IP address for the XT-LB so that it always receives the same IP address from the DHCP server.

To set a custom IP address

- 1 Obtain the IP address, subnet mask, and default gateway address for the XT-LB from the facility network administrator.
- 2 On the **Connections** page, under the **Gig-E Port** tab > **Primary BACnet/IP**, select **Custom Static** in the drop-down list for **Address Mode**.
- 3 Enter the **IP Address**, **Subnet Mask**, and **Default Gateway** addresses given to you by the network administrator.
- 4 Click .


To set a default IP address

Default IP addressing assigns the following to the XT-LB:

- IP address = 192.168.168.**x**
where **x** is the setting on the rotary switches in the range from 1 to 253
- Subnet Mask = 255.255.255.0
- Default Gateway = 192.168.168.254

- 1 Set the XT-LB's three rotary switches to a unique address on the network. Set the left rotary switch to the hundreds digit, the middle switch to the tens digit, and the right switch to the ones digit.

EXAMPLE The switches below are set to 125.




- 2 On the **Connections** page, under the **Gig-E Port** tab > **Primary BACnet/IP**, select **Default IP Address** in the drop-down list for **Address Mode**.

- 3 Click .



CAUTION

- If you set the Default IP address on the controller setup **Connections** page > **Gig-E Port** tab and then change the rotary switches, you must do one of the following to correct the IP address in the XT-LB:

- Click .
- Cycle the XT-LB's power.

Correct the IP address in the i-Vu® application using Find Devices and Upload All Content. See the *i-Vu® Help* for more information.

NOTE The default address is an intranet address. Data packets from this address are not routable to the Internet.

To set an IPv6 address

You must define the XT-LB's IPv6 addressing (IPv6 address, multicast address, and default gateway) in the Service Port controller setup pages so that the XT-LB can communicate with the i-Vu Server on the IPv6 network.

Use one of the IPv6 addressing schemes described below with the instructions that follow. See the *IPv6 Best Practices Guide*.

| Use a... | If... |
|---|--|
| Default IP Address that your system creates | fd01::192:168:168:<rotary> |
| Custom Static from your network administrator | You have a permanent IP address which does not change and is usually obtained from the network administrator. |
| DHCP generated by a DHCP server | The IP network uses a DHCP server for IP addressing |
| Link-Local | This is an autogenerated private IP address used for local network segment communications. Segment starts with FE80. |
| SLAAC | Used for Global Scope addressing and multicasting. This is defined by the building network administrator. |

NOTE Carefully plan your addressing scheme to avoid duplicating addresses. If third-party devices are integrated into the system, make sure your addresses do not conflict with their addresses.

To set a custom IP address

- 1 Obtain the IP address, subnet mask, and default gateway address for the XT-LB from the facility network administrator.
- 2 On the **Connections** page, under the **Gig-E Port** tab > **BACnet/IPv6**, select **Custom Static** in the drop-down list for **Address Mode**.
- 3 Enter the **IP Address**, **Prefix Length**, and **Default Gateway** addresses that the network administrator gave you.

- 4 Click .


To set a default IP address

Default IP addressing assigns the following to the XT-LB:

- **IP address** = fd01::192:168:168:x
where **x** is the setting on the rotary switches in the range from 1 to 253
- **Prefix Length** = 64
- **Default Gateway** = fd01::192:168:168:254

- 1 Set the XT-LB's three rotary switches to a unique address on the network. Set the left rotary switch to the hundreds digit, the middle switch to the tens digit, and the right switch to the ones digit.

EXAMPLE The switches below are set to 125.




- 2 In the Service Port controller setup pages on the **Connections** page, under the **Gig-E Port** tab > **BACnet/IPv6**, select **Default IP Address** in the drop-down list for **Address Mode**.

- 3 Click .



CAUTIONS

- If you configure your XT-LB to use link-local addressing, then your IPv6 connection must also be configured to use link-local addressing. The i-Vu® Server address must start with fe80 and the Multicast Address must start with ff02.
- If you set the Default IP address on the controller setup **Connections** page > **Gig-E Port** tab and then change the rotary switches, you must do one of the following to correct the IP address in the XT-LB:

- Go to the controller setup **Connections** page and click .
- Cycle the XT-LB's power.

Correct the IP address in SiteBuilder.

NOTE The default address is an intranet address. Data packets from this address are not routable to the Internet.

To set the Port S1 address and baud rate

The address should be in one of the following ranges based on the port's use.

- For ARCNET, the range is 1 to 254.
- For MS/TP, the range is 0 to 127.

On the **Connections** > **Port S1** tab, type the address in the **MAC Address** field.

NOTE ARCNET is not supported on Port S2.

For MS/TP, set up the port's baud rate

- 1 On the **Connections** > **Port S1** tab, select the **Baud Rate**. The default is 76,800 bps.

- 2 Click .

To set the Port S2 address and baud rate

- 1 On the **Connections** > **Port S2** tab, select **BACnet MSTP** from the droplist.
- 2 Type the address in the **MAC Address** field. The address must be in the range of 0 to 127.
- 3 Select the **Baud Rate**. The default is 76,800 bps.

NOTE Select the same baud rate for all devices on the MS/TP network.

- 4 Click .

To set up the Local Network

You can use the controller setup **Local Network** tab to discover Carrier devices on a single network. You can configure them and assign addresses to each one using one of the methods described below.

Wiring for communications

The XT-LB communicates on the following ports.

| Port | Protocol | Port type(s) | Speed(s) |
|---|--|--------------|--------------------------------|
| Gig-E | BACnet/IPv4 BACnet/IPv6 and/or BACnet/Ethernet | Ethernet | 10, 100, or 1000 Mbps (1 Gbps) |
| Port S1 ¹ | BACnet/ARCNET | EIA-485 | 156 kbps |
| Port S1 ¹ or Port S2 | BACnet/MSTP | EIA-485 | 9.6 to 115.2 Kbps ² |
| Service Port ³ | HTTPS/IP | Ethernet | 10 Mbps 100 Mbps |
| USB Port | USB2.0 | USB | |

¹ Set the **Port S1 Configuration** rotary switch to:

- 0** if the port is not used
- 1** for MS/TP
- 2** for ARCNET
- 3** for Modbus
- 4** for other third-party protocols

² Default for MS/TP is 76.8 kbps.

³ See *Connecting to the XT-LB through the Service Port* (page 8).

Wiring specifications

| For... | Use... | Maximum Length |
|----------|--|------------------------|
| Ethernet | Cat5e or higher Ethernet cable | 328 feet (100 meters) |
| ARCNET | 22 AWG, low-capacitance, twisted, stranded, shielded copper wire * | 2000 feet (610 meters) |
| MS/TP | 22 AWG, low-capacitance, twisted, stranded, shielded copper wire * | 2000 feet (610 meters) |

* See the *Open Controller Network Wiring Guide*.



WARNING Do not apply line voltage (mains voltage) to the XT-LB's ports and terminals.

To connect the XT-LB to the Ethernet

Connect an Ethernet cable to the Gig-E Ethernet port.

If your system has multiple routers that reside on different IP subnets, you must set up one router on each IP subnet as a BACnet/IP Broadcast Management Device (BBMD).

Every subnet with a router must have a BBMD configured in order for broadcasts from routers on that subnet to reach the rest of the routers on the network.

NOTES

- The i-Vu® Standard or Plus application - If the i-Vu® web server is on a separate subnet than the rest of the routers, the internal router must be assigned a routable IP address and configured as a BBMD.
- The i-Vu® Pro application - If the i-Vu® Pro server is on a separate subnet than the rest of the routers, you must register it as a foreign device to a router acting as a BBMD device.

Use the **BBMD Configuration Tool** to:

- Write/read the **Broadcast Distribution Table** (BDT) of each BBMD device
- Allow controllers on one subnet to communicate with controllers on other subnets
- Enable the i-Vu® application to see, upload, or configure controllers on different subnets

To wire to a BACnet/ARCNET network

- 1 Turn **off** the XT-LB's power.
- 2 Check the communications wiring for shorts and grounds.
- 3 Connect the communications wiring to **Port S1**'s screw terminals labeled **Net +**, **Net -**, and **Shield**.
NOTE Use the same polarity throughout the network segment.
- 4 If the XT-LB has a **Port S1 Configuration** rotary switch, set it to 2.
- 5 If the XT-LB is at either end of a network segment, set the port's **End of Net** switch to **Yes**.
NOTE The XT-LB's **End of Net** switch applies network termination and bias. See the *Open Controller Network Wiring Guide*.
- 6 Turn on the XT-LB's power.
- 7 To verify communication with the network, get a Module Status report in the i-Vu® interface for a XT-LB on the ARCNET network.
NOTE This step requires that you have discovered and uploaded the XT-LB in the i-Vu® application.

To wire to a BACnet MS/TP network

An MS/TP network can be wired to either **Port S1** or **Port S2**.

- 1 Turn **on** the XT-LB's power.
- 2 Check the communications wiring for shorts and grounds.
- 3 Connect the communications wiring to the **Port S1** or **Port S2** screw terminals labeled **Net +**, **Net -**, and **Shield**.

NOTE Use the same polarity throughout the network segment.

- 4 If you are using **Port S1**, and the controller has a **Port S1 Configuration** rotary switch, set it to 1.

NOTE If **Port S1** is not being used for any network, set this rotary switch to 0.

- 5 If the XT-LB XT-LB is at either end of a network segment, set the port's **End of Net?** switch to **Yes**.

NOTE The XT-LB's **End of Net** switch applies network termination and bias. See the *Open Controller Network Wiring Guide*.

- 6 Turn on the XT-LB's power.
- 7 To verify communication with the network, get a Module Status report in the i-Vu® interface for a XT-LB on the MS/TP network.

NOTE This step requires that you have discovered and uploaded the XT-LB in the i-Vu® application.

Find and upload in the i-Vu® interface

In the i-Vu® interface, select the System level in the navigation tree.

- 1 On the **Devices** page > **Manage** tab, click **Find Devices** to discover your routers and their drivers and graphics.
- 2 Once routers are found, select one or more routers in the list on the **Manage** tab and click **Upload All Content** to upload to the i-Vu® application. Use **Ctrl+click**, **Shift+click**, or both to select multiple items.
- 3 Click **OK** when you see the message **This will upload all content for the controller. Are you sure you want to do this?**. When complete, a check mark under **Status** indicates a successful upload.

NOTES

- If an error message appears, click on the message to view an explanation.
- For details, see the i-Vu® Help.

Downloading the driver

Download to send the following items to the XT-LB:


- drv_gen5_< version >. driverx (See NOTES below.)
- Editable properties

NOTES

- The driver must be in <system_name>**drivers**. The exact location of the system directory depends on where you have saved it. It is typically under **I-Vux.x\programdata\systems**.
- To verify that you have the driver's latest version, go to the Carrier Partner Community website and compare the latest version to the XT-LB's driver in SiteBuilder.
- If you change any of the above items or the XT-LB's address after the initial download, you must download again. The first download takes longer than subsequent downloads.

To stage a driver for later installation

To avoid interrupting controller function when installing a driver, you can first stage the driver to the controller before installing it. The controller retains full functionality while the new driver is staged and continues to use the existing driver until you install the new driver.

- 1 On the i-Vu® navigation tree, choose a network and go to the **Devices** > **Drivers** tab.
- 2 Select the XT-LB and click  .
- 3 Check **Stage driver in controller**.

Find and upload in the i-Vu® interface

- 4 Do one of the following:
 - If the driver is in the **Driver Version** drop-down list:
 - a. Select the driver.
 - b. Click **Accept**.
 - If the driver is not in the list:
 - a. Click **Add**.
 - b. Browse to select the driver.
 - c. Click **Open**.
 - d. Click **Continue**.
 - e. Click **Close**.
 - f. Click **Close** again.
- 5 On the **Devices > Drivers** tab, click **Start Staging**.
- 6 Once you are ready to install the staged driver to the controller, click **Start Installation**.

Adjusting driver properties and controller setup through the Service Port or the i-Vu® interface

The driver properties pages in the i-Vu® application are the same controller setup pages that you access by connecting to the Service Port.

NOTES

- The **Home Network** portion of the **Connections > Device** tab is available only by connecting to the Service Port and not through the driver properties.
- Some properties, such as the home network settings, cannot be changed in the i-Vu® driver interface. This prevents losing communication to the XT-LB. You can change those settings by connecting directly to the Service Port.


After you download the driver to the XT-LB, you may want to change the driver's properties in the i-Vu® interface to suit your application.


- 1 On the i-Vu® navigation tree, right-click the XT-LB and select **Driver Properties** from the drop-down list.
- 2 Select **Driver > Settings** tab to open the controller setup pages, which are detailed below.

Home tabs

Dashboard tab

This page shows general controller information.

| Controller Status | |
|---|--|
| Number of alarms undelivered by the controller | Click to view undelivered alarms. |
| BACnet System Status | Current state of the controller |
| Sys Net | Current connection status |
| |  TIP Click the Sys or Net LED to view LED descriptions. See <i>LEDs</i> (page 51). |
| Performance | |
| CPU Load | Percentage of CPU used |
| Program Load | Percentage of time used by control programs |
| Memory Load | Percentage of long-term memory used |

| Port Info | |
|--|--|
| Device Instance | Unique ID assigned to the controller |
| Enabled BACnet Ports |  indicates the port set as the home network |
| Active Alarms | |
| If there are any currently active alarms, they are shown here. | |

Diagnostics tab

This page allows you to:

- Access additional diagnostic tools with assistance from Carrier Controls System Support
- **NOTE** You can only access this tool in the controller setup pages connecting through the Service Port.
- Download log files
- Blink the device's Locator LED
- Capture network communication and then download the capture file for troubleshooting
- View network diagnostics

| | |
|-------------------------|--|
| Technical Support Tools | <p>Enable the toggle switch to view the Challenge key. Send the displayed Challenge key to the Carrier Controls System Support representative who will provide an Activation Key for you to enter.</p> <p>Additional tools will be displayed to help Carrier Controls System Support troubleshoot issues. Enabling these tools has security implications, therefore they are automatically disabled after 2 hours.</p> |
| Logs | <ul style="list-style-type: none"> • Retrieve all — Downloads all logs in a zip file to your computer • Specific log — Allows you to choose to download the application logs (by date) or the system logs • Delete all — Deletes all logs, including current logs |
| Blink | <p>To physically identify a device that is displayed on the Local Devices table, click Blink to light the Locator LED in the actuator release button.</p> |

| | |
|---|---|
| Packet Capture Primary/secondary BACnet/IP BACnet/IPv6 BACnet/Ethernet Primary/secondary BACnet SC Port S1 BACnet/MSTP Port S1 BACnet/ARCNET Port S2 BACnet/MSTP | <p>This allows you to capture network communication on the corresponding port and then download the capture file for troubleshooting.</p> <ul style="list-style-type: none"> • Start now — Start a capture immediately. The capture runs until you click Stop or until it reaches the file size limit, whichever occurs first. • Start continuous — Start a continuous capture immediately. The capture stores the most recent 5MB of captured data and runs continuously until you click Stop. <p>NOTES</p> <ul style="list-style-type: none"> ○ The number of continuous captures that you can run simultaneously is limited. ○ Continuous captures are disabled when the XT-LB is in a low-memory state. • Schedule — Schedule a packet capture to automatically run at a future date and time of your choosing. Choose whether the capture stops until it reaches the file size limit or specify a duration of time for the capture to run. • Capture Data of Type — Choose whether to capture all packets or only BACnet packets (BACnet MS/TP only). • Get capture file — Download the capture file once you have stopped the capture or the capture has reached the file size limit. <p>NOTE Capture files have a 25MB limit. If you need a larger capture, you must attach a computer running Wireshark. Please see the <i>Carrier BACnet Integration Guide</i> for more details.</p> <p>Please contact the <i>Carrier Training Department</i> regarding Networking I/II classes for more details on using packet captures for diagnostics and troubleshooting.</p> |
| Network Diagnostics | <p>Click Reset statistics to reset values to 0, which then resume accumulating.</p> <p>See <i>Appendix - Module Status field descriptions</i> (page 58) for descriptions of these fields.</p> |

Connections tabs

Use these pages to set up communication with the XT-LB. The fields are editable when the setup pages are accessed by connecting directly to the Service Port. Some of those fields will not be editable when you access them through the i-Vu® system driver properties.

NOTE For communication with third-party protocols, see the specific protocol's integration guide.

Device tab

Typically, you define the information on the **Device** tab in the Service Port controller setup interface and then configure the same information in the i-Vu® interface. Except for the **Home Network**, you can adjust the settings on the **Device** tab in the i-Vu® system.

NOTE Carefully plan your addressing scheme to avoid duplicating addresses. If third-party devices are integrated into the system, make sure your addresses do not conflict with their addresses.

The **Device > Home Network** tab is autopopulated based on what is set for the home network. Refer to the Network Parameters listed in the appropriate section based on the home network you selected.

| | |
|-----------------------------|---|
| Device Communication | The current BACnet BMS connection status |
| Auto Identity Scheme | <ul style="list-style-type: none"> • Not Autogenerated—you can enter a specific ID that is unique on the network. • Autogenerated—the Device Instance is automatically set. You cannot edit the field. |
| Device Instance | Contents and editability depend on your Auto Identity Scheme choice. |

Identification

| | |
|-------------------------|--|
| Auto Name Scheme | <ul style="list-style-type: none"> • Not Autogenerated—you can enter a specific name that is unique on the network. • Autogenerated—the Device Name is automatically set as the word "device + the Device Instance". For example, "device2423911". You cannot edit the field. |
| Device Name | Contents and editability depend on your Auto Name Scheme choice. |
| Location | You can enter an intuitive location for the device in the i-Vu® interface. This will be the device's display name when discovered through Find Devices . |
| Description | You can enter an intuitive description for the device in the i-Vu® interface. |

APDU

The following three fields refer to all networks over which the XT-LB communicates.

| | |
|---------------------------------|---|
| APDU Timeout | How many milliseconds the device waits before resending a message if no response is received. |
| APDU Segment Timeout | How many milliseconds the device waits before resending a message segment if no response is received. |
| Number of APDU Retries | The number of times the device resends a message. |
| Max APDU Length Accepted | The maximum length of a message or message segment that can be accepted by the BACnet device. The actual APDU length used for communication is automatically adjusted based on the capabilities of the enabled datalinks. |

Gig-E Port using BACnet/IPv4

| | |
|-----------------------------------|--|
| 802.1x Port Authentication | Enable the toggle switch to use 802.1x Port Authentication. Then, click Manage port certificates . |
| Manage port certificates | <p>Opens the 802.1x Port Authentication window where you can manage port certificates. Enter your Identity and User Private Key Password, then upload the CA certificate, user certificate, and user private key. Upon successful upload, a Certificate/key valid message appears next to the upload button.</p> <p>Once the connection has been authenticated, Port Authentication Status will change from Authentication Pending to Authenticated. This may take up to a minute.</p> |

IP Addressing

IPv4

| | |
|--|--|
| Address Mode | <p>Select the type of addressing the XT-LB is to use. See Addressing the XT-LB.</p> <p>Select Default IP Address to automatically assign the following to the XT-LB:</p> <ul style="list-style-type: none"> IP address = 192.168.168.x where x is the setting on the rotary switches in the range from 1 to 253 Subnet Mask = 255.255.255.0 Default Gateway = 192.168.168.254 <p>Select Custom Static if you have a permanent IP address which does not change and is usually obtained from the network administrator.</p> <p>Select DHCP if the network uses a DHCP server for IP addressing.</p> |
| Address | Displays the unique address of the device, if assigned. Editable only if using Custom Static addressing. |
| Subnet Mask | Displays the Subnet Mask of the device, if assigned. Editable only if using Custom Static addressing. |
| Default Gateway | Displays the Default Gateway of the device, if assigned. Editable only if using Custom Static addressing. |
| Inhibit BACnet/IP on loss of DHCP lease | <p>Inhibits BACnet communications via the IPv4 port when DHCP lease is not available or not renewed.</p> <p>NOTE Checkbox visible only if using DHCP addressing.</p> |

DNS

| | |
|---------------------|--|
| Edit Servers | <p>DNS servers are required if Internet host name resolution for BBMD, NTP, or BACnet/SC are needed. For DHCP application, enter in the DNS name servers provided by the building network administrator.</p> <ul style="list-style-type: none"> To add a server, click Add and then enter the Name Server Address field below. To delete a server in the table, select it in the list and click Delete. |
|---------------------|--|

Protocols

BACnet (bacnet://)

| | |
|--------------------------------|--|
| Advanced | |
| Back Off Period | How long (0:01 to 10:00 min:sec) the XT-LB waits before trying to connect to a device after the last failed connection attempt. The default is 5:00 min:sec. |
| Interpacket Delay | How long (0 milliseconds to 10 seconds) the XT-LB waits between sending request packets to the device. The default is 20 milliseconds. |
| Max Multiple Properties | The maximum number of properties that the XT-LB can read from or write to the device at one time. |

Primary BACnet/IP

| | |
|------------------------------------|--|
| Home network or Set as home | This is the network that communicates with the i-Vu® application. This sets the BACnet Address of the Device Object. To set this port as the home network, activate the toggle switch and click Set as home . To disable the port from use, deactivate the toggle switch. |
| Network Number | Specify a number for the BACnet/IP network or set to 0 if the port is not used. The network number is 0 by default. NOTE When downloaded from the i-Vu® application, these numbers match those set using SiteBuilder. |
| UDP Port | The port that the XT-LB will use for BACnet communication. If the XT-LB has two BACnet/IP networks communicating on the Gig-E port, confirm that the home network interface has the port number set to what the i-Vu® application will use for BACnet communication. |

Primary IPv4 Statistics

| | |
|--------------------------------|---|
| Reset statistics | Resets values to 0, which then resume accumulating. |
| Import BBMD Export BBMD | If this network interface will be used to access BBMDs, set the BBMD tables by using the BBMD buttons. <ul style="list-style-type: none"> • Import BBMD—Import BBMD tables in the specified format. See "Setting up BACnet Broadcast Management Devices (BBMDs)" in SiteBuilder or i-Vu® Help. • Export BBMD—Export the BBMD table that is in the controller to use for storage, viewing, or troubleshooting. |

Secondary BACnet/IP

| | |
|---|--|
| Enable for a secondary BACnet/IP network. | |
| Home network or Set as home | This is the network that communicates with the i-Vu® application. This sets the BACnet Address of the Device Object. To set this port as the home network, activate the toggle switch and click Set as home . To disable the port from use, deactivate the toggle switch. |
| Network Number | The network number for the secondary BACnet/IP network. This number must be unique for the system. NOTE When downloaded from the i-Vu® application, these numbers match those set using SiteBuilder. |

| | |
|------------------------------------|--|
| UDP Port | <p>The port that the XT-LB will use for BACnet communication.</p> <p>If the XT-LB has two BACnet/IP networks communicating on the Gig-E port, confirm that the home network interface has the port number set to what the i-Vu® application will use for BACnet communication.</p> <p>NOTE This UDP Port number must be different from the one used for the primary BACnet/IP port.</p> |
| Secondary IPv4 Statistics | |
| Reset statistics | Resets values to 0, which then resume accumulating. |
| Import BBMD Export BBMD | <p>If this network interface will be used to access BBMDs, set the BBMD tables by using the BBMD buttons.</p> <ul style="list-style-type: none"> • Import BBMD—Import BBMD tables in the specified format. See "Setting up BACnet Broadcast Management Devices (BBMDs)" in SiteBuilder or i-Vu® Help. • Export BBMD—Export the BBMD table that is in the controller to use for storage, viewing, or troubleshooting. |

Gig-E Port using BACnet/IPv6

| | |
|-----------------------------------|--|
| 802.1x Port Authentication | Enable the toggle switch to use 802.1x Port Authentication. Then, click Manage port certificates . |
| Manage port certificates | <p>Opens the 802.1x Port Authentication window where you can manage port certificates. Enter your Identity and User Private Key Password, then upload the CA certificate, user certificate, and user private key. Upon successful upload, a Certificate/key valid message appears next to the upload button.</p> <p>Once the connection has been authenticated, Port Authentication Status will change from Authentication Pending to Authenticated. This may take up to a minute.</p> |

IP Addressing

| | |
|---------------------|--|
| IPv6 | |
| Address Mode | <p>Select the type of addressing the XT-LB is to use. See Addressing the XT-LB.</p> <p>Select Default IP Address to automatically assign the following to the XT-LB:</p> <ul style="list-style-type: none"> • IP address = fd01::1 • Prefix length = 64 • Default Gateway = fe80::1 <p>Select Custom Static if you have a permanent IP address which does not change and is usually obtained from the network administrator.</p> <p>Select DHCP if the network uses a DHCP server for IP addressing.</p> |
| Address | Displays the unique address of the device, if assigned. Editable only if using Custom Static addressing. |

| IPv6 | |
|------------------------------------|--|
| Prefix Length | Value set between 10 and 128 to define the number of leftmost bits identifying the network portion of the address. |
| Default Gateway | Displays the Default Gateway of the device, if assigned. Editable only if using Custom Static addressing. |
| DNS | |
| Edit Servers | <p>DNS servers are required if Internet host name resolution for BBMD, NTP, or BACnet/SC are needed. For DHCP application, enter in the DNS name servers provided by the building network administrator.</p> <ul style="list-style-type: none"> To add a server, click Add and then enter the Name Server Address field below. To delete a server in the table, select it in the list and click Delete. |
| IPv6 Network Interfaces | |
| — IPv6 Network Interfaces — | System message showing the setting for IPv6, including the display name, interface name, set address, Link-Local, Zone Index, MAC address, etc.. |
| Protocols | |
| BACnet (bacnet://) | |
| Advanced | |
| Back Off Period | How long (0:01 to 10:00 min:sec) the XT-LB waits before trying to connect to a device after the last failed connection attempt. The default is 5:00 min:sec. |
| Interpacket Delay | How long (0 milliseconds to 10 seconds) the XT-LB waits between sending request packets to the device. The default is 20 milliseconds. |
| Max Multiple Properties | The maximum number of properties that the XT-LB can read from or write to the device at one time. |
| BACnet/IPv6 | |
| Home network or Set as home | This is the network that communicates with the i-Vu® application. This sets the BACnet Address of the Device Object. To set this port as the home network, activate the toggle switch and click Set as home . To disable the port from use, deactivate the toggle switch. |
| Network Number | <p>The network number for the BACnet/IPv6 network. This number must be unique for the system.</p> <p>NOTE When downloaded from the i-Vu® application, these numbers match those set using SiteBuilder.</p> |
| UDP Port | The port that the XT-LB will use for BACnet communication. |
| Multicast Address | Used for broadcasts on an IPv6 network using SLAAC. Defined by the building network administrator. |
| Multicast UDP Port | The port that the XT-LB will use for BACnet communication. |

| | |
|--|--|
| IPv6 Statistics | |
| Reset Statistics | Resets values to 0, which then resume accumulating. |
| Import BBMD Export BBMD | <p>If this network interface will be used to access BBMDs, set the BBMD tables by using the BBMD buttons.</p> <ul style="list-style-type: none"> • Import BBMD—Import BBMD tables in the specified format. See "Setting up BACnet Broadcast Management Devices (BBMDs)" in SiteBuilder or i-Vu® Help. • Export BBMD—Export the BBMD table that is in the controller to use for storage, viewing, or troubleshooting. |

Gig-E Port using BACnet/SC

NOTE Because BACnet/SC runs on your IP network, you must configure the router's IPv4 or IPv6 address information under **IP Addressing**. If the router will route to IP devices, you must enable the IP protocol in addition to the Secure Connect protocol.

The **BACnet/SC** sections provide hub status information and the ability to configure the items described in the table below for up to 2 Secure Connect ports.

| | |
|-----------------------------------|--|
| 802.1x Port Authentication | Enable the toggle switch to use 802.1x Port Authentication. Then, click Manage port certificates . |
| Manage port certificates | <p>Opens the 802.1x Port Authentication window where you can manage port certificates. Enter your Identity and User Private Key Password, then upload the CA certificate, user certificate, and user private key. Upon successful upload, a Certificate/key valid message appears next to the upload button.</p> <p>Once the connection has been authenticated, Port Authentication Status will change from Authentication Pending to Authenticated. This may take up to a minute.</p> |

IP Addressing

| | |
|---------------------|--|
| IPv4 | |
| Address Mode | <p>Select the type of addressing the XT-LB is to use. See Addressing the XT-LB.</p> <p>Select Default IP Address to automatically assign the following to the XT-LB:</p> <ul style="list-style-type: none"> • IP address = 192.168.168.x where x is the setting on the rotary switches in the range from 1 to 253 • Subnet Mask = 255.255.255.0 • Default Gateway = 192.168.168.254 <p>Select Custom Static if you have a permanent IP address which does not change and is usually obtained from the network administrator.</p> <p>Select DHCP if the network uses a DHCP server for IP addressing.</p> |
| Address | Displays the unique address of the device, if assigned. Editable only if using Custom Static addressing. |
| Subnet Mask | Displays the Subnet Mask of the device, if assigned. Editable only if using Custom Static addressing. |

| IPv4 | |
|------------------------------------|--|
| Default Gateway | Displays the Default Gateway of the device, if assigned. Editable only if using Custom Static addressing. |
| DNS | |
| Edit Servers | <p>DNS servers are required if Internet host name resolution for BBMD, NTP, or BACnet/SC are needed. For DHCP application, enter in the DNS name servers provided by the building network administrator.</p> <ul style="list-style-type: none"> To add a server, click Add and then enter the Name Server Address field below. To delete a server in the table, select it in the list and click Delete. |
| IPv6 | |
| Address Mode | <p>Select the type of addressing the XT-LB is to use. See Addressing the XT-LB.</p> <p>Select Default IP Address to automatically assign the following to the XT-LB:</p> <ul style="list-style-type: none"> IP address = fd01::1 Prefix length = 64 Default Gateway = fe80::1 <p>Select Custom Static if you have a permanent IP address which does not change and is usually obtained from the network administrator.</p> <p>Select DHCP if the network uses a DHCP server for IP addressing.</p> |
| Address | Displays the unique address of the device, if assigned. Editable only if using Custom Static addressing. |
| Prefix Length | Value set between 10 and 128 to define the number of leftmost bits identifying the network portion of the address. |
| Default Gateway | Displays the Default Gateway of the device, if assigned. Editable only if using Custom Static addressing. |
| DNS | |
| Edit Servers | <p>DNS servers are required if Internet host name resolution for BBMD, NTP, or BACnet/SC are needed. For DHCP application, enter in the DNS name servers provided by the building network administrator.</p> <ul style="list-style-type: none"> To add a server, click Add and then enter the Name Server Address field below. To delete a server in the table, select it in the list and click Delete. |
| IPv6 Network Interfaces | |
| — IPv6 Network Interfaces — | System message showing the setting for IPv6, including the display name, interface name, set address, Link-Local, Zone Index, MAC address, etc.. |

Protocols

BACnet (bacnet://)

| | |
|--|--|
| Advanced | |
| Back Off Period | How long (0:01 to 10:00 min:sec) the XT-LB waits before trying to connect to a device after the last failed connection attempt. The default is 5:00 min:sec. |
| Interpacket Delay | How long (0 milliseconds to 10 seconds) the XT-LB waits between sending request packets to the device. The default is 20 milliseconds. |
| Max Multiple Properties | The maximum number of properties that the XT-LB can read from or write to the device at one time. |
| Primary BACnet SC/Secondary BACnet SC | |
| Home network or Set as home | This is the network that communicates with the i-Vu® application. This sets the BACnet Address of the Device Object. To set this port as the home network, activate the toggle switch and click Set as home . To disable the port from use, deactivate the toggle switch. |
| Network number | Specify a number for the BACnet/SC network or set to 0 if the port is not used. The network number is 0 by default. NOTE When downloaded from the i-Vu® application, these numbers match those set using SiteBuilder. |
| Address | The Virtual MAC address of the XT-LB on the BACnet/SC network. It is the hex representation of the Device Instance found on the Connections > Device tab. NOTE If the Device ID of the XT-LB is zero (not recommended), a '01' is assigned to the third octet of this address because zero addresses are not valid on a BACnet/SC network. |
| Connection State | The status of the XT-LB's connection as a client on the BACnet/SC network. |
| Primary Hub URI | Web address used to connect to the primary hub. Format options (address can be an IP address or DNS name): <ul style="list-style-type: none"> • wss://address (if using standard port 443) • wss://address:port NOTE If you must use a proxy to reach the hub, enter proxy information on the Advanced > Network tab. |
| Primary Hub Status | The state of the primary hub communication. |
| Fallover Hub URI | Web address used to connect to the optional failover hub. Format options (address can be an IP address or DNS name): <ul style="list-style-type: none"> • wss://address (if using standard port 443) • wss://address:port NOTE If you must use a proxy to reach the hub, enter proxy information on the Advanced > Network tab. |
| Fallover Hub Status | The state of the failover hub communication. |

Advanced

| | |
|---|---|
| Is Failover Hub? | Indicates if being used as a failover hub. |
| NOTES | |
| <ul style="list-style-type: none"> A XT-LB can serve as a failover hub, but not as a primary hub. A supported BACnet/SC network requires a virtual or cloud-hosted hub to be used as the primary BACnet/SC hub. Using a XT-LB as a failover hub is supported for up to 10 BACnet/SC router connections. For BACnet/SC networks with more than 10 router connections, purchase an additional BACnet/SC Virtual Hub to use as a failover hub. | |
| Listening Connection Type | When set as a failover hub, select interface type used to listen for connections. |
| Server Port | When set as a failover hub, enter the port on which the hub will be listening. |
| URIs | When set as a failover hub, this is the web address used by network devices to connect to the hub. The URI is derived from the IP Port configured on the Connections > Gig-E Port tab. |
| Minimum Reconnect Time | Initial number of seconds to wait before retrying a connect to a hub which increases with each failure. |
| Maximum Reconnect Time | Maximum number of seconds to wait between connection retries to a hub. |
| Connection Wait Timeout | Number of seconds to wait for a hub to reply to a connection request. |
| Disconnect Wait Timeout | Number of seconds to wait for a hub to reply to a disconnect request. |
| Initiating Heartbeat Interval | Number of seconds to wait to send a heartbeat. |
| Accepting Heartbeat Interval | Number of seconds to wait to receive a heartbeat. |
| Primary SC Statistics Secondary SC Statistics | |
| Reset statistics | Resets values to 0, which then resume accumulating. |
| Manage certificates | See "To create or replace a BACnet/SC device's operational certificate" in the <i>BACnet/SC Setup Guide</i> for instructions on how to create the XT-LB's operational certificate, signed by the BACnet/SC network's Certificate Authority. |

Gig-E Port using BACnet/Ethernet

| | |
|-----------------------------------|--|
| 802.1x Port Authentication | Enable the toggle switch to use 802.1x Port Authentication. Then, click Manage port certificates . |
| Manage port certificates | <p>Opens the 802.1x Port Authentication window where you can manage port certificates. Enter your Identity and User Private Key Password, then upload the CA certificate, user certificate, and user private key. Upon successful upload, a Certificate/key valid message appears next to the upload button.</p> <p>Once the connection has been authenticated, Port Authentication Status will change from Authentication Pending to Authenticated. This may take up to a minute.</p> |



Protocols

BACnet (bacnet://)

| Advanced | |
|---|--|
| Back Off Period | How long (0:01 to 10:00 min:sec) the XT-LB waits before trying to connect to a device after the last failed connection attempt. The default is 5:00 min:sec. |
| Interpacket Delay | How long (0 milliseconds to 10 seconds) the XT-LB waits between sending request packets to the device. The default is 20 milliseconds. |
| Max Multiple Properties | The maximum number of properties that the XT-LB can read from or write to the device at one time. |
| BACnet/Ethernet | |
| Home network or Set as home | This is the network that communicates with the i-Vu® application. This sets the BACnet Address of the Device Object. To set this port as the home network, activate the toggle switch and click Set as home . To disable the port from use, deactivate the toggle switch. |
| Network Number | The network number for the BACnet/Ethernet network. This number must be unique for the system. NOTE When downloaded from the i-Vu® application, these numbers match those set using SiteBuilder. |
| MAC Address | A factory-assigned Ethernet MAC Address |

Port S1 and Port S2

| Port S1 | |
|-------------------------------------|---|
| Port S1 BACnet/MSTP | Enable for a BACnet/MSTP network. |
| Auto Generate Network Number | If checked, network number is automatically set to ((IP network number + rotary switch address) x 10) + 0. Uncheck to set the network number manually using Custom Static Address Mode . |
| Network Number | The network number is 0 by default. Filled in automatically if Autogenerate Network Number is checked. NOTE When downloaded from the i-Vu® application, these numbers match those set using SiteBuilder. |
| MAC Address | You set the address for Port S1, which must be unique for the system. |
| End of Network | Indicates status of the XT-LB's End of Net? switch. |
| Max Master | To increase MS/TP performance, enter the highest address used on the MS/TP network for a master controller. This number must be less than or equal to 127. |

| | |
|-------------------------------------|---|
| Max Info Frames | <p>This is the maximum number of information messages a controller may transmit before it must pass the token to the next controller. Valid values are 1 to 255.</p> <p> TIP Set Max Info Frames to a number in the range 20 to 100 so that the XT-LB does not become a bottleneck for traffic being routed from a high-speed network to the slower MS/TP network.</p> |
| Baud Rate | Set this to a baud rate that all other devices on the MS/TP network are set to. Select 9600, 19200, 38400, 57600, 76800, or 115200. |
| Port S1 MSTP Statistics | Shows statistics for the port. Click Reset statistics to refresh the data. |
| Port S1 BACnet/ARCNET | |
| Auto Generate Network Number | <p>If checked, network number is automatically set to ((IP network number + rotary switch address) x 10) + 0.</p> <p>Uncheck to set the network number manually using Custom Static Address Mode.</p> |
| Network Number | <p>The network number is 0 by default. Filled in automatically if Autogenerate Network Number is checked.</p> <p>NOTE When downloaded from the i-Vu® application, these numbers match those set using SiteBuilder.</p> |
| MAC Address | You set the address for Port S1, which must be unique for the system. |
| End of Network | Indicates status of the XT-LB's End of Net? switch. |
| Port S1 ARCNET Statistics | Shows statistics for the port. Click Reset statistics to refresh the data. |
| Port S2 | |
| Port S2 BACnet/MSTP | Enable for a BACnet/MSTP network. |
| Auto Generate Network Number | <p>If checked, network number is automatically set to ((IP network number + rotary switch address) x 10) + 3.</p> <p>Uncheck to set the network number manually using Custom Static Address Mode.</p> |
| Network Number | <p>The network number is 0 by default. Filled in automatically if Autogenerate Network Number is checked.</p> <p>NOTE When downloaded from the i-Vu® application, these numbers match those set using SiteBuilder.</p> |
| MAC Address | You set the address for Port S2, which must be unique for the system. |
| End of Network | Indicates status of the XT-LB's End of Net? switch. |
| Max Master | To increase MS/TP performance, enter the highest address used on the MS/TP network for a master controller. This number must be less than or equal to 127. |
| Max Info Frames | <p>This is the maximum number of information messages a controller may transmit before it must pass the token to the next controller. Valid values are 1 to 255.</p> <p> TIP Set Max Info Frames to a number in the range 20 to 100 so that the XT-LB does not become a bottleneck for traffic being routed from a high-speed network to the slower MS/TP network.</p> |
| Baud Rate | Set this to a baud rate that all other devices on the MS/TP network are set to. Select 9600, 19200, 38400, 57600, 76800, or 115200. |
| Port S2 MSTP Statistics | Shows statistics for the port. Click Reset statistics to refresh the data. |

Local Network tab


Use the **Local Network** tab to:

- Discover 256 devices on a single network at a time.
- Discover both configured or unconfigured devices on this controller's network.
- See the number of devices discovered and the total number on the network.
- Identify the controller that has had its DSC button pressed.
- Export the **Local Devices** that are present in the table (limited to 100) to a .csv file.
- Set a device's **Mode**, **Address**, and **Location**.
- Assign IP addresses to multiple devices at one time.
- Prompt an LED to blink on a device.

| Port S1/Port S2 | |
|------------------------|---|
| Address Mode | <p>Select the type of addressing the XT-LB is to use. See Addressing through the USB service port.</p> <p>Select Custom Static if you have a permanent IP address which does not change and is usually obtained from the network administrator.</p> <p>Select DHCP if the network uses a DHCP server for IP addressing.</p> |
| Address | Displays the unique address of the device, if assigned. Editable only if using Custom Static addressing. |
| Subnet Mask | Displays the Subnet Mask of the device, if assigned. Editable only if using Custom Static addressing. |
| Default Gateway | Displays the Default Gateway of the device, if assigned. Editable only if using Custom Static addressing. |
| Device Instance | <p>Displays the IP address of the device, if assigned. You can edit the address only if the device is set to Custom Static.</p> <p>To auto-assign multiple sequential addresses, select the devices, enter the beginning address, and click Assign.</p> |
| Network Number | Displays the network number of the lead device. |

A device that is new from the factory or has not been previously configured with an IP address, can always be configured using the **Local Devices** table. However, once you have assigned a valid IP address, you have up to 24 hours to make any other changes. After 24 hours, the fields are not editable and the device is **Locked**.

You can unlock a device for 24 hours by either pressing the DSC button on the XT-LB controller or by using the i-Vu® application. In the i-Vu® navigation tree, right-click the XT-LB, select **Driver Properties** and go to **Driver > Settings** tab > **Local Network Configuration**. Check **Allow Local Network Configuration from other devices on the local network for 24 hours** and click **Accept**.



To discover devices on a network

- 1 To address a network of devices, you must first select one controller and set the **IP Address**, **Subnet Mask**, and **Default Gateway** on the **Ports** tab.

NOTE This controller is referred to as the connected controller.

- 2 On the **Local Network** tab, at the top of the page, verify that the connected controller's **Mode**, **IP Address**, **Subnet Mask**, and **Default Gateway** are accurate.
- 3 Use the following settings to define the devices that you want to discover in the **Local Devices** table.

| Local Devices | |
|--------------------------|--|
| Only Unconfigured | When checked, only discovers devices that do not have an IP address and are linked to the connected controller's network. When unchecked, discovers both configured and unconfigured devices. |
| Clear All | Erases all information in the table. |
| Export | Creates .csv file of the data in the table, limited to 256 devices. |

- 4 Click **Discover** to populate the table with your devices that are on a single network communicating with the connected controller.

Sequential IP addressing

- 1 Follow the above steps to **Discover** devices.
- 2 In the **Select** column, click the checkbox for the devices you want to assign addresses to.
NOTE To change the IP Address, the device's **Mode** must be **Custom Static**.
- 3 Enter the starting IP address under **Address** and click **Assign** to automatically assign sequential IP addresses.

NOTE Changes in the Local Network interface are pending and need to be submitted. A warning will appear when navigating away with pending changes.

There are different workflows for using the **Local Devices** table to address your devices, depending on the information you have from the installation. See *To address when you know the serial numbers* or *To address when you do not know the serial numbers*.

| Local Devices table | |
|---------------------|--|
| Select | Check to select devices for: <ul style="list-style-type: none"> • Changing the Mode • Resolving a Mismatch • Auto-assigning an IP Address NOTE You cannot select devices with a lock symbol. |
| MAC | Ethernet MAC address of device |
| Model | Displays the model number of discovered devices |
| Serial# | The discovered devices are in order by serial number. NOTE To change how the rows are sorted, click a different column heading. |

| Local Devices table | |
|---------------------|--|
| Mode | <p>To change the Mode:</p> <ol style="list-style-type: none"> 1 Select the devices you want to change. 2 Select one of the following IP addressing modes: <ul style="list-style-type: none"> • Default IP - Devices with rotary switches that are used when autogenerating the address (if applicable) • Custom Static - A permanent IP addresses which does not change and is usually obtained from the network administrator • NOTE Selecting this automatically sets the device's subnet and default gateway to match the connected controller. • DHCP - Allows the DHCP server to automatically assign an IP address 3 Click the Set button. |
| Address | <p>Displays the IP address of the device, if assigned. You can edit the address only if the device is set to Custom Static.</p> <p>To auto-assign multiple sequential addresses, select the devices, enter the beginning address, and click Assign.</p> |
| Location | You can describe the location of the device or any other helpful information. |
| Mismatch | <p>A Mismatch occurs when the connected controller's mode is set to Custom Static and a discovered device's subnet and default gateway do not match the connected controller. The incorrect addresses are shown with SN for subnet and GW for default gateway.</p> <p>To resolve a mismatch, select the device(s) by clicking the Select checkbox and then clicking the Resolve button. The subnet mask and default gateway addresses of the selected devices change to match the connected controller.</p> |
| Status | <p>The following are the results of changing Mode, Address, Location, or pressing Blink:</p> <ul style="list-style-type: none"> • Success - Successful operation • No Response - Device is not communicating • Device Locked - Device must be unlocked before you can make any changes using the Local Devices table. You can unlock the XT-LB by pressing the DSC button on the device or by using the i-Vu® application. (See instructions above.) <p>NOTE The status of a device changes to locked 24 hours after unlocking it.</p> <ul style="list-style-type: none"> • Failure - A conflict between the device and the information entered |
| Blink | <p>Click the Blink button to prompt the Locator LED to flash for 15 seconds, allowing you to verify the controller's physical location. After flashing, whenever the actuator moves, the LED rotates in the same direction. LED rotation is automatically disabled after 1 hour and can be re-enabled by pressing the Blink button again.</p> <p>At the same time, the Sys and Net LEDs blink white, once per second for 10 seconds, and then stop.</p> <p>NOTES</p> <ul style="list-style-type: none"> • The blue dot appears when you Blink a device. • You can Blink a locked device. |

NOTE If a device's IP address is the loopback address (127.0.0.1), it is considered unconfigured and unlocked. The IP address, subnet mask, and default gateway fields are blank in the **Ports** and **Local Network** tabs. You can configure it in the **Local Devices** table.

Licensing tab

| Status | |
|-----------------------------------|--|
| Activate temporary license | Use for initial setup. A temporary license is valid for 30 days. |
| Import license | Upload a .device-license file to a controller to increase the number of permitted integration points as determined by protocol or add a new feature. |
| License Status | Current status of the license. |
| Features | |
| Enabled | Enable the toggle switch to enable the feature. |
| Points | |
| Point Distribution | Shows how points are distributed across protocols. |
| License Distribution | A negative value in the Remaining column indicates how many more points are required to restore proper function to the controller. |

Advanced tabs

Security tab

| Configuration Access | |
|--|--|
| Disable Service Ports | When checked, disables all communication through the Service Port. You can only configure the XT-LB in the i-Vu® application or Field Assistant. |
| Allow Configuration on Service Port | Enables access to the controller setup pages through the Service Port. |
| Allow Configuration on Gig-E Port | Enables access to the controller setup pages through the network that the Gig-E Port is connected to. See Connecting to the XT-LB through the Gig-E Port. NOTE You must first set a password in the i-Vu® application. |
| Disable Network Port Configuration via BACnet | When checked, disables Network Port Objects properties such as network numbers from being written to via BACnet. |
| Enable HTTP Redirect | When enabled allows http connections to the local webserver, but redirects automatically to https. When disabled the webserver is only available via https. |
| Allow Remote Management of IP Configuration | Enables you to configure IP settings remotely through tunneled Enhanced Access Protocol commands. NOTE The Address Mode must be set to Custom Static . |
| Allow Local Network Configuration from other Devices on the Local Network for 24 Hours. | Allows Local Network Configuration for 24 hours. It is the same as pressing the DCS button on the controller. |

| | |
|---|---|
| Device Unlock Time Remaning | Displays the amount of time that the device will be unlocked. |
| TouchScreen Control | |
| TouchScreen Schedule Edit Enable | Check to enable. |
| BACnet Whitelist for Gig-E | |
| Enable BACnet Whitelist | Check to enable. The list of IP addresses displayed on the page are the IP addresses the device is allowed to communicate with. Must include the server IP address. |
| Enable Private IP Ranges | Permits communication with any BACnet device configured with a private IP address. |
| IPv4 | List of IPv4 ranges that can be used in whitelisting |
| IPv6 | List of IPv6 ranges that can be used in whitelisting |
| Whitelist | |
| Enable Custom Range Whitelist | Check to enable. |
| Address Ranges | Click Add to enter information or Delete to remove existing information. |

Alarms tab

Use this tab to configure settings for the following Alarms:

- **Controller Halted**
- **Dead Controller Timeout**
- **Excessive COV**
- **BACnet/SC Certificate Expiration**
- **Locked I/O**
- **Point Count Exceeds Licenses**
- **Duplicate Address Alarm**
- **Program Unexpectedly Stopped**
- **Program Manually Stopped**
- **Port Authentication Expiration**

| | |
|-----------------------------------|---|
| Enable To Off-Normal Event | Clear this checkbox to disable Alarm or Return to off-normal messages of this type from the XT-LB. |
| Enable to Normal Event | Clear this checkbox to disable Alarm or Return to normal messages of this type from the XT-LB. |
| Time Delay | Specifies the delay between the onset of the Off-Normal condition and the reporting of the alarm to the i-Vu® application. |
| Description | Short message shown when this type of alarm is generated. |
| Notification Class | <p>A BACnet alarm's Notification Class defines:</p> <ul style="list-style-type: none"> • Alarm priority for Alarm, Fault, and Return to Normal states • Options for BACnet alarm acknowledgment • Where alarms should be sent (recipients) <p>Alarms in the i-Vu® application use Notification Class #1. The i-Vu® application is automatically a recipient of these alarms.</p> |
| Object Name | A unique alphanumeric string that defines the BACnet object. |
| Warning Threshold | <p>If a certificate is within this number of days of expiring, it will appear yellow in the Certificate Management table.</p> <p>A weekly alarm will be triggered in the i-Vu® application when one of the XT-LB's BACnet/SC certificates is in this state.</p> |
| Critical Threshold | <p>If a certificate is within this number of days of expiring, it will appear red in the Certificate Management table.</p> <p>A daily alarm will be triggered in the i-Vu® application when one of the XT-LB's BACnet/SC certificates is in this state.</p> |



Notification Class tab

A BACnet alarm's Notification Class defines:

- Alarm priority for Alarm, Fault, and Return to Normal states
- Options for BACnet alarm acknowledgment
- Where alarms should be sent (recipients)

Alarms in the i-Vu® application use Notification Class #1. The i-Vu® application is automatically a recipient of these alarms.

| | |
|--------------------------------------|---|
| Notification Class Recipients | <p>The first row in this list is from the i-Vu® application. Do not delete this row. Click Add if you want other BACnet devices to receive alarms associated with this Notification Class.</p> <p>NOTE Additional entries in this table may be lost after a download.</p> |
|--------------------------------------|---|

| | |
|---|--|
| Recipient Type | <p>Select Recipient Device for device recipients that support dynamic binding. Complete the Recipient Device field if you are using this recipient type.</p> <p>Select Recipient Address (static binding) for either of the following:</p> <ul style="list-style-type: none">• Third-party BACnet device recipients that do not support dynamic binding• When you want alarms to be broadcast (you must uncheck Issue Confirmed Notifications). This use is rare. <p>Complete the Network Number and MAC Address fields if you are using this recipient type.</p> |
| Recipient Device | Type the Device Instance from SiteBuilder (or from the network administrator for third-party devices) in the # field. |
| Network Number | <p>Specify the number of the BACnet network on which to send the notification.</p> <p> TIP For the home network, this can be set to 0.</p> |
| MAC Address | MAC address of the recipient software or device. |
| Issue Confirmed Notifications | Select to have a device continue sending an alarm message until it receives delivery confirmation from the recipient. |
| | |
| Transitions to Send | Uncheck the types of alarms you do not want the recipient to receive. |
| Off Normal | BACnet priority for Alarms. |
| Fault | BACnet priority for Fault messages. |
| Normal | BACnet priority for Return-to-normal messages. |
| | |
| Days and Times to Send | |
| Monday to Sunday From Time To Time | Select days and times during which the recipient will receive alarms. |
| Process Identifier | Change for third-party devices that use a BACnet Process Identifier other than 1. The i-Vu® application processes alarms for any 32-bit Process Identifier. |
| | |
| Acknowledgments Required | |
| To Fault Ack Required | <p>Specifies whether alarms associated with this Notification Class require a BACnet Acknowledgment for Off-Normal, Fault, or Normal alarms.</p> <p> TIP You can require operator acknowledgment for an Alarm or Return-to-normal message (stored in the i-Vu® database). In the i-Vu® interface on the Alarm > Enable/Disable tab, change the acknowledgment settings for an alarm source or an alarm category.</p> |
| To Normal Ack Required | |
| To Off-Normal Ack Required | |
| | |
| Priority | |
| To Fault Priority | BACnet priority for Fault messages. |
| To Normal Priority | BACnet priority for Return-to-normal messages. |

| | |
|-------------------------------|---|
| To Off Normal Priority | BACnet priority for Alarms. |
| Identification | |
| Notification Class | <p>A BACnet alarm's Notification Class defines:</p> <ul style="list-style-type: none"> • Alarm priority for Alarm, Fault, and Return to Normal states • Options for BACnet alarm acknowledgment • Where alarms should be sent (recipients) <p>Alarms in the i-Vu® application use Notification Class #1. The i-Vu® application is automatically a recipient of these alarms.</p> |
| Object Instance | The instance number of this BACnet Notification Class object. It must be unique within the BACnet Device that contains it. |
| Object Name | The alpha-numeric name of this BACnet Notification Class object. |
| Description | The description of this BACnet Notification Class object. |

Controller Clock tab

The Controller Clock page provides the following information plus the items described in the table below:

- Date Format
- Local Date
- Time Format
- Local Time
- Time Zone Offset
- Daylight Saving Status
- Offset for Daylight Saving

| | |
|-------------------------------|--|
| Advanced Clock Options | |
| Clock Fail Date | Date the XT-LB uses when its real-time clock is invalid. |
| Clock Fail Time | Time the XT-LB uses when its real-time clock is invalid. |

Network Time Protocol

To define an NTP server to use for time synchronization:

- 1 Click **Add**.
- 2 Define **Server** by one of the following:
 - **IP Address**
 - **Host name**
 - **Fully qualified domain name**

NOTE DNS has to be set up on the **Gig-E Port** tab in order to use names on NTP.

- 3 Check the **Enable** box.
- 4 Click **Restart**.

BACnet Time Synchronization

Time Synchronization Sensitivity

When the XT-LB receives a time sync request, if the difference between the XT-LB's time and the time sync's time is greater than this field's value, the XT-LB's time is immediately changed. If the difference is less than this field's value, the XT-LB's time is slowly adjusted until the time is correct.

Time Broadcaster will synchronize time every

If you have third-party BACnet devices on one of the XT-LB's networks, you can have the XT-LB send a BACnet time sync to those devices at the interval you define in this field.

Time Synchronization Recipients

To define third-party BACnet devices as Time Synchronization Recipients:

- 1 Click **Add**.
- 2 Select **Recipient Type**:
 - **Device ID**
 - **Address**
 - **Local Broadcaster**
 - **Global Broadcaster**
- 3 Enter the **Recipient Device** information.
- 4 Click **Accept**.

Color Cache tab

| | |
|-----------------------------|---|
| Cache Group Number | For use by the i-Vu® system |
| Peer Caching Enabled | This checkbox is checked for the router that was defined in SiteBuilder as the peer caching router. |

| | |
|--------------------------------|--|
| Disable Color Cache | <p>Clear (enable) to improve responsiveness of retrieving thermographic colors and prime values from networked controllers. See <i>EIKON® Help</i> for more information regarding thermographic colors and prime values.</p> <p>Select (disable) to reduce network traffic to third-party (non-color-supporting) devices.</p> <p>NOTE Selecting this checkbox also disables Dead Controller Timeout alarms.</p> |
| Dead Controller Timeout | <p>After this period (minutes:seconds) of non-response from a peer Carrier controller, the XT-LB sends an alarm to the server as defined by the Dead Controller Timeout alarm configuration.</p> |
| Reports Colors To | <p>The BACnet Object Identifier of the router that was defined in SiteBuilder as the peer caching router.</p> |

Diagnostics tab

This page allows you to:

- Access additional diagnostic tools with assistance from Carrier Controls System Support
NOTE You can only access this tool in the controller setup pages connecting through the Service Port.
- Download log files
- Blink the device's Locator LED
- Capture network communication and then download the capture file for troubleshooting
- View network diagnostics

| | |
|--------------------------------|--|
| Technical Support Tools | <p>Enable the toggle switch to view the Challenge key. Send the displayed Challenge key to the Carrier Controls System Support representative who will provide an Activation Key for you to enter.</p> <p>Additional tools will be displayed to help Carrier Controls System Support troubleshoot issues. Enabling these tools has security implications, therefore they are automatically disabled after 2 hours.</p> |
| Logs | <ul style="list-style-type: none"> • Retrieve all — Downloads all logs in a zip file to your computer • Specific log — Allows you to choose to download the application logs (by date) or the system logs • Delete all — Deletes all logs, including current logs |
| Blink | <p>To physically identify a device that is displayed on the Local Devices table, click Blink to light the Locator LED in the actuator release button.</p> |

| | |
|---|---|
| Packet Capture Primary/secondary BACnet/IP BACnet/IPv6 BACnet/Ethernet Primary/secondary BACnet SC Port S1 BACnet/MSTP Port S1 BACnet/ARCNET Port S2 BACnet/MSTP | <p>This allows you to capture network communication on the corresponding port and then download the capture file for troubleshooting.</p> <ul style="list-style-type: none"> • Start now — Start a capture immediately. The capture runs until you click Stop or until it reaches the file size limit, whichever occurs first. • Start continuous — Start a continuous capture immediately. The capture stores the most recent 5MB of captured data and runs continuously until you click Stop. <p>NOTES</p> <ul style="list-style-type: none"> ○ The number of continuous captures that you can run simultaneously is limited. ○ Continuous captures are disabled when the XT-LB is in a low-memory state. • Schedule — Schedule a packet capture to automatically run at a future date and time of your choosing. Choose whether the capture stops until it reaches the file size limit or specify a duration of time for the capture to run. • Capture Data of Type — Choose whether to capture all packets or only BACnet packets (BACnet MS/TP only). • Get capture file — Download the capture file once you have stopped the capture or the capture has reached the file size limit. <p>NOTE Capture files have a 25MB limit. If you need a larger capture, you must attach a computer running Wireshark. Please see the <i>Carrier BACnet Integration Guide</i> for more details.</p> <p>Please contact the <i>Carrier Training Department</i> regarding Networking I/II classes for more details on using packet captures for diagnostics and troubleshooting.</p> |
| Network Diagnostics | <p>Click Reset statistics to reset values to 0, which then resume accumulating.</p> <p>See <i>Appendix - Module Status field descriptions</i> (page 58) for descriptions of these fields.</p> |

Network tab

| | |
|-------------------------|---|
| Device Host Name | <p>Device name identified on the IP network. Primarily used for DHCP to help the IT administrator identify this device on their network.</p> <p>Characters allowed are:</p> <ul style="list-style-type: none"> • ASCII letters from A to Z, lower or upper case • 0 to 9 • hyphen <p>A Host Name may not start with a hyphen or have only numerals</p> |
| Enable Proxy | <p>Enable this checkbox if the communication interface needs to get through a proxy firewall to communicate out to other networks.</p> |

| | |
|-----------------------------|--|
| Proxy Server Address | Set the IP address of the proxy host. NOTE If you have a DNS set up on the Gig-E Port tab, you can use the DNS name of the proxy server here. |
| Proxy Port | Set the port for communication on the proxy host. |
| Proxy Username | Set a username if required to authenticate on the proxy server. |
| Proxy Password | Set a password if required to authenticate on the proxy server. |
| No Proxy For | Set addresses that do not require passing through the proxy to communicate. These addresses are typically exempt from the proxy requirements. |

Control Programs tab

The Control Programs tab provides the following information as well as the items described in the table below.

- Number of control programs running
- Memory load percentage
- Estimated memory usage
- Maximum memory available
- Execution rate

BACnet COV Throttling

Enable COV Throttling

Under normal circumstances, COV Throttling should be enabled to prevent excessive network traffic if an object's COV Increment is set too low. See EXCEPTION below.

When enabled, if an object generates excessive COV broadcasts (5 updates in 3 seconds), the driver automatically throttles the broadcasts to 1 per second. Also, if the object's value updates excessively for 30 seconds, an alarm is sent to the i-Vu® application listing all objects that are updating excessively. A Return-to-normal alarm is sent only after all objects have stopped updating excessively.

EXCEPTION: In rare circumstances, such as process control, a subscribing object may require COV updates more frequently than once per second. For these situations, clear this checkbox, but make sure that your network can support the increased traffic. You will also need to disable the **Excessive COV** alarms under the driver's **Common Alarms**.

Trend Sampling

Collect a Daily Midnight Sample For All COV Points

For values that change infrequently, select to verify at midnight daily that the point is still able to communicate trend values.

Protocols tab

Select the tab for the protocol you are integrating and use the toggle switch to enable the protocol. See the specific protocol's integration guide for information on configuring the integration.

IoT tab

Enable the toggle switch to use the protocol.

NOTE For communication with third-party protocols, see the specific protocol's integration guide.

Managing third-party points and feature licenses

If a controller's remaining number of third-party integration points is a negative value, you must add additional points to the controller to restore proper function. Points are added in the form of a license.

You can also upload a license for a feature in the driver properties or controller setup interface in the **Licensing** tab.

To add more points or a feature to a controller, you must:

- purchase the points or feature in the E-Store
- generate a .requirements file in the i-Vu® application
- assign the points from your .requirements file and download the license on the Hardware License Manager page on the Carrier Community Portal website
- apply the license to your controllers

See the sections below.

To view points, license, and feature status

You can view feature status in the controller setup interface or driver properties under **Licensing** tab > **Features**.


You can view point license status information for a controller in two ways:

For a specific controller—in the controller setup interface or driver properties, go to **Licensing** tab > **Points**.

For one or more controllers—in the i-Vu® interface, use the navigation tree to select the controllers for which you want to view data. Then click **Reports** > **Point License Requirements**.

To generate a requirements file

A .requirements file specifies the number of licensed points needed for a given protocol in the controller. This file is used in the Hardware Point Manager to generate licenses.

- 1 In the i-Vu® interface, click , then select **System Options** > **License Administration**.
- 2 Under **Licenses for Controllers**, use the tree to select the areas or individual controllers for which you want to generate a .requirements file. Selecting an area automatically selects each license-supported controller within that area.
- 3 Click **Generate Requirements**.



TIP You can also generate a .requirements file on the **Point License Requirements** report page. After running the report, click **Generate Requirements**.

To download a license

You can download either a feature license or controller license. To download a controller license, you must upload a .requirements file and configure the points you have purchased.

To download a controller license

- 1 Go to the Carrier Partner Community website and select **Order Management > Hardware License Manager**.
- 2 Click the **Order Number** from which you want to assign points. If you do not have any work orders, you must purchase more points in the E-Store.
- 3 Click **Upload New Requirements** and select the .requirements file you previously downloaded from the i-Vu® application. Then, click **Load Requirements**.
- 4 In the **Points Assignment** tab, click **Edit Points**. Use the drop-down menu to select the number of packs to assign. Each pack contains a certain number of points.
- 5 Click **Save**, then click **Review**, then click **Submit**.
- 6 Click **Download** to download the .device-license files. These files are placed in a zip file.



TIP The .device-license file's file name is the serial number of the controller.

To download a feature license

- 1 Go to the Carrier Partner Community website and select **Order Management > Hardware License Manager**.
- 2 In the **Features** tab, locate the feature in the table and check **Enable**.
- 3 Click **Review**.


To apply a license to a controller

You can apply a license to each controller individually or to multiple controllers at once.

For a specific controller

- 1 In the controller setup interface or driver properties, go to the **Licensing** tab.
- 2 Under **Status**, click **Import license** and upload the .device-license or zip file.


For one or more controllers

- 1 In the i-Vu® interface, click , then select **System Options > License Administration**.
- 2 Under **Licenses for Controllers**, select an area in the tree containing the controller(s) you want to apply the license(s) to. The system applies the license to any controller in the selected area that the .device-license or zip file has a license for.

- 3 Click **Choose File** and select the .device-license or zip file you downloaded from the Hardware License Manager. To automatically apply to controllers, check **Apply to Controllers**. Then, click **Upload**.
- 4 If you did not check **Apply to Controllers** in the previous step, click **Apply to Controllers**.

Troubleshooting

LEDs



NET (Network Status) Tricolor LED

| Color | Pattern | Condition | Message in Module Status | Possible Solutions |
|-------|---------|--|----------------------------------|---|
| Red | On | Ethernet connection problem | No Ethernet Link | <ul style="list-style-type: none"> Connect Ethernet Cable Check other network components |
| Red | 1 blink | One of the following BACnet/IP (Ethernet) DLL reporting issue: <ul style="list-style-type: none"> Unable to create tasks Unable to open socket for BACnet port | BACnet/IP error | Cycle power |
| Red | 2 blink | Current default IP address does not match the current rotary switch setting | Default IP address mismatch | <ul style="list-style-type: none"> Use the controller setup Ports tab to set the IP address Cycle power to accept new IP address Change rotary switches to match current default IP address |
| Red | 4 blink | Unable to get an IPV4 address using DHCP or an IPV6 address using SLACC | DHCP or SLAAC error | Check with network administrator |
| Red | 5 blink | NAT configuration problem | NAT Configuration Error Detected | Check global IP address or hostname |

NET (Network Status) Tricolor LED


| Color | Pattern | Condition | Message In Module Status | Possible Solutions |
|-------|---------|---|---|--|
| White | 1 blink | Unable to connect to BACnet/SC Hub | BACnet/SC Not Connected | <ul style="list-style-type: none"> Configuration issue – ex: no URL for hub Certificate issue No hub connection |
| White | On | Unable to connect to BACnet/SC Hub, but connection to failover hub was successful | BACnet/SC Connected to failover hub | Fix any issues present with the primary hub connection |
| Blue | On | One of the following issues: <ul style="list-style-type: none"> Port communication firmware did not load properly Port communication firmware is not running Invalid protocol selected | ARCNET/MSTP firmware error | <ul style="list-style-type: none"> Change rotary switch to select valid protocol Cycle power |
| Blue | 1 blink | Invalid address selected for protocol | Invalid address selection for ARCNET/MSTP | Change rotary switch to valid address |
| Blue | 2 blink | Router has same MAC address as another connected device | Duplicate address on ARCNET/MSTP | Change rotary switch to unique address |
| Blue | 3 blink | Router is the only device on the network | No other devices detected on ARCNET/MSTP | <ul style="list-style-type: none"> Check that network cable is connected properly Check that baud rate is correct |
| Blue | 4 blink | Excessive errors detected over 3 second period | Excessive communication errors on ARCNET/MSTP | <ul style="list-style-type: none"> Check that network cable is connected properly Check that baud rate is correct |
| Blue | 5 blink | ARCNET traffic overload possibly due to circular router or excessive COVs (change of values) | Event System Error - FPGA RX FIFO full | <ul style="list-style-type: none"> Check the network configuration for a circular route Increase the time between COVs to reduce excessive COV traffic |
| Blue | 6 blink | ARCNET or MSTP datalink configuration problem | Configuration Error | Check ARCNET or BACnet MS/TP network parameters |
| Green | On | All enabled networks are functioning properly | No errors | No action required |

SYS (System Status) Tricolor LED

| Color | Pattern | Condition | Message in Module Status | Possible Solution |
|--------|------------|---|---|--|
| Red | 1 blink | XT-LB is stopped | Startup Aborted Detected | Restart the XT-LB or perform a memory download in the i-Vu® application. |
| Red | 2 blink | Restarting after an abnormal exit | Auto restart delay due to system error on startup | After 5-minute delay has expired, if condition occurs again then cycle power |
| Red | 3 blink | System is non-operational due to one or more control programs halted | Control program stopped due to program error | Remove control program and download |
| Red | 4 blink | Firmware image is corrupt | Firmware error | Download driver again |
| Red | Fast blink | Firmware error has caused the firmware to exit and restart | Fatal error detected | No action required |
| Green | 1 blink | No errors | Operational | No action required |
| Green | 2 blink | Download of driver is in progress | Download in progress | No action required |
| Green | 3 blink | BACnet Device ID is not set | Download required | Download the XT-LB |
| Green | Fast blink | Installation of recently downloaded driver is occurring | N/A | No action required |
| Blue | On | Router is starting up | N/A | No action required |
| Blue | Slow blink | Linux (operating system) is starting up | N/A | No action required |
| Blue | Fast blink | Linux is running but it could not start the firmware application | N/A | Download driver |
| Orange | slow blink | XT-LB with drv_gen5 driver is starting | N/A | No action required |
| Orange | 2 blink | XT-LB with drv_gen5 driver has started but is not yet able to determine system and network status | N/A | No action required |

To get a Module Status report

A Module Status report provides information about the XT-LB and verifies proper network communication with the XT-LB. You can get this report:

- In the i-Vu® application—Right-click the XT-LB on the navigation tree, then select **Module Status**.
- In the controller setup interface through the Service Port—Click  and select **Modstat** from the drop-down list.


See *Appendix - Module Status field descriptions* (page 58).

To get a Device Log

If Carrier Controls System Support instructs you to get the XT-LB's Device Log containing diagnostic information for troubleshooting:



- 1 Select the XT-LB in the i-Vu® navigation tree.
- 2 On the **Properties** page, click **Device Log**.

NOTES


- To download a file containing multiple Device Logs to your computer, click **Device Log Archive**.
- To download network packet captures, access the driver properties or controller setup interface and go to  > **Diagnostics** tab > **Packet Capture**, then click **Get capture file**.

To get the XT-LB's serial number

If you need the XT-LB's serial number when troubleshooting, the number is on:

- A Module Status report (Modstat). See To get a Module Status report.
- A laser-etched number and QR code on the circuit board inside the XT-LB.
- A sticker on the front with the serial number, MAC address, and a QR code.
- In the driver properties or controller setup interface under  > **Dashboard** tab > **Controller Status** > .

To replace the XT-LB's fuse

If you turn on the XT-LB's power switch and the  LED is not lit, the fuse that protects the XT-LB may be blown. Remove the fuse and use a multimeter to check it.


The fuse is a fast acting, 250Vac, 2A, 5mm x 20mm glass fuse that you can purchase from one of the following vendors:

| Manufacturer | Mfr. Model # |
|--------------|--------------|
| Littelfuse | 0217002.HXP |
| Bussmann | S500-2-R |
| Belfuse | 5SF 2-R |
| Optifuse | FSD-2A |


Before replacing the fuse, try to determine why the fuse blew. Check the power wiring polarity of the XT-LB and any other devices that share the power supply. Use the same polarity for all of them.


To replace the fuse:

- 1 Turn off the XT-LB's power.
- 2 Remove the red power connector.
- 3 On both ends of the XT-LB, insert a small flathead screwdriver as shown below, and then gently pry up the cover until it is released from the base.



- 4 Remove the cover from the base.
- 5 The fuse labeled **F1** is located near the power connector. Use a fuse puller to remove the fuse.



- 6 Use the fuse puller to snap the new fuse into the fuse holder.
- 7 Replace the XT-LB's cover.
- 8 Replace the power connector.
- 9 Turn on the XT-LB's power switch.
- 10 Verify that the  LED on top of the XT-LB is on.

To take the XT-LB out of service

If needed for troubleshooting or start-up, you can prevent the i-Vu® application from communicating with the XT-LB by shutting down communication from the XT-LB to the i-Vu® application. When **Out of Service**, i-Vu® no longer communicates properties, colors, trends, etc.

- 1 On the i-Vu® navigation tree, select the XT-LB.
- 2 On the **Properties** page, check **Out of Service**.
- 3 Click **Accept**.

Compliance

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1 This device may not cause harmful interference.
- 2 This device must accept any interference received, including interference that may cause undesired operation.

NOTE This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy, and if it is not installed and used in accordance with this document, it may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.



CAUTION Any modifications made to this device that are not approved by Carrier voids the authority granted to the user by the FCC to operate this equipment.

CE and UKCA Compliance



WARNING This is a Class B product. In a light industrial environment, this product may cause radio interference in which case the user may be required to take adequate measures.

Industry Canada Compliance

This Class A digital apparatus complies with Canadian ICES-003.
Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

BACnet Compliance

Compliance of listed products to requirements of ASHRAE Standard 135 is the responsibility of BACnet International. BTL® is a registered trademark of BACnet International.

Appendix - Module Status field descriptions

| Field | Description |
|--|--|
| Product Name | Identifies the Product Type |
| Version | The version of the driver |
| Date/Time | Date and time the Modstat was run |
| Product Serial Number | The serial number of the module set at the factory |
| Operating System Java Version Processor Architecture | Underlying hardware and software architecture of the XT-LB |
| Device Instance | A unique ID assigned to the XT-LB |
| Number of BACnet Objects | The number of BACnet objects that were created in the device and the number of those objects that are trends or events. |
| Model Name | Identifies the Product Type |
| Downloaded by | When and where the last download was performed |
| # PRGs initialized # PRGs running | If applicable, the number of control programs that were downloaded vs. the number that are running. If these numbers are not the same, the controller has a problem such as lack of memory. |
| Memory | Total size of the XT-LB's memory and the amount being used for the application and short term memory. Cleanup indicates the rate of memory cleanup. |
| Reset Counters | <p>The number of times each of the following events have occurred since the last time the XT-LB was commanded to clear the reset counters. See NOTE below this table.</p> <p>Power failures—Interruption of incoming power</p> <p>Commanded boots—Includes commands issued from the i-Vu® interface such as the zap manual command, plus commands issued during a memory download.</p> <p>System errors—Error in the XT-LB's firmware or hardware</p> <p>S/W Watchdog timeouts—Watchdog is firmware that monitors the application firmware for normal operation. If the watchdog firmware detects a problem, it restarts the application firmware.</p> <p>H/W Watchdog timeouts—H/W Watchdog will restart the XT-LB if it detects a severe problem with the XT-LB's operating system</p> |
| Network Information | The various network addresses for the XT-LB. The Current and Assigned addresses will be the same unless there are configuration changes that have not been activated. |

| Field | Description |
|-------------------------|--|
| BBMD Configuration | <p>Shows the following information for each active IP network:</p> <p>BBMD Active shows whether the BACnet Broadcast Management Device is currently active (true) or inactive (false).</p> <p>BBMD Entries—the number of entries in the BBMD table (500 maximum).</p> <p>FDT Entries—the number of entries in the Foreign Device Table (500 maximum).</p> |
| BACnet/SC Information | BACnet/SC connection status as of when the Modstat was run. Also shows the web addresses used to access the primary and/or failover hubs. |
| BACnet/SC Certificates | Lists the operational certificates and certificate authorities installed on the XT-LB, with expiration information. |
| Routing Information | BACnet networks that a XT-LB is currently routing traffic to. The list changes as BACnet routers are added or removed from the system. |
| Router statistics | <p>Dropped Packets—Data packets that could not be delivered.</p> <p>Route Not Found—Packets that could not be delivered because the requested network does not exist.</p> <p>Route Unreachable—Routed packets whose destination network is either busy or offline.</p> <p>Router Sourced Packets—Shows the number of packets initiated by the XT-LB that are not in response to a request from another device.</p> |
| Device statistics | Shows the number of incoming and outgoing unicast and broadcast packets for each of the XT-LB's networks. Dropped Incoming indicates the number of incoming packets that could not be delivered. |
| BACnet/IP Statistics | <p>Rx Unicasts—BACnet/IP packets received from a single BACnet device.</p> <p>Tx Unicasts—BACnet/IP packets transmitted to a single BACnet device.</p> <p>Rx Broadcasts—BACnet/IP broadcast packets received by the XT-LB.</p> <p>Tx Broadcasts—BACnet/IP broadcast packets transmitted by the XT-LB.</p> <p>Whitelist Rejections (if BACnet Firewall is enabled)—Messages blocked by the BACnet Firewall because the IP address that sent the message was not in the whitelist.</p> |
| Gig-E Port Statistics | <p>Rx packets—All packets (including non-BACnet packets such as a ping) received by the XT-LB.</p> <p>Tx packets—All packets (including non-BACnet packets such as a ping) transmitted by the XT-LB.</p> <p>Rx Error Count—All errors related to received packets such as CRC errors, FIFO errors, frame errors, length errors, missed errors, and overrun errors.</p> <p>Tx Error Count—All errors related to transmitted packets such as aborted errors, carrier errors, dropped errors, FIFO errors, heartbeat errors, and window errors.</p> <p>Dropped Packets—Packets dropped by the XT-LB.</p> |
| BACnet Protocol Details | <p>COV subscriptions—Change of value subscriptions.</p> <p>Communications—Number of data packets transmitted and received by the XT-LB.</p> |

| Field | Description |
|------------------------------|---|
| IoT Publisher Information | <p>Connection State—Current state of the connection to the broker.</p> <p>Last Connected—Timestamp of when the connection was last established.</p> <p>Protocol—Name of the protocol used</p> <p>Broker URI—Full connection string to the UDMI Broker</p> <p>Client Id—Identifier for a given client</p> |
| Base and Core board hardware | <p>Gives the following information about the XT-LB's boards:</p> <ul style="list-style-type: none"> Type and board numbers that are used internally by Carrier. The manufacture date and serial number. |
| System status | Gives the current status of the XT-LB's operation. See <i>LEDs</i> (page 51) for all possible conditions. |
| Network status | Gives the current status of the XT-LB's networks. See <i>LEDs</i> (page 51) for all possible conditions. |
| Driver | The name, version, and date of the driver, as well as all the bundles and versions. |
| Switch Settings | <p>Protocol Rotary—The XT-LB's rotary switch setting for Port S1 protocol</p> <p>Address Rotary—The XT-LB's rotary switch address (MAC address)</p> <p>Port S1 End of Network—End of Network switch position for Port S1</p> <p>Port S2 End of Network—End of Network switch position for Port S2</p> |
| System error message history | High-severity errors since the last memory download. Shows the most recent 10 messages. See NOTE below this table. |
| Warning message history | Low-severity errors and warning messages since the last memory download. Shows the most recent 10 messages. See NOTE below this table. |
| Information message history | Information-only messages since the last memory download. Shows the most recent 10 messages. See NOTE below this table. |

NOTE To clear the Reset counters and the three message history fields, click the **Clear Counts/Logs** button on the XT-LB's **Properties** page in the i-Vu® application. To delete all logs, including current logs, click the **Delete All** button in the **Home > Diagnostics** tab under **Logs**.

Document revision history

Important changes to this document are listed below. Minor changes such as typographical or formatting errors are not listed.

| Date | Topic | Change description | Code* |
|---------|-------------------------------|---------------------------------|--------------|
| 6/23/25 | Diagnostic tab | Updated notes in Packet Capture | X-TS-RB-J-RB |
| 4/17/25 | Critical Product Announcement | New topic | C-PM-DD-J-DD |
| | Specifications | Updated FLEX Points | C-PM-EH-E-EH |

* For internal use only

