FILE NO. SVM-20104

Carrier SERVICE MANUAL AIR-CONDITIONER MULT TYPE

<High Wall Types> MMK-AP0157HPUL MMK-AP0187HPUL MMK-AP0247HPUL

TOSHIBA



December, 2020

CONTENTS

PRECAUTION FOR SAFETY	6
NEW REFRIGERANT (R410A)1	1
1. CONSTRUCTION VIEWS (EXTERNAL VIEWS)	3
2. WIRING DIAGRAM 14	4
3. PARTS RATING 1	5
4. REFRIGERANTING CYCLE DIAGRAM	6
5. CONTROL OUTLINE	7
6. CONFIGURATION OF CONTROL CIRCUIT	3
7. APPLIED CONTROL	0
8. TROUBLESHOOTING 44	4
9. INSTALLATION MANUAL 68	8
10. HOW TO REPLACE MAIN PARTS10	6
11. REPLACEMENT OF P.C.BOARD FOR INDOOR UNIT SERVICING	3
12. EXPLODED VIEWS AND PARTS LIST11	

Original instruction

Please read carefully through these instructions that contain important information which complies with the Machinery Directive (Directive 2006/42/EC), and ensure that you understand them.

Generic Denomination: Air Conditioner

Definition of Qualified Installer or Qualified Service Person

The air conditioner must be installed, maintained, repaired and removed by a qualified installer or qualified service person.

When any of these jobs is to be done, ask a qualified installer or qualified service person to do them for you. A qualified installer or qualified service person is an agent who has the qualifications and knowledge described in the table below.

Agent	Qualifications and knowledge which the agent must have				
	• The qualified installer is a person who installs, maintains, relocates and removes the air conditioners made by Toshiba Carrier Corporation.				
	He or she has been trained to install, maintain, relocate and remove the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such operations by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to these operations.				
Qualified installer	• The qualified installer who is allowed to do the electrical work involved in installation, relocation and removal has the qualifications pertaining to this electrical work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to electrical work on the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work.				
	• The qualified installer who is allowed to do the refrigerant handling and piping work involved in installation, relocation and removal has the qualifications pertaining to this refrigerant handling and piping work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to refrigerant handling and piping work on the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work.				
	• The qualified installer who is allowed to work at heights has been trained in matters relating to working at heights with the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work.				
	 The qualified service person is a person who installs, repairs, maintains, relocates and removes the air conditioners made by Toshiba Carrier Corporation. 				
	He or she has been trained to install, repair, maintain, relocate and remove the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such operations by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to these operations.				
Qualified service	• The qualified service person who is allowed to do the electrical work involved in installation, repair, relocation and removal has the qualifications pertaining to this electrical work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to electrical work on the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work.				
	• The qualified service person who is allowed to do the refrigerant handling and piping work involved in installation, repair, relocation and removal has the qualifications pertaining to this refrigerant handling and piping work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to refrigerant handling and piping work on the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work.				
	• The qualified service person who is allowed to work at heights has been trained in matters relating to working at heights with the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work.				

Definition of Protective Gear

When the air conditioner is to be transported, installed, maintained, repaired or removed, wear protective gloves and 'safety' work clothing.

In addition to such normal protective gear, wear the protective gear described below when undertaking the special work detailed in the table below.

Failure to wear the proper protective gear is dangerous because you will be more susceptible to injury, burns, electric shocks and other injuries.

Work undertaken	Protective gear worn		
All types of work	Protective gloves 'Safety' working clothing		
Electrical-related work	Gloves to provide protection for electricians and from heat Insulating shoes Clothing to provide protection from electric shock		
Work done at heights (50 cm or more)	Helmets for use in industry		
Transportation of heavy objects	Shoes with additional protective toe cap		
Repair of outdoor unit	Gloves to provide protection for electricians and from heat		

The important contents concerned to the safety are described on the product itself and on this Service Manual. Please read this Service Manual after understanding the described items thoroughly in the following contents (Indications/Illustrated marks), and keep them.

[Explanation of indications]

Indication	Explanation
	Indicates contents assumed that an imminent danger causing a death or serious injury of the repair engineers and the third parties when an incorrect work has been executed.
	Indicates possibilities assumed that a danger causing a death or serious injury of the repair engineers, the third parties, and the users due to troubles of the product after work when an incorrect work has been executed.
	Indicates contents assumed that an injury or property damage (*) may be caused on the repair engineers, the third parties, and the users due to troubles of the product after work when an incorrect work has been executed.

* Property damage: Enlarged damage concerned to property, furniture, and domestic animal/pet

[Explanation of illustrated marks]

Mark	Explanation			
\bigcirc	Indicates prohibited items (Forbidden items to do) The sentences near an illustrated mark describe the concrete prohibited contents.			
0	Indicates mandatory items (Compulsory items to do) The sentences near an illustrated mark describe the concrete mandatory contents.			
	Indicates cautions (Including danger/warning) The sentences or illustration near or in an illustrated mark describe the concrete cautious contents.			

Warning Indications on the Air Conditioner Unit

[Confirmation of warning label on the main unit]

Confirm that labels are indicated on the specified positions If removing the label during parts replace, stick it as the original.

Warning indication	Description
WARNING ELECTRICAL SHOCK HAZARD Disconnect all remote electric power supplies before servicing.	WARNING ELECTRICAL SHOCK HAZARD Disconnect all remote electric power supplies before servicing.
WARNING Moving parts. Do not operate unit with grille removed. Stop the unit before the servicing.	WARNING Moving parts. Do not operate unit with grille removed. Stop the unit before the servicing.
CAUTION High temperature parts. You might get burned when removing this panel.	CAUTION High temperature parts. You might get burned when removing this panel.
CAUTION Do not touch the aluminum fins of the unit. Doing so may result in injury.	CAUTION Do not touch the aluminum fins of the unit. Doing so may result in injury.
CAUTION BURST HAZARD Open the service valves before the operation, otherwise there might be the burst.	CAUTION BURST HAZARD Open the service valves before the operation, otherwise there might be the burst.
CAUTION Do not climb onto the fan guard. Doing so may result in injury.	CAUTION Do not climb onto the fan guard. Doing so may result in injury.

Precautions for Safety

The manufacturer shall not assume any liability for the damage caused by not observing the description of this manual.

	Before carrying out the installation, maintenance, repair or removal work, be sure to set the circuit breaker for both the indoor and outdoor units to the OFF position. Otherwise, electric shocks may result.
	Before opening the intake grille of the indoor unit or service panel of the outdoor unit, set the circuit breaker to the OFF position. Failure to set the circuit breaker to the OFF position may result in electric shocks through contact with the interior parts. Only a qualified installer (*1) or qualified service person (*1) is allowed to remove the intake grille of the indoor unit or service panel of the outdoor unit and do the work required.
	Before starting to repair the outdoor unit fan or fan guard, be absolutely sure to set the circuit breaker to the OFF position, and place a "Work in progress" sign on the circuit breaker.
Turn off breaker.	When cleaning the filter or other parts of the indoor unit, set the circuit breaker to OFF without fail, and place a "Work in progress" sign near the circuit breaker before proceeding with the work.
	When you have noticed that some kind of trouble (such as when an error display has appeared, there is a smell of burning, abnormal sounds are heard, the air conditioner fails to cool or heat or water is leaking) has occurred in the air conditioner, do not touch the air conditioner yourself but set the circuit breaker to the OFF position, and contact a qualified service person. Take steps to ensure that the power will not be turned on (by marking "out of service" near the circuit breaker, for instance) until qualified service person arrives.
	Continuing to use the air conditioner in the trouble status may cause mechanical problems to escalate or result in electric shocks or other failure.
Electric shock hazard.	When you access inside of the service panel to repair electric parts, wait for about five minutes after turning off the breaker. Do not start repairing immediately. Otherwise you may get electric shock by touching terminals of high-voltage capacitors. Natural discharge of the capacitor takes about five minutes.
	Place a "Work in progress" sign near the circuit breaker while the installation, maintenance, repair or removal work is being carried out. There is a danger of electric shocks if the circuit breaker is set to ON by mistake.
Prohibition	Before operating the air conditioner after having completed the work, check that the electrical parts box cover of the indoor unit and service panel of the outdoor unit are closed, and set the circuit breaker to the ON position. You may receive an electric shock if the power is turned on without first conducting these checks.
Stay on protection.	If, in the course of carrying out repairs, it becomes absolutely necessary to check out the electrical parts with the electrical parts box cover of one or more of the indoor units and the service panel of the outdoor unit removed in order to find out exactly where the trouble lies, wear insulated heat-resistant gloves, insulated boots and insulated work overalls, and take care to avoid touching any live parts. You may receive an electric shock if you fail to heed this warning. Only qualified service person (*1) is allowed to do this kind of work.



	Before starting to repair the air conditioner, read carefully through the Service Manual, and repair the air conditioner by following its instructions.
	Only qualified service person (*1) is allowed to repair the air conditioner. Repair of the air conditioner by unqualified person may give rise to a fire, electric shocks, injury, water leaks and/or other problems.
	Do not use any refrigerant different from the one specified for complement or replacement. Other wise, abnormally high pressure may be generated in the refrigeration cycle, which may result in a failure or explosion of the product or an injury to your body.
	Only a qualified installer (*1) or qualified service person (*1) is allowed to carry out the electrical work of the air conditioner. Under no circumstances must this work be done by an unqualified individual since failure to carry out the work properly may result in electric shocks and/or electrical leaks.
	When transporting the air conditioner, wear shoes with protective toe caps, protective gloves and other protective clothing.
	When connecting the electrical wires, repairing the electrical parts or undertaking other electrical jobs, wear gloves to provide protection for electricians and from heat, insulating shoes and clothing to provide protection from electric shocks. Failure to wear this protective gear may result in electric shocks.
	Electrical wiring work shall be conducted according to law and regulation in the community and installation manual. Failure to do so may result in electrocution or short circuit.
0	Only a qualified installer (*1) or qualified service person (*1) is allowed to undertake work at heights using a stand of 50 cm or more or to remove the intake grille of the indoor unit to undertake work.
General.	When working at heights, use a ladder which complies with the ISO 14122 standard, and follow the procedure in the ladder's instructions. Also wear a helmet for use in industry as protective gear to undertake the work.
	When working at heights, put a sign in place so that no-one will approach the work location, before proceeding with the work. Parts and other objects may fall from above, possibly injuring a person below.
	When executing address setting, test run, or troubleshooting through the checking window on the electric parts box, put on insulated gloves to provide protection from electric shock. Otherwise you may receive an electric shock.
	Do not touch the aluminum fin of the outdoor unit. You may injure yourself if you do so. If the fin must be touched for some reason, first put on protective gloves and safety work clothing, and then proceed.
	Do not climb onto or place objects on top of the outdoor unit. You may fall or the objects may fall off of the outdoor unit and result in injury.
	When transporting the air conditioner, wear shoes with additional protective toe caps.
	When transporting the air conditioner, do not take hold of the bands around the packing carton. You may injure yourself if the bands should break.
	Be sure that a heavy unit (10kg or heavier) such as a compressor is carried by two persons.
	This air conditioner has passed the pressure test as specified in IEC 60335-2-40 Annex EE.
	Before troubleshooting or repair work, check the earth wire is connected to the earth terminals of the main unit, otherwise an electric shock is caused when a leak occurs. If the earth wire is not correctly connected, contact an electric engineer for rework.
Chask parth	After completing the repair or relocation work, check that the ground wires are connected properly.
Check earth wires.	Be sure to connect earth wire. (Grounding work) Incomplete grounding causes an electric shock. Do not connect ground wires to gas pipes, water pipes, and lightning rods or ground wires for tele- phone wires.
Prohibition of modification.	Do not modify the products. Do not also disassemble or modify the parts. It may cause a fire, electric shock or injury.

Use specified parts.	When any of the electrical parts are to be replaced, ensure that the replacement parts satisfy the specifications given in the Service Manual (or use the parts contained on the parts list in the Service Manual). Use of any parts which do not satisfy the required specifications may give rise to electric shocks, smoking and/ or a fire.
Do not bring a child close to the equipment.	Refrigerantlf, in the course of carrying out repairs, it becomes absolutely necessary to check out the electrical parts with the electrical parts box cover of one or more of the indoor units and the service panel of the outdoor unit removed in order to find out exactly where the trouble lies, put a sign in place so that no-one will approach the work location before proceeding with the work. Third-party individuals may enter the work site and receive electric shocks if this warning is not heeded.
Insulating measures	Connect the cut-off lead wires with crimp contact, etc., put the closed end side upward and then apply a watercut method, otherwise a leak or production of fire is caused at the users' side.
P No fire	 When performing repairs using a gas burner, replace the refrigerant with nitrogen gas because the oil that coats the pipes may otherwise burn. When repairing the refrigerating cycle, take the following measures. 1) Be attentive to fire around the cycle. When using a gas stove, etc., be sure to put out fire before work; otherwise the oil mixed with refrigerant gas may catch fire. 2) Do not use a welder in the closed room. When using it without ventilation, carbon monoxide poisoning may be caused. 3) Do not bring inflammables close to the refrigerant cycle, otherwise fire of the welder may catch the inflammables.
	The refrigerant used by this air conditioner is the R410A. Check the used refrigerant name and use tools and materials of the parts which match with it. For the products which use R410A refrigerant, the refrigerant name is indicated at a position on the outdoor unit where is easy to see. To prevent miss-charging, the route of the service port is changed from one of the former R22.
	For an air conditioner which uses R410A, never use other refrigerant than R410A. For an air conditioner which uses other refrigerant (R22, etc.), never use R410A. If different types of refrigerant are mixed, abnormal high pressure generates in the refrigerating cycle and an injury due to breakage may be caused.
	When the air conditioner has been installed or relocated, follow the instructions in the Installation Manual and purge the air completely so that no gases other than the refrigerant will be mixed in the refrigerating cycle. Failure to purge the air completely may cause the air conditioner to malfunction.
Refrigerant	Do not charge refrigerant additionally. If charging refrigerant additionally when refrigerant gas leaks, the refrigerant composition in the refrigerating cycle changes resulted in change of air conditioner characteristics or refrigerant over the specified standard amount is charged and an abnormal high pressure is applied to the inside of the refrigerating cycle resulted in cause of breakage or injury. Therefore if the refrigerant gas leaks, recover the refrigerant in the air conditioner, execute vacuuming, and then newly recharge the specified amount of liquid refrigerant. In this time, never charge the refrigerant over the specified amount.
	When recharging the refrigerant in the refrigerating cycle, do not mix the refrigerant or air other than R410A into the specified refrigerant. If air or others is mixed with the refrigerant, abnormal high pressure generates in the refrigerating cycle resulted in cause of injury due to breakage.
	After installation work, check the refrigerant gas does not leak. If the refrigerant gas leaks in the room, poisonous gas generates when gas touches to fire such as fan heater, stove or cocking stove though the refrigerant gas itself is innocuous.
	Never recover the refrigerant into the outdoor unit. When the equipment is moved or repaired, be sure to recover the refrigerant with recovering device. The refrigerant cannot be recovered in the outdoor unit; otherwise a serious accident such as breakage or injuryis caused.
Assembly/ Wiring	After repair work, surely assemble the disassembled parts, and connect and lead the removed wires as before. Perform the work so that the cabinet or panel does not catch the inner wires. If incorrect assembly or incorrect wire connection was done, a disaster such as a leak or fire is caused at user's side.
Insulator check	After the work has finished, be sure to use an insulation tester set (500V Megger) to check the resistance is $1M\Omega$ or more between the charge section and the non-charge metal section (Earth position). If the resistance value is low, a disaster such as a leak or electric shock is caused at user's side.

Ventilation	When the refrigerant gas leaks during work, execute ventilation. If the refrigerant gas touches to a fire, poisonous gas generates. A case of leakage of the refrigerant and the closed room full with gas is dangerous because a shortage of oxygen occurs. Be sure to execute ventilation.
Ω	When the refrigerant gas leaks, find up the leaked position and repair it surely. If the leaked position cannot be found up and the repair work is interrupted, pump-down and tighten the service valve, otherwise the refrigerant gas may leak into the room. The poisonous gas generates when gas touches to fire such as fan heater, stove or cocking stove though the refrigerant gas itself is innocuous. When installing equipment which includes a large amount of charged refrigerant such as a multi air conditioner in a sub-room, it is necessary that the density does not the limit even if the refrigerant leaks. If the refrigerant leaks and exceeds the limit density, an accident of shortage of oxygen is caused.
Compulsion	Tighten the flare nut with a torque wrench in the specified manner. Excessive tighten of the flare nut may cause a crack in the flare nut after a long period, which may result in refrigerant leakage.
	Nitrogen gas must be used for the airtight test.
	The charge hose must be connected in such a way that it is not slack.
	For the installation/moving/reinstallation work, follow to the Installation Manual. If an incorrect installation is done, a trouble of the refrigerating cycle, water leak, electric shock or fire is caused.
	Once the repair work has been completed, check for refrigerant leaks, and check the insulation resistance and water drainage. Then perform a trial run to check that the air conditioner is running properly.
•	After repair work has finished, check there is no trouble. If check is not executed, a fire, electric shock or injury may be caused. For a check, turn off the power breaker.
Check after repair	After repair work (installation of front panel and cabinet) has finished, execute a test run to check there is no generation of smoke or abnormal sound. If check is not executed, a fire or an electric shock is caused. Before test run, install the front panel and cabinet.
	Be sure to fix the screws back which have been removed for installation or other purposes.
Do not operate the unit with the valve closed.	 Check the following matters before a test run after repairing piping. Connect the pipes surely and there is no leak of refrigerant. The valve is opened. Running the compressor under condition that the valve closes causes an abnormal high pressure resulted in damage of the parts of the compressor and etc. and moreover if there is leak of refrigerant at connecting section of pipes, the air is sucked and causes further abnormal high pressure resulted in burst or injury.
	Only a qualified installer (*1) or qualified service person (*1) is allowed to relocate the air conditioner. It is dangerous for the air conditioner to be relocated by an unqualified individual since a fire, electric shocks, injury, water leakage, noise and/or vibration may result.
Check after reinstallation	 Check the following items after reinstallation. 1) The earth wire is correctly connected. 2) The power cord is not caught in the product. 3) There is no inclination or unsteadiness and the installation is stable. If check is not executed, a fire, an electric shock or an injury is caused.
	When carrying out the pump-down work shut down the compressor before disconnecting the refriger- ant pipe. Disconnecting the refrigerant pipe with the service valve left open and the compressor still operating will cause air, etc. to be sucked in, raising the pressure inside the refrigeration cycle to an abnormally high level, and possibly resulting in reputing, injury, etc.
	When the service panel of the outdoor unit is to be opened in order for the compressor or the area around this part to be repaired immediately after the air conditioner has been shut down, set the circuit breaker to the OFF position, and then wait at least 10 minutes before opening the service panel. If you fail to heed this warning, you will run the risk of burning yourself because the compressor pipes and other parts will be very hot to the touch. In addition, before proceeding with the repair work, wear the kind of insulated heat-resistant gloves designed to protect electricians.
Cooling check	Take care not to get burned by compressor pipes or other parts when checking the cooling cycle while running the unit as they get heated while running. Be sure to put on gloves providing protection for electric shock and heat.
	When the service panel of the outdoor unit is to be opened in order for the fan motor, reactor, inverter or the areas around these parts to be repaired immediately after the air conditioner has been shut down, set the circuit breaker to the OFF position, and then wait at least 10 minutes before opening the service panel. If you fail to heed this warning, you will run the risk of burning yourself because the fan motor, reactor, inverter heat sink and other parts will be very hot to the touch. In addition, before proceeding with the repair work, wear the kind of insulated heat-resistant gloves designed to protect electricians.

Only a qualified installer (*1) or qualified service person (*1) is allowed to install the air conditioner. If the air conditioner is installed by an unqualified individual, a fire, electric shocks, injury, water leakage, noise and/or vibration may result.
Before starting to install the air conditioner, read carefully through the Installation Manual, and follow its instructions to install the air conditioner.
Be sure to use the company-specified products for the separately purchased parts. Use of non- specified products may result in fire, electric shock, water leakage or other failure. Have the installation performed by a qualified installer.
Do not supply power from the power terminal block equipped on the outdoor unit to another outdoor unit. Capacity overflow may occur on the terminal block and may result in fire.
Do not install the air conditioner in a location that may be subject to a risk of expire to a combustible gas. If a combustible gas leaks and becomes concentrated around the unit, a fire may occur.
Install the indoor unit at least 2.5 m above the floor level since otherwise the users may injure them- selves or receive electric shocks if they poke their fingers or other objects into the indoor unit while the air conditioner is running.
Install a circuit breaker that meets the specifications in the installation manual and the stipulations in the local regulations and laws.
Install the circuit breaker where it can be easily accessed by the qualified service person (*1).
If you install the unit in a small room, take appropriate measures to prevent the refrigerant from exceeding the limit concentration even if it leaks. Consult the dealer from whom you purchased the air conditioner when you implement the measures. Accumulation of highly concentrated refrigerant may cause an oxygen deficiency accident.
Do not place any combustion appliance in a place where it is directly exposed to the wind of air conditioner, otherwise it may cause imperfect combustion.

Explanations given to user

• If you have discovered that the fan grille is damaged, do not approach the outdoor unit but set the circuit breaker to the OFF position, and contact a qualified service person to have the repairs done. Do not set the circuit breaker to the ON position until the repairs are completed.

Relocation

- Only a qualified installer (*1) or qualified service person (*1) is allowed to relocate the air conditioner.
 It is dangerous for the air conditioner to be relocated by an unqualified individual since a fire, electric shocks, injury, water leakage, noise and/or vibration may result.
- When carrying out the pump-down work shut down the compressor before disconnecting the refrigerant pipe. Disconnecting the refrigerant pipe with the service valve left open and the compressor still operating will cause air, etc. to be sucked in, raising the pressure inside the refrigeration cycle to an abnormally high level, and possibly resulting in reputing, injury, etc.
- (*1) Refer to the "Definition of Qualified Installer or Qualified Service Person."

• New Refrigerant (R410A)

This air conditioner adopts a new HFC type refrigerant (R410A) which does not deplete the ozone layer.

1. Safety Caution Concerned to New Refrigerant

The pressure of R410A is high 1.6 times of that of the former refrigerant (R22). Accompanied with change of refrigerant, the refrigerating oil has been also changed. Therefore, be sure that water, dust, the former refrigerant or the former refrigerating oil is not mixed into the refrigerating cycle of the air conditioner with new refrigerant during installation work or service work. If an incorrect work or incorrect service is performed, there is a possibility to cause a serious accident. Use the tools and materials exclusive to R410A to purpose a safe work.

2. Cautions on Installation/Service

- (1) Do not mix the other refrigerant or refrigerating oil.
 - For the tools exclusive to R410A, shapes of all the joints including the service port differ from those of the former refrigerant in order to prevent mixture of them.
- (2) As the use pressure of the new refrigerant is high, use material thickness of the pipe and tools which are specified for R410A.
- (3) In the installation time, use clean pipe materials and work with great attention so that water and others do not mix in because pipes are affected by impurities such as water, oxide scales, oil, etc. Use the clean pipes.

Be sure to brazing with flowing nitrogen gas. (Never use gas other than nitrogen gas.)

- (4) For the earth protection, use a vacuum pump for air purge.
- (5) R410A refrigerant is azeotropic mixture type refrigerant. Therefore use liquid type to charge the refrigerant. (If using gas for charging, composition of the refrigerant changes and then characteristics of the air conditioner change.)

3. Pipe Materials

For the refrigerant pipes, copper pipe and joints are mainly used. It is necessary to select the most appropriate pipes to conform to the standard. Use clean material in which impurities adhere inside of pipe or joint to a minimum.

(1) Copper pipe

<Piping>

The pipe thickness, flare finishing size, flare nut and others differ according to a refrigerant type.

When using a long copper pipe for R410A, it is recommended to select "Copper or copper-base pipe without seam" and one with bonded oil amount 40mg/10m or less. Also do not use crushed, deformed, discolored (especially inside) pipes. (Impurities cause clogging of expansion valves and capillary tubes.)

<Flare nut>

Use the flare nuts which are attached to the air conditioner unit.

(2) Joint

The flare joint and socket joint are used for joints of the copper pipe. The joints are rarely used for installation of the air conditioner. However clear impurities when using them.

4. Tools

(1) Required Tools for R410A

Mixing of different types of oil may cause a trouble such as generation of sludge, clogging of capillary, etc. Accordingly, the tools to be used are classified into the following three types.

- 1) Tools exclusive for R410A (Those which cannot be used for conventional refrigerant (R22))
- 2) Tools exclusive for R410A, but can be also used for conventional refrigerant (R22)
- 3) Tools commonly used for R410A and for conventional refrigerant (R22)

The table below shows the tools exclusive for R410A and their interchangeability.

	Tools whose s	specifications are char	nged for R410A	and their interch	angeability.	
	Used tool	Usage	R410A air conditioner installation		Conventional air conditioner installation	
No [.]			Existence of new equipment for R410A	Whether conven- tional equipment can be used	Whether new equipment can be used with conventional refrigerant	
1	Flare tool	Pipe flaring	Yes	*(Note 1)	Yes	
2	Copper pipe gauge for adjusting projection margin	Flaring by conventional flare tool	Yes	*(Note 1)	*(Note 1)	
3	Torque wrench	Connection of flare nut	Yes	No	No	
4	Gauge manifold	Evacuating, refrigerant	Yesa	No	No	
5	Charge hose	charge, run check, etc.	1654	NO		
6	Vacuum pump adapter	Vacuum evacuating	Yes	No	Yes	
7	Electronic balance for refrigerant charging	Refrigerant charge	Yes	Yes	Yes	
8	Refrigerant cylinder	Refrigerant charge	Yes	No	No	
9	Leakage detector	Gas leakage check	Yes	No	Yes	
10	Charging cylinder	Refrigerant charge	(Note 2)	No	No	


(Note 1) When flaring is carried out for R410A using the conventional flare tools, adjustment of projection margin is necessary. For this adjustment, a copper pipe gauge, etc. are necessary.(Note 2) Charging cylinder for R410A is being currently developed.

General tools (Conventional tools can be used.) In addition to the above exclusive tools, the following equipments which serve also for R22 are necessary as the general tools. (1) Vacuum pump Use vacuum pump by attaching vacuum pump adapter. (7) Screwdriver (+, -)(8) Spanner or Monkey wrench (2) Torque wrench (3) Pipe cutter (9) Hole core drill (10) Hexagon wrench (Opposite side 4mm) (4) Reamer (5) Pipe bender (11) Tape measure (6) Level vial (12) Metal saw Also prepare the following equipments for other installation method and run check.


- (3) Ilnsulation resistance tester
 - (4) Electroscope

- (1) Clamp meter
- (2) Thermometer

1. CONSTRUCTION VIEWS (EXTERNAL VIEWS)



2. WIRING DIAGRAM




3. PARTS RATING


3-1. Parts Rating

No.	Parts Name	Туре	Specications
1	Fan motor (for indoor)	ICF-340-30-6	Output (Rated) 30W, DC340V
2	Louver motor	24BYJ48A-080	4 phase, DC12V
3	Thermo. Sensor (TA sensor)	16.4"(418mm)	10kΩ at 25°C
4	Heat exchanger sensor (TC1 sensor)	Ø4, 19.7"(500mm)	10kΩ at 25°C
5	Heat exchanger sensor (TC2 sensor)	Ø6, 31.4"(800mm)	10kΩ at 25°C
6	Heat exchanger sensor (TCJ sensor)	Ø6, 19.7"(500mm)	10kΩ at 25°C

3-2. Name of Each Part



4. REFRIGERANTING CYCLE DIAGRAM



Functional part name		Functional outline
Pulse Motor Valve	PMV	 (Connector CN82 (6P): Blue) 1) Controls super heat in cooling operation 2) Controls under cool in heating operation 3) Recovers refrigerant oil in cooling operation 4) Recovers refrigerant oil in heating operation
Temp. sensor	1. TA	(Connector CN104 (2P): White) 1) Detects indoor suction temperature
	2. TC1	(Connector CN100 (3P): Brown) 1) Controls PMV super heat in cooling operation
3. TC2		(Connector CN101 (2P): Blue) 1) Controls PMV under cool in heating operation
	4. TCJ	(Connector CN102 (2P): Yellow) 1) Controls PMV super heat in cooling operation

5. CONTROL OUTLINE

5-1. Indoor Unit Control Specifications

No.	ltem	Outline of spec	Remarks		
1	Power supply is reset.	 (1) Distinction of outdoor unit When the power supply is reset distinguished, and control is exc distinctive results. (2) Check code clear When the power supply is reset once. If an abnormal status white after Start/Stop button of the ren pushed continues, the check con remote controller. 	 Judgment of outdoor unit Exchange of cooling-only unit Exchange of standard model with the flex model 		
2	Operation select	(1) Based upon the operation select the operation mode is se-lected		troller or central controller,	
		Remote controller command	Control o	utline	
		STOP	Stops air cor		
		FAN	Fan oper		
		COOL	Cooling op		
		DRY	Dry oper		
		HEAT	Heating op		
		AUTO	Cooling or HEAT operation mod by Ta and Ts and the unit starts	de is automatically selected	
3	Room temp. control	 (2) Operation commend permission Neither AUTO mode of the stan selected. When a wireless remo Pi, Pi (Twice) and alternative fla To release the alternative flashin (1) Adjustment range Set temperatu <u>COOL/DRY</u> <u>Wired type</u> 64°F [18°C] to 84°F [29° Wireless type 63°F [17°C] to 86°F [30° (2) From the item code 06, the setu 	otified by the receiving sound		
		operation can be corrected. SET DATA 0 Temperature setting adjustment +0°F[+0°C]	2 4 6 3.6°F[+2°C] +7.2°F[+4°C] +10.8°F[+6°C]	Heating suction temperature shift	
		Setup at shipment Setup data 2			
4	Automatic capacity control	 Based upon difference between frequency of the outdoor unit va 	Ta: Room temperature Ts: Setup temperature		
5	Air volume control	 (1) By the command from the remo "MED (H)", or "LOW (L)" "AUTO For the wireless remote controll "L", or "AUTO" operation is exec (2) While air speed is in AUTO mod according to the difference betw 	HH > H+ > H > L+ > L > LL		

No.	Item	Outline of specifications	Remarks
6	Prevention of cold air discharge	 (1) In heating operation, the upper limit of the fan tap is set by one with higher temperature of TC2 sensor and TCJ sensor. When B zone has continued for 6 minutes, the operation shifts to C zone. In defrost time, the control point is set to +10.8°F(+6°C). (°F) (°C) 89.6 32 86 30 82.4 28 78.8 26 A zone: OFF B zone: Over 78.8°F(26°C), below 82.4°F(28°C), ULTRA LOW (LL) C zone: Over 82.4°F(28°C), below 86°F(30°C), LOW (L) D zone: Over 86°F(30°C), below 89.6°F(32°C), MED (H) E zone: HIGH (HH) 	 In D and E zones, priority is given to remote control- ler air speed setup. In A and B zones, """ is displayed.
7	Freeze preven- tion control (Low temp. release)	 (1) In cooling operation, the air conditioner operates as described below based upon temp. detected by TC1, TC2 and TCJ sensors. To prevent the heat exchanger from freezing, the operation stops. • When "J" zone is detected for 5 minutes, the forced thermo is OFF. • In "K" zone, the timer count is interrupted, and held. • When "I" zone is detected, the timer is cleared and the operation returns to the normal operation. • When "I" zone, operation of the the indoor fan in LOW (L) mode until it reaches the "I" zone. It is reset when the following conditions are satisfied. Reset conditions 1) TC1 ≥ 53.6°F(12°C) and TC2 ≥ 53.6°F(12°C) and TCJ ≥ 53.6°F(12°C) 2) 20 minutes passed after stop. (°F) P1 O1 O1 O1 O1 O1 O1 O1 O1 O1 O1 O1 O1 O1	

No.	ltem	Outline of specifications	Remarks
8	Cooling oil (refrigerant) recovery control	 While the outdoor unit is recovering cooling oil (refrigerant), the indoor units perform the following control tasks: [common for operational (cooling thermo ON/thermo OFF/FAN), as well as nonoperational indoor units] (1) Open the indoor PMV to a certain degree. (2) Engage in recovery control for a specified period of time and return to normal cooling operation at the end of this period upon terminating the control. 	 Recovery operation normally takes place roughly every 2 hours. The opening position of the indoor PMV depending on the type and capacity of the indoor unit.
9	Heating refriger- ant (oil) recovery control	 While the outdoor unit is recovering heating refrigerant (oil), the indoor units perform the following control tasks: (1) Open the indoor PMV to a certain degree. (2) Control the indoor fan according to the operation mode. [Indoor units operating in heating thermo ON/OFF state] Let the indoor fan continue operating, but turn it off if the temperature of the indoor heat exchanger drops. [Indoor units operating in FAN mode] Turn off the indoor fan and display "HEATING STANDBY " on the remote controller. [Non-operational indoor units] Keep the indoor fan turned off. (3) Terminate the recovery operation depending on the TC2 temperature reading. The timing of termination is determined by each indoor unit. 	 Recovery operation normally takes place roughly every hour. The opening position of the indoor PMV depending on the type and capacity of the indoor unit.
10	Short intermittent operation compensation control	 For 5 minutes after the operation has started, the operation is continued even if entering thermostat-OFF condition. However, Cooling/Heating exchange and the system protective control precede and thermostat is OFF. 	
11	Elimination of remaining heat	(1) When the air conditioner stops in the "HEAT" mode, drive the indoor fan with "LOW" mode for approx. 30 seconds.	
12	Flap control	 (1) Flap position setup (Wired type) The flap position can be set up in the following operation range. In cooling/dry operation In heating/fan operation In cooling/dry operation In heating/fan operation (a) In group operation, the flap positions can be set up collectively or individually. (2) Swing setup The swinging position can be moved in the following operation range. All modes Collectively or individually. (3) Fix set up (Wireless type) Keep pressing or pressing briefly the FIX button to move the flap in the desired direction. Operating angle of flap will be different during cooling, dry and heating operation. (4) When the unit stops, the flap automatically closes. (5) While the heating operation is ready, the flap automatically moves upward. 	

No.	Item			(Outline of s	pecific	ations		Remarks
13	 Filter sign display (None in wireless type) * Provided in the separately laid type TCB-AX21E2. (1) The operation time of the indoor fan is integrated and stored in memory, and the filter exchange signal is sent to the remote controller to display on the remote controller LCD after the specified time. (150H) (2) When the filter reset signal is received form the remote controller, time of the integrated timer is cleared. In this time, if the specified time has passed, the measured time is reset and LCD display disappears. 								
14	Operation sta Heating stand	-	 (1) When "P09 sup "P10 indo "L30 indo (2) Force 	any of 5" - Det oly wirir 0" - Det oor unit 0" - Det oor unit d therm	the DN code ection of an og ection of ind ection of an no OFF	es listed open pl oor floo interloc	d below is hase in th ding in a k alarm ir	ne power t least one n at least one	 "OPERATION STANDBY (j) " displayed No display provided on wireless remote controller
	 "COOL/DRY" operation is unavailable beca least one indoor unit is operating in "HEAT" "HEAT" operation is unavailable because at indoor unit is operating in "COOL/DRY" mo priority cooling setting (bit 1 of SW11 on ou P.C. board ON). (3) All indoor units not able to engage in any of operations stand by in thermo OFF state. (4) The indoor fan has been turned off because system is engaged in a heat refrigerant (oil) operation. 					AT" mode. e at least one mode under n outdoor I/F of the above ise the			
			 (1) Norm During (2) During (UL o from b) (3) Force "HE indo prio 	 <heating standby=""> Displayed on wired remote controller</heating> (1) Normal thermo OFF During heating, the indoor unit goes thermo OFF as the heating temperature setting is reached. (2) During heating, the fan rotates at a breeze speed (UL or lower) or remains stationary to prevent cold air from being discharged (including defrosting operation). (3) Forced thermo OFF "HEAT" operation is unavailable because at least one indoor unit is operating in "COOL/DRY" mode under priority cooling setting (bit 1 of SW11 on outdoor I/F P.C. board ON). 				 "HEATING STANDBY (*)" " displayed 	
15	Selection of control mode		indoo throug (2) Settin	r unit re gh the s g detail	emote contro setting of the	ller can	be deter		 In the case of a wired remote controller, "CEN- TRAL CONTROL IN PROGRESS ()" is displayed (lit up) while in central control mode.
	Operation via		Opera	ation via	RBC-AMT32	UL		RBC-	 The display blinks when a control function
	TCC-Link central control	Start/stop selection	Operation mode selection	Timer setting	Temperature setting	Fan speed setting	Air flow direction setting	AMT32UL display	 control function inaccessible to a remote controller is chosen. A wireless remote
	Individual	0	0	0	0	0	0		controller has the same set
	Central 1	×	0	×	0	0	0	"CENTRAL	of control functions, although there is no
	Central 2	×	×	×	×	0	0	CONTROL IN PROGRESS"	display. When a control operation
	Central 3	0	×	0	×	0	0		is performed via a wireless
	Central 4	0	×	0	0	0	0		remote controller while in central control mode, a peep sound alert (5 times) is provided.


No.	ltem	Outline of specifications	Remarks
16	Hi POWER operation (Wireless remote control specific operations)	 When you press the Hi POWER button during cooling, heating or A operation, the air conditioner will start the following operation. Cooling operation Performs the cooling operation at 2.0F°(1°C) lower than the setting temperature. Only when the fan speed before the Hi POWER operation is not high, the fan speed will be increased. Heating operation Performs the heating operation at 3.5F°(2°C) higher than the setting temperature. Only when the fan speed before the Hi POWER operation is not high, the fan speed before the Hi POWER operation is not high, the fan speed before the Hi POWER operation is not high, the fan speed before the Hi POWER operation is not high, the fan speed before the Hi POWER operation is not high, the fan speed will be increased.	
17	ECO timer operation (Wireless remote control specific operations)	<text><text><text><text><text><text><text></text></text></text></text></text></text></text>	

No.	ltem	Outline of specifications	Remarks
18	PRESET operation (Wireless remote control specific operation)	 To operate the air conditioner with the setting memorized. (1) Press the PRESET button. The setting memorized will be indicated and the air conditioner operates with regards to the setting. The lamp (White) on the display panel of the indoor unit goes on, and operation starts after approximately 3 minutes. Initial setting: MODE : AUTO Temperature : 22 (Memorized Setting) (1) Select your preferred operation (2) Press and hold PRESET PRESET button more than 3 seconds. The (P) make is indicated and the setting is memorized. (3) Press the PRESET button to operate the setting memorized. 	1 PRESET TEMP. TEMP. TEMP. TEMP. TIMER FIX € QUIET H POWER TIMER COMFORT ▲ CLR SLEEP ON OFF SET OFF SET CLR SLEEP ON OFF SET CLR COMFORT ▲ CLR CLR COMFORT ▲ CLR CLR COMFORT ▲ CLR CLR CLR CLR CLR CLR CLR CLR
19	DC motor	 (1) When the fan stator, positioning is performed for the starter and the rotor. (Vibrate slightly) (2) DC motor operates according to the command from the indoor controller. (Note) If the fan lock was detected, the operation of the indoor unit stops and the error is displayed. 	Check code [P12]
20	Save operation	 The save operation starts when sweet of the vired remote controller is turned on. While the save operation is performed, segment goes on the screen of the wired remote controller. The request capacity ratio is restricted to approx. 75% during save operation. If the save operation was validated, the contents are held during the operation stop, the operation mode change and the resetting of power supply. Therefore the operation at the next time also will be activated with "Save operation is valid" 	RBC-AMT32UL

6. CONFIGURATION OF CONTROL CIRCUIT


6-1. Indoor Controller block diagram (MCC-1696)

6-1-1. Connection of wired remote controller




208/230-1-60Hz

6-1-2. Connection of Wireless Remote Controller



6-2. Indoor P.C. Board MCC-1696



Wall-Type P.C. Board Optional Switch/Connector Specifications

Function	Connector No.	Pin No.	Specifications	Remarks
Terminator resistor provided/Not provided	SW01	Bit 1	OFF: No terminator resistor, ON: Terminator resistor provided	Setup at shipment OFF: No terminator resistor. Only 1 unit is ON during central control by custom only.
Remote controller A/B		Bit 2	OFF: Remote controller A ON: Remote controller B	Setup at shipment OFF: Remote controller A
For output	CNI22	1	DC12V	Setup at shipment: Linked operation of ON with operation of indoor unit and OFF with stop
Fan output	CN32	2	Output	 * The setup of single operation by FAN button on remote controller is executed from remote controller. (DN = 31)
		1	Start/Stop input	HA Start/Stop input (J01: Provided/Not provided = Pulse (At shipment from factory)/Static input switch)
		2	0V (COM)	
НА	CN61	3	Handy prohibition input	Operation stop of handy remote controller is permitted / prohibited by input.
nA	CINOT	4	Operation output	ON during operation (Answer back of HA)
		5	DC12V (COM)	
		6	Alarm output	ON during output of alarm
		1	DC12V (COM)	
		2	Defrost output	ON during defrosting of outdoor unit
		3	Thermo-ON output	ON when Real thermo. ON (Comp. ON)
Optional output	CN60	4	Cooling output	ON when operation mode is cooling line (Cool, Dry, Cooing/Heating AUTO cooling)
		5	Heating output	ON when operation mode is heating line (Heat, Cooling/Heating AUTO heating)
		6	Fan output	ON when indoor fan is ON
	CN80	1	DC12V (COM)	At shipment from factory, the error code "L30" generates and optional error input to stop operation forcedly (DN:2A = 1) is
Outside error input		2	DC12V (COM)	controlled (Display of protection for devices attached to outside) by setup of outside error input (DN:2A = 2) for 1 minute.
		3	Filter/Option/Outside error input	* Optional error input control is set up on the remote controller.
СНК		1	Check mode input	This check is used for operation check of indoor unit. (The specified operation such as indoor fan "H", drain pump
Operation check	CN71	2	0V	ON, etc. is executed without communication with outdoor unit or remote controller.)
		1	Display mode input	Display mode, communication is enabled by indoor unit and
DISP Display mode	CN72	2	0V	remote controller only. (When power supply is turned on.)
		4	Demondianut	Timer short (Usual)
EXCT	CN73	1	Demand input	Indoor unit forced thermo-OFF operation
Demand		2	0V	
Input for float	CN34	1	DC12V	Normal when between ①-③ short-circuits, but
SW	01104	2	NC	abnormal when open-circuits. (check code "P10" appears)
		3	Float SW input	
Output for	CN81	1	DC12V	
Flow selector unit	CINOT	2	EP valve output (Open collector)	
		3	Balance valve output (Open collector)	
		4	Suction valve output (Open collector)	
		5	Discharge valve output (Open collector)	
Output power	CN309	1	AC230V	This can be used as power supply for option devices.
supply for option	014009	3	AC230V	
Connection		1	DC12V	Connected Application control kit (TCB-PCUC2E)
for option	CN521	2	DC5V	
P.C.board		3	Send	
		4	Receive	
		5	0V	
		5	U V	

6-3. Functions at test run

■ Cooling/Heating test run check

The test run for cooling/heating can be performed from either indoor remote controller or outdoor interface P.C. board.


1. Start/Finish operation of test run

⊙ Test run from indoor remote controller

— Wired remote controller: Refer to the below item of "Test run" of the wired remote controller.

- Wireless remote controller: Refer to the next page item of "Test run" of the wireless remote controller.

In case of wired remote controller <RBC-AMT32UL>



Procedure	Operation contents	
1	Push [TEST] button for 4 seconds or more. [TEST] is displayed at the display part and the mode enters in TEST mode.	
2	Push [ON/OFF] button.	
3	 Change the mode from [COOL] to [HEAT] using [MODE] button. Do not use [MODE] button for other mode except [COOL]/[HEAT] modes. The temperature cannot be adjusted during test run. The error detection is performed as usual. 	**
4	After test run, push [ON/OFF] button to stop the operation. (Display on the display part is same to that in Procedure 1 .)	
5	Push [TEST] button to clear the TEST mode. ([TEST] display in the display part disappears and status becomes the normal stop status.)	

Note) The test run returns to the normal operation after 60 minutes.

In case of wireless remote controller

REQUIREMENT

- 1. For the operation procedure, be sure to follow the matter.
- Finish the forced cooling operation in a short time because it applies excessive strength to the air conditioner.
- 3. A test operation of forced heating is unavailable. Perform a test operation by heating operation using the switches of the remote controller.


However heating operation may be not carried out according to the temperature conditions.

• Check wiring/piping of indoor and outdoor units

- 1. Open the front panel.
- 2. When pushing [RESET] button for 10 seconds or more, "Pi!" sound is heard and the operation changes to a forced cooling operation. After approx. 3 minutes, a cooling operation starts forcedly. Check cool air starts blowing. If the operation does not start, check wiring again.
- 3. To stop a test operation, push [RESET] button once again (Approx. 1 second). The up/down air flow adjusting plate closes and the operation stops.

Check transmission of remote controller

- 1. Push "START/STOP" button of the remote controller to check an operation can also start by the remote controller.
 - When pushing [RESET] button once (For 1 second), the operation changes to automatic operation. For a forced cooling operation, keep the [RESET] button pushed over 10 seconds.
 - "Cooling" operation by the remote controller may be unavailable according to the temperature conditions. Check wiring/piping of the indoor and outdoor units in forced cooling operation.



■ Check function for operation of indoor unit (Functions at indoor unit side)

This function is provided to check the operation of the indoor unit singly without communication with the remote controller or the outdoor unit. This function can be used regardless of operation or stop of the system.

However, if using this function for a long time, a trouble of the equipment may be caused. Limit using this function within several minutes.

[How to operate]

- Short-circuit CHK pin (CN71 on the indoor P.C. board). The operation mode differs according to the indoor unit status in that time. Normal time: Both float SW and fan motor are normal. Abnormal time: Either one of float SW or fan motor is abnormal.
- Restricted to the normal time, if short-circuiting DISP pin (CN72 on the indoor P.C. board) in addition to short-circuit of CHK pin (CN71 on the indoor P.C. board), the minimum opening degree (30pls) can be set to the indoor PMV only.

When open DISP pin, the maximum opening degree (1500pls) can be obtained again.

[How to clear]

Open CHK pin. While the system is operating, it stops once but automatically returns to operation after several minutes.

	Norma	al time	Abnormal time
	DISP pin open	DISP pin short circuit	Abilormartime
Fan motor	(H)	(H)	Stop
Indoor PMV (*)	Max. opening degree (1500pls)	Min. opening degree (30pls)	Min. opening degree (30pls)
Louver	Horizontal	Horizontal	Immediate stop
Drain pump	ON	ON	ON
Communication	All ignored	All ignored	All ignored
P.C. board LED	Lights	Lights	Flashes

• To exchange the indoor PMV coil, set the indoor PMV to Max. opening degree.


• For the detailed positions of CHK pin (CN71 on indoor P.C. board) and DISP pin (CN72 on indoor P.C. board), refer to the indoor P.C. board MCC-1696.

7. APPLIED CONTROL

7-1. Setup of Selecting Function in Indoor Unit

(Be Sure to Execute Setup by a Wired Remote Controller)

<Procedure> Execute the setup operation while the unit stops.



- **1** Push SET, CL, and SET buttons simultaneously for 4 seconds or more. The firstly displayed unit No. indicates the header indoor unit address in the group control. In this time, the fan of the selected indoor unit is turned on.
- 2 Every pushing button, the indoor unit numbers in the group control are successively displayed. In this time, the fan of the selected indoor unit only is turned on.
- **3** Specify the CODE No. (DN) using the setup temperature \bigcirc and \bigcirc buttons.
- 4 Select the setup data using the timer time → and buttons.
 (When selecting the CODE No. (DN) to " ∃∃", change the temperature indication of the unit from " °C " to " °F " on the remote controller.)
- **5** Push $\stackrel{\text{\tiny SET}}{\frown}$ button. (OK if display goes on.)
 - To change the selected indoor unit, return to procedure ${f 2}$.
 - To change the item to be set up, return to procedure $\boldsymbol{3}$.
- **6** Pushing $\stackrel{\text{TEST}}{\frown}$ button returns the status to normal stop status.

Table: Function selecting item numbers (DN) (Items necessary to perform the applied control at the local site are described.)

CODE No. [DN]	ltem	Description	At shipment
01	Filter display delay timer	0000 : None 0001 : 150H 0002 : 2500H 0003 : 5000H 0004 : 10000H	0002 : 2500H
02	Dirty state of filter	0000 : Standard 0001 : High degree of dirt (Half of standard time)	0000 : Standard
03	Central control address	0001 : No.1 unit to 0064 : No.64 unit 0099 : Unfixed	0099 : Unfixed
04	Specific indoor unit priority	0000 : No priority 0001 : Priority	0000 : No priority
06	Heating temp shift	0000 : No shift 0001 : +1.8°F(1°C) 0002 : +3.6°F(2°C) to 0010 : +18°F(10°C) (Up to +6 recommended)	0002 : +3.6°F(2°C) (Floor type 0000: 0°C)
0d	Existence of [AUTO] mode	0000 : Provided 0001 : Not provided (Automatic selection from connected outdoor unit)	0001 : Not provided
0F	Cooling only	0000 : Heat pump 0001 : Cooling only (No display of [AUTO] [HEAT])	0000 : Heat pump
10	Туре	0008 : High Wall	Depending on model type
11	Indoor unit capacity	0000 : Unfixed 0001 to 0041	According to capacity type
12	Line address	0001 : No.1 unit to 0030 : No.30 unit	0099 : Unfixed
13	Indoor unit address	0001 : No.1 unit to 0064 : No.64 unit	0099 : Unfixed
14	Group address	0000 : Individual 0001 : Header unit of group 0002 : Follower unit of group	0099 : Unfixed
1E	Temp difference of [AUTO] mode selection COOL \rightarrow HEAT, HEAT \rightarrow COOL	0000 : 0 deg to 0010 : 10 deg (For setup temperature, reversal of COOL/HEAT by ± (Data value)/2)	0003 : 3 deg (Ts±1.5)
28	Automatic restart of power failure	0000 : None 0001 : Restart	0000 : None
2A	Selection of option/error input (CN70)	0000 : Filter input 0001 : Alarm input (Air washer, etc.) 0002 : None	0002 : None
2E	HA terminal (CN61) select	0000 : Usual 0001 : Leaving-ON prevention control 0002 : Fire alarm input	0000 : Usual (HA terminal)
31	Ventilating fan control	0000 : Unavailable 0001 : Available	0000 : Unavailable
32	TA sensor selection	0000 : Body TA sensor 0001 : Remote controller sensor	0000 : Body TA sensor
33	Temperature unit select	0000 : °C (at factory shipment) 0001 : °F	0001 : °F

CODE No. [DN]	Item	Description	At shipment
60	Timer setup (Wired remote controller)	0000 : Available (Operable) 0001 : Unavailable (Operation prohibited)	0000 : Available
7A	Change unit +0.9°F(0.5°C) or +1.8°F(1.0°C) on remote	0000 : +0.9°F(0.5°C) 0001 : 1.8°F(1.0°C)	0000 : +0.9°F(0.5°C)
E0	Region	0000 : Japan model 0001 : North America model	0001 : North America model

TYPE CODE No. [10]

Setting data	Туре	Type name abb.
0008 *1	High Wall	MMK-AP***HPUL

* 1 EEPROM initial value on the P.C.board for indoor unit servicing

Indoor unit capacity CODE No. [11]

Setting data	Туре	
0000*	Disable	
0007	015	
0009	018	
0011	024	

* EEPROM initial value on the P.C. board for indoor unit servicing.

7-2. Applied Control in Indoor Unit

Remote location ON/OFF control box (TCB-IFCB-4UL)

[Wiring and setup]


- Use the exclusive connector for connection with the indoor control P.C. board.
- In a group control, the system can operate when connecting with any indoor unit (Control P.C. board) in the group. However when taking out the operation/error signal from the other unit, it is necessary to take out from each unit individually.

1. Control items

- 1) Start/Stop input signal : Operation start/stop in unit
- 2) Operation signal : Output during normal operation
- 3) Error signal : Output during alarm
 - (Serial communication error or indoor/outdoor protective device) operation

2. Wiring diagram using remote control interface (TCB-IFCB-4UL)

InputIFCB-4UL : No voltage ON/OFF serial signalOutputNo voltage contact for operation, error display
Contact capacity: Below Max. AC240V 0.5A



Ventilating fan control from wired remote controller

[Function]

- The start/stop operation can be operated from the wired remote controller when air to air heat exchanger or ventilating fan is installed in the system.
- The fan can be operated even if the indoor unit is not operating.
- Use a fan which can receive the no-voltage A contact as an outside input signal.
- In a group control, the units are collectively operated and they can not be individually operated.

1. Operation

Handle a wired remote controller in the following procedure.

- * Use the wired remote controller during stop of the system.
- * Be sure to set up the wired remote controller to the header unit. (Same in group control)
- * In a group control, if the wired remote controller is set up to the header unit, both header and follower units are simultaneously operable.

1 Push concurrently $\stackrel{\text{\tiny SET}}{\longrightarrow}$ + $\stackrel{\text{\tiny CL}}{\longrightarrow}$ + $\stackrel{\text{\tiny TEST}}{\swarrow}$ buttons for 4 seconds or more.

The unit No. displayed firstly indicates the header indoor unit address in the group control. In this time, the fan of the selected indoor unit turns on.

2 Every pushing button (button at left side), the indoor unit numbers in group control are displayed successively.

In this time, the fan of the selected indoor unit only turns on.

- **3** Using the setup temp \bigcirc or \bigcirc button, specify the CODE No $\exists l$.
- **4** Using the timer time **•** or **•** button, select the setup data. (At shipment: **0000**) The setup data are as follows:


Setup data	Handling of operation of air to air heat exchanger or ventilating fan
0000	Unavailable (At shipment)
0001	Available

5 Push $\stackrel{\text{\tiny SET}}{\frown}$ button. (OK if display goes on.)

- To change the selected indoor unit, go to the procedure **2**).
- To change the item to be set up, go to the procedure **3**).

6 Pushing $\overset{\text{TEST}}{\bigotimes}$ returns the status to the usual stop status.

2. Wiring



■ Leaving-ON prevention control (with Wired remote controller)

[Function]

- This function controls the indoor units individually. It is connected with cable to the control P.C. board of the indoor unit.
- In a group control, it is connected with cable to the indoor unit (Control P.C. board), and the CODE No. 2E is set to the connected indoor unit.
- It is used when the start operation from outside if unnecessary but the stop operation is necessary.
- Using a card switch box, card lock, etc, the forgotten-OFF of the indoor unit can be protected.
- When inserting a card, start/stop operation from the remote controller is allowed.
- When taking out a card, the system stops if the indoor unit is operating and start/stop operation from the remote controller is forbidden.

1. Control items

- 1) Outside contact ON : The start/stop operation from the remote controller is allowed. (Status that card is inserted in the card switch box)
- 2) Outside contact OFF : If the indoor unit is operating, it is stopped forcedly. (Start/Stop prohibited to remote controller)


(Status that card is taken out from the card switch box)

* When the card switch box does not perform the above contact operation, convert it using a relay with B contact.

2. Operation

Handle the wired remote controller switch in the following procedure.


- \ast Use the wired remote controller switch during stop of the system.
- **1** Push concurrently $\stackrel{\text{set}}{\frown} + \stackrel{\text{cL}}{\frown} + \stackrel{\text{rest}}{\swarrow}$ buttons for 4 seconds or more.
- **2** Using the setup temp \bigcirc or \bigcirc button, specify the CODE No. **2***E*.
- **3** Using the timer time \bigcirc or \bigcirc button, set **0001** to the setup data.
- **4** Push \bigcirc^{SET} button.
- **5** Push status returns to the usual stop status.)



Note) Determine the cable length between the indoor control P.C. board and the relay within 79"(2m)

Power peak-cut from indoor unit

When the relay is turned on, a forced thermostat-OFF operation starts.




Note) Determine the cable length between the indoor or outdoor control P.C. board and the relay within 79"(2m)


Address setup (Manual setting from Wired remote controller)


In case that addresses of the indoor units will be determined prior to piping work after wiring work

- Set an indoor unit per a remote controller.
- Turn on power supply.
- **1** Push $\stackrel{\text{SET}}{\longrightarrow}$ + $\stackrel{\text{CL}}{\longrightarrow}$ + $\stackrel{\text{TEST}}{\swarrow}$ buttons simultaneously for 4 seconds or more.
- 2 (Line address) Using the temperature setup ▼ / ▲ buttons, set *1*2 to the CODE No.
- **3** Using timer time () / () buttons, set the line address.
- **4** Push $\stackrel{\text{\tiny SET}}{\bigcirc}$ button. (OK when display goes on.)
- 5 (Indoor unit address) Using the temperature setup ▼ / ▲ buttons, set / J to the CODE No.
- **6** Using timer time I buttons, set 1 to the line address.
- 7 Push $\stackrel{\text{\tiny SET}}{\frown}$ button. (OK when display goes on.)
- 8 (Group address) Using the temperature setup ▼ / ▲ buttons, set / 4 to the CODE No.
- 9 Using timer time ▼ / ▲ buttons, set 0000 to Individual, 0001 to Header unit and 0002 to follower unit.
- 10 Push ^{SET} button. (OK when display goes on.)
- Push ^{TEST} button.
 Setup completes.
 (The status returns to the usual stop status.)



For the above example, perform setting by connecting singly the wired remote controller without remote controller inter-unit cable.





Note 1)

When setting the line address from the wired remote controller, do not use Address 29 and 30. As they are addresses which cannot be set to the outdoor unit, if they are set, the check code [E04] (Indoor/Outdoor communication circuit error) is issued.

Note 2)

When an address was manually set from the wired remote controller and the central control over the refrigerant lines is carried out, perform the following setting for the Header unit of each line.

- Set the line address for every line using SW13 and 14 on the interface P.C. board of the Header unit in each line.
- Except the least line address No., turn off SW30-2 on the interface P.C. board of the Header units in the lines connected to the identical central control.

(Draw the terminal resistances of indoor/outdoor and central control line wirings together.)

- For each refrigerant line, connect the relay connector between Header unit [U1U2] and [U3U4] terminals.
- After then set the central control address. (For setting of the central control address, refer to the Installation manual for the central remote controller.)

Confirmation of indoor unit No. position

- 1. To know the indoor unit addresses though position of the indoor unit is recognized
 - In case of individual operation (Wired remote controller : indoor unit = 1 : 1) (Follow to the procedure during operation)

<Procedure>


- **1** Push $\underbrace{(UON/OFF)}_{UON/OFF}$ button if the unit stops.
- **2** Push $\underbrace{\overset{\text{UNIT LOUVER}}{\bullet}}_{\bullet}$ button (button at left side).

Unit No. **1-1** is displayed on LCD.

(It disappears after several seconds.)

The displayed unit No. indicate line address and indoor unit address.

(When other indoor units are connected to the identical remote controller (Group control unit), other unit numbers are also displayed every pushing \bigcirc button (button at left side).



<Operation procedure> 1 →2 END


2. To know the position of indoor unit by address


• To confirm the unit No. in the group control (Follow to the procedure during operation) (in this procedure, the indoor units in group control stop.)

<Procedure>

The indoor unit numbers in the group control are successively displayed, and fan, louver, and drain pump of the corresponding indoor unit are turned on. (Follow to the procedure during operation)

- 1 Push ^{VENT} and ^{TEST} buttons simultaneously for 4 seconds or more.
 - Unit No. *ALL* is displayed.
 - Fans and louvers of all the indoor units in the group control operate.
- 2 Every pushing button (button at left side), the unit numbers in the group control are successively displayed.
 - The unit No. displayed at the first time indicates the header unit address.
 - Fan and louver of the selected indoor unit only operate.
- 3 Push [™] button to finish the procedure. All the indoor units in the group control stop.






Function selection setup

<Procedure> Perform setting while the air conditioner stops.

- **1** Push $\overset{\text{TEST}}{{ }}$ + $\overset{\text{SET}}{\bigcirc}$ + $\overset{\text{CL}}{\bigcirc}$ buttons simultaneously for 4 seconds or more. The first displayed unit No. is the header indoor unit address in the group control. In this time, fan and louver of the selected indoor unit operate. Û Every pushing button (button at left side), the indoor unit No. in the group control is 2 displayed one after the other. In this time, fan and louver of the selected indoor unit only operate. Û Using the set temperature $\overset{\texttt{RTEMP.}}{\textcircled{\baselineskip}}$ buttons, specify the CODE No. (DN). 3 Û Using the timer time $\overline{\mathbf{v}}^{\text{TME}}$ buttons, select the set data. Û **5** Push $\stackrel{\text{\tiny SET}}{\bigcirc}$ button. (OK if indication lights) • To change the selected indoor unit, proceed to Procedure 2. • To change item to be set up, proceed to Procedure **3**. Ŷ
- **6** Pushing $\overset{\text{TEST}}{>}$ button returns the status to the normal stop status.



How to check all the unit No. from an arbitrary wired remote controller

<Procedure> Carry out this procedure during stop of system.

The indoor unit No. and the position in the identical refrigerant piping can be checked.

An outdoor unit is selected, the identical refrigerant piping and the indoor unit No. are displayed one after the other, and then its fan and louver are on.

- Push the timer time button (▼) + ^{TEST} simultaneously for 4 seconds or more. First line 1 and CODE No. AC (Address Change) are displayed. (Select outdoor unit.)
- 2 Select line address using $\underbrace{I_{LOUVER}}_{\square} / \underbrace{I_{\square}}_{\square}$ button.
- **3** Determine the selected line address using $\stackrel{\text{\tiny SET}}{\frown}$ button.
 - The address of the indoor unit connected to the refrigerant piping of the selected outdoor unit is displayed and the fan and the louver are on.

Û

- 4 Every pushing button (button at left side), the indoor unit No. in the identical piping is displayed one after the other.
 - Only fan and louver of the selected indoor unit start operation.


[To select the other line address]


5 Push $\stackrel{\alpha}{\bigcirc}$ button and the operation returns to Procedure 2.

* The indoor address of other line can be continuously checked.



6 Push $\stackrel{\text{TEST}}{>}$ button and then the procedure finishes.





How to change all indoor addresses from an arbitrary wired remote controller

(It is possible when setting has finished by automatic addresses.)

Contents: The indoor unit addresses in each identical refrigerant piping line can be changed from an arbitrary wired remote controller.

⊙ Enter in address check/change mode and then change the address.

<Procedure> Carry out this procedure during stop of system.

- **1** Push the timer time button \bigcirc + $\stackrel{\text{TEST}}{>}$ simultaneously for 4 seconds or more. First line 1 and CODE No. \mathcal{H} (Address Change) are displayed.
- 2 Select line address using UNIT LOUVER / SWING/FIX

Ŷ

Û

3 Push the \bigcirc^{SET} button.

• The address of the indoor unit connected to the refrigerant piping of the selected outdoor unit is displayed and the fan and the louver are on. First the current indoor address is displayed.

(Line address is not displayed.)

Û

4 (▼) ▲ button push up/down the indoor address of the SET DATA.

The set data is changed to a new address.

Û

5 Push $\stackrel{\text{\tiny SET}}{\frown}$ button to determine the set data.

$\hat{\Gamma}$

- 6 Every pushing button (button at left side), the indoor unit No. in the identical piping is displayed one after the other.
 - Only fan and louver of the selected indoor unit start operation.


Repeat the Procedures **4** to **6** to change all the indoor addresses so that they are not duplicated.

Û

7 Push ^{SET} button. (All the indications of LCD go on.)


Û

8 Push [™] button and then the procedure finishes.



If the UNIT No. is not call up here, the outdoor unit in that line does not exist.

Push $\stackrel{\text{\tiny CL}}{\bigcirc}$ button to select a line again in the Procedure $\mathbf{2}$.



Function to clear error


1. Clearing method from remote controller

⊙ How to clear error of outdoor unit

In the unit of refrigerant line connected by indoor unit of the remote controller to be operated, the error of the outdoor unit currently detected is cleared. (Error of the indoor unit is not cleared.) The service monitor function of the remote controller is utilized.

<Method>

- Push ^{CL}→ + ^{TEST} buttons simultaneously for 4 seconds or more to change the mode to service monitor mode.
- **2** Push $\overrightarrow{\mathbf{T}}$ button to set the CODE No. to [*FF*].
- **3** The display of A part in the following figure is counted as "0005" \rightarrow "0004" \rightarrow "0003" \rightarrow "0003" \rightarrow "0001" \rightarrow "0000" with 5-seconds interval. When "0000" appear, the error was cleared.
 - * However counting from "OOOS" is repeated on the display screen.
- 4 When pushing $\overset{\text{TEST}}{\swarrow}$ button, the status becomes normal.



Returns to normal status

● How to clear error of indoor unit

The error of indoor unit is cleared by button of the wired remote controller. (Only error of the indoor unit connected with wired remote controller to be operated is cleared.)

Monitoring function of remote controller switch

When using the remote controller (Model Name: RBC-AMT32UL), the following monitoring function can be utilized.

Calling of display

<Contents>

The temperature of each sensor of the remote controller, indoor unit and outdoor unit and the operating status can be checked by calling the service monitor mode from the remote controller.

<Procedure>

1 Push $\stackrel{\text{TEST}}{\Rightarrow}$ + $\stackrel{\circ}{\bigcirc}$ buttons simultaneously for 4 seconds or more to call up the service monitor mode. The service monitor goes on and firstly the temperature of the CODE No. \mathcal{GO} is displayed.

Ĵ


Ŷ

3 Push (left side button) button to change to item to be monitored.

The sensor temperature of indoor unit or outdoor unit in its refrigerant line and the operating status are monitored.

Ŷ

4 Push [™] button to return the status to the normal display.



< Based on the SMMS-e >

	CODE No.	Data name	Display format	Unit	Remote control display example
	00	Room temperature (Use to control)	×1	°C	[0027] = 27 °C
	01	Room temperature (Remote control)	×1	°C	[0027] = 27 0
*2	02	Indoor suction air temperature (TA)	×1	°F	
data	03	Indoor coil temperature (TCJ)	×1	°F	
ţd	04	Indoor coil temperature (TC2)	×1	°F	[0075]= 75 °F
unit	05	Indoor coil temperature (TC1)	×1	°F	
Indoor	06	Indoor discharge air temperature (TF) *1	×1	°F	
Ъ	08	Indoor PMV opening	×1/10	pls	[0150]= 1500 pls
-	F3	Filter sign time	×1	h	[2500] = 2500h
	F9	Suction temperature of air to air heat exchanger (TSA) *1	×1	°F	[0080]= 80 °F
a	FA	Outside air temperature (TOA)*1	×1	°F	
data	0A	No. of connected indoor units	×1	unit	[0048]= 48 units
System	0B	Total horsepower of connected indoor units	×10	ton	[0215]= 21.5 ton
/ste	0C	No. of connected outdoor units	×1	unit	[0003]= 3 units
Ś	0D	Total horsepower of outdoor units	×10	ton	[0160]= 16 ton

	CO	DE I	No.	Data name	Display format	Unit	Remote control display example
	U1	U2	U3	Data Haine	Display format	Unit	Remote control display example
	10	20	30	High-pressure sensor detention pressure (Pd)	×10	psi	[4350] = 435 psi
ę,	11	21	31	Low-pressure sensor detention pressure (Ps)	×10	psi	[4330] = 433 psi
<u>م</u>	12	22	32	Compressor 1 discharge temperature (TD1)	×1	°F	
data	13	23	33	Compressor 2 discharge temperature (TD2)	×1	°F	
al	15	25	35	Outdoor coil temperature (TE1)	×1	°F	
idu	16	26	36	Outdoor coil temperature (TE2)	×1	°F	
unit individual	17	27	37	Outdoor coil temperature (TG1)	×1	°F	[0075]= 75 °F
it i	18	28	38	Outdoor coil temperature (TG2)	×1	°F	[0075]=75 F
S	19	29	39	Outside ambient temperature (TO)	×1	°F	
0 N	1A	2A	ЗA	Suction temperature (TS1)	×1	°F	
Outdoor	1C	2C	3C	Suction temperature (TS3)	×1	°F	
Ő	1D	2D	3D	Temperature at liquid side (TL1)	×1	°F	
	1E	2E	3E	Temperature at liquid side (TL2)	×1	°F	
	1F	2F	3F	Temperature at liquid side (TL3)	×1	°F	

	CO	DE I	No.	Data name	Display format	Unit	Remote control display example
	U1	U2	U3	Data Hallie	Display format	Unit	Remote control display example
	50	60	70	PMV1 opening	×1	pls	
	51	61	71	PMV3 opening	×1	pls	[0500] = 500pls
*4	52	62	72	PMV4 opening	×1	pls	
data 2	53	63	73	1 fan model : Compressor 1 curent (I1) 2 fan model : Compressor 1 and Outdoor fan 1 current (I1)	×10	A	[0135] = 13.5A
individual o	54	64	74	1 fan model : Compressor 2 and Outdoor fan 1 current (I2) 2 fan model : Compressor 2 and Outdoor fan 2 current (I2)	×10	A	[0135] = 13.5A
divi	56	66	76	Compressor 1 revolutions	×10	rps	[0042] 04 2mg
⊒.	57	67	77	Compressor 2 revolutions	×10	rps	[0642] = 64.2rps
unit	59	69	79	Outdoor fan mode	×1	mode	[0058] = 58 mode
<u>o</u>	5A	6A	7A	Compressor IPDU 1 heat sink temperature	×1	°F	
Outdoor	5B	6B	7B	Compressor IPDU 2 heat sink temperature	×1	°F	[0075]= 75 °F
lõ	5D	6D	7D	Outdoor fan IPDU 1 heat sink temperature	×1	°F	
	5E	6E	7E	Outdoor fan IPDU 2 heat sink temperature	×1	°F	
	5F	6F	7F	Outdoor unit horsepower	×10	ton	[0080] = 8 ton

	CODE No.	Data name	Display format	Unit	Remote control display example
unit Jal *5	90	Heating/cooling recovery controlled	0: Normal		[0010]=Heating recovery controlled
a u u	91	Pressure release	0: Normal		[0010]=Pressure release controlled
Outdoor I individu data 3	92	Discharge temperature release	1: Release control	led	[0001]=Discharge temperature release controlled
o ⊓ O	93	Follower unit release (U2/U3 outdoor units)			[0100]=U2 outdoor unit release controlled

*1 Only a part of indoor unit types is installed with the discharge air temperature sensor. This temperature is not displayed for other types.

- *2 When the units are connected to a group, data of the header indoor unit only can be displayed.
- *3 The first digit of an CODE No. indicates the outdoor unit number.
- *4 The upper digit of an CODE No. -4 indicates the outdoor unit number.
 - 1*, 5* ... U1 outdoor unit (Header unit)
 - 2*, 6* ... U2 outdoor unit (Follower unit 1)
 - 3*, 7* ... U3 outdoor unit (Follower unit 2)
- *5 Only the CODE No. 9* of U1 outdoor unit (Header unit) is displayed.

8. TROUBLESHOOTING

8-1. Troubleshooting Summary


1. Before troubleshooting

- 1) Applied models
 - S-MMS Multi type models
 Indoor unit : MMX-APXXX,
 Outdoor unit : MMY-MAPXXXXT8X, MMY-MAPXXXHT7X
 - ② Super Heat Recovery Multi type models Indoor unit : MMX-APXXX, Outdoor unit : MMY-MAPXXXFT8X
 - Mini-S-MMS Multi type models
 Indoor unit : MMX-APXXX,
 Outdoor unit : MCY-MAPXXXHT, MCY-MAPXXXHT2X
- 2) Required tools / measuring devices
 - Screwdrivers (Philips, Minus), spanner, radio pinchers, nipper, push pin for reset switch, etc.
 - Tester, thermometer, pressure gauge, etc.
- 3) Confirmation before check (The following items are not troubles.)

No.	Operation	Check items
1	Compressor does not operate.	 Is not delayed for 3 minutes? (3 minutes after compressor-OFF) Is not thermostat OFF? Is not the fan operating or timer? Is not the system initially communicating? Heating operation cannot be performed under condition of outside temperature 37.8°F(21°C) or higher. Cooling operation cannot be performed under condition of outside temperature -9°F(-5°C) or lower.
2	Indoor fan does not work.	• Is not the cold draft prevention being controlled in heating operation?
3	Outdoor fan does not rotate, or fan speed changes.	Is not low cooling operation being controlled?Is not a defrost operation being performed?
4	Indoor fan does not stop.	 Is not after-heat elimination operation being controlled after heating operation?
5	Start/stop operation on remote controller is unavailable.	 Is not auxiliary unit or remote control being operated?
6		Is connecting wire of indoor unit or remote controller correct?

2. Troubleshooting procedure

When a trouble occurred, advance the check operation in the following procedure.



NOTE

While a check operation is performed, a malfunction of the microprocessor may be caused due to condition of the power supply or the external noise.

If there is any noise source, change wires of the remote controller and signal wires to shield wires.

×
$\overline{\mathbf{U}}$
<u>v</u>
Ð
ç
<u> </u>
0
-
0
5
2
2
~
0
Ť
Т
-
 i
ω

On the remote controller (Remote controller, Central control remote controller) and on the interface P.C. board of the outdoor unit, LCD display part (Remote controller) or 7segment display part (on outdoor interface P.C. board) is provided in order to display the operation status.

When a trouble occurred, the method to judge the trouble or defective position of the air conditioner by this self-diagnosis function is shown below.

• Check from the indoor remote controller or TCC-LINK central controller: Refer to "Display on remote controller & TCC-LINK central controller" in the following table. The following table shows the list of each check code that each device detects. Check the check contents in the following table according to position to be checked.

- Check from outdoor unit: Refer to "Display of outdoor segment" in the following table.
- Check from indoor unit of wireless remote controller: Refer to Sensor lamp display" in the following table.

Check code display list (Indoor unit)

[Indoor unit detects error.]

(∗) O: Goes on, ⊚: Flashes, ●: Goes off A (Alternate) : Flashing condition is alternate when there are two flashing LED. S (Simultaneously) : Two LED flash simultaneously when there are two flashing LED.

Check	sk code	Check code display	Senso	vr lamp	Sensor lamp display			
TCC-LINK central		Outdoor 7-segment	Bloc	Block display (*)	lay (*)		Main defective position	Description
& remote controller		Auxiliary code	Operation Timer		Ready Fla	Flash		
E03		I	0		•	Re anc	Regular communication error between indoor and remote controller	No communication from remote controller and network adapter (No central control system communication also)
E04		I	•		 ©	Reand	Regular communication error between indoor and outdoor	No communication from outdoor unit
E08	E08	Duplicated indoor unit No.	0		•	Du	Duplicated indoor address	An address same to self address was detected.
E10		I	0		•	Ŝ	Communication error between indoor MCU	Communication error between MCU of main motor microprocessors
E18		I	0		•	Reand	Regular communication error between header and follower in indoor unit	Regular communication between header and follower units in indoor unit was impossible.
F01		I	0	0		A Ind	Indoor heat exchanger temp. sensor (TCJ) error	Open/short of heat exchanger temp. sensor (TCJ) was detected.
F02		I	0	0	•	A Ind	Indoor heat exchanger temp. sensor (TC2) error	Open/short of heat exchanger temp. sensor (TC2) was detected.
F03		I	0	0	•	A Ind	Indoor heat exchanger temp. sensor (TC1) error	Open/short of heat exchanger temp. sensor (TC1) was detected.
F10		I	0	0	- I	A Roo	Room tem. Sensor (TA) error	Open/short of room temp. sensor (TA) was detected.
F11		I	0	0		A Dis	Discharge air temp. sensor (TF) error.	Open/short of discharge air temp. sensor was detected.
F29		I	0	0	•	S Ind	Indoor or other P.C. board error	Indoor EEPROM error (Other error may be detected.)
L03		I	0		0 	s Dul	Duplicated setting of header in indoor group	There were multiple header units in a group.
L07	-	I	0	•	о - ©	S The	nere is group cable in individual indoor unit.	There is even an indoor unit connected to group in individual indoor unit.
L08	L08	I	0		s @	S Ind	Indoor group address is unset.	Indoor group address is unset. (Detected also at outdoor unit side)
F09		I	0		s - ©	S Ind	Indoor capacity is unset.	Capacity of indoor unit is unset.
L20		I	0	0	о ©	s Dul	Duplicated central control system address	Setting of central control system address is duplicated.
L30	L30	Detected indoor unit No.	0	0	s @	S Ext	External error was input in indoor (Interlock).	System abnormally stopped by input of external error (CN80).
P01		I	•	0	@ \	A Ind	Indoor AC fan error	Error of indoor AC can was detected. (Fan motor thermal relay operation)
P10	P10	Detected indoor unit No.	•	0	0 A	A Ind	Indoor overflow was detected.	Float switch operated.
P12		I	•	0	© A	A Ind	Indoor DC fan error	Error (Over-current, lock, etc.) of indoor DC fan was detected.
P31		I	0		∀ 	A Oth	Other indoor unit error	Group follower unit cannot be operated by [E03/L03/L07/L08] alarm of header unit.

Note) The check code display may be different according to the detected device even same error contents such as communication error.

[Remote controller detects error.]

(∗) O: Goes on, ⊚: Flashes, ●: Goes off A (Alternate) : Flashing condition is alternate when there are two flashing LED. S (Simultaneously) : Two LED flash simultaneously when there are two flashing LED.

Check	Check code display	v	Sensor	Sensor lamp display		
Pemote controller	Outdoo	Outdoor 7-segment	Block	Block display (*)	Main defective position	Description
	AI	uxiliary code	Operation Tim	Auxiliary code Operation Timer Ready Flash		
E01		I	0	•	No remote controller header unit, remote controller communication (receive) error	When signal cannot be received from indoor unit, when header of remote controllers was not set (including 2 remote controllers)
E02	-		•	-	Remote controller communication (send) error	When signal cannot be sent to indoor unit
E09		I	6	•	Duplicated remote controller header	In 2-remote controller control, both remote controllers were set to header. (Indoor header stops with alarm and follower unit continues operation.)

[Central controller detects error.]

Check	Check code display	lay	Sensor lamp display		
TCC I NIC control	Outdo	Outdoor 7-segment	Block display (*)	Main defective position	Description
		Auxiliary code	Operation Timer Ready Flash		
C05	 	Ι	Is not displayed	Central control system communication (send) error	When signal of central control system cannot be sent, there are same multiple central devices (AI-NET)
C06		I	(In shared use	Central control system communication (receive) error	When signal of central control system cannot be received
Ι		Ι		There are multiple network adapters.	There were multiple network adapters (AI-NET) on remote controller communication line.
C12	 	I	I	Batched alarm of interface for general-purpose equipment control	Error of equipment connected to control interface of the general-purpose unit exclusive to TCC-LINK/AI-NET
P30	 	I	According to unit with alarm (Abovementioned)	Group follower unit error	Group follower unit error (For remote controller, [****] details is displayed together with unit No.)

Note) The check code display may be different according to the detected device even same error contents such as communication error.

Check code display list (Outdoor unit)

[SMMS-i interface detects error: Main example]

(∗) O: Goes on, ⊚: Flashes, ●: Goes off A (Alternate) : Flashing condition is alternate when there are two flashing LED. S (Simultaneously) : Two LED flash simultaneously when there are two flashing LED.

	Check code display		Sensor lam	amp display	Ŋ		
	Outdoor 7-segment	TCC-LINK central &	Bloc	display	- ī	Main defective position	Description
	+		Operation I Imer	Keady	Flash		No communication from indoce unit
E06	No. of indoor units which received signal normally	E06	•	0		Decrease of quantity of indoor units	No communication from indoor unit (Decrease of connected indoor units)
E07		(E04)	•	0		Indoor/Outdoor communication circuit error	Signal cannot be sent to indoor unit. (→There is no communication from outdoor unit.)
E08	3 Duplicated indoor unit number	(E08)	•	•		Duplicated indoor address	There are multiple indoor units having the same address. (Detected also at indoor unit side)
E12	01: Indoor/Outdoor communication 02: Communication between Outdoor units	E12	•	•	~	Automatic address start error	Automatic indoor address operation while setting automatic address of other system Outdoor automatic address operation while setting automatic indoor address
E15		E15	•	0		There is none during auto addressing.	There is no signal receiving from outdoor unit during automatic addressing.
E16	00: Capacity over 01 ~ : No. of connected units	E16	•	0	20	No. of connected indoor units: Over capacity	Total capacity of indoor units exceeded (total capacity of outdoor units \times 135%)*
E19		E19	•	0	~	No. of center outdoor units error	There is no center outdoor unit or there are 2 or more outdoor units in 1 line.
E20		E20	•	0	0.0	Connected to other line during automatic addressing	Indoor unit of other line was detected during automatic address is been setting.
E21		E21	•	0	-	Header heat unit quantity error	There is no header heat unit in the system, or there are multiple header units.
E22		E22	•	0		Decrease of heat unit quantity	No communication from heat unit (Decrease of connected heat units)
E23		E23	•	0		Send error communication between outdoor units	Sending to other outdoor is unavailable.
E25		E25	•	0		Duplicated terminal outdoor address setting	Manually set outdoor address was duplicated.
E26	Receive error of outdoor address	E26	•	0		Decrease of connected outdoor units	No communication from terminal outdoor unit (Decrease of connected terminal outdoor units)
E28	3 Detected outdoor unit number	E28	•	0		Terminal outdoor error	Center outdoor unit detected terminal outdoor unit error. (For terminal outdoor unit, details are displayed.)
Е31	A3-IPDU FAN A3-IPDU FAN 1 2 3 IPDU 0 1 2 3 IPDU 01 0 <td>E 31</td> <td>•</td> <td>©</td> <td>_</td> <td>IPDU communication error</td> <td>No communication of each IPDU (P.C. board) in inverter box</td>	E 31	•	©	_	IPDU communication error	No communication of each IPDU (P.C. board) in inverter box
F04	1	F04	0	0	A	Outdoor discharge temp. sensor (TD1) error	Open/Short of outdoor discharge temp. sensor (TD1) was detected.
F05		F05		0		Outdoor discharge temp. sensor (TD2) error	Open/Short of outdoor discharge temp. sensor (TD2) was detected.
F06	5 01: TE1 02: TE2	F06	0	0	<	Outdoor heat exchanger temp. sensor (TE1, TE2) error	Open/Short of heat exchanger temp. sensor (TE1, TE2) was detected.
F07	+	F07	0	0		Outdoor liquid temp. sensor (TL) error	Open/Short of outdoor liquid temp. sensor (TL) was detected.
		F08		o	۷ ۲	Outdoor outer air temp. sensor (TO) error	Open/Short of outer air temp. sensor (TO) was detected.
F12		F12		С	+	Outdoor suction temp. sensor (TS1) error	Deen/Short of outdoor suction temp. sensor (TS1) was detected.
F15	1	F15		0	A	Outdoor temp. sensor (TE1, TL) miswiring	Miswiring by temp. sensor (TE1, TL) was detected.
F16		F16		0		Outdoor pressure sensor (Pd, Ps) miswiring	Miswiring by outdoor pressure sensor (Pd, Ps) was detected.
F22	1	F22	00		4	Outdoor discharge temp. sensor (TD3) error	Open/Short of outdoor discharge temp. sensor (TD3) was detected.
F24		F24				High pressure (Pd) sensor error	Output voltage of how pressure (Pd) sensor detected 0 or error value was
F31	1	F31		0	ں ا	Outdoor EEPROM error	uerected during stop of compressor. Outdoor EEPROM error (Center unit stops altant and terminal unit continues operation.).
- - *	of consolity of index unit connect	tion coloridate MANK		UD C/ TD/	6		

* In case of capacity of indoor unit connection, calculate MMK-AP0054MHP-E(-TR) as 0.6HP

(∗) O: Goes on, ⊚: Flashes, ●: Goes off A (Alternate) : Flashing condition is alternate when there are two flashing LED. S (Simultaneously) : Two LED flash simultaneously when there are two flashing LED.

$ \begin{array}{ $				ľ			$\left \right $		
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$				Ne l		p display		:	-
$ \begin{array}{c c c c c c c c c c c c c c c c c c c $		Outdoor /-segment	TCC-LINK central &	Oneration		E	hach	Main derective position	Description
$\begin{array}{c c c c c c c c c c c c c c c c c c c $	H05		H05			+ -	-	Outdoor discharge temp. sensor (TD1)	Miswiring or mismounting of outdoor discharge temp. sensor (TD1) or coming-out
$\begin{array}{c c c c c c c c c c c c c c c c c c c $						- -	+	Dutdoor discharde temp sensor (TD2)	Mitwiring or mismolinting of nitdoor discharge term sensor (TD2) or coming-out
$\begin{array}{c c c c c c c c c c c c c c c c c c c $	H15		H15		0	•		miswiring	of TD2 sensor was detected.
$\begin{array}{c c c c c c c c c c c c c c c c c c c $	H25		H25	•	0	•		Outdoor discharge temp. sensor (TD3) miswiring	Miswiring or mismounting of outdoor discharge temp. sensor (TD3) or coming-out of TD3 sensor was detected.
$\begin{array}{c c c c c c c c c c c c c c c c c c c $	90H		H06	•	0	•		Low pressure protective operation	Protection by low pressure (Ps) sensor was detected.
$ \begin{array}{cccccccccccccccccccccccccccccccccccc$	H07	-	H07	•	0	-		Protection for oil level drop	Protection detection by temp. sensor (TK1 to 5) for oil level detection.
20: TK2 Oli circuit system error 00: TK2 Oli circuit system error 00: TK3 Oli circuit system error 00: TK3 Oli circuit system error 00: TK4 Oli circuit system error 00: TK4 Oli circuit system error 14 OLI CloB by middle display) H16 ● ● ● > Detection circuit error 00: TK4 Oli circuit system error 14 OLI CloB by middle display) Detection circuit error 15 Displayed priority indoor units 0.0 Detection circuit error 0.0 Detection circu	H08	01: TK 02: TK 03: TK 05: TK 05: TK	Н08	•	0	•		Oil level detection temp. sensor (TK1 to 5) error	Open/Short of temp. sensor (TK1 to 5) for oil level detection was detected.
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	H16	01: TK 02: TK 03: TK 05: TK 05: TK	H16	•	0	•		Detection circuit error	After starting compressor operation, temperature change of temp. sensor (TK1 to 5) for oil level detection was not detected.
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	L04		L04	0	0	0		Duplicated outdoor system address	Duplicated setting of system address to outdoor units of different refrigerant piping system
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	901		L05	0	•	 ©		Duplicated priority indoor units (Displayed in priority indoor unit)	Duplicated priority indoor units (For priority indoor unit)
$\begin{array}{ c c c c c c c c c c c c c c c c c c c$			P06	0	•	 ©		Duplicated priority indoor units (Displayed except priority indoor unit)	Duplicated priority indoor units (For indoor units without priority)
$\begin{array}{ c c c c c c c c c c c c c c c c c c c$	L08		L08	0	•	@		Unset indoor group address	There is indoor unit which indoor group address was not set (Detected also at indoor unit side)
$\begin{array}{ c c c c c c c c c c c c c c c c c c c$	L10		L10	0	0	_ ©		Unset outdoor unit capacity	Capacity of outdoor unit is not set. (Exchange service P.C. board.)
No. of connected heat unitsL18 \bigcirc \bigcirc \bigcirc SRefigerant change unit system errorNo. of connected heat unitsL27 \bigcirc \bigcirc SNo. of connected heat unit overNo. of connected heat unitsL27 \bigcirc \bigcirc SNo. of connected heat unit over $$ L28 \bigcirc \bigcirc \bigcirc SNo. of connected heat unit over $$ L28 \bigcirc \bigcirc \bigcirc SNo. of connected heat unit over $$ L28 \bigcirc \bigcirc \bigcirc SNo. of connected heat unit over $$	L17		L17	0	0	- 0		Disagreed error of outdoor model	Former model of outdoor unit (Before 3 series) was connected.
No. of connected heat unitsL26©U©ISNo. of connected heat unit overNo. of connected heat unitsL27©OSNo. of connected heat unit error $$	L18	+	L18	0	0	- 0	+	Refrigerant change unit system error	COOL/HEAT cycle error by mispiping, etc was detected.
No. of connected heat unitsL27Image: Connected heat unit error $$	L26	+	L26	0	С	_ . @		No. of connected heat unit over	There are 3 or more connected heat units.
$\begin{array}{ c c c c c c c c c c c c c c c c c c c$	L27		L27	0	0	0		No. of connected heat unit error	Heat unit was not connected, or combination of No. of outdoor units with No. of heat units defective.
A3-IPDU FAN A3-IPDU FAN 01 0 0 0 0 0 02 0 0 0 0 0 0 03 0 0 0 0 0 0 0 04 0 0 0 0 0 0 0 0 05 0	L28		L28	0	0	- ©		No. of connected outdoor units over	No. of connected outdoor units exceeded 4 units
Detection of indoor unit number (L30) (D (L30)	L29	A3-IPDU FAN A3-IPDU FAN 01 0 2 3 IPDU 1 2 3 02 O 0 0 0 0 0 0 03 O 0	L29	0	0	 ©		IPDU quantity error	No. of IPDU (P.C. board) in inverter box is few.
— P03 O O A Outdoor unit discharge (TD1) temp. error -00: Open phase shortage detection - - P05 O P05 P05 00: Compressor 1 side P05 O 0 P A Inverter DC voltage (Vdc) error 03: Compressor 3 side 03: Compressor 3 side 03: Compressor 3 side P05 O P05	L30		(T30)	0	0	 ©		Outside error input in indoor (Interlock)	There is indoor unit which abnormally stops by outer error input in 1 system. (← Indoor unit detected.)
00: Open phase shortage detection PO5 PO5 PO6 Phase shortage: Power failure error 01: Compressor 1 side PO5 PO5 PO5 PO5 PO5 02: Compressor 2 side PO5 PO5 PO5 PO5 PO5	P03		P03	0	•	0		Outdoor unit discharge (TD1) temp. error	High temp. error was detected at outdoor discharge temp. sensor (TD1).
	P05	00: Open phase shortage detection01: Compressor 1 side 02: Compressor 2 side 03: Compressor 3 side	P05	0	•	 ©		Open phase shortage: Power failure error Inverter DC voltage (Vdc) error	When power supply was turned on, open phase shortage was detected. Over current/Current shortage was detected at inverter DC voltage.

(∗) O: Goes on, ⊚: Flashes, ●: Goes off A (Alternate) : Flashing condition is alternate when there are two flashing LED. S (Simultaneously) : Two LED flash simultaneously when there are two flashing LED.

	CITECA COUR UISPIRY		Sen	Sensor lamp display	o display	>		
	Outdoor 7-segment	TCC-LINK central &		Block display	splay		Main defective position	Description
	Auxiliary code	remote controllers	Operation -	Timer F	Ready	Flash		
P07 01: 03: 03:	01: Compressor 1 side 02: Compressor 2 side 03: Compressor 3 side	P07	0		 ©	A	Heat sink overheat error	High temp. error was detected in outdoor IGBT built-in temp. sensor (TH).
P09 De	Detection of heat unit number	(60d)	•	0	 ©	A	Heat unit water-shortage error	There is heat unit which was been detected water-shortage in 1 system. (\leftarrow Heat unit detected.)
P10 De	Detection of indoor unit number	(P10)		0	 ©	A	There is indoor unit which overflow was detected.	There is abnormally stopped indoor unit which was been detected water-overflow in 1 system. (\leftarrow Indoor unit detected.)
P13	I	P13	•	0	0	A	Outdoor liquid back detection error	Liquid back operation was judged from refrigerant cycle status.
P15 01:	01: TS condition 02: TD condition	P15	0		0	A	Gas leak detection	Outdoor suction temp. sensor (TS1) continuously and repeatedly detected high temperature over standard value.
P17		P17	0		0	A	Outdoor discharge (TD2) temp. error	High temp. error was detected in outdoor discharge temp. sensor (TD2).
P18		P18	0		_ ©	A	Outdoor discharge (TD3) temp. error	High temp. error was detected in outdoor discharge temp. sensor (TD3).
P19 De	Detection of outdoor unit number	P19	0		0	A	4-way valve invert error	Refrigerant cycle error was detected in heating operation.
P20		P20	0		0	A	High pressure protection operation	High pressure (Pd) sensor detected pressure over standard value.
P24 De	Detection of heat unit number	P24	0	•	 ©	A	Heat unit error (Main code)	Heat unit detected error (Heat remote controller displays detailed check code together with model number.)

Check code display list (Outdoor unit)

[SMMS-i unit IPDU detects error: Main example]

(∗) O: Goes on, ⊚: Flashes, ●: Goes off A (Alternate) : Flashing condition is alternate when there are two flashing LED. S (Simultaneously) : Two LED flash simultaneously when there are two flashing LED.

	Description		ror Open/Short of outdoor unit IGBT built-in temp. sensor (TH) was detected.	Inverter current (Idc) detection circuit detected over-current.	Compressor lock was detected.	Abnormal current was detected during stop of compressor.	High pressure SW operated.	High temp. error was detected in outdoor IGBT built-in temp. sensor (TH).	IPDU for outdoor fan detected each error.	Short-circuit protective operation (Instantaneous over-current) of compres- sor motor driving circuit element operated.	error Position detection error of compressor motor was detected.
	Main defective position		Outdoor IGBT built-in temp. sensor (TH) error	Compressor break down	Compressor error (Lock)	Current detection circuit error	High pressure SW system operation	Heat sink overheat error	IPDU for outdoor fan error	G-Tr (IGBT) short-circuit protection error	Compressor position detection circuit system error
lav		Flash	ج				¥	<	۷	¥ 	¥
Sensor lamp display	display	Ready	0	•	•	•	0	0	۲	0	0
ensor la	Block	Operation Timer	0	0	0	0	•	•	•	•	٠
S		-	0	•	•	•	0	0	۵	0	0
	TCC-LINK central &	remote controllers	F13	H01	H02	HO3	P04	P07	P22	P26	P29
Check code display	Outdoor 7-segment	Auxiliary code	01: Compressor 1 side 02: Compressor 2 side 03: Compressor 3 side	01: Compressor 1 side 02: Compressor 2 side 03: Compressor 3 side	01: Compressor 1 side 02: Compressor 2 side 03: Compressor 3 side	01: Compressor 1 side 02: Compressor 2 side 03: Compressor 3 side	01: Compressor 1 side 02: Compressor 2 side 03: Compressor 3 side	01: Compressor 1 side 02: Compressor 2 side 03: Compressor 3 side	0*: IGBT circuit 1*: Position detection circuit error 3*: Motor lock error 4*: Motor current detection C*: TH sensor error C*: TH sensor error E*: Inverter DC voltage error (Outdoor fan) Note) In position *, 0 to F is displayed, but ignore it.	01: Compressor 1 side 02: Compressor 2 side 03: Compressor 3 side	01: Compressor 1 side 02: Compressor 2 side 03: Compressor 3 side
			F13	H01	HO2	Н03	P04	P07	P22	P26	P29

Note) The above check codes are the representative examples and they differ according to the combined outdoor units (Cooling/Heating flex, etc.). For details, refer to the Service Manual for the corresponding outdoor unit.

- 50 -

8-3. Troubleshooting by Check Display on Wired Remote Controller ■

■ In case of wired remote controller (RBC-AMT32UL)

1. Confirmation and check

When an error occurred on the air conditioner, the check code and the indoor unit No. are displayed on the display section of the remote controller.


The check code is displayed while the air conditioner operates.

If the display disappeared, operate the air conditioner and check the error based upon the following "Confirmation of error history".

2. Confirmation of error history

When an error occurred on the air conditioner, the error history can be confirmed with the following procedure.

(Up to 4 error histories are stored in memory.) This history can be confirmed from either operating status or stop status.



Ρ

Procedure	Description
1	 When pushing ^{SET} and ^{TEST} buttons simultaneously for 4 seconds or more, the below display appears. If [
2	Every pushing temp. set 🔍 / 🏊 buttons, the error histories stored in the memory are displayed in order. The numbers in CODE No. indicates CODE No. [01] (Latest) to [04] (Oldest). CAUTION Do not push of button because all the error histories of the indoor unit will be deleted.
3	After confirmation, push solution to return to the usual display.

How to read the check monitor display


<7-segment display>



<How to read>

2 0 1 3 4 5 6 7 8 9 Α b С d Ε F н J

■ In case of central remote controller (TCB-SC642TLE2)




1. Confirmation and check

When a trouble occurred on the air conditioner, the check code and the indoor unit No. are displayed on the display section of the remote controller.

The check code is displayed while the air conditioner operates.

If the display disappeared, operate the air conditioner and check the error based upon the following "Confirmation of error history".



2. Confirmation of error history


When a trouble occurred on the air conditioner, the error history can be confirmed with the following procedure. (Up to 4 error histories are stored in memory.)

This history can be confirmed from either operating or stop.

- 1) Push \nearrow and (SET) buttons in succession for 4 seconds or more.
- 2) SERVICE CHECK F goes on and CODE No. 01 goes on.
- 3) When selecting (flash) the group number if there is the alarm history, the UNIT number and the latest alarm history are displayed alternately.

 $\ast\,$ In this time, the temperature cannot be set up.

- 4) To confirm the alarm history other than the latest one, push temp. set ▲ / ▼ to select CODE No. (01 to 04).
- 5) To confirm the alarm in the other group, push ZONE and \checkmark to select the group number Do not push CL button because all the alarm histories of the currently selected group are deleted.
- 6) To finish the service check, push \nearrow button.



■ Indoor unit display part (Receiving unit) (Wireless type)

When specifying the check code, check 7-segment display on the center unit. For the check code which is not displayed on the outdoor 7-segment, confirm it in Section **"8-2 How to Check / Check code display list (Indoor unit)**".

Lamp indication Check code Cause of trouble occurrence Operation Timer Readv Power supply OFF or miswiring between receiving unit and indoor unit No indication at all Operation Timer Readv E01 Receiving error Receiving unit Miswiring or wire connection error -)Ó(-E02 Sending error between receiving unit and indoor unit Flash E03 Communication interruption E08 Duplicated indoor unit No. (Address) Setup error E09 Duplicated header units of remote controller Communication error between MCU on indoor unit P.C. board E10 F12 Automatic address start error E18 Wire connection error between indoor units, indoor power supply OFF Operation Timer Ready Miswiring or wire connection error between indoor unit and outdoor unit E04 (Communication interruption between indoor and outdoor units) -)Ó́-Communication (receiving) error between indoor and outdoor units, decrease of No. of Flash E06 connected indoor units E07 Communication (sending) error between indoor and outdoor units E15 No indoor unit during setting of automatic address E16 No. of connected indoor units, capacity over E19 Error of No. of header unit Disagreement of refrigerant pipe communication during setting of automatic address F20 E23 Communication (sending) error between outdoor units E25 Duplicated setting of follower unit address Communication (receiving) error between outdoor units, decrease of No. of connected E26 outdoor units F28 Follower unit error IPDU communication error F31 Operation Timer Ready P01 Indoor fan error P10 Indoor overflow error -Ò--0 P12 Indoor fan error Outdoor unit liquid back detection error Alternate flash P13 Operation P03 Outdoor unit discharge temp. (TD1) error Timer Readv P04 Outdoor unit high pressure switch operation -Ò́--Ò Outdoor unit inverter DC voltage (Vdc) error was detected, negative phase error was P05 detected Alternate flash Outdoor unit heat sink overheat error: Heat radiation error of electric part (IGBT) in P07 outdoor unit P15 Gas leak was detected: Short of refrigerant charge amount P17 Outdoor unit discharge temp. (TD2) error P18 Outdoor unit discharge temp. (TD3) error P19 Outdoor unit 4-way valve inverse error P20 High pressure protection error P22 Outdoor unit DC fan error P26 Outdoor unit G-Tr short-circuit error P29 Compressor position detection circuit error P31 Other indoor unit stopped due to error in the group.

Lam	p indicati	ion	Check code	Cause of trou	ible occurrence
Operation	Timer	Ready	F01	Heat exchanger sensor (TCJ) error	
-`ᢕ´-	-`ᢕ´-		F02	Heat exchanger sensor (TC2) error	
		•	F03	Heat exchanger sensor (TC1) error	Temp. sensor error in indoor unit
Alternate	e flash		F10	Room temp. sensor (TA) error	
			F11	Discharge air temp.sensor (TF) error	J
Operation	Timer	Ready	F04	Discharge temp. sensor (TD1) error	
-`Ć´-	-`ᢕ´-	\bigcirc	F05	Discharge temp. sensor (TD2) error	
		\bigcirc	F06	Heat exchanger sensor (TE1, TE2) error	
Alternate	e flash		F07	Liquid temp. sensor (TL) error	Outdoor unit temp. sensor error
			F08	Outside temp. sensor (TO) error	
			F12	Suction temp. sensor (TS1) error	
			F13	Heat sink sensor (TH) error)
			F15	Misconnection of heat exchanger sensor ([−] → Miswiring of temp. sensor in outdoor uni	
			F16	Miswiring between high pressure sensor (F \rightarrow Misconnection of pressure sensor in our	Pd) and low pressure sensor (Ps) tdoor unit
			F22	Discharge temp. sensor (TD3) error	
			F23	Low pressure sensor (Ps) error	Pressure sensor error in outdoor unit
			F24	High pressure sensor (Pd) error	
Operation	Timer -Ŏ- ous flash	Ready ●	F29	Indoor unit EEPROM error	
Operation	Timer	Ready	H01	Compressor break-down)
	-`Ċ҉-	•	H02	Compressor lock	Outdoor unit compressor system error
•	Flash	-	H03	Current detection circuit error	
			H04	Compressor 1 case thermo operation	,
			H05	Miswiring or mismounting of outdoor discharge TD1 sensor	arge temp. sensor (TD1) or coming-off of
			H06	Low pressure (Ps) drop error	
			H07	Oil face drop detection error	Protections stop of outdoor unit
			H08	Oil face detection circuit system temp. sense	sor (TK1, TK2, TK3, TK4, TK5) error
			H15	Miswiring or mismounting of outdoor dischart TD2 sensor	arge temp. sensor (TD2) or coming-off of
			H16	Oil face detection circuit system error: Outdoor	unit TK1, TK2, TK3, TK4 circuit system error
			H25	Miswiring or mismounting of outdoor dischart TD3 sensor	arge temp. sensor (TD3) or coming-off of
Operation	Timer	Ready	L03	Duplicated header units in indoor unit	
-`O		-`Ó-	L05	Duplicated priority indoor unit (Displayed ir	n the room with priority)
			L06	Duplicated priority indoor unit (Displayed ir	n a room except one with priority)
Simul	taneous fl	lash	L07	Group cable was connected to individual ir	ndoor unit.
			L08	Indoor group address was unset.	
			L09	Indoor capacity was unset.	
Operation	Timer	Ready	L04	Duplicated setting of outdoor line address	
-`Ó́-	\bigcirc	-`ᢕ´-	L10	Outdoor capacity was unset.	
			L17	Disagreement error of outdoor unit type	
Simul	taneous fl	lash	L18	Flow selector unit error	
			L20	Duplicated address of central control syste	m
			L28	No. of connected outdoor units over	
			L29	Defective No. of IPDU	
			L30	Indoor unit outside interlock error	
Operation	Timer	Ready			
-)	-)(-	\bigcirc	F31	Outdoor unit EEPROM error	
Simul	taneous fl	lash			

Others (Except check code)

Lam	p indicati	ion	Check code	Cause of trouble occurrence
Operation	Timer -Ŏ- taneous f	Ready - Č-	_	During test run
Operation	Timer	Ready		
	-`	-Ò-	_	COOL/HEAT disagreement (Automatic cooling/heating setup to automatic cooling/heating unavailable model, heating setup to cooling only model)

8-4. Check Code and Check Position Displayed on the Remote Controller and Outdoor Unit (7-Segment Display of Interface)

<In case of SUPER MODULAR MULTI SYSTEM>

	Check code	ahor					
Wired	Outdoor	Outdoor 7-seament display	Detected	Check code name	Status	Error detection condition	Check ttem (position)
remote controller	Check code	Auxiliary code	position				
E01		1	Remote controller	Communication error between indoor and remote controller (Detected at remote controller side)	Corresponding unit only stops.	Communication interrupted between indoor P.C. board and remote controller.	 Check remote controller inter-unit cable (A/B). Check disconnection, connector contact error. Check indoor power supply. Check remote controller address setup. (When two remote controllers operate) Check remote controllers operate) Check remote controller P.C. board.
E02	I		Remote controller	Remote controller sending error	Corresponding unit only stops.	Signal could not be sent from remote controller to indoor unit.	 Check the communication wire of remote controller: Exchange remote controller.
E03			Indoor unit	Communication error between indoor and remote controller (Detected at indoor side)	Corresponding unit only stops.	No communication from remote controller (including wireless) and communication adapter.	 Check remote controller and communication adapter wiring.
E04	I	1	Indoor unit	Indoor/outdoor communication circuit error (Detected at indoor side)	Corresponding unit only stops.	Indoor unit does not receive communication from outdoor unit.	 Check power-ON order of indoor/outdoor. Check indoor address setup. Check inter-unit cabling between indoor and outdoor. Check outdoor end terminal resistance setup (SW30-2).
E06	E06	No. of indoor units which received signal normally	Ι/F	Decreased number of indoor units	All stop	When signal is not sent for a certain period from the indoor unit which has been used to send signals.	 Check the power supply of indoor unit. (Power-ON) Check connection of communication line between indoor and outdoor. Check connector connection for communication in indoor P.C. board. Check indoor P.C. board failure. Check outdoor P.C. board (I/F) failure.
1	E07		I/F	Indoor/outdoor communication circuit error (Detected at outdoor side)	All stop	Transmission from outdoor to indoor cannot continue for 30 seconds.	 Check outdoor terminator resistor setup (SW30-2). Check the communication connection between indoor and outdoor.
E08	E08	Duplicated indoor addresses	Indoor I/F	Duplicated indoor addresses	All stop	Multiple indoor unit address setup are duplicated.	 Check indoor address. Check the change of remote controller connection (Group / individual) after setup of indoor address.
E09	I	I	Remote controller	Duplicated master remote controllers	Corresponding unit only stops.	In 2-remote controller control (including wireless), both are setup as master (Header indoor unit stops and other indoor unit is operating.)	 Check remote controller setup. Check remote controller P.C. board.
E10	1	I	Indoor unit	Communication error between indoor P.C. board assembly	Corresponding unit only stops.	Communication was not succeeded after power was supplied or during communication.	Indoor P.C. board failure
E12	E12	01: Indoor/outdoor communication 02: Between outdoors communication	Ч	Automatic address start error	All stop	 When indoor automatic address started, other refrigerant circuit system was setting automatic address. When outdoor automatic address was executed. indoor automatic address was executed. 	 Setup the address again after disconnecting communication connection with other refrigerant circuit system.

		Check code					
Wired		Outdoor 7-segment display	Detected	Check code name	Status	Error detection condition	Check item (position)
remote controller	Check code	Auxiliary code					
E15	E15	1	I/F	No corresponding indoor unit during automatic address	All stop	Indoor unit is not found when indoor automatic address start was set up.	 Check the communication line connection between indoor and outdoor. Check the electric power line error in indoor. Check the noise of surrounding devices. Power failure Check indoor P.C. board error.
E16	E 16	00: Capacity over 01 to: No. of connected units	I/F	No. of connected indoor units / Capacity over	All stop	 Total capacity of indoor units exceeded 135% of total outdoor capacity.* No. of connected indoor units are more than 48 units. Inote] If this code appears after backup if this code appears after backup setup of outdoor unit trouble, set up "No. capacity-over detection". Setup method of "No. capacity-over detection". Sun I/F P.C. board of outdoor header unit. 	 Check the connection capacity of indoor unit. Check the HP capacity of indoor unit. Check the indoor/outdoor capacity setup Check the No. of connected indoor units. Check the outdoor I/F P.C. board error
E18		I	Indoor unit	Communication error between indoor header and follower units	Corresponding unit only stops.	Regular communication between indoor header and follower units	 Check cable of the remote controller. Check power cabling of indoor. Check P.C. board of indoor.
E19	E19	00: No header unit 02: Two or more header units	I/F	Header outdoor unit quantity error	All stop	 There are multiple header outdoor units in 1 line. There is none of header outdoor unit in 1 line. 	 The outdoor unit connected with communication cable between indoor and outdoor (U1.U2) is the outdoor unit. Check connection of communication line between indoor and outdoor. Check outdoor P.C. board(I/F) error.
E20	E20	01: Connection of outdoor of other line 02: Connection of indoor of other line	I/F	Other line unit connected during automatic address	All stop	Unit of other line was connected when indoor automatic address started.	Separate the cable between lines according to automatic address setup method in "Address setup".
E23	E23	1	l/F	Communication sending error between outdoor units	All stop	Transmission of other outdoor unit was unavailable for 30 seconds or more.	 Check power supply in outdoor unit. (Is power supplied?) Check connection or disconnection of connecting wire between outdoor units. Check connection of connector for outdoor P.C. board communication. Check outdoor P.C. board (<i>I/F</i>) error. Check terminal resistance setting of communication between outdoor units
E25	E25		I/F	Duplicated outdoor follower address setup	All stop	Outdoor addresses manually set up are duplicated.	[Note] Do not set up the outdoor address manually.
E26	E26	No. of normally received outdoor units	l/F	Decreased number of connected outdoor units	All stop	The signal was not returned for constant from the outdoor unit which was receiving signal.	 Outdoor backup is being set. Check power supply of outdoor unit. (Is power supplied?) Check connection or disconnection of connecting wire between outdoor units. Check connection of connector for outdoor P.C. board communication. Check outdoor P.C. board (<i>VF</i>) error.
E28	E28	No. of detected outdoor units	I/F	Outdoor follower unit error	All stop	Outdoor header unit received error code from outdoor follower unit.	Check the check code of outdoor follower unit.
When If push	pushing SW04 iing SW04 and	When pushing SW04 for 1 second or more under condition that [E28] is displayed on 7-segment display of outdoor header unit, the fan of outdoor unit which stopped abnormally starts rotating. If pushing SW04 and SW05 simultaneously, the fan of normal outdoor unit operates. When pushing SW05 singly, the operation of fan is cleared.	[E28] is dis utdoor unit	splayed on 7-segment display of or or operates. When pushing SW05 sir	spectrons outdoor h SW05 singly, the	ieader unit, the fan of outdoor unit whi • operation of fan is cleared. 	ch stopped abnormally starts rotating.
* In case	of capacity	* In case of capacity of indoor unit connection, calculate MMK-AP0054MHP-E(-TR) as 0.6HP	e MMK-∕	10054MHP-E(-TR)	as 0.6HP		

		Check code						_
Wired		Outdoor 7-segment display	Detected	Check code name	Status	Error detection condition	Check item (position)	
remote controller	Check code	Auxiliary code						
E31	E31	A-3-IPU FAN 1 2 3 IPDU FAN 01 0 1 2 3 IPDU FAN 03 0 0 0 1 2 3 IPDU 03 0 <td>νF</td> <td>IPDU communication error</td> <td>All stop</td> <td>Communication of each IPDU (P.C. board) in inverter box interrupted.</td> <td> Check connection of communication connector and disconnection between IPDU and I/F P.C. board. Check outdoor P.C. board (I/F, Comp., IPDU, Fan IPDU) error. Check external noise. </td> <td></td>	νF	IPDU communication error	All stop	Communication of each IPDU (P.C. board) in inverter box interrupted.	 Check connection of communication connector and disconnection between IPDU and I/F P.C. board. Check outdoor P.C. board (I/F, Comp., IPDU, Fan IPDU) error. Check external noise. 	
F01		I	Indoor unit	Indoor TCJ sensor error	Corresponding unit only stops.	Resistance value of sensor is infinite or zero. (Open/Short)	 Check connection/cabling of TCJ sensor connector. Check characteristics of TCJ sensor resistance value. Check indoor P.C. board error. 	
F02	I	I	Indoor unit	Indoor TC2 sensor error	Corresponding unit only stops.	 Resistance value of sensor is infinite or zero (Open/Short). 	 Check connection/cabling of TC2 sensor connector. Check characteristics of TC2 sensor resistance value. Check indoor P.C. board error. 	
F03		I	Indoor unit	Indoor TC1 sensor error	Corresponding unit only stops.	 Resistance value of sensor is infinite or zero (Open/Short). 	 Check connection/cabling of TC1 sensor connector. Check characteristics of TC1 sensor resistance value. Check indoor P.C. board error. 	
F04	F04	I	I/F	TD1 sensor error	All stop	Resistance value of sensor is infinite or zero (Open/Short)	 Check connection of TD1 sensor connector. Check characteristics of TD1 sensor resistance value. Check outdoor P.C. board (I/F) error. 	;
F05	F05	I	I/F	TD2 sensor error	All stop	 Resistance value of sensor is infinite or zero (Open/Short) 	 Check connection of TD2 sensor connector. Check characteristics of TD2 sensor resistance value. Check outdoor P.C. board (I/F) error. 	
F06	F06	01: TE1 sensor error 02: TE2 sensor error	l/F	TE1, TE2 sensor error	All stop	 Resistance value of sensor is infinite or zero (Open/Short). 	 Check connection of TE1, TE2 sensor connector. Check characteristics of TE1, TE2 sensor resistance value. Check outdoor P.C. board (I/F) error. 	
F07	F07	I	I/F	TL sensor error	All stop	 Resistance value of sensor is infinite or zero (Open/Short). 	 Check connection of TL sensor connector. Check characteristics of TL sensor resistance value. Check outdoor P.C. board (I/F) error. 	
F08	F08	I	I/F	TO sensor error	All stop	 Resistance value of sensor is infinite or zero (Open/Short). 	 Check connection of TO sensor connector. Check characteristics of TO sensor resistance value. Check outdoor P.C. board (I/F) error. 	
F10	I	I	Indoor	Indoor TA sensor error	Corresponding unit only stops.	 Resistance value of sensor is infinite or zero (Open/Short). 	 Check connection/cabling of TA sensor connector. Check characteristics of TA sensor resistance value. Check indoor P.C. board error. 	
F12	F12	I	I/F	TS1 sensor error	All stop	 Resistance value of sensor is infinite or zero (Open/Short). 	 Check connection of TS1 sensor connector. Check characteristics of TS1 sensor resistance value. Check outdoor P.C. board (I/F) error. 	
F13	F13	01: Compressor 1 side 02: Compressor 2 side 03: Compressor 3 side	IPDU	TH sensor error	All stop	 Resistance value of sensor is infinite or zero (Open/Short). 	 IGBT built-in temp sensor error → Exchange Comp. IPDU P.C. board. 	<u> </u>

			Detected				
Wired remote controller	Outdoor Check code	Outdoor 7-segment display ck code Auxiliary code	position	Check code name	Status	Error detection condition	Check frem (position)
F15	F15	I	I/F	Outdoor temp sensor miscabling (TE1, TL)	All stop	During operation of compressor in HEAT mode, the TE1 detection temp was higher than that of TL by the specified value continued for 3 minutes or more.	 Check installation of TE1 sensor and TL sensor. Check characteristics of TE1 and TL sensor resistance value. Check outdoor P.C. board (<i>VF</i>) error.
F16	F16	1	١/F	Outdoor pressure sensor miscabling (Pd, Ps)	All stop	High-pressure Pd sensor and low-pressure Ps sensor were exchanged, or output voltages of both sensors are zero.	 Check connection of high-pressure Pd sensor connector. Check connection of low-pressure Ps sensor connector. Check pressure sensors Pd and Ps error. Check outdoor P.C. board (<i>I/</i>F) error. Check compression error of compressor.
F22	F22		I/F	TD3 sensor error	All stop	Sensor resistance value is infinite or 0 (Open/Short)	 Check connection of TD3 sensor connector. Check resistance value characteristics of TD3. Check error of outdoor P.C. board (<i>I/F</i>).
F23	F23	1	l/F	Ps sensor error	All stop	Output voltage of Ps sensor was zero.	 Misconnection of Ps sensor and Pd sensor connectors Check connection of Ps sensor connector. Check Ps sensor error. Check compression error of compressor. Check 4-way valve error. Check outdoor P.C. board (I/F) error. Check SV4 circuit error.
F24	F24	I	I/F	Pd sensor error	All stop	Output voltage of Pd sensor was zero. (Sensor Open) Pd > 4.15MPa during stop of compressor	 Check connection of Pd sensor connector. Check Pd sensor error. Check outdoor P.C. board (I/F) error.
F29	Ι	I	Indoor	Indoor other error	Corresponding unit only stops.	Indoor P.C. board did not operate normally.	 Check indoor P.C. board error (EEPROM error).
F31	F31	I	I/F	Outdoor EEPROM error	All stop (*1)	Outdoor P.C. board (I/F) did not operate normally.	 Check power voltage. Check power noise. Check outdoor P.C. board (I/F) error.
Н01	H01	01: Compressor 1 side 02: Compressor 2 side 03: Compressor 3 side	NDAI	Compressor breakdown	All stop	Inverter current detection circuit detected over-current and stopped.	 Check power voltage. (AC380–415V ± 10%). Check compressor error. Check cause of abnormal overload operation. Check outdoor P.C. board (Comp. IPDU) error.
H02	Н02	01: Compressor 1 side 02: Compressor 2 side 03: Compressor 3 side	NDAI	Compressor error (lock)	All stop	Over-current was detected several seconds after header compressor had started.	 Check compressor error. Check power voltage. (AC380–415V ±10%). Check cable of compressor and phase-missing. Check connector/terminal connection on IPDU P.C. board. Check activation error due to liquid stagnation in compressor.) Check outdoor P.C. board (Comp. IPDU) error.
НОЗ	HO3	01: Compressor 1 side 02: Compressor 2 side 03: Compressor 3 side	IPDU	Current detection circuit system error	All stop	While header compressor stopped, current flowed more than the specified current and was detected.	 Check cabling of current detection circuit system. Check outdoor P.C. board (Comp. IPDU) error.

	Check code	code					
Wired	Outdoor	Outdoor 7-segment display	Detected	Check code name	Status	Error detection condition	Check item (position)
remote controller	Check code	Auxiliary code	position				
H04	H04	1	μF	Compressor 1 case thermo operation	All stop	Compressor 1 case thermostat performed protective operation.	 Check compressor 1 case thermo circuit. (Connector, cable, P.C. board) Check full opening of service valve. (Gas and liquid side) Check outdoor PMV clogging. (PMV1, 2) Check SV41 circuit leakage. Check miscabling/misinstallation of SV41 and SV42. Check valve open status of indoor PMV. Check tefrigerant shortage. Check refrigerant shortage.
HO5	H05	I	l/F	Outdoor unit discharge temp. sensor (TD1) miswiring	All stop	While compressor 1 is operating, the discharge temp. (TD1) does not rise up.	 Check mounting of TD1 sensor. Check connection and wiring of TD1sensor connector. Check characteristics of TD1 sensor resistance value. Check outdoor unit P.C. board (<i>I</i>/F) error.
90Н	90H	1	μF	Low-pressure protective operation	All stop	Low-pressure Ps detected operation lower than 0.02MPa.	 Check full opening of service valve. (Discharge gas, suction gas and liquid side) Check outdoor PMV clogging. (PMV1, 2) Check sV2 circuit and SV4 circuit error. Check low-pressure Ps sensor error. Check low-pressure Ps sensor error. Check valve open of indoor NWV. Check outdoor fan operation. (All heating, mainly heating, part cooling operation) Check refrigerant shortage.
НО7	НО7	I	μF	Protection for oil level drop detection	All stop	The operating compressor detected oil shortage continuously for 2 hours.	 Check all the outdoor units in the corresponding line.> Check full opening of service valve of balance pipe. Check connection and installation of TK1, TK2, TK3, and TK4 sensors. Check characteristics of TK1, TK2, TK3, and TK4 resistance values. Check gas leak and oil leak in the same line. Check error of SV34, SV36, SV30, SV3E, valves. Check clogging of oil separator oil return circuit. Check clogging of oil separator oil return circuit.
H08	H08	01: TK1 sensor error 02: TK2 sensor error 03: TK3 sensor error	I/F	Oil level detective temp sensor error	All stop	 Resistance value of sensor is infinite or zero. (Open/Short) 	 Check connection of TK1 sensor connector. Check characteristics of TK1 sensor resistance value. Check outdoor P.C. board (I/F) error.
		05: TK5 sensor error			All stop	 Resistance value of sensor is infinite or zero. (Open/Short) 	 Check connection of TK2 sensor connector. Check characteristics of TK2 sensor resistance value. Check outdoor P.C. board (I/F) error.
					All stop	 Resistance value of sensor is infinite or zero. (Open/Short) 	 Check connection of TK3 sensor connector. Check characteristics of TK3 sensor resistance value. Check outdoor P.C. board (I/F) error.
					All stop	 Resistance value of sensor is infinite or zero. (Open/Short) 	 Check connection of TK4 sensor connector. Check characteristics of TK4 sensor resistance value. Check outdoor P.C. board (I/F) error.
					All stop	 Resistance value of sensor is infinite or zero. (Open/Short) 	 Check connection of TK5 sensor connector. Check characteristics of TK5 sensor resistance value. Check outdoor P.C. board (I/F) error.

Check code	leck code		Detected				
Outdoor 7-segment display Durdoor position Check code Auxiliary code	door 7-segment display Auxiliary code	posit	noi	Check code name	Status	Error detection condition	Check item (position)
H15 — UF		Ι/F		Outdoor unit discharge temp. sensor (TD2) miswiring	All stop	While compressor 2 is operating, the discharge temp. (TD2) does not rise up.	 Check mounting of TD2 sensor. Check connection and wiring of TD2 sensor connector. Check characteristics of TD2 sensor resistance value. Check outdoor unit P.C. board (<i>VF</i>) error.
H16 01: TK1 oil circuit system error 02: TK2 oil circuit system error 03: TK3 oil circuit system error 04: TK4 oil circuit system error 05: TK5 oil circuit system error		LΈ		Oil level detective circuit system error	All stop	Temperature change of TK1 could not be detected though compressor 1 started the operation.	 Check TK1 sensor coming-off. Check characteristics of TK1 sensor resistance value. Check TK1, TK2, TK3, TK4 and TK5 misconnection. Check operation error of SV3E, SV3F valve. Check capillary clogging of oil-equation circuit and operation error of stop valve. Check refrigerant stagnation in compressor.
						Temperature change of TK2 could not be detected though compressor 2 started the operation.	 Check TK2 sensor coming-off. Check characteristics of TK2 sensor resistance value. Check TK1, TK2, TK3, TK4 and TK5 misconnection. Check SV3E, SV3F valve operation. Check capillary clogging of oil equalization circuit and check stop valve operation. Check refrigerant stagnation in compressor shell.
						Temperature change of TK3 could not be detected though compressor started the operation.	 Check TK3 sensor coming-off. Check characteristics of TK3 sensor resistance value. Check TK1, TK2, TK3, TK4 and TK5 misconnection. Check SV3E, SV3F valve operation. Check capillary clogging of oil-equalization circuit and check valve operation. Check refrigerant stagnation in compressor shell.
						Temperature change of TK4 could not be detected though compressor started the operation, or the difference from other TK sensor changed for a constant time only within the specified range.	 Check TK4 sensor coming-off. Check characteristics of TK4 sensor resistance value. Check TK1, TK2, TK3, TK4 and TK5 misconnection. Check SV3E, SV3F valve operation. Check capillary clogging of oil-equalization circuit and check valve operation. Check refrigerant stagnation in compressor shell.
						Temperature change of TK5 could not be detected though compres- sor started the operation, or the difference from other TK sensor changed for a constant time only within the specified range.	 Check TK5 sensor coming-off. Check characteristics of TK5 sensor resistance value. Check TK1, TK2, TK3, TK4 and TK5 misconnection. Check SV3E valve operation error. Check capillary clogging of oil-equalization circuit and check valve operation error. Check refrigerant stagnation in compressor.
H25 – UF C			026	Outdoor unit discharge temp. sensor (TD3) miswiring	All stop	While compressor 2 is operating, the discharge temp. (TD3) does not rise up.	 Check mounting of TD3 sensor. Check connection and wiring of TD3 sensor connector. Check characteristics of TD3 sensor resistance value. Check outdoor unit P.C. board (<i>VF</i>) error.
- Indoor				Duplicated indoor center units	Corresponding unit only stops.	There are multiple center units in a group.	 Check indoor address. Check the change of remote controller connection (Group/individual) after indoor address setup.
L04 — I/F				Duplicated outdoor line address	All stop	Line address setup is duplicated against the outdoor unit in different refrigerant pipe system.	Check line address.
			1				

	(inclusion)	with priority.	: with priority and outdoor		displayed when the power	(1)	or I/F P.C. board A'ssy for	iss. board.	idoor units. between outdoor units. /F) error.	loor I/F service P.C. board. communication connector. JU, and I/F P.C. board us Receiver Transmitter	Outside device is connected to connector (CN80): 1) Check outside device error. 2) Check indoor P.C. board error. Outside device is not connected to connector (CN80):	l error.
moti trond		Check display of indoor unit with priority.	 Check display of indoor unit with priority and outdoor unit. 	Check indoor address.	 Check indoor address. Note) After installation, this code is displayed when the power is firstly turned on. 	Set up indoor capacity. (DN=11)	Check model setup on outdoor I/F P.C. board A'ssy for service.	 Check central control address. Check network adaptor P.C. board. (In case of TCC-Link) 	 Check No. of connected outdoor units. (Max. 4 units per 1 system) Check communication line between outdoor units. Check outdoor P.C. board (I/F) error. 	 Check model setup for outdoor I/F service P.C. board. Check connection of UART communication connector. Check Comp. IPDU, fan IPDU, and I/F P.C. board error. Note) UART: Universal Asynchronous Receiver Transmitter 	 Outside device is connected to connector (CN80): 1) Check outside device error. 2) Check indoor P.C. board error. Outside device is not connected to connector (CN) 	 Check indoor P.C. board error. Check indoor (I/F) P.C. board.
Error dottootion condition		Indoor units with priority were duplicated.	Indoor units with priority were duplicated.	At least one indoor unit connected to a group existed in the individual indoor units.	Address was not yet set up.	Indoor unit capacity was unset.	On the I/F P.C. board for service, jumper line was not cut according to the model.	Duplicated central control addresses	There were more than four outdoor units.	No. of IPDU units detected when power was turned on were less.	Outside error input terminal Detected signal to (CN80) for more 1 minute	P.C. board (VF) parts error
Ctatuo	olarus	All stop	All stop	Corresponding unit only stops.	Corresponding unit only stops.	Corresponding unit only stops.	All stop	All stop	All stop	All stop	Corresponding unit only stops.	Operation continues.
Chool and a		Duplicated indoor units with priority (Displayed on indoor unit with priority)	Duplicated indoor units with priority (Displayed on the unit other than indoor unit with priority)	Group line in individual indoor unit.	Indoor group / address unset	Indoor capacity unset	Outdoor capacity unset	Duplicated central control addresses	Quantity over of connected outdoor units	IPDU quantity error	Interlock in indoor unit from outside	Extended IC (Integrated Circuit) error
Detected	position	l/F	I/F	Indoor	Indoor	Indoor	I/F	TCC-Link Indoor	l/F	l/F	Indoor	l/F
Check code		1	No. of indoor units with priority	1		1	1	1	1	A:3-IPU FAN A:3-IPU FAN 1 2 3 IPDU 1 2 1 01 0 0 0 1 2 3 IPDU 02 0 0 0 0 0 0 0 03 0 0 0 0 0 0 0 05 0 0 0 0 0 0 0 06 0 0 0 0 0 0 0 0 08 0	Detected indoor address	
	Check code	I	P00		L08	I	L10	I	L28	LL29	L30	L31
Miscol	remote	L05	L06	L07	L08	F09	L10	L20	L28	L29	L30	

	Check code	code					
Wired	Outdoor	Outdoor 7-segment display	Detected	Check code name	Status	Error detection condition	Check item (position)
remote controller	Check code		position				
P01	I	I	Indoor	Indoor fan motor error	Corresponding unit only stops.		 Check the lock of fan motor (AC fan). Check cabling.
P03	P03	1	l/F	Discharge temp TD1 error	All stop	Discharge temp (TD1) exceeded 115°C.	 Check full opening of outdoor service valves (Gas side, Liquid side). Check clogging of outdoor PMV. (PMV1, 2, 4) Check characteristics of TD1 sensor resistance value. Check refrigerant shortage. Check leakage of SV4 circuit. Check SV4 circuit. (Miswiring and misinstallation of SV41, SV42 and SV43)
P04	P04	01: Compressor 1 side 02: Compressor 2 side 03: Compressor 3 side	ΓL	Actuation of high-pressure SW	All stop	High-pressure SW actuated.	 Check connection of high-pressure SW connector. Check Pd pressure sensor error. Check full opening of outdoor service valves (Gas side, Liquid side). Check outdoor fan error. Check outdoor fan motor error. Check clogging of outdoor Next exchangers. Check clogging of indoor/outdoor heat exchangers. Check clogging of nudoor suction/discharge air. Check outdoor fan system error. Check clogging of SV2 circuit. Check outdoor fan system error. Check niswiring of communication line between indoor and outdoor. Check miswiring of communication line between indoor and outdoor. Check system error. Check valve circuit. Check refrigerant overcharge.
P05	PO5	00: 	I/F	Open phase shortage/phase sequence detection Inverter DC voltage (Vdc) error (Compressor)	All stop	 Open phase was detected when the power turned on. Overvoltage/Volt shortage was detected in inverter DC voltage 	 Check outdoor P.C. board (I/F) error.
PO7	P07	01: Compressor 1 side 02: Compressor 2 side 03: Compressor 3 side	IPDU I/F	Heat sink overheat error	All stop	IGBT built-in temp sensor (TH) was overheated.	 Check power voltage. Check outdoor fan system error. Check clogging of heat sink cooling duct. Check fixation between IGBT and heat sink. (Check screwing and contact.) Check IPDU error.(IGBT built-in temp sensor (TH) error).
P10	P10	Indoor address with trouble	Indoor	Indoor overflow error	All stop	 Float switch operated. Float switch circuit disconnected or the connector came off. 	 Check the float switch connector. Check operation of drain pump unit. Check the drain pump circuit. Check clogging of drain pipe. Check indoor P.C. board error.
P12		I	Indoor	Indoor fan motor error	Corresponding unit only stops.	 The value of motor speed deviated from target value was detected for certain time. Over-current protection operated. 	 Check connection of fan connector and wiring. Check fan motor error. Check indoor P.C. board error. Check influence of outside air control.

	Check code	de					
Wired		Outdoor 7-segment display	Detected	Check code name	Status	Error detection condition	Check item (position)
remote controller	Check code	Auxiliary code	hosinon				
P13	P13	1	I/F	Outdoor liquid back detection error	All stop	cln cooling> While the system operated in cooling mode, high ststus of high pressure value was detected in the stopped follower unit. cln heating> While the system is operating in HEAT mode, outdoor PMV of which opening degree was 100 pulse or less for a certain time.	 Check full close operation of outdoor PMV (1, 2, 4). Check Pd and Ps sensor error. Check clogging of SV2 circuit. Check clogging of balance pipe. Check clogging of SU2 circuit. Check clogging of SU2 circuit. Check capillary clogging of oil return circuit from oil separator. Check leakage of stop valve in discharge assembly part.
P15	P15	01: TS condition	I/F	Gas leak detection (TS1 condition)	All stop	Protective stop which generates when the status that suction temperature is over the judgment standard temperature continued for 10 minutes was repeated for 4 times or more. -TS error judgment standard temperatures In cooling operation: 60°C or higher In heating operation: 40°C or higher	 Check refrigerant shortage. Check full open of outdoor service valves (gas side, liquid side). Check outdoor PMV clogging (PMV1, 2). Check characteristics of TS1 sensor resistance value. Check leakage of SV4 circuit.
		02: TD condition	1/F	Gas leak detection (TD condition)	All stop	Protective stop which generates when the status that while compressor is under low frequency operation, the discharge temperature TD1, TD2 or TD3 detected 108°C or more continuously for 10 minutes was repeated for 4 times or more.	 Check refrigerant shortage. Check outdoor PMV clogging (PMV1, 2). Check characteristics of TD1, TD2 sensor resistance value. Check inforce liftic clogging. Check pipe clogging. Check SV4 circuit (Valve leakage, misinstallation)
P17	P17	I	1/F	Discharge temp TD2 error	All stop	Protective stop which generates when the discharge temperature (TD2) was over 115°C was repeated for 4 times or more.	 Check full opening of outdoor service valves (gas side, liquid side). Check clogging of outdoor PMV (PMV1, 2, 4). Check characteristics of TD2 sensor resistance value. Check 4-way valve error. Check faetkage of SV4 circuit. Check SV4 circuit. (Miscabling and misinstallation of SV41, SV42 and SV43)
P18	P18	I	1/F	Discharge temp. TD3 error	All stop	Discharge temp. (TD3) exceeded 115°C.	 Check full opening of outdoor service valve (gas side, liquid side). Check clogging of outdoor PMV (PMV1, 2, 4) Check characteristics of TD3 sensor resistance value. Check 4-way valve error. Check Bakage of SV4 circuit. Check SV4 circuit (Miswiring and mismounting of SV41, SV42, and SV43).
P19	P19	Detected outdoor unit No.	I/F	4-way valve operation error	All stop	When abnormal refrigerating cycle data was detected in heating	 Error of 4-way valve error. Check coil error and connector connection of 4-way valve. Check characteristics of TS1/TE1 sensor resistance value. Check characteristics of Pd, Ps pressure sensor output voltage. Check misconnection of TE1 and TL sensors.
P20	P20		ΓE	High-pressure protective operation	All stop	Pd sensor detected 3.6MPa or more.	 Check Pd pressure sensor error. Check full opening of service valves (Gas side, Liquid side). Check outdoor fan error. Check outdoor fan motor error. Check outdoor fan outor error. Check ologing of outdoor PMV. (PMV1,2, 4) Check clogging of indoor/outdoor heat exchangers. Check clogging of siron-circuiting in outdoor unit. Check and solve of a siron-circuiting in outdoor unit. Check indoor fan system error. (Cause of air volume decrease) Check miscabling of indoor PMN. Check indoor fan system error. (Cause of air volume decrease) Check miscabling of ontmunication line between indoor and outdoor. Check circuit of gas balance SV4 valve. Check circuit of gas balance SV4 valve. Check circuit of SV5 valve.

	5	Check code					
Wired	Out	Outdoor 7-segment display	Detected	Check code name	Status	Error detection condition	Check item (position)
remote controller	Check code	Auxiliary code					
P22	P22	0 *: IGBT circuit 1 *: Output circuit error between each position 3 *: Mater lock error	IPDU	Outdoor fan IPDU error	All stop	(Auxiliary code: 08) Fan IPDU position detection circuit Position detection was not normally performed.	 Fan motor check Connection check of connector for fan motor Error check of IPDU P.C. board for fan
		 4 ::: Detection of motor current 4 ::: TH sensor error C :: TH sensor error D :: TH sensor error E *: Inverter DC voltage error (Outdoor unit fan) 			All stop	(Auxiliary code: 0A) Fan IPDU over-current protective circuit When the fan started and while it is operating, the status that current flows over constant flow was detected	 Fan motor check Error check of IPDU P.C. board for fan
		Note) In " * ", 0 to F is displayed, but ignore it.			All stop	(Auxiliary code: 0E) Fan IPDU position detection circuit Position detection was not normally performed.	 Fan motor check Connection check of connector for fan motor Error check of IPDU P.C. board for fan
					All stop	(Auxiliary code: 0F) Fan IPDU position detection circuit Position detection was not normally performed.	 Fan motor check Connection check of connector for fan motor Error check of IPDU P.C. board for fan
					All stop	(Auxiliary code: 06) External cause such as blast Position detection was not normally performed. (Restart after 6 seconds)	 Fan motor check Connection check of connector for fan motor
					All stop	(Auxiliary code: 04) External cause such as blast When difference between target rpm and real rpm is 25% or more (Restart after 6 seconds)	 Fan motor check Connection check of connector for fan motor
					All stop	(Auxiliary code: 0D) Fan IPDU position detection circuit Position detection was not normally performed. (Windless status)	 Fan motor check Connection check of connector for fan motor Error check of IPDU P.C. board for fan
					All stop	(Auxiliary code: 0C) External cause such as blast Position detection was not normally performed. (Windy status) (Restart after 6 seconds)	 Fan motor check Connection check of connector for fan motor
P26	P26	01: Compressor 1 side 02: Compressor 2 side 03: Compressor 3 side	IPDU	G-Tr short-circuit protection error	All stop	Instantaneous over-current was detected when compressor started.	 Check connector connection and wiring on Comp. IPDU P.C. board. Check compressor error and defect of compressor coil. Check outdoor P.C. board (Comp. IPDU) error.
P29	P29	01: Compressor 1 side 02: Compressor 2 side 03: Compressor 3 side	IPDU	Compressor position detection circuit error	All stop	Position was not normally detected.	 Check connector connection and wiring. Check compressor error and defect of compressor coil. Check P.C. board (Comp. IPDU) error.
P 33	1	1	Indoor	Other indoor error (Group follower unit error)	Corresponding unit only stops.	E07/L07/L08 was detected when other indoor unit in the group was defective.	Check indoor P.C. board.


Error detected by TCC-LINK central control device

	Check code						
Display on	Outdoor 7-segment display	ment display	Detected position	Check code name	Status	Error detection condition	Check item (position)
central control device	Check code	Auxiliary code					
C05	I		TCC-LINK	TCC-LINK central control device transmission error	Operation continued.	Signal is not transmit from central control device.	 Check central control device error. Check communication line error of central control device. Check setup of terminator resistor.
CO6	1			TCC-LINK central control device transmission error	Operation continued.	Signal is not received from central control device.	 Check central control device error. Check communication line error of central control device. Check setup of terminator resistor. Check the power of connecting destination connected device. Check P.C. board error of the connected device.
C12	Ι		General-purpose equipment I/F	General-purpose equipment General-purpose controller control <i>I/</i> F Interface batched alarm	Operation continued.	Error was input in general- purpose equipment control interface.	Check error input.
P30	Differs according to error contents of the with alarm	cording to f the with alarm	TCC-LINK	Follower unit error of group control	Operation continued.	An error occurred in follower unit of the group control. ([P30] is displayed only on the central remote controller.)	 Check the check code of the unit with alarm.
	(L20 is displayed.)			Duplicated central control address	Operation continued.	Central control addresses were duplicated.	Check the address setup.


8-5. Sensor Characteristics

Indoor Unit


Temperature sensor characteristics



Temperature [C°]	Resistance value [kΩ]
0	33.9
5	26.1
10	20.3
15	15.9
20	12.6
25	10.0
30	8.0
35	6.4
40	5.2
45	4.2
50	3.5
55	2.8
60	2.4



Temperature	Resistance
[C°]	value [kΩ]
-20	99.9
-15	74.1
-10	55.6
-5 0 5	42.2
0	32.8
5	25.4
10	19.8
15	15.6
20	12.4
25	10.0
30	8.1
35	6.5
40	5.3
45	4.4
50	3.6
55	3.0
60	2.5 2.1
65	2.1
70	1.8
75	1.5
80	1.3
85	1.1
90	1.0
95	0.8
100	0.7



Temperature	Resistance
[C°]	value [k Ω]
-20	115.2
-15	84.2
-10	62.3
-5 0 5	46.6
0	35.2
5	26.9
10	20.7
15	16.1
20	12.6
25	10.0
30	8.0
35	6.4
40	5.2
45	4.2
50	3.5
55	2.8
60	2.4
65	2.0
70	1.6
75	1.4
80	1.2

9. INSTALLATION MANUAL

Please read this Installation Manual carefully before installing the Air Conditioner.

- This Manual describes the installation method of the indoor unit.
- · For installation of the outdoor unit, follow the Installation Manual attached to the outdoor unit.

ADOPTION OF NEW REFRIGERANT

This Air Conditioner is a new type which adopts a new refrigerant HFC (R410A) instead of the conventional refrigerant R22 in order to prevent destruction of the ozone layer.

Contents

1	PRECAUTIONS FOR SAFETY
2	ACCESSORY PARTS
3	SELECTION OF INSTALLATION PLACE
4	INSTALLATION OF INDOOR UNIT
5	CUTTING A HOLE AND MOUNTING INSTALLATION PLATE
6	PIPING AND DRAIN HOSE INSTALLATION
7	INDOOR UNIT FIXING
8	DRAINAGE
9	REFRIGERANT PIPING
10	ELECTRICAL CONNECTION
11	APPLICABLE CONTROLS
12	TEST RUN
13	TROUBLESHOOTING

Generic Denomination: Air Conditioner

Definition of Qualified Installer or Qualified Service Person

The air conditioner must be installed, maintained, repaired and removed by a qualified installer or qualified service person. When any of these jobs is to be done, ask a qualified installer or qualified service person to do them for you.

A qualified installer or qualified service person is an agent who has the qualifications and knowledge described in the table below.

Agent	Qualifications and knowledge which the agent must have
Qualified installer	 The qualified installer is a person who installs, maintains, relocates and removes the air conditioners made by Toshiba Carrier Corporation. He or she has been trained to install, maintain, relocate and remove the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such operations by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to these operations. The qualified installer who is allowed to do the electrical work involved in installation, relocate and removal has the qualifications pertaining to this electrical work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to electrical work on the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. The qualified installer who is allowed to do the refrigerant handling and piping work involved in installation, relocation and removal has the qualifications pertaining to this refrigerant handling and piping work as stipulated by the local laws and regulations, and he or she is allowed to do the refrigerant handling and piping work involved in installation, relocation and removal has the qualifications pertaining to this refrigerant handling and piping work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to refrigerant handling and piping work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to refrigerant handling and piping work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to individuals who have been trained and is thus thoroughly acquainted with the knowledge related
Qualified service person	 The qualified service person is a person who installs, repairs, maintains, relocates and removes the air conditioners made by Toshiba Carrier Corporation. He or she has been trained to install, repair, maintain, relocate and remove the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such operations by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to these operations. The qualified service person who is allowed to do the electrical work involved in installation, repair, relocation and removal has the qualifications pertaining to this electrical work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to electrical work on the air conditioners made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. The qualified service person who is allowed to do the refrigerant handling and piping work involved in installation, repair, relocation and removal has the qualifications pertaining to this refrigerant handling and piping work as stipulated by the local laws and regulations, and he or she is a person who have been trained and is thus thoroughly acquainted by the local laws and regulations, and he or she is a person who is allowed to do the refrigerant handling and piping work involved in installation, repair, relocation and removal has the qualifications pertaining to this refrigerant handling and piping work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to refrigerant handling and piping work on the air conditioners made by Toshiba Carrier Corporation or, she is a person who has been trained in matters relating to update the nort develope related to this work. <li< td=""></li<>

Definition of Protective Gear

When the air conditioner is to be transported, installed, maintained, repaired or removed, wear protective gloves and 'safety' work clothing.

In addition to such normal protective gear, wear the protective gear described below when undertaking the special work detailed in the table below.

Failure to wear the proper protective gear is dangerous because you will be more susceptible to injury, burns, electric shocks and other injuries.

Work undertaken	Protective gear worn
All types of work	Protective gloves 'Safety' working clothing
Electrical-related work	Gloves to provide protection for electricians and from heat Insulating shoes Clothing to provide protection from electric shock
Work done at heights (19.7" (50 cm))	Helmets for use in industry
Transportation of heavy objects	Shoes with additional protective toe cap
Repair of outdoor unit	Gloves to provide protection for electricians and from heat

Warning indications on the air conditioner unit

Warning indication	Description
	Description
WARNING ELECTRICAL SHOCK HAZARD Disconnect all remote electric power supplies before servicing.	WARNING ELECTRICAL SHOCK HAZARD Disconnect all remote electric power supplies before servicing.
WARNING Moving parts. Do not operate unit with grille removed. Stop the unit before the servicing.	WARNING Moving parts. Do not operate unit with grille removed. Stop the unit before the servicing.
CAUTION High temperature parts. You might get burned when removing this panel.	CAUTION High temperature parts. You might get burned when removing this panel.
CAUTION Do not touch the aluminum fins of the unit. Doing so may result in injury.	CAUTION Do not touch the aluminium fins of the unit. Doing so may result in injury.
CAUTION BURST HAZARD Open the service valves before the operation, otherwise there might be the burst.	CAUTION BURST HAZARD Open the service valves before the operation, otherwise there might be the burst.

1 PRECAUTIONS FOR SAFETY

- Ensure that all Local, National and International regulations are satisfied.
- Read this "PRECAUTIONS FOR SAFETY" carefully before Installation.
- The precautions described below include the important items regarding safety. Observe them without fail.
- After the installation work, perform a trial operation (test run) to check for any problem.

Follow the Owner's Manual to explain how to use and maintain the unit to the customer.

- Turn off the main power supply switch (or breaker) before the unit maintenance.
- Ask the customer to keep the Installation Manual together with the Owner's Manual.

The manufacturer shall not assume any liability for the damage caused by not observing the description of this manual.

General

- Before starting to install the air conditioner, read through the Installation Manual carefully, and follow its instructions to install the air conditioner.
- Only a qualified installer(*1) or qualified service person(*1) is allowed to do installation work. Inappropriate installation may result in water leakage, electric shock or fire.
- Do not use any refrigerant different from the one specified for complement or replacement. Otherwise, abnormally high pressure may be generated in the refrigeration cycle, which may result in a failure or explosion of the product or an injury to your body.
- Before opening the front panel of the indoor unit or service panel of the outdoor unit, set the circuit breaker to the OFF position. Failure to set the circuit breaker to the OFF position may result in electric shocks through contact with the interior parts. Only a qualified installer(*1) or qualified service person(*1) is allowed to remove the front panel of the indoor unit or service panel of the outdoor unit and do the work required.
- Before carrying out the installation, maintenance, repair or removal work, be sure to set the circuit breaker to the OFF position. Otherwise, electric shocks may result.
- Place a "Work in progress" sign near the circuit breaker while the installation, maintenance, repair or removal work is being carried out. There is a danger of electric shocks if the circuit breaker is set to ON by mistake.
- Only a qualified installer(*1) or qualified service person(*1) is allowed to undertake work at heights using a stand of 19.7" (50 cm) or more or to remove the front panel of the indoor unit to undertake work.
- Wear protective gloves and safety work clothing during installation, servicing and removal.
- Do not touch the aluminium fin of the unit. You may injure yourself if you do so. If the fin must be touched for some reason, first put on protective gloves and safety work clothing, and then proceed.

- Do not climb onto or place objects on top of the outdoor unit. You may fall or the objects may fall off of the outdoor unit and result in injury.
- When work is performed at heights, use a ladder which complies with the ISO 14122 standard, and follow the procedure in the ladder's instructions. Also wear a helmet for use in industry as protective gear to undertake the work.
- Before cleaning the filter or other parts of the outdoor unit, set the circuit breaker to OFF without fail, and place a "Work in progress" sign near the circuit breaker before proceeding with the work.
- Before working at heights, put a sign in place so that no-one will approach the work location, before proceeding with the work. Parts and other objects may fall from above, possibly injuring a person below. While carrying out the work, wear a helmet for protection from falling objects.
- The refrigerant used by this air conditioner is the R410A.
- The air conditioner must be transported in stable condition. If any part of the product is broken, contact the dealer.
- When the air conditioner must be transported by hand, carry it by two or more people.
- Do not move or repair any unit by yourself. There is high voltage inside the unit. You may get electric shock while removing the cover and main unit.
- This appliance is intended to be used by expert or trained users in shops, in light industry, or for commercial use by lay persons.

Selection of installation location

- When the air conditioner is installed in a small room, provide appropriate measures to ensure that the concentration of refrigerant leakage occur in the room does not exceed the critical level.
- Do not install the air conditioner in a location that may be subject to a risk of exposure to a combustible gas. If a combustible gas leaks and becomes concentrated around the unit, a fire may occur.
- To transport the air conditioner, wear shoes with additional protective toe caps.
- To transport the air conditioner, do not take hold of the bands around the packing carton. You may injure yourself if the bands should break.
- Do not place any combustion appliance in a place where it is directly exposed to the wind of air conditioner, otherwise it may cause imperfect combustion.
- Do not install in a location where flammable gas leaks are possible. If the gas leak and accumulate around the unit, it may ignite and cause a fire.
- Install the indoor unit at least 8'2" (2.5 m) above the floor level since otherwise the users may injure themselves or receive electric shocks if they poke their fingers or other objects into the indoor unit while the air conditioner is running.

Installation

- Install the air conditioner securely in a location where the base can sustain the weight adequately. If the strength is not enough, the unit may fall down resulting in injury.
- Follow the instructions in the Installation Manual to install the air conditioner. Failure to follow these instructions may cause the product to fall down or

topple over or give rise to noise, vibration, water leakage or other trouble.

- Carry out the specied installation work to guard against the possibility of high winds and earthquake. If the air conditioner is not installed appropriately, a unit may topple over or fall down, causing an accident.
- If refrigerant gas has leaked during the installation work, ventilate the room immediately. If the leaked refrigerant gas comes in contact with fire, noxious gas may generate.
- Use forklift to carry in the air conditioner units and use winch or hoist at installation of them.

Refrigerant piping

- Install the refrigerant pipe securely during the installation work before operating the air conditioner. If the compressor is operated with the valve open and without refrigerant pipe, the compressor sucks air and the refrigeration cycles is over pressurized, which may cause a injury.
- Tighten the flare nut with a torque wrench in the specified manner. Excessive tighten of the flare nut may cause a crack in the flare nut after a long period, which may result in refrigerant leakage.
- After the installation work, confirm that refrigerant gas does not leak. If refrigerant gas leaks into the room and flows near a fire source, such as a cooking range, noxious gas may be generated.
- When the air conditioner has been installed or relocated, follow the instructions in the Installation Manual and purge the air completely so that no gases other than the refrigerant will be mixed in the refrigerating cycle. Failure to purge the air completely may cause the air conditioner to malfunction.
- Nitrogen gas must be used for the airtight test.
- The charge hose must be connected in such a way that it is not slack.

Electrical wiring

- Only a qualified installer(*1) or qualified service person(*1) is allowed to carry out the electrical work of the air conditioner. Under no circumstances must this work be done by an unqualified individual since failure to carry out the work properly may result in electric shocks and/or electrical leaks.
- To connect the electrical wires, repair the electrical parts or undertake other electrical jobs, wear gloves to provide protection for electricians and from heat, insulating shoes and clothing to provide protection from electric shocks. Failure to wear this protective gear may result in electric shocks.
- Use wiring that meets the specifications in the Installation Manual and the stipulations in the local regulations and laws. Use of wiring which does not meet the specifications may give rise to electric shocks, electrical leakage, smoking and/or a fire.
- Connect earth wire. (grounding work)
 Incomplete grounding causes an electric shock.
- Do not connect earth wires to gas pipes, water pipes, and lightning conductor or telephone earth wires.
- After completing the repair or relocation work, check that the earth wires are connected properly.

- Install a circuit breaker that meets the specifications in the installation manual and the stipulations in the local regulations and laws.
- Install the circuit breaker where it can be easily accessed by the agent.
- When installing the circuit breaker outdoors, install one which is designed to be used outdoors.
- Under no circumstances the power wire must not be extended. Connection trouble in the places where the wire is extended may give rise to smoking and/or a fire.
- Electrical wiring work shall be conducted according to law and regulation in the community and installation manual. Failure to do so may result in electrocution or short circuit.

Test run

- Before operating the air conditioner after having completed the work, check that the electrical control box cover of the indoor unit and service panel of the outdoor unit are closed, and set the circuit breaker to the ON position. You may receive an electric shock if the power is turned on without first conducting these checks.
- If there is any kind of trouble (such as an error display has appeared, smell of burning, abnormal sounds, the air conditioner fails to cool or heat or water is leaking) has occurred in the air conditioner, do not touch the air conditioner yourself but set the circuit breaker to the OFF position, and contact a qualified service person. Take steps to ensure that the power will not be turned on (by marking "out of service" near the circuit breaker, for instance) until qualified service person(*1) arrives. Continuing to use the air conditioner in the trouble status may cause mechanical problems to escalate or result in electric shocks or other trouble.
- After the work has finished, use an insulation tester set (500V Megger) to check the resistance is $1M\Omega$ or more between the charge section and the non-charge metal section (earth section). If the resistance value is low, a disaster such as a leak or electric shock is caused at user's side.
- Upon completion of the installation work, check for refrigerant leaks and check the insulation resistance and water drainage. Then conduct a test run to check that the air conditioner is operating properly.

Explanations given to user

- Upon completion of the installation work, tell the user where the circuit breaker is located. If the user does not know where the circuit breaker is, he or she will not be able to turn it off in the event that trouble has occurred in the air conditioner.
- If the fan grille is damaged, do not approach the outdoor unit but set the circuit breaker to the OFF position, and contact a qualified service person(*1) to have the repairs done. Do not set the circuit breaker to the ON position until the repairs are completed.
- After the installation work, follow the Owner's Manual to explain to the customer how to use and maintain the unit.

Relocation

- Only a qualified installer(*1) or qualified service person(*1) is allowed to relocate the air conditioner. It is dangerous for the air conditioner to be relocated by an unqualified individual since a fire, electric shocks, injury, water leakage, noise and/or vibration may result.
- While carrying out the pump-down work shut down the compressor before disconnecting the refrigerant pipe. Disconnecting the refrigerant pipe with the service valve left open and the compressor still operating will cause air or other gas to be sucked in, raising the pressure inside the refrigeration cycle to an abnormally high level, and possibly resulting in rupture, injury or other trouble.

New refrigerant air conditioner installation

- This air conditioner adopts the new HFC refrigerant (R410A) which does not destroy ozone layer.
- The characteristics of R410Å refrigerant are; easy to absorb water, oxidizing membrane or oil, and its pressure is approx. 1.6 times higher than that of refrigerant R22. Accompanied with the new refrigerant, refrigerating oil has also been changed. Therefore, during installation work, be sure that water, dust, former refrigerant, or refrigerating oil does not enter the refrigerating cycle.
- To prevent charging an incorrect refrigerant and refrigerating oil, the sizes of connecting sections of charging port of the main unit and installation tools are changed from those for the conventional refrigerant.
- Accordingly the exclusive tools are required for the new refrigerant (R410A).
- For connecting pipes, use new and clean piping designed for R410A, and please care so that water or dust does not enter.

To disconnect the appliance from main power supply.

• This appliance must be connected to the main power supply by means of a switch with a contact separation of at least 0.1" (3 mm)

The installation fuse (all types can be used) must be used for the power supply line of this air conditioner.

Install the indoor unit at least 8'2" (2.5 m) above the floor level since otherwise the users may injure themselves or receive electric shocks if they poke their fingers or other objects into the indoor unit while the air conditioner is running.

(*1) Refer to the "Definition of Qualified Installer or Qualified Service Person."

2 ACCESSORY PARTS

Part name	Q'ty	Shape	Usage
Installation Manual	1	This manual	(Hand over to customers)
Owner's Manual	1		(Hand over to customers)
Installation plate	1		
Wireless remote controller	1		
Battery	2	۵	
Remote controller holder	1	E C	
Mounting screw Ø0.16" (4 mm) × 1.0" (25 mm)	6		
Flat head wood screw Ø1/8" (3.1 mm) × 0.6" (16 mm)	2		
Screw Ø0.16"(4 mm) × 0.4"(10 mm)	2		
Heat insulator	1		
Mounit-Conduit	1		

3 SELECTION OF INSTALLATION PLACE

• Install the air conditioner at enough strong place to withstand the weight of the unit. If the strength is not enough, the unit may fall down resulting in injury.

• Do not install the air conditioner in a location subject to a risk of exposure to a combustible gas.

If a combustible gas leaks and stays around the unit, a fire may occur.

Upon approval of the customer, install the air conditioner in a place that satisfies the following conditions.

- Place where the unit can be installed horizontally.
- Place where a sufficient servicing space can be ensured for safety maintenance and check.
- Place where drained water will not cause any problem.

Avoid installing in the following places.


Select a location for the indoor unit where the cool or warm air will circulate evenly. Avoid installation in the following kinds of locations.

- · Saline area (coastal area).
- Locations with acidic or alkaline atmospheres (such as areas with hot springs, factories where chemicals or pharmaceuticals are made and places where the exhaust air from combustion appliances will be sucked into the unit).

Doing so may cause the heat exchanger (its aluminum fins and copper pipes) and other parts to become corroded.

- Locations with atmospheres with mist of cutting oil or other types of machine oil. Doing so may cause the heat exchanger to become corroded, mists caused by the blockage of the heat exchanger to be generated, the plastic parts to be damaged, the heat insulators to peel off, and other such problems to result.
- Places where iron or other metal dust is present. If iron or other metal dust adheres to or collects on the interior of the air conditioner, it may spontaneously combust and start a fire.
- Locations where vapors from food oils are formed (such as kitchens where food oils are used). Blocked filters may cause the air conditioner's performance to deteriorate, condensation to form, the plastic parts to be damaged, and other such problems to result.
- Locations near obstructions such as ventilation openings or lighting fixtures where the flow of the blown air will be disrupted (a disruption of the air flow may cause the air conditioner's performance to deteriorate or the unit to shut down).
- Locations where an in-house power generator is used for the power supply. The power line frequency and voltage may fluctuate, and the air conditioner may not work properly as a result.
- · On truck cranes, ships or other moving conveyances.
- The air conditioner must not be used for special applications (such as for storing food, plants, precision instruments or art works).
- (The quality of the items stored may be degraded.)
- Locations where high frequencies are generated (by inverter equipment, in-house power generators, medical equipment or communication equipment). (Malfunctioning or control trouble in the air conditioner or noise may adversely affect the equipment's operation.)
- Locations where there is anything under the unit installed that would be compromised by wetness. (If the drain has become blocked or when the humidity is over 80%, condensation from the indoor unit will drip, possibly causing damage to anything underneath.)
- In the case of the wireless type of system, rooms with the inverter type of fluorescent lighting or locations exposed to direct sunlight.
- (The signals from the wireless remote controller may not be sensed.)
- Locations where organic solvents are being used.
- The air conditioner cannot be used for liqueed carbonic acid cooling or in chemical plants.
- Location near doors or windows where the air conditioner may come into contact with high-temperature, high-humidity outdoor air. (Condensation may occur as a result.)
- · Locations where special sprays are used frequently.

Installation diagram of Indoor and outdoor units



Installation space

The indoor unit shall be installed at least 8'2" (2.5 m) height. Also it must be avoided to put anything on top of the indoor unit.

- *1 Reserve space required to install the indoor unit and for service work. Keep 4.3" (110 mm) or more for clearance between top plate of the indoor unit and the ceiling surface.
- *2 Provide a space as shown for service clearance for the cross flow fan.


Installation place

- A place which provides the spaces around the indoor unit as shown in the above diagram.
- A place where there is no obstacle near the air inlet and outlet.
- · A place that allows easy installation of the piping to the outdoor unit.
- A place which allows the front panel to be opened.

- · Direct sunlight to the indoor unit's wireless receiver should be avoided.
- The microprocessor in the indoor unit should not be too close to RF noise sources. (For details, see the owner's manual.)

Wireless remote controller

- A place where there are no obstacles such as a curtain that may block the signal from the indoor unit.
- Do not install the remote controller in a place exposed to direct sunlight or close to a heating source, such as a stove.
- Keep the remote controller at least 3'3" (1 m) apart from the nearest TV set or stereo equipment. (This is necessary to prevent image disturb-bounces or noise interference.)
- The location of the remote controller should be determined as shown below.



4 INSTALLATION OF INDOOR UNIT

Install the air conditioner certainly to sufficiently withstand the weight. If the strength is insufficient, the unit may fall down resulting in human injury. Perform a specified installation work to guard against strong wind or earthquake. An incomplete installation can cause accidents by the units falling and dropping.

REQUIREMENT

Strictly comply with the following rules to prevent damage of the indoor units and human injury.

- · Do not put a heavy article on the indoor unit. (Even units are packaged)
- Carry in the indoor unit as it is packaged if possible. If carrying in the indoor unit unpacked by necessity, be sure to use buffering cloth, etc. to not damage the unit.
- To move the indoor unit, do not apply force to the refrigerant pipe, drain pan, foamed parts, or resin parts, etc.
- Carry the package by two or more persons, and do not bundle it with plastic band at positions other than specified.

Be careful to the following items when installing the unit.

• Considering air discharge direction, select an installation place where discharde air can circulate evenly in a room. Avoid to install the unit at place with "NO GOOD" mark in the right figure.




NO GOOD

Good installation place Cooled well all over.




Bad installation place




Changing MOUNT-COUNT

• Step to remove the MOUNT-CONDUIT

1) The MOUNT-CONDUIT can be removed by removing the screw securing the MOUNT-CONDUIT and them pulling out the MOUNT-CONDUIT.




2) Remove the MOUNT-CONDUIT by direction backside of unit.



 Remove the EDGE-SADDLE take off from MOUNT-CONDUIT.



• Step to install the MOUNT-CONDUIT (Option connect power supply 2 Hole)




5 CUTTING A HOLE AND MOUNTING INSTALLATION PLATE

Cutting a hole

In case of installing the refrigerant pipes from the rear:

 Decide the hole position for piping at 7.1" (180 mm) from the arrow mark (⇔) on the installation plate and drill a hole at a slight downward slant toward outdoor side. Pipe hole; dia.2.6" (65 mm): AP015-AP018 type Pipe hole; dia.3.1" (80 mm): AP024 type




NOTE

• When drilling a wall that contains a metal lath, wire lath or metal plate, be sure to use a pipe hole brim ring sold separately.

Mounting the installation plate


Be sure that the installation plate is fix to the wall with screws to make the indoor unit fit to the wall.



When the installation plate is directly mounted on the wall

- 1. Securely fit the installation plate onto the wall by screwing it in the upper and lower parts to hook up the indoor unit.
- 2. To mount the installation plate on a concrete wall with anchor bolts, utilize the anchor bolt holes as illustrated in the above figure.
- 3. Install the installation plate horizontally in the wall.

When installing the installation plate with a mounting screw, do not use the anchor bolt hole. Otherwise the unit may fall down and result in personal injury and property damage.



Failure to firmly install the unit may result in personal injury and property damage if the unit falls.

- In case of block, brick, concrete or similar type walls, make 0.2" (5 mm) dia. holes in the wall.
- Insert clip anchors for appropriate mounting screws.


NOTE

• Secure four corners and lower parts of the installation plate with 6 mounting screws to install it.

6 PIPING AND DRAIN HOSE INSTALLATION

Piping and drain hose forming

* Since dewing results in a machine trouble, make sure to insulate both connecting pipes. (Use polyethylene foam as insulating material.)



1. Die-cutting front panel slit

Cut out the slit on the left or right side of the front panel for the left or right connection and the slit on the bottom left or right side of the front panel for the bottom left or right connection with a pair of nippers.

2. Changing drain hose

For leftward connection, bottom-leftward connection and rearleftward connection's piping, it is necessary to change the drain hose and drain cap.


How to remove the drain hose

- The drain hose can be removed by removing the screw securing the drain hose and then pulling out the drain hose.
- When removing the drain hose, be careful of any sharp edges of steel plate. The edges can injuries.
- To install the drain hose, insert the drain hose firmly until the connection part contacts with heat insulator, and then secure it with original screw.




How to remove the drains cap

Clip the drain cap by needle-nose pliers and pull out.




How to fix the drains cap

1) Insert hexagonal wrench (dia. 0.6" (4 mm)) in a centre head.



2) Firmly insert drains cap.



Firmly insert the drain hose and drain cap; otherwise, water may leak.


How to remove the drain hose

- 1) Remove the front panel.
- 2) Remove the screws of drain hose.
- 3) Pull out the drain hose.

▼ In case of right or left piping


How to fix the drain hose

- 1) Put the drain hose.
- 2) Screw the drain hose to the indoor unit.
- 3) Install the front panel.
- After scribing slits of the front panel with a knife or a marking-off pin, cut them with a pair of nippers or an equivalent tool.



▼ In case of bottom right or bottom left piping

• After scribing slits of the front panel with a knife or a marking-off pin, cut them with a pair of nippers or an equivalent tool.




Left-hand connection with piping

Bend the connecting pipe so that it is laid within 1.7" (43 mm) above the wall surface. If the connecting pipe is laid exceeding 1.7" (43 mm) above the wall surface, the indoor unit may unstably be set on the wall. When bending the connecting pipe, make sure to use a spring bender so as not to crush the pipe.

Bend the connecting pipe within a radius of 1.2" (30 mm).

To connect the pipe after installation of the unit (figure)




NOTE

If the pipe is bent incorrectly, the indoor unit may unstably be set on the wall. After passing the connecting pipe through the pipe hole, connect the connecting pipe to the auxiliary pipes and wrap the facing tape around them.




• Bind the auxiliary pipes (two) and power supply wiring and control wiring with facing tape tightly. In case of leftward piping and rear leftward piping, bind the auxiliary pipes (two) only with facing tape.




- · Carefully arrange pipes so that any pipe does not stick out of the rear plate of the indoor unit.
- Carefully connect the auxiliary pipes and connecting pipes to one another and cut off the insulating tape wound on the connecting pipe to avoid double-taping at the joint; moreover, seal the joint with the vinyl tape, etc.
- Since dew results in a machine trouble, make sure to insulate both the connecting pipes. (Use polyethylene foam as insulating material.)
- When bending a pipe, carefully do it, not to crush it.

7 INDOOR UNIT FIXING

- 1. Pass the pipe through the hole in the wall, and hook the indoor unit on the installation plate at the upper hooks.
- 2. Swing the indoor unit to right and left to confirm that it is firmly hooked up on the installation plate.
- 3. While pressing the indoor unit onto the wall, hook it at the lower part on the installation plate. Pull the indoor unit toward you to confirm that it is firmly hooked up on the installation plate.




• For detaching the indoor unit from the installation plate, pull the indoor unit toward you while pushing its bottom up at the specified parts.



Information

The lower part of indoor unit may float, due to the condition of piping and you cannot fix it to the installation plate. In that case, use the screws provided to fix the unit and the installation plate.




8 DRAINAGE

1. Run the drain hose sloped downwards.

NOTE


- Hole should be made at a slight downward slant on the outdoor side.
- 2. Put water in the drain pan and make sure that the water is drained out of doors.
- 3. When connecting extension drain hose, insulate the connecting part of extension drain hose with shield pipe.



Arrange the drain pipe for proper drainage from the unit.

Improper drainage can result in dew-dropping.

This air conditioner has the structure designed to drain water collected from dew, which forms on the back of the indoor unit, to the drain pan. Therefore, do not store the power cord and other parts at a height above the drain guide.



9 REFRIGERANT PIPING

Refrigerant Piping

- 1. Use copper pipe with 0.03" (0.8 mm) or more thickness. (In case pipe size is dia. 5/8" (15.9 mm),with 0.04" (1.0 mm) or more.)
- 2. Flare nut and flare works are also different from those of the conventional refrigerant. Take out the flare nut attached to the main unit of the air conditioner, and use it.

REQUIREMENT

When the refrigerant pipe is long, provide support brackets at intervals of 8'2" - 9'9" (2.5 - 3 m) to clamp the refrigerant pipe. Otherwise, abnormal sound may be generated

IMPORTANT 4 POINTS FOR PIPING WORK

- 1. Remove dust and moisture from the inside of the connecting pipes.
- 2. Tight connection (between pipes and unit)
- 3. Evacuate the air in the connecting pipes using VACUUM PUMP.
- 4. Check the gas leakage. (Connected points)

Pipe size

(dia.: in (mm))

Model	AP015 to AP018 type	AP024 type
Gas side	1/2" (12.7)	5/8" (15.9)
Liquid side	1/4" (6.4)	3/8" (9.5)


Permissible Piping Length and Height Difference

They vary according to the outdoor unit. For details, refer to the Installation Manual attached to the outdoor unit.

Flaring

- Cut the pipe with a pipe cutter. Remove burrs completely. Remaining burrs may cause gas leakage.
- Insert a flare nut into the pipe, and flare the pipe. As the flaring sizes of R410A differ from those of refrigerant R22, the flare tools newly manufactured for R410A are recommended. However, the conventional tools can

be used by adjusting projection margin of the copper pipe.



А

▼ Projection margin in flaring: B (Unit: in (mm)) RIDGID (Clutch type)

Outer dia. of	R410A tool used	Conventional tool used	
copper pipe	R410A	R410A	
1/4" (6.4) , 3/8" (9.5)	0 - 0.02" (0 - 0.5)	0.04" - 0.06"	
1/2" (12.7) , 5/8" (15.9)	0 - 0.02 (0 - 0.5)	(1.0 - 1.5)	

▼ Flaring dia. meter size: A (Unit: in (mm))

Outer die of eenner nine	A -0.4		
Outer dia. of copper pipe	R410A		
1/4" (6.4)	0.36" (9.1)		
3/8" (9.5)	0.52" (13.2)		
1/2" (12.7)	0.66" (16.6)		
5/8" (15.9)	0.78" (19.7)		

* In case of flaring for R410A with the conventional flare tool, pull it out approx. 0.02" (0.5 mm) more than that for R22 to adjust to the specified flare size. The copper pipe gauge is useful for adjusting projection margin size.

- 87 -

Tightening connection

• Do not apply excessive torque. Otherwise, the nut may crack depending on the conditions.

	(01111.111 (11111))
Outer dia. of copper pipe	Tightening torque
1/4" (6.4 mm) (dia.)	10-13 (14-18)
3/8" (9.5 mm) (dia.)	24-31 (33-42)
1/2" (12.7 mm) (dia.)	37-46 (50-62)
5/8" (15.9 mm) (dia.)	50-60 (68-82)

(Unit: in (mm))

▼ Tightening torque of flare pipe connections

Pressure of R410A is higher than that of R22. (Approx. 1.6 times) Therefore, using a torque wrench, tighten the flare pipe connecting sections which connect the indoor and outdoor units of the specified tightening torque.

Incorrect connections may cause not only a gas leak, but also a trouble of the refrigeration cycle. Align the centres of the connecting pipes and tighten the flare nut as far as possible with your fingers. Then tighten the nut with a spanner and torque wrench as shown in the figure.



Work using double spanner

REQUIREMENT

Tightening with an excessive torque may crack the nut depending on installation conditions. Tighten the nut within the specified tightening torque.

Piping with outdoor unit


• Shape of valve differs according to the outdoor unit.

For details of installation, refer to the Installation Manual of the outdoor unit.

Heat insulation

Heat insulation for the pipes should be done separately for the liquid side and gas side. Because both of the liquid and gas side pipes become a low temperature during cooling operation, sufficient heat insulation should be done to prevent condensation.

- Heat insulator with a heat resistance of 248°F (120°C) or more must be used for the gas side pipe.
- The pipe connection section of the indoor unit must be heat insulated securely and compactly with the attached heat insulator.



■ Airtight test/Air purge, etc.

For airtight test,air purge, addition of refrigerant, and gas leak check, follow the Installation Manual attached to the outdoor unit.

Open fully valves of the outdoor unit

Gas leak check

Check with a leak detector or soap water whether gas leaks or not, from the pipe connecting section or cap of the valve.

REQUIREMENT

Use a leak detector manufactured exclusively HFC refrigerant (R410A, R134a, etc.).

10 ELECTRICAL CONNECTION

1. Use predefined wire and connect them certainly. Keep the connecting terminal freefrom external force.

Improper wire connection or clamping may result in exothermic, fire or malfunction.

- 2. Connect ground wire. (grounding work) Incomplete grounding cause an electric shock. Do not connect ground wires to gas pipes, water pipes, lightning rods or ground wires for telephone wires.
- 3. Install appliance in accordance with national wiring regulations. Capacity shortage of circuit breaker or incomplete installation may cause an electric shock or a fire.

- Consult local building codes, NEC (National Electrical Code) or CEC (Canadian Electrical Code) for special requirements.
- If incorrect / incomplete wiring is carried out, it will cause an electrical fire or smoke.
- Install circuit breaker is not tripped by shock waves. If circuit breaker is not installed,an electric shock may be caused.
- Use the cord clamps attached to the product.
- Do not damage or scratch the conductive core and inner insulator of power and control wires when peeling them.
- Use the power cord and control wire of specifed thickness, type, and protective devices required.
- Do not connect 208/230 V power to the terminal blocks (U1, U2, A, B etc.) for control wiring. (Otherwise,the system will fail.)
- Perform the electric wiring so that it does not come to contact with the high-temperature part of the pipe.
- The coating may melt resulting in an accident.
- Do not turn on the circuit breaker of the indoor unit until vacuuming of the refrigerant pipes completes.

REQUIREMENT

- For power supply wiring, strictly conform to the Local Regulation in each country.
- Run the refrigerant piping line and control wiring line in the same line.

Power supply wire and control wires specifications

Power supply wire and control wires are locally procured.

For the power supply specifications, follow to the table below. If capacity is little, it is dangerous because overheat or seizure may be caused.

Indoor unit power supply

For the power supply of the indoor unit, prepare the exclusive power supply separated from that of the outdoor unit.

Power supply

Power supply 208 / 230-1-60

Control wiring, Central control wiring

- 2-core with non-polarity wires are used for the control wiring between indoor unit and outdoor unit and Central control wiring.
- . To prevent noise trouble, use 2-core shielded wire.
- The length of the communication line means the total length of the control wire length between indoor and outdoor units added with the central control wire length.

Power supply wire

Recommended wire diameter and wire length for power supply wire.

Power supply wiring	Wire size: 2 × AWG12 Ground 1 × AWG12 or thicker	Up to 164'1" (50 m)
---------------------	---	---------------------

▼ Electric characteristics

		Voltage F	Range (V)	MCA	MOCP
Model	Power Supply	Min	Мах	(A)	(A)
MMK-AP0157HPUL				0.38	15
MMK-AP0187HPUL	208/230V-1-60Hz	187	253	0.41	15
MMK-AP0247HPUL				0.60	15


Control wire

Control wiring between indoor units, and outdoor unit (2-core shielded wire)	Wire size	(Up to 3280'10" (1000 m)) AWG16 (Up to 6561'8" (2000 m)) AWG14
--	-----------	---

Remote control wiring

2-core with non-polarity wire is used for wiring of the remote control wiring and group remote controls wiring.

Remote control wiring, remote control inter-unit wiring	Wire size: AWG20		
Total wire length of remote control wiring and remote control	I In case of wired type only Up to 1640'5" (50		
inter-unit wiring = $L + L1 + L2 + Ln$		Up to 1312'4" (400 m)	
Total wire length of remote control inter-unit wiring = L1 + L2	Up to 656'2" (200 m)		



NOTE


- Use copper supply wire.
- Use UL wire rated 600 V for the power supply.
- Use UL wire rated 300 V for the remote control wires and control wires.

The remote control wire (Communication line) and AC208 / 230 V wires cannot be parallel to contact each other and cannot be stored in the same conduits. If doing so, a trouble may be caused on the control system due to noise or other factor.

NOTE

An outdoor unit connected with control wiring between indoor and outdoor units wire becomes automatically the header unit.

Wiring example




Address setup

Set up the addresses as per the Installation Manual supplied with the outdoor unit.

Wired remote controller wiring

 As the wired remote controller wire has non-polarity, there is no problem if connections to indoor unit terminal blocks A and B are reversed.

▼ Wiring diagram



Wiring Connection

How to connect the power supply wiring and control wiring


The power supply wire and the control wire can be connected without removing the front panel.

REQUIREMENT

Connect the power supply wire after connecting the control wire for this model.

- Remove the air inlet grille. Open the air inlet grille upward and pull it toward you.
- 2. Remove the terminal cover and the clamp base.
- 3. Insert the power supply wire and control wire (according to the local rule) into the pipe hole on the wall.
- 4. Take the power supply wire out of the cable slot on the rear panel so that it protrudes about 5.9" (150 mm) mm from the front.
- Insert the control wire fully into the control/wired remote controller terminal block (U1),(U2),(A),(B) and secure it tightly with screws.
- 6. Clamp the control wire with the cord clamp.
- 7. Install the clamp base with a screw.
- Insert the power supply wire fully into the terminal block and secure it tightly with screws. Tightening torque: 0.9 ft • lbs (1.2 N·m) Secure the earth line with the earth screw.
- 9. Clamp the power supply wire with the cord clamp.
- 10. Attach the terminal cover and the air inlet grille to the indoor unit.

- Be sure to refer to the wiring diagram attached inside the front panel.
- Check local electrical cords an also any specific wiring instructions and limitations.
- Do not catch the control wire when installing the clamp base.



Wiring connection for flow selector unit


How to connect the wiring of flow selector unit

Connect the power supply wire and the communication wire supplied with the flow selector unit to the indoor unit.

- 1. Remove the air inlet grille.
- Open the air inlet grille upward and pull it toward you.
- 2. Remove the terminal cover and the clamp base.
- 3. Insert the control wire fully into the control/wired remote controller terminal block and secure it tightly with screws.
- 4. Connect the control wire connector of the flow selector unit to the lead with a connector to the left of the control/wired remote controller terminal block.
- 5. Clamp the control wire and the control wire of the flow selector unit with the cord clamp.
- 6. Install the clamp base with a screw.
- Insert the power supply wire fully into the terminal block and secure it tightly with screws. Tightening torque: 0.9 ft • lbs (1.2 N·m) Secure the earth line with the earth screw.
- 8. Clamp the power supply wire with the cord clamp.
- 9. Insert the power supply wire fasten terminal of the flow selector unit into the power supply terminal.

Secure the earth line with the earth screw.

- 10.Clamp the power supply wire of the flow selector unit tight with the cord clamp.
- 11.Attach the terminal cover, the front panel and the air inlet grille to the indoor unit.



Confirm that every wires are stored in the electric parts box without getting caught before attaching the terminal cover.

11 APPLICABLE CONTROLS


A wired remote controller is necessary for this function. This function cannot be operate with a wireless remote controller.

REQUIREMENT

 When you use this air conditioner for the first time, it takes approx. 5 minutes until the remote controller becomes available after power-on. This is normal.


<When power is turned on for the first time after installation>

It takes approx. 5 minutes until the remote controller becomes available.



<When power is turned on for the second (or later) time>

It takes approx. 1 minute until the remote controller becomes available.



• Normal settings were made when the indoor unit was shipped from factory.

Change the indoor unit settings as required.

- Use the wired remote controller to change the settings.
 - * The settings cannot be changed using the wireless remote controller, sub remote controller, or remote-controller less system (for central remote controller only). Therefore, install the wired remote controller to change the settings.

Changing of settings of for applicable controls


Basic procedure for changing settings

Change the settings while the air conditioner is not working.

(Be sure to stop the air conditioner before making settings.)

The display content for setting differs from that on the former types of remote conteoller (RBC-AMT32UL).

(The number of CODE No. has increased.)




Procedure 1

Push button and "TEMP." v button simultaneously for at least 4 seconds. After a while, the display flashes as shown in the figure.

Confirm that the CODE No. is [10].

If the CODE No. is not [10], push to erase the display content, and repeat the procedure from the beginning.


(No operation of the remote controller is accepted for a while after remote controller is (While air conditioners are operated under the group control, "ALL" is displayed first. When ^{UNT LOVER} is pushed, the indoor unit number displayed following "ALL" is the header unit.)



Procedure 2

Each time you push (DUIT LOUVER button, indoor unit numbers in the control group change cyclically. Select the indoor unit you want to change settings for.

The fan of the selected unit runs and the louvers start swinging. You can confirm the indoor unit for which you want to change settings.



Procedure 3

Using "TEMP." () buttons, specify CODE No. [**].

Procedure 4

Using timer "TIME" 💌 / 🏊 buttons, select SET DATA [****].

Procedure 5

Push $\stackrel{\text{\tiny SET}}{\bigcirc}$ button. When the display changes from flashing to lit, the setup is completed.

- · To change settings of another indoor unit, repeat from Procedure 2.
- · To change other settings of the selected indoor unit, repeat from Procedure 3.


Use $\stackrel{\text{SET}}{\bigcirc}$ button to clear the settings. To make settings after $\stackrel{\text{SET}}{\bigcirc}$ button was pushed, repeat from Procedure $\mathbf{\tilde{2}}$.

Procedure 6

When settings have been completed, push button to determine the settings.

When button is pushed, "SETTING" flashes and then the display content disappears and the air conditioner enters the normal stop mode.

(While "SETTING" is flashing, no operation of the remote controller is accepted.)



Change of lighting time of filter sign

According to the installation condition, the lighting time of the filter sign (Notification of filter cleaning) can be changed.

Follow to the basic operation procedure

$$(\mathbf{1} \rightarrow \mathbf{2} \rightarrow \mathbf{3} \rightarrow \mathbf{4} \rightarrow \mathbf{5} \rightarrow \mathbf{6}).$$

- For the CODE No. in Procedure 3, specify [01].
- For the ISET DATA1 in Procedure **4**, select the SET DATA of filter sign lighting time from the following table.

SET DATA	Filter sign lighting time					
0000	None					
0001	150H (Factory setting)					
0002	2500H					
0003	5000H					
0004	10000H					

To secure better effect of heating

When it is difficult to obtain satisfactory heating due to installation place of the indoor unit or structure of the room, the detection temperature of heating can be raised. Also use a circulator, etc. to circulate heat air near the ceiling.

Follow to the basic operation procedure

$$(1 \rightarrow 2 \rightarrow 3 \rightarrow 4 \rightarrow 5 \rightarrow 6).$$

- For the CODE No. in Procedure **3**, specify [06].
- For the SET DATA in Procedure 4, select the SET DATA of shift value of detection temperature to be set up from the table below.

SET DATA	Detection temp shift value
0000	No shift
0001	+1.8°F (+1°C)
0002	+3.6°F (+2°C) (Factory setting)
0003	+5.4°F (+3°C)
0004	+7.2°F (+4°C)
0005	+9°F (+5°C)
0006	+10.8°F(+6°C)

Adjustment of air direction

- 1. Using the remote controller switch, change the up/down air direction by moving the horizontal louver.
- 2. Adjust the right/left air direction by bending the vertical grille inside of the air outlet port with hands.

REQUIREMENT

Do not touch the horizontal louver directly with hands; otherwise a trouble may be caused. For handling of the horizontal louver, refer to "Owner's Manual" attached to the outdoor unit.

Group control

In a group control, a remote controller can control up to maximum 8 units.

- The wired remote controller only can control a group control. The wireless remote controller is unavailable for this control.
- For cabling procedure and cables of the individual line (Identical refrigerant line) system, refer to "Electric connection" in this Manual.
- Cabling between indoor units in a group is performed in the following procedure. Connect the indoor units by connecting the remote controller inter-unit cables from the remote controller terminal blocks (A,B) of the indoor unit connected with a remote controller to the remote controller terminal blocks (A,B) of the other indoor unit. (Non-polarity)
- For address setup, refer to the Installation Manual attached to the outdoor unit.

NOTE

Net work adapter (Model TCB-PCNT20E) can not connect to this High Wall type air conditioner.

12 TEST RUN

A wired remote controller is necessary for this function. This function cannot be operate with a wireless remote controller.

Before test run

- Before turning on the power supply, carry out the following procedure.
 - 1) Using 500V-megger, check that resistance of $1M\Omega$ or more exists between the terminal block of the power supply and the earth (grounding). If resistance of less than $1M\Omega$ is detected,
 - do not run the unit.2) Check the valve of the outdoor unit being opened fully.
- To protect the compressor at activation time, leave power-ON for 12 hours or more be for operating.



 Never press the electromagnetic contactor to forcibly perform a test run. (This is very dangerous because the protective

device does not work.)

• Before starting a test run, be sure to set addresses following the installation manual supplied with the outdoor unit.

How to execute a test run

Using the wired remote controller, operate the unit as usual.


For the procedure of the operation, refer to the attached Owner's Manual.

A forced test run can be executed in the following procedure even if the operation stops by thermo.-OFF.

In order to prevent a serial operation, the forced test run is released after 60 minutes have passed and returns to the usual operation.


• Do not use the forced test run for cases other than the test run because it applies an excessive load to the devices.

In case of wired remote controller



Procedure 1

Keep button pushed for 4 seconds or more. [TEST] is displayed on the display part and the selection of mode in the test mode is permitted.




Procedure 2

Push (DON/OFF) button.

Procedure 3

Using $\textcircled{\text{MODE}}$ button, select the operation mode, [COOL] or [HEAT].

- Do not run the air conditioner in a mode other than [COOL] or [HEAT].
- The temperature controlling function does not work during test run.
- The detection of error is performed as usual.



Procedure 4


After the test run, push $\bigcirc 0 \text{ on } / 0 \text{ FF}$ button to stop a test run.

(Display part is same as procedure 1.)

Procedure 5

Push $\overset{\text{TEST}}{\checkmark}$ check button to cancel (release from) the test run mode.


([TEST] disappears on the display and the status returns to a normal.)



In case of wireless remote controller (Forced test operation is performed in a different way.)

REQUIREMENT

- For the operation procedure, be sure to follow the Owner's Manual.
- Finish the forced cooling operation in a short time because it applies excessive strength to the air conditioner.
- A test operation of forced heating is unavailable. Perform a test operation by heating operation using the switches of the remote controller.
 However heating operation may be not carried out according to the temperature conditions.
- Check wiring/piping of indoor and outdoor units
- When pushing [RESET] button for 10 seconds or more, "Pi!" sound is heard and the operation changes to a forced cooling operation. After approx. 3 minutes, a cooling operation starts forcedly. Check cool air starts blowing. If the operation does not start, check wiring again.
- 2. To stop a test operation, push [RESET] button once again (Approx. 1 second). The louver closes and the operation stops.



- Check transmission of remote controller
- 1. Push "START/STOP" button of the remote controller to check an operation can also start by the remote controller.
 - "Cooling" operation by the remote controller may be unavailable according to the temperature conditions. Check wiring/piping of the indoor and outdoor units in forced cooling operation.

13 TROUBLESHOOTING


A wired remote controller is necessary for this function. This function cannot be operate with a wireless remote controller.

Confirmation and check

When a trouble occurred in the air conditioner, the check code and the indoor UNIT No. appear on the display part of the remote controller.

The check code is only displayed during the operation.

If the display disappears, operate the air conditioner according to the following "Confirmation of error history" for confirmation.






Indoor UNIT No. in which an error occurred

Confirmation of error history

When a trouble occurred on the air conditioner, the trouble history can be confirmed with the following procedure. (The trouble history is stored in memory up to 4 troubles.)

The history can be confirmed from both operating status and stop status.




Procedure 1

When pushing \bigcirc^{SET} and \bigcirc^{TEST} buttons at the same time for 4 seconds or more, the following display appears.

If [Service check] \checkmark is displayed, the mode enters in the trouble history mode.

- [01: Order of trouble history] is displayed in CODE No. window.
- [Check code] is displayed in CHECK window.
- [Indoor unit address in which an error occurred] is displayed in UNIT No.



Procedure 2

Every pushing of "TEMP." \bigcirc button used to set temperature, the trouble history stored in memory is displayed in order. The numbers in CODE No. indicate CODE No. [01] (latest) \rightarrow [04] (oldest).

REQUIREMENT

Do not push button because all the trouble history of the indoor unit will be deleted.

Procedure 3

After confirmation, push $\overset{\text{TEST}}{\bigotimes}$ button to return to the usual display.

Check method

On the remote controller (Wired remote controller, Central control remote controller) and the interface P.C. board of the outdoor unit (I/F), a check display LCD (Remote controller) or 7-segment display (on the outdoor interface P.C. board) to display the operation is provided. Therefore the operation status can be known. Using this self-diagnosis function, a trouble or position with error of the air conditioner can be found as shown in the table below.

Check code list

The following list shows each check code. Find the check contents from the list according to part to be checked.

- In case of check from indoor remote controller: See "Wired remote controller display" in the list.
- In case of check from outdoor unit: See "Outdoor 7-segment display" in the list.
- In case of check from indoor unit with wireless remote controller: See "Sensor block display of receiving unit" in the list.

O : Lighting, ሺ : Flashing, ● : Goes off ALT: Flashing is alternately when there are two flashing LED. SIM: Simultaneous flashing when there are two flashing LED. Inverter: Compressor / Fan inverter P.C. board

Check code		Wirel	ess rem	ote cont	roller			
Wired remote	Ou	utdoor unit 7-segment display	Sensor block display of receiving unit			y of	Check code name	Judging device
controller display		Auxiliary code	Operation	Timer	Ready	Flash		
E01	-	_	۵	•	•		Communication trouble between indoor unit and remote controller (Detected at remote controller side)	Remote controller
E02	-	_	a	•	•		Remote controller transmission trouble	Remote controller
E03	-	-	۵	•	•		Communication trouble between indoor unit and remote controller (Detected at indoor unit side)	Indoor unit
E04	-	_	•	•	۵		Communication circuit trouble between indoor / outdoor unit (Detected at indoor unit side)	Indoor unit
E06	E06	No. of indoor units in which sensor has been normally received	•	•	α		Decrease of No. of indoor units	I/F
_	E07	_	•	•	α		Communication circuit trouble between indoor / outdoor unit (Detected at outdoor unit side)	I/F
E08	E08	Duplicated indoor unit addresses	a	•	•		Duplicated indoor unit addresses	Indoor unit • I/F
E09	-	_	۵	•	•		Duplicated master remote controllers	Remote controller
E10	-	_	a	•	•		Communication trouble between indoor unit MCU	Indoor unit
E11	-	_	a	•	•		Communication trouble between Application control kit and indoor unit	Indoor unit Application control kit
E12	E12	01: Indoor/Outdoor units communication 02: Outdoor/Outdoor units communication	۵	•	•		Automatic address start trouble	I/F
E15	E15	_	•	•	۵		No indoor unit during automatic addressing	I/F
E16	E16	00: Capacity over 01 ~: No. of connected units	•	•	۵		Capacity over / No. of connected indoor units	I/F
E18	-	_	۵				Communication trouble between header and follower units Indoor unit	Indoor unit
E19	E19	00: Header is not detected 02: Two or more header units			۵		Outdoor header units quantity trouble	I/F

Check code			Wirele	ess rem	ote cont	roller		
Wired remote			Sen		k displa ng unit	iy of	Check code name	Judging device
display		Auxiliary code	Operation	Timer	Ready	Flash		
E20	E20	01: Outdoor unit of other line connected 02: Indoor unit of other line connected	•	•	α		Other line connected during automatic address	I/F
E23	E23	_	•	•	a		Sending trouble in communication between outdoor units Trouble in number of heat storage units (trouble with reception)	I/F
E25	E25	-			Ø		Duplicated follower outdoor addresses	I/F
E26	E26	No. of outdoor units which received signal normally	•	•	۵		Decrease of No. of connected outdoor units	I/F
E28	E28	Detected outdoor unit number			a		Follower outdoor unit trouble	I/F
E31	E31	*1 Inverter quantity information			a		Inverter communication trouble	I/F
F01	-	-	a	a		ALT	Indoor unit TCJ sensor trouble	Indoor unit
F02	-	_	a	a		ALT	Indoor unit TC2 sensor trouble	Indoor unit
F03	-	_	α	Ø		ALT	Indoor unit TC1 sensor trouble	Indoor unit
F04	F04	_	α	a	0	ALT	TD1 sensor trouble	I/F
F05	F05	_	a	a	0	ALT	TD2 sensor trouble	I/F
F06	F06	01: TE1 sensor 02: TE2 sensor 03: TE3 sensor	a	α	0	ALT	TE1,TE2 or TE3 sensor trouble	I/F
F07	F07	01: TL1 sensor 02: TL2 sensor 03: TL3 sensor	a	α	0	ALT	TL1,TL2 or TL3 sensor trouble	I/F
F08	F08	_	a	a	0	ALT	TO sensor trouble	I/F
F09	F09	01: TG1 sensor 02: TG2 sensor 03: TG3 sensor 03: TG3 sensor		TG1,TG2 or TG3 sensor trouble	I/F			
F10	-	_	α	a		ALT	Indoor unit TA sensor trouble	Indoor unit
F11	-	_	α	a		ALT	TF sensor trouble	Indoor unit
F12	F12	01: TS1 sensor 03: TS3 sensor	a	a	0	ALT	TS1 or TS3 sensor trouble	I/F
F13	F13	01: Comp. 1 side 02: Comp. 2 side 03: Comp. 3 side	α	α	0	ALT	TH sensor trouble	Inverter
F15	F15	_	a	a	0	ALT	Outdoor unit temp. sensor miswiring (TE, TL)	I/F
F16	F16	_	a	ø	0	ALT	Outdoor unit pressure sensor miswiring (Pd, Ps)	I/F
F22	F22	-	a	a	0	ALT	TD3 sensor trouble	I/F
F23	F23	_	α	a	0	ALT	Ps sensor trouble	I/F
F24	F24	_	α	a	0	ALT	Pd sensor trouble	I/F
F29	-	_	a	a		SIM	Indoor unit other trouble	Indoor unit
F30	F30	_	a	a	0	SIM	Occupancy sensor trouble	Indoor unit
F31	F31	_	a	a	0	SIM	Indoor unit EEPROM trouble	I/F
H01	H01	01: Comp. 1 side 02: Comp. 2 side 03: Comp. 3 side	•	۵	•		Compressor break down	Inverter
H02	H02	01: Comp. 1 side 02: Comp. 2 side 03: Comp. 3 side	•	α	•		Compressor trouble (lock)	Inverter
H03	H03	01: Comp. 1 side 02: Comp. 2 side 03: Comp. 3 side	•	¤	•		Current detect circuit system trouble	Inverter
H04	H04	_		a			Comp. 1 case thermostat operation	I/F
H05	H05	_		a			TD1 sensor miswiring	I/F
H06	H06	_		a	•		Low pressure protective operation	I/F
H07	H07	_		α			Oil level down detective protection	I/F

Check code			Wirele	ess rem	ote cont	roller		
Wired remote controller		Sen		k displang unit	y of	Check code name	Judging device	
display		Auxiliary code	Operation	Timer	Ready	Flash		
H08	H08	01: TK1 sensor trouble 02: TK2 sensor trouble 03: TK3 sensor trouble 04: TK4 sensor trouble 05: TK5 sensor trouble	•	α	•		Oil level detective temp. sensor trouble	I/F
H14	H14	_		Ø			Comp. 2 case thermostat operation	I/F
H15	H15	-		a			TD2 sensor miswiring	I/F
H16	H16	01: TK1 oil circuit system trouble 02: TK2 oil circuit system trouble 03: TK3 oil circuit system trouble 04: TK4 oil circuit system trouble 05: TK5 oil circuit system trouble	•	۵	•		Oil level detective circuit trouble	l/F
H25	H25	-		a			TD3 sensor miswiring	I/F
L02	L02	_	Ø	0	Ø	SIM	Model mismatch of indoor and outdoor unit	I/F
L03	-	_	a		a	SIM	Indoor unit centre unit duplicated	Indoor unit
L04	L04	_	a	0	a	SIM	Outdoor unit line address duplicated	I/F
L05	_	_	۵	•	α	SIM	Duplicated indoor units with priority (Displayed in indoor unit with priority)	I/F
L06	L06	No. of indoor units with priority	a	•	۵	SIM	Duplicated indoor units with priority (Displayed in unit other than indoor unit with priority)	I/F
L07	-	_	a		a	SIM	Group line in individual indoor unit	Indoor unit
L08	L08	_	a	0	a	SIM	Indoor unit group/Address unset	Indoor unit, I/F
L09	-	_	a	0	a	SIM	Indoor unit capacity unset	Indoor unit
L10	L10	_	α	0	α	SIM	Outdoor unit capacity unset	I/F
L17	L17	_	a	0	a	SIM	Outdoor unit type mismatch trouble	I/F
L18	L18	_	a	0	a	SIM	Flow selector unit trouble	I/F
L20	_	_	α	0	a	SIM	Duplicated central control addresses	Indoor unit
L28	L28	_	α	0	a	SIM	Too many outdoor units connected	I/F
L29	L29	*1 Inverter quantity information	α	0	a	SIM	No. of inverter trouble	I/F
L30	L30	Detected indoor unit address		0	1	SIM	Indoor unit outside interlock	Indoor unit
_	L31	_		_			Extended I/C trouble	I/F
P01	_	_		a	Ø	ALT	Indoor fan motor trouble	Indoor unit
P03	P03	_	a	•	Ø	ALT	Discharge temp. TD1 trouble	I/F
		01: Comp. 1 side		-				
P04	P04	02: Comp. 2 side 03: Comp. 3 side	Ø	•	Ø	ALT	High-pressure SW system operation	Inverter
P05	P05	00: 01: Comp. 1 side 02: Comp. 2 side 03: Comp. 3 side	a	•	¤	ALT	Phase missing detection/Power failure detection Inverter DC voltage trouble (comp.) Inverter DC voltage trouble (comp.) Inverter DC voltage trouble (comp.)	I/F
P07	P07	01: Comp. 1 side 02: Comp. 2 side 03: Comp. 3 side	¤	•	a	ALT	Heat sink overheat trouble	Inverter, I/F
		04: Heat sink		Heat sink dew condensation trouble				
P10	P10	Detected indoor unit address	Ø	Ø	Ø	ALT	Indoor unit overflow trouble	Indoor unit
P11	P11	_	Ø	Ø	Ø	ALT	Outdoor heat exchanger freezing trouble	I/F
P12	-	_	Ø	Ø	Ø	ALT	Indoor unit fan motor trouble	Indoor unit
P13	P13	_	Ø	Ø	a	ALT	Outdoor liquid back detection trouble	I/F
P15	P15	01: TS condition 02: TD condition	¤	•	a	ALT	Gas leak detection	I/F
P17	P17	-	Ø	•	a	ALT	Discharge temp. TD2 trouble	I/F
P19	P19	Detected outdoor unit number	α	•	Ø	ALT	4-way valve inverse trouble	l/F
P20	P20	_				ALT	High-pressure protective operation	I/F

		Check code	Wirele	ess rem	ote cont	roller			
Wired remote	Ou	utdoor unit 7-segment display	Sen		k displa ng unit	y of	Check code name	Judging device	
controller display		Auxiliary code	Operation Timer Ready		Flash				
P22	P22	 #0: Element short circuit #E: Vdc voltage trouble #1: Position detection circuit trouble #2: Input current sensor trouble #3: Motor lock trouble #C: Sensor temperature trouble (No TH sensor) #4: Motor current trouble #D: Sensor short circuit/release trouble (No TH sensor) #5: Synchronization/step-out trouble *Put in Fan Inverter No. in [#] mark. 	۵	•	۵	ALT	Outdoor unit fan inverter trouble	Inverter	
P26	P26	01: Comp. 1 side 02: Comp. 2 side 03: Comp. 3 side	Ø	•	۵	ALT	IPM short protection trouble	Inverter	
P29	P29	01: Comp. 1 side 02: Comp. 2 side 03: Comp. 3 side	۵	•	۵	ALT	Comp. position detective circuit system trouble	Inverter	
P31	-	-	۵	•	۵	ALT	Other indoor unit trouble (Group follower indoor unit trouble)	Indoor unit	

*1 Inverter quantity information (Super Modular Multi System i series (SMMS-i))

No.	Com	ıp. Inv	erter	Fan	Trouble			
110.	1	2	3	Inverter	Touble			
01	0				Comp. 1			
02		0			Comp. 2			
03	0	0			Comp. 1 + Comp. 2			
04			0		Comp. 3			
05	0		0		Comp. 1 + Comp. 3			
06		0	0		Comp. 2 + Comp. 3			
07	0	0	0		Comp. 1 + Comp. 2 + Comp. 3			
08				0	Fan			
09	0			0	Comp. 1 + Fan			
0A		0		0	Comp. 2 + Fan			
0B	0	0		0	Comp. 1 + Comp. 2 + Fan			
0C			0	0	Comp. 3 + Fan			
0D	0		0	0	Comp. 1 + Comp. 3 + Fan			
0E		0	0	0	Comp. 2 + Comp. 3 + Fan			
0F	0	0	0	0	All			
	○ : Inverter trouble		ole					

*1 Inverter quantity information (Super Modular Multi System e series (SMMS-e))

No.	Cor Inve	np. erter		an erter	Trouble	
	1	2	1	2	nouble	
01	0				Comp. 1	
02		0			Comp. 2	
03	0	0			Comp. 1 + Comp. 2	
08			0		Fan1	
09	0		0		Comp. 1 + Fan1	
0A		0	0		Comp. 2 + Fan1	
0B	0	0	0		Comp. 1 + Comp. 2 + Fan1	
10				0	Fan2	
11	0			0	Comp. 1 + Fan2	
12		0		0	Comp. 2 + Fan2	
13	0	0		0	Comp. 1 + Comp. 2 + Fan2	
18			0	0	Fan1 + Fan2	
19	0		0	0	Comp. 1 + Fan1 + Fan2	
1A		0	0	0	Comp. 2 + Fan1 + Fan2	
1B	0	0	0	0	All	
(○: Inverter trouble		е			

• For details about check codes determined with an Interface P.C. board or an Inverter P.C. board, refer to the Installation Manual of the outdoor unit.

Trouble detected by central control device

		Check code	Wirele	ess rem	ote cont	roller			
Central control device	control Outdoor unit 7-segment display		Sensor block display of receiving unit			y of	Check code name	Judging device	
indication		Auxiliary code	Operation	Timer	Ready	Flash			
C05	-	_	-				Sending trouble in central control device	Communication Link	
C06	-	-	-				Receiving trouble in central control device	Communication Link	
C12	-	-	_				Batch alarm of general-purpose equipment control interface	General-purpose equipment I/F	
	Dif	fers according to trouble contents	of unit wi	th occuri	rence of	alarm	Group control follower unit trouble		
P30 (L20)	_	_)	 Duplication addresses of indoor units in central control device With the combination of air conditioning system, the indoor unit may detect the check code of L20 	Communication Link

WARNINGS ON REFRIGERANT LEAKAGE

Check of Concentration Limit

The room in which the air conditioner is to be installed requires a design that in the event of refrigerant gas leaking out, its concentration will not exceed a set limit.

The refrigerant R410A which is used in the air conditioner is safe, without the toxicity or combustibility of ammonia, and is not restricted by laws to be imposed which protect the ozone layer. However, since it contains more than air, it poses the risk of suffocation if its concentration should rise excessively. Suffocation from leakage of R410A is almost non-existent. With the recent increase in the number of high concentration buildings, however, the installation of multi air conditioner systems is on the increase because of the need for effective use of floor space, individual control, energy conservation by curtailing heat and carrying power etc. Most importantly, the multi air conditioner system is

Most importantly, the multi air conditioner system is able to replenish a large amount of refrigerant compared with conventional individual air conditioners. If a single unit of the multi conditioner system is to be installed in a small room, select a suitable model and installation procedure so that if the refrigerant accidentally leaks out, its concentration does not reach the limit (and in the event of an emergency, measures can be made before injury can occur).

In a room where the concentration may exceed the limit, create an opening with adjacent rooms, or install mechanical ventilation combined with a gas leak detection device.

The concentration is as given below.


Total amount of refrigerant (kg)

 $\begin{array}{ll} \mbox{Min. volume of the indoor unit installed room (m^3)} \\ &\leq \mbox{ Concentration limit (kg/m)} \end{array}$

The concentration limit of R410A which is used in multi air conditioners is 0.3 kg/m^3 .

▼ NOTE 1

If there are 2 or more refrigerating systems in a single refrigerating device, the amounts of refrigerant should be as charged in each independent device.




Indoor unit

For the amount of charge in this example: The possible amount of leaked refrigerant gas in rooms A, B and C is 10 kg. The possible amount of leaked refrigerant gas in rooms D, E and F is 15 kg.


▼ NOTE 2

The standards for minimum room volume are as follows.


(1) No partition (shaded portion)



(2) When there is an effective opening with the adjacent room for ventilation of leaking refrigerant gas (opening without a door, or an opening 0.15% or larger than the respective floor spaces at the top or bottom of the door).




(3) If an indoor unit is installed in each partitioned room and the refrigerant piping is interconnected, the smallest room of course becomes the object. But when a mechanical ventilation is installed interlocked with a gas leakage detector in the smallest room where the density limit is exceeded, the volume of the next smallest room becomes the object.



Mechanical ventilation device - Gas leak detector

VNOTE 3

The minimum indoor floor area compared with the amount of refrigerant is roughly as follows: (When the ceiling is 8'9" (2.7 mm)



CONFIRMATION OF INDOOR UNIT SETUP

Prior to delivery to the customer, check the address and setup of the indoor unit, which has been installed in this time and fill the check sheet (Table below). Data of four units can be entered in this check sheet. Copy this sheet according to the No. of the indoor units. If the installed system is a group control system, use this sheet by entering each line system into each installation manual attached to the other indoor units.

REQUIREMENT

This check sheet is required for maintenance after installation. Be sure to fill this sheet and then pass this Installation Manual to the customers.

Indoor unit setup check sheet

l	ndoor unit	t		Indoor un	it		Indoor uni	t	Indoor unit		
Room nam	ne		Room nan	ne		Room nar	ne		Room name		
Model			Model			Model			Model		
Check indoor unit address. (For ch			eck method,	refer to Ap	plicable cont	rols in this sl	heet.)				
* In case of	a single sys	stem, it is un	necessary to	o enter the	indoor addre	ss. (CODE No.: Line [12], Indoor [13			3], Group [14	1], Central c	ontrol [03])
Line	Indoor	Group	Line	Indoor	Group	Line	Indoor	Group	Line	Indoor	Group
Central	control a	ddress	Centra	l control a	address	Centra	l control a	ddress	Centra	l control a	ddress
Va	rious setu	ıp	Va	arious set	up	Va	arious set	up	V	arious setu	ıp
(For check	method, re	efer to Appli	cable contro		ark [×] in [NC sheet.) * In c						
board, setu											
	h ceiling se ODE No. [5			gh ceiling s ODE No. [gh ceiling s ODE No. [gh ceiling se ODE No. [5	
	-	Jul)			.Ju])	п ио сн		Jul)		-	Jul)
		[0000]			[0000]			[0000]			[0000]
□ HIGH C		[0001] [0003]			[0001] [0003]	□ HIGH C		[0001] [0003]			[0001] [0003]
Have you c	hanged lig	hting time of	of filter sign?	? If not, fill	check mark	[×] in [NO C	CHANGE],	and fill chec	k mark [×] i	n [ITEM] if	changed,
respectively	y.	0	0				2,				J ,
(For check	method, re	efer to Appli	cable contro	ols in this s	sheet.)						
	sign lighting DDE No. [0		Filter sign lighting time (CODE No. [01])			Filter sign lighting time (CODE No. [01])			Filter sign lighting time (CODE No. [01])		
	ANGE		□ NO CHANGE			NO CHANGE			NO CHANGE		
		[0000]			[0000]			[0000]			[0000]
□ 150H		[0001]	□ 150H		[0001]	□ 150H		[0001]	□ 150H		[0001]
□ 2500H □ 5000H		[0002] [0003]	□ 2500H □ 5000H		[0002] [0003]	□ 2500H □ 5000H		[0002] [0003]	□ 2500H □ 5000H		[0002] [0003]
□ 10000H		[0004]	□ 10000⊦	1	[0004]		4	[0004]	□ 10000F	1	[0004]
Have you c	hanged de	tected tem	. shift value	e? If not, fi	Il check mar	1 =		, and fill che	eck mark [×]	in [ITEM] i	f changed,
respectively	,						-				-
(For check	method, re	efer to Appli	cable contro	ol in this sh	neet.)	1					
					value setup			/alue setup	1	emp. shift v	
	DDE No. [0	6])	(CODE No. [06])				ODE No. [()6 <u>]</u>)	(CODE No. [06]) □ NO CHANGE		
		[0000]	□ NO CH/		[0000]	□ NO CH		[0000]	I □ NO CH.		[0000]
□ +1.8°F		[0000]	□ +1.8°F		[0000]	□ +1.8°F		[0000]	□ +1.8°F		[0000]
□ +3.6°F		[0002]	□ +3.6°F		[0002]	□ +3.6°F		[0002]	□ +3.6°F		[0002]
□ +5.4°F		[0003]	□ +5.4°F		[0003]	□ +5.4°F		[0003]	□ +5.4°F		[0003]
+7.2°F	(+4°C)	[0004]	+7.2°F	(+4°C)	[0004]	+7.2°F	(+4°C)	[0004]	+7.2°F	(+4°C)	[0004]
🗆 +9°F	(+5°C)	[0005]	🗆 +9°F	(+5°C)	[0005]	□ +9°F	(+5°C)	[0005]	□ +9°F	(+5°C)	[0005]
□ +10.8°F	(+6°C)	[0006]	□ +10.8°F	(+6°C)	[0006]	🗆 +10.8°F	= (+6°C)	[0006]	□ +10.8°F	(+6°C)	[0006]
Incorporation of parts sold Incorpora						ration of p			ration of pa		
separately				separatel			separately			separately	
Have you incorporated the follow (When incorporating, the setup c each part sold separately.)										on Manual	attached to
	Panel			Panel			Panel			Panel	
☐ Standard			🗆 Standar			□ Standard panel			☐ Standard panel		
	Filter			Filter		Filter			Filter		
Super lo	0	r	🗌 Super lo	ong life filte	er	🗌 Super le	ong life filte	r	Super long life filter		
Others ((Others			□ Others	· /		□ Others		
Others ()		🔲 Others (()		Others	()		Others	()	

10. HOW TO REPLACE THE MAIN PARTS

WARNING

• Since high voltages pass through the electrical parts, turn off the power without fail before proceeding with the repairs.

Electric shocks may occur if the power plug is not disconnected.

After the repairs have been completed (after the front panel and cabinet have been installed), perform a test run, and check for smoking, unusual sounds and other abnormalities.
 If this check is omitted, a fire and/or electric shocks may occur.
 Before proceeding with the test run, install the front panel and cabinet.


- Ensure that the following steps are taken when doing repairs on the refrigerating cycle.
 - Do not allow any naked flames in the surrounding area.
 If a gas stove or other appliance is being used, extinguish the flames before proceeding.
 If the flames are not extinguished, they may ignite any oil mixed with the refrigerant gas.
 - Do not use welding equipment in an airtight room. Carbon monoxide poisoning may result if the room is not properly ventilated.
 - Do not bring welding equipment near flammable objects.
 Flames from the equipment may cause the flammable objects to catch fire.
- If keeping the power on is absolutely unavoidable while doing a job such as inspecting the circuitry, wear rubber gloves to avoid contact with the live parts.
 Electric shocks may be received if the live parts are touched.
 High-voltage circuits are contained inside this unit.
 Proceed very carefully when conducting checks since directly touching the parts on the control circuit

board may result in electric shocks.


10-1. Indoor Unit

No.	Part name	Procedures	Remarks
1	Air inlet grille	 Stop operation of the air conditioner and turn off its main power supply. Open the air inlet grille and push it up until the air inlet grille take off. <remark> If you do not have enough space for push the air inlet grille up until it take off, you can push the arms of air inlet grille toward the outside, and remove the air inlet grille. </remark> 	Air inlet grille
		 <to re-installation=""></to> Carry out attaching in the reverse order to removal. Keep front panel horizontally and put both arms into guides. Make sure both arms are inserted completely. 	

No.	Part name	Procedures	Remarks
2	Air filters	 1) Follow to the procedure in the item ①. 1) Follow to the procedure in the item ①. I is a state of the procedure in the item ①. I is a state of the procedure in the item ①. I is a state of the procedure in the item ①. I is a state of the procedure in the item ①. I is a state of the procedure in the item ①. I is a state of the procedure in the item ①. I is a state of the procedure in the item ①. I is a state of the procedure in the item ①. I is a state of the procedure in the item ①. I is a state of the procedure in the item ①. I is a state of the procedure in the item ①. I is a state of the procedure in the item ①. I is a state of the procedure in the item ①. I is a state of the procedure in the item ①. I is a state of the procedure in the item ①. I is a state of the procedure in the procedure in the item of the procedure in the procedure in the procedure in the item of the procedure in the procedure	
3	Front panel	 Stop operation of the air conditioner and turn off its main power supply. Open two screw caps and securely remove screws (2 pcs.) at the front panel. Image: the front panel of the front panel from the parel back body. Take off the hooks of front panel from top side of the back body. Slightly open the lower part of the front panel then pull the upper part of the front panel toward you to remove it as shown on figure. 	<image/>



No.	Part name	Procedures	Remarks
5	Fan motor	 Follow the procedure item ③and④. Loosen the set screw of the cross flow fan. Image: Cross flow fan Body back Strew fan motor Remove 2 fixing screws of the motor band. Pull the motor band and the fan motor outward. Cro re-installation> Keep connector position and arrange fan motor wire follow figure. 	Cross flow fan Vertical louver Hexagon screw driver Vertical louver Hexagon screw driver Crews Vertical louver Hexagon screw driver Kotor band Crews Vertical Louver Hexagon screw driver
6	Horizontal louver	1) Remove shaft of the horizontal louver from the back body. (First remove 2 the center shafts then remove the other shafts.)	Drain pan
	Drain hose	 1) Follow the procedure item ③. 2) The drain hose can be removed by removing the screw securing the drain hose and then pulling out the drain hose. 3) When removing the drain hose, be careful of any sharp edges of steel plate. The edges can injuries. Drain pan Heat insulator of drain pan drain hose firming the drain hose, be careful of drain pan be careful of drain hose of drain hose of drain hose firming until the drain hose, insert the drain hose firming until the connection part contacts with heat insulator, and then secure it with original screw. 	Prain pan



No.	Part name	Procedures	Remarks
9	Vertical louver assembly	 Follow the procedure item(3) and (8). Remove 2 fixing screws from the base vertical louver then remove the vertical louver assembly from the body back. 	Vertical louver Screw Screw
10	Cover motor VT assembly	 Follow the procedure item ③, ⑧ and ⑨. Remove 4 fixing screws from the body back. then remove cover motor VT assembly from rear side of main unit. 	
1)	Bearing base	 Follow the procedure item (3). Remove 4 fixing screws from the bearing base, then remove it from the main unit. Bearing base Bearing Caution at assembling> If the bearing is out from the housing, push it into the specified position, then incorporate it in the main unit. 	Heat exchanger
12	Cross flow fan	 1) Follow the procedure item (9) and (1). 2) Loosen the set screw of the cross flow fan. 3) Lift up the heat exchanger follow the figure. Pull out the left hand side until the cross flow fan released from the shaft of the fan motor and then pull out the lower side of heat exchanger follow the figure. <to re-installation=""></to> 1) To incorporate the fan motor and the motor into the position in the following figure. Install the cross flow fan so that the right end of the 1st joint from the right of the Cross flow fan is keep 3.5mm from closed wall of the main unit. 	Cross flow fan Vertical louver Hexagon screw driver Heat exchanger Vertical louver Hexagon screw driver

No.	Part name	Procedures	Remarks
		 Cross flow fan Body back 3.5 mm John Sody back Set screw Fan motor Holding the set screw, install the cross flow fan so that flat area on shaft of the fan motor comes to the mounting hole of the set screw. 	
13	Heat exchanger (Evaporator)	 1) Follow the procedure in item(3) and 4. 2) Remove 3 fixing screws at the upper left side of the heat exchanger. 3) Remove 2 fixing screws at the upper and right side of the heat exchanger. 4) Remove the pipe holder from the rear side of the main unit. 5) Pull out the heat exchanger to upper side. 	<image/>
		 Keep the back body horizontally and put the heat exchanger carefully to the back body. Make sure the heat exchenger can be assembled with the back body and secure it tightly with screws. 	

11. Replacement of P.C. Board for Indoor Unit Servicing

<Models>

MMK-AP****HPUL Series

<Note : when replacing the P.C. board for indoor unit servicing>

The nonvolatile memory (hereafter called EEPROM, IC503) on the indoor unit P.C. board before replacement includes the model specific type information and capacity codes as the factory-set value and the important setting data which have been automatically or manually set when the indoor unit is installed, such as system/indoor/group addresses, high ceiling select setting, etc. When replacing the P.C. board for indoor unit servicing, follow the procedures below. After replacement completes, confirm whether the settings are correct by checking the indoor unit No.,Group header unit/ follower unit settings and perform the cooling cycle confirmation through the trial operation.

<Replacement procedures>

Case 1

Before replacement, the indoor unit can be turned on and the setting data can be read out by wired remote control operation.

EEPROM data read out [1] (Refer to page 1)

Replacement of P.C. board for Indoor unit servicing and power on [2] (Refer to page 2.)

 \bigcirc Writing the read out EEPROM data [3] (Refer to page 2.)

Power reset(for all indoor units connected to the remote control when the group operation control is performed.)

Case 2

The EEPROM before replacement is defective and the setting data cannot be read out.

Writing the setting data to EEPROM, such as high ceiling installation setting and optional connection setting, etc.,

based on the customer information. [3] (Refer to page 2.)

Û

Power reset (for all indoor units connected to the remote control when the group operation control is performed.)

[1] Setting data read out from EEPROM

The setting data modified on the site, other than factory-set value, stored in the EEPROM shall be read out.

Step 1 Press Ö, Öand Est button on the remote control simultaneously for more than 4 seconds.

When the group operation control is performed, the unit No. displayed for the first time is the header unit No. At this time, the CODE No.(DN)shows *II*. Also, the fan of the indoor unit selected starts its operation and the swing operation also starts if it has the louvers.

- Step 2 Every time when the button is pressed, the indoor unit No. under the group control is displayed in order. Specify the indoor unit No.to be replaced.
 - 1. Change the CODE No.(DN) to 🚺 🚺 by pressing 💌 / 🔺 buttons for the temperature setting.

(this is the setting for the filter sign lighting time.)

At this time, be sure to write down the setting data displayed.

2.Change the CODE No.(DN) by pressing \bigcirc \bigcirc buttons for the temperature setting.

Similarly, be sure to write down the setting data displayed.

3. Repeat the step 2-2 to set the other settings in the same way and write down the setting data as shown in the table 1(example)on page 4.

The CODE No.(DN)are ranged from **I** to **I** to **I I**. The CODE No.(DN) may skip.

Step 3 After writing down all setting data, press *●* button to return to the normal stop status.

(It takes approx. 1 min until the remote control operation is available again.)

CODE No.required at least

DN	Contents				
10	Туре				
11	Indoor unit capacity				
12	System address				
13	Indoor unit address				
14	Group address				
FC	Communication protocol				
1FC Indoor Unit terminating resistance					

- 1. The CODE No. for the Indoor unit type and Indoor unit capacity are required to set the rotation number setting of the fan.
- 2. If the system/indoor/group addresses are different from those before replacement, the auto-address setting mode starts and the manual resetting may be required again.

(when the multiple units group operation including twin system.)

- [2] P.C. Board for indoor unit servicing replacement procedures
- Step 1 Replace the P.C. board to the P.C. board for indoor unit servicing.

At this time, perform the same setting of the jumper wire(J01,J08,J09)setting(cut),switch SW501, (short-circuit) connector CN34 as the setting of the P.C. board before replacement.

Step 2 It is necessary to set Indoor unit to be exchanged : Remote controller = 1:1

Based upon the system configuration, turn on power of the indoor unit with one of the following items.

- 1) Single (Individual) operation
 - Turn on power of the indoor units and proceed to[3].
- 2) Group operation
 - A) In case that power of the exchanged indoor unit only can be turned on


Turn on power of the exchanged indoor unit only and proceed to [3].

- B) In case that power of the indoor units cannot be turned on individually (Case 1)
 - a) Remove temporarily the group wire connected to the terminal blocks A and B of the exchanged indoor unit.
 - b) After connecting the remote controller wire only to the removed terminal block, turn on power of the indoor units and proceed to[3].

When the above methods cannot be used, follwer to the two cases below.

- C)In case that power of the indoor units cannot be turned in individually (Case 2)
 - a) Remove all CN41 connectors of the indoor units in the same group except those of the exchanged indoor unit.
 - b) Turn on power of the indoor units and proceed to [3].

After [3] operation has finished, be sure to return the temporarily removed group wire or CN41 connector to the original connection.



[3] Writing the setting data to EEPROM

The settings stored in the EEPROM of the P.C. board for indoor unit servicing are the factory-set values.

Step 1 Press \bigcirc^{set} , $\bigcirc^{\text{c.}}$ and $\overset{\text{rest}}{\textcircled{O}}$ buttons on the remote control simultaneously for more than 4 seconds.

* In the group control operation, the unit No. displayed for the first time is the header unit No.

At this time, the CODE No. (DN)shows 💭 Also, the fan of the indoor unit selected starts its operation and the swing operation starts if it has the louvers.

(The unit No. **HLL** is displayed if the auto-address setting mode is interrupted in [2] step 2 a) 2. on pervious page.)

UNIT LOUVER

Step 2 Every time when the • button is pressed, the indoor unit Nos. in the group control operation are displayed in order.

(The settings stored in the EEPROM of the P.C. board for indoor unit servicing are the factory-set values.) Specify the indoor unit No.with its P.C. board replaced to the P.C. board for indoor unit servicing.

(You cannot perform this operation if **FLL** is displayed.)

Step 3 Select the CODE No. (DN) can be selected by pressing the V/ button

for the temperature setting.

• Set the indoor unit type and capacity.

The factory-set values shall be written to the EEPROM by changing the type and capacity.

- 1. Set the CODE No. (DN) to 🚻 . (without change)
- Select the type by pressing ♥ / ▲ buttons for the timer setting.
 (For example, High wall type is set to "0008" Refer to table 2 on page 4.)
- 3.Press [™] button. (The operation completes if the setting data is displayed.)
- 4. Change the CODE No. (DN) to **{ }** by pressing ▼ / ▲ buttons for the temperature setting.
- 5. Select the capacity by pressing ()/ () buttons for the timer setting. (For example, 024 Type is set to "0011". Refer to table 2 on page 4.)
- 6. Press [≝] button. (The setting completes if the setting data are displayed.)
- 7. Press the $\overset{\text{\tiny TEST}}{$ button to return to the normal stop status.

(It takes approx. 1 min until the remote control operation is available again.)

Write the on-site setting data to the EEPROM, such as address setting, etc. Perform the steps 1 and 2 above again.

Change the CODE No. (DN) to \square by pressing \bigcirc / \checkmark buttons for the temperature setting. (this is the setting for the filter sign lighting time.)

Check the setting data displayed at this time with the setting data put down in [1] (on page 1).

1. If the setting data is different, modify the setting data by pressing ♥/ ▲buttons for the timer setting to the data put down in [1].

The operation completes if the setting data is displayed.

2. If the data is the same, proceed to next step.

Change the CODE No. (DN) by pressing \bigcirc / \bigcirc buttons for the temperature setting.

As described above, check the setting data and modify to the data put down in [1]. Repeat the steps 6 and 7.

After the setting completes, press $\stackrel{\text{\tiny TEST}}{>}$ button to return to the normal stop status.


(It takes approx. 1 min until the remote control operation is available again.)

* The CODE No. (DN) are ranged from [] to 4 []. The CODE No. (DN) is not limited to be serial No. Even after modifying the data wrongly and pressing 🖱 button, it is possible to return to the data before modification by pressing \bigcirc button if the CODE No. (DN) is not changed.

<Fig.2 EEPROM layout diagram>

The EEPROM (IC503) is attached to the IC socket. When detaching the EEPROM, use a tweezers, etc. Be sure to attach the EEPROM by fitting its direction as shown in the figure.

* Do not bend the IC lead when replacing.






Table 1.Setting data(CODE No. table(example))

DN	Item	Setting data	Factory-set value
01	Filter display delay timer		0002 : 2500H
02	Dirty state of filter		0000 : Standard
03	Central control address		00Un/0099 : Unfixed
04	Specific indoor unit priority		0000 : No priority
06	Heating suction temperature shift		0002 : +2°C
0D	Automatic mode		0001 : No automatic
0F	Cooling only		0000 : Heat pump
10	Туре		Depending on model type
11	Indoor unit capacity		According to capacity type
12	Line address		00Un/0099 : Unfixed
13	Indoor unit address		00Un/0099 : Unfixed
14	Group address		00Un/0099 : Unfixed
19	Flap type (Wind direction adjustment)		Depending on Type
1E	Temperature range of cooling/heating automatic SW control point		0003 : 3 deg9Ts±1.5)
28	Automatic restart of power failure	0001 : Enable	0000 : None
29	Humidifier operation condition		0000 : Usual
2A	Selection of option / Trouble input (TCB-PCUC2E: CN3)		0002 : None
2E	HA terminal (CN61) select		0000 : Usual (HA terminal)
31	Ventilating fan control		0000 : Unavailable
32	Sensor SW		0000 : Body sensor
33	Temperature unit select	0001 : Fahrenheit (°F)	0000 : Centigrade (°C)
5D	External static pressure		0000 : Default setting
60	Timer setting (wired remote controller)		0000 : Available
7A	Change unit 0.5°C or 1.0°C on remote	0001 : 1°C	0000 : 0.5°C
D0	Remote controller operation save function		0001 : Enable
E0	Region	0001 : North America	0000 : Japan model
F6	Presence of Application control kit (TCB-PCUC2E)		0000 : None
FC	Communication protocol		0000 : TCC-LINK
FE	FS unit adress		00Un/0099 : Unfixed
103	Remote controller setting		0000 : With remote controller
1Fb	Remote controller operation		0000 : Operation possible
1FC	Indoor Unit terminating resistance		0000 : OFF

Table 2. Type : CODE No.10

Setting data	Туре	Type name abb.
0001 *1	1 ^{*1} 4-way Air Discharge MMU-AP****	
0008	High wall type	MMK-AP****HPUL

*1 EEPROM initial value on the P.C. board for indoor unit servicing.

*2 **A** CAUTION

< Model name MMK-AP****HPUL >

For the above model. Set the CODE no. to

"E0" the setting data "0000" (initial) to "0001"

"28" the setting data "0000" (initial) to "0001"

- "33" the setting data "0000" (initial) to "0001"
- "7A" the setting data "0000" (initial) to "0001"

Table 3. Indoor unit capacity : CODE No.11

Setup data	Model
0000 *1	Invalid
0001	007 type
0003	009 type
0005	012 type
0007	015 type
0009	018 type
0011	024 type


12. EXPLODED VIEWS AND PARTS LIST

-239 ĺ (For TCJ, TC2) (For TC1) <u>216</u> -235 ବ୍ତ <u>215</u> Ð ASM-ACCE E) <u>203</u> -19 Ş ELECTRICAL PARTS ASSEMBLY

Indoor	Unit
maoor	υπι

Location	Part	Description	Location	Part	Description
No.	No.	Description	No.	No.	Description
201	43T00822	FRONT PANEL ASSY	223	43T49045	PIPE, SHIELD
202	43T00752	CAP SCREW ASSEMBLY	224	43T49043	HOLDER, PIPE
203	43T09591	GRILLE OF AIR INLET ASSY	225	43T82008	PLATE, INSTALLATION
204	43T80351	AIR FILTER	226	43T62364	TERMINAL COVER ASSY
205	43T03420	BACK BODY ASSY	227	43T66415	WIRELESS REMOCO (WH-TE03NE)
206	43T22360	VERTICAL LOUVER ASSY	228	43T83305	HOLDER, REMOTE CONTROL
209	43T72346	DRAIN PAN ASSY	232	43T91409	PACKING CARTON BOX
210	43T22354	HORIZONTAL LOUVER	233	43T91334	PACKING CUSHION RIGHT
211	43T70321	DRAIN HOSE	234	43T91335	PACKING CUSHION LEFT
212	43T79322	DRAIN CAP	235	43T85799	OWNER'S MANUAL
213	43T21478	MOTOR; STEPPING	236	43T62365	CLAMP BASE ASSY
214	43T21495	FAN-MOTOR	237	43T19321	FIX-P-SENSOR
215	43T20357	CROSS FLOW FAN ASSY	238	43T04378	PMV COVER ASSEMBLY
216	43T39385	BASE BEARING	239	43T46519	COIL, PMV
217	43T22312	BEARING ASSY, MOLD	240	43T46518	BODY, PMV
218	43T39384	MOTOR COVER	241	43T63377	PLATE-HOLDER-SENSOR
219	43T39381	MOTOR BAND BACK	242	43T91392	REINFORCEMENT FIBERBOARD ASSY
220	43T39382	MOTOR BAND FRONT	243	43T62384	CONDUIT PARTITION A ASSENBY
221	43T44700	REFRIGERATION CYCLE ASSY	244	43T62385	CONDUIT MOUNT
		(FOR MMK-AP0157,0187HPUL)	245	43T62382	CONDUIT PARTITION B ASSENBY
221	43T44701	REFRIGERATION CYCLE ASSY	246	43T62388	CONDUIT MOUNT
		(FOR MMK-AP0247HPUL)	247	43T85815	INSTALLATION MANUAL
222	43T19333	HOLDER, SENSOR			

Indoor Unit (Part-E)



Location No.	Part No.	Description	Location No.	Part No.	Description
401	43T6W850	PC BOARD ASSY	408	43T60548	ASM-HOUSING(PW)
402	43T60448	TERMINAL	409	43T60546	ASM-HOSING(BUS)
403	43T60435	SERV-TERMINAL	410	43T60545	ASM-HOUSING(REM)
404	43T50392	SENSOR, THERMOSTAT	411	43T60539	ASM-HOUSING(MOV)
405	43T50410	TC-SENSOR	412	43T6V932	PC BOARD ASSY
406	43T50414	TC-SENSOR	413	43T63356	HOLDER-TA
407	43T50306	TEMPERATURE SENSOR			

WARNINGS ON REFRIGERANT LEAKAGE

Check of Concentration Limit

The room in which the air conditioner is to be installed requires a design that in the event of refrigerant gas leaking out, its concentration will not exceed a set limit. The refrigerant R410A which is used in the air conditioner is safe, without the toxicity or combustibility of ammonia, and is not restricted by laws to be imposed which protect the ozone layer. However, since it contains more than air, it poses the risk of suffocation if its concentration should rise excessively. Suffocation from leakage of R410A is almost non-existent. With the recent increase in the number of high concentration buildings, however, the installation of multi air conditioner systems is on the increase because of the need for effective use of floor space, individual control, energy conservation by curtailing heat and carrying power etc.

Most importantly, the multi air conditioner system is able to replenish a large amount of refrigerant compared with conventional individual air conditioners. If a single unit of the multi conditioner system is to be installed in a small room, select a suitable model and installation procedure so that if the refrigerant accidentally leaks out, its concentration does not reach the limit (and in the event of an emergency, measures can be made before injury can occur).

In a room where the concentration may exceed the limit, create an opening with adjacent rooms, or install mechanical ventilation combined with a gas leak detection device. The concentration is as given below.


Total amount of refrigerant (kg)

Min. volume of the indoor unit installed room (m³) Concentration limit (kg/m³)

The concentration limit of R410A which is used in multi air conditioners is 0.3 kg/m^3 .

NOTE 1 :

If there are 2 or more refrigerating systems in a single refrigerating device, the amounts of refrigerant should be as charged in each independent device.



For the amount of charge in this example:


The possible amount of leaked refrigerant gas in rooms A, B and C is 10 kg.

The possible amount of leaked refrigerant gas in rooms D, E and F is 15 kg.


Important

NOTE 2 :


The standards for minimum room volume are as follows. (1) No partition (shaded portion)



(2) When there is an effective opening with the adjacent room for ventilation of leaking refrigerant gas (opening without a door, or an opening 0.15 % or larger than the respective floor spaces at the top or bottom of the door).




(3) If an indoor unit is installed in each partitioned room and the refrigerant piping is interconnected, the smallest room of course becomes the object. But when a mechanical ventilation is installed interlocked with a gas leakage detector in the smallest room where the density limit is exceeded, the volume of the next smallest room becomes the object.



NOTE 3 :

The minimum indoor floor area compared with the amount of refrigerant is roughly as follows: (When the ceiling is 2.7 m high)



Toshiba Carrier (Thailand) Co., Ltd.

144/9 MOO 5, BANGKADI INDUSTRIAL PARK, TIVANON ROAD, TAMBOL BANGKADI, AMPHUR MUANG, PATHUMTHANI 12000, THAILAND.