TOSHIBA Carrier

AIR CONDITIONER (MULTI TYPE)

SERVICE MANUAL

Indoor unit

<1-way cassette type>

MMU-UB0151YHP-UL MMU-UB0181YHP-UL MMU-UB0241YHP-UL

R454B









This Air Conditioner is an environmentally friendly refrigerant.

CONTENTS

| | PRECAUTIONS FOR SAFETY | 6 |
|---|---|-----|
| | 1. SPECIFICATIONS | |
| | 2. CONSTRUCTION VIEWS (EXTERNAL VIEWS) | 14 |
| | 3. WIRING DIAGRAMS | 15 |
| | 4. PARTS RATING | 16 |
| | 5. REFRIGERANT CYCLE DIAGRAM | 17 |
| | 6. CONTROL OUTLINE | 18 |
| | 7. COMMUNICATION TYPE, MODEL NAMES AND THE MAXIMUM NUMBER OF CONNECTABLE UNITS | 28 |
| | 8. CONFIGURAION OF CONTROL CIRCUIT | 29 |
| | 8-1. Indoor controller block diagram (MCC-1797) | 29 |
| | 8-1-2. In Case of Connection of Wireless Remote Controller | |
| | 8-2. Indoor Print Circuit Board | |
| | 8-3. Functions at test run | 34 |
| | 9. APPLIED CONTROL | 36 |
| | 9-1. Setup of Selecting Function indoor Unit9-2. Applied Control in Indoor Unit | |
| , | 10. TROUBLESHOOTING | 52 |
| | 10-1. Overview | _ |
| | 10-2. Troubleshooting method | |
| | (7-Segment Display on I/F Board) and Locations to Be Checked | 79 |
| 1 | 11. REPLACEMENT OF SERVICE P.C.BOARD | 93 |
| | 12. DETACHMENTS | |
| | 13 FXPI ODED VIEWS AND PARTS LIST | 106 |
| | | |

SAFETY CAUTION

Please read carefully through these instructions that contain important information and ensure that you understand them.

Generic Denomination: Air Conditioner

Definition of Qualified Installer or Qualified Service Person

The air conditioner must be installed, maintained, repaired and removed by a qualified installer or qualified service person. When any of these jobs is to be done, ask a qualified installer or qualified service person to do them for you.

A qualified installer or qualified service person is an agent who has the qualifications and knowledge described in the table below.

| Agent | Qualifications and knowledge which the agent must have |
|--------------------------|---|
| | The qualified installer is a person who installs, maintains, relocates and removes the air conditioners. He or she has been trained to install, maintain, relocate and remove the air conditioners he or she has been instructed in such operations by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to these operations. |
| Qualified installer | The qualified installer who is allowed to do the electrical work involved in installation, relocation and removal has the qualifications pertaining to this electrical work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to electrical work on the air conditioners he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. |
| | The qualified installer who is allowed to do the refrigerant handling and piping work involved in installation, relocation and removal has the qualifications pertaining to this refrigerant handling and piping work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to refrigerant handling and piping work on the air conditioners e or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. |
| | The qualified installer who is allowed to work at heights has been trained in matters relating to working at heights with the air conditioners he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. |
| | The qualified service person is a person who installs, repairs, maintains, relocates and removes the air conditioners. He or she has been trained to install, repair, maintain, relocate and remove the air conditioners he or she has been instructed in such operations by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to these operations. |
| Qualified service person | The qualified service person who is allowed to do the electrical work involved in installation, repair, relocation and removal has the qualifications pertaining to this electrical work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to electrical work on the air conditioners he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. |
| | The qualified service person who is allowed to do the refrigerant handling and piping work involved in installation, repair, relocation and removal has the qualifications pertaining to this refrigerant handling and piping work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to refrigerant handling and piping work on the air conditioners he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. |
| | The qualified service person who is allowed to work at heights has been trained in matters relating to working at heights with the air conditioners he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. |

Definition of Protective Gear

When the air conditioner is to be transported, installed, maintained, repaired or removed, wear protective gloves and 'safety' work clothing.

In addition to such normal protective gear, wear the protective gear described below when undertaking the special work detailed in the table below.

Failure to wear the proper protective gear is dangerous because you will be more susceptible to injury, burns, electric shocks and other injuries.

| Work undertaken | Protective gear worn | | |
|---|--|--|--|
| All types of work | Protective gloves 'Safety' working clothing | | |
| Gloves to provide protection for electricians Electrical-related work Insulating shoes Clothing to provide protection from electric shock | | | |
| Work done at heights (19.7" (50 cm) or more) | Helmets for use in industry | | |
| Transportation of heavy objects | Shoes with additional protective toecap | | |
| Repair of outdoor unit Gloves to provide protection for electricians | | | |

The important contents concerned to the safety are described on the product itself and on this Service Manual. Please read this Service Manual after understanding the described items thoroughly in the following contents (Indications / Illustrated marks), and keep them.

[Explanation of indications]

| Indication | Explanation | | |
|------------------|---|--|--|
| ⚠ DANGER | Indicates contents assumed that an imminent danger causing a death or serious injury of the repair engineers and the third parties when an incorrect work has been executed. | | |
| ⚠ WARNING | Indicates possibilities assumed that a danger causing a death or serious injury of the repair engineers, the third parties, and the users due to troubles of the product after work when an incorrect work has been executed. | | |
| ⚠ CAUTION | Indicates contents assumed that an injury or property damage (*) may be caused on the repair engineers, the third parties, and the users due to troubles of the product after work when an incorrect work has been executed. | | |

^{*} Property damage: Enlarged damage concerned to property, furniture, and domestic animal / pet

[Explanation of illustrated marks]

| Indication | Explanation | | | |
|-------------|---|--|--|--|
| | Indicates prohibited items (Forbidden items to do) The sentences near an illustrated mark describe the concrete prohibited contents. | | | |
| 0 | Indicates mandatory items (Compulsory items to do) The sentences near an illustrated mark describe the concrete mandatory contents. | | | |
| \triangle | Indicates cautions (Including danger / warning) The sentences or illustration near or in an illustrated mark describe the concrete cautious contents. | | | |

■ Warning indications on the Air Conditioner Unit

| R454B Refrigerant Safety Group A2L | WARNING (Risk of fire) | This mark is for R454B refrigerant only. Refrigerant type is written on nameplate of outdoor unit. In case that refrigerant type is R454B, this unit uses a flammable refrigerant. If refrigerant leaks and comes in contact with fire or heating part, it will create harmful gas and there is risk of fire. | |
|-------------------------------------|---|---|--|
| | Read the OWNER'S MANUAL carefully before operation. | | |
| | Service personnel are required to carefully read the OWNER'S MANUAL and INSTALLATION MANUAL before operation. | | |
| i | Further information is available in the OWNER'S MANUAL, INSTALLATION MANUAL, and the like. | | |

| INSTALLATI | ION MANUAL, a | and the like. | | |
|---|---------------------|--|--|--|
| Warning indication | | Description | | |
| WARNING ELECTRICAL SHOCK HAZARD Disconnect all remote electric power supplies before servicing. | | WARNING ELECTRICAL SHOCK HAZARD Disconnect all remote electric power supplies before servicing. | | |
| Moving parts. Do not operate unit removed. Stop the unit before the | with grille | WARNING Moving parts. Do not operate unit with grille removed. Stop the unit before the servicing. | | |
| High temperature You might get but when removing the | parts. | CAUTION High temperature parts. You might get burned when removing this panel. | | |
| Do not touch the al fins of the unit. Doing so may resu | uminum | CAUTION Do not touch the aluminium fins of the unit. Doing so may result in injury. | | |
| CAUTIO BURST HAZ Open the service val the operation, otherw might be the burst. | ZARD lves before | CAUTION BURST HAZARD Open the service valves before the operation, otherwise there might be the burst. | | |

PRECAUTIONS FOR SAFETY

The manufacturer shall not assume any liability for the damage caused by not observing the description of this manual.



/ DANGER

Before carrying out the installation, maintenance, repair or removal work, be sure to set the circuit breaker for both the indoor and outdoor units to the OFF position. Otherwise, electric shocks may

Before opening the intake grille of the indoor unit or service panel of the outdoor unit, set the circuit breaker to the OFF position. Failure to set the circuit breaker to the OFF position may result in electric shocks through contact with the interior parts. Only a qualified installer or qualified service person is allowed to remove the intake grille of the indoor unit or service panel of the outdoor unit and do the work required.



Before opening the electric box cover set the circuit breaker to the OFF position. Failure to set the circuit breaker to the OFF position may result in injury through contact with the rotation parts. Only a qualified installer or qualified service person is allowed to remove the electric box cover and do the work required.

Before starting to repair the outdoor unit fan or fan guard, be absolutely sure to set the circuit breaker to the OFF position, and place a "Work in progress" sign on the circuit breaker.

When cleaning the filter or other parts of the indoor unit, set the circuit breaker to OFF without fail, and place a "Work in progress" sign near the circuit breaker before proceeding with the work.

When you have noticed that some kind of trouble (such as when a check code display has appeared, there is a smell of burning, abnormal sounds are heard, the air conditioner fails to cool or heat or water is leaking) has occurred in the air conditioner, do not touch the air conditioner yourself but set the circuit breaker to the OFF position, and contact a qualified service person. Take steps to ensure that the power will not be turned on (by marking "out of service" near the circuit breaker, for instance) until qualified service person arrives. Continuing to use the air conditioner in the trouble status may cause mechanical problems to escalate or result in electric shocks or other failure.



When you access inside of the electric cover to repair electric parts, wait for about five minutes after turning off the breaker. Do not start repairing immediately Otherwise you may get electric shock by touching terminals of high-voltage capacitors. Natural discharge of the capacitor takes about five minutes.

When checking the electric parts, removing the cover of the electric parts box of Indoor Unit and/or service panel of Outdoor Unit inevitably to determine the failure, use gloves to provide protection for electricians, insulating shoes, clothing to provide protection from electric shock and insulating tools. Be careful not to touch the live part. Electric shock may result. Only "Qualified service person" is allowed to

Place a "Work in progress" sign near the circuit breaker while the installation, maintenance, repair or removal work is being carried out.

There is a danger of electric shocks if the circuit breaker is set to ON by mistake.



When checking the electric parts, removing the cover of the electric parts box of Indoor Unit and/or front panel of outdoor unit inevitably to determine the failure, put a sign "Do not enter" around the site before the work. Failure to do this may result in third person getting electric shock.

Before operating the air conditioner after having completed the work, check that the electrical parts box cover of the indoor unit and service panel of the outdoor unit are closed, and set the circuit breaker to the ON position.

You may receive an electric shock if the power is turned on without first conducting these checks.



Stay on protection If, in the course of carrying out repairs, it becomes absolutely necessary to check out the electrical parts with the electrical parts box cover of one or more of the indoor units and the service panel of the outdoor unit removed in order to find out exactly where the trouble lies, wear insulated heat-resistant gloves, insulated boots and insulated work overalls, and take care to avoid touching any live parts. You may receive an electric shock if you fail to heed this warning. Only qualified service person is allowed to do this kind of work.

MARNIG

Before starting to repair the air conditioner, read carefully through the Service Manual, and repair the air conditioner by following its instructions.

Only qualified service person is allowed to repair the air conditioner.

Repair of the air conditioner by unqualified person may give rise to a fire, electric shocks, injury, water leaks and / or other problems.

Do not use any refrigerant different from the one specified for complement or replacement. Otherwise, abnormally high pressure may be generated in the refrigeration cycle, which may result in a failure or explosion of the product or an injury to your body.

Only a qualified installer or qualified service person is allowed to carry out the electrical work of the air conditioner.

Under no circumstances must this work be done by an unqualified individual since failure to carry out the work properly may result in electric shocks and / or electrical leaks.

When the air conditioner is to be transported, installed, maintained, repaired or removed, wear protective gloves and 'safety' work clothing.

To connect the electrical wires, repair the electrical parts or undertake other electrical jobs, wear gloves to provide protection for electricians, insulating shoes and clothing to provide protection from electric shocks. Failure to wear this protective gear may result in electric shocks.

Electrical wiring work shall be conducted according to law and regulation in the community and Installation Manual. Failure to do so may result in electrocution or short circuit.



Use wiring that meets the specifications in the Installation Manual and the stipulations in the local regulations and laws. Use of wiring which does not meet the specifications may give rise to electric shocks, electrical leakage, smoking and/or a fire.

Only a qualified installer or qualified service person is allowed to undertake work at heights using a stand of 19.7"(50cm) or more or to remove the intake grille of the indoor unit to undertake work.

When working at heights, use a ladder which complies with the ISO 14122 standard, and follow the procedure in the ladder's instructions.

Also wear a helmet for use in industry as protective gear to undertake the work.

Before working at heights, put a sign in place so that no-one will approach the work location, before proceeding with the work. Parts and other objects may fall from above, possibly injuring a person below. While carrying out the work, wear a helmet for protection from falling objects.

When executing address setting, test run, or troubleshooting through the checking window on the electric parts box, put on insulated gloves to provide protection from electric shock. Otherwise you may receive an electric shock.

Do not touch the aluminum fin of the unit.

You may injure yourself if you do so. If the fin must be touched for some reason, first put on protective gloves and safety work clothing, and then proceed.

Do not climb onto or place objects on top of the outdoor unit.

You may fall or the objects may fall off the outdoor unit and result in injury.

Use forklift truck to carry in the air conditioner units and use winch or hoist at installation of them.

When transporting the air conditioner, wear shoes with protective toe caps, protective gloves and other protective clothing.

When transporting the air conditioner, do not hold the bands around the packing carton. You may injure yourself if the bands should break.

Be sure that a heavy unit 22 lbs (10 kg) or heavier such as a compressor is carried by four persons.

This air conditioner has passed the pressure test as specified in UL 60335-2-40 Annex EE.



Before troubleshooting or repair work, check the earth wire is connected to the earth terminals of the main unit, otherwise an electric shock is caused when a leak occurs. If the earth wire is not correctly connected, contact an electric engineer for rework.

After completing the repair or relocation work, check that the ground wires are connected properly.

Connect earth wire. (Grounding work) Incomplete grounding causes an electric shock. Do not connect earth wires to gas pipes, water pipes, and lightning rods or ground wires for telephone wires.

| Prohibition of modification. | Do not modify the products.Do not also disassemble or modify the parts. It may cause a fire, electric shock or injury. |
|---|--|
| Use specified parts. | When any of the electrical parts are to be replaced, ensure that the replacement parts satisfy the specifications given in the Service Manual (or use the parts contained on the parts list in the Service Manual). Use of any parts which do not satisfy the required specifications may give rise to electric shocks, smoking and / or a fire. |
| Do not bring a child close to the equipment. | If, in the course of carrying out repairs, it becomes absolutely necessary to check out the electrical parts with the electrical parts box cover of one or more of the indoor units and the service panel of the outdoor unit removed in order to find out exactly where the trouble lies, put a sign in place so that no-one will approach the work location before proceeding with the work. Third-party individuals may enter the work site and receive electric shocks if this warning is not heeded. |
| Insulating measures | Connect the cut-off lead wires with crimp contact, etc., put the closed end side upward and then apply a watercut method, otherwise a leak or production of fire is caused at the users' side. |
| No fire | When performing repairs using a gas burner, replace the refrigerant with nitrogen gas because the oil that coats the pipes may otherwise burn. When repairing the refrigerating cycle, take the following measures. 1) Be attentive to fire around the cycle. When using a gas stove, etc., be sure to put out fire before work; otherwise the oil mixed with refrigerant gas may catch fire. 2) Do not use a welder in the closed room. When using it without ventilation, carbon monoxide poisoning may be caused. 3) Do not bring inflammables close to the refrigerant cycle, otherwise fire of the welder may catch the inflammables. |
| | The refrigerant used by this air conditioner is the R454B. |
| | Check the used refrigerant name and use tools and materials of the parts which match with it. For the products which use R454B refrigerant, the refrigerant name is indicated at a position on the outdoor unit where is easy to see. To prevent miss charging, the route of the service port is changed from one of the former R22. |
| | Do not use any refrigerant different from the one specified for complement or replacement. Otherwise, abnormally high pressure may be generated in the refrigeration cycle, which may result in a failure or explosion of the product or an injury to your body. |
| | For an air conditioner which uses R454B, never use other refrigerant than R454B. For an air conditioner which uses other refrigerant (R22, etc.), never use R454B. If different types of refrigerant are mixed, abnormal high pressure generates in the refrigerating cycle and an injury due to breakage may be caused. |
| Refrigerant | When the air conditioner has been installed or relocated, follow the instructions in the Installation Manual and purge the air completely so that no gases other than the refrigerant will be mixed in the refrigerating cycle. Failure to purge the air completely may cause the air conditioner to malfunction. |
| | Do not charge refrigerant additionally. If charging refrigerant additionally when refrigerant gas leaks, the refrigerant composition in the refrigerating cycle changes resulted in change of air conditioner characteristics or refrigerant over the specified standard amount is charged and an abnormal high pressure is applied to the inside of the refrigerating cycle resulted in cause of breakage or injury. Therefore if the refrigerant gas leaks, recover the refrigerant in the air conditioner, execute vacuuming, and then newly recharge the specified amount of liquid refrigerant. In this time, never charge the refrigerant over the specified amount. |
| | When recharging the refrigerant in the refrigerating cycle, do not mix the refrigerant or air other than R454B into the specified refrigerant. If air or others is mixed with the refrigerant, abnormal high pressure generates in the refrigerating cycle resulted in cause of injury due to breakage. |
| | After installation work, check the refrigerant gas does not leak. If the refrigerant gas leaks in the room, poisonous gas generates when gas touches to fire such as fan heater, stove or cooking stove though the refrigerant gas itself is innocuous. |
| | Never recover the refrigerant into the outdoor unit. When the equipment is moved or repaired, be sure to recover the refrigerant with recovering device. The refrigerant cannot be recovered in the outdoor unit; otherwise a serious accident such as breakage or injury is caused. |

| Assembly / Wiring | After repair work, surely assemble the disassembled parts, and connect and lead the removed wires as before. Perform the work so that the cabinet or panel does not catch the inner wires. If incorrect assembly or incorrect wire connection was done, a disaster such as a leak or fire is caused at user's side. |
|--|---|
| Insulator check | After the work has finished, be sure to use an insulation tester set ($500\text{VM}\Omega$) to check the resistance is 1 M Ω or more between the charge section and the non-charge metal section (Earth position). If the resistance value is low, a disaster such as a leak or electric shock is caused at user's side. |
| | When the refrigerant gas leaks during work, execute ventilation. If the refrigerant gas touches to a fire, poisonous gas generates. A case of leakage of the refrigerant and the closed room full with gas is dangerous because a shortage of oxygen occurs. Be sure to execute ventilation. |
| Ventilation | If refrigerant gas has leaked during the installation work, ventilate the room immediately. If the leaked refrigerant gas comes in contact with fire, noxious gas may generate. |
| | After installation work, check the refrigerant gas does not leak. If the refrigerant gas leaks in the room, poisonous gas generates when gas touches to fire such as fan heater, stove or cooking stove though the refrigerant gas itself is innocuous. |
| | When the refrigerant gas leaks, find out the leaked position and repair it surely. If the leaked position cannot be found out and the repair work is interrupted, reclaim and tighten the service valve, otherwise the refrigerant gas may leak into the room. The poisonous gas generates when gas touches to fire such as fan heater, stove or cooking stove though the refrigerant gas itself is innocuous. When installing equipment which includes a large amount of charged refrigerant in a sub-room, it is necessary that the concentration does not the limit even if the refrigerant leaks. If the refrigerant leaks and exceeds the limit concentration, an accident of shortage of oxygen is caused. |
| Compulsion | Tighten the flare nut with a torque wrench in the specified manner. Excessive tighten of the flare nut may cause a crack in the flare nut after a long period, which may result in refrigerant leakage. |
| | Nitrogen gas must be used for the airtight test. |
| | The charge hose must be connected in such a way that it is not slack. |
| | For the installation / moving / reinstallation work, follow to the Installation Manual. If an incorrect installation is done, a trouble of the refrigerating cycle, water leak, electric shock or fire is caused. |
| | Once the repair work has been completed, check for refrigerant leaks, and check the insulation resistance and water drainage. Then perform a trial run to check that the air conditioner is running properly. |
| | After repair work has finished, check there is no trouble. If check is not executed, a fire, electric shock or injury may be caused. For a check, turn off the power breaker. |
| Check after repair | After repair work (installation of front panel and cabinet) has finished, execute a test run to check there is no generation of smoke or abnormal sound. If check is not executed, a fire or an electric shock is caused. Before test run, install the front panel and cabinet. |
| | Be sure to fix the screws back which have been removed for installation or other purposes. |
| Do not operate the unit with the valve closed. | Check the following matters before a test run after repairing piping. • Connect the pipes surely and there is no leak of refrigerant. • The valve is opened. Running the compressor under condition that the valve closes causes an abnormal high pressure resulted in damage of the parts of the compressor and etc. and moreover if there is leak of refrigerant at connecting section of pipes, the air is sucked and causes further abnormal high pressure resulted in burst or injury. |
| | Only a qualified installer or qualified service person is allowed to relocate the air conditioner. It is dangerous for the air conditioner to be relocated by an unqualified individual since a fire, electric shocks, injury, water leakage, noise and / or vibration may result. |
| | Check the following items after reinstallation. |
| Check after reinstallation | 1) The earth wire is correctly connected. 2) The power cord is not caught in the product. 3) There is no inclination or unsteadiness and the installation is stable. If check is not executed, a fire, an electric shock or an injury is caused. |
| | The earth wire is correctly connected. The power cord is not caught in the product. There is no inclination or unsteadiness and the installation is stable. |

When the service panel of the outdoor unit is to be opened in order for the compressor or the area around this part to be repaired immediately after the air conditioner has been shut down, set the circuit breaker to the OFF position, and then wait at least 10 minutes before opening the service panel. If you fail to heed this warning, you will run the risk of burning yourself because the compressor pipes and other parts will be very hot to the touch. In addition, before proceeding with the repair work, wear the kind of insulated heat-resistant gloves designed to protect electricians. Take care not to get burned by compressor pipes or other parts when checking the cooling cycle while running the unit as they get heated while running. Be sure to put on gloves providing protection for heat. When the service panel of the outdoor unit is to be opened in order for the fan motor, reactor, inverter

or the areas around these parts to be repaired immediately after the air conditioner has been shut down, set the circuit breaker to the OFF position, and then wait at least 10 minutes before opening the service panel.

If you fail to heed this warning, you will run the risk of burning yourself because the fan motor, reactor, inverter heat sink and other parts will be very hot to the touch.

In addition, before proceeding with the repair work, wear the kind of insulated heat-resistant gloves designed to protect electricians.

Only a qualified installer or service person is allowed to do installation work. Inappropriate installation may result in water leakage, electric shock or fire.

Before starting to install the air conditioner, read carefully through the Installation Manual, and follow its instructions to install the air conditioner.

Be sure to use the company-specified products for the separately purchased parts. Use of nonspecified products may result in fire, electric shock, water leakage or other failure. Have the installation performed by a qualified installer.

Do not supply power from the power terminal block equipped on the outdoor unit to another outdoor unit. Capacity overflow may occur on the terminal block and may result in fire.

Do not install the air conditioner in a location that may be subject to a risk of expire to a combustible gas. If a combustible gas leaks and becomes concentrated around the unit, a fire may occur.



Cooling check

Install the indoor unit at least 8'2"(2.5 m) above the floor level since otherwise the users may injure themselves or receive electric shocks if they poke their fingers or other objects into the indoor unit while the air conditioner is running.

Install a circuit breaker that meets the specifications in the Installation Manual and the stipulations in the local regulations and laws.

Install the circuit breaker where it can be easily accessed by the agent.

If you install the unit in a small room, take appropriate measures to prevent the refrigerant from exceeding the limit concentration even if it leaks. Consult the dealer from whom you purchased the air conditioner when you implement the measures. Accumulation of highly concentrated refrigerant may cause an oxygen deficiency accident.

Do not place any combustion appliance in a place where it is directly exposed to the wind of air conditioner, otherwise it may cause imperfect combustion.

Explanations given to user

If you have discovered that the fan grille is damaged, do not approach the outdoor unit but set the circuit breaker to the OFF position, and contact a qualified service person to have the repairs done. Do not set the circuit breaker to the ON position until the repairs are completed.

Relocation

- Only a qualified installer or qualified service person is allowed to relocate the air conditioner. It is dangerous for the air conditioner to be relocated by an unqualified individual since a fire, electric shocks, injury, water leakage, noise and / or vibration may result.
- When carrying out the reclaim work shut down the compressor before disconnecting the refrigerant pipe. Disconnecting the refrigerant pipe with the service valve left open and the compressor still operating will cause air, etc. to be sucked in, raising the pressure inside the refrigeration cycle to an abnormally high level, and possibly resulting in rupture, injury, etc.

Refrigerant R454B

This air conditioner adopts a type refrigerant R454B which does not deplete the ozone layer.

1. Safety Caution Concerned to R454B Refrigerant

Accompanied with change of refrigerant, the refrigerating oil has been also changed.

Therefore, be sure that water, dust, the former refrigerant or the former refrigerating oil is not mixed into the refrigerating cycle of the air conditioner with new refrigerant during installation work or service work. If an incorrect work or incorrect service is performed, there is a possibility to cause a serious accident. Use the tools and materials exclusive to R454B to purpose a safe work.

2. Cautions on Installation/Service

- (1) Do not mix the other refrigerant or refrigerating oil.
 For the tools exclusive to R454B, shapes of all the joints including the service port differ from those of the former refrigerant in order to prevent mixture of them.
- (2) As the use pressure of the new refrigerant is high, use material thickness of the pipe and tools which are specified for R454B.
- (3) In the installation time, use clean pipe materials and work with great attention so that water and others do not mix in because pipes are affected by impurities such as water, oxide scales, oil, etc. Use the clean pipes.
 - Be sure to brazing with flowing nitrogen gas. (Never use gas other than nitrogen gas.)
- (4) For the earth protection, use a vacuum pump for air purge.
- (5) R454B refrigerant is azeotropic mixture type refrigerant.

 Therefore use liquid type to charge the refrigerant. (If using gas for charging, composition of the refrigerant changes and then characteristics of the air conditioner change.)

3. Pipe Materials

For the refrigerant pipes, copper pipe and joints are mainly used.

It is necessary to select the most appropriate pipes to conform to the standard.

Use clean material in which impurities adhere inside of pipe or joint to a minimum.

(1) Copper pipe

<Piping>

The pipe thickness, flare finishing size, flare nut and others differ according to a refrigerant type. When using a long copper pipe for R454B, it is recommended to select "Copper or copper-base pipe without seam" and one with bonded oil amount 0.0001/lbs / 32'10" (40mg/10m)

Also do not use crushed, deformed, discolored (especially inside) pipes.(Impurities cause clogging of expansion valves and capillary tubes.)

<Flare nut>

Use the flare nuts which are attached to the air conditioner unit.

(2) Joint

The flare joint and socket joint are used for joints of the copper pipe.

The joints are rarely used for installation of the air conditioner.

However clear impurities when using them.

4. Tools

(1) Required Tools for R454B

Mixing of different types of oil may cause a trouble such as generation of sludge, clogging of capillary, etc. Accordingly, the tools to be used are classified into the following three types.

- 1) Tools exclusive for R454B
- 2) Tools exclusive for R454B, but can be also used for conventional refrigerant
- 3) Tools commonly used for R454B and for conventional refrigerant

The table below shows the tools exclusive for R454B and their interchangeability.

4) Joint preparation are recommend to double-flare fitting accordance to ASHRAE15 requirements.

Tools exclusive for R454B (The following tools for R454B are required.)

Tools whose specifications are changed for R454B and their interchangeability

| | | Usage | R454B air conditioner installation | | Conventional air conditioner installation |
|-----|---|------------------------------------|--|--|---|
| No. | Used tool | | Existence of new equipment for R454B | Whether conventional equipment can be used | Whether new equipment can be used with conventional refrigerant |
| 1 | Flare tool | Pipe flaring | Yes | *(Note 1) | Yes |
| 2 | Copper pipe gauge for adjusting projection margin | Flaring by conventional flare tool | Yes | *(Note 1) | *(Note 1) |
| 3 | Torque wrench | Connection of flare nut | Yes | No | No |
| 4 | Gauge manifold | Evacuating, refrigerant | Yes | No | No |
| (5) | Charge hose | charge, run check, etc. | ies | INO | NO |
| 6 | Vacuum pump adapter | Vacuum evacuating | Yes | No | Yes |
| 7 | Electronic balance for refrigerant charging | Refrigerant charge | Yes | Yes | Yes |
| 8 | Refrigerant cylinder | Refrigerant charge | Yes | No | No |
| 9 | Leakage detector | Gas leakage check | Yes | No | Yes |
| 9 | Charging cylinder | Refrigerant charge | (Note 2) | No | No |

(Note 1) When flaring is carried out for R454B using the conventional flare tools, adjustment of projection margin is necessary. For this adjustment, a copper pipe gauge, etc. are necessary.

(Note 2) Charging cylinder for R454B is being currently developed.

General tools (Conventional tools can be used.)

In addition to the above exclusive tools, the following equipments are necessary as the general tools.

Vacuum pump
 Use vacuum pump by attaching vacuum pump adapter.

2) Torque wrench

8) Spanner or Monkey wrench

3) Pipe cutter

9) Hole core drill

4) Reamer

10) Hexagon wrench (Opposite side 0.16"(4mm))

5) Pipe bender

11) Tape measure

6) Level vial

12) Metal saw

7) Screwdriver (+, -)

Also prepare the following equipments for other installation method and run check.

1) Clamp meter

3) Insulation resistance tester

2) Thermometer

4) Electroscope


1. SPECIFICATIONS

1 Way cassette type


| Model name | | | MMU-UB0151YHP-UL | MMU-UB0181YHP-UL | MMU-UB0241YHP-UL | |
|-----------------------------|---------------------|-------------|--|------------------------------|------------------|--|
| Cooling Capacity (Btu/h) | | | 15400 | 18000 | 24000 | |
| Heating Capacity | | (Btu/h) | 17000 | 20000 | 27000 | |
| E | Power supply | | | 1Ph. 208/230V ~ 60Hz. | | |
| Electrical characteristics | Running current | (A) | 0.24 | 0.26 | 0.34 | |
| onaraotonotios | Power consumpt | on (kW) | 0.025 | 0.027 | 0.042 | |
| | Main unit | | | Zinc hot dipping steel plate | | |
| Appearance | Ceiling panel | Model name | | RBC-UY42P-UL | | |
| | Celling parier | Panel Color | Gran White | | | |
| | | Height (in) | | 5.9 | | |
| | Main unit | Width (in) | | 46.5 | | |
| Outer diamension | | Depth (in) | | 17.7 | | |
| Outer diamension | | Height (in) | | 1.1 | | |
| | Ceiling panel | Width (in) | 20.8 | | | |
| | | Depth (in) | 55.5 | | | |
| Total weight | Main unit (Ibs) | | 34.0 | | | |
| Total Weight | Ceiling panel (lbs) | | 11 | | | |
| Heat exchanger | | | Finned tube | | | |
| | Fan | | Cross flow fan | | | |
| Fan unit | Standard air flow | H/M/L (cfm) | 440/370/295 | 470/380/295 | 555/450/355 | |
| | Motor (W) | | 42 61 | | | |
| Air filter | | | Standard filter attached (Long life filter) | | | |
| Controller | | | Optional | | | |
| Sound pressure level H/M/L | | (dB) | 39/36/33 | 40/37/33 | 46/42/37 | |
| Sound power level H/M/L (dB | | (dB) | 54/51/48 | 55/52/48 | 61/57/52 | |
| Gas side (in) | | 1/2 5/8 | | 5/8 | | |
| Connecting | pipe Liquid | (in) | 1/4 3/ | | 3/8 | |
| Drain port (ii | | ort (in) | VP25 (Polyvinyl chloride tube: External Dia. 1-1/4 Internal Dia.1) | | | |

2. CONSTRUCTION VIEWS (EXTERNAL VIEWS)

1-way cassette type



3. WIRING DIAGRAM




4. PARTS RATING

| | MMU- | | | |
|-----------------------------|--|-----------------------------------|------------------------|--|
| Model | UB015 | UB018 | UB024 | |
| Fan motor | WDF-340-30CA1 | | ICF-280-61-3 | |
| Motor for horizontal grille | Motor for horizontal grille 24BYJ48-ST | | | |
| Pulse motor valve | PAM-B40YGTF-1 | | | |
| TA sensor | Lead wire length: 8.6" (218 mm) Vinyl tube | | | |
| TC1 sensor | Ø0.16" (4 mm) size lead wire length: 39.4" (1000 mm) Vinyl tube (Brown) | | | |
| TC2 sensor | Ø0.24" (6 mm) size | lead wire length : 39.4" (1000 mr | nm) Vinyl tube (Black) | |
| TCJ sensor | Ø0.24" (6 mm) size lead wire length : 39.4" (1000 mm) Vinyl tube (Red) FS-0359-601 PMD-08D12TF-2 | | | |
| Float switch | | | | |
| Drain pump motor | | | | |

5. REFRIGERANT CYCLE DIAGRAM

Indoor unit



Explanation of functional parts in indoor unit

| Functional part | t name | Functional outline |
|-------------------|--------|--|
| Pulse Motor Valve | | (Connector CN82 (6P): Blue) 1) Controls superheat in cooling operation 2) Controls subcool in heating operation 3) Recovers refrigerant oil in cooling operation 4) Recovers refrigerant oil in heating operation |
| Temp. Sensor TA | | (Connector CN104 (2P): Yellow) 1) Detects indoor suction temperature |
| | TC1 | (Connector CN100 (3P): Brown) 1) Controls PMV superheat in cooling operation |
| | TC2 | (Connector CN101 (2P): Black) 1) Controls PMV subcool in heating operation |
| | TCJ | (Connector CN102 (2P): Red) 1) Controls PMV superheat in cooling operation |

6. CONTROL OUTLINE

Control Specifications

| No. | Item | Outline of specifications | Remarks |
|-----|----------------------------|--|---|
| 1 | When power supply is reset | Distinction of outdoor unit When the power supply is reset, the outdoors ar distinguished and the control is selected according distinguished result. Setting of indoor fan speed and existence of air of adjustment Based on EEPROM data, select setting of the inspeed and the existence of air direction adjustment If resetting the power supply during occurrence of the trouble, the check code is once cleared. After ON button of the remote controller was pushed and operation was resumed, if the abnormal status of the check code is again displayed on the remote | ng to the direction door fan ent. of a N/OFF the ontinues, |
| 2 | Operation mode selection | Based on the operation mode selecting comman remote controller, the operation mode is selected Remote controller Control outline | |
| | | command | |
| | | STOP Air conditioner stops. | |
| | | FAN Fan operation | |
| | | COOL Cooling operation | |
| | | DRY Dry operation | |
| | | HEAT Heating operation | |
| | | AUTO (Heat recovery system outdoor unit type) TA and Ts automatically select CHEAT operation mode for operation is performed as shiften the following figure according to The tat the first time only. (In the range of Ts - 1 - 1.8°F (1°C) + Cooling thermo. OFF (Fan) / Setup air voloperation continues.) | tion. own in a value C) ng |
| | | Ta (°F) +1.8 +1.0 Ta (°F) Ts Cooling thermo. ON Cooling thermo. OFF (at the first time only) | |
| | | -1.0 - Heating //////////////////////////////////// | |
| | | * Only Heat recovery system outdoor unit type can automatic mode. While a wireless remote controll used, the mode is notified by "Pi Pi" (two times) re sound and the alternate flashing of [TIMER ①] at [READY 🕸]. To clear the alternate flashing, chan mode on the wireless remote controller. | er is eceiving nd |
| 3 | Room temp. control | 1) Adjustment range: Remote controller setup temperatu COOL/DRY HEAT Wired type 64°F [18°C] to 84°F [29°C] 64°F [18°C] to 88°F [30°C] 63°F [17°C] to 88°F [30°C] 63°F [17°C] to 88°F [30°C] 63°F [30 | * For Heat recovery system outdoor unit |

| | Item | Outilite | or spec | ification | S | | Remarks |
|---|--------------------------------------|--|---|--|--|-------------------------------|---|
| 3 | Room temp. control (Continued) | Using the Item code 0 operation can be com SET DATA | pensate 0 | d. 2 | 4 | 6 | Shift of return air temperature in heating operation |
| | | Temperature setting adjustment | +0 °F [+0°C] | +3.6 °F [+2°C] | +7.2 °F [+4°C] | +10.8 °F [+6°C] | Except while sensor of |
| | | Setting at shipment | | | | | the remote controller is controlled |
| | | Mod Floor standing cabinet, Fl | | ding conce | | Set data 0 | (Code No. [32], "0001") |
| | | Floor standing Other models | 2 | | | | |
| | | Callet medale | | | | | |
| 4 | Automatic capacity control | 1) Based on the difference tion capacity is determ Ta(°F) Ta Cooling (°C) 1 | nined by | | | · | |
| | | +3.6 +2 SD SB SB S9 | +1. | 8 +1 | \$3\\$0 \$5 \$7 | _ | |
| | | Ts Ts S7 S5 S5 S3 S0 | -1.8 | <u> </u> | S9 SB SD | # | |
| | | -1.8 -1 | - 3. | 6 -2 | SF | \rightarrow | Ts: Setup temp. |
| | | | _ | | | | TA: Room temp. |
| 5 | Automatic cooling/heating control | 1) The judgment of select shown below. When +2 10 minutes and after the (Thermostat OFF) exch Description in the parest cooling ON/OFF. Ta Ta Coc (°F) (°C) +2.7 +1.5 | 7°F (+1 ermosta nanges to ntheses | .5°C) exc tt OFF, he o cooling shows ar | ceeds age ating of operation operation examp | gainst Tsh peration on. le of | * For Heat recovery system outdoor unit type Tsc: Setup temp. in cooling operation Tsh: Setup temp. in heating operation + temp. compensation of room temp. control |
| | | When -2.7°F (-1.5°C) and after thermostat C (Thermostat OFF) exc 2) For the automatic capa cooling/heating, see It 3) For temperature comp automatic heating, see | OFF, coo changes acity cor em 4. ensatior | ling oper to heatin ntrol after | sc 10 mii ation g operat judgme | tion. nt of | |

| No. | Item | Outline of specifications | Remarks |
|-----|------------------------|---|--|
| 6 | Fan speed selection | 1) By the command from remote control, fan speed is changed. ((HH), (H+), (H), (L+), (L) or [AUTO]) 2) When the fan speed mode [AUTO] is selected, the fan speed varies by the difference between TA and Ts. COOL> Ta (°F) Ta (°C) +5.4 +3.0 HH B +4.5 +2.5 HH > C +5.4 +3.0 HH B +4.5 +2.5 HH > C +2.7 +1.5 H+ <hh> D +1.8 +1.0 H <hh> D +1.8 +1.0 H <hh> D +0.9 +0.5 L <h> E -0.9 -0.5 L <h> F -0.9 -0.5 L <h> G C > : Indicate automatic cooling.</h></h></h></hh></hh></hh> | HH > H+ > H > L+ > L > UL Depending on the remote controller used, (H+) and (L+) cannot be selected. For Floor Standing Concealed Type, or Floor Standing Cabinet Type, (HH), (H), (L) or [AUTO] can be selected regardless of remote controller models. |
| | | Fan speed mode [AUTO] in case when remote controller sensor works is equal to that in case when indoor unit sensor works. If the fan speed has been changed once, it is not changed for 3 minutes. However when the air volume is changed, the fan speed changes. When cooling operation has started, select a downward slope for the fan speed, that is, the high position. If the temperature is just on the difference boundary, the fan speed does not change Ta (°F) Ta (°C) | Code No. [32] 0000: Indoor unit sensor (Main unit) 0001: Remote controller sensor |
| | | Value in the parentheses indicates one when sensor of the remote controller works. Value without parentheses indicates one when sensor of the indoor unit sensor works. If the fan speed has been changed once, it is not changed for 1 minute. However when the fan speed changed, the fan speed changes. When heating operation has started, select an upward slope for the fan speed, that is, the high position. If the temperature is just on the difference boundary, the fan speed does not change. In TC2 ≥ 60°C, the fan speed increases by 1 step. | TC2: Temperature of indoor heat exchanger sensor |

| No. | Item | Outline of specifications | Remarks |
|-----|---|--|--|
| 7 | Prevention of cold air discharge | In heating operation, the higher temperature of TC2 sensor and TCJ sensor is compared with temperature of TC1 sensor and then the lower temperature is used to set the upper limit of the fan tap. When B zone has continued for 6 minutes, the operation shifts to C zone. In defrost time, the control point is set to +10.8 °F [+6°C]. (°F) (°C) 89.6 32 86 30 82.4 28 78.8 26 | TCJ: Temperature of indoor heat exchanger sensor • In D and E zones, priority is given to remote controller fan speed setup. • In A zone " * " is displayed. |
| | | 68 20 Cover 86°F(30°C), below 89.6 E zone: HIGH (HH) B A | °F(32°C), MED (H) |
| 8 | Freeze prevention control (Low temp. release) | In all cooling operation, the air conditioner operates as described below based upon temp. detected by TC1, TC2 and TCJ sensors. When "J" zone is detected for 5 minutes, the thermostat is forcedly off. In "K" zone, the timer count is interrupted, and held. When "I"zone is detected, the timer is cleared and the operation returns to the normal operation. If "J" zone continues, operation of the indoor fan in LOW mode continues until it reaches the "I"zone. It is reset when the following conditions are satisfied. Reset conditions 1) TC1 > 53.6° E(12°C) and TC2 > 53. | TC1: Temperature of indoor heat exchanger sensor |
| | | 1) TC1 ≥ 53.6°F(12°C) and TC2 ≥ 53.6°F(12°C) and TCJ ≥ 53.6°F(12°C) 2) 20 minutes passed after stop. (°F) (°C) (°C) (°C) (°C) (°C) (°C) (°C) (°C | () value: When the power supply is turned on, the forced thermostat becomes OFF if the temperature is less than this indicated temperature. |
| | | Reset conditions 1) TC1 ≥ 53.6°F(12°C) and TC2 ≥ 53.6°F(12°C) and TCJ ≥ 53.6°F(12°C) 2) 20 minutes passed after stop. (°F) (°C) P2 Q2 N P2 41°F(5°C) Q2 28.4°F(-2.0°C) | |

| No. | Item | Outline of specifications | Remarks |
|-----|---|--|--|
| 9 | Refrigerant (Oil) recovery control in cooling operation | Indoor units during stop/thermostat OFF or FAN operation perform following controls when a refrigerant (compressor oil) recovery signal is received from outdoor unit at the cooling operation, (1) Opening the indoor unit PMV at constant valve opening. (For a maximum of about 4 minutes) (2) Operating the drain pump for about one minute, during recovery control and after the control finished. Also, indoor unit fan or louvers may operate depending on the indoor unit type. | Control is performed per two hours or when the outdoor unit determines its need.(It varies depending on the indoor units connected.) |
| 10 | Refrigerant (Oil) recovery control in heating operation | Indoor units during stop/thermostat OFF or FAN operation perform following controls when a refrigerant (compressor oil) recovery signal is received from outdoor unit at the heating operation, (1) Opening the indoor unit PMV at constant valve opening. (For a maximum of about 20 minutes) (2) TC2 temperature is detected to close its PMV. Also, the fan, louvers, drain pump may operate for about one minute after recovery control finished depending on indoor unit types, until the number of recovery control reaches the predetermined number. NOTE The PMV, indoor fan, or louvers may operate through the outdoor unit instruction. For its detail, refer to the outdoor unit service guide. | Indoor unit during cooling thermostat OFF or FAN operation stops the indoor fan and displays "Operation standby (b)". Control is performed per one hour or when the outdoor unit determines its need.(It varies depending on the indoor units connected.) |
| 11 | Compensation control for short intermittent operation | For 3 minutes after start of operation, the operation is forcedly continued even if the unit enters in Thermostat-OFF condition. However the thermostat is OFF giving prior to COOL/HEAT selection, READY for operation and protective control. | Usually the priority is given to 5 minutes at outdoor controller side. |
| 12 | Drain pump control | In cooling operation (including DRY operation), this control anytime operates the drain pump. During operation of the drain pump, if the float switch operates, the drain pump continuously operates and a check code is issued. During stop status of the drain pump, if the float switch operates, the thermostat is forcedly off and this control operates the drain pump. After continuous operation of the float switch for approx. 5 minutes, this control stops the operation and a check code is issued. | Check Code [P10] • A model with a drain pump: 4-way Concealed Duct High Static Duct Fresh air |
| 13 | Elimination of retained heat | When the unit stopped from [HEAT] operation, the indoor fan operates with [L] for approx. 30 seconds. | |
| 14 | HA control | ON/OFF operation is available by input of HA signal from the remote site when connected to remote controller or the remote ON/OFF interface. HA control outputs ON/OFF status to HA terminal. The input-output specifications of HA conform to JEMA standard. | When using HA terminal (CN61) for the remote ON/OFF, a connector sold separately is necessary. In case of group operation, use the connector to connect HA terminal to either master or follower indoor unit. |

| No. | Item | | | Outline of | of specifica | ations | | | Remarks |
|-----|--|---|--|--|---|---|-------------------|-----------------------|--|
| 15 | Alarm output setup | indoo outpu Follo | | g group con ader unit an le below, req arm output of the ader indoor unthe state of fo | (Refer to connection indoor Found (MCC-1) | Connector CN61 (Refer to 8-3-1,8-3-2. Optional connector specifications of indoor P.C.board (MCC-1643) Be sure to change the setting data while operation stops. | | | |
| 16 | Display of filter sign [III] (Not provided to the wireless type) | re tii op 2) T re Ir | he filter sig eset signal to me (150H/2 peration tim he integrate eceived from a this time, if eset and the | to the remo 500H) elaps e of the indo d timer is cl n the remote the specific | | | | | |
| 17 | Display of [READY] [HEAT READY] | 1) W • • 2) D • 3) T T 4) T [F <he. td="" the="" wher<=""><td colspan="6">READY> Displayed on the remote controller When the following check codes are indicated Open phase of power supply wiring [P05] was detected. There is an indoor unit that detected the indoor overflow [P10]. There is an indoor unit that detected the interlock alarm [L30]. During Force Thermostat-OFF [COOL/DRY] operation is unavailable because the other indoor unit operates with [HEAT] mode. [HEAT] operation is unavailable because COOL priority (SW11-bit1 of the Outdoor I/F P. C. board is ON) is set and the other indoor unit operates with [COOL/DRY] mode. The above indoor units that cannot operate stay in Thermostat-OFF status. The indoor fan stops because the system performs [Recovery operation for heating refrigerant (Oil)]. CHEAT READY> Displayed on the remote controller The indoor fan stops in order to prevent discharge of cool air when heating operation started or during heating operation.</td><td>EADY (*) > display display for wireless remote controller EAT READY (*) > lay</td></he.> | READY> Displayed on the remote controller When the following check codes are indicated Open phase of power supply wiring [P05] was detected. There is an indoor unit that detected the indoor overflow [P10]. There is an indoor unit that detected the interlock alarm [L30]. During Force Thermostat-OFF [COOL/DRY] operation is unavailable because the other indoor unit operates with [HEAT] mode. [HEAT] operation is unavailable because COOL priority (SW11-bit1 of the Outdoor I/F P. C. board is ON) is set and the other indoor unit operates with [COOL/DRY] mode. The above indoor units that cannot operate stay in Thermostat-OFF status. The indoor fan stops because the system performs [Recovery operation for heating refrigerant (Oil)]. CHEAT READY> Displayed on the remote controller The indoor fan stops in order to prevent discharge of cool air when heating operation started or during heating operation. | | | | | | EADY (*) > display display for wireless remote controller EAT READY (*) > lay |
| 18 | Selection of central control mode | remote controller at the indoor unit side is possible | | | | | | | 1 |
| | Operation fro central contro | | ON/OFF setting | Operation selection | Operation on Timer setting | Temp. | Fan speed setting | Air direction setting | |
| | Individual | | 0 | 0 | 0 | 0 | 0 | 0 |] |
| | [Central 1] | | × | 0 | × | 0 | 0 | 0 | |
| | [Central 2] | | X | X | × | × | 0 | 0 | - |
| | [Central 3] | | 0 | × | 0 | × 0 | 0 | 0 | - |
| | (O: Operation poss | 71. | _ | | | <u> </u> | | | J |

| No. | Item | Outline of specification | s Remarks |
|-----|----------------|--|--|
| 19 | Louver control | 1) Louver position setup • When the louver position is changed, the necessarily to downward discharge positive set position. • The louver position can be set up in the range. In cooling/dry operation In heating | tion once to return to |
| | | | |
| | | In group twin/triple operation, the louver up collectively or individually. In case that HEAT refrigerant recovery c formed in STOP status, the louver position horizontal when the operation is resume Swing setup Compact 4-way, 2-way cassette, 1-way campact 4-way, 2-way cassette, 1-way c | control was per- on becomes d. assette (SH): |
| | | (Repeats) • In group operation, the louver positions of | ean be set up |
| | | collectively or individually. Floor standing: • [SWING] is displayed and the following d In all operations | |
| | | <i>)</i> | |
| | | As for Floor standing, the vertical louver horizontal direction. (Perform vertical wind direction adjustmeter of the louver positions of collectively or individually. When the unit stopped or the warning was automatically set to full closed position. When PRE-HEAT (Heating ready) is disposited the louver direction started or defrost operation heating thermostat is off or self-cleaning is position is automatically set to horizontal discharge position. * The louver which air direction is individual louver closes fully when the unit stops at automatically set to horizontal discharge HEAT (Heating ready) is displayed, he | ent manually) can be set up coutput, the louver is clayed on is performed), erformed, the louver position. ally set or the locked and the louver is exposition when PRE- |

| No. | Item | | Outline of specifications | | Remarks | |
|-----|-------------------------------|--|--|---|--|--------------------------|
| 19 | Louver control (Continued) | remote • While | e is the locked louver in the unit, [controller screen. the following controls are performed, e even if executing the louver lock. | For the setting operarefer to [How to set I lock] of Installation N | ouver | |
| | | | Control which ignores lock | Object | tive louver No. | |
| | | 1 | Operation stop | Full- | close position | |
| | | 2 | When heating operation started | Horizontal | discharge position | |
| | | 3 | Heating thermostat OFF | Horizontal | discharge position | |
| | | 4 | During defrost operation | Horizontal | discharge position | |
| | | (5) | Initialize operation | Full-o | close position | |
| | | on the | al louver corresponding to the louver N remote controller screen during setting erates swinging. | | It is position check op and it does not link w real louver and air dir setup (Illustration on remote controller scre | ith the ection the |
| 20 | DC motor | starte 2) DC m the in (Note) I | n the fan starts, positioning is performer and the rotor. (Vibrate slightly) notor operates according to the commidoor controller. If the fan rotates by entry of outside a he air conditioner stopped, the indoor operate as the fan motor stops. If the fan lock was detected, the operandoor unit stops and the check code | Check code [P12] | | |
| 21 | Power saving mode | 1. Push 2. The control 3. The rapprof 4. If the are remode The ptime remode outo | the save button on the remote cont segment lights up on the wired coller display. equirement capacity ratio is limited to eximately 75 %. power saving operation is enabled, the etained when the operation is stopped is changed, or when the power is repower saving operation will be enabled the operation starts. Operation may differ depending on the door unit. Refer to the Service Manual door unit. | the settings d, when the set. ed at the next the connected | | |


| No. | Item | Outline of specifications | Remarks |
|-----|----------------------|--|--|
| 22 | Secondary heating | Secondary heating can be used while heating operations are performed. Control Outline (Normal Mode)> 1) If the difference between the indoor temperature and the outdoor temperature is large while the air conditioner is operating, turn ON the secondary heating. 2) This function is valid when the CODE No. (DN) [DC] is set to "0001" (32.9°F(0.5°C)) to "0010" (41°F(5.0°C)) using the wired remote controller, and the output to the external heating source will turn ON if the room temperature satisfies the condition. 3) The output will always stay ON while defrosting operations are being performed. | |
| | | TA TS TAH OFF TAH OFF TAL OFF TON ON A The output can be turned on by the outdoor temperature when CODE No. (DN) [C7] is set to "0001" (33.8°F(1°C)) to "0010" (50°F(10°C)) using the wired remote controller. | TAH: Temp.set air high (= Ts - a) TAL: Temp.set air low (= TAH - b) |
| | | TOL OFF ON C | TO _H : Temp.set out high TO _L : Temp.set out low (= TO _H - c) |
| | | <control (flip="" mode)="" outline=""> If the difference between the room temperature and the set temperature is large while using secondary heating, run the air conditioner. This function is valid when the CODE No. (DN) [C5] is set to "0001" (Flip mode) or the CODE No. (DN) [C7] is set to "0001" (33.8°F(1°C)) to "0010" (50°F(10°C)) using the wired remote controller, and when the output is switched ON when the room temperature satisfies the conditions. * The outdoor temperature determination is invalid whilst this control is performed. </control> | |
| | | TAH TAL ON a | |

| DN [C5] | Data 0000 0001 | Secondary heating mode Normal mode (Factory default) | |
|--|--|--|--|
| 1) | 0000 | Normal mode (Factory default) | |
| | | ` | |
| DN IC61 | 0001 | | |
| DN IC61 | | Flip mode | |
| | Data | TOн: Set temp. out (high) [°F(°C)] | |
| | -0015 | "-0015": 5°F(-15°C) to "0015": 59°F(15°C) | |
| | to | "0000": 32°F(0°C) (Factory default) | |
| | 0015 | | |
| DN [C7] | Data | с : ТОн - TОL [°F(°С)] | |
| | 0000 | Unavailable (Factory default) | |
| | 0001 | 0001: 33.8°F(1°C) to "0010": 50°F(10°C) | |
| | to | | |
| | 0010 | | |
| DN [DB] | Data | b : ТАн - ТАL [°F(°С)] | |
| | 0001 | "0001": 32.9°F(0.5°C) to "0010": 41°F(5.0°C) | |
| | | "0006": 37.4°F(3°C) (Factory default) | |
| | 0010 | | |
| DN [DC] | Data | a : Ts - TAн (Normal mode)[°F(°C)] | |
| | | TA∟ - Ts (Flip mode)[°F(°C)] | |
| | 0000 | Unavailable (Factory default) | |
| | | 0001: 33.8°F(1°C) to "0010": 50°F(10°C) | |
| | | | |
| Indoor F CN60 Option output (6P WHI) Indoor cont P.C. board * The output the wired controller Monit CODE | Relay Corrections of the state carremote coffor operations of the state carrendomic contents of the state carrendomic | connect to secondary heating unit Desponds to the relay up to one that the rated ont of the operation coil is approx. 75mA Connect to secondary heating unit Desponds to the relay up to one that the rated ont of the operation coil is approx. 75mA Connect to secondary heating unit Desponds to the relay up to one that the rated ont of the operation of the relay within 2m. Desponds to the relay up to one that the rated ont of the operation on the secondary heating unit Desponds to the relay up to one that the rated ont of the remote indoor control is approx. 75mA Connect to secondary heating unit Desponds to the relay up to one that the rated ont of the remote indoor control is approx. 75mA Connect to secondary heating unit Desponds to the relay up to one that the rated ont of the rated ont of the relay within 2m. | |
| | CN60 Option output (6P WHI) Indoor cont P.C. board * The output the wired controller Monit | DN [C7] Data 0000 0001 to 0010 DN [DB] Data 0001 to 0010 DN [DC] Data 0000 0001 to 0010 <wiring> 1) Use ① - ④ pin (O indoor P.C. board Relay Correcurre CN60 Option output (6P WHI) 3 3 4 4 5 5 6 6 Note Indoor control P.C. board * The output state ca the wired remote co controller for operat Monitor Sec CODE No. E5</wiring> | DN [C7] Data C: TOH - TOL [°F(°C)] 0000 Unavailable (Factory default) 0001 0001: 33.8°F(1°C) to "0010": 50°F(10°C) to 0010 DN [DB] Data b: TAH - TAL [°F(°C)] 0001 0001 0001 0001 DN [DC] Data a: Ts - TAH (Normal mode)[°F(°C)] TAL - Ts (Flip mode)[°F(°C)] TAL - Ts (Flip mode)[°F(°C)] 0000 Unavailable (Factory default) 0001 0001 Viring> 1) Use ① - ④ pin (Cooling output, DC 12 V) of CN60 on indoor P.C. board for output. Relay (DC12V, procured locally) Corresponds to the relay up to one that the rated current of the operation coil is approx. 75mA CN60 Option output (6P WHI) Note) Determine the cable length between the indoor control P.C. board and the relay within 2m. * The output state can be checked from "Monitor function" on the wired remote controller. The manual for the remote controller for operation methods of "Monitor function". Monitor Secondary heating output CODE No. ": Unavailabl |

7. COMMUNICATION TYPE, MODEL NAMES AND THE MAXIMUM NUMBER OF CONNECTABLE UNITS

If TU2C-Link (U series) is combined with TCC-Link (other than U series), the wiring specifications and the maximum number of connectable indoor units during group control operation will be changed.

- (1) For wiring specifications, carry out the installation, maintenance, or repair according to the attached Installation Manual.
- (2) For a communication type combination and the max. number of connectable indoor units, refer to the following table.
 - Only when all outdoor unit, indoor unit and remote control are a U series, communication method is TU2C-LINK, and the maximum number of connectable units will be 16.



The combination of unit type and the number of the maximum connection of a communication method


| | Unit type | | | | | | | | | |
|-------------------------------------|-----------|----------|----------|----------|----------|----------|----------|---|--|--|
| Outdoor unit | U series | U series | U series | U series | * | * | * | * | | |
| Indoor unit | U series | U series | * | * | U series | U series | * | * | | |
| Remote controller Remote sensor | U series | * | U series | * | U series | * | U series | * | | |
| Communication type | TU2C-Link | | TCC-Link | | | | | | | |
| Maximum number of connectable units | 16 | | 8 | | | | | | | |

^{*} Other than U series


8. CONFIGURATION OF CONTROL CIRCUIT

8-1. Indoor controller block diagram (MCC-1797)


8-1-1. In case of connection of wired remote controller




8-1-2. In case of connection of wireless remote controller



8-1-3. Connection of both wired remote controller and wireless remote controller



8-2. Indoor Print Circuit Board MCC-1797



Optional connector specifications of indoor P.C. board (MCC-1797)

| Connector No. | Color | Function | Compact 4-way Cassette | 2-way Cassette | 1-way Cassette (SH) | Floor standing | Pin No. | Specifications | Remarks |
|------------------|-----------|---------------------------------------|------------------------------|-------------------|---------------------------|------------------------------|------------|--|--|
| CN32 | White | White Ventilation | 0 | 0 | 0 | 0 | Θ | DC12V | Secondary Heating Output (DN [191] = 01) |
| | | | | | | | 0 | Output (Open collector) | secondary neating can be used wnie neating operation are performed. |
| | | | | | | | | | Ventilation Output (DN [191] = 00) |
| | | | | | | | | | Single operation by FAN button on remote controller is set up from remote controller (DN = 31) |
| CN34 | Red | Input for float SW | • | | • | X (With short- circuit | 90 | DC12V NC | Normal when between ①-③ short-circuits, but abnormal when open-circuits, (check code "P10" appears) |
| | | | | | | | <u>—</u> | Float SW input | |
| CN61 | Yellow HA | НА | 0 | 0 | 0 | 0 | Θ | ON/OFF input | HA ON/OFF input (J01: YES/NO=Pulse (At shipment from factory /Static input selection) |
| | | | | | | | 00 | COM) ote controller prohibited | Permission/Prohibition of remote controller operation stop |
| | | | | | | | ⊕ | input Operation output | is performed by input. Operation ON (Answer back of HA) |
| | | | | | | | | | |
| | | | | | | | 9 | Warning output (Open collector) | Warning output ON |
| CN71 | White | CHK Operation check | 0 | 0 | 0 | 0 | 90 | Check mode input 00 | This check is used to check indoor operation. (Performs operation of indoor fan "H", Louver horizontal and Drain pump ON without communication with outdoor and remote controller) |
| CN72 | White | DISP Exhibition mode | 0 | 0 | 0 | 0 | Θ | DISP mode input 0V | Communication is available by indoor unit and remote controller only (When the power is turned on). Shortening time of timer (Always) |
| CN81 | Black | Output for Flow selector unit | ◁ | ⊲ | ⊲ | ⊲ | | DC12V EP valve output (Open collector) Balance valve output (Open collector) Suction valve output (Open collector) Discharge valve output (Open collector) | |
| CN309 | Yellow | Yellow Output power supply for option | 0 | 0 | 0 | 0 | 00 | AC230V AC230V | This can be used as power supply for option devices. |
| CN521 | Red | Connection for option P.C.board | 4 | ◁ | ◁ | ◁ | 00000 | DC12V DC5V Send Receive 0V | Connected Application control kit (TCB-PCUC2E) |

Use in standard, ○: Available, △: Use by connecting parts sold separately, x: Unavailable
 * To use the functions operated by CN60, CN70 and CN73, which are provided for other P.C.board, use the Application control kit (TCB-PCUC2E) sold separately.

8-3. Functions at test run

■ Cooling/Heating test run check

The test run for cooling/heating can be performed from either indoor remote controller or outdoor interface P.C. board.

1. Start/Finish operation of test run

Test run from indoor remote controller

Wired remote controller: Refer to the below item of "Test run" of the wired remote controller.


Wireless remote controller: Refer to the next page item of "Test run" of the wireless remote controller.

♦ In case of wired remote controller

<RBC-AWSU52-UL>



| | Test mode |
|------|------------------|
| | Test mode start. |
| ⊅ No | ■ Yes |



- (2) Room 12:00 (Mon)

 Test
- Test mode

 Test mode stop.

 Description:

- 2 Press [ON/OFF ON/OFF]
 - → Operation starts, and in test mode screen (1) opens. (While stopped, it is screen (2))
 - → Test mode is done while the operating mode is set to "Cool" or "Heat".
 - → The temperature cannot be set in test mode.
 - → Check codes are displayed in the normal way.

- - → Screen (3) appears.
 - → Press [Set/Fix] to end test mode and do normal operation.

Note) The test run returns to the normal operation after 60 minutes.

■ Check function for operation of indoor unit (Functions at indoor unit side)

This function is provided to check the operation of the indoor unit singly without communication with the remote controller or the outdoor unit. This function can be used regardless of operation or stop of the system.

However, if using this function for a long time, a trouble of the equipment may be caused. Limit using this function within several minutes.

[How to operate]

1) Short-circuit CHK pin (CN71 on the indoor P.C. board).

The operation mode differs according to the indoor unit status in that time.

Normal time: Both float SW and fan motor are normal.

Abnormal time: Either one of float SW or fan motor is abnormal.

2) Restricted to the normal time, if short-circuiting DISP pin (CN72 on the indoor P.C. board) in addition to short-circuit of CHK pin (CN71 on the indoor P.C. board), the minimum opening degree (30pls) can be set to the indoor PMV only.

When open DISP pin, the maximum opening degree (1500pls) can be obtained again.

[How to clear]

Open CHK pin. While the system is operating, it stops once but automatically returns to operation after several minutes.


| | | Short-circuit of CHK pin | | | | |
|----------------|-------------------------------|-----------------------------|-----------------------------|--|--|--|
| | Norm | al time | Abnormal time | | | |
| | DISP pin open | DISP pin short circuit | Abnormal time | | | |
| Fan motor | (H) | (H) | Stop | | | |
| Indoor PMV (*) | Max. opening degree (1500pls) | Min. opening degree (30pls) | Min. opening degree (30pls) | | | |
| Louver | Horizontal | Horizontal | Immediate stop | | | |
| Drain pump | ON | ON | ON | | | |
| Communication | All ignored | All ignored | All ignored | | | |
| P.C. board LED | Lights | Lights | Flashes | | | |

- To exchange the indoor PMV coil, set the indoor PMV to Max. opening degree.
- For the detailed positions of CHK pin (CN71 on indoor P.C. board) and DISP pin (CN72 on indoor P.C. board), refer to the indoor P.C. board MCC-1797.

9. APPLIED CONTROL

9-1. Setup of Selecting Function in Indoor Unit
(Be Sure to Execute Setup by a Wired Remote Controller)

<RBC-AWSU52-UL>



| | Field setting menu (2/3) |
|-----|------------------------------|
| 6. | Setting louver position |
| 7. | Setting timer operation mode |
| 8. | Easy I.DN setting |
| 9. | DN setting |
| 10. | Reset Power Consumption data |
| | |
| | |

| 1 | Press | $\Gamma =$ | Menu] | l to | open | the | "Menu" |
|---|---------|------------|---------|------|-------|-----|--------|
| | L I COO | | INICIIU | l LO | Obell | uic | MEHU |

| 2 | Press and hold [Menu] and [| \vee | at the |
|---|----------------------------------|--------|--------|
| | same time to open "Field setting | g me | nu" |
| | → Press and hold / seconds | | |

| 1 | In the "Field setting menu" screen, press |
|---|---|
| | [$igwide$] and [$igwide$] to select "DN setting", and |
| | then press [Set/Fix] |

| 2 | Press [\wedge] and [\vee |] to select "Indoor unit" |
|---|---------------------------------|---------------------------|
| | or "Outdoor unit", a | nd the press [🔲 Set/ |
| | Fix] | |

| \rightarrow | · If "Indoor unit" | was selected, | the fans | and lovvre | es of |
|---------------|--------------------|---------------|----------|------------|-------|
| | the indoor uni | ts operate. | | | |

When doing group connections:

- → The fans and louvres of the selected indoor units operate.
- **3** Press [<] to black highlight the item code (DN), and then press [<] and [< ✓] to set the item code
- 4 Press [>] to black highlight the data, and then press [∧] and [∨] to set the data
- 5 After finishing setting the data of the item code (DN), press [Set/Fix]
 - → "Continue?" is displayed.
- 6 To set the data of other item codes (DN), press [☐ Set/Fix]

To not do other settings, press [5 Return]

- → The changes are fixed, and the "Field setting menu" screen returns.
- → "∑" appears while data is changing.

When doing group connections:

NOTE

For details on item codes and data to be set, refer to the Installation Manual and Service manual of the indoor unit and outdoor unit.

Indoor unit function Code No. (DN Code) table (includes functions needed to perform applied control on site)

| DN | Item | Description | At shipment |
|-----|---|---|--------------------------|
| | Filter display delay timer | 0000: None 0001: 150H | Depending on model |
| 01 | | 0002: 2500H 0003: 5000H | type |
| • | | 0004: 10000H | [" |
| 00 | Dirty state of filter | 0000: Standard | 0000: Standard |
| 02 | | 0001: High degree of dirt (Half of standard time) | |
| | Central control address | 0001: No.1 unit to 0064: No.64 unit TCC-LINK | 00Un/0099: Unfixed *1 |
| 00 | | 0001: No.1 unit to 0128: No.128 unit TU2C-LINK | |
| 03 | | 00Un: Unfixed (When using U series remote controller) | |
| | | 0099: Unfixed (Other than U series remote controller) | |
| 0.4 | Specific indoor unit | 0000: No priority 0001: Priority | 0000: No priority |
| 04 | priority | | |
| | Heating temp. shift | 0000: 0°F(0°C) 0001: +1.8°F(+1°C) | Depending on model |
| 06 | | 0002: +3.6°F(+2°C) to 0010: +18°F(+10°C) | type |
| | | (Up to +6 recommended) | , |
| | Demand control | 0000: Demand input 0001: O2 sensor input | 0000: Demand input |
| | (CN73 / CN4) | 0002: Card input setup.3 0003: Fire alarm input | |
| | | 0004: Card input setup.4 (Normal open) | |
| 0b | | 0005: Fire alarm input 0006: Notice cord (202) | |
| | | (Normal close) 0008: Card input setup.1 | |
| | | 0007: Card input setup.5 | |
| | | 0009: Card input setup.2 | |
| | Existence of [AUTO] | 0000: Provided | 0001: Not provided |
| 0d | mode | 0001: Not provided | |
| | | (Automatic selection from connected outdoor unit) | |
| 0F | Cooling only | 0000: Heat pump | 0000: Heat pump |
| | _ | 0001: Cooling only (No display of [AUTO] [HEAT]) | |
| 10 | Туре | Refer to Type DN code "10" list | Depending on model |
| | | | type |
| 11 | Indoor unit capacity | 0000: Unfixed 0001 to 0034 | According to capacity |
| | | Refer to Indoor Unit Capacity DN code "11" list | type |
| | Line address | 0001: No.1 unit to 0064: No.30 unit TCC-LINK | 00Un/0099: Unfixed *1 |
| 12 | | 0001: No.1 unit to 0128: No.128 unit TU2C-LINK | |
| | | 00Un: Unfixed (When using U series remote controller) | |
| | In decree with a delice a | 0099: Unfixed (Other than U series remote controller) | 0011-70000-11-5 |
| | Indoor unit address | 0001: No.1 unit to 0064: No.64 unit TCC-LINK | 00Un/0099: Unfixed *1 |
| 13 | | 0001: No.1 unit to 0128: No.128 unit TU2C-LINK | |
| | | 00Un: Unfixed (When using U series remote controller) | |
| | Craus address | 0099: Unfixed (Other than U series remote controller) 0000: Individual 0001: Header unit of group | 00Un/0099: Unfixed *1 |
| | Group address | , · | 000n/0099: Unlixed "1 |
| 14 | | 0002: Follower unit of group | |
| | | 00Un: Unfixed (When using U series remote controller) | |
| | I annual to the a | 0099: Unfixed (Other than U series remote controller) 0000: No louver 0001: Swing only | Dan an din nan maadal |
| 19 | Louver type (Air direction adjustment) | 0000: No louver 0001: Swing only 0004: (4-way Air Discharge Cassette type, etc.) | Depending on model |
| | Temp difference of | 0000: 0°F(0°C) to 0010: 18°F(10°C) (Ts ± 9.0°F(5°C)) | type 0003: 5.4°F(3°C) |
| | [AUTO] mode selection | 10000. 0 1 (0 0) 10 0010. 10 F(10 0) (15 ± 9.0 F(5 0)) | ' ' |
| 1E | COOL → HEAT, | | (Ts ±2.7°F(1.5°C)) |
| | HEAT → COOL | Ts:Remote controller setup temp. | |
| | Automatic restart of | 0000: None 0001: Restart | 0001: Restart |
| 28 | power failure | ooo i. i tostait | Joon Nostant |
| | Selection of option/Trouble | 0000: Filter input 0001: Alarm input | 0002: None |
| 2A | input (TCB-PCUC2E: CN3) | 0002: None (Air washer, etc.) | |
| | HA terminal (CN61) | 0000: Usual 0001: Card input setup.1 (3) | 0000: Usual |
| | select | 0002: Fire alarm input 0003: Card input setup.2 (4) | (HA terminal) |
| 2E | | (arbiter contact) | <u> </u> |
| | | 0004: Notice cord (201) 0005: Card input setup.5 | |
| 31 | Ventilating fan control | 0000: Unavailable 0001: Available | 0000: Unavailable |
| | ١ ٠٠٠٠٠٠٠٠ ال | 1 | 1 |
| 32 | TA sensor selection | 0000: Body TA sensor 0001: Remote controller sensor | 0000: Body TA sensor |

| DN | Item | Description | | At shipment |
|----|---|---|--|---|
| 33 | Temperature unit select | 0000: °C | 0001: °F | 0001: °F |
| 5d | External static pressure High-ceiling adjustment (Air flow selection) | Refer to next page. | | Depending on model type |
| 60 | Timer setting (wired remote controller) | 0000: Available (can be performed) | 0001: Unavailable (cannot be performed) | 0000: Available |
| 77 | Dual set point | 0000: Unavailable | 0002: Available | 0000: Unavailable |
| 79 | Alarm output setup of the header unit | 0000: Not including the state of following unit | 0001: Including the state of following unit | 0000: Not including the state of following unit |
| 7A | Change unit 0.9°F(0.5°C) or 1.8°F(1°C) on remote | 0000: 1.8°F(0.5°C) | 0001: 0.9°F(1°C) | 0001: 0.9°F(1°C) |
| b3 | Soft cooling | 0000: Unavailable | 0001: Available | 0001: Available |
| b5 | Occupancy sensor/ Wireless Remote controller Provided / None | 0000: None 0002: Wireless remote controll | 0001: Occupancy sensor provided ler provided | 0000: None |
| b6 | Occupancy sensor Enable / Invalid (Absence time judgment time) | 0000: Invalid 0002: 60min. 0005: 150min. | 0001: 30min. 0004: 120min. | 0002: Enable (60 min.) |
| b7 | Occupancy sensor operation at absent time | 0000: Stand by | 0001: operation stop | 0000: Stand by |
| d0 | Whether the power saving mode can be set by the remote controller | 0000: Invalid | 0001: Valid | 0001: Valid |
| E0 | Destination | 0000: Domestic | 0001: North America | 0001: North America |
| E6 | Wireless remote controller A-B selection | 0000: A | 0001: B | 0000: A |
| F6 | Presence of Application control kit (TCB-PCUC2E) | 0000: None | 0001: Exist | 0000: None |
| FC | Communication protocol *2 | 0000:TCC-LINK | 0003:TU2C-LINK | 0000: TCC-LINK |
| Fd | Priority operation mode (FS unit) | 0000: Heating | 0001: Cooling | 0000: Heating |
| FE | FS unit address | | | 00Un/0099: Unfixed *1 |

| DN | Item | Description | At shipment |
|-----|--|--|------------------------------------|
| 180 | Notice code number 01 | 0000: None 0001 ~ 0255 : Notice code | 0000: None |
| 181 | Notice code number 02 | 0129 : Notice code (201) 0130 : Notice code (202) (0001 ~ 0255 : TU2C-LINK only) | 0000: None |
| 182 | Notice code number 03 | . (666). 626 626 2.1111 6.111,7 | 0000: None |
| 183 | Notice code number 04 | | 0000: None |
| 184 | Notice code number 05 | | 0000: None |
| 185 | Notice code number 06 | | 0000: None |
| 186 | Notice code number 07 | | 0000: None |
| 187 | Notice code number 08 | | 0000: None |
| 188 | Notice code number 09 | | 0000: None |
| 189 | Notice code number 10 | | 0000: None |
| 191 | Secondary Heat / Ventilation output port switching | 0000: Ventilation output 0001: Secondary heating output | 0001 : Secondary heating output |
| 1FB | Central device control state | 0000: No central device control (Remote controller use is possible) 0001: Central device control (Remote controller use is impossible) | 0000: No central device control |
| 1FC | Indoor Unit terminating resistance | 0000: OFF 0001: ON | 0000: OFF |

^{*1} Display order of "00Un" and "0099" varies depending on remote controller models or communication types.

For Central control address (DN [03]), Indoor unit address (DN [13]), FS unit address (DN [FE])

| | \ L 1// | (L 3// |
|---------------------|--------------------|--------------------------------|
| Remote controller | Communication type | Display order |
| II a a mi a a | TU2C-LINK | ··· ⇔ 0128 ⇔ 00Un ⇔ 0001 ⇔ ··· |
| U series | TCC-LINK | ··· ⇔ 0064 ⇔ 00Un ⇔ 0001 ⇔ ··· |
| Other than U series | TCC-LINK | ··· ⇔ 0064 ⇔ 0099 ⇔ 0001 ⇔ ··· |

For Line address (DN [12])

| Remote controller | Communication type | Display order |
|---------------------|--------------------|--------------------------------|
| II aawiaa | TU2C-LINK | ··· ⇔ 0128 ⇔ 00Un ⇔ 0001 ⇔ ··· |
| U series | TCC-LINK | ··· ⇔ 0030 ⇔ 00Un ⇔ 0001 ⇔ ··· |
| Other than U series | TCC-LINK | ··· ⇔ 0030 ⇔ 0099 ⇔ 0001 ⇔ ··· |

For Group address (DN [14])

| Remote controller | Communication type | Display order | |
|---------------------|--------------------|---------------------------------|--|
| U series | TU2C-LINK | ··· ⇔ 0002 ⇔ 00Un ⇔ 0000 ⇔ ··· | |
| U Series | TCC-LINK | ··· ⇔ 0002 ⇔ 00011 ⇔ 0000 ⇔ ··· | |
| Other than U series | TCC-LINK | ··· ⇔ 0002 ⇔ 0099 ⇔ 0000 ⇔ ··· | |

^{*2} Communication protocol can be automatically switched with the setup in the outdoor unit during installation.

Type DN code "10"

| | Value | Туре | Model |
|---|--------|----------------|------------------|
| | 0000*1 | 4-way cassette | MMU-UB****HP-UL |
| Г | 0003 | 1-way cassette | MMU-UB****YHP-UL |

^{*1 :} Initial setting value of EEPROM installed on the service P.C.Board.

Indoor Unit Capacity DN code "11"

■ 1-way cassette type

| Value | Capacity |
|--------|----------|
| 0000*1 | Invalid |
| 0007 | 015 type |
| 0009 | 018 type |
| 0011 | 024 type |

9-2. Applied Control in Indoor Unit

■ Remote location ON/OFF control box (TCB-IFCB-4UL)

[Wiring and setup]

- Use the exclusive connector for connection with the indoor control P.C. board.
- In a group control, the system can operate when connecting with any indoor unit (Control P.C. board) in the group. However when taking out the operation/error signal from the other unit, it is necessary to take out from each unit individually.

1. Control items

Start/Stop input signal : Operation start/stop in unit
 Operation signal : Output during normal operation


3) Error signal : Output during alarm

(Serial communication error or indoor/outdoor protective device) operation

2. Wiring diagram using remote control interface (TCB-IFCB-4UL)

Input IFCB-4UL : No voltage ON/OFF serial signal
Output No voltage contact for operation, error display

Contact capacity: Below Max. AC240V 0.5A



Ventilating fan control from remote controller

[Function]

- The start / stop operation can be operated from the wired remote controller when air to air heat exchanger or ventilating fan is installed in the system.
- The fan can be operated even if the indoor unit is not operating.
- · Use a fan which can receive the no-voltage normally-open contact as an outside input signal.
- In a group control, the units are collectively operated and they cannot be individually operated.
- * Ventilation function the code No.191 must be setting data 0000 (refer indoor unit function code no. table.)

1. Operation

Handle a wired remote controller in the following procedure.

- * Use the wired remote controller during stop of the system.
- * Be sure to set up the wired remote controller to the header unit. (Same in group control)
- * In a group control, if the wired remote controller is set up to the header unit, both header and follower units are simultaneously operable.

<RBC-AWSU52-UL>

- 1 Press [Menu] to open the "Menu"
- Press and hold [Menu] and [□] at the same time to open "Field setting menu"

 → Press and hold 4 seconds.
- $m{3}$ In the "Field setting menu" screen, press [$ilde{ imes}$] and [$ilde{ imes}$] to select "DN setting", and then press [oxdot Set/Fix]
- 4 Press [△] and [∨] to select "Indoor unit" or "Outdoor unit", and the press [□ Set/Fix]
 - → If "Indoor unit" was selected, the fans and lovvres of the indoor units operate.
 - When doing group connections:
 - → The fans and louvers of the selected indoor units operate.
- f 5 Press [igcesim] to black highlight the item code (DN), and then press [igcesim] and [igcesim] to set the item code No. 31.
- $oldsymbol{6}$ Press [igwedge] to black highlight the data, and then press [igwedge] and [igwedge] to set the data (At shipment : 0000).

| SET DATA Handling of operation of air to air heat exchanger or ventila | | |
|--|---------------------------|--|
| 0000 | Unavailable (At shipment) | |
| 000 (| Available | |


7 After finishing setting the data of the item code (DN), press [\square Set/Fix]

→ "Continue?" is displayed.

- 8 To set the data of other item codes (DN), press [🗆 Set/Fix] To not do other settings, press [🔄 Return]
 - → The changes are fixed, and the "Field setting menu" screen returns.
 - → "∑" appears while data is changing.

When doing group connections:

2. Wiring



Note) Determine the cable length between the indoor control P.C. board and the relay within 2m.


■ Auto-off feature control

[Function]

- This function controls the indoor units individually. It is used when the start operation from outside is unnecessary but the stop operation is necessary.
- A card switch box or card lock helps protect customers from forgetting to turn off the indoor unit. (not including the following Card Input 3)
- It is connected with connector on the indoor control P.C. board, and switched with the Code No. and jumper wire setup for use.

[Setup method] (1) Wiring

Connecting to the CN61 connector



Outside contact (Card switch box, etc: Procured locally)

NOTE) Determine the cable length between the indoor control P.C. board and the relay within 3m.

(2) Code (DN) setup

Set Code (DN) according to set indoor unit function DN code.

| Connector | Jumper wire (J01) | Code No. (DN) | Set data | Function |
|-----------|---|---------------|------------------------|----------------------------|
| | | | 0000 (Factory default) | "HA normal setup" (pulse) |
| | Short-circuit (Factory default) Open-circuit (cut) | 002E | 0001 | "Card Input 1" setup |
| | | | 0003 | "Card Input 2" setup |
| CN61 | | | 0005 | "Card Input 5" setup |
| | | | 0000 (Factory default) | "HA normal setup" (Static) |
| | | | 0001 | "Card Input 3" setup |
| | | | 0003 | "Card Input 4" setup |

[Control items]

| Function | External contact terminal | | | | |
|--------------|---|--|--|--|--|
| runction | Close (Status that card is inserted) | Open (Status that card is taken out) | | | |
| Card Input 1 | Manual prohibition release (Manual operation) | Manual prohibition (Operation stop) | | | |
| Card Input 2 | Manual prohibition release (Automatic operation) | Manual prohibition (Operation stop) | | | |
| Card Input 3 | Operation status continues (Do nothing) | Operation status continues and setting temperature changes (COOL/DRY: 84.2°F(29°C), HEAT: 64.4°F(18°C)) | | | |
| Card Input 4 | Manual prohibition release (The status returns to operating condition before removing the card.) | Manual prohibition (Operation stop) | | | |
| Card Input 5 | 1) To change a setting temperature by changing data at DN code No. 172 to 174. 2) The operation mode can be set by changing data (0000, 0001, 0002) at DN code No. 16b. 0000: operation mode is the same at the current mode. (factory setting default) 0001: operation mode returns to the previous mode when card was inserted. (in case of the previous mode is off operation, the operation mode is also off.) 0002: operation mode starts at the same previous mode when the card was inserted. (the operation mode is on operation even the previous mode is off operation.) See contents below for DN settings and detailed operations. | To change a setting temperature, fan speed and wind direction by changing data at DN code No. 16C to 171. The operation mode can be set by changing data (0000, 0001) at DN code No. 16A. Ooo: operation mode is the same at the current mode. (factory setting default) Ooo1: operation automatically starts. See contents below for DN settings and detailed operations. | | | |

^{*} For the card switch box that does not involve contact operation described above, convert signals with a relay including a normally-closed contact.

[Card input setup.5 Code (DN)]

| Loa | vara input octupio ocuc (bit/) | | | | | | |
|-----|---|--|---------------------|--|--|--|--|
| DN | Item | Description | At shipment | | | | |
| 16C | Open mode Set temp. (Cool, Dry) | -0015 : 5°F(-15°C) to 0060 : 140°F(60°C) | 0027:80.6°F(27°C) | | | | |
| 16d | Open mode Set temp. (Heat) | -0015 : 5°F(-15°C) to 0060 : 140°F(60°C) | 0020 : 68°F(20°C) | | | | |
| 16E | Open mode Set temp. (Auto) | -0015 : 5°F(-15°C) to 0060 : 140°F(60°C) | 0024 : 75.2°F(24°C) | | | | |
| 16F | Open mode Fan speed (All operation mode) | 0000 : No change | 0000 : No change | | | | |
| 170 | Open mode Wind direction (Cool, Dry, Fan) | 0000 : No change | 0000 : No change | | | | |
| 171 | Open mode Wind direction (Heat) | 0000 : No change | 0000 : No change | | | | |
| 16A | Open mode Operation | 0000 : No change 0001 : Run operation | 0000 : No change | | | | |
| 172 | Close mode Set temp. (Cool, Dry) | -0015 : 5°F(-15°C) to 0060 : 140°F(60°C) | 0024 : 75.2°F(24°C) | | | | |
| 173 | Close mode Set temp. (Heat) | -0015 : 5°F(-15°C) to 0060 : 140°F(60°C) | 0024 : 75.2°F(24°C) | | | | |
| 174 | Close mode Set temp. (Heat) | -0015 : 5°F(-15°C) to 0060 : 140°F(60°C) | 0024 : 75.2°F(24°C) | | | | |
| 16b | Close mode Operation | 0000 : No change 0001 : Card ON mode operation 0002 : Run operation (Card ON mode setting) | 0000 : No change | | | | |

[The example of Card Input 5 setting]

| | | C | Code | No. ([| ON) se | etting | | | | External contact terminal | | | | |
|-------|---------------|---------------|---------------|---------------|---------------|---------------|---------------|---------------|---------------|--|---|--|--|--|
| Case. | [16A] data | [16b] data | [16C] data | [16d] data | [16F] data | [170] data | [171] data | [172] data | [173] data | Close (Status that card is inserted) | Open (Status that card is taken n out) | | | |
| (1) | 0000 | 0000 | 0027 | 0020 | 0000 | 0000 | 0000 | 0024 | 0024 | The operation mode continues running at the same as the current mode. The setting temperature of cooling/dry and heating mode is changed to 75.2°F(24°C) and 75.2°F(24°C) respectively due to change in code No. 172, 173. | The operation mode continues running at the same as the current mode. The setting temperature of cooling/dry and heating mode is changed to 80.6°F(27°C) and 68°F(20°C) respectively due to change in code No. 16C, 16d. | | | |
| (2)* | 0000 | 0001 | 0027 | 0020 | 0003 | 0001 | 0001 | 0024 | 0024 | The operation mode is running at the same mode as the last time when the card was inserted due to change in code no. 16b. * The operation mode will be off if the mode at the last time was in off operation. Also, the fan speed will the same as the last time when the card is inserted. • The setting temperature of cooling/dry and heating mode is changed to 75.2°F(24°C) and 75.2°F(24°C) respectively due to change in code No. 172, 173. | The operation mode continues running at the same as the current mode. The setting temperature of cooling/dry and heating mode is changed to 80.6°F(27°C) and 68°F(20°C) respectively due to change in code no. 172, 173. The fan speed for all operation modes is changed due to change in code no.16F. The wind direction of Cooling/dry/fan and heating mode are changed due to change in code No. 170, 171 respectively. | | | |
| (3)* | 0000 | 0002 | 0027 | 0020 | 0003 | 0001 | 0001 | 0024 | 0024 | The operation mode is running at the same mode as the last time when the card was inserted. Also, the operation mode will be on even the mode was in off operation at the last time due to change in code no. 16B. The fan speed will the same as the last time when the card is inserted. The setting temperature of cooling/dry and heating mode is changed to 75.2°F(24°C) and 75.2°F(24°C) respectively due to change in code No. 172, 173. | Same operation as case (2) | | | |
| (4) | 0001 | 0000 | 0027 | 0020 | 0003 | 0001 | 0001 | 0024 | 0024 | The operation mode continues running at the same as the current mode. The setting temperature of cooling/dry and heating mode is changed to 75.2°F(24°C) and 75.2°F(24°C) respectively due to change in code No. 172, 173. | Due to change in code no. 16A, the operation mode will be as below. When the operation is ON, the operation mode will continue running at the same as the current mode. When the operation is OFF, the air conditioner will turn on automatically. The setting temperature of cooling/dry and heating mode is changed to 80.6°F(27°C) and 68°F(20°C) respectively due to change in code No. 172, 173. The fan speed for all operation modes is changed due to change in code no.16F. The wind direction of Cooling/dry/fan and heating mode are changed due to change in code No. 170, 171 respectively. | | | |

^{*} The history operation mode is only recorded when the card is inserted even if the operation mode is changed when the card is taken out, there is no related to the history operation mode.

■ Notice code signal

Notice code is a function dedicated to TU2C-Link communication. See service manual for u series outdoor unit for details of Notice code.


[Function]

- Notice Code is issued if there is signal input to connector of outdoor unit P.C. board. This can be used in cases such as when confirming state of outdoor unit (filter clogging, etc.) by air conditioner system.
- Used by switching functions with settings of Code No. (DN Code).
- · Notice Code is continuously issued while input signal is ON.

[Setup method]

(1) Wiring

Connecting to the CN61 connector



Note) Determine the cable length between the indoor control P.C. board and the relay within 3m.

(2) Code (DN) setup and Notice code

Set Code (DN) according to set indoor unit function DN code.

| Connector | Code No. (DN) | Set data | Notice code |
|-----------|---------------|----------|-------------|
| CN61 | 002E | 0004 | 201 |

^{*} Setting of Code No. (DN Code) is necessary to display Notice code mark at remote controller. Set data corresponding to Notice code to be used to one of Code No. 180 to 189, in accordance with following table. In case where data other than 0000 is already set, set to other Code No. (DN Code).


| Code No. (DN) | Set data | Notice code | | |
|---------------|----------|-----------------------|--|--|
| 0180 | 0000 | OFF (Factory default) | | |
| to | 0129 | 201 | | |
| 0189 | 0130 | 202 | | |

^{*} It may take up to ten minutes to be displayed on remote controller after Notice code is issued.

■ Manual address setting using the remote controller


Procedure when setting indoor units' addresses first under the condition that indoor wiring has been completed and outdoor wiring has not been started (manual setting using the remote controller)

▼ Wiring example of 2 refrigerant lines



In the example above, disconnect the remote controller connections between the indoor units and connect a wired remote controller to the target unit directly before address setting.

<RBC-AWSU52-UL>



Pair the indoor unit to set and the remote controller one-to-one. Turn on the power.

- 1 Press [Menu] to open the "Menu"
- f 2 Press and hold [$oxed{\equiv}$ Menu] and [$oxed{igwedge}$] at the same time to open "Field setting menu"
 - → Press and hold 4 seconds.
- $m{3}$ In the "Field setting menu" screen, press [igtriangle] and [igtriangle] to select "DN setting", and then press [igtriangle Set/Fix]
- 4 Press [☐] and [☐] to select "Indoor unit" or "Outdoor unit", and the press [☐ Set/Fix]
 - → If "Indoor unit" was selected, the fans and lovvres of the indoor units operate.

When doing group connections:

→ The fans and louvres of the selected indoor units operate.

<Line (system) address>

- **5** Press [<] to black highlight the item code (DN), and then press [<] and [<] to set the item code No. to 12.
- **6** Press [>] to black highlight the data, and then press [<] and [<] to set the data system address.

(Match the address with the address on the interface P.C.board of the header outdoor unit in the same refrigerant line.)

- 7 After finishing setting the data of the item code (DN), press [Set/Fix]
 - → "Continue?" is displayed.

<Indoor unit address> 8 Press [<] to black high</pre>

- 8 Press [<] to black highlight the item code (DN), and then press [<] and [<] to set the item code No. to 13.
- **9** Press [\triangleright] to black highlight the data, and then press [\triangleright] and [\triangleright] to set the data indoor unit address.
- $m{10}$ After finishing setting the data of the item code (DN), press [lacksquare Set/Fix]
 - → "Continue?" is displayed.

<Group address>

- 11 Press [<] to black highlight the item code (DN), and then press [<] and [<] to set the item code No. to 14.
- Press [>] to black highlight the data, and then press [<] and [<] to set the data indoor unit address. a group address. If the indoor unit is individual, set the address to 0000; header unit, 0001; follower unit, 0002.</p>

Individual : 0000
Header unit : 0001
Follower unit : 0002

In case of group control

- 13 After finishing setting the data of the item code (DN), press [Set/Fix]
 - → "Continue?" is displayed.
- 14 To set the data of other item codes (DN), press [Set/Fix] To not do other settings, press [Return]
 - → The changes are fixed, and the "Field setting menu" screen returns.
 - → "∑" appears while data is changing.

When doing group connections:

→ Press [⑤ Return] to open the unit selection screen. In the unit selection screen, press [⑤ Return] to briefly display "∑", and then return to the "Field setting menu" screen.

NOTE

<In the case of combining with outdoor units of Super Modular Multi System u series (SMMS-u)>

- Turn ON DIP switch 1 of SW100 on the header outdoor unit interface P.C. board the lowest system address number.
- After finishing all the settings above, set the address of the central control devices. (For the setting of the central control address, refer to the installation manual of the central control devices.)

< In the case of combining with outdoor units other than Super Modular Multi System u series (SMMS-u)>

- Set a system address for the header outdoor unit of each line with SW13 and 14 of their interface P.C. boards.
- Turn off dip switch 2 of SW30 on the interface P.C. boards of all the header outdoor units connected to the same central control, except the unit that has the lowest address. (For unifying the termination of the wiring for the central control of indoor and outdoor units)
- Connect the relay connectors between the [U1, U2] and [U3, U4] terminals on the header outdoor unit of each refrigerate line.
- After finishing all the settings above, set the address of the central control devices. (For the setting of the central control address, refer to the installation manuals of the central control devices.)

◆ To find an indoor unit's position from its address

Procedure to know the position of indoor unit body by address while indoor unit No. is known.

· Confirm each indoor unit address while indoor unit is stopped. (Be sure to stop air conditioner.)

<RBC-AWSU52-UL>


[Procedure]


The position of indoor unit body by address

- 1 Push the [MENU] button to display the menu screen.
- **2** Push and hold the [MENU] button and the [✓] button at the same time to display the "Field setting menu".
 - → Push and hold the buttons for more than 4 seconds.
- **3** Push the [△] / [✓] button to select "7. DN setting" on the "Field setting menu" screen, then push the "[□] Set"
- 4 Push the unit to confirm the address of indoor unit.
 - → The selected unit changes as follows each time the button is pushed:




- **5** Push the [\square Set/Fix]
 - → The setting display for the selected unit appears.
 - → When the group control is used, the fan and louver of the selected indoor unit operate.
- 6 Push the [MENU] button to set the other Code(DN) and Data. After "Continue?" is displayed on the screen, push the [⑤ Return] to finish the setting operation. " ☒ Setting" appears on the screen for a while, then the screen returns to the "Field setting menu" screen.





Address is displayed here.




◆ Check code clearing function


How to clear the check code using the wired remote controller

<RBC-AW5U52-UL>

Displays the last 10 check codes, and at which unit and when they occurred.







NOTE

- The check code history data shows a history of 10 occurrences. If the occurrences exceed 10, the oldest data is deleted.
- If the same check code occurs repeatedly, the date of the first occurrence is displayed.

Deleting check code history



1 Press [■ Menu] while the "Alarm history" screen is displayed

→ "Reset all alarm data." is displayed.

2 Press [Set/Fix]

REQUIREMENT

If you are using 2 remote controllers, delete the history at each remote controller.

▼ Monitoring function of wired remote controller

<RBC-AWSU52-UL>

Displays the codes and data indicating the operating condition and temperature of each sensor on the indoor units, outdoor units, and remote controllers.

| Monitor | function |
|-----------------|----------|
| Code | Data |
| 0.0 | 0024 |
| | |
| ⊅ Return | ^~ |

| 1 | In the "Field setting menu" screen, press |
|---|---|
| | [$	riangle$] and [$	riangle$] to select "Monitor function", |
| | and then press [|

- → In a group connection, after a selection in the unit selection screen, move to the "Monitor function" screen.

2 Press [S Return]

→ Return to the "Field setting menu" screen.

♦ Indoor service monitor list

| | Code No. | Data name | Display format | Unit | Remote controller display example |
|--------|--|--|----------------|--------|-----------------------------------|
| | 00 | Room temperature (Use to control) | ×1 | °F(°C) | |
| | 01 | Room temperature (Remote controller) | ×1 | °F(°C) | |
| | 02 | Indoor suction air temperature (TA) | ×1 | °F(°C) | |
| | 03 | Indoor coil temperature (TCJ) | ×1 | °F(°C) | |
| data * | 04 | Indoor coil temperature (TC2) | ×1 | °F(°C) | |
| | 05 | Indoor coil temperature (TC1) | ×1 | °F(°C) | |
| r unit | 06 | Indoor discharge air temperature (TF) ** | ×1 | °F(°C) | |
| Indoor | 07 | Indoor fan motor number of revolutions** | ×1 | rpm | [0600] = 600rpm |
| = | 08 | Indoor PMV opening | ×1/10 | pls | [0150]=1500pls |
| | F3 | Filter sign time | ×1 | h | [2500] = 2500h |
| | F9 Suction temperature of air to air heat exchanger (TSA) ** | | ×1 | °F(°C) | [0024] = 75.2°F(24°C) |
| | FA Outside air temperature (TOA) ** | | ×1 | °F(°C) | , , |

^{*} When the units are connected to a group, data of the header indoor unit only can be displayed.

^{**} There is also a model which cannot be displayed.

[•] Refer to the service manual of an outdoor unit for "outdoor service monitor list".

10. TROUBLESHOOTING

10-1. Overview

- (1) Before engaging in troubleshooting
 - (a) Applicable models

All Super Modular Multi System (SMMS-*) models.

(Indoor units: MM*-UB***, Outdoor units: MMY-MUB***)

- (b) Tools and measuring devices required
 - Screwdrivers (Philips, flat head), spanners, long-nose pliers, nipper, pin to push reset switch, etc.
 - Multimeter, thermometer, pressure gauge, etc.
- (c) Things to check prior to troubleshooting (behaviors listed below are normal)

| NO. | Behavior | Possible cause |
|-----|--|--|
| 1 | A compressor would not start | The air conditioner is being controlled by the 3-minute protective function. It is in standby status though the room temperature has reached the setup temperature. It is being operated in timer mode or fan mode. It is being in initial communication. |
| 2 | An indoor fan would not start | The air conditioner is being controlled by the cool air discharge preventive function in "heating"? |
| 3 | An outdoor fan would not start or would change speed for no reason | The air conditioner is being operated in "cooling" under the low outside air temperature. It is being operated in defrost operation. |
| 4 | An indoor fan would not stop | The air conditioner is being controlled by function of residual heat elimination being performed as part of the air conditioner shutdown process after heating operation. |
| 5 | The air conditioner would not respond to a start/stop command from a remote controller | The air conditioner is being operated under external or remote controller. |




CAUTION

The cooling performance may be declining considerably when total operating capacity of cooling indoor units is less than 4 HP while ambient temperature is below.

(2) Troubleshooting procedure

When a problem occurs, proceed with troubleshooting in accordance with the procedure shown below.



NOTE

Rather than a product trouble (see the List of Check Codes below), the problem could have been caused by a microprocessor malfunction attributable to a poor quality of the power source or an external noise. Check for possible noise sources, and shield the remote controller wiring and signal wires as necessary.

10-2. Troubleshooting method

The remote controllers (main remote controller and central control device) and the interface P.C. board of an outdoor unit are provided with an a 7-segment display (outdoor interface P.C. board) to display operational status. Using this self-diagnosis feature, the trouble site / trouble part may be identified in the event of a trouble by following the method described below.

The list below summarizes check codes detected by various devices. Analyze the check code according to where it is displayed and work out the nature of the trouble in consultation with the list.

- · When investigating a trouble on the basis of a display provided on the indoor remote controller or central control device - See the "central control device or main remote controller display" section of the list.
- When investigating a trouble on the basis of a display provided on an outdoor unit See the "Outdoor 7segment display" section of the list.
- · When investigating a trouble on the basis of a wireless remote controller-controlled indoor unit See the "Indicator light block" section of the list.

List of check codes (indoor unit)

(Check code detected by indoor unit)

IPDU: Compressor / Fan inverter P.C. board

O: Lighting, (i): Flashing, iii Goes off
ALT.: Flashing is alternately when there are two flashing LED
SIM: Simultaneous flashing when there are two flashing LED

| | Ch | eck code | Display | y of re | ceiving | g unit | J | Simultaneous flashing when there are two flashing LED |
|---------------------------------|------|---------------------------|----------|---------|---------|--------|---|---|
| Bernete | Outo | loor 7-segment display | Indic | ator li | ght bl | ock | | |
| Remote controller display | | Sub-code | Operatio | n Timer | Ready | Flash | Typical trouble on site | Description of check code |
| E03 | _ | _ | 0 | • | | | Indoor-remote controller periodic communication check code | Communication from remote controller or network adaptor has been lost (so has central control communication). |
| E04 | _ | _ | • | • | 0 | | Indoor-outdoor periodic communication check code | Signals are not being received from outdoor unit. |
| E08 | E08 | Duplicated indoor address | 0 | | • | | Duplicated indoor address | Indoor unit detects address identical to its own. |
| E10 | _ | _ | 0 | • | • | | Communication trouble between indoor unit MCU | Communication trouble between main MCU and the motor microcomputer MCU |
| E11 | _ | _ | 0 | | • | | Communication check code between Application control kit and indoor unit | Communication check code between Application control kit and indoor unit P.C. board |
| E18 | _ | _ | 0 | • | • | | Check cod in periodic communication between indoor header and follower unit | Periodic communication between indoor header and follower units cannot be maintained. |
| F01 | _ | _ | 0 | 0 | • | ALT | Indoor heat exchanger temperature sensor (TCJ) check code | Heat exchanger temperature sensor (TCJ) has been open / short-circuit. |
| F02 | _ | - | 0 | 0 | • | ALT | Indoor heat exchanger temperature sensor (TC2) check code | Heat exchanger temperature sensor (TC2) has been open / short-circuit. |
| F03 | _ | - | 0 | 0 | • | ALT | Indoor heat exchanger temperature sensor (TC1) check code | Heat exchanger temperature sensor (TC1) has been open / short-circuit. |
| F10 | _ | _ | 0 | 0 | | ALT | Ambient temperature sensor (TA) check code | Ambient temperature sensor (TA) has been open / short-circuit. |
| F11 | _ | _ | 0 | 0 | • | ALT | Discharge temperature sensor (TF) check code | Discharge temperature sensor (TF) has been open / short-circuit. |
| F29 | _ | _ | 0 | 0 | • | SIM | P.C. board or other indoor check code | Indoor EEPROM is abnormal (some other trouble may be detected). |
| F30 | _ | _ | 0 | 0 | 0 | ALT | Occupancy sensor trouble | Occupancy sensor trouble has been detected. |
| L03 | _ | _ | 0 | • | 0 | SIM | Duplicated indoor group header unit | There is more than one header unit in group. |
| L07 | _ | _ | 0 | • | 0 | SIM | Connection of group control cable to a single indoor unit | There is at least one a single indoor unit to which group control cable is connected. |
| L08 | L08 | - | 0 | • | 0 | SIM | Indoor group address not set | Address setting has not been performed for one or more indoor units (also detected at outdoor unit end). |
| L09 | _ | _ | 0 | | 0 | SIM | Indoor capacity not set | Capacity setting has not been performed for indoor unit. |
| L20 | _ | _ | 0 | 0 | 0 | SIM | Duplicated central control address | There is duplication in central control address setting. |
| L30 | L30 | Detected indoor unit No. | 0 | 0 | 0 | SIM | Indoor external check code input (interlock) | Unit shutdown has been caused by external check code input (CN80). |
| P01 | _ | - | • | 0 | 0 | ALT | Indoor AC fan check code | Indoor AC fan check code is detected (activation of fan motor thermal relay). |
| P10 | P10 | Detected indoor unit No. | | 0 | 0 | ALT | Indoor overflow check code | Float switch has been activated. |
| P12 | _ | _ | • | 0 | 0 | ALT | Indoor DC fan check code | Indoor DC fan check code (e.g. overcurrent or lock-up) is detected. |
| P31 | _ | _ | 0 | | 0 | ALT | Other indoor unit check code | Follower unit cannot be operated due to header unit alarm (E03 /L03 / L07 / L08). |

(Check code detected by remote controller)

| Che | Check code | | | | | g unit | | | |
|----------------|------------|------------------------|-----------------------|-------|-------|--------|--|--|--|
| | Outo | loor 7-segment display | Indicator light block | | | | Typical trouble site | Description of trouble | |
| Remote control | | Sub-code | Operation (1) | Timer | Ready | Flash | Typical trouble site | bescription of trouble | |
| E01 | - | - | 0 | • | • | | No master remote control, failure remote control communication (reception) | Signals cannot be received from indoor unit; master remote control has not been set (including two remote control). | |
| E02 | - | - | 0 | • | • | | Failure remote control communication (transmission) | Signals cannot be transmitted to indoor unit. | |
| E09 | - | - | 0 | • | • | | Duplicated master remote control | Both remote controls have been set as master remote control in two remote control (alarm and shutdown for header unit and continued operation for follower unit) | |

(Check code detected by central control device)

| Che | eck co | ode | Display of reco | eiving | unit | | | |
|-----------------|--------|------------------------|-------------------|--------|-------|---|--|--|
| | Outo | loor 7-segment display | Indicator lig | ht blo | ck | Typical trouble site | Decement on of two while | |
| Central control | | Sub-code | Operation Timer F | Ready | Flash | Typical trouble site | Description of trouble | |
| C05 | - | - | No indication (| | | Failure central control communication (transmission) | Central control device is unable to transmit signal due to duplication of central control device | |
| C06 | - | - | also in use) | | | Failure central control communication (reception) | Central control device is unable to receive signal. | |
| C12 | - | - | - | | | Bracket alarm for general- purpose device control interface | Device connected to general-purpose device control interface is trouble. | |
| P30 (L20) | - | - | (L20 is display | ved.) | | Communication Link | Duplication addresses of indoor units in central control device With the combination of air conditioning system, the indoor unit may detect the check code of L20 | |

Note: The same trouble, e.g. a communication trouble, may result in the display of different check codes depending on the device that detects it. Moreover, check codes detected by the main remote controller / central control device do not necessarily have a direct impact on air conditioner operation.

Flow selector unit (FS unit) Relation

(Check code detected by indoor unit)

| Che | Check code | | | | | | | | |
|---------------------|------------|------------------------|---------------|--------|----------|-------|---|--|--|
| | Outo | loor 7-segment display | Indica | ator I | ight blo | ock | Typical trouble site | Description of trouble | |
| Main remote control | | Sub-code | Operation (1) | Timer | Ready | Flash | Typical trouble site | Description of trouble | |
| E17 | - | - | 0 | • | • | | Communication trouble between indoor unit (s) and FS unit (s) | There is no communication from FS unit(s) | |
| J03 | - | - | • | 0 | 0 | | Duplicated FS units | More than one FS units have been set up in one refrigerant line. | |
| J10 | - | - | • | 0 | 0 | | FS unit overflow trouble | FS unit has been shutdown in one refrigerant line due to detection of overflow | |
| J11 | - | - | • | 0 | 0 | | FS unit temperature sensor (TCS) trouble | FS unit temperature sensor (TCS) has been open/short-circuited. | |
| L12 | L12 | - | 0 | 0 | 0 | | FS unit(s) system trouble | FS unit(s) outside the application setting | |

List of Check Codes (Outdoor Unit)

(Check code detected by outdoor interface - typical examples)

If "HELLO" is displayed on the oudoor 7-segment for 1 minute or more, turn off the power supply once and then turn on the power supply again after passage of 30 seconds or more. When the same symptom appears, it is considered there is a possibility of I/F board trouble.

 \bigcirc : Lighting, \bigcirc : Flashing, \bigcirc : Goes off ALT.: Flashing is alternately when there are two flashing LED

SIM: Simultaneous flashing when there are two flashing LED Check code Display of receiving unit

| | Outdoor 7-segment display | Central | Indic | ator li | ght blo | ock | | Description of problem | |
|-----|---|--|-----------|---------|---------|-------|--|---|--|
| | Sub-code | control or main remote controller display | Operation | Timer | Ready | Flash | Typical problem site | | |
| E06 | Number of indoor units from which signal is received normally | E06 | • | • | 0 | | Signal lack of indoor unit | Indoor unit initially communicating normally fails to return signal (reduction in number of indoor units connected). | |
| E07 | - | (E04) | • | • | 0 | | Indoor-outdoor communication circuit trouble | Signal cannot be transmitted to indoor units (→ indoor units left without communication from outdoor unit). | |
| E08 | Duplicated indoor address | (E08) | 0 | • | • | | Duplicated indoor address | More than one indoor unit are assigned same address (also detected at indoor unit end). | |
| E12 | 01: Indoor-outdoor communication 02: Outdoor-outdoor communication | E12 | 0 | • | • | | Automatic address starting trouble | Indoor automatic address setting is started while automatic address setting for equipment in other refrigerant line is in progress. Outdoor automatic address setting is started while automatic address setting for indoor units is in progress. | |
| E15 | - | E15 | • | • | 0 | | Indoor unit not found during automatic address setting | Indoor unit fails to communicate while automatic address setting for indoor units is in progress. | |
| E16 | 00: Capacity over 01: Number of units connected | E16 | • | • | 0 | | Too many indoor units connected/capacity over | Combined capacity of indoor units is too large. The maximum combined of indoor units shown in the specification table. | |
| E19 | 00: No header unit 02: Two or more header units | E19 | • | • | 0 | | Trouble in number of outdoor header units | There is no or more than one outdoor header unit in one refrigerant line. | |
| E20 | 01: Connection of outdoor unit from other refrigerant line 02: Connection of indoor unit from other refrigerant line | E20 | • | • | 0 | | Connection to other refrigerant line found during automatic address setting | Indoor unit from other refrigerant line is detected while indoor automatic address setting is in progress. | |
| E23 | - | E23 | • | • | 0 | | Outdoor-outdoor communication transmission trouble | Signal cannot be transmitted to other outdoor units. | |
| E25 | - | E25 | • | • | 0 | | Duplicated follower outdoor address | There is duplication in outdoor addresses set manually. | |
| E26 | Address of outdoor unit from which signal is not received normally | E26 | • | • | 0 | | Signal lack of outdoor unit | Follower outdoor unit initially communicating normally fails to do so (reduction in number of follower outdoor units connected). | |
| E28 | Detected outdoor unit No. | E28 | • | • | 0 | | Outdoor follower unit trouble | Outdoor header unit detects trouble relating to follower outdoor unit (detail displayed on follower outdoor unit). | |
| E31 | P.C. board Compressor Fan Motor 1 2 | E31 | • | • | 0 | | P.C. board communication trouble Sub MCU communication trouble | There is no communication between P.C. boards in inverter box. | |
| F04 | - | F04 | 0 | 0 | 0 | ALT | Outdoor discharge temperature sensor (TD1) trouble | Outdoor discharge temperature sensor (TD1) has been open/short-circuited. | |
| F05 | - | F05 | 0 | 0 | 0 | ALT | Outdoor discharge temperature sensor (TD2) trouble | Outdoor discharge temperature sensor (TD2) has been open/short-circuited. | |
| F06 | 01: TE1 sensor 02: TE2 sensor 03: TE3 sensor | F06 | 0 | 0 | 0 | ALT | Outdoor heat exchanger liquid side temperature sensor (TE1, TE2, TE3) trouble | Outdoor heat exchanger liquid side temperature sensors (TE1, TE2, TE3) have been open/ short-circuited. | |
| F07 | 01: TL1 sensor 02: TL2 sensor 03: TL3 sensor | F07 | 0 | 0 | 0 | ALT | Outdoor liquid temperature sensor (TL1,TL2,TL3) trouble | Outdoor liquid temperature sensor (TL1,TL2,TL3) has been open/short-circuited. | |
| F08 | - | F08 | 0 | 0 | 0 | ALT | Outdoor outside air temperature sensor (TO) trouble | Outdoor air temperature sensor (TO) has been open/short-circuited. | |
| F09 | 01: TG1 sensor 02: TG2 sensor 03: TG3 sensor | F09 | 0 | 0 | 0 | ALT | Outdoor heat exchanger gas side temperature sensor (TG1, TG2, TG3) trouble | Outdoor heat exchanger gas side temperature sensors (TG1, TG2, TG3) have been open/short-circuited. | |

| Check code | | | Display of receiving unit | | | g unit | | | |
|------------|---|--|---------------------------|---------|---------|--------|---|---|--|
| | Outdoor 7-segment display | Central | Indica | ator li | ght ble | ock | | | |
| | Sub-code | control or main remote controller display | Operation (1) | Timer | Ready | Flash | Typical problem site | Description of problem | |
| F12 | 01: TS1 sensor 03: TS3 sensor | F12 | 0 | © © | 0 | ALT | Outdoor suction temperature sensor (TS1,TS3) trouble | Outdoor suction temperature sensor (TS1,TS3) has been open/short-circuited. | |
| F15 | - | F15 | 0 | 0 | 0 | ALT | Outdoor temperature sensor (TE1,TL1) wiring trouble | Wiring trouble in outdoor temperature sensors (TE1,TL1) has been detected. | |
| F16 | - | F16 | 0 | 0 | 0 | ALT | Outdoor pressure sensor (Pd, Ps) wiring trouble | Wiring trouble in outdoor pressure sensors (Pd, Ps) has been detected. | |
| F23 | - | F23 | 0 | 0 | 0 | ALT | Low pressure sensor (Ps) trouble | Output voltage of low pressure sensor (Ps) is zero. | |
| F24 | - | F24 | 0 | 0 | 0 | ALT | High pressure sensor (Pd) trouble | Output voltage of high pressure sensor (Pd) is zero or provides abnormal readings when compressors have been turned off. | |
| F31 | - | F31 | 0 | 0 | 0 | SIM | Outdoor EEPROM trouble | Outdoor EEPROM is failure (alarm and shutdown for header unit and continued operation for follower unit) | |
| J29 | - | J29 | • | 0 | 0 | SIM | Leak Detector Trouble | There is no communication from Leak Detector A Malfunction signal received from Leal Detector. | |
| J30 | Detected indoor unit address *Not displayed depending on the DN code (I.DN) setting | J30 | • | 0 | 0 | SIM | Refrigerant leak detection | Leak Detector detects refrigerant leak | |
| J31 | - | J31 | • | 0 | 0 | SIM | Refrigerant leak detection sensor exceeding its life of the product | Energization time of the Leak Detector has reached its useful life. | |
| H05 | - | H05 | • | 0 | • | | Outdoor discharge temperature sensor (TD1) wiring trouble | Wiring/installation trouble or detachment of outdoor discharge temperature sensor (TD1) has been detected. | |
| H06 | _ | H06 | • | 0 | • | | Activation of low-pressure protection | Low pressure (Ps) sensor detects abnormally low operating pressure. | |
| H07 | - | H07 | • | 0 | • | | Low oil level protection | Temperature sensor for oil level detection (TK1,TK2) detects abnormally low oil level. | |
| H08 | 01: TK1 sensor trouble 02: TK2 sensor trouble | H08 | • | © | • | | Trouble in temperature sensor for oil level detection (TK1,TK2) | Temperature sensor for oil level detection (TK1,TK2) has been open/short-circuited. | |
| H15 | - | H15 | • | 0 | • | | Outdoor discharge temperature sensor (TD2) wiring trouble | Wiring/installation trouble or detachment of outdoor discharge temperature sensor (TD2) has been detected. | |
| H16 | 01: TK1 oil circuit trouble 02: TK2 oil circuit trouble | H16 | • | 0 | • | | Oil level detection circuit trouble | No temperature change is detected by temperature sensor for oil level detection (TK1,TK2) despite compressor having been started. | |
| L04 | - | L04 | 0 | 0 | 0 | SIM | Duplicated outdoor refrigerant line address | Identical refrigerant line address has been assigned to outdoor units belonging to different refrigerant piping systems. | |
| | Number of priority indoor units | L05 | 0 | • | 0 | SIM | Duplicated priority indoor unit (as displayed on priority indoor unit) | More than one indoor unit have been set up as priority indoor unit. | |
| L06 | (check code L05 or L06 depending on individual unit) | L06 | 0 | • | 0 | SIM | Duplicated priority indoor unit (as displayed on indoor unit other than priority indoor unit) | More than one indoor unit have been set up as priority indoor unit. | |
| L08 | - | (L08) | 0 | • | 0 | SIM | Indoor group address not set | Address setting have not been performed for one or more indoor units (also detected at indoor end). | |
| L10 | _ | L10 | 0 | 0 | 0 | SIM | Outdoor capacity not set | Outdoor unit capacity has not been set (after P.C. board replacement). | |
| L17 | _ | L17 | 0 | 0 | 0 | SIM | Outdoor model incompatibility trouble | Old model outdoor unit has been connected. | |
| L23 | - | L23 | 0 | 0 | 0 | SIM | SW setting mistake | | |
| L28 | _ | L28 | 0 | 0 | 0 | SIM | Too many outdoor units connected | More than five outdoor units have been connected. | |

| | Check code | | Display of receiving unit | | | | | |
|-----|--|--------------------------------------|---------------------------|---------|---------|-------|--|--|
| | Outdoor 7-segment display | Central control or | Indica | ator li | ght blo | ock | Typical problem site | Description of problem |
| | Sub-code | main remote controller display | Operation (1) | Timer | Ready | Flash | Typical problem site | bescription of problem |
| L29 | P.C.board Compressor Fan Motor 1 2 | L29 | © | 0 | 0 | SIM | Trouble in number of P.C. boards | There are insufficient number of P.C. board in inverter box. |
| L30 | Detected indoor unit No. | (L30) | 0 | 0 | 0 | SIM | Indoor external trouble input (interlock) | Indoor unit has been shut down for external trouble input in one refrigerant line (detected by indoor unit). |
| P03 | - | P03 | 0 | • | 0 | ALT | Outdoor discharge (TD1) temperature trouble | Outdoor discharge temperature sensor (TD1) has detected abnormally high temperature. |
| P05 | 00: Power detection trouble 01: Open phase 02: Power supply miswiring | P05 | 0 | • | 0 | ALT | Power detection trouble /Open phase detection /Power supply miswiring detection | Open phase is detected when power is turned on. Inverter DC voltage is too high (overvoltage) or too low (undervoltage). |
| D07 | 1 : Compressor 1 heat sink trouble 2 : Compressor 2 heat sink trouble | D07 | | | | A . F | Heat sink overheating trouble | Temperature sensor built into IPM (TH) detects overheating. |
| P07 | 04: Heat sink dew condensation | P07 | 0 | | 0 | ALT | Heat sink dew condensation trouble | Outdoor liquid temperature sensor (TL2) has detected abnormally low temperature. |
| P10 | Indoor unit No. detected | (P10) | • | 0 | 0 | ALT | Indoor unit overflow | Indoor unit has been shutdown in one refrigerant line due to detection of overflow (detected by indoor unit). |
| P11 | _ | P11 | • | 0 | 0 | ALT | Outdoor heat exchanger freeze trouble | Remaining frost on outdoor heat exchanger has been detected repeatedly. |
| P13 | - | P13 | • | 0 | 0 | ALT | Outdoor liquid backflow detection trouble | State of refrigerant cycle circuit indicates liquid backflow operation. |
| P15 | P15 01: TS condition 02: TD condition | | 0 | • | 0 | ALT | Gas leak detection | Outdoor suction temperature sensor (TS1) detects sustained and repeated high temperatures that exceed standard value. |
| P17 | P17 – | | 0 | • | 0 | ALT | Outdoor discharge (TD2) temperature trouble | Outdoor discharge temperature sensor (TD2) detects abnormally high temperature. |
| P19 | P19 Outdoor unit No. detected | | 0 | • | 0 | ALT | 4-way valve reversing trouble | Abnormality in refrigerating cycle is detected during heating operation. |
| P20 | - | P20 | 0 | • | 0 | ALT | Activation of high-pressure protection | High pressure (Pd) sensor detects high pressure that exceeds standard value. |

MG-CTT: Magnet contactor


(Check code detected by Inverter of Compressor featuring in outdoor unit - typical examples)


| | Check code | | | | ceiving | unit | | |
|-----|--|--------------------------------------|---------------|---------|---------|-------|--|---|
| | Outdoor 7-segment display | Central control or | Indica | ator li | ght blo | ock | Typical problem site | Description of proplem |
| | Sub-code | main remote controller display | Operation (1) | Timer | Ready | Flash | Typical problem site | Description of propient |
| F13 | 1*: Compressor 1 2*: Compressor 2 | F13 | 0 | 0 | 0 | ALT | Trouble in temperature sensor built into indoor IPM (TH) | Temperature sensor built into indoor IPM (TH) has been open/short-circuited. |
| H01 | 1*: Compressor 1 2*: Compressor 2 | H01 | • | 0 | • | | Compressor breakdown | Inverter current (Idc) detection circuit detects overcurrent. |
| H02 | 1*: Compressor 1 2*: Compressor 2 | H02 | • | 0 | • | | Compressor trouble (lockup) | Compressor lockup is detected |
| H03 | 1*: Compressor 1 2*: Compressor 2 | H03 | • | 0 | • | | Current detection circuit trouble | Abnormal current is detected while inverter compressor is turned off. |
| P04 | 01: Compressor 1 02: Compressor 2 | P04 | 0 | • | 0 | ALT | Activation of high-pressure SW | High-pressure SW is activated. |
| P05 | 01: Compressor 1 side 02: Compressor 2 side | P05 | 0 | • | 0 | ALT | Compressor Vdc trouble | Inverter DC voltage is too high (overvoltage) or too low (undervoltage). |
| P07 | 01: Compressor 1 side 02: Compressor 2 side | P07 | 0 | • | 0 | ALT | Heat sink overheat trouble | Temperature sensor built into IPM (TH) detects overheating. |
| P11 | - | P11 | • | 0 | 0 | ALT | Outdoor heat exchanger freeze trouble | Remaining frost on outdoor heat exchanger has been detected repeatedly. |
| P22 | 1*: Fan P.C. board 1 2*: Fan P.C. board 2 | P22 | 0 | • | 0 | ALT | Outdoor fan P.C. board trouble | Outdoor fan P.C. board detects trouble. |
| P26 | 1*: Compressor 1 2*: Compressor 2 | P26 | 0 | • | 0 | ALT | Activation of IPM, compressor short-circuit protection | Short-circuit protection for compressor motor driver circuit components is activated (momentary overcurrent). |
| P29 | 1*: Compressor 1 2*: Compressor 2 | P29 | 0 | • | 0 | ALT | Compressor position detection circuit trouble | Compressor motor position detection trouble is detected. |

Note: The above check codes are examples only, and different check codes may be displayed depending on the outdoor unit configuration

10-3. Troubleshooting by check Display on Remote Controller

<RBC-AWSU52-UL>





When an error occurs in the air conditioner, the check code and the indoor unit number flash on the display of the remote controller.

The check code is only displayed during the operation.


When the check code and indoor unit number are displayed, pressing [Return] opens the "Check" screen.

In the "Check" screen, press [Set/Fix] to show the contacts.

Press [Menu] to display "Model information".

■ Contact information for repairs

You can look for contact information for repairs.



In the "Information" screen, press [] and [] to select "Service information", and then press [Set/Fix]

Using indoor unit indicators (receiving unit light block) (wireless type)

To identify the check code, check the 7-segment display on the header unit. To check for check codes not displayed on the 7-segment display, consult the "List of Check Codes (Indoor Unit)" in "10-2. Troubleshooting method".

■: Goes off ○: Lighting -: Blinking (0.5 seconds)

| Light block | Check code | ode Cause of trouble | | | | | | | |
|--|------------|--|--|-------------------------------|--|--|--|--|--|
| Operation Timer Ready All lights out | - | Power turned off or trouble in wiring | Power turned off or trouble in wiring between receiving and indoor units | | | | | | |
| Operation Timer Ready | E01 | Trouble reception | Trouble or poor contact in | | | | | | |
| | E02 | Trouble transmission | Receiving unit | wiring between receiving unit | | | | | |
| - - | E03 | Loss of communication | | and indoor units | | | | | |
| Blinking | E08 | Duplicated indoor unit No. (addr | ress) | Setting trouble | | | | | |
| | E09 | Duplicated master remote control | oller | Cetting trouble | | | | | |
| | E10 | Communication trouble between | n indoor unit MCU | | | | | | |
| | E11 | Communication trouble between | Application control kit and indo | or unit P.C. board | | | | | |
| | E12 | Automatic address starting troul | ole | | | | | | |
| | E18 | Trouble or poor contact in wiring | between indoor units, indoor po | wer turned off | | | | | |
| Operation Timer Ready | E04 | Trouble or poor contact in wiring (loss of indoor-outdoor commun | g between indoor and outdoor un ication) | its | | | | | |
| • • -\bar{\bar{\bar{\bar{\bar{\bar{\bar{ | E06 | Trouble reception in indoor-outd | loor communication (dropping ou | it of indoor unit) | | | | | |
| Blinking | E07 | Trouble transmission in indoor-o | outdoor communication | | | | | | |
| 5 | E15 | Indoor unit not found during auto | omatic address setting | | | | | | |
| | E16 | Too many indoor units connected | ed / overloading | | | | | | |
| | E19 | Trouble in number of outdoor he | eader units | | | | | | |
| | E20 | Detection of refrigerant piping communication trouble during automatic address setting | | | | | | | |
| | E23 | Trouble transmission in outdoor-outdoor communication | | | | | | | |
| | E25 | Duplicated follower outdoor address | | | | | | | |
| | E26 | Trouble reception in outdoor-out | ele reception in outdoor-outdoor communication, dropping out of outdoor unit | | | | | | |
| | E28 | Outdoor follower unit trouble | | | | | | | |
| | E31 | P.C. board communication troub | uble | | | | | | |
| Operation Timer Ready | P01 | Indoor AC fan trouble | Indoor AC fan trouble | | | | | | |
| | P10 | Indoor overflow trouble | | | | | | | |
| ~ ~ ~ | P11 | Outdoor heat exchanger freezin | g trouble | | | | | | |
| Alternate blinking | P12 | Indoor DC fan trouble | | | | | | | |
| | P13 | Outdoor liquid backflow detection | on trouble | | | | | | |
| | P03 | Outdoor discharge (TD1) tempe | rature trouble | | | | | | |
| Operation Timer Ready | P04 | Activation of outdoor high-press | ure SW | | | | | | |
| Alternate blinking | P05 | Open phase / power failure Inverter DC voltage (Vdc) troubl MG-CTT trouble | е | | | | | | |
| J | P07 | Outdoor heat sink overheating to outdoor unit | rouble - Poor cooling of electrical | component (IGBT) of | | | | | |
| | P15 | Gas leak detection - insufficient | refrigerant charging | | | | | | |
| | P17 | Outdoor discharge (TD2) tempe | rature trouble | | | | | | |
| | P18 | Outdoor discharge (TD3) tempe | rature trouble | | | | | | |
| | P19 | Outdoor 4-way valve reversing t | rouble | | | | | | |
| | P20 | Activation of high-pressure prote | ection | | | | | | |
| | P22 | Outdoor fan P.C. board trouble | | | | | | | |
| | P26 | Outdoor IPM, Compressor short | t-circuit trouble | | | | | | |
| | P29 | Compressor position detection of | circuit trouble | | | | | | |
| | P31 | Shutdown of other indoor unit in | group due to trouble (group follo | ower unit trouble) | | | | | |

MG-CTT: Magnet contactor

| Light block | Check code | Cause of trouble | | | | | | | |
|-----------------------|------------|--|---|--|--|--|--|--|--|
| Operation Timer Ready | F01 | Heat exchanger temperature sensor (TCJ) trouble | | | | | | | |
| | F02 | Heat exchanger temperature sensor (TC2) trouble | Indoor unit temperature | | | | | | |
| | F03 | Heat exchanger temperature sensor (TC1) trouble | sensor trouble | | | | | | |
| Alternate blinking | F10 | Ambient temperature sensor (TA) trouble | | | | | | | |
| | F11 | Discharge temperature sensor (TF) trouble | | | | | | | |
| Operation Timer Ready | F04 | Discharge temperature sensor (TD1) trouble Discharge | | | | | | | |
| -66-0 | F05 | temperature sensor (TD2) trouble Heat exchanger temperature sensor (TE1, TE2) trouble | | | | | | | |
| | F06 | | | | | | | | |
| Alternate blinking | F07 | Liquid temperature sensor (TL) trouble Outdoor unit temperature sensor (TO) trouble | | | | | | | |
| | F08 | Outside air temperature sensor (TO) trouble | | | | | | | |
| | F09 | TG1,TG2 or TG3 sensor trouble | | | | | | | |
| | F12 | Suction temperature sensor (TS1) trouble | | | | | | | |
| | F13 | Heat sink sensor (TH) trouble | (71) | | | | | | |
| | F15 | Wiring trouble in heat exchanger sensor (TE1) and liquid temper Outdoor unit temperature sensor wiring / installation trouble | , | | | | | | |
| | F16 | Wiring trouble in outdoor high pressure sensor (Pd) and low pres Outdoor pressure sensor wiring trouble | ssure sensor (Ps) | | | | | | |
| | F22 | Outdoor discharge temperature sensor (TD3) trouble | | | | | | | |
| | F23 | Low pressure sensor (Ps) trouble | | | | | | | |
| | F24 | High pressure sensor (Pd) trouble | Outdoor unit pressure sensor trouble | | | | | | |
| | F30 | Occupancy sensor trouble | | | | | | | |
| | F31 | Indoor unit EEPROM trouble | | | | | | | |
| Operation Timer Ready | F29 | Failure in indoor EEPROM | | | | | | | |
| | H01 | Compressor breakdown | | | | | | | |
| Operation Timer Ready | H02 | Compressor lockup | Outdoor unit compressor related trouble | | | | | | |
| • - <u>Q</u> - | H03 | Current detection circuit trouble | Totaled trouble | | | | | | |
| Blinking | H04 | Comp. 1 case thermostat operation | | | | | | | |
| | H05 | Wiring / installation trouble or detachment of outdoor discharge to | emperature sensor (TD1) | | | | | | |
| | H06 | Abnormal drop in low-pressure sensor (Ps) reading | Protective shutdown of outdoor | | | | | | |
| | H07 | Abnormal drop in oil level | unit | | | | | | |
| | H08 | Trouble in temperature sensor for oil level detection circuit (TK1, | TK2, TK3, TK4 or TK5) | | | | | | |
| | F14 | Comp. 2 case thermostat operation | | | | | | | |
| | H15 | Wiring / installation trouble or detachment of outdoor discharge t | . , , | | | | | | |
| | H16 | Oil level detection circuit trouble - Trouble in outdoor unit TK1, T | | | | | | | |
| | H25 | Wiring / installation trouble or detachment of outdoor discharge t | emperature sensor (TD3) | | | | | | |
| Operation Timer Ready | J29 | Leak Detector trouble | | | | | | | |
| • -QQ- | J30 | Refrigerant leak detection | | | | | | | |
| Blinking Blinking | J31 | Refrigerant leak detection sensor has reached product life | | | | | | | |
| Operation Timer Ready | L02 | Model mismatched of indoor and outdoor unit | | | | | | | |
| <u>-\</u> | L03 | Duplicated indoor group header unit | | | | | | | |
| | L05 | Duplicated priority indoor unit (as displayed on priority indoor unit | | | | | | | |
| Synchronized blinking | L06 | Duplicated priority indoor unit (as displayed on indoor unit other | than priority indoor unit) | | | | | | |
| | L07 | Connection of group control cable to a single indoor unit | | | | | | | |
| | L08 | Indoor group address not set | | | | | | | |
| | L09 | Indoor capacity not set | | | | | | | |
| Operation Timer Ready | L04 L10 | Duplicated outdoor refrigerant line address | | | | | | | |
| <u>-``</u> Ö- | L10 | Outdoor capacity not set Outdoor model incompatibility trouble | | | | | | | |
| | L17 | Flow selector units trouble | | | | | | | |
| Synchronized blinking | L20 | Duplicated central control address | | | | | | | |
| | L28 | Too many outdoor units connected | | | | | | | |
| | L29 | Trouble in number of P.C. boards | | | | | | | |
| | L30 | Indoor external interlock trouble (External abnormal input) | | | | | | | |
| | | | | | | | | | |

| Light block | Check code | Cause of trouble |
|-----------------------|------------|--------------------------|
| Operation Timer Ready | F30 | Occupancy sensor trouble |
| Synchronized blinking | F31 | Outdoor EEPROM trouble |

Other (indications not involving check code)

| Light block | Check code | Cause of trouble |
|-----------------------|------------|--|
| Operation Timer Ready | - | Test run in progress |
| Operation Timer Ready | - | Setting incompatibility (automatic cooling / heating setting for model incapable of it and heating setting for cooling-only model) |

Flow selector unit (FS unit) Relation

| Light block | Check code | Cause of trouble |
|---------------------------------|------------|---|
| Operation Timer Ready Blinking | E17 | Communication trouble between indoor unit(s) and FS unit(s) |
| Operation Timer Ready | L12 | FS unit(s) system trouble |
| Synchronized blinking | L24 | FS unit(s) setting trouble |
| Operation Timer Ready | J01 | Communication trouble between indoor unit(s) and FS unit (or SV unit) |
| ● -¤¤- | J02 | Communication trouble between control boards in FS unit |
| Blinking Blinking | J03 | Duplicated FS units |
| | J10 | FS unit overflow trouble |
| | J11 | FS unit temperature sensor(TCS) trouble |

10-4. Check Codes Displayed on Remote Controller and SMMS series Outdoor Unit (7-Segment Display on I/F Board) and Locations to Be Checked

For other types of outdoor units, refer to their own service manuals.

| | Check | code | | | | | |
|----------------------|------------|--|----------------------|--|----------------------------------|--|---|
| Main | | 7-segment display | Location of | Description | System status | Check code detection condition(s) | Check items (locations) |
| remote controller | Check code | Sub-code | detection | | - | condition(s) | |
| E01 | _ | _ | Remote controller | Indoor-remote controller communication trouble (detected at remote controller end) | Stop of corresponding unit | Communication between indoor P.C. board and remote controller is disrupted. | Check remote controller inter-unit tie cable (A/B). Check for broken wire or connector bad contact. Check indoor power supply. Check for failure in indoor P.C. board. Check remote controller address settings (when two remote controllers are in use). Check remote controller P.C. board. |
| E02 | _ | _ | Remote controller | Remote controller transmission trouble | Stop of corresponding unit | Signal cannot be transmitted from remote controller to indoor unit. | Check internal transmission circuit of remote controller. Replace remote controller as necessary. |
| E04 | _ | _ | Indoor unit | Indoor-outdoor communication circuit trouble (detected at indoor end) | Stop of corresponding unit | Indoor unit is not receiving signal from outdoor unit. | Check order in which power was turned on for indoor and outdoor units. Check indoor address setting. Check indoor-outdoor tie cable. Check outdoor terminator resistor setting (SW100, Bit 2). |
| E04 | E06 | No. of indoor units from which signal is received normally | I/F | Dropping out of indoor unit | All stop | Condition 1 All indoor unit initially communicating normally fails to return signal for specified length of time. Condition 2 Outdoor I / F board SW103, Bit4 : OFF (Factory default) | Check power supply to indoor unit. (Is power turned on?) Check connection of indoor-outdoor communication cable. Check connection of communication connectors on indoor P.C. board. Check connection of communication connectors on outdoor P.C. board. Check for failure in indoor P.C. board. Check for failure in outdoor P.C. board. Check for failure in outdoor P.C. board (I/F). |
| | _ | _ | Indoor unit | Indoor-outdoor communication circuit trouble | Only specified indoor units stop | Condition 1 Indoor unit initially communicating normally fails to return signal for specified length of time. | Check power supply to indoor unit. (Is power turned on?) Check indoor-outdoor power-on sequence. Check indoor address setting Check wiring of Indoor-outdoor communication wires Check outdoor terminator resistor setting (SW100, Bit 2). |

| | Check code | | | | | | |
|----------------------|------------|---|----------------------|--|----------------------------|---|--|
| | Outdoor | 7-segment display | Location of | Description | System status | Check code detection condition(s) | Check items (locations) |
| remote controller | Check code | Sub-code | detection | | | condition(s) | , |
| | | No. of indoor units from which signal is received normally | Indoor unit | Indoor-outdoor communication circuit trouble (E04) | All stop | Condition 1 One indoor unit or more initially communicating normally fails to return signal for specified length of time. Condition 2 Outdoor I / F board SW103, Bit4 : ON (To switch the check code detection condition.) | Check power supply to indoor unit. (Is power turned on?) Check indoor-outdoor power-on sequence. Check indoor address setting Check wiring of Indoor-outdoor communication wires Check outdoor terminator resistor setting (SW100, Bit 2). |
| E04/E06 | E06 | | I/F | Dropping out of indoor unit (E06) | | ON 1 2 3 4 | Check power supply to indoor unit. (Is power turned on?) Check connection of indoor-outdoor |
| | | | | | | Display on main remote controller. Indoor units unavailable for indoor / outdoor communication. :E04 Indoor units available for indoor / outdoor communication. : E06 | communication cable. Check connection of communication connectors on indoor P.C. board. Check connection of communication connectors on outdoor P.C. board. Check for failure in indoor P.C. board. Check for failure in outdoor P.C. board (I/F). |
| l | E07 | _ | I/F | Indoor-outdoor communication circuit trouble (detected at outdoor end) | All stop | Signal cannot be transmitted from outdoor to indoor units for 30 seconds continuously. | Check outdoor terminator resistor setting (SW100, Bit 2). Check connection of indoor-outdoor communication circuit. |
| E08 | E08 | Duplicated indoor address | Indoor unit I/F | Duplicated indoor address | All stop | More than one indoor unit are assigned same address. | Check indoor addresses. Check for any change made to remote controller connection (group/individual) since indoor address setting. |
| E09 | _ | _ | Remote controller | Duplicated master remote controller | Stop of corresponding unit | In two remote controller configuration (including wireless), both controllers are set up as master. (Header indoor unit is shut down with alarm, while follower indoor units continue operating.) | Check remote controller settings. Check remote controller P.C. boards. |
| E10 | _ | _ | Indoor unit | Indoor inter- MCU communication trouble | Stop of corresponding unit | Communication cannot be established/maintained upon turning on of power or during communication. | Check for failure in indoor P.C. board |
| E12 | E12 | 01: Indoor-outdoor communication 02: Outdoor-outdoor communication | I/F | Automatic address starting trouble | All stop | Indoor automatic address setting is started while automatic address setting for equipment in other refrigerant line is in progress. Outdoor automatic address setting is started while automatic address setting for indoor units is in progress. | Perform automatic address setting again after disconnecting communication cable to that refrigerant line. |
| E15 | E15 | _ | I/F | Indoor unit not found during automatic address setting | All stop | Indoor unit cannot be detected after indoor automatic address setting is started. | Check connection of indoor-outdoor communication line. Check for trouble in indoor power supply system. Check for noise from other devices. Check for power failure. Check for failure in indoor P.C. board. |

| | Check | code | | | | | |
|-------------|---------------|---|-------------|---|----------------------------|---|---|
| Main remote | | 7-segment display | Location of | Description | System status | Check code detection condition(s) | Check items (locations) |
| controller | Check code | Sub-code | detection | | | | |
| E16 | E16 | 00: Capacity over 01-: No. of units connected | I/F | Too many indoor units connected | All stop | Combined capacity of indoor units is too large. Note: If this code comes up after backup setting for outdoor unit failure is performed, perform "No capacity over detected" setting. <"No capacity over detected" setting method> Turn on SW103 / Bit 3 on I/F P.C. board of outdoor header unit. For Cooling Only model, this check code is not displayed even if it exceeds the combined capacity of indoor units. | Check capacities of indoor units connected. Check combined HP capacities of indoor units. Check HP capacity settings of outdoor units. Check No. of indoor units connected. Check for failure in outdoor P.C. board (I/F). |
| | | | | | 0 | More than 128 indoor units are connected. | |
| E18 | _ | _ | Indoor unit | Trouble in communication between indoor header and follower units | Stop of corresponding unit | Periodic communication between indoor header and follower units cannot be maintained. | Check remote controller wiring. Check indoor power supply wiring. Check P.C. boards of indoor units. |
| E19 | E19 | 00: No header unit 02: Two or more header units | l/F | Trouble in number of outdoor header units | All stop | There are more than one outdoor header units in one line. There is no outdoor header unit in one line. | Outdoor header unit is outdoor unit to which indoor-outdoor tie cable (U1,U2) is connected. • Check connection of indoor-outdoor communication line. • Check for failure in outdoor P.C. board (I/F). |
| E20 | E20 | 01: Connection of outdoor unit from other line 02: Connection of indoor unit from other line | I/F | Connection to other line found during automatic address setting | All stop | Equipment from other line is found to have been connected when indoor automatic address setting is in progress. | Disconnect inter-line tie cable in accordance with automatic address setting method explained in "Address setting" section. |
| E23 | E23 | _ | I/F | Outdooroutdoor communication transmission trouble | All stop | Signal cannot be transmitted to other outdoor units for at least 30 seconds continuously. | Check power supply to outdoor units. (Is power turned on?) Check connection of tie cables between outdoor units for bad contact or broken wire. Check communication connectors on outdoor P.C. boards. Check for failure in outdoor P.C. board (I/F). Check termination resistance setting for communication between outdoor units. |
| E25 | E25 | _ | I/F | Duplicated follower outdoor address | All stop | There is duplication in outdoor addresses set manually. | Note: Do not set outdoor addresses manually. |
| E26 | E26 | Address of outdoor unit from which signal is not received normally | VF | Signal lack of outdoor unit | All stop | Outdoor unit initially communicating normally fails to return signal for specified length of time. | Backup setting is being used for outdoor units. Check power supply to outdoor unit. (Is power turned on?) Check connection of tie cables between outdoor units for bad contact or broken wire. Check communication connectors on outdoor P.C. boards. Check for failure in outdoor P.C. board (I/F). |

| | Check | code | | | | | |
|-------------------|---------|--|-------------|--|----------------------------|---|---|
| | Outdoor | 7-segment display | Location of | Description | System status | Check code detection | Check items (locations) |
| remote controller | Check | Sub-code | detection | 2000 | | condition(s) | |
| E28 | E28 | Detected outdoor unit No. | I/F | Outdoor follower unit trouble | All stop | Outdoor header unit receives trouble code from outdoor follower unit. | Check check code displayed on outdoor follower unit. Convenient functions> If SW04 is pressed and held for at least 1 second while [E28] is displayed on the 7-segment display of outdoor header unit, the fan of the outdoor unit that has been shut down due to an trouble comes on. If SW04 and SW05 are pressed simultaneously, the fans of normal outdoor units come on. To stop the fan or fans, press SW05 on its own. |
| E31 | E31 | P.C.board Compressor Fan Motor 1 2 | I/F | P.C. board communication trouble | All stop | Communication is disrupted between P.C. board in inverter box. | Check wiring and connectors involved in communication between P.C. board I/F P.C. board for bad contact or broken wire. Check for failure in outdoor P.C. board (I/F, comp. P.C. board or Fan P.C. board). Check for external noise. |
| | | 80 | | Communication trouble between MCU and Sub MCU | All stop | Communication between MCU and Sub MCU stopped. | Operation of power supply reset (OFF for 60 seconds or more) Outdoor I/F PC board trouble check |
| F01 | _ | _ | Indoor unit | Indoor TCJ sensor trouble | Stop of corresponding unit | Sensor resistance is infinity or zero (open/short circuit). | Check connection of TCJ sensor connector and wiring. Check resistance characteristics of TCJ sensor. Check for failure in indoor P.C. board. |
| F02 | _ | _ | Indoor unit | Indoor TC2 sensor trouble | Stop of corresponding unit | Sensor resistance is infinity or zero (open/short circuit). | Check connection of TC2 sensor connector and wiring. Check resistance characteristics of TC2 sensor. Check for failure in indoor P.C. board. |
| F03 | _ | _ | Indoor unit | Indoor TC1 sensor trouble | Stop of corresponding unit | Sensor resistance is infinity or zero (open/short circuit). | Check connection of TC1 sensor connector and wiring. Check resistance characteristics of TC1 sensor. Check for failure in indoor P.C. board. |
| F04 | F04 | _ | I/F | TD1 sensor trouble | All stop | Sensor resistance is infinity or zero (open/short circuit). | Check connection of TD1 sensor connector. Check resistance characteristics of TD1 sensor. Check for failure in outdoor P.C. board (I/F). |

| | Check code | | | | | | |
|-------------|---------------|---|--------------------------|--|----------------------------|--|--|
| Main remote | | 7-segment display | Location of | Description | System status | Check code detection condition(s) | Check items (locations) |
| controller | Check code | Sub-code | detection | | | containon(c) | |
| F05 | F05 | _ | I/F | TD2 sensor trouble | All stop | Sensor resistance is infinity or zero (open/short circuit). | Check connection of TD2 sensor connector. Check resistance characteristics of TD2 sensor. Check for failure in outdoor P.C. board (I/F). |
| F06 | F06 | 01: TE1 sensor trouble 02: TE2 sensor trouble 03: TE3 sensor trouble | I/F | TE1/TE2/TE3 sensor trouble | All stop | Sensor resistance is infinity or zero (open/short circuit). | Check connection of TE1/TE2/TE3 sensor connectors. Check resistance characteristics of TE1/TE2/TE3 sensors. Check for failure in outdoor P.C. board (I/F). |
| F07 | F07 | 01: TL1 sensor trouble 02: TL2 sensor trouble 03: TL3 sensor trouble | I/F | TL1/TL2/TL3 sensor trouble | All stop | Sensor resistance is infinity or zero (open/short circuit). | Check connection of TL1/ TL2/TL3 sensor connector. Check resistance characteristics of TL1/TL2/ TL3 sensor. Check for failure in outdoor P.C. board (I/F). |
| F08 | F08 | _ | I/F | TO sensor trouble | All stop | Sensor resistance is infinity or zero (open/short circuit). | Check connection of TO sensor connector. Check resistance characteristics of TO sensor. Check for failure in outdoor P.C. board (I/F). |
| F09 | F09 | 01: TG1 sensor trouble 02: TG2 sensor trouble 03: TG3 sensor trouble | I/F | TG1/TG2/TG3 sensor trouble | All stop | Sensor resistance is infinity or zero (open/short circuit). | Check connection of TG1/TG2/TG3 sensor connectors. Check resistance characteristics of TG1/TG2/TG3 sensors. Check for failure in outdoor P.C. board (I/F). |
| F10 | _ | _ | Indoor unit | Indoor TA sensor trouble | Stop of corresponding unit | Sensor resistance is infinity or zero (open/short circuit). | Check connection of TA sensor connector and wiring. Check resistance characteristics of TA sensor. Check for failure in indoor P.C. board. |
| F11 | _ | _ | Indoor unit | Indoor TF sensor trouble | Stop of corresponding unit | Sensor resistance is infinity or zero (open/short circuit). | Check connection of TF sensor connector and wiring. Check resistance characteristics of TF sensor. Check for failure in indoor P.C. board. |
| F12 | F12 | 01: TS1 sensor trouble 03: TS3 sensor trouble | I/F | TS1/TS3 sensor trouble | All stop | Sensor resistance is infinity or zero (open/short circuit). | Check connection of TS1/TS3 sensor connector Check resistance characteristics of TS1/TS3 sensor. Check for failure in indoor P.C. board. |
| F13 | F13 | 1*: Compressor 1 side 2*: Compressor 2 side | Compressor P.C. board | TH sensor trouble | All stop | Sensor resistance is infinity or zero (open/short circuit). | Failure in IPM built-in temperature sensor → Replace Compressor P.C. board. |
| F15 | F15 | _ | I/F | Outdoor temperature sensor wiring trouble (TE1, TL1) | All stop | During compressor operation in HEAT mode, TL1 continuously provides temperature reading higher than indicated by TL1 by at least specified margin for 3 minutes or more. | Check installation of TE1 and TL1 sensors. Check resistance characteristics of TE1 and TL1 sensors. Check for outdoor P.C. board (I/F) trouble |

| | Check code | | | | | | |
|----------------------|------------|--|--------------------------|--|----------------------------|--|---|
| Main | Outdoor | 7-segment display | Location of | Description | System status | Check code detection | Check items (locations) |
| remote controller | Check code | Sub-code | detection | 2000.iption | oyotom otatao | condition(s) | Check nome (resultancy |
| F16 | F16 | _ | VF | Outdoor pressure sensor wiring trouble (Pd, Ps) | All stop | Readings of high-pressure Pd sensor and low-pressure Ps sensor are switched. Output voltages of both sensors are zero. | Check connection of high-pressure Pd sensor connector. Check connection of low-pressure Ps sensor connector. Check for failure in pressure sensors Pd and Ps. Check for trouble in outdoor P.C. board (I/F). Check for compressor poor compression. |
| F23 | F23 | _ | I/F | Ps sensor trouble | All stop | Output voltage of Ps sensor is zero. | Check for connection trouble involving Ps sensor and Pd sensor connectors. Check connection of Ps sensor connector. Check for failure in Ps sensor. Check for compressor poor compression. Check for failure in 4-way valve. Check for failure in outdoor P.C. board (I/F). Check for failure in SV4 circuit. |
| F24 | F24 | _ | I/F | Pd sensor trouble | All stop | Output voltage of Pd sensor is zero (sensor open-circuited). Pd > 4.15MPa despite compressor having been turned off. | Check connection of Pd sensor connector. Check for failure in Pd sensor. Check for failure in outdoor P.C. board (I/F). |
| F29 | _ | _ | Indoor unit | Other indoor trouble | Stop of corresponding unit | Indoor P.C. board does not operate normally. | Check for failure in indoor P.C. board (failure EEPROM) |
| F31 | F31 | _ | I/F | Outdoor EEPROM trouble | All stop *1 | Outdoor P.C. board (I/F) does not operate normally. | Check power supply voltage. Check power supply noise. Check for failure in outdoor P.C. board (I/F). |
| H01 | H01 | 1*: Compressor 1 side 2*: Compressor 2 side | Compressor P.C. board | Compressor breakdown | All stop | Inverter current detection circuit detects overcurrent and shuts system down. | Check power supply voltage. (AC380V-415V ± 10%). Check for failure in compressor. Check for possible cause of abnormal overloading. Check for failure in outdoor P.C. board (Compressor). |
| H02 | H02 | 1*: Compressor 1 side 2*: Compressor 2 side | Compressor P.C. board | Compressor trouble (lockup) MG-CTT trouble | All stop | Overcurrent is detected several seconds after startup of inverter compressor. | Check for failure in compressor. Check power supply voltage. (AC380V-415V ± 10%). Check compressor system wiring, particularly for open phase. Check connection of connectors/terminals on compressor P.C. board. Check conductivity of case heater. (Check for refrigerant problem inside compressor.) Check for failure in outdoor P.C. board (Compressor). |
| H03 | H03 | 1*: Compressor 1 side 2*: Compressor 2 side | Compressor P.C. board | Current detection circuit trouble | All stop | Current flow of at least specified magnitude is detected despite inverter compressor having been shut turned off. | Check current detection circuit wiring. Check failure in outdoor P.C. board (Compressor). |

^{*1} Total shutdown in case of header unit Continued operation in case of follower unit

| | Check code | | | | | | |
|-------------|------------|--|-------------|--|---------------|--|--|
| Main remote | | 7-segment display | Location of | Description | System status | Check code detection condition(s) | Check items (locations) |
| controller | Check | Sub-code | detection | | | condition(3) | |
| H05 | H05 | _ | I/F | TD1 sensor miswiring (incomplete insertion) | All stop | Discharge temperature of compressor 1 (TD1) does not increase despite compressor being in operation. | Check installation of TD1 sensor. Check connection of TD1 sensor connector and wiring. Check resistance characteristics of TD1 sensor. Check for failure in outdoor P.C. board (I/F). |
| H06 | H06 | _ | I/F | Activation of low-pressure protection | All stop | Low-pressure Ps sensor detects operating pressure lower than 0.02MPa. | Check service valves to confirm full opening (both gas and liquid sides). Check outdoor PMVs for clogging (PMV1, 2, 3). Check for failure in SV4 circuits. Check for failure in low-pressure Ps sensor. Check indoor filter for clogging. Check valve opening status of indoor PMV. Check refrigerant piping for clogging. Check operation of outdoor fan (during heating). Check for insufficiency in refrigerant quantity. |
| H07 | H07 | _ | VF | Low oil level protection | All stop | Operating compressor detects continuous state of low oil level for about 2 hours. | <all be="" checked="" corresponding="" in="" line="" outdoor="" to="" units=""> Check connection and installation of TK1 and TK2 sensors. Check resistance characteristics of TK1 and TK2 sensors. Check for gas or oil leak in same line. Check for refrigerant problem inside compressor casing. Check SV3D, SV3F valves for failure. Check oil return circuit of oil separator for clogging. Check oil equalizing circuit for clogging. </all> |
| HOS | H08 | 01: TK1 sensor trouble 02: TK2 sensor trouble | I/F | Trouble in temperature sensor for oil level detection | All stop | Sensor resistance is infinity or zero (open/short circuit). | Check connection of TK1 sensor connector. Check resistance characteristics of TK1 sensor. Check for failure in outdoor P.C. board (I/F). |
| H08 | 1100 | | | | All stop | Sensor resistance is infinity or zero (open/short circuit). | Check connection of TK2 sensor connector. Check resistance characteristics of TK2 sensor. Check for failure in outdoor P.C. board (I/F). |
| H15 | H15 | _ | I/F | TD2 sensor miswiring (incomplete insertion) | All stop | Discharge temperature of (TD2) does not increase despite compressor 2 being in operation. | Check installation of TD2 sensor. Check connection of TD2 sensor connector and wiring. Check resistance characteristics of TD2 sensor. Check for failure in outdoor P.C. board (I/F). |

| | Check | code | J | | | | |
|-------------------|---------|--|---|--|---|---|---|
| Main | Outdoor | 7-segment display | Location of | Description | System status | Check code detection | Check items (locations) |
| remote controller | Check | Sub-code | detection | | ., | condition(s) | , |
| | | 01: TK1 oil circuit trouble 02: TK2 oil circuit trouble | I/F | Oil level detection circuit trouble | All stop | No temperature change is detected by TK1 despite compressor 1 having been started. | Check for disconnection of TK1 sensor. Check resistance characteristics of TK1 sensor. Check for connection trouble involving TK1 and TK2 sensors Check for clogging in oil equalizing circuit capillary. Check for refrigerant entrapment inside compressor. |
| H16 | H16 | | | | | No temperature change is detected by TK2 despite compressor 2 having been started. | Check for disconnection of TK2 sensor. Check resistance characteristics of TK2 sensor. Check for connection trouble involving TK1 and TK2 sensors Check SV3F valve malfunction. Check for clogging in oil equalizing circuit capillary. Check for refrigerant entrapment inside compressor. |
| H17 | H17 | 1*: Compressor 1 side 2*: Compressor 2 side | Compressor P.C. board | Compressor trouble (Step-out) | All stop | Judged that the synchronization could not be taken. | Check power supply voltage. (AC380V-415V ± 10%). Check for failure in compressor. Check for possible cause of abnormal overloading. Check for failure in outdoor P.C. board (compressor). |
| J01 | _ | _ | FS unit | Communication trouble between indoor unit(s) and FS unit | Stop of corresponding unit(s) (Indoor unit(s) connected to the same FS unit) | FS unit not receiving signal from indoor unit(s) | Check wiring between FS unit and indoor unit(s). Check FS unit port address setting of indoor unit. Check FS unit port combining branches setting of indoor unit. |
| J02 | _ | _ | Indoor unit | Communication trouble between control boards in Flow Selector unit | Stop of corresponding unit(s) (Indoor units (s) connected to the same FS unit) | There is no communication from P.C.board after No.2 of FS unit Multi-port type. | Check connector connection of FS unit for PC board communication. Check for PC board defects in FS unit. Check FS unit control number setting (SW01 of FS unit, Bit 1 to 4). |
| J03 | _ | _ | Indoor unit | Duplicated FS units | Stop of corresponding unit(s) | Multiple FS unit (or SV units) are installed in one indoor unit. | Check indoor unit(s) - FS unit(s) cable |
| J29 | J29 | Detected indoor unit address | Indoor unit or Leak Detector Interface | Leak Detector Trouble | When DN code 06B = 0001 or 0002 are set • All stop | There is no communication from Leak Detector. A Malfunction signal received from Leak Detector. | Check Malfunction LED of Leak Detector. Check disconnection and connectors of Leak Detector. Check PC board defects of Leak Detector. |
| | _ | _ | | | Continued operation All stop (detected when power is turned on) | | or Leak Detector. Check PC board defects of indoor unit or Leak Detector Interface. |

| Check | | | Leastion | | | | |
|----------------------|---------------------------|------------------------------|---|---|--|---|---|
| Main | Outdoor 7-segment display | | Location of | Description | System status | Check code detection condition(s) | Check items (locations) |
| remote controller | Check code | Sub-code | detection | | • | condition(s) | , , |
| J30 | J30 | Detected indoor unit address | Indoor unit or Leak Detector Interface | Refrigerant leak detection | All stop (Safety measures setting of indoor unit is "Pump-down operation" or "Leak Detector only" | Leak Detector detects refrigerant leak | Check refrigerant detection status of Leak Detector. Check refrigerant leaks from indoor unit or Flow Selector / Shut-off Valve unit. Check for false |
| | _ | _ | Indoor unit | | Stop of corresponding unit(s) (Safety measures setting of indoor unit is "Individual shut-off operation") | | detection. |
| J31 | _ | _ | Indoor unit or Leak Detector Interface | Refrigerant leak detection sensor exceeding its life of the product | Continued operation | The energization time of refrigerant sensor has reached 10 years. | Check Malfunction LED of Leak Detector. Check refrigerant sensor of Leak Detector. |
| L02 | L02 | _ | Indoor unit | Outdoor units model disagreement trouble | Stop of corresponding unit | In case of different outdoor unit (Not corresponded to Air to Air Heat Exchanger type) | Check outdoor unit model. (Check whether the outdoor unit corresponds to Air to Air Heat Exchanger type or not.) |
| L03 | _ | _ | Indoor unit | Duplicated indoor header unit | Stop of corresponding unit | There are more than one header units in group. | Check indoor addresses. Check for any change made to remote controller connection (group/individual) since indoor address setting. |
| L04 | L04 | _ | I/F | Duplicated outdoor line address | All stop | There is duplication in line address setting for outdoor units belonging to different refrigerant piping systems. | Check line addresses. |
| L05 | _ | _ | I/F | Duplicated priority indoor unit (as displayed on priority indoor unit) | All stop | More than one indoor units have been set up as priority indoor unit. | Check display on priority indoor unit. |
| L06 | L06 | No. of priority indoor units | I/F | Duplicated priority indoor unit (as displayed on indoor unit other than priority indoor unit) | All stop | More than one indoor units have been set up as priority indoor unit. | Check displays on priority indoor unit and outdoor unit. |
| L07 | _ | _ | Indoor unit | Connection of group control cable to standalone indoor unit | Stop of corresponding unit | There is at least one standalone indoor unit to which group control cable is connected. | Check indoor addresses. |
| L08 | L08 | _ | Indoor unit | Indoor group / addresses not set | Stop of corresponding unit | Address setting has not been performed for indoor units. | Check indoor addresses. Note: This code is displayed when power is turned on for the first time after installation. |
| L09 | _ | _ | Indoor unit | Indoor capacity not set | Stop of corresponding unit | Capacity setting has not been performed for indoor unit. | Set indoor capacity. (DN = 11) |

| | Check code | | | | | | |
|-------------|---------------|--|-----------------------------------|--|----------------------------------|---|---|
| Main remote | nto J | | Location of | Description | System status | Check code detection condition(s) | Check items (locations) |
| controller | Check code | Sub-code | detection | | | Containon(c) | |
| L10 | L10 | _ | I/F | Outdoor capacity not set | All stop | Initial setting of I/F P.C. board has not been implemented. | Check model setting of P.C. board for servicing outdoor I/F P.C. board. |
| L20 | | _ | Network adaptor Indoor unit | Duplicated central control address | All stop | There is duplication in central control address setting. | Check central control addresses. |
| L23 | _ | _ | I/F | SW setting mistake | All stop | Outdoor P.C. board (I/F) does not operate normally. | Check switch setting of outdoor P.C. board (I/F). |
| L28 | L28 | _ | VF | Too many outdoor units connected | All stop | There are more than 5 outdoor units. | Check No. of outdoor units connected (Only up to 5 units per system allowed). Check communication lines between outdoor units. Check for failure in outdoor P.C. board (I/F). |
| L29 | L29 | P.C.board Compressor Fan Motor 1 2 1 2 2 1 2 2 2 2 | I/F | Trouble in No. of P.C. board | All stop | Insufficient number of P.C. board are detected when power is turned on. | Check model setting of P.C. board for servicing outdoor I/F P.C. board. Check connection of UART communication connector. Check compressor P.C. board, fan P.C. board, and I/F P.C. board for failure. |
| L30 | L30 | Detected indoor address | Indoor unit | Indoor external interlock (External abnormal input) | Stop of corresponding unit | Indoor unit has been shut down due to external abnormal input signal. | When external device is connected: 1) Check for trouble in external device. 2) Check for trouble in indoor P.C. board. When external device is not connected: 1) Check for trouble in indoor P.C. board. |
| _ | L31 | _ | I/F | Extended IC trouble | Continued operation | There is part failure in P.C. board (I/F). | Check outdoor P.C. board (I/F). |
| P01 | _ | _ | Indoor unit | Indoor fan motor trouble | Stop of corresponding unit | | Check the lock of fan motor (AC fan). Check wiring. |
| P03 | P03 | _ | I/F | Discharge temperature TD1 trouble | All stop | Discharge temperature (TD1) exceeds 115 °C. | Check outdoor service valves (gas side, liquid side) to confirm full opening. Check outdoor PMVs (PMV1, 2, 3, 4) for clogging. Check resistance characteristics of TD1 sensor. Check for insufficiency in refrigerant quantity. Check for failure in 4-way valve. Check for leakage of SV4 circuit. Check SV4 circuit (wiring or installation trouble in SV41 or SV42). |

| | Check | code | Location | | | | |
|-------------|------------------|---|-----------------------------|--|---------------|---|--|
| Main remote | Outdoor Check | 7-segment display | Location of detection | Description | System status | Check code detection condition(s) | Check items (locations) |
| controller | code | Sub-code | | | | | |
| P04 | P04 | 1*: Compressor 1 side 2*: Compressor 2 side | I/F | Activation of high-pressure SW | All stop | High-pressure SW is activated. | Check connection of highpressure SW connector. Check for failure in Pd pressure sensor. Check outdoor service valves (gas side, liquid side) to confirm full opening. Check for failure in outdoor fan. Check for failure in outdoor fan motor. Check outdoor PMVs (PMV1, 2, 3) for clogging. Check indoor/outdoor heat exchangers for clogging. Check for short-circuiting of outdoor suction/discharge air flows. Check for failure in outdoor P.C. board (I/F). Check for trouble in indoor fan system (possible cause of air flow reduction). Check opening status of indoor PMV. Check indoor-outdoor communication line for wiring trouble. Check for failure operation of check valve in discharge pipe convergent section. Check for refrigerant overcharging. |
| P05 | P05 | 00: Power detection trouble 01: Open phase 02: Power supply miswiring 1*: Compressor 1 sid 2*: Compressor | I/F Compressor P.C. board | Power detection trouble / Open phase detection / Power supply miswiring Compressor Vdc trouble | All stop | Open phase is detected when power is turned on. Inverter DC voltage is too high (overvoltage) or too low (undervoltage). | Check for failure in outdoor P.C. board (I/F). Check wiring of outdoor power supply. Check power supply voltage. |
| | | 2*: Compressor 2 sid | | | | | |
| | | 1*: Compressor 1 sid 2*: Compressor 2 sid | Compressor P.C. board | Heat sink overheating trouble | All stop | Temperature sensor built into IPM (TH) is overheated. | Check outdoor fan system trouble. Check IPM and heat sink for thermal performance for failure installation. (e.g. mounting screws and thermal conductivity) Check for failure in Compressor P.C. board. (failure IPM built-in temperature sensor (TH)) |
| P07 | P07 | 01: Compressor 1 heat sink trouble 02: Compressor 2 heat sink trouble 04: Heat sink dew condensation | I/F | Heat sink overheating trouble Heat sink dew condensation trouble | All stop | Condensation detection on heat sink has occurred four times or more in operation. Temperature sensor built into IPM (TH) is overheated. | Check outdoor fan system trouble. Check IPM and heat sink for thermal performance for troubled installation. (e. g. mounting screws and thermal conductivity) Check for failure in compressor P.C. board. (failure IPM built-in temperature sensor (TH)) Check shortage of refrigerant. Check outdoor service valves. Check connection of TL2 sensor. Check resistance characteristics of TL2 sensor. Check mesistance characteristics of TO sensor. Check malfunctions of Pd and Ps sensors. Check outdoor I/F P.C. board malfunction. Check PMV2 and PMV3 |

| | Check | code | | | | | |
|-------------------|-------|-------------------------|-------------|--|----------------------------|---|--|
| | | 7-segment display | Location of | Description | System status | Check code detection condition(s) | Check items (locations) |
| remote controller | Check | Sub-code | detection | | | Condition(3) | |
| P10 | P10 | Detected indoor address | Indoor unit | Indoor overflow trouble | All stop | Float switch operates. Float switch circuit is open-circuited or disconnected at connector. | Check float switch connector. Check operation of drain pump. Check drain pump circuit. Check drain pipe for clogging. Check for failure in indoor P.C. board. |
| P11 | | _ | I/F | Outdoor heat exchanger freeze trouble | All stop | Outdoor heat exchanger remaining frost detection has occurred eight times or more due to abnormal frost formation in heating operation. | Check shortage of refrigerant. Check connection of TE1, TE2 and TE3 sensors. Check resistance characteristics of TE1, TE2, and TE3 sensors. Check disconnection of TS1 sensor. Check resistance characteristics of TS1 sensor. Check outdoor I/F P.C. board malfunction. Check operation of 4 way valve. Check operation of outdoor PMV (1, 2, 3). Check short circuit from outlet air to inlet air. |
| P12 | _ | _ | Indoor unit | Indoor fan motor trouble | Stop of corresponding unit | Motor speed measurements continuously deviate from target value. Overcurrent protection is activated. | Check connection of fan connector and wiring. Check for failure in fan motor. Check for failure in indoor P.C. board. Check impact of outside air treatment (OA). |
| P13 | P13 | _ | I/F | Outdoor liquid backflow detection trouble | All stop | <during cooling="" operation=""> When system is in cooling operation, high pressure is detected in the unit that has been turned off. <during heating="" operation=""> When system is in heating operation, low pressure is detected to be high in unit that has been turned off.</during></during> | Check full-close operation of outdoor PMV (1, 2, 3, 4). Check for failure in Pd or Ps sensor. Check failure in outdoor P.C. board (I/F). Check capillary of oil separator oil return circuit for clogging. Check for leakage of check valve in discharge pipe |
| P15 | P15 | 01: TS condition | I/F | Gas leak detection (TS1 condition) | All stop | Protective shutdown due to sustained suction temperature at or above judgment criterion for at least 10 minutes is repeated four times or more. <ts criterion="" judgment="" trouble=""> In cooling operation: 60 °C In heating operation: 40 °C</ts> | Check for insufficiency in refrigerant quantity. Check outdoor service valves (gas side, liquid side) to confirm full opening. Check PMVs (PMV1, 2, 3, 4) for clogging. Check resistance characteristics of TS1 sensor. Check for failure in 4-way valve. Check SV4 circuit for leakage |
| | | 02: TD condition | I/F | Gas leak detection (TD condition) | All stop | Protective shutdown due to sustained discharge temperature (TD1 or TD2) at or above 108 °C for at least 10 minutes is repeated four times or more. | Check for insufficiency in refrigerant quantity. Check PMVs (PMV 1, 2, 3, 4) for clogging. Check resistance characteristics of TD1 and TD2 sensors. Check indoor filter for clogging. Check piping for clogging. Check SV4 circuit (for leakage or coil installation trouble). |

| | Check | code | | | | | |
|----------------------|------------|---------------------------|-------------|---|---------------|--|---|
| Main | Outdoor | 7-segment display | Location of | Description | System status | Check code detection | Check items (locations) |
| remote controller | Check code | Sub-code | detection | Description | Cystom status | condition(s) | oncok items (locations) |
| P17 | P17 | | I/F | Discharge temperature TD2 trouble | All stop | Discharge temperature (TD2) exceeds 115 °C. | Check outdoor service valves (gas side, liquid side) to confirm full opening. Check outdoor PMVs (PMV1, 2, 3, 4) for clogging. Check resistance characteristics of TD2 sensor. Check for failure in 4-way valve. Check SV4 circuit for leakage. Check SV4 circuit (for wiring or installation trouble involving SV41 and SV42). |
| P19 | P19 | Detected outdoor unit No. | I/F | 4-way valve reversing trouble | All stop | Abnormal refrigerating cycle data is collected during heating operation. | Check for failure in main body of 4-way valve. Check for coil failure in 4-way valve and loose connection of its connector. Check resistance characteristics of TS1 and TE1,TE2 sensors. Check output voltage characteristics of Pd and Ps pressure sensors. Check for wiring trouble involving TE1 and TL1 sensors. |
| P20 | P20 | | I/F | Activation of high-pressure protection | All stop | <during cooling="" operation=""> Pd sensor detects pressure equal to or greater than 3.85 MPa. <during heating="" operation=""> Pd sensor detects pressure equal to or greater than 3.6 MPa.</during></during> | Check for failure in Pd pressure sensor. Check service valves (gas side, liquid side) to confirm full opening. Check for failure in outdoor fan. Check for failure in outdoor fan motor. Check outdoor PMV (PMV1, 2, 3, 4) for clogging. Check indoor/outdoor heat exchangers for clogging. Check for short-circuiting of outdoor suction/discharge air flows. Check for failure in outdoor P.C. board (I/F). Check for failure in indoor fan system (possible cause of air flow reduction). Check opening status of indoor PMV. Check indoor-outdoor communication line for wiring trouble. Check for troble operation of check valve in discharge pipe convergent section. Check gas balancing SV4 valve circuit. Check for refrigerant overcharging. |

| | Check code | | | | | | |
|----------------------|------------|--|--------------------------|---|----------------------------|--|--|
| Main | Outdoor | 7-segment display | Location of | Description | System status | Check code detection | Check items (locations) |
| remote controller | Check code | Sub-code | detection | 2000 | - Cyclom clause | condition(s) | |
| P22 | P22 | 1*: Fan P.C. board 1 2*: Fan P.C. board 2 | Fan INV. P.C. board | Outdoor fan P.C. board trouble | All stop | Protected operation of Fan inverter P.C. board | Check fan motor. Check for failure in fan P.C. board. Check connection of fan motor connector. Check power voltage of the main power supply. |
| P26 | P26 | 1*: Compressor 1 side 2*: Compressor 2 side | Compressor P.C. board | IPM, Compressor shortcircuit protection trouble | All stop | Overcurrent is momentarily detected during startup of compressor. | Check connector connection and wiring on compressor P.C. board. Check for failure in compressor (layer shortcircuit). Check for failure in outdoor P.C. board (Compressor). |
| P29 | P29 | 1*: Compressor 1 side 2*: Compressor 2 side | Compressor P.C. board | Compressor position detection circuit trouble | All stop | Position detection is not going on normally. | Check wiring and connector connection. Check for compressor layer short-circuit. Check for failure in compressor P.C. board. |
| P31 | _ | _ | Indoor unit | Other indoor trouble (group follower unit trouble) | Stop of corresponding unit | There is trouble in other indoor unit in group, resulting in detection of E07/L07/L03/L08. | Check indoor P.C. board. |

Check codes Displayed on by Central Control Device

| | Check | code | | | | | |
|----------------------|------------|--------------------------------|--------------------------------------|--|----------------------------|---|---|
| Main | Outdoor | 7-segment display | Location | Description | System status | Check code detection | Check items (locations) |
| remote controller | Check code | Sub-code | detection | 2000.iption | Gyotom otatao | condition(s) | Chook Rome (resultane) |
| E03 | _ | _ | Indoor unit | Indoor-remote controller communication trouble (detected at indoor end) | Stop of corresponding unit | There is no communication from remote controller (including wireless) or network adaptor. | Check remote controller and network adaptor wiring. |
| C05 | _ | | Central control device | Central control device transmission trouble | Continued operation | Central control device is unable to transmit signal. | Check for failure in central control device. Check for failure in central control communication line. Check termination resistance setting. |
| C06 | _ | | Central control device | Central control device reception trouble | Continued operation | Central control device is unable to receive signal. | Check for failure in central control device. Check for failure in central control communication line. Check terminator resistor setting. Check power supply for devices at other end of central control communication line. Check failure in P.C. boards of devices at other end of central control communication line. |
| C12 | _ | | General- purpose device I/F | Batch alarm for general- purpose device control interface | Continued operation | Trouble signal is input to control interface for general-purpose devices. | Check trouble input. |
| P30 | | ccording to f alarm-causing | Central control device | Group control follower unit trouble | Continued operation | Trouble occurs in follower unit under group control. ([P30] is displayed on central control remote controller.) | Check check code of unit that has generated alarm. |
| | (L20 dis | played.) | | Duplicated central control address | Continued operation | There is duplication in central control addresses. | Check address settings. |

▼ Points to Note When Servicing Compressor

(1) When checking the outputs of inverters, remove the wiring from all the compressors.

▼ How to Check Inverter Output

- (1) Turn off the power supply.
- (2) Remove compressor leads from the compressor P.C. board. (The model with two compressor should remove the wiring for two sets (6 leads).
- (3) Turn on the power supply and start cooling or heating operation.
- (4) Check the output voltage across each pair of inverter-side. If the result is unsatisfactory according to the judgment criteria given in the table below, replace the compressor P.C. board.


| No. | Measured leads | Criterion |
|-----|----------------|-----------|
| 1 | CN201 - CN202 | 380~580V |
| 2 | CN202 - CN203 | 380~580V |
| 3 | CN203 - CN201 | 380~580V |

▼ How to Check Resistance of Compressor Winding


- (1) Turn off the power supply.
- (2) Remove compressor leads from the compressor P.C. board. (Be sure to remove all the leads.)
- (3) With each compressor, check the phase-to-phase winding resistances and winding-to-outdoor cabinet resistance using a multimeter.
 - Earth trouble?
 - \rightarrow It is normal if the winding-to-outdoor cabinet resistance is 10M Ω or more.
 - · Inter-winding short circuit?
 - \rightarrow It is normal if the phase-to-phase resistances are in the 0.1-1.0 Ω range. (Use a digital multimeter.)


▼ How to Check Outdoor Fan Motor


- (1) Turn off the power supply.
- (2) Remove fan motor leads from the fan P.C. board for the outdoor fan.
- (3) Rotate the fan by hand. If the fan does not turn, the fan motor is faulty (locked up). Replace the fan motor. If the fan turns, measure the phase-to-phase winding resistances using a multimeter. It is normal if the measurements are in the 8.1-9.9 range. (Use a digital multimeter.)





10-5. Diagnostic Procedure for Each Check Code (Indoor Unit)































































Push and hold the alarm lamp button and reset button of Leak Detector at the same time for at least 5 seconds and release after that. (Please push the reset button using a tool such as a precision screwdriver) Set the rotary switch [SW01/SW02/SW03] on the 1/F board of the outdoor unit to [2/1/9]. Push and hold SW04 more than 5 seconds, system is locked. To release manual system lock, push and hold SW05 more than 5 seconds. After release the shut-off valves lock, refrigerant remaining downstream side of the shut-off valves may flow from leakage point. (Especially, when DN code [107] set to 3, some refrigerant remains.) When refrigerant leakage continues, dose the shut-off valve connected to leak point. (Close PMV-L, PMV-S, and PMV-D). Refer to "7-7-7. Pulse Motor Valve (PMV) Forced Open/Close Function in FS unit and shut-off valve unit" for how to operate the shut-off valves. · The shut-off valves that was locked will be released. (All shut-off valves lock in the system will be released within 3 minutes. **Do NOT turn off power until operation is completed**. After release the shut-off valves lock, reset system power. When DN code [107] set to 1 or 3, the shut-off valve will not open until power is reset. This product has a function to manual system lock. * Perform this release operation even if the system is only connected to the indoor unit with the indoor unit DN code No. [107] set to 3 "Leak Detector only" Remarks: How to manual system lock. SW04 SW06 SW06 SW06 When a system power reset, Malfunction LED of Leak Detector will turn ON and Notice code is displayed on remote controller Tum OFF system power and repair leakage point, or replace indoor unit. After repair is completed, tum ON system power. After replacing refrigerant sensor module, confirm that Malfunction LED is turned off and Notice code is cleared. After release the shut-off valves lock, check refrigerant pressure. If pressure is rising, recover refrigerant again. If more than one Leak Detector detects a refrigerant leak, replace refrigerant sensor module of all detected Leak Detectors. The refrigerant may leak again from the part where the refrigerant leaked, which may become dangerous. * The release operation should be performed on all Leak Detectors that detected refrigerant leakage. Refrigerant sensor will become unusable once it has been exposed to refrigerant. (Not limited to R32) * Perform this release operation on the Leak Detector connected to the Leak Detector Interface. (3) Determine which indoor unit and Flow Selector/Shut-off Valve unit occurred a refrigerant leak. Set the rotary switch [SW01/SW02/SW03] on the 1/F board of the outdoor unit to [2/1/9]. 7-segment display: [o. U. Loc] (While system is locked.) · Check DN code No. [107] setting. (Leak Detector sounds again, and please stop it again refer to "8-11. System operation when the Leak Detector detects refrigerant leak.".) Refrigerant should be collected before release the shut-off valves lock described below. After a sufficient amount of ventilation, replace the refrigerant sensor module. When Leak Detector detects a refrigerant leak, alarm lamp is blinking. (1 Hz) Be sure to perform this operation after release the shut-off valves lock. 12) After completing all the work, system power reset and start test run. The following actions are performed: • Leak Detector makes a sound of "beep, beep, beep, beeeeep" Push and hold SW05 more than 5 seconds, system lock is released. 7-segment display: [o. U. ... C L] (display for 5 seconds) (4) Release the shut-off valves lock by operating Leak Detector. * While shut-off valve is locked, shut-off valve of FS unit or SV unit is closed and fixed, and compressor cannot start operating while system is locked. (2) Determine which Leak Detector detected a refrigerant leak With sufficient ventilation, release the shut-off valves lock. (11) Replace refrigerant sensor module in Leak Detector. [o. U.] (Others.) · Clarify the installation location of the Leak Detector through the Leak Detector Interface and Flow Selector/Shut-off Valve unit. (6) Repair the refrigerant leak point. (5) Recovering refrigerant. (Again) (10) Release the system lock. (1) Recovering refrigerant. (9) Charging refrigerant Airtightness test. (8) Vacuum drying. This product has a function to lock shut-off valve and system when refrigerant leakage is detected · Please ventilate thoroughly before operating, it can be dangerous if the refrigerant is stagnant. Recovery method after refrigerant leakage detection (repair flow) (3) Determine which indoor unit and Flow Selector/Shut-off Valve unit occurred a refrigerant leak. (2) Determine which Leak Detector detected a refrigerant leak. (11) Replace refrigerant sensor module. (4) Release the shut-off valves lock. (6) Repair the refrigerant leak point. (10) Release the system lock. (1) Recovering refrigerant. (5) Recovering refrigerant. · Start repairing with the system power turned ON (9) Charging refrigerant. Airtightness test. Follow this repair flow to repair and release lock. (8) Vacuum drying. (12) Test run. Caution:

10-6. Sensor Characteristics

Indoor Unit

■ Temperature sensor characteristics



| Temperature [°F(°C)] | Resistance [k Ω] |
|----------------------|--------------------------|
| 32°F(0°C) | 33.9 |
| 41°F(5°C) | 26.1 |
| 50°F(10°C) | 20.3 |
| 59°F(15°C) | 15.9 |
| 68°F(20°C) | 12.6 |
| 77°F(25°C) | 10.0 |
| 86°F(30°C) | 8.0 |
| 95°F(35°C) | 6.4 |
| 104°F(40°C) | 5.2 |
| 113°F(45°C) | 4.2 |
| 122°F(50°C) | 3.5 |
| 131°F(55°C) | 2.6 |
| 140°F(60°C) | 2.4 |

| Indoor TC | 1 sensor | |
|---|--|--|
| 200 | - | 20 |
| $\begin{array}{c} 150 \\ \text{Resistance [k}\Omega] \\ (50^{\circ}\text{F}(10^{\circ}\text{C})) \\ \text{or below)} \end{array}$ | 22'F -4'F 14'F 32'F 50'F 68'F 86'F 104'F 122'F 140'F 158'F 176'F 194'F 2 | - 15 Resistance [kΩ] (50°F(10°C)) or below) - 10 |
| | Temperature °F [°C] | |

| Temperature [°F(°C)] | Resistance [$k\Omega$] |
|----------------------|--------------------------|
| -4°F(-20°C) | 99.9 |
| -5°F(-15°C) | 74.1 |
| -14°F(-10°C) | 55.6 |
| -23°F(-5°C) | 42.2 |
| 32°F(0°C) | 32.8 |
| 41°F(5°C) | 25.4 |
| 50°F(10°C) | 19.8 |
| 59°F(15°C) | 15.6 |
| 68°F(20°C) | 12.4 |
| 77°F(25°C) | 10.0 |
| 86°F(30°C) | 8.1 |
| 95°F(35°C) | 6.5 |
| 104°F(40°C) | 5.3 |
| 113°F(45°C) | 4.4 |
| 122°F(50°C) | 3.6 |
| 131°F(55°C) | 3.0 |
| 140°F(60°C) | 2.5 |
| 149°F(65°C) | 2.1 |
| 158°F(70°C) | 1.8 |
| 167°F(75°C) | 1.5 |
| 176°F(80°C) | 1.3 |
| 185°F(85°C) | 1.1 |
| 194°F(90°C) | 1.0 |
| 203°F(95°C) | 0.8 |
| 212°F(100°C) | 0.7 |
| · | |

| Indoor TC2 and TCJ sensors | |
|----------------------------|--|
| 200 - | 20 |
| 150 | - 15 Resistance [kΩ] (50°F(10°C)) or below) - 10 |
| Temperature °F [°C] | |

| Temperature [°F(°C)] | Resistance [k Ω] |
|----------------------|--------------------------|
| -4°F(-20°C) | 115.2 |
| -5°F(-15°C) | 84.2 |
| -14°F(-10°C) | 62.3 |
| -23°F(-5°C) | 46.6 |
| 32°F(0°C) | 35.2 |
| 41°F(5°C) | 26.9 |
| 50°F(10°C) | 20.7 |
| 59°F(15°C) | 16.1 |
| 68°F(20°C) | 12.6 |
| 77°F(25°C) | 10.0 |
| 86°F(30°C) | 8.0 |
| 95°F(35°C) | 6.4 |
| 104°F(40°C) | 5.2 |
| 113°F(45°C) | 4.2 |
| 122°F(50°C) | 3.5 |
| 131°F(55°C) | 2.8 |
| 140°F(60°C) | 2.4 |
| 149°F(65°C) | 2.0 |
| 158°F(70°C) | 1.6 |
| 167°F(75°C) | 1.4 |
| 176°F(80°C) | 1.2 |

11. REPLACEMENT OF SERVICE P.C. BOARD

Replacement of P.C. Board for Indoor Unit Servicing

<Models>

| MMU-UB***1YHP-UL Series | |
|-------------------------|--|
|-------------------------|--|

<Note: when replacing the P.C. board for indoor unit servicing>

The nonvolatile memory (hereafter called EEPROM, IC503) on the indoor unit P.C. board before replacement includes the model specific type information and capacity codes as the factory-set value and the important setting data which have been automatically or manually set when the indoor unit is installed, such as system/indoor/group addresses, high ceiling select setting, etc. When replacing the P.C. board for indoor unit servicing, follow the procedures below.

After replacement completes, confirm whether the settings are correct by checking the indoor unit No., Group header unit/follower unit settings and perform the cooling cycle confirmation through the trial operation.

<Replacement procedures>

Case 1

Before replacement, the indoor unit can be turned on and the setting data can be read out by wired remote control operation.

EEPROM data read out [1]

Writing the read out EEPROM data [3]

Power reset(for all indoor units connected to the remote control when the group operation control is performed.)

Case 2

The EEPROM before replacement is defective and the setting data cannot be read out.

Writing the setting data to EEPROM, such as high ceiling installation setting and optional connection setting, etc., based on the customer information. [3]

Power reset (for all indoor units connected to the remote control when the group operation control is performed.)

| [1] | Setting | data | read | out | from | EEP | ROM |
|-----|---------|------|------|-----|------|-----|-----|
|-----|---------|------|------|-----|------|-----|-----|

The setting data modified on the site, other than factory-set value, stored in the EEPROM shall be read out.

Step 1 Push [Menu] to open the "Menu"

Step 2 Push and hold [Menu] and [] at the same time to open "Field setting menu". (Push and hold 4 seconds.)

Step 3 Push [] and [] to select " DN setting", and then push [Set / Fix].

Step 4 Select "Indoor unit", and the push [Set / Fix].

Step 5 For group operation, all connected room in the system are displayed.

Select the unit whose EEPROM contents you want to read and push [Set / Fix].

- ⇒ The fan of the selected indoor unit operates and the flap swings.
- 1. Push [] to black highlight the code (DN), and then push [] and [] to set the code No. to 1. (This is the setting for the filter sign lighting time.) at this time, be sure to write down the setting data displayed.
- 2. Change the CODE No. (DN) by pushing \(\sqrt{\sq}}}}}}}}}}}}} \signtimes \sqrt{\sqrt{\sqrt{\sqrt{\sqrt{\sqrt{\sqrt{\sqrt{\sqrt{\sqrt{\sqrt{\sqrt{\sqrt{\sqrt{\sqrt{\sqrt{\sq}}}}}}}}}}}}} \simes \sqrt{\sqrt{\sintitta}}}}}}} \simes \sqrt{\sqrt{\sintitta}}}}}}} \end{\sqrt{\sqrt{\sintitta}\sintintita\sintitit{\sintiq}}}}}}} \simes \sqrt{\sqintilex{\sintitita}}}}}}} \end{
- 3. Repeat the step 2 to set the other setting in the same way and write down the setting data in the manual that comes with the P.C board.

CODE No.required at least

| DN | Contents | |
|-----|--------------------------------------|--|
| 10 | Type | |
| 11 | Indoor unit capacity | |
| 12 | System address | |
| 13 | Indoor unit address | |
| 14 | Group address | |
| FC | C Communication protocol | |
| 1FC | C Indoor Unit terminating resistance | |


- 1. The CODE No. for the Indoor unit type and Indoor unit capacity are required to set the rotation number setting of the fan.
- 2. If the system/indoor/group addresses are different from those before replacement, the auto-address setting mode starts and the manual resetting may be required again.

 (when the multiple units group operation including twin system.)

[2] P.C. Board for indoor unit servicing replacement procedures

Step 1 Replace the P.C. board to the P.C. board for indoor unit servicing.

At this time, perform the same setting of the jumper wire(J01) setting(cut), switch SW501, SW502 (short-circuit) connector CN34 as the setting of the P.C. board before replacement.



Step 2 It is necessary to set Indoor unit to be exchanged: Remote controller = 1:1


Based upon the system configuration, turn on power of the indoor unit with one of the following items.

- 1) Single (Individual) operation
 - Turn on power of the indoor units and proceed to [3].
- 2) Group operation
 - A) In case that power of the exchanged indoor unit only can be turned on Turn on power of the exchanged indoor unit only and proceed to [3].
 - B) In case that power of the indoor units cannot be turned on individually (Case 1)
 - Remove temporarily the group wire connected to the terminal blocks A and B of the exchanged indoor unit.
 - b) After connecting the remote controller wire only to the removed terminal block, turn on power of the indoor units and proceed to [3].

When the above methods cannot be used, follwer to the two cases below.

- C) In case that power of the indoor units cannot be turned in individually (Case 2)
 - Remove all CN41 connectors of the indoor units in the same group except those of the exchanged indoor unit.
 - b) Turn on power of the indoor units and proceed to [3].

After [3] operation has finished, be sure to return the temporarily removed group wire or CN41 connector to the original connection.



| [3] Writ | ting the setting data to EEPROM |
|----------|--|
| | The settings stored in the EEPROM of the P.C. board for indoor unit servicing are the factory-set values.) |
| Step 1 | Push [Menu] to open the "Menu" <fig. 1="" rbc-awsu5*-ul=""></fig.> |
| Step 2 | Push and hold [Menu] and [] at the same time to open "Field setting menu". (Push and hold 4 seconds.) |
| Step 3 | Push [→] and [→] to select " DN setting", and then push [☐ Set / Fix]. |
| Step 4 | Select "Indoor unit", and the push [Set / Fix]. |
| Step 5 | For group operation, all connected room in the system are displayed. Select the unit whose EEPROM contents you want to read and push [Set / Fix]. The fan of the selected indoor unit operates and the flap swings. |
| Step 6 | Push [] to black highlight the code (DN), and then push [] and [] to set the code (Set the indoor unit type and capacity) |
| | The factory-set values shall be written to the EEPROM by changeing the type and capacity. 1. Set the CODE No. (DN) to 10 (without change) 2. Push [] to black highlight the data, and then push [] and [] to set the type. |
| | (Refer to Type DN code "10".) 3. After finishing setting the data of the code (DN), push [☐ Set / Fix] ⇒ "Continues?" is displayed. |
| | 4. To set the data of other codes (DN), push [Set / Fix] |
| | 5. Push [] to black highlight the code (DN), and then push [] and [] to set the code No. to 11. |
| | 6. Push [▶] to black highlight the data, and then push [▶] and [▶] to set the capacity. |
| | (Refer to indoor unit capacity DN code "11" on page 4.) |
| | 7. After finishing setting the data of the code (DN), push [Set / Fix] |
| | ⇒ "Continues ?" is displayed. |
| | 8. Push [S Return] |
| | When doing group connections : |
| | ⇒ Push [🕦 Return] to open the unit selection screen. In the unit selection screen, push [🐧 Return] to briefly display " 🧮 ", and then return to the "Field setting menu" screen. |
| Step 7 | Write the on-site setting data to the EEPROM, such as address setting etc. Perforn the steps 1 and 4 above agian. |
| Step 8 | Push [] to black highlight the code (DN), and then push [] and [] to set the code No. to 1. (This is the setting for the filter sign lighting time.) |
| Step 9 | Check the setting data displayed at this time with the setting data put down in [1]. 1. If the data is different, push [) to highlight the data in black and write, push [) and [) to change the data to what you wrote down, and push [) Set / Fix]. |
| | 2. If the data is the same, proceed to next step. |
| Step 10 | Push [] to black highlight the code (DN), and then push [] and [] to set the code. As described above, check the setting data and modify to the data put down in [1]. |
| Ct== 44 | |

Step 11 Repeat the steps 8 and 9.

Step 12 After the setting completes, push [Return]

When doing group connections:


⇒ Push [🔁 Return] to open the unit selection screen. In the unit selection screen, push [🔁 Return] to briefly $\overline{\text{display}}$ " Ξ ", and then return to the "Field setting menu" screen.

Even after modifying the data wrongly and pushing [Set / Fix] it is possible to return to the data

before modification by pushing [Return] if the CODE No. (DN) is not changed.

<Fig.2 EEPROM layout diagram>

The EEPROM (IC503) is attached to the IC socket. When detaching the EEPROM, use a tweezers, etc. Be sure to attach the EEPROM by fitting its direction as shown in the figure.



Do not bend the IC lead when replacing.

Table 1.Setting data(CODE No. table(example))

| DN | Item | Setting data | Factory-set value |
|-----|--|------------------------|----------------------------|
| 01 | Filter display delay timer | - | 0002 : 2500H |
| 02 | Dirty state of filter | | 0000 : Standard |
| 03 | Central control address | | 00Un/0099 : Unfixed |
| 04 | Specific indoor unit priority | | 0000 : No priority |
| 06 | Heating suction temperature shift | | 0002 : +2°C |
| 0D | Automatic mode | | 0001 : No automatic |
| 0F | Cooling only | | 0000 : Heat pump |
| 10 | Туре | | Depending on model type |
| 11 | Indoor unit capacity | | According to capacity type |
| 12 | Line address | | 00Un/0099 : Unfixed |
| 13 | Indoor unit address | | 00Un/0099 : Unfixed |
| 14 | Group address | | 00Un/0099 : Unfixed |
| 19 | Flap type (Wind direction adjustment) | | Depending on Type |
| 1E | Temperature range of cooling/heating | | 0003 : 3 deg (Ts±1.5) |
| | automatic SW control point | | 0003 : 3 deg (13±1.3) |
| 28 | Automatic restart of power failure | 0001 : Enable | 0000 : None |
| 2A | Selection of option / Trouble input | | 0002 : None |
| 27 | (TCB-PCUC2E: CN3) | | 0002 . Notile |
| 2B | Themo output SW | | 0000 : Thermo ON |
| 2E | HA terminal (CN61) select | | 0000 : Usual (HA terminal) |
| 31 | Ventilating fan control | | 0000 : Unavailable |
| 32 | Sensor SW | | 0000 : Body sensor |
| 33 | Temperature unit select | 0001 : Fahrenheit (°F) | 0000 : Centigrade (°C) |
| 5D | High ceiling setting | | 0000 : Default setting |
| 60 | Timer setting (wired remote controller) | | 0000 : Available |
| 7A | Change unit 0.5°C or 1.0°C on remote | 0001 : 1°C | 0000 : 0.5°C |
| D0 | Remote controller operation save function | | 0001 : Enable |
| E0 | Region | 0001 : North America | 0000 : Domestic |
| F6 | Presence of Application control kit (TCB-PCUC2E) | | 0000 : None |
| FC | Communication protocol | | 0000 : TCC-LINK |
| FE | FS unit adress | | 00Un/0099 : Unfixed |
| 1Fb | Remote controller operation | | 0000 : Operation possible |
| 1FC | Indoor Unit terminating resistance | | 0000 : OFF |

Table 2. Type: CODE No.10

| Setting data | Туре | Type name abb. |
|--------------|--------------------------------------|------------------|
| 0001 *1 | 4-way Air Discharge Cassette Type | MMU-UB***1HP-UL |
| 0003 | 1-way Cassette Type | MMU-UB***1YHP-UL |

^{*1} EEPROM initial value on the P.C. board for indoor unit servicing.

*2 **A** CAUTION

For the above model. Set the CODE no. to **"E0"** the setting data "0000" (initial) to "0001"

Table 3. Indoor unit capacity: CODE No.11


| Setup data | Model |
|------------|----------|
| 0000*1 | Invalid |
| 0007 | 015 type |
| 0009 | 018 type |
| 0011 | 024 type |

12. DETACHMENTS

| No. | Part name | Procedure | Remarks |
|-----|----------------------|--|--|
| 1 | Air inlet grille | CAUTION Be sure to put on the gloves and long-sleeved shirt at disassembling work; otherwise an injury will be caused by a part, etc. | |
| | | 1. Detachment 1) Stop operation of the air conditioner and then turn off switch of the breaker. 2) Loosen the screw on hook lock grille both side. 3) Slide the hook lock grille on air inlet grille in the direction of arrow 1. (Fig. 1) 4) Push the center hook of air inlet grille in the direction of arrow 2. and open the grille. (Fig. 1) 5) Release the safety strap hook from the air inlet grille. • Do not remove the safety strap screw on the | (Fig. 1) Loosen screw thook lock grille Air inlet grille |
| | | ceiling panel side. 6) Remove the hinges on the air inlet grille from ceiling panel by slide the grille fixture (3 positions) in direction of arrow 3 then pull out the air inlet grille. (Fig. 2) | (Fig. 2) |
| | | 2. Attachment 1) Attach the air inlet grille by reversing the procedure of its removal. 2) Be sure to attach the safety strap to air inlet grille. | Hinges Hinges Hinges Safety strap hook Air inlet grille hook hole |
| 2 | Electric parts cover | 1. Detachment 1) Carry out work of item 1 of ① 2) Remove the fixing screws of the terminal cover and take off. 3) Remove the fixing screw of the electric parts cover, and detach the electric parts cover by slide.(The electric parts cover is clamped onto the hinge.) (Fig. 3) 2. Attachment 1) Attach the electric parts cover by slide. 2) Tighten the fixing screw for fix electric parts cover. 3) Attach the terminal cover and tighten the fixing screws of the terminal cover. | (Fig. 3) Electric parts cover Terminal cover Fixing screw Fixing screw |
| | | CAUTION Make sure insert the terminal cover on the top of hanger. | Terminal cover Hanger |

| No. | Part name | Procedure | Remarks |
|-----|-------------------|--|--|
| 3 | Control P.C.board | 1. Detachment 1) Carry out work of item 1 of ① and item 1 of ②. 2) Remove connectors which are connected from the control P.C. board to the other parts and then remove wiring from the clamp. CN510: Louver motor (20P, White) CN34: Float switch (3P, Red) CN504: Drain pump (2P, White) CN100: TC1 sensor (3P, Brown) CN101: TC2 sensor (2P, Black) CN102: TCJ sensor (2P, Red) CN210: Fan motor (7P, White) CN82: PMV (6P, Blue) Note: Unlock the lock of the housing part and then remove the connector. 3) Unlock the locks of the card edge spacer (4 positions) and then remove the control P.C. board. 2. Attachment 1) Fix the control P.C. board to the card edge spacer. (4 positions) 2) Connect the connector removed in item 1 as before and then fix the wiring with the clamp. 3) Following to work of item 2 of ② and 2 of ① mount the electric parts box cover and the air inlet grille as before. | Card edge spacer |
| 4 | Adjust corner cap | 1. Detachment 1) Pull the edge of the adjust corner cap in the direction of arrow, adjust corner cap will be release from ceiling panel. (Fig. 4) 2. Attachment 1) Hook the strap of the adjust corner cap securely to the pin. 2) Insert the two claws A of the adjust corner cap into the rectangular holes of the ceiling panel in the direction of arrow. (Fig. 5) 3) Push the adjust corner cap so that the two claws B on the back of the cap are fitted. CAUTION Press the two claws B of the adjust corner cap firmly as far as they will go, and then check that the adjust corner cap is closely attached. Failure to do so may result in water leakage. | (Fig. 4) Pull Adjust corner cap Ceiling panel Claws A Strap Claws A Adjust corner cap |

| No. | Part name | Procedure | Remarks |
|-----|-----------|---|--|
| (5) | Louver | 1. Detachment 1) Open the louver until the end (1) then slide the louver in direction of arrow 2 until the end. (Fig. 6) 2) Pull the louver shaft A off from the shaft holder of ceiling panel then slide the louver to opposite side (3) and pull another shaft off. (Fig. 6) 3) Close the louver (4) then pull the louver off from the louver motor both side in direction of arrow 5 (1 side at a time) (Fig. 7) | (Fig. 6) Louver shaft Shaft holder Shaft A |
| | | Attachment Insert the louver hole into the louver motor shaft in direction of arrow 1 (1 side at a time) (Fig. 8) Open the louver (2) and slide in direction of arrow 3 until the end then push the louver shaft A into the shaft holder of ceiling panel. (Fig. 9) Slide the louver to opposite direction (4) then push another shaft to shaft holder (Fig. 9) | (Fig. 7) |
| | | CAUTION Make sure that the plus shape of louver motor shaft completely matches with the plus shape of louver hole. | (Fig. 8) Louver motor shaft Louver hole |
| | | Louver hole Louver motor shaft Plus shape must be match direction before mounting | 150 |
| | | | (Fig. 9) Louver shaft Shaft holder Louver Shaft Shaft holder |
| | | | |
| | | | |



| No. | Part name | Procedure | Remarks |
|-----|------------|---|---------------|
| 7 | Drain pan | 1. Detachment 1) Carry out work of item 1 of ⑥. 2) Remove the cap drain and then drain the water accumulated in the drain pan. (Fig. 17) * When taking off the cap drain, be sure to prepare a bucket, etc. for spilled water. 3) Loosen the fixing screw (Ø5/32" (4mm) x 0.4" (10mm), 7 pcs.) and then remove the drain pan. (Fig. 18) 2. Attachment 1) Tighten the fixing screw to the drain pan with the cabinet. 2) Firmly insert cap drain to drain pan. | (Fig. 17) |
| | | | Drain pan |
| 8 | Drain pump | Detachment Carry out work of item 1 of 7. Remove the drain pump connector (CN504, White, 2P) connected to the control P.C. board and then remove the lead wire from the clamp. Remove the band hose from the drain hose in the direction of arrow. (Fig. 19) Remove the drain hose from drain pump in the direction of arrow. (Fig. 20) Loosen the fixing screw (Ø5/32" (4mm) x 0.4" (10mm), 3 pcs.) and then remove the drain pump from the pump fixture. (Fig. 21) | (Fig. 19) |
| | | 2. Attackment | (Fig. 21) |
| | | 2. Attachment 1) Tighten the fixing screw to the the drain pump with the pump fixture. 2) Insert the drain hose to the drain pump. Note: | |
| | | Insert the drain hose up to the end of the drain pump connecting part, apply band to the white mark position of the hose. | |
| | | Connect the drain pump connector (CN504, White, 2P) to the control P.C. board and then fix it as before with the clamp. | Fixing screws |

| No. | Part name | Procedure | Remarks |
|-----|--------------|---|------------------------------------|
| 9 | Float switch | 1. Detachment 1) Carry out work of item 1 of ⑦. 2) Remove the float switch connector (CN34, Red, 3P) connected to the control P.C. board and then remove the lead wire from the clamp. 3) Loosen the nut fixing float switch then float switch will be release. (Fig. 22) 2. Attachment 1) Tighten the nut fixing float switch to the float switch with the pump fixture. 2) Connect the float switch connector (CN34, Red, 3P) to the control P.C. board and then fix it as before with the clamp. | (Fig. 22) Nut fixing float switch |
| (1) | PMV coil | 1. Detachment 1) Carry out work of item 1 of 7. 2) Remove the PMV coil connector (CN82, Blue, 6P) connected to the control P.C. board and then remove the lead wire from the clamp. 3) Turn the PMV coil slightly follow the direction of arrow (Fig. 23), and then remove the PMV coil follow the direction of arrow (Fig. 24) 2. Attachment 1) Attach the PMV coil as original. Note: • Check the direction of the PMV coil. • Check the claw holes in the PMV coil. are securely placed into four clows on the PMV body. • Check position of the lock part on the binding band and the lead wire. 2) Connect the PMV coil connector (CN82, Blue, 6P) to the control P.C. board and then fix it as before with the clamp. Fit the late wholes on the PMV coil into four claws on the PMV coil connector with the binding band. Lead wire (with protective tube) | (Fig. 24) |
| 11 | Cover pipe | Ensure that the lock part on the binding band comes to the position in the figure. 1. Detachment 1) Carry out work of item 1 of (7). 2) Loosen the fixing screw (Ø5/32" (4mm) x 0.4" (10mm), 7 pcs.) and then remove the cover pipe. (Fig. 25) | (Fig. 25) |
| | | Attachment Tighten the fixing screw to the cover pipe for fix with the side cabinet. | Fixing screw |


| No. | Part name | Procedure | Remarks |
|-----|------------------------------|--|----------------------|
| 12 | Fan motor and cross flow fan | Detachment Carry out work of item 1 of 7 and item 1 of 1. Remove the fan motor connector (CN210, White, 7P) connected to the control P.C. board and then remove the lead wire from the clamp. Loosen the fixing screw (Ø5/32" (4mm) x 0.4" (10mm), 2 pcs.) of heat exchanger. (Fig. 26) Loosen the fixing screw (Ø5/32" (4mm) x 0.4" (10mm), 2 pcs.) of cover motor and then remove the cover motor. (Fig. 27) Loosen the set screw of the cross flow fan by hexagonal wrench. (Fig. 28) Loosen the fixing screw (Ø5/32" (4mm) x 0.4" (10mm), 2 pcs.) of fan motor band and then remove the fan motor and the cross flow fan. (Fig. 29) | (Fig. 26) |
| | | 2. Attachment 1) Check the type name of the fan motor. 2) Keep connector position and arrange the fan motor wire following (Fig. 30) For WDF-340-30CA1, ICF-280-61-3 (Fig. 30) Motor band Fan motor Fan motor Motor band 3) Install the fan motor and the cross flow fan into the original position and then tighten the fixing screw to the fan motor band. 4) Keep distance between main unit and cross flow fan as (Fig. 31) and then tighten set screw to the original position. (Fig. 31) Main unit O 2" (5 mm) Cross flow fan Tighten the fixing screw to the cover motor. 6) Tighten the fixing screw to the heat exchanger. 7) Connect the fan motor connector (CN210, White, 7P) to the control P.C. board and then fix it as before with the clamp. | (Fig. 28) (Fig. 29) |

| No. | Part name | Procedure | Remarks |
|-----|----------------|--|---|
| (3) | Bearing | 1. Detachment 1) Carry out work of item 1 of ②. 2) Push the bearing to inside hole of base bearing follow direction of arrow (Fig. 32) 3) Pull the bearing follow direction of arrow (Fig. 33) | (Fig. 32) Bearing Base bearing |
| | | 2. Attachment 1) Mounting bearing to the original position. | (Fig. 33) Bearing Base bearing |
| 14 | Heat exchanger | 1. Detachment 1) Recover the refrigerant gas. 2) Remove the refrigerant pipe at indoor unit side. 3) Carry out work of item 1 of 7 and item 1 of 1. 4) Remove the heat exchanger sensor (CN100: TC1 sensor, Brown, 3P) (CN101: TC2 sensor, Black, 2P) and (CN102: TCJ sensor, Red, 2P) connected to the control P.C. board and then remove the lead wire from the clamp. 5) Loosen the earth screw and then remove the earth lead wire from the heat exchanger. 6) Loosen the fixing screw (Ø5/32" (4mm) x 0.4" (10mm), 4 pcs.) and then remove the heat exchanger. (Fig. 32) 2. Attachment 1) Tighten the fixing screw to the heat exchanger. 2) Mount the earth lead wire with the earth screw to the heat exchanger. 3) Connect the heat exchanger sensor (TC1, TC2 and TCJ) to the control P.C. board and then fix it as before with the clamp. | (Fig. 34) Heat exchanger Fixing screw Earth screw position for 0241YHP series. Earth screw position for 0151YHP,0181YHP series. |

No. Part name **Procedure** Remarks Installation position (Inside Indoor Unit) 15) Gas Leak Detection 1. Detachment 1) Perform works until opening of the electric parts box cover in works of item 1 of 2 2) Remove the connectors which connect to gas leak detection sensor the control P.C. board CN120 : gas leak detection sensor (4P : White) Remove connect CN120 Electric parts box Gas Leak Detection Sensor position How to install Gas Leak Detection Sensor \triangle Caution : Turn off power supply before installation. 3) Remove the fixing screws (2 positions) of gas leak detection Gas Leak Detection Sensor Accessory Gas leak detection sensor Gas Leak Detection Sensor Screws 2 Pcs. 2. Attachment 1) Open gas leak detection sensor accessory. 2) Insert the gas leak detection sensor into unit and fix it by the screw. 3) Connect the gas leak detection sensor box wiring as original and close the electric parts box cover for fixing. Screws 3 Pcs. Electric parts box cover Connect CN120


13. EXPLODED VIEWS AND PARTS LIST

Indoor Unit 1-way cassette type




| Location | Part No. | Description - | М | Model name MMU-UB****YHP-UL | | |
|----------|----------|--------------------------|------|--------------------------------|------|--|
| No. | | | 0151 | 0181 | 0241 | |
| 201 | 43T70327 | DRAIN HOSE ASSY | 1 | 1 | 1 | |
| 202 | 43T22312 | BEARING ASSY, MOLD | 1 | 1 | 1 | |
| 203 | 43T21532 | FAN-MOTOR(ICF-280-61-3) | | | 1 | |
| 203 | 43T21551 | FAN-MOTOR(WDF-340-30CA1) | 1 | 1 | | |
| 204 | 43T39428 | MOTOR BAND DOWN | 1 | 1 | | |
| 204 | 43T39453 | MOTOR BAND DOWN | | | 1 | |
| 205 | 43T39429 | MOTOR BAND UP | 1 | 1 | | |
| 205 | 43T39454 | MOTOR BAND UP | | | 1 | |
| 206 | 43T20368 | CROSS FLOW FAN ASSY | 1 | 1 | 1 | |
| 207 | 43T44790 | REFRIGERATION CYCLE ASSY | 1 | 1 | | |
| 207 | 43T44791 | REFRIGERATION CYCLE ASSY | | | 1 | |
| 208 | 43T46517 | BODY, PMV | 1 | 1 | 1 | |
| 209 | 43T46515 | COIL, PMV | 1 | 1 | 1 | |
| 210 | 43T19321 | FIX-P-SENSOR | 1 | 1 | 1 | |
| 211 | 43T19333 | HOLDER, SENSOR | 2 | 2 | 2 | |
| 212 | 43T49389 | PIPE COVER ASSY | 1 | 1 | 1 | |
| 213 | 43T77303 | PUMP ASSY | 1 | 1 | 1 | |
| 214 | 43T51317 | FLOAT SWITCH ASSY | 1 | 1 | 1 | |
| 215 | 43T07341 | PUMP FIXTURE | 1 | 1 | 1 | |
| 216 | 43T72392 | DRAIN PAN ASSY | 1 | 1 | 1 | |
| 217 | 43T79322 | DRAIN CAP | 1 | 1 | 1 | |
| 218 | 43T07326 | SCREW PLATE | 3 | 3 | 3 | |
| 219 | 43T83307 | BAND, HOSE | 1 | 1 | 1 | |
| 220 | 43T97315 | SCREW, FIX PANEL | 4 | 4 | 4 | |
| 221 | 43T70326 | HOSE, DRAIN | 1 | 1 | 1 | |
| 222 | 43T83311 | BAND, HOSE | 1 | 1 | 1 | |
| 223 | 43T62407 | CONDUIT MOUNT | 1 | 1 | 1 | |
| 224 | 43T47386 | STRAINER | | | 1 | |
| 224 | 43T47429 | P-STRAINER | 1 | 1 | | |
| 225 | 43T82337 | SOCKET | | | 1 | |
| 225 | 43T82352 | SOCKET | 1 | 1 | | |
| 226 | 43T97320 | NUT, FLARE, 1/4 IN | 1 | 1 | 1 | |
| 226 | 43T97321 | NUT, FLARE, 3/8 IN | | | 1 | |
| 227 | 43T49405 | PLASTIC BONNET 6.35DIA | 1 | 1 | | |
| 227 | 43T49406 | PLASTIC BONNET 9.52DIA | | | 1 | |
| 228 | 43T47386 | STRAINER | 1 | 1 | 1 | |
| 229 | 43T82353 | SOCKET | 1 | 1 | | |
| 229 | 43T82354 | SOCKET | | | 1 | |
| 230 | 43T97322 | NUT, FLARE, 3/8 IN | 1 | 1 | | |
| 230 | 43T97323 | NUT, FLARE, 5/8 IN | | | 1 | |
| 231 | 43T49407 | PLASTIC BONNET 12.7DIA | 1 | 1 | | |
| 231 | 43T49412 | PLASTIC BONNET 15.88DIA | | | 1 | |
| 232 | 43T85963 | INSTALLATION MANUAL | 1 | 1 | 1 | |
| 233 | 43T63422 | PACKING SENSOR ASSEMBLY | 1 | 1 | 1 | |
| 234 | 43T63416 | PLATE FIX SENSOR | 1 | 1 | 1 | |

Electric Parts



| Location | Part No. | Description | Model name MMU-UB***YHP-UL | | |
|----------|----------|--------------------------|-------------------------------|------|------|
| No. | | | 0151 | 0181 | 0241 |
| 401 | 43TNV644 | PC BOARD ASSY (MCC-1797) | 1 | 1 | 1 |
| 402 | 43T60362 | TERMINAL | 1 | 1 | 1 |
| 403 | 43T60078 | TERMIMAL BLOCK | 1 | 1 | 1 |
| 404 | 43T50389 | TA-SENSOR | 1 | 1 | 1 |
| 405 | 43T50477 | TC-SENSOR (TC1) | 1 | 1 | 1 |
| 406 | 43T50387 | TC-SENSOR (TC2) | 1 | 1 | 1 |
| 407 | 43T50386 | TCJ SENSOR (RED) | 1 | 1 | 1 |
| 408 | 43T50351 | HOLDER-TA | 1 | 1 | 1 |
| 409 | 43T6W912 | PC BOARD ASSY (WP-503) | 1 | 1 | 1 |
| 410 | 43T50408 | DUST SENSOR | 1 | 1 | 1 |

RBC-UY42P-UL



| Location No. | Part No. | Description | RBC-UY42P-UL |
|-----------------|----------|------------------------|--------------|
| 301 | 43T22397 | HORIZONTAL LOUVER ASSY | 1 |
| 302 | 43T01344 | PANEL COVER ASSY | 1 |
| 303 | 43T01335 | PANEL COVER ASSY | 1 |
| 304 | 43T09632 | GRILLE ASSY | 1 |
| 305 | 43T19381 | GRILLE HOOK RIGHT | 1 |
| 306 | 43T19382 | GRILLE HOOK LEFT | 1 |
| 307 | 43T80370 | AIR FILTER | 2 |
| 308 | 43T07327 | PANEL FIXED PLATE | 4 |
| 309 | 43T07328 | LOUVER MOTOR COVER | 2 |
| 310 | 43T21478 | MOTOR; STEPPING | 2 |
| 311 | 43T60593 | LEAD-MOTOR | 1 |
| 312 | 43T97331 | SCREW FIX PANEL | 5 |
| 313 | 43T07342 | GRILLE FIXTURE | 3 |

WARNINGS ON REFRIGERANT LEAKAGE

Check of Concentration Limit

The room in which the air conditioner is to be installed requires a design that in the event of refrigerant gas leaking out, its concentration will not exceed a set limit.

The refrigerant R454B which is used in the air conditioner is safe, without the toxicity or combustibility of ammonia, and is not restricted by laws to be imposed which protect the ozone layer. However, since it contains more than air, it poses the risk of suffocation if its concentration should rise excessively. Suffocation from leakage of R454B is almost non-existent. With the recent increase in the number of high concentration buildings, however, the installation of multi air conditioner systems is on the increase because of the need for effective use of floor space, individual control, energy conservation by curtailing heat and carrying power etc.

Most importantly, the multi air conditioner system is able to replenish a large amount of refrigerant compared with conventional individual air conditioners. If a single unit of the multi conditioner system is to be installed in a small room, select a suitable model and installation procedure so that if the refrigerant accidentally leaks out, its concentration does not reach the limit (and in the event of an emergency, measures can be made before injury can occur).

In a room where the concentration may exceed the limit, create an opening with adjacent rooms, or install mechanical ventilation combined with a gas leak detection device.


The concentration is as given below.

Total amount of refrigerant (lbs/ft(kg)) \leq Concentration limit (lbs/ft³(kg/m³)) Min. volume of the indoor unit installed room (ft³(m³))

Refrigerant Concentration limit shall be in accordance with local regulation.

NOTE 1:

If there are 2 or more refrigerating systems in a single refrigerating device, the amounts of refrigerant should be as charged in each independent device.



For the amount of charge in this example:


The possible amount of leaked refrigerant gas in rooms A, B and C is 22.046lbs (10kg). The possible amount of leaked refrigerant gas in rooms D, E and F is 33.069lbs (15kg).

Important


NOTE 2:

The standards for minimum room volume are as follows.

1) No partition (shaded portion)



2) When there is an effective opening with the adjacent room for ventilation of leaking refrigerant gas (opening without a door, or an opening 0.15% or larger than the respective floor spaces at the top or bottom of the door).



3) If an indoor unit is installed in each partitioned room and the refrigerant piping is interconnected, the smallest room of course becomes the object. But when a mechanical ventilation is installed interlocked with a gas leakage detector in the smallest room where the density limit is exceeded, the volume of the next smallest room becomes the object.

