



# Installation, Start-Up, Service and Controls Operation and Troubleshooting

## CONTENTS


	Page
<b>SAFETY CONSIDERATIONS</b> .....	<b>1</b>
<b>GENERAL</b> .....	<b>2</b>
<b>PRE-INSTALLATION</b> .....	<b>3</b>
<b>Inspection</b> .....	<b>3</b>
• UNIT STORAGE	
<b>INSTALLATION</b> .....	<b>3</b>
<b>Step 1 — Check Jobsite</b> .....	<b>3</b>
<b>Step 2 — Check Unit</b> .....	<b>3</b>
<b>Step 3 — Locate Unit</b> .....	<b>4</b>
• ACOUSTICAL CONSIDERATIONS	
• UNIT PLACEMENT AND RIGGING	
• SINGLE-PIECE UNITS (50BVJ)	
• MODULAR UNITS (50BVT,V,W)	
• LOW BOY UNITS	
• HIGH BOY UNITS	
• REMOVE PACKAGING	
• ASSEMBLING MODULAR UNITS	
• PROTECTION	
<b>Step 4 — Check Duct System</b> .....	<b>27</b>
• DUCT STATIC PRESSURE PROBE AND TUBING (VAV ONLY)	
• DUCT HIGH-STATIC (DHS) LIMIT SWITCH (VAV ONLY)	
<b>Step 5 — Make Piping Connections</b> .....	<b>28</b>
• CONDENSER WATER PIPING	
• EVAPORATOR CONDENSATE DRAIN	
• HOT WATER HEATING COIL (OPTIONAL)	
• WATERSIDE ECONOMIZER (OPTIONAL)	
<b>Step 6 — Complete Electrical Connections</b> .....	<b>31</b>
• POWER WIRING	
• CONTROL WIRING (CV ONLY)	
• HOT GAS REHEAT CONTROL (OPTIONAL)	
• ENERGY MANAGEMENT SWITCH (OPTIONAL)	
• ALARM OUTPUT (ALL UNITS)	
• CONTROL WIRING (VAV ONLY)	
<b>Step 7 — Configure Unit Control Components</b> ...	<b>42</b>
• UNIT PROTECTION MODULE	
• WATERSIDE ECONOMIZER (CV UNITS)	
• VARIABLE FREQUENCY DRIVE PARAMETERS (VAV UNITS)	
<b>START-UP</b> .....	<b>44</b>
<b>General</b> .....	<b>44</b>
• CRANKCASE HEATERS	
• CONFIRM THE INPUT POWER PHASE SEQUENCE	
• INTERNAL WIRING	
• RETURN-AIR FILTERS	
• COMPRESSOR MOUNTING	
• REFRIGERANT SERVICE PORTS	
• WATER PIPING	
<b>CV Unit Start-Up</b> .....	<b>44</b>
• EVAPORATOR FAN	
• COOLING	
<b>OPERATION</b> .....	<b>50</b>
<b>Unit Protection Module (UPM)</b> .....	<b>50</b>
• GENERAL DESCRIPTION	
• FEATURES AND SAFETIES	
<b>Sequence of Operation, CV Units — 50BVT,V</b> ....	<b>51</b>
• WATER ECONOMIZER COOLING	
• Y CALL (COOLING OR HEATING)	
<b>SERVICE</b> .....	<b>53</b>
<b>Compressor Rotation</b> .....	<b>53</b>
<b>Fan Motor Replacement</b> .....	<b>53</b>
• CHECK/CHANGE VFD OUTPUT CURRENT LIMIT	
<b>MAINTENANCE</b> .....	<b>53</b>
<b>Cleaning Unit Exterior</b> .....	<b>53</b>
<b>Coil Cleaning</b> .....	<b>53</b>
<b>Inspection</b> .....	<b>53</b>
<b>Air Filters</b> .....	<b>53</b>
<b>Condensate Drains</b> .....	<b>53</b>
<b>Water-Cooled Condensers</b> .....	<b>53</b>
• GRAVITY FLOW METHOD	
• FORCED CIRCULATION METHOD	
<b>Fan Motor Lubrication</b> .....	<b>54</b>
<b>Fan Bearing Lubrication</b> .....	<b>54</b>
<b>Fan Sheaves</b> .....	<b>54</b>
• ALIGNMENT	
<b>Evaporator Fan Performance Adjustment</b> .....	<b>55</b>
• BELT TENSION ADJUSTMENT	
<b>Compressor Oil</b> .....	<b>55</b>
<b>TROUBLESHOOTING</b> .....	<b>55</b>
<b>START-UP CHECKLIST</b> .....	<b>59</b>

## SAFETY CONSIDERATIONS

Installation and servicing of air-conditioning equipment can be hazardous due to system pressure and electrical components. Only trained and qualified service personnel should install, repair, or service air-conditioning equipment.

Untrained personnel can perform basic maintenance functions of cleaning coils and filters and replacing filters. All other operations should be performed by trained service personnel. When working on air-conditioning equipment, observe precautions in the literature, tags and labels attached to the unit, and other safety precautions that may apply.

Follow all safety codes, including ANSI (American National Standards Institute) Z223.1. Wear safety glasses and work gloves. Use quenching cloth for unbrazing operations. Have fire extinguisher available for all brazing operations.

It is important to recognize safety information. This is the safety-alert symbol . When you see this symbol on the unit and in instructions or manuals, be alert to the potential for personal injury.

Understand the signal words DANGER, WARNING, CAUTION, and NOTE. These words are used with the safety-alert symbol. DANGER identifies the most serious hazards which **will** result in severe personal injury or death. WARNING signifies hazards which **could** result in personal injury or death. CAUTION is used to identify unsafe practices, which **may** result in minor personal injury or product and property damage. NOTE is used to highlight suggestions which **will** result in enhanced installation, reliability, or operation.

Improper installation, adjustment, alteration, service, maintenance, or use can cause explosion, fire, electrical shock or other conditions which may cause personal injury or property damage. Consult a qualified installer, service agency, or your distributor or branch for information or assistance with the equipment.

The qualified installer or service provider must use factory-authorized kits, parts, or accessories when servicing or repairing this product. Refer to the individual instructions packaged with the kits or accessories when installing.

### **WARNING**

Before performing service or maintenance operations on unit, turn off main power switch to unit and open all disconnects. More than one disconnect switch may be required to de-energize this equipment. Electric shock hazard can cause injury or death.

### **CAUTION**

Use care in handling, rigging, and setting bulky equipment.

### **WARNING**

**DO NOT USE TORCH** to remove any component. System contains oil and refrigerant under pressure.

To remove a component, wear protective gloves and goggles and proceed as follows:

- Shut off electrical power to unit.
- Recover refrigerant to relieve all pressure from system using both high-pressure and low pressure ports.
- Traces of vapor should be displaced with nitrogen and the work area should be well ventilated. Refrigerant in contact with an open flame produces toxic gases.
- Cut component connection tubing with tubing cutter and remove component from unit. Use a pan to catch any oil that may come out of the lines and as a gauge for how much oil to add to the system.
- Carefully un-sweat remaining tubing stubs when necessary. Oil can ignite when exposed to torch flame.

Failure to follow these procedures may result in personal injury or death.

### **CAUTION**

**DO NOT** re-use compressor oil or any oil that has been exposed to the atmosphere. Dispose of oil per local codes and regulations. **DO NOT** leave refrigerant system open to air any longer than the actual time required to service the equipment. Seal circuits being serviced and charge with dry nitrogen to prevent oil contamination when timely repairs cannot be completed. Failure to follow these procedures may result in damage to equipment.

## **GENERAL**

Omnizone™ 50BV Indoor Packaged units are very flexible for a variety of applications. These self-contained units are available as water source cooling only and heat pump units. The 50BV units are available with either constant volume (CV) or variable air volume (VAV) controls. Finally, Omnizone 50BV units are available in two cabinet styles. Unit sizes 020-034 are constructed in a single-piece, unpainted galvanized cabinet. Unit sizes 034-064 are available as modular units, and can be taken apart for easier installation. Modular units are built using an unpainted, galvanized steel cabinet with steel framework, and can be easily disassembled without breaking the refrigerant lines. See Table 1 for a model number reference by application.

Each unit contains multiple scroll compressors piped in separate refrigerant circuits. Each water-cooled circuit includes a coaxial (tube-in-tube) condenser, TXV (thermostatic expansion valve), individual evaporator coils, and all interconnecting piping. Water source units are shipped fully charged with Puron® (R-410A) refrigerant.

Each unit is equipped with one or two forward-curved centrifugal blowers, to ensure quiet air delivery to the conditioned space. Constant volume units are equipped with a non-inverter rated supply fan motor and operate at a single fan speed. Single piece units include adjustable sheave that can be field adjusted to change the airflow rate. Modular units include a fixed sheave. For VAV applications, the unit is supplied with an inverter duty motor with variable frequency drive(s) (VFD) that automatically adjusts blower speed to maintain a constant, adjustable duct static pressure.

Constant volume units can be controlled by a field provided two-stage cooling only (50BVT) or two-stage heat pump (50BVV) thermostat or field provided digital controller.

VAV units include a factory-installed digital VAV controller that provides compressor staging (two or four stages) based on return air temperature and supply air temperature set points for multi-zone VAV operation.

All 50BV units have removable access panels for easy servicing. These panels allow access to controls, compressors, condensers, VFD(s) (if applicable), evaporator motors, blowers, belts, pulleys, and refrigeration components.

**Table 1 — Model Number Reference By Application Type**

MODEL	TYPE <sup>a</sup>	AVAILABLE CAPACITY	CONSTRUCTION	CONTROLS
<b>50BVJ</b>	Water-Cooled	18 to 30 nominal tons	Single-piece	VAV
<b>50BVT</b>	Water-Cooled	30 to 60 nominal tons	Modular	CV
<b>50BVV</b>	Water-Cooled Heat Pump	30 to 60 nominal tons	Modular	CV
<b>50BVW</b>	Water-Cooled	30 to 60 nominal tons	Modular	VAV

NOTE(S):

- a. All units are cooling only unless specified.

#### **LEGEND**

**CV** — Constant Volume  
**VAV** — Variable Air Volume

## PRE-INSTALLATION

Omnizone™ 50BV units are intended for indoor installation only. Review unit dimensions, piping and wiring connections, service clearances, and other equipment details included in this installation guide, the product data, or the unit submittal prior to equipment installation.

### Inspection

Upon receipt of shipment, carefully check the shipment against the bill of lading. Single piece units ship as a complete assembly. Modular units ship as either one (30 ton low boy), two (30 ton high boy, 40-60 ton low boy), or four (40-60 ton high boy) separate pieces. Make sure all pieces have been received. Inspect the carton or crating of each unit, and inspect each unit for damage on both the interior and exterior. Ensure the shipping company makes proper notation of any shortages or damage on all copies of the freight bill. Concealed damage not discovered during unloading must be reported to the shipping company **within 5 days** of receipt of shipment.

NOTE: It is the responsibility of the purchaser to file all necessary claims with the shipping company.

### UNIT STORAGE

The 50BV units are designed and packaged for indoor storage and use only. If the equipment is not needed for immediate installation upon its arrival at the job site, it should be left in its shipping carton and stored in a clean, dry area. Units should not be stored in a location that is subject to freezing. Units must only be stored or moved in the normal upright position, as indicated by the up arrows on each carton, at all times. **DO NOT STACK UNITS.**

## INSTALLATION

### Step 1 — Check Jobsite

Prior to proceeding with removal of existing equipment and/or installation of new equipment, verify the following:

1. Be sure that the location chosen for unit installation provides ambient temperatures maintained above freezing.
2. Be sure the installation location is isolated from sleeping areas, private offices and other acoustically sensitive spaces.
3. Be sure unit is mounted at a height sufficient to provide an adequate slope of the condensate lines. If an appropriate slope cannot be achieved, a field-supplied condensate pump may be required.
4. On horizontal units, allow adequate room below the unit for condensate drain trap and do not locate the unit above supply piping.
5. Provide sufficient space for duct connection. Do not allow the weight of the ductwork to rest on the unit.
6. Provide adequate clearance for filter replacement and drain pan cleaning. Do not allow piping, conduit, etc. to block filter access.
7. Provide sufficient access to allow maintenance and servicing of the blower and blower motor, compressor, refrigerant circuit, controls, and coils.
8. For units with free return (non-ducted), provide adequate space for proper return airflow. For units installed in closets or mechanical rooms, provide sufficient return grill area for proper airflow.
9. Provide ready access to water valves and fittings, and screwdriver access to unit side panels, discharge collar, and all electrical connections.
10. Where access to side panels is limited, pre-removal of the control box side mounting screws may be necessary for future servicing.

11. For units that are installed in enclosed spaces (such as furred-in closets or behind finished ceilings), provide access panels to allow for the installation, maintenance, service, and removal of the unit.
12. For CV/SAV applications verify that the proper thermostat or third-party DDC exists for unit operation.
13. For VAV applications, verify that VAV air terminal units have been installed or will be installed prior to starting up the unit. Also verify that a control interface will be available.

If any of the above items are missing or incorrect, contact your local Carrier equipment sales office.

**IMPORTANT:** It is the installing contractor's responsibility to ensure that all equipment is installed with proper access for service, start-up, installation of accessories, configuration of control and other components, and equipment removal in accordance with Carrier's recommended service clearances and installation instructions. Please refer to the Carrier Commercial WSHP Warranty Statement (document number 04-570008-01) for details on warranty exclusions regarding equipment, access, removal and clearances.

### Step 2 — Check Unit

Upon receipt of equipment at the job site, inspect the carton or crating of each unit, and inspect each unit for damage on both the interior and exterior. Note any damage and contact your local Carrier equipment sales office.

To prepare the unit for installation, complete the procedures listed below:

1. Verify that the correct unit has been received. Check the unit capacity (tonnage), voltage, orientation, and configuration.
2. Compare the electrical data on the unit nameplate to verify the jobsite power feed (voltage, amperage, MCA) and power protection (MOCP).
3. Verify that the unit is the correct model for the entering water temperature of the job (standard or extended range).
4. Remove the unit packaging, keeping the unit attached to the shipping pallet. Do not destroy packaging. Save for re-installation on the unit if the unit will not be fully installed.
5. Open the unit access panel. Verify that the refrigerant tubing is free of kinks or dents, and that it does not touch other unit components.
6. Check the water piping and piping connections to make sure they are free from defects, kinks, dents, and appear to be water tight. Verify system operating water pressure.
7. Inspect the blower assembly. Verify that the blower has not come loose during shipping. Verify clearance between the blower wheel and the blower housing. Verify free blower rotation.
8. Inspect all electrical connections. Be sure connections are clean and tight at the terminals.
9. Check unit controls. If a CV unit, verify a thermostat or DDC control is available to control the unit. If a VAV unit, verify proper sensors have been provided and a commissioning interface will be available.
10. Remove any shipping brackets from the unit.
11. If a modular unit, verify all modules/pieces have been received.

If any of the above items are missing or incorrect, contact your local Carrier equipment sales office.

Before unit installation, read all manuals and become familiar with the unit and its operation. Thoroughly check out the system before operation. Complete the inspections and instructions listed below to prepare a unit for installation. See Tables 2 and 3 on page 8 for unit physical data and Tables 11 and 12 on pages 40 and 41 for unit electrical data. For unit service clearances refer to Fig. 6 on page 9 and for typical unit dimensions refer to Fig. 7-23 on pages 10-26.

### Step 3 — Locate Unit

Locate unit in an indoor area that allows easy removal of the filters, access panels, and accessories. Make certain enough space is available for service personnel to perform maintenance or repairs. See Fig. 6 for service clearances.

Provide sufficient room to make all water, duct, and electrical connections. If the unit is located in a small mechanical equipment room, make sure adequate space is available for air to return freely to the unit. These units are not approved for outdoor installations and must be installed inside the structure. Do not locate in areas that are subject to freezing.

### ACOUSTICAL CONSIDERATIONS

Proper acoustical considerations are a critical part of every system's design and operation. Each system design and installation should be reviewed for its own unique requirements. For job specific requirements, contact an acoustical consultant for guidance and recommendations. Consider the following recommendations:

1. Locate unit and supply/return ducts away from noise-sensitive locations, including sleeping areas, private offices, and other sound sensitive spaces.
2. Whenever possible, work with the architect to locate the equipment rooms around the perimeters of restrooms, hallways, fire escapes, stair wells, etc., to reduce noise transmission. This allows not only for isolation from radiated sound but also enables the contractor to route duct systems around sensitive locations.
3. Construct the equipment room of concrete block or use a double offset stud wall with interwoven insulation. Seal all penetrations.
4. Design the system for low total static pressure.
5. Use suitable vibration isolation pads or isolation springs according to the design engineer's specifications.
6. A flexible canvas duct connector is recommended on both the supply and return air sides of units to be connected to system ductwork.
7. Use a minimum of 15 ft of return ductwork between the last air terminal or diffuser and the unit.
8. Insulate supply and return ducts with 2 in., 3-lb density insulation.
9. Round duct is recommended. If rectangular ductwork is used, keep aspect ratios as small as possible (i.e., as close to square as possible).
10. Avoid any direct line of sight from return air grilles into the unit's return. If return air is to be ducted to an equipment room, an elbow should be installed within the equipment room.
11. Running a return air drop to near the floor of the room will aid in sound attenuation.
12. Do not exceed the recommended supply duct velocity of 2,000 fpm.
13. Do not exceed the recommended return duct velocity of 1,000 fpm.

14. Use turning vanes on 90-degree elbows.
15. Place isolation springs under each corner of the unit and under compressor sections.
16. Consider the use of compressor sound blankets where the above steps cannot be taken.

### UNIT PLACEMENT AND RIGGING

Ensure that the floor or equipment support structure is structurally strong enough to support the weight of the equipment with minimum deflection. A good, level floor is required for proper unit operation and to ensure proper fit-up and alignment of all bolt-together and union-coupled modules on modular units. Utilize vibration isolation springs or pads between the unit and the support structure or floor to reduce vibration and sound.

Use proper lifting and handling practices to avoid damage to the unit. See Tables 2 and 3 for typical operating weights and Fig. 7-23 for unit dimensions.

NOTE: Unit options may change unit operating weights and dimensions.

### SINGLE-PIECE UNITS (50BVJ)

Single-piece units are shipped as an entire assembly with factory refrigerant charge. Single-piece units are not designed to be disassembled for rigging. Use spreader bars and rigging straps if lifting with a crane to avoid damage to the unit. Otherwise, move with a fork truck using the shipping pallet.

NOTE: Do not rotate or tip any of the main unit sections prior to or during installation.

For single-piece units with take apart construction engineered to order (ETO) package, units will ship a nitrogen charge and split refrigerant piping to allow the unit top and bottom sections to be field separated. Refrigerant charge and field brazing of refrigerant piping will be required. Do not rotate or tip units or unit sections prior to or during installation.

### MODULAR UNITS (50BVT,V,W)

Modular units are shipped in multiple sections (except the low boy size 034) for easy movement and installation without the need for breaking refrigerant lines. Move modular units with a fork truck using the included base rails or use spreader bars and lifting straps as shown in Fig. 1.

NOTE: Do not rotate or tip any of the main unit sections prior to or during installation.

### LOW BOY UNITS

50BV low boy units are short and wide, to allow installation in height restricted areas. Low boy units ship as either one (unit size 034) or two (unit sizes 044-064) separate modules that are mated together during the final installation. See Fig. 18, 19, 22, and 23 for low boy base unit dimensions. The filter rack/economizer section of the low boy unit can be field removed for easier installation. See Fig. 4 and 5 for low boy field splits.

### HIGH BOY UNITS

50BV high boy units are tall and thin and ship in two (size 034) or four (sizes 044-064) modules that require field assembly of fan and main sections. See Fig. 16, 17, 20, and 21 for high boy base unit dimensions. The filter rack/economizer can be removed from the main section to allow all high boy units to fit through a 36 in. wide opening. NOTE: The fan assembly needs to be rotated. See Fig. 2 and 3 for high boy field splits.

Refer to Fig. 7-23 for unit dimensions. Refer to Tables 2 and 3 for physical data.

### REMOVE PACKAGING

Remove all protective plastic and other supports only after the units have been installed. Remove and discard unit top cover protector, filter cover, controller display protector, remove any included shipping supports, and water piping connection packaging.


## ASSEMBLING MODULAR UNITS

50BVT,V,W unit sizes 034-064 ship in pieces. Reassemble the unit. Use the loose hardware provided in the main air-conditioning section and the instructions below.

1. The filter/economizer section ships bolted to the main air-conditioning section and can be removed in the field (high and low boy units). When reattaching the filter/economizer section to the main air-conditioning section, place the filter side of the filter/economizer section facing out and away from the main air-conditioning section.
2. If the unit has two filter/economizer and two main air-conditioning sections (unit sizes 044-064), bolt the remaining filter/economizer section and main air-conditioning section together, as in Step 1.
3. For units with two filter/economizer and two main air-conditioning sections, use the provided unions to assemble the water connections between the two additional sections joined in Step 2.
4. For unit sizes 044-064, connect the condensate drain hoses from the “B” side of the unit to the drain manifold on the “A” side of the unit.
5. For unit sizes 044-064, connect power wiring from the main terminal block in the “A” side of the unit to the power terminal block in the “B” side of the unit.

### CAUTION

Remove all shipping blocks, if any, under blower housing or damage to the fan may occur.




**Fig. 1 — Modular Unit Rigging**


## PROTECTION

Once the units are properly positioned on the jobsite, cover them with either a shipping carton, vinyl film, or an equivalent protective covering. Cap open ends of pipes stored on the jobsite. This precaution is especially important in areas where painting, plastering, or spraying of fireproof material, etc. is not yet complete. Foreign material that accumulates within the units can prevent proper start-up and require costly clean-up operations. Before installing any of the system components, be sure to examine each pipe, fitting, and valve, and remove any dirt or foreign material found in or on these components.







**Fig. 2 — 50BVT, V, W High Boy Field Split (30 Ton)**



**Fig. 3 — 50BVT, V, W High Boy Field Split (40-60 Ton)**



**Fig. 4 — 50BVT,V,W Low Boy Field Split (30 Ton)**



**Fig. 5 — 50BVT,V,W Low Boy Field Split (40-60 Ton)**

**Table 2 — Physical Data — 50BVJ**

UNIT 50BVJ	020	024	028	034
NOMINAL CAPACITY (Tons)	18	20	25	30
OPERATING WEIGHT (lb)	1,090	1,310	1,530	1,650
SHIPPING WEIGHT (lb)	1,180	1,400	1,630	1,750
COMPRESSOR	Copeland Scroll			
Quantity	2	2	2	2
Number of Refrigerant Circuits	2	2	2	2
REFRIGERANT TYPE	R-410A			
Expansion Device	TXV	TXV	TXV	TXV
Operating Charge (oz) per Ckt	130	145	145	288
CONDENSER	Tube-in-Tube Coaxial			
Quantity of Manifolder Coils	2	2	2	2
Nominal Flow Rate (gpm)	50	60	75	90
Water Flow Range (gpm)	36-72	40-80	50-100	60-120
Max Water Working Pressure (psig)	450	450	450	450
Max Refrig. Working Pressure (psig)	600	600	600	600
Water Connection Size (in.)/Type (Qty)	2 FPT(1)	2 FPT(1)	2 FPT(1)	2 FPT(1)
Volume (gal)	3.0	3.4	3.4	3.3
EVAPORATOR COIL				
Rows...Fins/in.	3...14	3...14	3...14	3...14
Total Face Area (sq ft)	18.1	18.1	18.1	27.1
EVAPORATOR FAN				
Qty... Size	2...15x15	2...15x15	2...15x15	2...15x15
Type Drive	Belt	Belt	Belt	Belt
Nominal cfm	7,000	8,000	10,000	12,000
Motor Quantity	2	2	2	2
Motor HP Options	2, 3, 5	2, 3, 5	3, 5	5
Motor Nominal rpm (2, 3 HP)	1,725	1,725	1,725	—
Motor Nominal rpm (5 HP)	3,450	3,450	3,450	3,450

LEGEND

TXV — Thermostatic Expansion Valve


**Table 3 — Physical Data — 50BVT, V, W**

UNIT 50BVT,V,W	034	044	054	064
NOMINAL CAPACITY (Tons)	30	40	50	60
OPERATING WEIGHT (lb)	2,650	4,750	5,500	5,550
SHIPPING WEIGHT (lb)	2,866	4,846	5,700	5,732
COMPRESSOR	Copeland Scroll			
Quantity	2	4	4	4
Number of Refrigerant Circuits	2	4	4	4
REFRIGERANT TYPE	R-410A			
Expansion Device	TXV	TXV	TXV	TXV
Operating Charge (oz per Ckt)	288	160	288	288
CONDENSER	Tube-in-Tube Coaxial			
Quantity of Manifolder Coils	2	4	4	4
Nominal Flow Rate (gpm)	90	120	150	180
Water Flow Range (gpm)	60-120	80-160	100-200	120-240
Max Water Working Pressure (psig)	400	400	400	400
Max Refrig. Working Pressure (psig)	600	600	600	600
Water Connection Size (in.)/Type (Qty)	2.5 FPT(1)	2.5 FPT(1)	3 FPT(1)	3 FPT(1)
Volume (gal)	5.4	7.2	10.8	10.8
EVAPORATOR COIL				
Rows...Fins/in.	4...12	3...12	4...12	4...12
Total Face Area (sq ft)	22.4	44.8	44.8	44.8
EVAPORATOR FAN				
Qty...Size	1...18x18	2...18x18	2...18x18	2...18x18
Type Drive	Belt	Belt	Belt	Belt
Nominal cfm	12,200	16,000	20,000	24,000
Motor HP Options	1	2	2	2
Supply Fan Motor HP Range	7.5, 10, 15, 20	7.5, 10, 15	7.5, 10, 15, 20	7.5, 10, 15, 20
Motor Nominal rpm	1750	1750	1750	1750
Fan rpm (Range)	794-1,256	794-1,256	794-1,256	794-1,256
Motor Bearing Type	Ball	Ball	Ball	Ball
RETURN AIR FILTERS				
Qty...Size (in.)	8...17x27x4	16...17x27x4	16...17x27x4	16...17x27x4

LEGEND

TXV — Thermostatic Expansion Valve






**NOTE(S):**

- Dimensions are in inches.
- Blower Motor and Blower Housing access is required on BOTH SIDES of the unit.

**Fig. 6 — 50BVJ Service Clearances**



UNIT SIZE 50BVJ <sup>a,b</sup>	HEIGHT	WIDTH	DEPTH <sup>c</sup>	CONDENSER WATER CONNECTIONS				DUCT FLANGE	FILTER RACK	REPLACEMENT FILTER SIZE (NOMINAL)
				A	B	C	DIAMETER (FTP)			
020	62.00	80.00	32.00	18.00	8.75	2.75	2	40.00	38.00	20 x 34-1/2 x 1 (4 per unit)  30 x 34-1/2 x 1 (4 per unit, size 034 only)
024	66.50	80.00	32.00	18.00	8.75	2.75	2	40.00	38.00	
028	66.50	80.00	32.00	18.00	8.75	2.75	2	40.00	38.00	
034	86.50	80.00	32.00	17.00	9.00	3.50	2	60.00	58.00	


NOTE(S):

a. All dimensions in inches unless otherwise noted. All dimensions within  $\pm 0.125$  in. Specifications subject to change without notice. Condensate connections are 1.25 in. FPT on sizes 020 through 034.

b. Front of unit is side with water and electrical connections.

c. When SCU Open Controller is installed increase depth by 3.00 inches.

**Fig. 7 — 50BVJ 020-034 Dimensions**




DESCRIPTION	UNIT SIZE 50BVJ a,b,c,d		
	020	024	028
(Filter Qty.)...size	(4) 17 X 34-1/2 X 1 in.	(4) 17 X 34-1/2 X 1 in.	(4) 17 X 34-1/2 X 1 in.
Condensate Connection	1-1/4 in. FPT	1-1/4 in. FPT	1-1/4 in. FPT
Water Connection	2 in. FPT	2 in. FPT	2 in. FPT
D	62 in. [1575]	66.5 in. [1689]	66.5 in.
C	17.5 in. [445]	18.75 in. [476]	18.75 in.
B	31 in. [787]	35 in. [889]	35 in.
A	28 in. [711]	32 in. [813]	32 in.


NOTE(S):

- Dimensions in inches [mm] unless otherwise noted.
- Refer to base unit certified drawing for additional unit dimensions, service clearance, and alternate airflow configurations.
- For all other airflow configuration drawings see SCUBuilder program.
- 50BVJ are Rear Return, Top Supply only.


**Fig. 8 — 50BVJ 020-028 Dimensions**  
**Front Return, Top Supply with Optional Waterside Economizer**




**Rear View**




**Top View**



**Left Side View**



**Front View**



**Right Side View**


DESCRIPTION	UNIT SIZE 50BVJ <sup>a,b,c</sup>		
	020	024	028
(Filter Qty.)...size	(4) 17 X 34-1/2 X 1 in.	(4) 17 X 34-1/2 X 1 in.	(4) 17 X 34-1/2 X 1 in.
Condensate Connection	1-1/4 in. FPT	1-1/4 in. FPT	1-1/4 in. FPT
Water Connection	2 in. FPT	2 in. FPT	2 in. FPT
D	62 in. [1575]	66.5 in. [1689]	66.5 in.
C	17.5 in. [445]	18.75 in. [476]	18.75 in.
B	31 in. [787]	35 in. [889]	35 in.
A	28 in. [711]	32 in. [813]	32 in.

NOTE(S):


- Dimensions in inches [mm] unless otherwise noted.
- Refer to base unit certified drawing for additional unit dimensions, service clearance, and alternate airflow configurations.
- For all other airflow configuration drawings see SCUBuilder program.

**Fig. 9 — 50BVJ 020-028 Dimensions**  
**Rear Return, Top Supply with Optional Waterside Economizer**







**Rear View**




**Top View**



**Left Side View**



**Front View**



**Right Side View**


DESCRIPTION	UNIT SIZE 50BVJ <sub>a,b,c</sub>
	034
(Filter Qty)...Size	(4) 17 X 34-1/2 X 1 in.
Water Connection	2 in. FPT
Condensate Connection	1-1/4 in. FPT

**NOTE(S):**

- Dimensions in inches [mm] unless otherwise noted.
- Refer to base unit certified drawing for additional unit dimensions, service clearance, and alternate airflow configurations.
- For all other airflow configuration drawings see SCUBuilder program.
- 50BVJ are rear return, top supply only.

**Fig. 11 — 50BVJ 034 Dimensions**  
**Rear Return, Top Supply with Optional Waterside Economizer**






DESCRIPTION	UNIT SIZE 50BVJ <sup>a,b,c</sup>		
	020	024	028
(Filter Qty.)...size	(4) 17 X 34-1/2 X 1 in.	(4) 17 X 34-1/2 X 1 in.	(4) 17 X 34-1/2 X 1 in.
Condensate Connection	1-1/4 in. FPT	1-1/4 in. FPT	1-1/4 in. FPT
(Qty) Hot Water Coil Connection	(4) 2-1/8 in. OD	(4) 2-1/8 in. OD	(4) 2-1/8 in. OD
D	62 in. [1575]	66.5 in. [1689]	66.5 in.
C	17.5 in. [445]	18.75 in. [476]	18.75 in.
B	31 in. [787]	35 in. [889]	35 in.
A	28 in. [711]	32 in. [813]	32 in.


NOTE(S):

- Dimensions in inches [mm] unless otherwise noted.
- Refer to base unit certified drawing for additional unit dimensions, service clearance, and alternate airflow configurations.
- For all other airflow configuration drawings see SCUBuilder program.


**Fig. 12 — 50BVJ 020-028 Dimensions**  
**Front Return, Top Supply with Waterside Economizer and Hot Water Coil**




**Rear View**




**Top View**



**Left Side View**



**Front View**




**Right Side View**

DESCRIPTION	UNIT SIZE 50BVJ <sup>a,b,c</sup>		
	020	024	028
(Filter Qty.)...size	(4) 17 X 34-1/2 X 1 in.	(4) 17 X 34-1/2 X 1 in.	(4) 17 X 34-1/2 X 1 in.
Condensate Connection	1-1/4 in. FPT	1-1/4 in. FPT	1-1/4 in. FPT
Water Connection	2 in. FPT	2 in. FPT	2 in. FPT
D	62 in. [1575]	66.5 in. [1689]	66.5 in.
C	17.5 in. [445]	18.75 in. [476]	18.75 in.
B	31 in. [787]	32 in. [889]	32 in.
A	28 in. [711]	32 in. [813]	32 in.


**NOTE(S):**

- Dimensions in inches [mm] unless otherwise noted.
- Refer to base unit certified drawing for additional unit dimensions, service clearance, and alternate airflow configurations.
- For all other airflow configuration drawings see SCUBuilder program.

**Fig. 13 — 50BVJ 020-028 Dimensions**  
**Rear Return, Top Supply with Waterside Economizer and Hot Water Coil**




**Fig. 14 — 50BVJ 034 Dimensions**  
**Front Return, Top Supply with Waterside Economizer and Hot Water Coil**



DESCRIPTION	UNIT SIZE 50BVJ
	034
(Filter Qty)...Size	(4) 17 X 34-1/2 X 1 in.
Water Connection	2 in. FPT
Condensate Connection	1-1/4 in. FPT

**Fig. 15 — 50BVJ 034 Dimensions**  
**Rear Return, Top Supply with Waterside Economizer and Hot Water Coil**



WATER CONNECTIONS	
H <sub>2</sub> O In <sup>a</sup>	2.5
H <sub>2</sub> O Out <sup>a</sup>	2.5
Condensate <sup>a</sup>	0.75
Economizer Condensate	1.25
HW In/Out Sweat Connection	1.38

NOTE(S):

a. FTP Type Connection.

FILTERS	
NOMINAL	QUANTITY
17 x 27 x 4	8

NOTES:

a. Optional hot water coil connections may add up to 3 in. on both the left and right side of the unit increasing the unit width an additional 6 in.

b. Dimensions in inches.


c. Recommended minimum service clearances are as follows:

1. Front and rear: 36 in.
2. Left of right side: 65 in. for coil removal
3. Side opposite coil removal: 36 in.

d. For all other airflow configuration drawings see SCUBuilder program.

e. Dimensions Include Base Rail Height (1.5 in.).

**Fig. 16 — 50BVT,V,W 034 (High-Boy) Dimensions**  
**Rear Return, Front Supply (with or without Waterside Economizer or Hot Water Coil)**



WATER CONNECTIONS	
H <sub>2</sub> O In <sup>a</sup>	2.5
H <sub>2</sub> O Out <sup>a</sup>	2.5
Condensate	1.25
Economizer Condensate	1.25
HW In/Out	1.38

NOTE(S):

a. FTP Type Connection.

FILTERS	
NOMINAL	QUANTITY
17 x 27 x 4	8

NOTES:

a. Optional hot water coil connections may add up to 3 in. on both the left and right side of the unit increasing the unit width an additional 6 in.

b. Dimensions in inches.

c. Recommended minimum service clearances are as follows:


1. Front and rear — 36 in.
2. Left of right side — 65 in. for coil removal
3. Side opposite coil removal — 36 in.

d. For all other airflow configuration drawings see SCUBuilder program.






e. Dimensions Include Base Rail Height (1.5 in.).

**Fig. 17 — 50BVT,V,W 034 (High Boy) Dimensions**  
**Rear Return, Rear Supply (with or without Waterside Economizer or Hot Water Coil)**





**Fig. 18 — 50BVT,V,W 034 (Low-Boy) Dimensions**  
Rear Return, Front Supply (with or without Waterside Economizer or Hot Water coil)



WATER CONNECTIONS	
H <sub>2</sub> O In <sup>a</sup>	2.5
H <sub>2</sub> O Out <sup>a</sup>	2.5
Condensate <sup>a</sup>	0.75
Economizer Condensate	1.25
HW In/Out Sweat Connection	1.38

NOTE(S):

a. FPT Type Connection.

NOTES:

a. Dimensions in inches.

b. Recommended minimum service clearances are as follows:

1. Front and rear — 36 in.

2. Left and right side — 65 in. for coil removal





3. Side opposite coil removal — 36 in.

c. For all other airflow configuration drawings see SCUBuilder program.

d. Dimensions include base rail height (1.5 in.).

FILTERS		
NOMINAL	ACTUAL	QUANTITY
17 x 27 x 4	16.5 x 26.50	8

**Fig. 19 — 50BVT,V,W 034 (Low Boy) Dimensions**  
Rear Return, Top Supply with or without Waterside Economizer or Hot Water Coil



- NOTES:
- Dimensions in inches.
  - Recommended minimum service clearances are as follows:
    - Front and rear — 36 in.
    - Left and right side — 65 in. for coil removal
  - For all other airflow configuration drawings see SCUBuilder program.
  - Dimensions include base rail height (1.5 in.).


WATER CONNECTIONS			
Model	44	54	64
H <sub>2</sub> O In <sup>a</sup>	2.5	3.0	3.0
H <sub>2</sub> O Out <sup>a</sup>	2.5	3.0	3.0
Condensate <sup>a</sup>	0.75	0.75	0.75
Economizer Condensate	1.25	1.25	1.25
HW In/Out Sweat Connection	1.38	1.38	1.38

NOTE(S):


- FPT Type Connection.

FILTERS		
NOMINAL	ACTUAL	QUANTITY
17 x 27 x 4	16.5 x 29.75 x 4	16


**Fig. 20 — 50BVT,V,W 044-064 (High-Boy) Dimensions**  
**Rear Return, Rear Supply with or without Waterside Economizer or Hot Water Coil**



**Fig. 21 — 50BVT,V,W 044-064 (High Boy) Dimensions**  
**Rear Return, Front Supply with or without Waterside Economizer or Hot Water Coil**



**Fig. 22 — 50BVT,V,W 044-064 (Low-Boy) Dimensions**  
**Rear Return, Front Supply with or without Waterside Economizer and Hot Water Coil**



NOTE(S):

a. FPT Type Connection.

FILTERS		
NOMINAL	ACTUAL	QUANTITY
17 x 27	16.5 x 29.75	16

NOTES:

a. Dimensions in inches.

b. Recommended minimum service clearances are as follows:

1. Front and rear — 36 in.
2. Left and right side — 65 in. for coil removal
3. Side opposite coil removal — 36 in.


c. For all other airflow configuration drawings see *SCUBuilder* program.

d. Dimensions include base rail height (1.5 in.).



## Step 4 — Check Duct System

All dual fan units are required to use a “pair of pants” configuration as shown in Fig. 24. Refer to ASHRAE (American Society of Heating, Refrigerating and Air-Conditioning Engineers) standards for the duct connection to unit with 2 fans. An adequate straight length of ducting from the unit should be allowed before elbows are installed. If connecting an elbow directly to the fan outlet, a minimum straight length of 3 fan diameters from the fan outlet is recommended. Elbows should turn in the direction of fan rotation. Abrupt turns will generate air turbulence, excessive noise, and cause vibration, which can lead to component failure. Turning vanes should be used in all short radius bends. Ensure that ducting does not obstruct access to the unit for routine servicing.



**Fig. 24 — Typical Fan Discharge Connections for Multiple Fan Units**

A supply air outlet collar and return air duct flange are provided on all units to facilitate duct connections. Refer to dimensional drawings (Fig. 7-23) for connection sizes and locations.

A flexible canvas duct connector is recommended on both supply and return air sides of the units to be connected to the system ductwork.

All metal ductwork should be adequately insulated to avoid heat loss or gain and to prevent condensation from forming on the duct walls. Uninsulated ductwork is not recommended, as the unit's performance will be adversely affected.

Do not connect discharge ducts directly to the blower outlet(s). The factory filter should be left in place on a free return system.


If the unit will be installed in a new installation, the duct system should be designed in accordance with ASHRAE (American Society of Heating, Refrigeration and Air-Conditioning Engineers) procedures for duct sizing. If the unit will be connected to an existing duct system, check that the existing duct system has the capacity to handle the required airflow for the unit application at an acceptable system static pressure. If the existing duct system is too small, larger ductwork must be installed.

The duct system and diffusers should be sized to handle the design airflow volumes quietly. To maximize sound attenuation of the unit's blower(s), the supply and return air plenums should be insulated for a length of at least 15 ft from the unit. Direct line of sight from return air grilles into the unit's return should be avoided. If return air is to be ducted to an equipment room, an elbow should be installed within the equipment room. Running a return air drop to near the floor of the room will aid in sound attenuation. Avoid transmitting vibrations generated by the movement of air in the ducting to the walls of the building. This is especially important where ductwork penetrates walls. The maximum recommended return air velocity is 1,000 fpm. Lower return air velocities will result in lower sound power levels. The use of round supply duct plenums should be considered, as it will significantly reduce low frequency sound at the equipment room. If rectangular supply plenums are used, the aspect ratio of the duct should be kept as small as possible (i.e., as close to square as possible). The large, flat surface areas associated with large aspect ratio duct systems will transmit sound to the space, and the potential for duct-generated noise is increased. The maximum recommended supply air duct velocity is 2,000 fpm.

## DUCT STATIC PRESSURE PROBE AND TUBING (VAV ONLY)

On VAV systems, the duct static pressure sensor is factory-supplied (ships inside control cabinet) and requires field installation and field provided tubing and pressure pick-up port. The pressure sensor low port should be left open to atmosphere. The pressure sensor high port should be connected with tubing to a pressure pick up port. The pressure pick up port should be installed as close to 2/3 of the way down the duct system in a straight section of duct, away from any turning vanes, take offs, or areas in the duct that could feature turbulence.

Install the duct static pressure probe with the tip facing into the airflow. See Fig. 25.



**Fig. 25 — Duct Static Pressure Probe**

Use 1/4 in. OD approved polyethylene tubing for up to 50 ft (3/8 in. OD for 50 to 100 ft) to connect the probe to the bulkhead fitting mounted above the unit display panel. Carefully route the tubing from the probe to this bulkhead fitting.

The static pressure control should be adjusted so that, at full airflow, all of the remote VAV terminal boxes receive the minimum static pressure required plus any downstream resistance. Control the system to the lowest static pressure set point that will satisfy airflow requirements. Lower static pressure set points reduce total required brake horsepower and reduce generated sound levels.

## DUCT HIGH-STATIC (DHS) LIMIT SWITCH (VAV ONLY)

The duct high static limit switch is a field provided mechanical safety that prevents duct over pressurization. The switch is optional and is field-provided.

**IMPORTANT:** Use tubing that complies with local codes. Improper location or installation of the supply duct pressure tubing will result in unsatisfactory unit operation and poor performance.

## Step 5 — Make Piping Connections

### CONDENSER WATER PIPING

Always follow national and local codes when installing water piping to ensure a safe and proper installation. Connections to the unit should incorporate vibration eliminators to reduce noise and vibration to the building, and shutoff valves to facilitate servicing.

Prior to connecting the unit(s) to the condenser water system, the system should be flushed to remove foreign material that could cause condenser fouling. Install a screen strainer with a minimum of 20 mesh ahead of the condenser inlet to prevent condenser fouling and internal condenser tube damage from foreign material.

Supply and return water piping must be at least as large as the unit connections, and larger for long runs. Refer to the standard piping practice, when sizing, planning, and routing water piping. See dimension drawings (Fig. 7-23) for water connection sizes and locations.

Units are furnished standard with a copper heat exchanger. A cupronickel heat exchanger is also available as a factory-installed option. Copper is adequate for closed loop systems where good quality water is available. In conditions where scale formation or water treatment is questionable, the optional cupronickel heat exchanger should be used. Where the water is especially corrosive or could lead to excessive fouling, intermediate plate frame heat exchangers are recommended.

### ⚠ CAUTION

Galvanized pipe or fittings are not recommended with 50BV units due to the possibility of galvanic corrosion caused by dissimilar metals. When selecting piping materials, use only approved piping materials that meet applicable codes and that will handle the temperatures and pressures that may be experienced in the application. Piping systems will sweat if low temperature fluid is used in the system. For these applications, supply and return water piping should be insulated to protect from condensation damage. The minimum recommended entering water temperature to the unit is 50°F.

The unit is capable of operating with entering water temperatures as low as 50°F in cooling or heat pump heating mode, without the need for head pressure control. If the entering water temperature is expected to be lower, or more stable unit operation is desired, a field-supplied water-regulating valve may be used. The extended range option or field provided coaxial coil insulation should be supplied to prevent condensation, when the entering water temperature can be below the dew point in the unit installation location.

This unit has multiple independent refrigerant circuits with separate condensers. The individual condensers are manifolded together on the waterside to provide easy, single-point water connections. In order to achieve proper head pressure control when a water-regulating valve is used, a temperature-actuated valve is recommended. This allows any of the independent refrigerant circuits to operate while still modulating condenser water flow in response to loop water temperature.

A glycol solution should be used if ambient temperatures are expected to fall below freezing or if the loop water temperature is below 50°F while the unit is operating in heating mode. Refer to Table 4, which lists freezing points of glycol at different concentrations. Water pressure drop will increase and unit performance will decrease with increasing glycol concentrations.

Units with factory-installed waterside economizers have cooling water passing through the economizer and condenser in series while operating in the economizer mode. During normal operation, water bypasses the economizer coil.

**Table 4 — Glycol Freezing Points**

% GLYCOL	FREEZE POINT (° F)	
	Ethylene Glycol	Propylene Glycol
20	18	19
30	7	9
40	-7	-5
50	-28	-27

All manual flow valves used in the system should be of the ball valve design. Globe or gate valves must not be used due to high pressure drops and poor throttling characteristics.

Do not exceed recommended condenser fluid flow rates shown in Tables 5 and 6. Serious damage or erosion of the heat exchanger tubes could occur. Piping systems should not exceed 10 fps fluid velocities to ensure quietness and tube wall integrity. Refer to Tables 5 and 6 for condenser water pressure drop versus flow rate. Flow rates outside of the published range should not be used.

**Table 5 — Condenser Pressure Drop (50BVJ Units)**

FLOW RATE (gpm)	SIZE 020	SIZE 024	SIZE 028	SIZE 034
	Pressure Drop (ft wg)			
35	9.1	—	—	—
40	9.9	6.2	—	—
45	13.5	7.5	—	—
50	14.9	9.3	9.3	—
55	18.4	10.9	10.9	—
60	20.6	12.9	12.9	10.8
65	23.9	14.8	14.9	12.7
70	27.2	17.0	17.2	15.5
75	—	19.2	19.2	16.9
80	—	21.7	22.2	19.7
85	—	—	24.1	21.7
90	—	—	27.8	24.4
95	—	—	30.8	27.1
100	—	—	34.0	29.5
105	—	—	—	33.1
110	—	—	—	36.3
115	—	—	—	39.7
120	—	—	—	43.2

**Table 6 — Condenser Pressure Drop (50BVT,V,W Units)**

FLOW RATE (gpm)	SIZE 034	SIZE 044	SIZE 054	SIZE 064
	Pressure Drop (ft wg)			
60	8.9	—	—	—
70	11.7	—	—	—
80	14.9	6.3	—	—
90	18.4	8.6	—	—
100	24.2	10.4	6.0	—
110	29.3	12.3	7.3	—
120	34.9	14.4	8.8	8.7
130	—	16.7	10.2	10.2
140	—	19.4	11.7	11.8
150	—	22.3	13.2	13.2
160	—	25.3	15.5	14.8
170	—	—	17.4	16.6
180	—	—	19.6	18.3
190	—	—	21.8	21.8
200	—	—	24.2	24.2
210	—	—	—	26.6
220	—	—	—	29.2
230	—	—	—	31.9
240	—	—	—	34.8

Ball valves should be installed in the supply and return lines for unit isolation and water flow balancing.

Pressure and temperature ports are recommended in both the supply and return lines for system flow balancing. These openings should be 5 to 10 pipe diameters from the unit water connections. For thorough mixing and temperature stabilization, wells in the water piping should extend at least 1/2 pipe diameter into the pipe. Measure the condenser waterside pressure drop and refer to Tables 5 and 6 for help to properly set the water flow rate.

Improper fluid flow due to valving, piping, or improper pump operation constitutes abuse that may result in voiding of unit warranty. The manufacturer will not be responsible for damages or failures resulting from improper piping design or piping material selection.

#### EVAPORATOR CONDENSATE DRAIN

The condensate drain connection is 1-1/4 in. FPT and is located on the same side of the unit as the condenser water connections. See dimensional drawings (Fig. 7-23) for exact location.

Drain lines should be pitched away from the unit with a minimum slope of 1/8 in. per foot and conform to all local and national codes.

A trap must be installed in the condensate line to ensure free condensate flow (units are not internally trapped). A vertical air vent is sometimes required to avoid air pockets.


Install a condensate-trapping drain line at the unit's drain connection. See Fig. 26 for correct drain layout.

When calculating trap depth, remember that it is not the total static pressure but the upstream or downstream static resistance that is trapped against. For instance, when calculating the trap depth for a cooling coil condensate pan, trap against the coil pressure drop in that coil section and any other pressure drops upstream of it.

If calculating the trap depth for the cooling coil, use the total static pressure drop (coil plus any other components upstream of it) plus 1 in. ( $P_1 = \text{negative static pressure} + 1 \text{ in.}$ ), as shown in Fig. 26.

Traps must store enough condensate to prevent losing the drain seal at start-up. The "Minimum  $1/2 P_1$ " dimension ensures that enough condensate is stored.

Drain pans should be cleaned periodically to avoid the build-up of dirt and bacterial growth.



NOTE:  $P_1$  equals negative static pressure plus 1 in.

**Fig. 26 — Condensate Drain Layout**

#### HOT WATER HEATING COIL (OPTIONAL)

A factory-installed 1 or 2-row hot water heating coil is available as an option. The coil is supplied with hot water from a boiler through separate piping from the condenser water loop. On CV units all controls, including the hot water valve, freeze protection, and the valve control signal, for heating operation are field-supplied. On VAV units equipped with the factory-installed controller, a hot water valve is provided in the field.

Piping should be in accordance with accepted industry standards and all components rated for the system pressure expected. Pipe coils so that they will drain, and provide a drain and vent.

Always connect the supply to the bottom of the coil, and the return to the top of the coil. Refer to Fig. 7-23 for hot water supply and return piping locations.

Water coils should not be subjected to entering-air temperatures below 38°F to prevent coil freeze-up. If air temperatures across the coil are going to be below this value, use a glycol or brine solution. Use a solution with the lowest concentration that will match the coldest air expected. Excess concentrations will greatly reduce coil capacity. A coil freeze protection system that shuts off the supply fan and opens the hot water valve to 100% should also be considered.

The return air duct system should be carefully designed to get adequate mixing of the return air and outdoor air streams to prevent cold spots on the coil that could freeze.

A 2 or 3-way, field-supplied modulating control valve or a simple two-position on-off valve may be used to control water flow. Select the valve based on the control valve manufacturer's recommendations for size and temperature rating. Select the control valve CV based on pressure drop and flow rate through the coil. This information is available from the SCU/Builder software program or Tables 7 and 8.

Pipe sizes should be selected based on the head pressure available from the pump. Water velocity should not exceed 8 fps. Design the piping system for approximately 3 ft of loss per 100 equivalent ft of pipe. The piping system should allow for expansion and minimize vibration between the unit and piping system.

#### WATERSIDE ECONOMIZER (OPTIONAL)

The optional waterside economizer (pre-cooling coil) is factory-installed and piped internally, in series with the condenser water circuit (Fig. 27). A diverting valve and factory controls are included with the option. The condenser water supply is connected to the economizer water in and the condenser water return is connected to the condenser water out. In addition, when unit is shipped with economizer option, the economizer drain must be connected to a separate trap. Follow the same steps for the economizer drain as described for evaporator condensate drain. An Aquastat is used to modulate water flow through the economizer. The controller is mounted to the low voltage control box. Electrical connections are factory-installed and wired. The remote bulb is shipped internal to the unit and requires field mounting. Care should be taken not to dent the bulb or mis-calibration may occur. The Aquastat has a temperature range adjustment (–30 to 100°F) and is field set. See Fig. 7-23 for connection locations and sizes. See Tables 9 and 10 for economizer waterside pressure drop data.

**Table 7 — Hot Water Coil Pressure Drop  
(50BVJ Units)**

FLOW RATE (gpm)	SIZE 020	SIZE 024	SIZE 028	SIZE 034
Pressure Drop (ft wg)				
10	0.7	0.7	0.7	—
15	1.5	1.5	1.5	—
20	2.6	2.6	2.6	—
25	4.0	4.0	4.0	—
30	5.8	5.8	5.8	0.1
35	7.8	7.8	7.8	0.1
40	10.2	10.2	10.2	0.1
45	12.9	12.9	12.9	0.2
50	15.8	15.8	15.8	0.2
55	—	—	—	0.3
60	—	—	—	0.3
65	—	—	—	0.4

**Table 8 — Hot Water Coil Pressure Drop (50BVT,V,W Units)**


FLOW RATE (gpm)	SIZE 034	SIZE 044	SIZE 054	SIZE 064
Pressure Drop (ft wg)				
45	2.4	—	—	—
50	3.0	—	—	—
55	3.6	—	—	—
60	4.2	—	—	—
65	5.0	—	—	—
70	5.7	—	—	—
75	6.6	—	—	—
80	7.5	—	—	—
85	8.4	—	—	—
90	9.5	2.6	2.5	2.5
100	—	2.9	3.1	3.1
110	—	3.5	3.7	3.7
120	—	4.2	4.2	4.4
130	—	5.1	4.9	5.1
140	—	5.9	5.7	5.9
150	—	6.7	6.6	6.6
160	—	7.6	7.6	7.5
170	—	8.6	8.6	8.5
180	—	9.6	9.6	9.5

**Table 9 — Economizer Pressure Drop Curve  
(50BVJ Units)**

FLOW RATE (gpm)	SIZE 020	SIZE 024	SIZE 028	SIZE 034
Pressure Drop (ft wg)				
35	8.9	—	—	—
40	11.5	11.0	—	—
45	14.4	13.8	—	—
50	17.6	16.9	16.9	—
55	21.1	20.4	20.4	—
60	24.9	24.1	24.1	3.5
65	29.0	28.1	28.2	4.1
70	34.4	32.5	32.5	4.7
75	—	37.1	37.2	5.4
80	—	42.1	42.1	6.1
85	—	—	47.4	6.9
90	—	—	52.9	7.7
95	—	—	58.7	8.5
100	—	—	64.9	9.4
105	—	—	—	10.3
110	—	—	—	11.3
115	—	—	—	12.3
120	—	—	—	13.4

**Table 10 — Economizer Pressure Drop Curve  
(50BVT,V,W Units)**

FLOW RATE (gpm)	SIZE 034	SIZE 044	SIZE 054	SIZE 064
Pressure Drop (ft wg)				
60	13.1	—	—	—
70	17.9	—	—	—
80	23.5	5.8	—	—
90	29.8	7.3	—	—
100	36.9	9.1	9.0	—
110	44.8	11.0	11.0	—
120	53.4	13.1	13.1	13.1
130	—	15.4	15.4	15.4
140	—	17.9	17.9	17.9
150	—	20.6	20.6	20.6
160	—	23.5	23.5	23.5
170	—	—	26.6	26.5
180	—	—	29.8	29.8
190	—	—	33.3	33.2
200	—	—	36.9	36.8
210	—	—	—	40.7
220	—	—	—	44.7
230	—	—	—	48.9
240	—	—	—	53.3



**Fig. 27 — Optional Water Economizer**

## Step 6 — Complete Electrical Connections


Verify that electrical requirements listed on the unit nameplate match available power supply. The unit voltage must be within the range shown in Tables 11 and 12 and phases must be balanced within 2%. Contact the local power company for line voltage corrections. Never operate a motor where a phase imbalance in supply voltage is greater than 2%.

For an unbalanced 3-phase supply voltage, use the following formula to determine the percent of voltage imbalance:

Percent Voltage Imbalance

$$= 100 \times \frac{\text{max voltage deviation from average voltage}}{\text{average voltage}}$$

Example: Supply voltage is 460-3-60.



AB = 452-v

BC = 464-v

AC = 455-v

$$\text{Average Voltage} = \frac{452 + 464 + 455}{3}$$

$$= \frac{1371}{3}$$

$$= 457$$

Determine maximum deviation from average voltage:

(AB) 457 - 452 = 5-v

(BC) 464 - 457 = 7-v

(AC) 457 - 455 = 2-v

Maximum deviation is 7-v.

Determine percent of voltage imbalance:

$$\% \text{ Voltage Imbalance} = 100 \times \frac{7}{457}$$

$$= 1.53\%$$

This amount of phase imbalance is satisfactory as it is below the maximum allowable 2%.

**IMPORTANT:** If supply voltage phase imbalance is more than 2%, contact the local electric utility company immediately.

## POWER WIRING

Properly sized fuses or HACR (Heating, Air-Conditioning and Refrigeration) circuit breakers must be installed for branch circuit protection, according to the national and applicable local codes. See unit nameplate and Tables 11 and 12 for maximum overcurrent protection size.

These units are provided with single point, main power supply terminal blocks. Refer to Fig. 7-23 for conduit connection locations.

See Fig. 29-35 for typical wiring connections. Connect the power leads as indicated on the unit wiring diagrams (found in the Troubleshooting section) and be certain to connect the ground lead to the ground lug in the unit high voltage electrical box. Refer to Tables 11 and 12 for unit electrical data.

## Transformer Settings for 208/230-v Units

Default from the factory, all 208/230-v units are wired for 230-v operation. For jobsites with a 208-v power supply, the primary leads on the unit transformer will need to be changed from 230-v to 208-v. Refer to the unit wiring diagram for details.

## Modular Units

For units with multiple main air-conditioning sections, connect the high voltage compressor power wiring to the line side of the high voltage terminal block in the second section's high voltage electrical box. This wiring is located in the upper portion of the compressor compartment.

Connect the low voltage wiring, located in the compressor compartment, between the two air-conditioning sections using the quick connects provided.

For the supply fan motor, connect the 3-phase high voltage wiring, coiled behind the high voltage panel, to the line side of the supply fan motor terminal block located in the fan compartment. For VAV units, connect the 3-phase high voltage wiring to the line side of VFD.

For units with multiple fans, connect the control power wiring with the quick connects provided at the fan compartment junction.

## CONTROL WIRING (CV ONLY)

A standard commercial thermostat controls constant volume units. These units turn compressors on or off in response to zone temperature. The 50BV 034 unit provides 2 stages of cooling. See Fig. 28 for typical thermostat wiring.

## 50BVT, V 034 Only

This model has 2 independent refrigerant circuits, each capable of being staged independently. Thermostat wiring is connected to the 6-position low voltage terminal block located in the unit electrical box. The 50BV units have a 24 vac control transformer, which provides power to the control circuit and to the thermostat. The thermostat connections and their functions are as follows:

C — Transformer 24 vac (common)

O — Reversing Valve (heat pumps only)

Y1 — 1st Stage Compressor Contactor

Y2 — 2nd Stage Compressor Contactor

R — Transformer 24 vac (hot)

G — Indoor Fan Contactor

H — Dehumidification (on/off HGRH only)



Select an appropriate commercial thermostat that has 2 stages of cooling control. If the unit is a heat pump, make sure the thermostat is capable of heat pump control.

Install the thermostat in the space where the temperature is being controlled, according to the instructions provided with the thermostat.

### ⚠ WARNING

Before wiring the thermostat to the unit, make sure that main power to the unit has been disconnected. Failure to heed this warning could result in personal injury.

To wire the thermostat:

1. Connect the 'C' terminal from the 50BV unit to the 'C' terminal on the thermostat.
2. Wire the 'Y1' and 'Y2' terminals from the 50BV unit to the 'Y1' and 'Y2' terminals, respectively, at the thermostat.
3. Make a connection between the 'G' terminal on the unit and the 'G' terminal on the thermostat.
4. Attach a wire from the 'R' terminal at the unit to the 'R' terminal at the thermostat.
5. **50BVV ONLY:** If the unit is a heat pump, connect a final wire from terminal 'O' on the heat pump unit to the 'W1/O/B' terminal at the thermostat. Configure the thermostat for heat pump operation using the installation instructions provided with the thermostat. Set the reversing valve polarity of the thermostat to 'O'.
6. For units with cycling (on/off) HGRH, connect the thermostat H output to the H terminal on the 50BV. Set up the thermostat to provide an H output only, as the unit will automatically enable the Y1 and O terminals when there is a call for H (dehumidification).

See Fig. 29 for typical thermostat wiring.

### **50BVT, V044-064 Only**

Unit sizes 044-064 have four independent refrigerant circuits. These units can be controlled using a standard commercial, 2-stage thermostat. In this case, the first stage of cooling will turn on compressors 1 and 2, and the second stage will turn on compressors 3 and 4. It is also possible to have 4 stages of cooling, using a suitable field-supplied control method.

For 2-stage thermostat wiring, refer to Fig. 29. Jumpers must be installed between the G and O terminals in Modules A and B. A field-supplied, 24-v pilot relay should be used to energize Y2 on Module B whenever Y1 is energized on Module A. Similarly, a field-supplied 24-v pilot relay should be installed to energize Y4

on Module B whenever Y3 on Module A is energized (Y2 stage of thermostat calls for cooling).

Finally, verify that transformer phasing is consistent between Modules A and B.

### HOT GAS REHEAT CONTROL (OPTIONAL)

#### **On/Off HGRH**

Units with on/off hot gas reheat (HGRH) will include an additional H terminal on the input terminal board for dehumidification control. To enable a call for dehumidification, a 24-v signal must be sent to the H terminal with no voltage applied to the Y1 or O terminals. Any call for cooling (Y1 and O) will override the dehumidification call.

#### **Modulating HGRH**


Units with modulating HGRH will require a field supplied controller capable of controlling the MHGRH valve via a 0-10vdc signal.

### ENERGY MANAGEMENT SWITCH (OPTIONAL)

Units with the energy management switch (EMS) relay can be field wired to disable unit operation when a 24-v signal is removed from a factory-installed normally open relay. Removing the 24-v signal causes the relay to open, which cuts 24-v power to the unit control circuit. All unit components will be disabled when the EMS is deactivated.


### ALARM OUTPUT (ALL UNITS)

If the unit is being connected to a thermostat or DDC control with an alarm indicator, this connection is made at the unit malfunction output on the Unit Protection Module (UPM). See the Unit Protection Module heading in the Set Up Unit Controls section for further details.





**Fig. 28 — Typical Wiring Unit Sizes 034 (Two-Stage Cooling Unit)**






**Fig. 29 — Typical Wiring 40 to 60 Ton Units (Two-Stage Cooling)**




- NOTES:**
- SEE UNIT NAME PLATE FOR ELECTRICAL RATING.
  - ALL FIELD WIRING MUST BE IN ACCORDANCE WITH N.E.C.-N.F.P.A. #70, COPPER CONDUCTORS ONLY 208/230V UNITS. ARE FACTORY WIRING FOR 230V OPERATION. FOR 208V OPERATION, REMOVE ORG LEAD AND REPLACE WITH RED LEAD.
  - FOR ALTERNATE EMS COIL VOLTAGES CONSULT FACTORY.
  - UPM-II INCLUDES BUILT IN: 270-300 SECOND RANDOM START 300 SECOND DELAY ON BREAK 120 SECOND LOW PRESSURE BYPASS
  - "TEST" DIP SWITCH REDUCES DELAYS TO 10 SEC WHEN SET TO "YES. MUST BE SET TO "NO" FOR NORMAL OPERATION. FREEZE SENSOR" WILL OPERATE AT 30°F BY DEFAULT. IF 15°F OPERATION IS REQUIRED, JUMPERS R77 & R17 MUST BE CUT IF FREEZE SENSOR IS NOT INSTALLED. A JUMPER SHALL BE INSTALLED BETWEEN THE FREEZE SENSOR TERMINALS. "ALARM OUTPUT" DIP SWITCH MUST BE SET TO "PULSE" IF BLINKING T-STAT SERVICE LIGHT IS DESIRED.
  - DEFAULT SETTINGS FOR UPM BOARD FROM FACTORY SHOWN. ALSO SEE INSTALLATION MANUAL.
  - ALARM OUTPUT IS NORMALLY OPEN (NO) DRY CONTACT. IF 24 VAC IS NEEDED, CONNECT R TO ALR-COM TERMINAL.
  - 24VAC WILL BE SENSED ON THE ALR-OUT WHEN THE UNIT IS IN ALARM.
  - CHECK PHASE ROTATION ON ALL SCROLL COMPRESSOR UNITS. REVERSE ROTATION WILL DAMAGE THE COMPRESSOR AND VOID UNIT WARRANTY.
  - REVERSING VALVES ARE WIRING TO A SEPARATE TRANSFORMER ON 30 TON UNITS.
  - REVERSING VALVES AND/OR REVERSING VALVE RELAYS ARE NOT PRESENT ON STRAIGHT COOL UNITS AND O IS NOT CONNECTED.

Fig. 30 — 50BVT,V 020-034 Constant Volume Wiring Diagram







- NOTES:
1. SEE UNIT NAME PLATE FOR ELECTRICAL RATING.
  2. ALL FIELD WIRING MUST BE IN ACCORDANCE WITH N.E.C.-N.F.P.A. #70, COPPER CONDUCTORS ONLY.
  3. 208/230V UNITS ARE FACTORY WIRED FOR 230V OPERATION. FOR 208V OPERATION, REMOVE ORG.
  4. 208/230V AND 460V BLOWER MOTORS HAVE 3 SPEED TAPS. 575V BLOWER MOTORS ARE SINGLE SPEED. FOR 460V BLOWER MOTORS, WIRE BLK AND ORG LEADS TOGETHER FOR MED OR LO SPEED OPERATION. CAP ALL UNUSED LEADS.
  5. 15T UNIT INCLUDES 15T. 120 SECOND DELAY ON BREAK.
  6. UPM-1 INCLUDES BUILT IN: 270-300 SECOND RANDOM START 300 SECOND DELAY ON BREAK 120 SECOND LOW PRESSURE BYPASS
  7. "TEST" DIP SWITCH REDUCES DELAYS TO 10 SEC WHEN SET TO "YES. MUST BE SET TO "NO" FOR NORMAL OPERATION.
  8. "FREEZE SENSOR" WILL OPERATE AT 30°F BY DEFAULT, IF 15°F OPERATION IS REQUIRED JUMPER R42 MUST BE CUT. IF FREEZE SENSOR IS NOT INSTALLED A JUMPER SHALL BE INSTALLED BETWEEN R42 AND R43.
  9. "ALARM OUTPUT" DIP SWITCH MUST BE SET TO "PULSE" IF BLINKING T-STAT SERVICE LIGHT IS DESIRED.
  10. DEFAULT SETTINGS FOR UPM BOARD FROM FACTORY SHOWN. ALSO SEE INSTALLATION MANUAL.
  11. "ALARM OUTPUT" DIP SWITCH MUST BE SET TO "PULSE" IF BLINKING T-STAT SERVICE LIGHT IS DESIRED.
  12. CHECK FOR PROPER PHASE ROTATION ON UNITS WITH SCROLL COMPRESSORS. REVERSE ROTATION WILL DAMAGE COMPRESSORS.
  13. AQUASTAT IS CONNECTED TO Y1 ON STRAIGHT COOL UNITS.
  14. FUSE PROTECTION IS REQUIRED ON ABB ACH580 MODELS PER UL-61800-5-1.

- STANDARD COMPONENTS LEGEND:
- TB1 - MAIN UNIT TERMINAL BLOCK
  - TB2 - SECONDARY UNIT TERMINAL BLOCK
  - BM - BLOWER MOTORS (1 PER SECTION)
  - CC - SCROLL COMPRESSORS
  - CCB - 24V CIRCUIT BREAKER
  - CS - CONDENSATE SENSOR (1 PER DRAIN PAN)
  - FS - FREEZE SENSORS
  - HPS - HIGH PRESSURE SWITCHES
  - LPS - LOW PRESSURE SWITCHES
  - MBV - MOTORIZED BALL VALVE
  - MVR - VARIABLE FREQUENCY DRIVES
  - VFD - VARIABLE FREQUENCY DRIVES

STATUS	LED/ALARM BUNK CODES
1	15T PRESSURE FAULT - CKT 1
2	LOW PRESSURE FAULT - CKT 1
3	HIGH PRESSURE FAULT - CKT 2
4	LOW PRESSURE FAULT - CKT 2
5	CONDENSATE FAULT
6	COMPRESSOR FAULT
7	BROWN OUT FAULT

TRANSFORMER	PRIMARY LEAD CLR.
120V	- WHT
208	- RED
240	- ORG
277	- BRN
480	- GRN OR YEL
575	- BLK/RED
	- GRN

- OPTIONAL COMPONENTS LEGEND:
- [ ] AUX - AUXILIARY RELAY (FOR LOOP PUMP, ETC.)
  - [ ] BMR - BLOWER MONITOR RELAY
  - [ ] CBR - COMPRESSOR MONITOR RELAY
  - [ ] CPM - COMPRESSOR PROTECTION MODULE (15 TON AND LARGER COMPRESSORS)
  - [ ] DPS - DIFFERENTIAL PRESSURE SWITCH
  - [ ] DRS - DIFFERENTIAL PRESSURE RELAY
  - [ ] EAS - ENERGY MGMT SYSTEM RELAY
  - [ ] FBS - FUSE BLOCK (WITH ACH580 MODEL ONLY)
  - [ ] FB - FUSE BLOCK
  - [ ] HSL - HIGH TEMP SUCTION LIMIT (WITH H.G. BYPASS ONLY)
  - [ ] PM - PHASE MONITOR

FACTORY WIRE  
FIELD WIRE

Fig. 33 — 50BWW 044-064 Variable Air Volume Wiring Schematic




Fig. 34 — 50BVJW SCU VAV Open DDC Wiring Diagram






Fig. 35 — 50BVJ/W SCU VAV Open DDC Expander Wiring Diagram

**Table 11 — Electrical Data — with Belt Drive Motor, Inverter Duty (50BVJ)**

50BVJ SIZE	RATED VOLTAGE	VOLTAGE MIN/MAX	COMPRESSOR			INDOOR FAN MOTOR			POWER SUPPLY	
			QTY	RLA (EACH)	LRA (EACH)	MOTOR HP	MOTOR QTY	FLA (EACH)	MIN CIRCUIT AMPS	MAX FUSE/ HACR
<b>20</b>	208-230/3/60	197/253	2	29.5	195.0	2.0	2	6.2	78.8	100
			2	29.5	195.0	3.0	2	8.8	84.0	110
			2	29.5	195.0	5.0	2	13.5	93.4	110
	460/3/60	414/506	2	14.7	95.0	2.0	2	3.1	39.3	50
			2	14.7	95.0	3.0	2	4.3	41.7	50
			2	14.7	95.0	5.0	2	6.2	45.5	60
	575/3/60	518/632	2	12.2	80.0	2.0	2	2.0	31.5	40
			2	12.2	80.0	3.0	2	3.5	34.4	45
			2	12.2	80.0	5.0	2	4.5	36.5	45
<b>24</b>	208-230/3/60	197/253	2	30.1	225.0	2.0	2	6.2	80.1	110
			2	30.1	225.0	3.0	2	8.8	85.3	110
			2	30.1	225.0	5.0	2	13.5	94.7	110
	460/3/60	414/506	2	16.7	114.0	2.0	2	3.1	43.8	60
			2	16.7	114.0	3.0	2	4.3	46.2	60
			2	16.7	114.0	5.0	2	6.2	50.0	60
	575/3/60	518/632	2	12.2	80.0	2.0	2	2.0	31.5	40
			2	12.2	80.0	3.0	2	3.5	34.4	45
			2	12.2	80.0	5.0	2	4.5	36.5	45
<b>28</b>	208-230/3/60	197/253	2	48.1	245.0	3.0	2	8.8	125.8	150
			2	48.1	245.0	5.0	2	13.5	135.2	175
	460/3/60	414/506	2	18.6	125.0	3.0	2	4.3	50.5	60
			2	18.6	125.0	5.0	2	6.2	54.3	70
	575/3/60	518/632	2	14.7	100.0	3.0	2	3.5	40.0	50
			2	14.7	100.0	5.0	2	4.5	42.1	50
<b>34</b>	208-230/3/60	197/253	2	55.8	340.0	5.0	2	13.5	152.6	200
	460/3/60	414/506	2	26.9	173.0	5.0	2	6.2	72.9	90

**LEGEND**

**FLA** — Full Load Amps  
**HP** — Horsepower  
**LRA** — Locked Rotor Amps  
**RLA** — Rated Load Amps



**Table 12 — Electrical Data — with Belt Drive Motor, Inverter Duty<sup>a</sup> (50BVV,W,T)**

50BVV/W/T SIZE	RATED VOLTAGE	VOLTAGE MIN/MAX	COMPRESSOR			INDOOR FAN MOTOR			POWER SUPPLY	
			QTY	RLA (EACH)	LRA (EACH)	MOTOR HP	MOTOR QTY	FLA (EACH)	MIN CIRCUIT AMPS	MAX FUSE/HACR
<b>034</b>	208-230/3/60	197/253	2	55.8	340	7.5	1	19.8	145.4	200
			2	55.8	340	10	1	25.4	151.0	200
			2	55.8	340	15	1	37.5	163.1	200
			2	55.8	340	20	1	48.5	174.1	225
	460/3/60	414/506	2	26.9	173	7.5	1	9.9	70.4	90
			2	26.9	173	10	1	12.7	73.2	100
			2	26.9	173	15	1	18.8	79.3	100
			2	26.9	173	20	1	24.3	84.8	110
	575/3/60	518/632	2	23.7	132	7.5	1	7.9	61.2	80
			2	23.7	132	10	1	10.3	63.6	80
			2	23.7	132	15	1	15.1	68.4	90
			2	23.7	132	20	1	19.5	72.8	90
<b>044</b>	208-230/3/60	197/253	4	33.3	239	7.5	2	19.8	181.1	200
			4	33.3	239	10	2	25.4	192.3	225
			4	33.3	239	15	2	37.5	217.6	250
			4	33.3	239	20	2	48.5	242.3	250
	460/3/60	414/506	4	17.9	125	7.5	2	9.9	95.9	110
			4	17.9	125	10	2	12.7	101.5	110
			4	17.9	125	15	2	18.8	113.9	125
			4	17.9	125	20	2	24.3	126.3	150
	575/3/60	518/632	4	12.8	80	7.5	2	7.9	70.2	80
			4	12.8	80	10	2	10.3	75.0	80
			4	12.8	80	15	2	15.1	85.2	100
			4	12.8	80	20	2	19.5	95.1	110
<b>054</b>	208-230/3/60	197/253	4	48.1	245	7.5	2	19.8	244.0	250
			4	48.1	245	10	2	25.4	255.2	300
			4	48.1	245	15	2	37.5	279.4	300
			4	48.1	245	20	2	48.5	301.5	350
	460/3/60	414/506	4	18.6	125	7.5	2	9.9	98.9	110
			4	18.6	125	10	2	12.7	104.5	110
			4	18.6	125	15	2	18.8	116.7	125
			4	18.6	125	20	2	24.3	129.1	150
	575/3/60	518/632	4	14.7	100	7.5	2	7.9	78.3	90
			4	14.7	100	10	2	10.3	83.1	90
			4	14.7	100	15	2	15.1	92.8	100
			4	14.7	100	20	2	19.5	102.7	110
<b>064</b>	208-230/3/60	197/253	4	55.8	340	7.5	2	19.8	276.8	300
			4	55.8	340	10	2	25.4	288.0	300
			4	55.8	340	15	2	37.5	312.2	350
			4	55.8	340	20	2	48.5	334.2	350
	460/3/60	414/506	4	26.9	173	7.5	2	9.9	134.1	150
			4	26.9	173	10.0	2	12.7	139.7	150
			4	26.9	173	15.0	2	18.8	151.9	175
			4	26.9	173	20.0	2	24.3	162.9	175
	575/3/60	518/632	4	23.7	132	7.5	2	7.9	116.5	125
			4	23.7	132	10.0	2	10.3	121.3	125
			4	23.7	132	15.0	2	15.1	130.9	150
			4	23.7	132	20.0	2	19.5	139.7	150

NOTE(S):

a. The presence of an inverter duty motor does not guarantee that the unit will be provided with a VFD; only 50BVW (VAV) units are provided with a VFD as standard.

**LEGEND**

**FLA** — Full Load Amps  
**VFD** — Variable Frequency Drive  
**HP** — Horsepower  
**LRA** — Locked Rotor Amps  
**RLA** — Rated Load Amps

## CONTROL WIRING (VAV ONLY)

See SCU VAV Open Controller manual for complete details regarding control wiring for VAV units. Refer to Table 13 for recommended cable use.

**Table 13 — Recommended Cables**

MANUFACTURER	PART NUMBER
Alpha	2413 or 5463
American	A22503
Belden	8772
Columbia	02525

## Step 7 — Configure Unit Control Components

### UNIT PROTECTION MODULE

All units are factory provided with a unit protection module (UPM) which controls the compressor and has built safeties. See the UPM section of the Controls section of this manual for complete details.

#### Configure Freeze Protection

The default setting for both the air coil and water coil freeze limit trip is 26°F refrigerant temperature for applications without anti-freeze. This can be changed to 15°F refrigerant temperature for applications with anti-freeze by cutting the R30 resistor located on top of the DIP switch SW1 on the UPM board.

### ⚠ CAUTION

If unit is employing a fresh water system (no anti-freeze protection), it is extremely important to have the Freeze1 R30 resistor set to 26°F in order to shut down the unit at the appropriate leaving-water temperature and protect your heat pump from freezing if a freeze sensor is included.

### DIP switch settings

The DIP switches are used to configure most of the available features of the UPM as follows:

- Hard Lockout Mode: two (2) or four (4) strikes
- Manual Reset Mode: Y signal or R signal
- Alarm Output Signal: Constant or Pulse
- Test Mode: Normal or Test operation

Refer to the unit wiring diagram for factory DIP switch default settings.

### Alarm output

Alarm output is normally open (NO) dry contact. If pulse is selected the alarm output will be pulsed. The fault output will depend on the DIP switch setting for ALARM. If it is set to CONST, a constant signal will be produced to indicate a fault has occurred and the unit requires inspection to determine the type of fault. If it is set to PULSE, a pulse signal is produced and a fault code is detected by a remote device indicating the fault. The remote device must have a malfunction detection capability when the UPM board is set to PULSE.

**IMPORTANT:** If 24 vac output is needed R must be wired to ALR-COM terminal; 24 vac will be available to the ALR-OUT terminal when the unit is in the alarm condition.

### WATERSIDE ECONOMIZER (CV UNITS)

When the waterside economizer option is built on CV that do not include a factory controller, it will include an Aquastat for economizer control. The Aquastat can be adjusted between 20°F and 60°F. When the water loop temperature is below the Aquastat set point, the economizer is enabled. The recommended Aquastat set point is 55°F.

### VARIABLE FREQUENCY DRIVE PARAMETERS (VAV UNITS)

Refer to Table 14 for parameter specifics.

**Table 14 — Variable Frequency Drive Parameters (VAV Units)**

ABB ACH 580 VFD — Factory Default Setting			
GROUP NUMBER	PARAMETER NUMBER	DESCRIPTION	VALUE
10	10.24	RO1 source	Damper control
	10.27	RO2 source	Running
	10.30	RO3 source	Fault (-1)
12	12.19	AI1 scaled at AI1 min	0.000
	12.20	AI1 scaled at AI1 max	60.000
	12.17	AI1 min	0.000 V
	12.18	AI1 max	10.000 V
	12.27	AI2 min	4.000 mA
	12.28	AI2 max	20.000 mA
	12.26	AI-2 Filter Time	0.100 s
	12.30	AI2 scaled at AI2 max	50.000
13	13.22	AO2 source	Motor current
	13.27	AO2 source min	0.0
	13.28	AO2 source max	30000.0
	13.29	AO2 out at AO2 src min	4.000 mA
	13.30	AO2 out at AO2 src max	20.000 mA
	13.26	AO2 filter time	0.100 s
20	20.01	Ext1 commands	In1Start
	20.03	Ext1 in1 source	DI1
	20.21	Direction	Forward
	20.40	Run permissive	DI1
	20.41	Start interlock 1	DI4
	20.42	Start interlock 2	Not used

**Table 14 — Variable Frequency Drive Parameters (VAV Units) (cont)**

ABB ACH 580 VFD — Factory Default Setting			
GROUP NUMBER	PARAMETER NUMBER	DESCRIPTION	VALUE
21	21.01	Start mode	Automatic
	21.03	Stop mode	Coast
28	28.11	Ext1 frequency ref1	AI1 scaled
	28.15	Ext2 frequency ref1	Zero
	28.22	Constant frequency sel1	DI3
	28.26	Constant frequency 1	6.00 Hz
	28.72	Freq acceleration time 1	30.000 s
	28.73	Freq deceleration time1	30.000 s
30	30.11	Minimum speed	0.00 rpm
	30.17	Maximum current	0.00 A
	30.13	Minimum frequency	0.00 Hz
	30.14	Maximum frequency	60.00 Hz
31	31.24	Stall function	No action
	31.27	Stall frequency limit	18.00 Hz
	31.28	Stall time	20 s
	31.20	External event (1 type)	Fault
	31.14	Number of trials	0
	31.15	Total trials time	30.0 s
	31.16	Delay time	0.0 s
	31.12	Autoreset section (overcurrent)	Bit 0
	31.12	Autoreset selection (overvoltage)	Bit 1
	31.12	Autoreset selection (undervoltage)	Bit 2
35	31.12	Autoreset selection (AI supervision fault)	Bit 3
	31.12	Autoreset selection (External fault 1)	Bit 11
	35.55	Motor thermal time constant	256 s
	35.51	Motor load curve	110%
40	35.52	Zero speed load	70%
	35.53	Break point	45.00 Hz
	40.32	Set 1 gain	1.00
	40.33	Set 1 integration time	10.0 s
	40.31	Set 1 deviation inversion	Not inverted (Ref —Fbk)
	40.79	Set 1 units	User text
	40.16	Set 1 setpoint 1 source	Internal setpoint
	40.26	Set 1 setpoint min	0.0 PID unit 1
97	40.27	Set1 setpoint max	200000.00 PID unit 1
	40.57	PID1 set1/set2 selection	PID set1
	97.20	U/F ratio	Squared
99	97.01	Switching frequency mode	4 kHz
	97.02	Minimum switching frequency	2 kHz
	96.04	Macro select	Done
	96.05	Macro active	HVAC default
	99.04	Motor control mode	Scalar
	99.07	Motor nominal voltage	*Refer to Motor Nameplate
99	99.06	Motor nominal current	*Refer to Motor Nameplate
	99.09	Motor nominal speed	*Refer to Motor Nameplate
	99.01	Motor nominal power	*Refer to Motor Nameplate

## START-UP

### General

Complete “START-UP CHECKLIST” on page CL-1 before attempting system start-up. Refer to Tables 15-19 on pages 45-49 for performance data of all units.

### CRANKCASE HEATERS

The 50BVT, V, W, 034-064 units include crankcase heaters. Crankcase heaters are energized as long as there is power to the unit.

*Wait 24 hours before starting the compressors to permit warming by the crankcase heaters.*

*AFTER 24 hours, continue with the procedures below.*

### CONFIRM THE INPUT POWER PHASE SEQUENCE

The input power phase rotation sequence must be L1-L2-L3=ABC (or forward or clockwise) as indicated with a phase rotation meter. Incorrect input phase rotation will cause the compressors to rotate in reverse, which results in no cooling capacity.

**IMPORTANT:** On VAV units, fan rotation direction CANNOT be used for the phase sequence check; fan rotation for VAV units with a variable speed drive is independent of the unit input wiring sequence.

If the compressor is rotating in the wrong direction, it may: emit increased noise; shut down due to internal overload protection; have only a small decrease in suction pressure when it starts; or have only a small increase in discharge pressure when it starts. Also, no cooling will be produced at the evaporator. If any of these conditions occurs, refer to the Service section to correct the compressor rotation before continuing.

### INTERNAL WIRING

Check all electrical connections in unit control boxes; tighten as required.

### RETURN-AIR FILTERS

Check that correct filters are installed in filter racks (see Tables 2 and 3). Do not operate unit without return-air filters.

### COMPRESSOR MOUNTING

Compressors are internally mounted on resilient rubber supports. Do not loosen or remove compressor hold down bolts.

### REFRIGERANT SERVICE PORTS

Each refrigerant system has a total of 2 Schrader-type service gauge ports per circuit. One port is located on the suction line, and one on the compressor discharge line. Be sure that caps on the ports are tight.

### WATER PIPING

Verify water piping is properly installed and water flow is present prior to operating unit. Check for water leaks and correct as needed.

### CV Unit Start-Up

#### EVAPORATOR FAN

Fan belt and variable pitch motor pulleys are factory-installed. Be sure that fans rotate in the proper direction.

### COOLING

Set the space thermostat to OFF position. Turn on unit power. Set space thermostat to COOL and the fan to AUTO. Adjust the thermostat temperature setting below room temperature. Compressor 1 starts on closure of contactor (compressors 1 and 2 on 4-circuit units with 2-stage thermostat).

Adjust the thermostat to an even lower setting until the thermostat energizes Y2 (the second cooling stage). Compressor 2 starts on closure of contactor (compressors 3 and 4 on 4-circuit units with 2-stage thermostat).

Adjust the thermostat temperature to a setting just below room temperature. The second stage of cooling should turn off.

Set the thermostat temperature above room temperature. All compressors and the unit fan should now be off.

Set the thermostat below room temperature and confirm that the compressors and fan turn off.

**Table 15 — Fan Performance — 50BVJ020 a,b,c,d,e,f,g**

AIRFLOW (cfm)	AVAILABLE EXTERNAL STATIC PRESSURE (in. wg)														
	0.2			0.4			0.6			0.8			1.0		
	rpm	Watts	bhp	rpm	Watts	bhp	rpm	Watts	bhp	rpm	Watts	bhp	rpm	Watts	bhp
4500	—	—	—	—	—	—	623	459	0.52	—	—	—	—	—	—
5000	—	—	—	—	—	—	638	545	0.61	—	—	—	—	—	—
5500	—	—	—	—	—	—	655	641	0.72	725	755	0.85	—	—	—
6000	—	—	—	608	641	0.72	676	755	0.85	742	878	0.99	807	1001	1.13
6500	—	—	—	636	755	0.85	699	878	0.99	761	1010	1.14	821	1142	1.29
7000	604	774	0.87	666	906	1.02	726	1029	1.16	784	1170	1.32	841	1311	1.48
7500	634	916	1.03	693	1057	1.19	750	1189	1.34	805	1330	1.50	858	1480	1.67
8000	667	1085	1.22	723	1226	1.38	777	1377	1.55	829	1526	1.72	880	1676	1.89
8500	700	1273	1.43	753	1423	1.60	804	1573	1.77	853	1732	1.95	902	1836	2.13
9000	735	1480	1.67	785	1638	1.84	833	1745	2.02	881	1908	2.21	927	2071	2.40

AIRFLOW (cfm)	AVAILABLE EXTERNAL STATIC PRESSURE (in. wg)														
	1.2			1.4			1.6			1.8			2.0		
	rpm	Watts	bhp	rpm	Watts	bhp	rpm	Watts	bhp	rpm	Watts	bhp	rpm	Watts	bhp
4500	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
5000	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
5500	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
6000	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
6500	881	1283	1.44	—	—	—	—	—	—	—	—	—	—	—	—
7000	897	1451	1.63	951	1601	1.80	—	—	—	—	—	—	—	—	—
7500	911	1629	1.83	963	1727	2.00	1014	1881	2.18	—	—	—	—	—	—
8000	930	1781	2.07	979	1935	2.24	1028	2098	2.43	1076	2260	2.62	1124	2422	2.81
8500	950	1989	2.31	997	2152	2.50	1043	2323	2.69	1089	2485	2.88	1134	2697	3.09
9000	973	2233	2.59	1018	2404	2.79	1062	2576	2.99	1106	2779	3.18	1149	2960	3.39

NOTE(S):

- Units are available with the following motor and drive combinations: 2, 3, 5 hp standard drive; 2, 3 hp medium static drive. For 2, 3 hp standard drives, the drive range is 753 to 952 rpm. For medium static drives, the drive range is 872 to 1071 rpm. For 5 hp standard drives, the drive range is 967 to 1290 rpm.
- Bold italics** indicates field-supplied drive required.
- Do not operate in shaded area.
- Static pressure losses must be applied to external static pressure before entering the fan performance table.
- Interpolation is permitted; extrapolation is not.
- Fan performance is based on filter, unit casing, and wet coil losses.
- Bhp values are per fan. Watts values are per motor. Unit has 2 supply fans and 2 motors.

LEGEND

**bhp** — Brake Horsepower Input to Supply Fan  
**Watts** — Input Power to Supply Fan Motor

**Table 16 — Fan Performance — 50BVJ024 a,b,c,d,e,f,g**

AIRFLOW (cfm)	AVAILABLE EXTERNAL STATIC PRESSURE (in. wg)														
	0.2			0.4			0.6			0.8			1.0		
	rpm	Watts	bhp	rpm	Watts	bhp	rpm	Watts	bhp	rpm	Watts	bhp	rpm	Watts	bhp
5,000	—	—	—	—	—	—	638	545	0.61	—	—	—	—	—	—
5,500	—	—	—	—	—	—	655	641	0.72	725	755	0.85	—	—	—
6,000	—	—	—	608	641	0.72	676	755	0.85	742	878	0.99	807	1001	1.13
6,500	—	—	—	636	755	0.85	699	878	0.99	761	1010	1.14	821	1142	1.29
7,000	604	774	0.87	666	906	1.02	726	1029	1.16	784	1170	1.32	841	1311	1.48
7,500	634	916	1.03	693	1057	1.19	750	1189	1.34	805	1330	1.50	858	1480	1.67
8,000	667	1085	1.22	723	1226	1.38	777	1377	1.55	829	1526	1.72	880	1676	1.89
8,500	700	1273	1.43	753	1423	1.60	804	1573	1.77	853	1732	1.95	902	1836	2.13
9,000	735	1480	1.67	785	1638	1.84	833	1745	2.02	881	1908	2.21	927	2071	2.40
9,500	769	1713	1.93	816	1827	2.12	863	1989	2.31	908	2152	2.50	952	2323	2.69
10,000	802	1908	2.21	848	2080	2.41	892	2251	2.61	936	2422	2.81	978	2624	3.01

AIRFLOW (cfm)	AVAILABLE EXTERNAL STATIC PRESSURE (in. wg)														
	1.2			1.4			1.6			1.8			2.0		
	rpm	Watts	bhp	rpm	Watts	bhp	rpm	Watts	bhp	rpm	Watts	bhp	rpm	Watts	bhp
5,000	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
5,500	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
6,000	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
6,500	881	1283	1.44	—	—	—	—	—	—	—	—	—	—	—	—
7,000	897	1451	1.63	951	1601	1.80	—	—	—	—	—	—	—	—	—
7,500	911	1629	1.83	963	1727	2.00	1014	1881	2.18	—	—	—	—	—	—
8,000	930	1781	2.07	979	1935	2.24	1028	2098	2.43	1076	2260	2.62	1124	2422	2.81
8,500	950	1989	2.31	997	2152	2.50	1043	2323	2.69	1089	2485	2.88	1134	2697	3.09
9,000	973	2233	2.59	1018	2404	2.79	1062	2576	2.99	1106	2779	3.18	1149	2960	3.39
9,500	996	2494	2.89	1039	2697	3.09	1081	2879	3.30	1123	3060	3.51	1165	3251	3.73
10,000	1020	2806	3.22	1061	2988	3.42	1102	3178	3.64	1142	3360	3.85	1182	3559	4.08

NOTE(S):

- Units are available with the following motor and drive combinations: 2, 3, 5 hp standard drive; 2, 3 hp medium static drive. For 2, 3 hp standard drives, the drive range is 753 to 952 rpm. For medium static drives, the drive range is 872 to 1071 rpm. For 5 hp standard drives, the drive range is 967 to 1290 rpm.
- Bold italics** indicates field-supplied drive required.
- Do not operate in shaded area.
- Static pressure losses must be applied to external static pressure before entering the fan performance table.
- Interpolation is permitted: extrapolation is not.
- Fan performance is based on filter, unit casing, and wet coil losses.
- Bhp values are per fan. Watts values are per motor. Unit has 2 supply fans and 2 motors.

LEGEND

**bhp** — Brake Horsepower Input to Supply Fan  
**Watts** — Input Power to Supply Fan Motor

Table 17 — Fan Performance — 50BVJ028 a,b,c,d,e,f,g

AIRFLOW (cfm)	AVAILABLE EXTERNAL STATIC PRESSURE (in. wg)														
	0.2			0.4			0.6			0.8			1.0		
	rpm	Watts	bhp	rpm	Watts	bhp	rpm	Watts	bhp	rpm	Watts	bhp	rpm	Watts	bhp
6,250	—	—	—	624	678	0.79	689	797	0.92	753	917	1.06	815	1045	1.21
7,000	604	751	0.87	666	880	1.02	726	999	1.16	784	1136	1.32	841	1273	1.48
7,500	634	889	1.03	693	1027	1.19	750	1155	1.34	805	1291	1.50	858	1437	1.67
8,000	667	1054	1.22	723	1191	1.38	777	1337	1.55	829	1482	1.72	880	1627	1.89
8,500	700	1237	1.43	753	1382	1.60	804	1528	1.77	853	1682	1.95	902	1836	2.13
9,000	735	1437	1.67	785	1591	1.84	833	1745	2.02	881	1908	2.21	927	2071	2.40
9,500	769	1664	1.93	816	1827	2.12	863	1989	2.31	908	2152	2.50	952	2323	2.69
10,000	802	1908	2.21	848	2080	2.41	892	2251	2.61	936	2422	2.81	978	2624	3.01
10,500	835	2179	2.53	879	2350	2.73	921	2531	2.93	963	2742	3.14	1004	2924	3.35
11,000	870	2467	2.86	912	2688	3.08	952	2870	3.29	992	3060	3.51	1032	3251	3.73
11,500	904	2824	3.24	944	3015	3.46	983	3206	3.67	1022	3405	3.90	1060	3605	4.13
12,000	937	3169	3.63	976	3369	3.86	1014	3569	4.09	1051	3777	4.33	1088	3985	4.57
12,500	972	3550	4.07	1010	3759	4.31	1046	3967	4.55	1082	4184	4.80	—	—	—

AIRFLOW (cfm)	AVAILABLE EXTERNAL STATIC PRESSURE (in. wg)														
	1.2			1.4			1.6			1.8			2.0		
	rpm	Watts	bhp	rpm	Watts	bhp	rpm	Watts	bhp	rpm	Watts	bhp	rpm	Watts	bhp
6,250	877	1173	1.36	—	—	—	—	—	—	—	—	—	—	—	—
7,000	897	1410	1.63	951	1555	1.80	—	—	—	—	—	—	—	—	—
7,500	911	1582	1.83	963	1727	2.00	1014	1881	2.18	—	—	—	—	—	—
8,000	930	1781	2.07	979	1935	2.24	1028	2098	2.43	1076	2260	2.62	1124	2422	2.81
8,500	950	1989	2.31	997	2152	2.50	1043	2323	2.69	1089	2485	2.88	1134	2697	3.09
9,000	973	2233	2.59	1018	2404	2.79	1062	2576	2.99	1106	2779	3.18	1149	2960	3.39
9,500	996	2494	2.89	1039	2697	3.09	1081	2879	3.30	1123	3060	3.51	1165	3251	3.73
10,000	1020	2806	3.22	1061	2988	3.42	1102	3178	3.64	1142	3360	3.85	1182	3559	4.08
10,500	1044	3106	3.56	1084	3296	3.78	1123	3496	4.01	1161	3686	4.23	1200	3886	4.45
11,000	1070	3451	3.95	1109	3641	4.17	1146	3840	4.40	1184	4049	4.64	1220	4248	4.87
11,500	1097	3804	4.36	1134	4012	4.60	1170	4221	4.84	1206	—	—	—	—	—
12,000	1124	4193	4.81	—	—	—	—	—	—	—	—	—	—	—	—
12,500	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—

NOTE(S):

- Units are available with the following motor and drive combinations: 3, 5 hp standard drive; 3 hp medium static drive. For 3 hp standard drives, the drive range is 753 to 952 rpm. For medium static drives, the drive range is 872 to 1071 rpm. For 5 hp standard drives, the drive range is 967 to 1290 rpm.
- Bold italics** indicates field-supplied drive required.
- Do not operate in shaded area.
- Static pressure losses must be applied to external static pressure before entering the fan performance table.
- Interpolation is permitted; extrapolation is not.
- Fan performance is based on filter, unit casing, and wet coil losses.
- Bhp values are per fan. Watts values are per motor. Unit has 2 supply fans and 2 motors.

LEGEND

**bhp** — Brake Horsepower Input to Supply Fan  
**Watts** — Input Power to Supply Fan Motor

Table 18 — Fan Performance — 50BVJ034 a,b,c,d,e,f,g

AIRFLOW (cfm)	AVAILABLE EXTERNAL STATIC PRESSURE (in. wg)														
	0.2			0.4			0.6			0.8			1.0		
	rpm	Watts	bhp	rpm	Watts	bhp	rpm	Watts	bhp	rpm	Watts	bhp	rpm	Watts	bhp
9,000	639	1187	1.36	693	1334	1.53	745	1490	1.71	795	1646	1.89	843	1802	2.07
9,500	665	1362	1.56	717	1518	1.74	766	1674	1.92	814	1839	2.11	861	2004	2.30
10,000	693	1555	1.78	743	1720	1.97	791	1894	2.17	836	2058	2.36	881	2232	2.56
10,500	721	1775	2.03	769	1949	2.23	815	2122	2.43	859	2296	2.63	902	2478	2.84
11,000	749	2004	2.30	795	2186	2.51	840	2369	2.71	882	2551	2.92	924	2742	3.14
11,500	777	2259	2.59	822	2451	2.81	864	2642	3.03	906	2833	3.25	946	3024	3.47
12,000	805	2533	2.90	848	2733	3.13	889	2933	3.36	929	3133	3.59	968	3333	3.82
12,500	835	2842	3.26	877	3042	3.49	917	3251	3.73	955	3460	3.97	993	3668	4.20
13,000	865	3169	3.63	905	3378	3.87	944	3596	4.12	981	3813	4.37	1018	4021	4.61
13,500	894	3514	4.03	933	3741	4.29	971	3958	4.54	1007	4184	4.80	—	—	—
14,000	924	3895	4.46	961	4121	4.72	998	4356	4.99	—	—	—	—	—	—

AIRFLOW (cfm)	AVAILABLE EXTERNAL STATIC PRESSURE (in. wg)														
	1.2			1.4			1.6			1.8			2.0		
	rpm	Watts	bhp	rpm	Watts	bhp	rpm	Watts	bhp	rpm	Watts	bhp	rpm	Watts	bhp
9,000	890	1958	2.24	936	2122	2.43	982	2296	2.63	1026	2460	2.82	1071	2642	3.03
9,500	906	2168	2.48	950	2341	2.68	994	2515	2.88	1037	2688	3.08	1079	2870	3.29
10,000	925	2405	2.76	967	2578	2.96	1009	2760	3.16	1051	2942	3.37	1092	3124	3.58
10,500	944	2660	3.05	986	2842	3.26	1026	3024	3.47	1066	3215	3.68	1105	3405	3.90
11,000	965	2924	3.35	1004	3115	3.57	1043	3315	3.80	1082	3505	4.02	1120	3705	4.25
11,500	985	3224	3.69	1024	3414	3.91	1062	3614	4.14	1099	3813	4.37	1136	4021	4.61
12,000	1006	3532	4.05	1044	3732	4.28	1080	3940	4.52	1117	4148	4.75	1152	4356	4.99
12,500	1030	3877	4.44	1066	4085	4.68	1102	4302	4.93	—	—	—	—	—	—
13,000	1053	4239	4.86	—	—	—	—	—	—	—	—	—	—	—	—
13,500	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
14,000	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—

NOTE(S):

- Units are available with the following motor and drive combinations: 5 hp standard drive. For 5 hp standard drives, the drive range is 967 to 1290 rpm.
- Bold italics** indicates field-supplied drive required.
- Do not operate in shaded area.
- Static pressure losses must be applied to external static pressure before entering the fan performance table.
- Interpolation is permitted; extrapolation is not.
- Fan performance is based on filter, unit casing, and wet coil losses.
- Bhp values are per fan. Watts values are per motor. Unit has 2 supply fans and 2 motors.

LEGEND

**bhp** — Brake Horsepower Input to Supply Fan  
**Watts** — Input Power to Supply Fan Motor



**Table 19 — Blower Performance**

50BV V,W,T SIZE	NOMINAL AIRFLOW (cfm)	AIRFLOW (cfm)	EXTERNAL STATIC PRESSURE (in. wg, WET COIL AND FILTER INCLUDED)											
			2.00		2.50		3.00		3.50		4.00		4.50	
			rpm	HP	rpm	HP	rpm	HP	rpm	HP	rpm	HP	rpm	HP
034	12,200	9,500	813	7.5	871	15	949	10	1034	15	1111	15	1172	15
		10,000	813	7.5	916	10	949	10	1034	15	1111	15	1172	15
		10,500	842	10	916	10	982	15	1034	15	1111	15	1172	15
		11,000	842	10	916	10	982	15	1034	15	1111	15	1172	15
		11,500	871	15	916	15	982	15	1034	15	1111	15	1172	20
		12,000	871	15	949	15	982	15	1072	15	1111	20	1172	20
		12,500	871	15	949	15	1034	15	1072	20	1111	20	1172	20
044	16,000	13,500	916	15	982	20	1034	20	1072	20	1149	20	—	—
		13,000	794	7.5	916	7.5	982	7.5	1111	7.5	1200	10	1256	10
		14,000	794	7.5	871	7.5	982	7.5	1072	10	1172	10	1256	10
		15,000	794	7.5	871	7.5	982	7.5	1072	10	1172	10	1256	15
		16,000	794	7.5	871	7.5	982	7.5	1034	10	1149	10	1256	15
		17,000	794	7.5	871	7.5	982	7.5	1034	10	1111	15	1214	15
		18,000	813	7.5	871	7.5	949	10	1034	10	1111	15	1172	15
054	20,000	19,000	813	7.5	871	15	949	10	1034	15	1111	15	1172	15
		16,000	794	7.5	871	7.5	982	7.5	1034	10	1149	10	1256	15
		17,000	794	7.5	871	7.5	982	7.5	1034	10	1111	15	1214	15
		18,000	813	7.5	871	8	949	10	1034	10	1111	15	1172	15
		19,000	813	7.5	871	15	949	10	1034	15	1111	15	1172	15
		20,000	813	7.5	916	10	949	10	1034	15	1111	15	1172	15
		21,000	842	10	916	10	982	15	1034	15	1111	15	1172	15
		22,000	842	10	916	10	982	15	1034	15	1111	15	1172	15
		23,000	871	15	916	15	982	15	1034	15	1111	15	1172	20
064	24,000	24,000	871	15	949	15	982	15	1072	15	1111	20	1172	20
		19,000	813	7.5	871	15	949	10	1034	15	1111	15	1172	15
		20,000	813	7.5	916	10	949	10	1034	15	1111	15	1172	15
		21,000	842	10	916	10	982	15	1034	15	1111	15	1172	15
		22,000	842	10	916	10	982	15	1034	15	1111	15	1172	15
		23,000	871	15	916	15	982	15	1034	15	1111	15	1172	20
		24,000	871	15	949	15	982	15	1072	15	1111	20	1172	20
064	24,000	25,000	871	15	949	15	1034	15	1072	20	1111	20	1172	20

## OPERATION

### Unit Protection Module (UPM)

#### GENERAL DESCRIPTION

The Unit Protection Module (UPM) as shown in Fig. 36 is a printed circuit board (PCB) included in all units, that interfaces with the thermostat for constant volume units or the digital direct controller on variable air volume units.

The main purpose of this device is to protect the compressors by monitoring the different states of switches and sensors of each refrigerant circuit. This device provides time delays and protects the unit against freezing of the water and refrigerant heat exchangers as well as condensate overflow when the appropriate sensors are installed.

#### FEATURES AND SAFETIES

Alarm output is Normally Open (NO) dry contact. If 24 vac output is needed, R must be wired to the ALR-COM terminal; 24 vac will be available on the ALR-OUT terminal when the unit is in alarm condition. If pulse is selected, the alarm output will be pulsed.

#### Power Random Start-Up

This feature prevents multiple units sharing same electrical circuit or network from starting at the same time. It assures that units sharing the same electrical circuit do not demand high inrush currents simultaneously when starting back up after a power failure.

If the controller has been completely powered down for more than 28 milliseconds, a random delay is initiated. If the controller is set to normal operation (test switch set to NO), then typically the unit will start within the time range of 270 to 300 seconds.

In order for the random sequence to initiate the unit power must be removed completely.

**IMPORTANT:** If the board is set to "TEST" mode through the "TEST" DIP switch, SW1 delay will be 10 seconds.

#### Anti-Short Cycle Delay

This feature protects the compressor short cycling if the Y call is set and removed. The anti-short cycle delay is 300 seconds on break during normal operation.

NOTE: If the board is set to test mode through the "TEST" DIP switch, the delay will be 5 seconds.

### High and Low Pressure Protection

The UPM monitors the state of the high and low pressure switch inputs of each refrigerant circuit, HP1, LP1, HP2, and LP2. These switches must be closed for the controller to energize the compressor output (CC1 and CC2). The CC output will only be energized when the switches are closed and the anti-short cycle (and/or random start-up when applicable) has expired.

#### High Pressure Protection

If the HP1 or HP2 switches are open upon a Y1 or Y2 call, the UPM will not energize the respective CC1 or CC2 outputs; the corresponding compressor will remain off, the fault LED will flash 1 time for the HP1 and 3 times for HP2, and the alarm contact will remain off.

If a compressor is running in normal mode on a Y call (Y1 or Y2 or both) and the high pressure switch opens, the UPM will shut down the compressor output and will keep it off until the switch closes and the anti-short cycle has expired. The controller will keep track of the number of times the switch opens; if, within a 1-hour period, the switch opens the number of times set via the DIP switch, the controller will shut down the compressor and perform a hard lockout condition. Under this condition the alarm contact will be energized.

The UPM allows the user to configure the counts that the HP will be allowed to open within 1 hour before the UPM performs a hard lockout on the compressor. The user can select either two or four times by changing switch 4 on the DIP switch SW1 on the UPM board.

#### Low Pressure Protection

If the LP1 or LP2 switches are open upon a Y1 or Y2 call (Y1 or Y2 or both) the UPM will not energize the CC1 or CC2 outputs; the corresponding compressor will remain off, the fault LED will flash 2 times for the LP1 and 4 times for the LP2, and the alarm contact will remain off.

If the compressor is running in normal mode on a Y call (Y1 or Y2 or both) and the low pressure switch opens, the UPM will keep the compressor running for 2 minutes. If the condition remains after this period of time, the compressor will shut down and the UPM will start a soft lockout. The UPM will flash 2 times for the LP1 and 4 times for the LP2 and the alarm contact will remain off.

If the switches close, the UPM will start the compressor after the anti-short cycle has expired and UPM will energize the compressor output.




Fig. 36 — Two-Stage Unit Protection Module

**IMPORTANT:** To exit the hard lockout the controller must be reset from the Y or R terminal by removing the power from the selected terminal. The user can choose which will be the reset point via the DIP switch SW1.

### Ground


The UPM controller takes its ground reference from the unit chassis which is connected to the controller via the C-GND spade terminal.

### DIP Switch Settings

The DIP switch is used to configure most of the available features of the UPM as follows:

- Alarm mode, Constant or Pulse
- Reset mode, Y signal or R signal
- Lockout mode, 2 or 4 strikes
- Test mode, Normal or Test operation

The settings shown in Fig. 37 are factory default. The unit wiring diagram is the ultimate guide for factory DIP switch default settings.



**Fig. 37 — Dip Switch Settings**

The following table is available on the UPM board as well and it depicts the switch position and its associated functionality (Table 20).

**Table 20 — UPM Dip Switch Configuration**

4	LOCKOUT	4	2
3	RESET	R	Y
2	ALARM	CONT	PULSE
1	TEST	YES	NO

### Selectable Alarm Mode

The UPM controller can be configured to have either a constant signal or a pulse.


If constant (CONT) is selected the UPM will provide a closed contact until the alarm is cleared.

If pulsed (PULSE) is selected the UPM will sequence the alarm contact with the fault LED flashes.

### Freeze Protection

The default setting for the freeze limit trip is 26°F; this can be changed to 15°F by cutting the R17 for Compressor 1 and R77 for Compressor 2 resistor located on top of the DIP switch SW1. The UPM controller will constantly monitor the refrigerant temperature with the sensor mounted close to the condensing water coil between the thermal expansion valve and water coil as shown in Fig. 38.

If temperature drops below or remains at the freeze limit trip for 30 seconds, the controller will shut the compressor down and enter into a soft lockout condition. Both the status LED and the Alarm contact will be active. The LED will flash 5 times the code associated with this alarm condition.



**Fig. 38 — Freeze Sensor Location**

### Brownout Protection

The UPM controller will constantly monitor the power supply. If the nominal voltage drops below 25% of its value (18 vac approximately), the unit will enter brownout protection mode. The compressor CC outputs will be de-energized and the unit will enter the soft lockout mode. The controller will **not** monitor the power supply during the first **500 milliseconds** of compressor start-up to avoid noise and false alarms. Once the UPM detects a brownout condition, its fault LED will flash 7 times as error code indication.

### Condensation Overflow

The UPM controller continuously monitors the drain pan for high condensate water level. To do so it utilizes a sensor which, when condensate sensor option is present, identifies an alarm condition when the sensor's impedance drops below  $230,000 \pm 15\%$ . Once the UPM senses this resistance value, it enters into a hard lockout and reports the corresponding code via its status LED (6 flashes). To exit the hard lockout, water has to return to its normal level and UPM has to be reset by removing the power from the Y terminal (R if set on the DIP switch). The compressors will be turned on after anti-short cycle expires.

### Sequence of Operation, CV Units — 50BVT,V

The following sequence of operation applies to constant volume units.

Cooling is initiated when the set point in the remote thermostat is not met (space temperature is higher than set point). The unit sequence of operation is as follows:

Contact closure at the 'G' terminal will provide power to the supply fan contactor energizing the supply fan. The supply fan will be off during unoccupied schedule, depending upon the features of the thermostat used.

The 'O' terminal energizes the reversing valve (heat pump units only). Typically 'Y1' will also be energized at this time for cooling operation. The second stage of cooling 'Y2' will be initialized after a minimum run time and there is a differential from set point plus a deadband or a proportional plus integral calculation based upon demand and length of time space temperature is greater than set point.

Additional assurance is provided by a delay on make timer in the second-stage compressor contactor circuit to avoid dual compressor in-rush starting current.

Heating mode (heat pump models only) follows the same sequence as above except that the reversing valve is not energized.

The UPM sequence of operation illustrated in Fig. 39 applies for both refrigerant circuits. The second compressor is energized 10 seconds after the first if both Y1 and Y2 signals are applied simultaneously.

## WATER ECONOMIZER COOLING

The unit diverts condenser inlet waterflow through an optional economizer coil to pre-cool evaporator entering airflow. If the entering water temperature is colder than the setting on the Aquastat and the return-air temperature is warmer than the setting on the return air thermostat, the two-position diverting valve will direct water to the economizer coil.

Economizer water flow is in series with the condensers allowing compressor operation while the economizer is operating.

## Y CALL (COOLING OR HEATING)

The UPM will energize the compressor's output (CC) in an event of a "Y" Call from a thermostat or controller (after the random start-up and/or the anti-short cycle delays have elapsed). The Y input terminal must be energized with a 24 vac signal.




Fig. 39 — UPM Sequence of Operation (SOO) Flow Chart

## SERVICE

### ⚠ CAUTION

Improper phase sequence will cause scroll compressor failure due to reverse rotation.

### Compressor Rotation

To determine whether or not the compressor is rotating in the proper direction:

1. Connect service gauges to suction and discharge pressure fittings.
2. Energize the compressor.  
The suction pressure should drop and the discharge pressure should rise, as is normal on any start-up. If the suction pressure does not drop and the discharge pressure does not rise to normal levels:
3. Turn off power to the unit and tag disconnect.
4. Reverse any 2 of the unit power leads.  
Reapply power to the unit. The suction and discharge pressure levels should now move to their normal start-up levels.  
Also, check that the fan is rotating in the proper direction.

Incorrect wiring can lead to improper phase sequence resulting in scroll compressor failure due to reverse rotation. Signs of reverse rotation include:

- Excessive noise
- Reverse rotation of 3 phase indoor fan
- Rapid temperature rise on suction tube
- No pressure differential
- No cooling

Correct immediately. Shut off power at disconnect and switch any 2 power leads at unit terminal block or pigtails.

### Fan Motor Replacement

If required, replace the fan motor with an equal or better type and efficiency motor with equal horsepower. The motor must be rated for a VFD or inverter application. Do not change the horsepower unless there is a system design requirement change and VFD size analysis.

#### CHECK/CHANGE VFD OUTPUT CURRENT LIMIT

The VFD provides additional fan motor protection by limiting the output current to a programmed value. This value has been factory set according to the factory-installed motor and VFD sizing options.

If the VFD and/or motor is replaced, the VFD setup mode parameter "tHr1" should be reprogrammed to the following calculated values for optimum motor protection and operating range:

For VFD size about equal to motor:

$tHr1 = 100 * \text{motor nameplate Amps} / \text{VFD rated output Amps}$

## MAINTENANCE

### Cleaning Unit Exterior

Unit exterior panels should be wiped down using a damp soft cloth or sponge with a mixture of warm water and a mild detergent.

### Coil Cleaning

Hot water, steam, and direct expansion coils must be cleaned at least once a year to maintain peak performance. Dirty coils can contribute to decreased heating or cooling capacity and efficiency, increased operating costs, and compressor problems on direct expansion systems. Dirt, grease, and other oils can also reduce the wettability of the coil surfaces, which can result in moisture

blow-off from cooling coils and resulting water leakage problems. If the grime on the surface of the coils becomes wet, which commonly occurs with cooling coils, microbial growth (mold) can result, causing foul odors and health-related indoor air quality problems.

Coils can become dirty over a period of time, especially if air filter maintenance is neglected. Coils should be inspected regularly and cleaned when necessary. Clean coils with a vacuum cleaner, fresh water, compressed air, or a bristle brush (not wire). Do **not** use high-pressure water or air (damage to fins may result). Backflush coil to remove debris. Commercial coil cleaners may also be used to help remove grease and dirt. Steam cleaning is NOT recommended. After cleaning, use a fin comb of the correct fin spacing when straightening mashed or bent coil fins.

Units installed in corrosive environments should be cleaned as part of a planned maintenance schedule. In this type of application, all accumulations of dirt should be cleaned off the coil.

### Inspection

Check coil baffles for tight fit to prevent air from bypassing the coil. Check panels for air leakage, particularly those sealing the fan and coil compartments. Check for loose electrical connections, compressor oil levels, proper refrigerant charge, and refrigerant piping leaks. Before start-up, be sure all optional service valves are open.

### Air Filters

The 50BV single-piece units come with 1 in. filters. The standard 1 in. filter provide lower pressure drop and longer filter service intervals. The 50BV modular units come with 4 in. filters.

Inspect air filters every 30 days and replace filters as necessary.

Replacement filters should have a minimum efficiency rating of MERV 6 per ASHRAE rating procedures and be rated for up to 625 fpm velocity. Job requirements or local codes may specify higher minimum ratings.

### Condensate Drains

Clean the drain line and unit drain pan at the start of each cooling season. Check flow by pouring water into the drain.

### Water-Cooled Condensers

Water-cooled condensers may require cleaning of scale (water deposits) due to improperly maintained closed-loop water systems. Sludge build-up may need to be cleaned in an open tower system due to inducted contaminants.

Local water conditions may cause excessive fouling or pitting of tubes. Condenser tubes should be cleaned at least once a year, or more often if the water is contaminated.

Proper water treatment can minimize tube fouling and pitting. If such conditions are anticipated, water treatment analysis is recommended.

### ⚠ CAUTION

Follow all safety codes. Wear safety glasses and rubber gloves when using inhibited hydrochloric acid solution. Observe and follow acid manufacturer's instructions.

Isolate the supply and return water connections when removing piping to the condenser.

Clean condensers with an inhibited hydrochloric acid solution. The acid can stain hands and clothing and attack concrete, and, without inhibitor, can attack steel. Cover surroundings to guard against splashing. Vapors from vent pipe are not harmful, but take care to prevent liquid from being carried over by gases.

Warm solution acts faster, but cold solution is just as effective if applied for a longer period.



## GRAVITY FLOW METHOD

Do not add solution faster than the vent can exhaust the generated gases.

When condenser is full, allow the solution to remain overnight; then drain the condenser and flush with clean water. Follow acid manufacturer's instructions. Refer to Fig. 40.

## FORCED CIRCULATION METHOD

Fully open the vent pipe when filling the condenser. The vent may be closed when the condenser is full and the pump is operating.

Regulate the flow to the condenser with a supply line valve. If the pump is the non-overloading type, the valve may be fully closed while the pump is running.

For average scale deposit, allow the solution to remain in the condenser overnight. For heavy scale deposit, allow a full 24 hours. Drain the condenser and flush with clean water. Follow acid manufacturer's instructions. Refer to Fig. 41.




Fig. 40 — Gravity Flow Method




Fig. 41 — Forced Circulation Method

## Fan Motor Lubrication

The fan motor was properly lubricated at the time of manufacture. Lubricate the fan motor(s) with SAE-20 (Society of Automotive Engineers) non-detergent electric oil.

**IMPORTANT: PILLOW BLOCK STYLE FAN BEARINGS:** Bearings have been prelubricated with high quality grease. Bearings must be relubricated once every 6 months or every 2500 hours of operation, whichever comes first.

## Fan Bearing Lubrication

Inspect the fan bearings for proper lubrication every 6 month or 2500 hours of operation, whichever comes first. Standard units have grease fittings on the fan shaft bearings, located on each side of the blower wheel. Lubricate bearings with a lithium-based grease (NLGI Grade 2).

## Fan Sheaves

Factory-supplied drives are pre-aligned and tensioned; however, it is recommended that the belt tension and alignment be checked before starting the unit. Always check the drive alignment after adjusting belt tension.

To install sheaves on the fan or motor shaft:

1. Isolate power to the unit.
2. Remove side unit access panel(s).
3. Remove any rust-preventive coating on the fan shaft.
4. Make sure the shaft is clean and free of burrs. Add grease or lubricant to bore of sheave before installing.
5. Mount sheave on the shaft; to prevent bearing damage, do not use excessive force.

Each factory-assembled fan, shaft, and drive sheave assembly is precision aligned and balanced. If excessive unit vibration occurs after field replacement of sheaves, the unit should be rebalanced. To change the drive ratio, follow the steps in the Evaporator Fan Performance Adjustment section (page 55).

After 1 to 3 minutes of operation, check the belt tension. Also check tension frequently during the first 24 hours of operation and adjust if necessary. Periodically check belt tension throughout the run-in period, which is normally the initial 72 hours of operation.

## ALIGNMENT

Make sure that fan shafts and motor shafts are parallel and level. The most common causes of misalignment are nonparallel shafts and improperly located sheaves. Where shafts are not parallel, belts on one side are drawn tighter and pull more than their share of the load. As a result, these belts wear out faster, requiring the entire set to be replaced before it has given maximum service. If misalignment is in the sheave, belts enter and leave the grooves at an angle, causing excessive belt and sheave wear.

## Shaft Alignment

Check shaft alignment by measuring the distance between the shafts at 3 or more locations. If the distances are equal, then the shafts are parallel.

### Sheave Alignment

1. To check the location of the fixed sheaves on the shafts, use a straightedge or a piece of string. If the sheaves are properly aligned, the string will touch them at the points indicated by the arrows in Fig. 42. Rotate each sheave a half revolution to determine whether the sheave is wobbly or the drive shaft is bent. Correct any misalignment.
2. With sheaves aligned, tighten cap screws evenly and progressively.  
NOTE: There should be a 1/8 in. to 1/4 in. gap between the mating part hub and the bushing flange. If the gap is closed, the bushing is probably the wrong size.
3. With taper-lock bushed hubs, be sure the bushing bolts are tightened evenly to prevent side-to-side pulley wobble. Check by rotating sheaves and rechecking sheave alignment. When substituting field-supplied sheaves for factory-supplied sheaves, only the motor sheave should be changed.




Fig. 42 — Sheave Alignment

### Evaporator Fan Performance Adjustment

To change fan speeds from factory settings:

1. Shut off unit power supply.
2. Loosen nuts on the 4 carriage bolts in the mounting base. Using adjusting bolts and plate, slide the motor and remove the belt.
3. Loosen movable-pulley flange setscrew.
4. Screw the movable flange toward the fixed flange to increase speed, and away from the fixed flange to decrease speed. Increasing the fan speed increases the load on the motor. Do not exceed the maximum speed specified in Tables 2 and 3.
5. Set the movable flange at nearest keyway of the pulley hub and tighten the setscrew. (See Tables 2 and 3 for speed change for each full turn of pulley flange.)
6. Replace and tighten the belts (see Belt Tension Adjustment section).
7. Restore power to the unit.

To align fan and motor pulleys:

1. Loosen fan pulley setscrews.
2. Slide fan pulley along fan shaft.
3. Make angular alignment by loosening motor from mounting plate.
4. Restore power to unit.

### BELT TENSION ADJUSTMENT

Using a gauge, apply 4 lb of force to the center of the belt and adjust the tension until a deflection of 1/64 in. is achieved for every inch of shaft center distance. See Fig. 43.

Ideal belt tension is the lowest value under which belt slip will not occur at peak load conditions.




Fig. 43 — Fan Belt Tension

### Compressor Oil

All units are factory charged with oil. It is not necessary to add oil unless compressor(s) is removed from the unit. If necessary, oil can be removed/charged via Schrader fitting. Operate the system at high evaporator temperature prior to oil recharge to assist oil return to the compressor(s) from other system components. If necessary, recharge the system as shown in Table 21.

Table 21 — Oil Recharge

50BV UNIT	SIZE	COMPRESSOR	OIL CHARGE (oz)	OIL TYPE
J	020	ZP94KCE	81	3MA-POE
	024	ZP103KCE	106	
	028	ZP137KCE	106	
	034	ZP182KCE	106	
T, V, W	034	ZP182KCE	106	
	044	ZP120KCE	106	
	054	ZP137KCE	106	
	064	ZP182KCE	106	

### TROUBLESHOOTING

Refer to Tables 22 and 23 to determine the possible cause of the problem and the associated procedure necessary to correct it.

Table 22 — CV Units LED Diagnostic Codes<sup>a</sup>

NO. OF BLINKS	DESCRIPTION
1	1st Stage High-Pressure Lockout
2	1st Stage Low-Pressure Lockout
3	2nd Stage High-Pressure Lockout
4	2nd Stage Low-Pressure Lockout
5	Freeze Protection Lockout <sup>b</sup>
6	Condensate Overflow Lockout <sup>b</sup>

NOTE(S):

- The main control board has a red LED (light-emitting diode) for fault indication and will blink a code as described above. Count the number of blinks to determine the lockout condition.
- Freeze protection and condensate overflow lockout require optional sensors.

**Table 23 — Unit Troubleshooting**

PROBLEM	POSSIBLE CAUSE	CORRECTION PROCEDURE
Unit Will Not Start.	Loss of unit power.	Check power source. Check fuses, circuit breakers, disconnect switch. Check electrical contacts.
	Unit voltage not correct	Check and correct.
	Open fuse	Check for short circuit in unit.
	Open protection device	Check relays (phase monitor option), contacts, pressure switches.
	Unit or motor contactor out of order	Test and replace if necessary.
Fan Does Not Operate.	Contactor or relay overload or out of order	Test and replace if necessary.
	VFD not running	Confirm VFD parameters set.
	Motor defective	Test and replace if necessary.
	Broken belt	Replace belt.
	Loose electrical contact	Tighten contact.
Compressor is Noisy, But Will Not Start.	Under voltage	Check and correct.
	Defect in compressor motor	Replace compressor.
	Missing phase	Check and correct.
	Compressor seized	Check and replace if necessary.
Compressor Starts, But Does Not Continue to Run.	Compressor or contact defect	Test and replace if necessary.
	Unit is under charged	Check and correct any leaks. Add refrigerant.
	Unit is too big	Check load calculation.
	Compressor is overloaded	Check protection device and replace.
		Check for missing phase. Check TXV. Check temperature in suction discharge line.
Unit is Noisy.	Compressor noise	Check TXV and replace if necessary. Compressor rotation incorrect; check and correct. Check internal noise.
	Tube vibration or condenser water problem	Check and correct.
	Unit panel or part vibrating	Check and tighten appropriate part.
Unit Runs Continuously, But Has Low Capacity.	Unit is too small	Check load calculation.
	Low refrigerant or non-condensing gas present	Check for leaks and add refrigerant or gas as necessary.
	Compressor defect	Check pressure and amps. Replace if necessary.
	Insufficient flow of refrigerant in evaporator	Check filter drier and replace if necessary. Check TXV and adjust or replace if necessary. Check position of TXV bulb and equalizer.
	Oil in evaporator	Drain evaporator.
	Low airflow	Check filters, and clean or replace as necessary.
		Check coils, and clean as necessary. Check for restrictions in ductwork. Check fan rotation and adjust. Check fan motor. Check belts for wear.
High Discharge Pressure.	Low waterflow in condenser	Purge air.
	Dirty condenser tubes.	Clean condenser.
	High temperature in condenser water	Check water tower fans and pumps.
	Overcharged	Check and reclaim excess charge. Adjust subcooling.
	Non-condensing gas present	Verify and correct.

**LEGEND**

**TXV** — Thermostatic Expansion Valve  
**VFD** — Variable Frequency Drive







## START-UP CHECKLIST

(Fill out this form on Start-Up and file in job folder)

**NOTE: To avoid injury to personnel and damage to equipment or property when completing the procedures listed in this start-up checklist, use good judgment, follow safe practices, and adhere to the safety considerations/information as outlined in preceding sections of this Installation, Start-Up, Service and Controls Operation and Troubleshooting document.**

### I. PRELIMINARY INFORMATION:

50BV UNIT: MODEL NO. \_\_\_\_\_ SERIAL NO. \_\_\_\_\_

START-UP DATE: \_\_\_\_\_

### II. PRE-START-UP:

VERIFY ALL SHIPPING MATERIALS HAVE BEEN REMOVED FROM THE UNIT

IS THERE ANY DAMAGE? \_\_\_\_\_ IF SO, WHERE \_\_\_\_\_

WILL THIS DAMAGE PREVENT UNIT START-UP? (Y/N) \_\_\_\_\_

CHECK POWER SUPPLY. DOES IT AGREE WITH UNIT? (Y/N) \_\_\_\_\_

HAS THE GROUND WIRE BEEN CONNECTED? (Y/N) \_\_\_\_\_

HAS THE CIRCUIT BREAKER AND DISCONNECT BEEN SIZED AND INSTALLED PROPERLY? (Y/N) \_\_\_\_\_

ARE THE POWER WIRES TO THE UNIT SIZED AND INSTALLED PROPERLY? (Y/N) \_\_\_\_\_

HAS THE CORRECT INPUT POWER PHASE SEQUENCE BEEN CONFIRMED WITH A METER? (Y/N) \_\_\_\_\_

HAS THE FAN AND MOTOR PULLEY BEEN CHECKED FOR PROPER ALIGNMENT AND DOES THE FAN BELT HAVE PROPER TENSION? (Y/N) \_\_\_\_\_

HAS WATER BEEN PLACED IN DRAIN PAN TO CONFIRM PROPER DRAINAGE? (Y/N) \_\_\_\_\_

ARE PROPER AIR FILTERS IN PLACE AND CLEAN? (Y/N) \_\_\_\_\_

VERIFY THAT THE UNIT IS INSTALLED WITHIN LEVELING TOLERANCES (Y/N) \_\_\_\_\_

#### CONTROLS

(CV ONLY) HAS THE THERMOSTAT BEEN INSTALLED AND VERIFIED TO BE OPERATIONAL? (Y/N) \_\_\_\_\_

(VAV ONLY) HAS THE DUCT STATIC PRESSURE PROBE BEEN INSTALLED? (Y/N) \_\_\_\_\_

HAVE CONTROL CONNECTIONS BEEN MADE AND CHECKED? (Y/N) \_\_\_\_\_

ARE ALL WIRING TERMINALS (including main power supply) TIGHT? (Y/N) \_\_\_\_\_

(VAV ONLY) HAS THE SUPPLY AIR TEMPERATURE AND RETURN AIR TEMPERATURE SENSORS BEEN INSTALLED? (Y/N) \_\_\_\_\_

HAS THE UNIT CONTROL SYSTEM INTERFACE BEEN PROVIDED (VIRTUAL BACVIEW)? (Y/N) \_\_\_\_\_

#### PIPING

HAVE LEAK CHECKS BEEN MADE AT COMPRESSOR, CONDENSER, EVAPORATOR, TXVs (Thermostatic Expansion Valves), SOLENOID VALVES, FILTER DRIERS, AND FUSIBLE PLUGS WITH A LEAK DETECTOR? (Y/N) \_\_\_\_\_

HAVE WATER AND STEAM VALVES BEEN OPENED (to fill piping and heat exchangers)? (Y/N) \_\_\_\_\_

HAS AIR PURGE BEEN PERFORMED? (Y/N) \_\_\_\_\_  
HAS THE WATER PIPING BEEN CHECKED FOR LEAKS AND VALVE OPERATION VERIFIED (Y/N) \_\_\_\_\_  
HAS THE CONDENSER FLUID BEEN CHECKED FOR PROPER FLOW AND CONCENTRATION (Y/N) \_\_\_\_\_

**DUCTWORK**

HAS THE DUCTWORK BEEN PROPERLY INSTALLED WITH A PAIR OF PANTS (DUAL FAN UNITS) (Y/N) \_\_\_\_\_  
(VAV ONLY) ARE ALL ZONE DAMPERS INSTALLED AND VERIFIED TO BE OPERATIONAL (Y/N) \_\_\_\_\_

**ELECTRICAL**

CHECK VOLTAGE IMBALANCE

LINE-TO-LINE VOLTS: AB \_\_\_\_\_ V AC \_\_\_\_\_ V BC \_\_\_\_\_ V

$(AB + AC + BC)/3 = \text{AVERAGE VOLTAGE} = \text{_____ V}$

MAXIMUM DEVIATION FROM AVERAGE VOLTAGE = \_\_\_\_\_ V

VOLTAGE IMBALANCE =  $100 \times (\text{MAX DEVIATION})/(\text{AVERAGE VOLTAGE}) = \text{_____ \%}$  (IF OVER 2% VOLT-  
AGE IMBALANCE, DO NOT ATTEMPT TO START SYSTEM; CALL LOCAL POWER COMPANY FOR ASSISTANCE.)

**III. START-UP:**

CHECK FAN SPEED AND RECORD. \_\_\_\_\_

AFTER AT LEAST 15 MINUTES RUNNING TIME, RECORD THE FOLLOWING MEASUREMENTS:

	CIRCUIT 1	CIRCUIT 2	CIRCUIT 3	CIRCUIT 4
SUCTION PRESSURE	_____	_____	_____	_____
SATURATED SUCTION TEMP	_____	_____	_____	_____
SUCTION LINE TEMP	_____	_____	_____	_____
SUPERHEAT DEGREES	_____	_____	_____	_____
DISCHARGE PRESSURE	_____	_____	_____	_____
SATURATED CONDENSING	_____	_____	_____	_____
LIQUID LINE TEMP	_____	_____	_____	_____
SUBCOOLING DEGREES	_____	_____	_____	_____
LIQUID SIGHT GLASS (CLEAR/BUBBLES)	_____	_____	_____	_____
ENTERING CONDENSER-WATER TEMP	_____	_____	_____	_____
LEAVING CONDENSER-WATER TEMP	_____	_____	_____	_____
EVAP ENTERING-AIR DB (dry bulb) TEMP	_____	_____	_____	_____
EVAP ENTERING-AIR WB (wet bulb) TEMP	_____	_____	_____	_____
EVAP LEAVING-AIR DB TEMP	_____	_____	_____	_____
EVAP LEAVING-AIR WB TEMP	_____	_____	_____	_____
HOT GAS BYPASS SETTING	_____	_____	_____	_____

COMPRESSOR AMPS:

L1	_____	_____	_____	_____
L2	_____	_____	_____	_____
L3	_____	_____	_____	_____

SUPPLY FAN AMPS:

L1	_____	_____
L2	_____	_____
L3	_____	_____

NOTES: \_\_\_\_\_  
\_\_\_\_\_

CUT ALONG DOTTED LINE