58SB0A/58SB1A Single Stage, Multi-Speed ECM, Non–Condensing Gas Furnace Input Capacities: 45,000 Thru 155,000 Btuh



## Installation, Start–Up, Operating and Service and Maintenance Instructions



Use of the AHRI Certified TM Mark indicates a

Use of the AFHA Certified TM Mark Indicates a manufacturer's participation in the program. For verification of certification for individual products, go to www.ahridirectory.org.

**NOTE:** Read the entire instruction manual before starting the installation.

SAFETY CONSIDERATIONS
INTRODUCTION
CODES AND STANDARDS
ELECTROSTATIC DISCHARGE (ESD) PRECAUTIONS PROCE-
DURE
LOCATION
GENERAL
AIR FOR COMBUSTION AND VENTILATION5
Table 1 – Minimum Free Area Required for Each Combustion Air
Opening or Duct to Outdoors
Table 2 - Minimum Space Volumes for 100% Combustion, Ventila-
tion, and Dilution from Indoors 7
INSTALLATION
UPFLOW INSTALLATION
DOWNFLOW INSTALLATION8
Table 3 – Opening Dimensions - In. (mm)    9
HORIZONTAL INSTALLATION9
LOCATION RELATIVE TO COOLING EQUIPMENT 10
AIR DUCTS
GENERAL REQUIREMENTS 11
SUPPLY AIR CONNECTIONS11
Table 4 – Air Delivery - CFM (With Filter)*       12
Table 5 – Dimensions    14
GAS PIPING
Table 6 – Maximum Capacity of Pipe*    15
ELECTRICAL CONNECTIONS 16
Table 7 – Electrical Data    17
J-BOX RELOCATION

ACCESSORIES 19
NOTES FOR THERMOSTAT WIRING DIAGRAMS 20
VENTING
GENERAL VENTING REQUIREMENTS
Table 8 – Combined Appliance Maximum Input Rating
in Thousands of Btuh per Hour
Table 9 – Minimum Allowable Input Rating of Space-Heating Appli-
ance in Thousands of Btuh per Hour
EXTERIOR MASONRY CHIMNEY FAN + NAT
INSTALLATIONS WITH TYPE-B DOUBLE-WALL
VENT CONNECTORS ©NFPA & AGA
VENTING NOTES FOR Fig. 31 - Fig. 43
START-UP, ADJUSTMENT, AND SAFETY CHECK
GENERAL
Table 10 – Altitude Derate Multiplier for U.S.A.    27
Table 11 - Orifice Size* and Manifold Pressure (In. W.C.) for Gas In-
put Rate
Table 12 – Orifice Size* And Manifold Pressure (In. W.C.) For Gas
Input Rate
Table 13 – Gas Rate (Cu Ft./Hr.).29
SERVICE AND MAINTENANCE PROCEDURES
GENERAL
ELECTRICAL CONTROLS AND WIRING
CARE AND MAINTENANCE
CLEANING AND/OR REPLACING AIR FILTER
Table 14 – Filter Size Information (In. / mm)    32
BLOWER MOTOR AND WHEEL
CLEANING HEAT EXCHANGER
SEQUENCE OF OPERATION
WIRING DIAGRAM
TROUBLESHOOTING
PARTS REPLACEMENT INFORMATION GUIDE
CASING GROUP 39
ELECTRICAL GROUP 39
BLOWER GROUP 39
GAS CONTROL GROUP
HEAT EXCHANGER GROUP
INDUCER GROUP
TRAINING

Portions of the text and tables are reprinted from current edition of NFPA 54/ANSI Z223.1E, with permission of National Fire Protection Association, Quincy, MA 02269 and American Gas Association, Washington DC 20001. This reprinted material is not the complete and official position of the NFPA or ANSI on the referenced subject, which is represented only by the standard in its entirety.

Manufacturer reserves the right to change, at any time, specifications and designs without notice and without obligations.

#### SAFETY CONSIDERATIONS

## WARNING

## FIRE, EXPLOSION, ELECTRICAL SHOCK, AND CARBON MONOXIDE POISONING HAZARD

Failure to follow this warning could result in dangerous operation, serious injury, death, or property damage.

Improper installation, adjustment, alteration, service, maintenance, or use could cause carbon monoxide poisoning, explosion, fire, electrical shock, or other conditions which may cause personal injury or property damage. Consult a qualified service agency, local gas supplier, or your distributor or branch for information or assistance. The qualified service agency must use only factory-authorized and listed kits or accessories when modifying this product.

## NARNING

## FIRE, EXPLOSION, ELECTRICAL SHOCK, AND CARBON MONOXIDE POINSING HAZARD

Failure to follow this warning could result in dangerous operation, personal injury, death, or property damage.

Furnaces shall NOT be twinned (i.e. tandem or staged operation) unless approved in factory technical specifications literature for the furnace. A factory authorized, field-supplied Twinning Kit MUST be used. Consult furnace pre-sale literature for specific models approved for twinning and the correct twinning kit. Twinned furnaces must be installed on both a common supply AND a common return duct system as shown in the Twinning Kit Installation Instructions. Only two furnaces can be twinned on a common supply and return duct system using a factory authorized twinning kit.

## **AUTION**

#### FURNACE RELIABILITY HAZARD

Improper installation or misapplication of furnace may require excessive servicing or cause premature component failure.

Application of this furnace should be indoors with special attention given to vent sizing and material, gas input rate, air temperature rise, unit leveling, and unit sizing.

Improper installation, adjustment, alteration, service, maintenance, or use can cause explosion, fire, electrical shock, or other conditions which may cause death, personal injury, or property damage. Consult a qualified installer, service agency, or your distributor or branch for information or assistance. The qualified installer or agency must use factory-authorized kits or accessories when modifying this product. Refer to the individual instructions packaged with the kits or accessories when installing.

Follow all safety codes. Wear safety glasses, protective clothing, and work gloves. Have a fire extinguisher available. Read these instructions thoroughly and follow all warnings or cautions include in literature and attached to the unit. Consult local building codes, the current editions of the current edition of National Fuel Gas Code (NFGC) NFPA 54/ANSI Z223.1 and the current edition of National Electrical Code (NEC) NFPA 70.

Recognize safety information. This is the safety-alert symbol  $\triangle$ . When you see this symbol on the unit and in instructions or manuals, be alert to the potential for personal injury.

Understand the signal words **DANGER**, **WARNING**, and **CAUTION**. These words are used with the safety-alert symbol. **DANGER** identifies the most serious hazards which will result in severe personal injury or death. **WARNING** signifies hazards which could result in personal injury or death. **CAUTION** is used to identify unsafe practices which may result in minor personal injury or product and property damage. **NOTE** is used to highlight suggestions which will result in enhanced installation, reliability, or operation.

## **CAUTION**

#### CUT HAZARD

Failure to follow this caution may result in personal injury.

Sheet metal parts may have sharp edges or burrs. Use care and wear appropriate protective clothing, safety glasses and gloves when handling parts and servicing furnaces.

The following additional safety considerations should be followed for gas furnaces:

- 1. Use only with type of gas approved for this furnace. Refer to the furnace rating plate.
- 2. Install this furnace only in a location and position as specified in the "Location" section of these instructions.
- 3. Provide adequate combustion and ventilation air to the furnace space as specified in "Air for Combustion and Ventilation" section.
- 4. Combustion products must be discharged outdoors. Connect this furnace to an approved vent system only, as specified in the "Venting" section of these instructions.
- 5. Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections, as specified in the "Gas Piping" section.
- 6. Always install furnace to operate within the furnace's intended temperature-rise range with a duct system which has an external static pressure within the allowable range, as specified in the "Start-Up, Adjustments, and Safety Check" section. See furnace rating plate.
- 7. When a furnace is installed so that supply ducts carry air circulated by the furnace to areas outside the space containing the furnace, the return air shall also be handled by duct(s) sealed to the furnace casing and terminating outside the space containing the furnace. See "Air Ducts" section.
- 8. A gas-fired furnace for installation in a residential garage must be installed as specified in the warning box in the "Location" section.
- 9. The furnace may be used for construction heat provided that the furnace installation and operation complies with the first CAUTION in the LOCATION section of these instructions.
- 10. These Multipoise Gas-Fired Furnaces are CSA (formerly A.G.A. and C.G.A). design-certified for use with natural and propane gases (see furnace rating plate) and for installation in alcoves, attics, basements, closets, utility rooms, crawlspaces, and garages. The furnace is factory-shipped for use with natural gas. A CSA listed accessory gas conversion kit is required to convert furnace for use with propane gas.
- 11. See Fig. 1 for required clearances to combustible construction.
- 12. Maintain a 1-in. (25 mm) clearance from combustible materials to supply air ductwork for a distance of 36 inches (914 mm) horizontally from the furnace. See current edition of NFPA 90B or local code for further requirements.
- 13. These furnaces SHALL NOT be installed directly on carpeting, tile, or any other combustible material other than wood flooring. In downflow installations, factory accessory floor base MUST be used when installed on combustible materials and wood flooring. Special base is not required when this furnace is installed on manufacturer's Coil Assembly Part No. CAR, CAP, CNRV, and CNPV, or when Coil Box Part No. KCAKC is used. See Fig. 1 for clearance to combustible construction information.

#### INTRODUCTION



Fig. 1 - Clearances to Combustibles

This 4-way multipoise Category I fan-assisted furnace is CSA design-certified. A Category I fan-assisted furnace is an appliance equipped with an integral mechanical means to either draw or force products of combustion through the combustion chamber and/or heat exchanger. The furnace is factory-shipped for use with natural gas.

This furnace is not approved for installation in mobile homes, recreational vehicles, or outdoors. This furnace is designed for minimum continuous return-air temperature of  $60^{\circ}$ F ( $16^{\circ}$ C) db or intermittent operation down to 55°F ( $13^{\circ}$ C) db such as when used with a night setback thermostat. Return-air temperature must not exceed  $80^{\circ}$ F ( $27^{\circ}$ C) db. Failure to follow these return-air temperature limits may affect reliability of heat exchangers, motors, and controls (see Fig. 2).

For accessory installation details, refer to the applicable instruction literature.

**NOTE:** Remove all shipping brackets and materials before operating the furnace.



Fig. 2 – Return Air Temperature

## WARNING

#### FIRE HAZARD

Failure to follow this warning could result in personal injury, death and/or property damage.

Do not install the furnace on its back or hang furnace with control compartment facing downward. Safety control operation will be adversely affected. Never connect return-air ducts to the back of the furnace (see Fig. 3).



Fig. 3 – Prohibit Installation on Back

A02054

A93044

## WARNING

#### FIRE HAZARD

Failure to follow this warning could result in personal injury, death, and/or property damage.

When the furnace is installed in a residential garage, the burners and ignition sources must be located at least 18 inches above the floor. The furnace must be located or protected to avoid damage by vehicles. When the furnace is installed in a public garage, airplane hangar, or other building having a hazardous atmosphere, the furnace must be installed in accordance with the NFGC (see Fig. 4).



Fig. 4 – Installation in a Garage

#### **CODES AND STANDARDS**

Follow all national and local codes and standards in addition to these instructions. The installation must comply with regulations of the serving gas supplier, local building, heating, plumbing, and other codes. In absence of local codes, the installation must comply with the national codes listed below and all authorities having jurisdiction.

In the United States, follow all codes and standards for the following:

#### <u>Safety</u>

USA: Current edition of National Fuel Gas Code (NFGC) NFPA 54/ANSI Z223.1 and the Installation Standards, Warm Air Heating and Air Conditioning Systems ANSI/NFPA 90B.

58SB0A/58SB1A: Installation, Start–Up, Operating and Service and Maintenance Instructions

#### **General Installation**

Current edition of the NFGC and the NFPA 90B. For copies, contact the National Fire Protection Association Inc., Batterymarch Park, Quincy, MA 02269; (www.NFPA.org) or for only the NFGC, contact the American Gas Association, 400 N. Capitol Street, N.W., Washington, DC 20001 (www.AGA.org).

#### **Combustion and Ventilation Air**

Current edition of NFGC NFPA54/ANSI Z223.1 Section 9.3, Air for Combustion and Ventilation.

#### Duct Systems

Air Conditioning Contractors Association (ACCA) Manual D, Sheet Metal and Air Conditioning Contractors National Association (SMACNA), or American Society of Heating, Refrigeration, and Air Conditioning Engineers (ASHRAE) 2005 Fundamentals Handbook Chapter 35 or 2004 HVAC Systems and Equipment Handbook Chapters 9 and 16.

#### Acoustical Lining and Fibrous Glass Duct

Current edition of SMACNA and NFPA 90B as tested by UL Standard 181 for Class I Rigid Air Ducts.

#### Gas Piping and Gas Pipe Pressure Testing

Current edition of NFGC NFPA54/ANSI Z223.1; chapters 5, 6, 7, and 8 and National Plumbing Codes.

#### **Electrical Connections**

Current edition of National Electrical Code (NEC) NFPA 70.

#### Venting

Current edition of NFGC NFPA 54 / ANSI Z223.1; Chapters 12 and 13.

#### ELECTROSTATIC DISCHARGE (ESD) PRECAUTIONS PROCEDURE

 Disconnect all power to the furnace. Multiple disconnects maybe required. DO NOT TOUCH THE CONTROL OR ANY WIRE CONNECTED TO THE CONTROL PRIOR TO DISCHARGING YOUR BODY'S ELECTROSTATIC CHARGE TO GROUND.

## **CAUTION**

#### FURNACE RELIABILITY HAZARD

Improper installation or service of furnace may cause premature furnace component failure.

Electrostatic discharge can affect electronic components. Follow the Electrostatic Discharge Precautions Procedure listed below during furnace installation and servicing to protect the furnace electronic control. Precautions will prevent electrostatic discharges from personnel and hand tools which are held during the procedure. These precautions will help to avoid exposing the control to electrostatic discharge by putting the furnace, the control, and the person at the same electrostatic potential.

- Firmly touch the clean, unpainted, metal surface of the furnace chassis which is close to the control. Firmly touch the clean, unpainted, metal surface of the furnace chassis which is close to the control. Tools held in a person's hand during grounding will be satisfactorily discharged.
- 3. After touching the chassis, you may proceed to service the control or connecting wires as long as you do nothing to recharge your body with static electricity (for example; DO NOT move or shuffle your feet, do not touch ungrounded objects, etc.).
- 4. If you touch ungrounded objects (and recharge your body with static electricity), firmly touch a clean, unpainted metal surface of the furnace again before touching control or wires.
- 5. Use this procedure for installed and uninstalled (ungrounded) furnaces.

- 6. Before removing a new control from its container, discharge your body's electrostatic charge to ground to protect the control from damage. If the control is to be installed in a furnace, follow items 1 through 4 before bringing the control or yourself in contact with the furnace. Put all used and new controls into containers before touching ungrounded objects.
- 7. An ESD service kit (available from commercial sources) may also be used to prevent ESD damage.

## CAUTION

#### PERSONAL INJURY AND/OR PROPERTY DAMAGE HAZARD

Improper use or installation of this furnace may cause premature furnace component failure.

This gas furnace may be used for heating buildings under construction provided that:

-The furnace is permanently installed with all electrical wiring, piping, venting and ducting installed according to these installation instructions. A return air duct is provided, sealed to the furnace casing, and terminated outside the space containing the furnace. This prevents a negative pressure condition as created by the circulating air blower, causing a flame rollout and/or drawing combustion products into the structure.

-The furnace is controlled by a thermostat. It may not be "hot wired" to provide heat continuously to the structure without thermostatic control. -Clean outside air is provided for combustion. This is to minimize the corrosive effects of adhesives, sealers and other construction materials. It also prevents the entrainment of drywall dust into combustion air, which can cause fouling and plugging of furnace components.

-The temperature of the return air to the furnace is maintained between  $55^{\circ}$ F (13°C) and 80°F (27°C), with no evening setback or shutdown. The use of the furnace while the structure is under construction is deemed to be intermittent operation per our installation instructions.

-The air temperature rise is within the rated rise range on the furnace rating plate, and the gas input rate has been set to the nameplate value. -The filters used to clean the circulating air during the construction process must be either changed or thoroughly cleaned prior to occupancy.

-The furnace, ductwork and filters are cleaned as necessary to remove drywall dust and construction debris from all HVAC system components after construction is completed.

-Verify proper furnace operating conditions including ignition, gas input rate, air temperature rise, and venting according to these installation instructions.

## WARNING

#### CARBON MONOXIDE POISONING HAZARD

Failure to follow this warning could result in personal injury or death, and unit component damage.

Corrosive or contaminated air may cause failure of parts containing flue gas, which could leak into the living space. Air for combustion must not be contaminated by halogen compounds, which include fluoride, chloride, bromide, and iodide. These elements can corrode heat exchangers and shorten furnace life. Air contaminants are found in aerosol sprays, detergents, bleaches, cleaning solvents, salts, air fresheners, and other household products. Do not install furnace in a corrosive or contaminated atmosphere. Make sure all combustion and circulating air requirements are met, in addition to all local codes and ordinances. LOCATION

#### GENERAL

This multipoise furnace is shipped in packaged configuration. Some assembly and modifications are required when used in any of the four applications (see Fig. 5).



#### Fig. 5 – Multipoise Orientations

This furnace must:

- be installed so the electrical components are protected from water.
- not be installed directly on any combustible material other than wood flooring for upflow applications. Downflow installations require use of a factory-approved floor base or coil assembly when installed on combustible materials or wood flooring (refer to SAFETY CONSIDERATIONS).
- be located as close to the chimney or vent and attached to an air distribution system. Refer to Air Ducts section.
- be provided ample space for servicing and cleaning. Always comply with minimum fire protection clearances shown on the furnace clearance to combustible label.

The following types of furnace installations may require OUTDOOR AIR for combustion due to chemical exposures:

- Commercial buildings
- · Buildings with indoor pools
- Laundry rooms
- · Hobby or craft rooms, and
- Chemical storage areas

If air is exposed to the following substances, it should not be used for combustion air, and outdoor air may be required for combustion:

- Permanent wave solutions
- · Chlorinated waxes and cleaners
- · Chlorine based swimming pool chemicals
- Water softening chemicals
- De-icing salts or chemicals
- · Carbon tetrachloride
- Halogen type refrigerants
- Cleaning solvents (such as perchloroethylene)
- Printing inks, paint removers, varnishes, etc.
- Hydrochloric acid
- Cements and glues
- Antistatic fabric softeners for clothes dryers
- Masonry acid washing materials

All fuel-burning equipment must be supplied with air for fuel combustion. Sufficient air must be provided to avoid negative pressure in the equipment room or space. A positive seal must be made between the furnace cabinet and the return-air duct to prevent pulling air from the burner area and from draft safeguard opening.

## **CAUTION**

#### FURNACE CORROSION HAZARD

Failure to follow this caution may result in furnace damage.

Air for combustion must not be contaminated by halogen compounds, which include fluoride, chloride, bromide, and iodide. These elements can corrode heat exchangers and shorten furnace life. Air contaminants are found in aerosol sprays, detergents, bleaches, cleaning solvents, salts, air fresheners, and other household products.

#### AIR FOR COMBUSTION AND VENTILATION

Provisions for adequate combustion, ventilation, and dilution air must be provided in accordance with:

• U.S. installations: Section 9.3 of the current edition of NFGC NFPA54/ANSI Z223.1, Air for Combustion and Ventilation, and applicable provisions of the local building codes.



#### CARBON MONOXIDE POISONING HAZARD

Failure to follow this warning could result in personal injury or death. The operation of exhaust fans, kitchen ventilation fans, clothes dryers, attic exhaust fans or fireplaces could create a NEGATIVE PRESSURE CONDITION at the furnace. Make-up air MUST be provided for the ventilation devices, in addition to that required by the furnace. Refer to Carbon Monoxide Poisoning Hazard warning in venting section of these instructions to determine if an adequate amount of make-up air is available.

The requirements for combustion and ventilation air depend upon whether or not the furnace is located in a space having a volume of at least 50 cubic feet per 1,000 Btuh input rating for all gas appliances installed in the space.

- Spaces having less than 50 cubic feet per 1,000 Btuh require the OUTDOOR COMBUSTION AIR METHOD.
- Spaces having at least 50 cubic feet per 1,000 Btuh may use the INDOOR COMBUSTION AIR, STANDARD or KNOWN AIR INFILTRATION METHOD.

#### **Outdoor Combustion Air Method**

- 1. Provide the space with sufficient air for proper combustion, ventilation, and dilution of flue gases using permanent horizontal or vertical duct(s) or opening(s) directly communicating with the outdoors or spaces that freely communicate with the outdoors.
- 2. Fig. 6 illustrates how to provide TWO OUTDOOR OPENINGS, one inlet and one outlet combustion and ventilation air opening, to the outdoors.
  - a. One opening MUST commence within 12-in. (300 mm) of the ceiling and the second opening MUST commence within 12-in. (300 mm) of the floor.
  - b. Size openings and ducts per Fig. 6 and Table 1.
  - c. TWO HORIZONTAL DUCTS require 1 square inch of free area per 2,000 Btuh (1,100 mm2/kW) of combined input for all gas appliances in the space per Fig. 6 and Table 1.
  - d. TWO OPENINGS OR VERTICAL DUCTS require 1 square inch of free area per 4,000 Btuh (550 mm2/kW) for combined input of all gas appliances in the space per Fig. 6 and Table 1.
- 3. ONE OUTDOOR OPENING requires:
  - a. 1 square inch of free area per 3,000 Btuh (734 mm2/kW) for combined input of all gas appliances in the space per Table 1 and

b. Not less than the sum of the areas of all vent connectors in the space.







The opening shall commence within 12" (300 mm) of the ceiling. Appliances in the space shall have clearances of at least 1" (25 mm) from the sides and back and 6" (150 mm) from the front. The opening shall directly communicate with the outdoors or shall communicate through a vertical or horizontal duct to the outdoors or spaces (crawl or attic) that freely communicate with the outdoors.

- Indoor Combustion Air NFPA & AGA
- Standard and Known-Air-Infiltration Rate Methods
- Indoor air is permitted for combustion, ventilation, and dilution, if the **Standard** or **Known-Air-Infiltration** Method is used.



#### CARBON MONOXIDE POISONING HAZARD

Failure to follow this warning could result in death and/or personal injury.

Many homes require air to be supplied from outdoors for furnace combustion, ventilation, and dilution of flue gases. The furnace combustion air supply must be provided in accordance with this instruction manual.

Table 1 – Minimum	Free Area Requ	ired for Each (	Combustion Air (	Opening or Duct to	Outdoors
Table I Minimum	i i i ce i ii ca i ce qu	incu ioi Lacii	combustion min	opening of Duce to	Outdoors

A03174

FURNACE INPUT (BTUH)	(1 SQ. IN./2	NTAL DUCTS ,000 BTUH) MM/KW)	(1 SQ. IN./3	TOR OPENING ,000 BTUH) MM/KW)	(1 SQ. IN./4	R VERTICAL DUCTS 4,000 BTUH) MM/KW)
	Free Area of Opening and Duct (sq. in. / sq. mm)	Round Duct Diameter (in./mm)	Free Area of Opening and Duct (sq. In. / sq. mm)	Round Duct Diameter (in. / mm)	Free Area of Opening and Duct (sq. In. / sq. mm)	Round Duct Diameter (In./mm)
44,000	22 (14193)	6 (152)	14.7 (9484)	5 (127)	11 (7097)	4 (102)
66,000	33 (21290)	7 (178)	22 (14193)	6 (152)	16.5 (10645)	5 (127)
88,000	44 (28387)	8 (203)	29.3 (18903)	7 (178)	22 (14193)	6 (152)
110,000	55 (35484)	9 (229)	36.7 (23677)	7 (178)	27.5 (17742)	6 (152)
132,000	66 (42581)	10 (254)	44 (28387)	8 (203)	33 (21290)	7 (178)
154,000	77 (49677)	10 (254)	51.3 (33096)	9 (229)	38.5 (24839)	8 (203)

#### EXAMPLES: Determining Free Area

FURNACE	3	WATER HEATER		TOTAL INPUT			
110,000	+	30,000	=	(140,000 divided by 4,000)	=	35.0 Sq. In. for each two Vertical Ducts or Openings	
66,000	+	40,000	=	(106,000 divided by 3,000)	=	35.3 Sq. In. for a Single Duct or Opening	
88,000	+	30,000	=	(118,000 divided by 2,000)	=	59.0 Sq. In. for each of two Horizontal Ducts	

#### The Standard Method

Use the Standard Method if:

- 1. The space has no less volume than 50 cubic feet per 1,000 Btuh of the maximum input ratings for all gas appliances installed in the space and
- 2. The air infiltration rate is not known to be less than 0.40 air changes per hour (ACH).

Use the **Known Air Infiltration Rate Method** if the infiltration rate is known to be:

- 1. Less than 0.40 ACH and
- 2. Equal to or greater than 0.10 ACH

Infiltration rates greater than 0.60 ACH shall not be used. The minimum required volume of the space varies with the number of ACH and shall

be determined per Table 2 or Equations 1 and 2. Determine the minimum required volume for each appliance in the space and add the volumes together to get the total minimum required volume for the space.

Table 2 - Minimum Space Volumes were determined by using the following equations from the current edition of National Fuel Gas Code ANSI Z223.1/NFPA 54:

1. For other than fan-assisted appliances, such as a draft hood-equipped water heater:

Volume 
$$_{Other} = \frac{21 \text{ ft}^3}{\text{ACH}} \left( \frac{\text{I}_{other}}{1000 \text{ Btu/hr}} \right)$$

58SB0A/58SB1A: Installation, Start-Up, Operating and Service and Maintenance Instructions

2. For fan-assisted appliances such as this furnace:

Volume = 
$$\frac{15 \text{ft}^3}{\text{ACH}} \left( \frac{\text{I}_{\text{fan}}}{1000 \text{ Btu/hr}} \right)$$

If the following is applied to either equation:

- Iother = combined input of all other than fan-assisted appliances in Btuh/hr
- Ifan = combined input of all fan-assisted appliances in Btuh/hr
- ACH = air changes per hour (ACH shall not exceed 0.60.)

The following requirements apply to the **Standard Method** and to the **Known Air Infiltration Rate Method**.

1. Adjoining rooms can be considered part of a space if:

- a. There are no closeable doors between rooms.
- b. Combining spaces on same floor level. Each opening shall have free area of at least 1 in.<sup>2</sup>/1,000 Btuh (2,000 mm<sup>2</sup>/kW) of the total input rating of all gas appliances in the space, but not less than 100 in.<sup>2</sup> (0.06 m<sup>2</sup>). One opening shall commence within 12" (300 mm) of the ceiling and the second opening shall commence within 12" (300 mm) of the floor. The minimum dimension of air openings shall be at least 3 in. (80 mm) (see Fig. 7).
- c. Combining space on different floor levels. The volumes of spaces on different floor levels shall be considered as communicating spaces if connected by one or more permanent openings in doors or floors having free area of at least 2 in.<sup>2</sup>/1,000 Btuh (4,400 mm<sup>2</sup>/kW) of total input rating of all gas appliances.

#### Table 2 - Minimum Space Volumes for 100% Combustion, Ventilation, and Dilution from Indoors

A04003

ACH*	OTHER THAN FAN-ASSISTED TOTAL (1,000'S BTUH GAS INPUT RATE			FAN-ASSISTED TOTAL (1,000'S BTUH GAS INPUT RATE)					
	30	40	50	44	66	88	110	132	
		1		Space Volu	ıme (ft. <sup>3</sup> )	1	1		
0.60	1,050	1,400	1,750	1,100	1,650	2,200	2,750	3,300	
0.50	1,260	1,680	2,100	1,320	1,980	2,640	3,300	3,960	
0.40	1,575	2,100	2,625	1,650	2,475	3,300	4,125	4,950	
0.30	2,100	2,800	3,500	2,200	3,300	4,400	5,500	6,600	
0.20	3,150	4,200	5,250	3,300	4,950	6,600	8,250	9,900	
0.10	6,300	8,400	10,500	6,600	9,900	13,200	16,500	19,800	
0.00	NP	NP	NP	NP	NP	NP	NP	NP	

\*Air Changes/Hour



\*Minimum opening size is 100 in.2 with minimum dimensions of 3 in. (76 mm). \*Minimum of 3 in. (76 mm), when type -B1 vent is used.

#### Fig. 7 – Air for Combustion, Ventilation, and Dilution from Indoors

- 2. An attic or crawlspace may be considered a space that freely communicates with the outdoors provided there are adequate permanent ventilation openings directly to outdoors having free area of at least 1-in.<sup>2</sup>/4,000 Btuh of total input rating for all gas appliances in the space.
- 3. In spaces that use the Indoor Combustion Air Method, infiltration should be adequate to provide air for combustion, permanent ventilation and dilution of flue gases. However, in buildings with

unusually tight construction, additional air MUST be provided using the methods described in the Outdoor Combustion Air Method section.

- Unusually tight construction is defined as construction with: a.Walls and ceilings exposed to the outdoors have a continuous, sealed vapor barrier. Openings are gasketed or sealed and
  - b.Doors and openable windows are weatherstripped and
  - c.Other openings are caulked or sealed. These include joints around window and door frames, between sole plates and floors, between wall-ceiling joints, between wall panels, at penetrations for plumbing, electrical and gas lines, etc.

#### Combination of Indoor and Outdoor Air

- 1. Indoor openings shall comply with the Indoor Combustion Air Method below and,
- Outdoor openings shall be located as required in the Outdoor Combustion Air Method mentioned previously and,
- 3. Outdoor openings shall be sized as follows:
  - a.Calculate the Ratio of all Indoor Space volume divided by required volume for Indoor Combustion Air Method below.b.Outdoor opening size reduction Factor is 1 minus the Ratio in
  - a. above.
  - c.Minimum size of Outdoor openings shall be the size required in Outdoor Combustion Air Method above multiplied by reduction Factor in b. above. The minimum dimension of air openings shall be not less than 3 in. (80 mm).

#### INSTALLATION

#### UPFLOW INSTALLATION Bottom Return Air Inlet

These furnaces are shipped with bottom closure panel installed in bottom return-air opening. Remove and discard this panel when bottom return air is used. To remove bottom closure panel, perform the following:

- 1. Tilt or raise furnace and remove two screws holding bottom filler panel (see Fig. 8).
- 2. Rotate bottom filler panel downward to release holding tabs.
- 3. Remove bottom closure panel.
- 4. Reinstall bottom filler panel and screws.



A10273

Fig. 8 - Removing Bottom Closure Panel

#### Side Return Air Inlet

These furnaces are shipped with bottom closure panel installed in bottom return-air opening. This panel MUST be in place when only side return air is used.

**NOTE:** Side return-air openings can be used in UPFLOW and most HORIZONTAL configurations. Do not use side return-air openings in DOWNFLOW configuration.

#### DOWNFLOW INSTALLATION

**NOTE:** For downflow applications, this furnace is approved for use on combustible flooring when any one of the following 3 accessories are used:

- Special Base, KGASB
- Cased Coil Assembly Part No. CNPV, CNRV, CAP, or CAR
- Coil Box Part No. KCAKC
- 1. Determine application being installed from Table 3.
- 2. Construct hole in floor (see Table 3 and Fig. 9).
- 3. Construct plenum to dimensions specified (see Table 3 and Fig. 9).
- 4. If downflow subbase KGASB is used, install as shown (see Table 10). If Coil Assembly Part No. CNPV, CNRV, CAP and CNR or Coil Box Part No. KCAKC is used, install as shown (see Fig. 11).

**NOTE:** It is required that the perforated supply-air duct flanges be completely folded over or removed from furnace when installing the furnace on a factory-supplied cased coil or coil box. To remove the supply-air duct flange, use wide duct pliers or hand seamers to bend flange back and forth until it breaks off. Be careful of sharp edges. Refer to Duct Flanges (Fig. 16) in the "Air Ducts" section.)

#### **Bottom Return Air Inlet**

These furnaces are shipped with bottom closure panel installed in bottom return-air opening. Remove and discard this panel when bottom return air is used. To remove bottom closure panel, perform the following:

- 1. Tilt or raise furnace and remove two screws holding bottom filler panel (see Fig. 8).
- 2. Rotate bottom filler panel downward to release holding tabs.
- 3. Remove bottom closure panel.
- 4. Reinstall bottom filler panel and screws



Fig. 9 – Floor and Plenum Opening Dimensions

A96283



Fig. 10 – Furnace, Plenum, and Subbase Installed on a Combustible Floor



Fig. 11 – Furnace, Plenum, and Coil Assembly or Coil Box Installed on a Combustible Floor

FURNACE		PLENUM	OPENING	FLOOR OPENING		
CASING WIDTH	APPLICATION	Α	В	С	D	
	Upflow Applications on Combustible or Noncombustible Flooring	12-11/16	21-5/8	13-5/16	22-1/4	
	(subbase not required)	(322)	(549)	(338)	(565)	
	Downflow Applications on Noncombustible Flooring	12-9/16	19	13-3/16	19-5/8	
14-3/16	(subbase not required)	(319)	(483)	(335)	(498)	
(360)	Downflow Applications on Combustible Flooring	11-13/16	19	13-7/16	20-5/8	
	(subbase required)	(284)	(483)	(341)	(600)	
	Downflow Applications on Combustible Flooring with Cased Coil	12-5/16	19	13-5/16	20	
	(subbase not required)	(319)	(483)	(338)	(508)	
	Upflow Applications on Combustible or Noncombustible Flooring	16	21-5/8	16-5/8	22-1/4	
	(subbase not required)	(406)	(549)	(422)	(565)	
	Downflow Applications on Noncombustible Flooring	15-7/8	19	16-1/2	19-5/8	
17–1/2 (445)	(subbase not required)	(403)	(483)	(419)	(498)	
	Downflow Applications on Combustible Flooring	15-1/8	19	16-3/4	20-5/8	
	(subbase required)	(384)	(483)	(425)	(600)	
	Downflow Applications on Combustible Flooring with Cased Coil	15-1/2	19	16-1/2	20	
	(subbase not required)	(394)	(483)	(419)	(508)	
	Upflow Applications on Combustible or Noncombustible Flooring	19-1/2	21-5/8	20-1/8	22-1/4	
	(subbase not required)	(495)	(549)	(511)	(565)	
_	Downflow Applications on Noncombustible Flooring	19-3/8	19	20	19-5/8	
21	(subbase not required)	(492)	(483)	(508)	(498)	
(533)	Downflow Applications on Combustible Flooring	18-5/8	19	20-1/4	20-5/8	
	(subbase required)	(473)	(483)	(514)	(600)	
	Downflow Applications on Combustible Flooring with Cased Coil	19	19	20	20	
	(subbase not required)	(483)	(483)	(508)	(508)	
	Upflow Applications on Combustible or Noncombustible Flooring	23	21-1/8	23-5/8	22-1/4	
	(subbase not required)	(584)	(537)	(600)	(565)	
Ē	Downflow Applications on Noncombustible Flooring	22-7/8	19	23-1/2	19-5/8	
24-1/2	(subbase not required)	(581)	(483)	(597)	(498)	
(622)	Downflow Applications on Combustible flooring	22-1/8	19	23-3/4	20-5/8	
	(subbase required)	(562)	(483)	(603)	(600)	
Ē	Downflow Applications on Combustible Flooring with Cased Coil	22-1/2	19	23-1/2	20	
	(subbase not required)	(572)	(483)	(597)	(508)	

#### Table 3 – Opening Dimensions - In. (mm)

## ! WARNING

## FIRE, EXPLOSION, AND CARBON MONOXIDE POISONING HAZARD

Failure to follow this warning could result in personal injury, death, and/or property damage.

Do not install the furnace on its back or hang furnace with control compartment facing downward. Safety control operation will be adversely affected. Never connect return-air ducts to the back of the furnace.

#### HORIZONTAL INSTALLATION

The furnace can be installed horizontally in an attic or crawl space on either the left-hand (LH) or right-hand (RH) side. The furnace can be hung from floor joists, rafters or trusses or installed on a non-combustible platform, blocks, bricks or pad.

#### **Bottom Return Air Inlet**

These furnaces are shipped with bottom closure panel installed in bottom return-air opening. Remove and discard this panel when bottom return air is used. To remove bottom closure panel, perform the following:

- 1. Tilt or raise furnace and remove two screws holding bottom filler panel (see Fig. 8).
- 2. Rotate bottom filler panel downward to release holding tabs.
- 3. Remove bottom closure panel.

4. Reinstall bottom filler panel and screws. Side Return Air Inlet **Side Return Air Inlet** 

These furnaces are shipped with bottom closure panel installed in bottom return-air opening. This panel MUST be in place when side return air inlet(s) is used without a bottom return air inlet.

Not all horizontal furnaces are approved for side return air connections (see Fig. 20).

#### FILTER ARRANGEMENT



## CARBON MONOXIDE AND POISONING HAZARD

Failure to follow this warning could result in personal injury, or death. Never operate a furnace without a filter or with filter access door removed.

There are no provisions for an internal filter rack in these furnaces.

A field-supplied accessory external filter is required.

Refer to the instructions supplied with the external filter rack for assembly and installation options.

#### Leveling Legs (If Desired)

In upflow position with side return inlet(s), leveling legs may be used (see Fig. 12). Install field-supplied,  $5/16 \times 1-1/2$  in. (8 x 38 mm) (max) corrosion-resistant machine bolts, washers and nuts.



Fig. 12 – Leveling Legs

A89014

**NOTE:** Bottom closure must be used when leveling legs are used. It may be necessary to remove and reinstall bottom closure panel to install leveling legs. To remove bottom closure panel, see Item 1. in Bottom Return Air Inlet section.

To install leveling legs:

- 1. Position furnace on its back. Locate and drill a hole in each bottom corner of furnace (see Fig. 12).
- 2. For each leg, install nut on bolt and then install bolt and nut in hole. (Install flat washer if desired.)
- 3. Install another nut on other side of furnace base. (Install flat washer if desired.)
- 4. Adjust outside nut to provide desired height, and tighten inside nut to secure arrangement.
- 5. Reinstall bottom closure panel if removed.

#### LOCATION RELATIVE TO COOLING EQUIPMENT

The cooling coil must be installed parallel with, or on the downstream side of the unit to avoid condensation in the heat exchangers. When installed parallel with the furnace, dampers or other flow control must prevent chilled air from entering the furnace. If the dampers are manually operated, they must be equipped with means to prevent operation of either unit unless the damper is in the full-heat or full-cool position.

#### Suspended Furnace Support

The furnace may be supported under each end with threaded rod, angle iron or metal plumber's strap as shown (see Fig. 14 and Fig. 15). Secure angle iron to bottom of furnace as shown. Heavy-gauge sheet metal straps (plumber's straps) may be used to suspend the furnace from each bottom corner. To prevent screws from pulling out, use  $2 \#8 \times 3/4$ -in. (19 mm) screws into the side and  $2 \#8 \times 3/4$ -in. (19 mm) screws in the bottom of the furnace casing for each strap (see Fig. 14 and Fig. 15). If the screws are attached to ONLY the furnace sides and not the bottom, the straps must be vertical against the furnace sides and not pull away from the furnace sides, so that the strap attachment screws are not in tension (are loaded in shear) for reliable support.

#### Platform Furnace Support

Construct working platform at location where all required furnace clearances are met (see Fig. 1 and Fig. 13). For furnaces with 1-in. (25 mm) clearance requirement on side, set furnace on noncombustible blocks, bricks or angle iron. For crawl space installations, if the furnace is not suspended from the floor joists, the ground underneath furnace must be level and the furnace set on blocks or bricks.



Fig. 13 – Typical Attic Installation



Fig. 14 – Horizontal Unit Suspension



Fig. 15 – Horizontal Suspension with Straps

58SB0A/58SB1A: Installation, Start-Up, Operating and Service and Maintenance Instructions

#### **Roll-Out Protection**

Provide a minimum 17-3/4 in. x 22 in. (451 mm x 559 mm) piece of sheet metal for flame roll-out protection in front of burner area for furnaces closer than 12 inches (305 mm) above the combustible deck or suspended furnaces closer than 12 inches (305 mm) to joists. The sheet metal MUST extend underneath the furnace casing by 1 in. (25 mm) with the door removed.

The bottom closure panel on furnaces of widths 17-1/2 in. (445 mm) and larger may be used for flame roll-out protection when bottom of furnace is used for return air connection. See Fig. 13 for proper orientation of roll-out shield.

#### **AIR DUCTS**

#### **GENERAL REQUIREMENTS**

The duct system should be designed and sized according to accepted national standards such as those published by: Air Conditioning Contractors Association (ACCA), Sheet Metal and Air Conditioning Contractors National Association (SMACNA) or American Society of Heating, Refrigerating and Air Conditioning Engineers (ASHRAE) or consult The Air Systems Design Guidelines reference tables available from your local distributor. The duct system should be sized to handle the required system design CFM at the design external static pressure. The furnace airflow rates are provided in Table 4-AIR DELIVERY-CFM (With Filter).

When a furnace is installed so that the supply ducts carry air circulated by the furnace to areas outside the space containing the furnace, the return air shall also be handled by duct(s) sealed to the furnace casing and terminating outside the space containing the furnace.

Secure ductwork with proper fasteners for type of ductwork used. Seal supply- and return-duct connections to furnace with code approved tape or duct sealer.

**NOTE:** Flexible connections should be used between ductwork and furnace to prevent transmission of vibration. Ductwork passing through unconditioned space should be insulated and sealed to enhance system performance. When air conditioning is used, a vapor barrier is recommended.

Maintain a 1-in. (25 mm) clearance from combustible materials to supply air ductwork for a distance of 36 in. (914 mm) horizontally from the furnace. See NFPA 90B or local code for further requirements.

#### **Ductwork Acoustical Treatment**

**NOTE:** Metal duct systems that do not have a 90 degree elbow and 10 ft. (3 M) of main duct to the first branch take-off may require internal acoustical lining. As an alternative, fibrous ductwork may be used if constructed and installed in accordance with the latest edition of SMACNA construction standard on fibrous glass ducts. Both acoustical lining and fibrous ductwork shall comply with NFPA 90B as tested by UL Standard 181 for Class 1 Rigid air ducts.

#### SUPPLY AIR CONNECTIONS

For a furnace not equipped with a cooling coil, the outlet duct shall be provided with a removable access panel. This opening shall be accessible when the furnace is installed and shall be of such a size that the heat exchanger can be viewed for possible openings using light assistance or a probe can be inserted for sampling the airstream. The cover attachment shall prevent leaks.

#### Upflow and Horizontal Furnaces

Connect supply-air duct to flanges on furnace supply-air outlet. Bend flange upward to 90° with wide duct pliers (see Fig. 16). The supply-air duct must be connected to ONLY the furnace supply-outlet-air duct flanges or air conditioning coil casing (when used). DO NOT cut main furnace casing side to attach supply air duct, humidifier, or other accessories. All accessories **MUST** be connected to duct external to furnace main casing.

**NOTE:** For horizontal applications, the top-most flange may be bent past 90 degrees to allow the evaporator coil to hang on the flange temporarily while the remaining attachment and sealing of the coil are performed.

#### **Downflow Furnaces**

Connect supply-air duct to supply-air outlet on furnace. Bend flange inward past 90° with wide duct pliers (see Fig. 16). The supply-air duct must be connected to ONLY the furnace supply outlet or air conditioning coil casing (when used). When installed on combustible material, supply-air duct must be connected to ONLY the factory-approved accessory subbase or a factory- approved air conditioning coil casing. DO NOT cut main furnace casing to attach supply side air duct, humidifier, or other accessories. All accessories **MUST** be connected to duct external to furnace casing.

#### **Return Air Connections**

## CAUTION

#### FIRE HAZARD

Failure to follow this warning could cause personal injury, death and/or property damage.

Never connect return-air ducts to the back of the furnace. Follow instructions below.



Fig. 16 – Duct Flanges

#### **Downflow Furnaces**

The return-air duct must be connected to return-air opening bottom inlet (see Fig. 17). DO NOT cut into casing sides (left or right). Side opening is permitted for only upflow and most horizontal furnaces (see Fig. 18). Bypass humidifier connections should be made at ductwork or coil casing sides exterior to furnace.

F	Wire Lead		1		Test Airf	low Delive	ry @ Vari	ious Exter	nal Static	Pressures		
Furnace	Color	Function	0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1
	Gray	Cooling. Do not use for heating.	1230	1190	1155	1120	1080	1045	1010	975	935	895
	Yellow	Alt Cooling or alt Heating	980	945	920	890	855	815	770	735	690	645
045E14-12	Orange	Alt Cooling or alt Heating	770	720	685	640	600	560	520	475	430	385
	Blue	Heating or alt Cooling	710	660	620	580	540	490	455	415	375	335
	Red	Alt Cooling. Do not use for heating.	600	540	500	455	415	385	345	305	235	-
	Gray	Cooling. Do not use for heating.	1370	1335	1295	1255	1215	1175	1135	1095	1055	1020
	Yellow	Alt Cooling or alt Heating	1130	1085	1040	995	955	910	865	825	780	730
045E17-12	Orange	Alt Cooling or alt Heating	930	885	835	795	745	700	655	600	545	495
010217 12	Blue	Heating or alt Cooling	760	720	670	625	580	515	460	410	355	300
	Red	Alt Cooling. Do not use for heating.	610	500	445	375	320	260	200	135	-	-
	Gray	Cooling. Do not use for heating.	1205	1170	1143	1105	1070	1035	1000	960	925	885
	Blue	Heating or alt Cooling	1095	1060	1030	995	960	925	885	840	800	735
070514 12			920	880	845	805	765	730	685	620	560	510
070E14-12	Yellow	Alt Cooling or alt Heating	715	650	610		520	465	410	380	305	245
	Orange	Alt Cooling. Do not use for heating.				575						
	Red	Alt Cooling. Do not use for heating.	635	490	445	375	315	270	205	230	190	140
	Gray	Cooling. Do not use for heating.	1185	1140	1095	1055	1005	960	915	865	820	780
	Yellow	Alt Cooling or alt Heating	1000	940	895	850	800	750	695	650	600	555
070E17-12	Blue	Heating or alt Cooling	990	935	895	845	790	740	690	640	590	535
	Orange	Alt Cooling or alt Heating	855	775	720	660	605	560	495	435	385	335
	Red	Alt Cooling. Do not use for heating.	860	685	515	445	385	340	275	205	-	-
	Gray	Cooling. Do not use for heating.	1650	1615	1580	1545	1515	1480	1445	1415	1380	1350
070E17-16	Yellow	Alt Cooling. Do not use for heating	1405	1365	1325	1285	1250	1215	1175	1140	1100	1065
	Orange	Alt Cooling or alt Heating	1255	1215	1175	1130	1090	1090	1010	970	930	895
	Blue	Heating or alt Cooling	1185	1140	1095	1050	1005	1005	920	880	840	800
	Red	Alt Cooling. Do not use for heating.	1100	1050	1005	960	915	915	825	785	740	700
	Gray	Cooling. Do not use for heating.	1735	1685	1640	1595	1545	1495	1450	1405	1360	1310
	Yellow	Alt Cooling or alt Heating	1480	1435	1395	1340	1290	1240	1190	1135	1085	1030
070E21-16	Blue	Heating or alt Cooling	1315	1275	1225	1180	1135	1085	1030	975	915	860
	Orange	Alt Cooling or alt Heating	1135	1080	1030	985	935	885	835	770	705	645
	Red	Alt Cooling. Do not use for heating.	980	930	875	820	775	715	665	595	530	455
	Gray	Cooling. Do not use for heating.	1355	1320	1285	1245	1210	1165	1125	1080	1025	815
	Yellow	Alt Cooling or alt Heating	1295	1255	1220	1185	1140	1100	1055	1005	955	815
090E17-14	Blue	Heating or alt Cooling	1220	1185	1150	1105	1065	1025	975	915	840	740
	Orange	Alt Cooling or alt Heating	1030	985	940	900	845	790	715	655	590	535
	Red	Alt Cooling. Do not use for heating.	945	905	855	800	750	670	600	540	490	435
	Gray	Cooling. Do not use for heating.	1625	1580	1535	1490	1445	1395	1340	1260	1135	995
	Yellow	Alt Cooling or alt Heating	1425	1380	1335	1290	1235	1185	1125	1075	1020	640
090E21-16	Blue	Heating or alt Cooling	1440	1395	1350	1305	1255	1200	1145	1090	1040	950
	Orange	Alt Cooling or alt Heating	1260	1210	1160	1105	1050	990	935	880	820	755
	Red	Alt Cooling. Do not use for heating.	1095	1040	980	905	845	780	720	650	585	520
	Gray	Cooling. Do not use for heating.	2180	2130	2080	2030	1980	1925	1870	1805	1745	1680
	Yellow	Alt Cooling or alt Heating	1900	1845	1795	1740	1685	1635	1570	1500	1435	1375
090E21-20	Blue	Heating or alt Cooling	1685	1620	1565	1505	1455	1385	1320	1260	1200	1140
.,	Orange	Alt Cooling or alt Heating	1390	1315	1240	1175	1095	1030	970	900	825	760
	Red	Alt Cooling. Do not use for heating.	1240	1155	1075	990	915	835	765	690	615	555
	Gray	Cooling. Do not use for heating.	2190	2135	2075	2015	1960	1900	1835	1775	1705	1630
	Yellow	Alt Cooling or alt Heating	1870	1810	1745	1685	1625	1565	1495	1420	1345	1280
090E24-20	Blue	Heating or alt Cooling	1580	1510	1/45	1385	1320	1240	1175	1115	1050	970
0901224-20	Orange	Alt Cooling or alt Heating	1305	1220	11443	1383	1000	930	865	770	690	610
	-						845					
	Red	Alt Cooling. Do not use for heating.	1210	1075	1000	915		765	675	595	515	425
	Gray	Cooling. Do not use for heating.	2255	2205	2150	2100	2040	1985	1920	1835	1735	1615
110721	Blue	Heating or alt Cooling	1945	1890	1830	1770	1715	1655	1600	1545	1480	1430
110E21-20	Yellow	Alt Cooling or alt Heating	1600	1525	1465	1400	1335	1275	1210	1150	1080	1015
	Orange	Alt Cooling. Do not use for heating.	1420	1340	1280	1200	1140	1065	1005	925	865	790
	Red	Alt Cooling. Do not use for heating.	1280	1205	1140	1055	990	910	840	760	695	630

#### Table 4 – Air Delivery - CFM (With Filter)\*

Table 4 – Air Delivery	- CFM (	With Filter)*	* (Continued)
------------------------	---------	---------------	---------------

Furnace	Wire Lead	Function			Test Airf	low Delive	Delivery @ Various External Static Pressures					
Furnace	Color	Color		0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1
	Gray	Cooling. Do not use for heating.	2250	2190	2130	2070	2005	1950	1885	1820	1755	1685
	Blue	Heating or alt Cooling	1995	1930	1865	1800	1740	1670	1605	1535	1465	1400
110E24-20	Yellow	Alt Cooling or alt Heating	1540	1460	1385	1305	1235	1165	1095	1035	955	890
	Orange	Alt Cooling. Do not use for heating.	1345	1195	1135	1055	980	920	845	770	695	620
	Red	Alt Cooling. Do not use for heating.		1075	965	890	820	735	660	580	505	440
	Gray	Cooling. Do not use for heating.	2065	2005	1940	1875	1810	1740	1670	1600	1530	1470
	Blue	Heating or alt Cooling	1825	1760	1695	1630	1560	1490	1420	1350	1275	1205
135E24-20	Yellow	Alt Cooling or alt Heating		1690	1625	1555	1485	1415	1345	1275	1200	1130
	Orange	Alt Cooling. Do not use for heating.		1550	1480	1405	1335	1260	1195	1130	1065	995
	Red	Alt Cooling. Do not use for heating.	1325	1260	1185	1100	1025	955	885	805	735	670
	Gray	Cooling. Do not use for heating.	2205	2150	2090	2030	1965	1905	1840	1780	1710	1645
	Blue	Heating or alt Cooling	2055	1995	1935	1875	1810	1750	1690	1615	1540	1460
155E24-20	Yellow	Alt Cooling or alt Heating	1860	1795	1730	1670	1605	1540	1470	1395	1320	1250
	Orange	Alt Cooling. Do not use for heating.	1495	1430	1355	1285	1210	1130	1065	995	930	850
	Red	Alt Cooling. Do not use for heating.	1295	1085	1000	910	835	765	670	600	530	465

1. A filter is required for each return-air inlet. Airflow performance included 3/4-in. (19 mm) washable filter (see accessory list). To determine airflow performance without this filter, assume an additional 0.1 In. W.C. available external static pressure.

2. Adjust the blower speed tabs as necessary for the proper air temperature rise for each installation.

3. -- Indicates unstable operating conditions.

4. If the same motor speed tap is needed for heating and cooling, a Jumper Wire accessory kit is available. (See Product Data sheet for the current Jumper Wire accessory part number). See Function column for applicable limitations.



NOTES:

1. Two additional 7/8-in. (22 mm) diameter holes are located in the top plate.

2. Minimum return-air openings at furnace, based on metal duct. If flex duct is used, see flex duct manufacturer's recommendations for equivalent diameters.

- a. For 800 CFM-16-in. (406 mm) round or 14 1/2 x 12-in. (368 x 305 mm) rectangle.
- b. For 1200 CFM-20-in. (508 mm) round or 14 1/2 x 19 1/2-in. (368 x 495 mm) rectangle.
- c. For 1600 CFM-22-in. (559 mm) round or 14 1/2 x 22 1/16-in. (368 x 560mm) rectangle.
- d. For airflow requirements above 1800 CFM, see Air Delivery table in Product Data Sheet literature for specific use of single side inlets. The use of both side inlets, a combination of 1 side and the bottom, or the bottom only will ensure adequate return air openings for airflow requirements above 1800 CFM.

Fig. 17 – Dimensional Drawing

13

Unit Size	A CABINET WIDTH	B OUTLET WIDTH	C TOP AND BOTTOM FLUE COLLAR	D BOTTOM INLET WIDTH	VENT CONNECTION SIZE	SHIP WT. LB. (KG)
045E14-12	14-3/16 (360)	12-9/16 (319)	9-5/16 (237)	12-11/16 (322)	4 (102)	104 (47)
045E17-12	17-1/2 (445)	15-7/8 (403)	11-9/16 (294)	16 (406)	4 (102)	119 (54)
070E14-12	14-3/16 (360)	12-9/16 (319)	9-5/16 (237)	12-11/16 (322)	4 (102)	114 (52)
070E17-12	17-1/2 (445)	15-7/8 (403)	11-9/16 (294)	16 (406)	4 (102)	120 (54)
070E17-16	17-1/2 (445)	15-7/8 (403)	11-9/16 (294)	16 (406)	4 (102)	126 (57)
070E21-16	21 (533)	19-3/8 (492)	13-5/16 (338)	19-1/2 (495)	4 (102)	142 (64)
090E17-14	17-1/2 (445)	15-7/8 (403)	11-9/16 (294)	16 (406)	4 (102)	131 (49)
090E21-16	21 (533)	19-3/8 (492)	13-5/16 (338)	19-1/2 (495)	4 (102)	137 (62)
090E21-20	21 (533)	19-3/8 (492)	13-5/16 (338)	19-1/2 (495)	4 (102)	140 (64)
090E24-20	24-1/2 (622)	22-7/8 (581)	15-1/16 (383)	23 (584)	4 (102)	146 (66)
110E21-20	21 (533)	19-3/8 (492)	13-5/16 (338)	19-1/2 (495)	4 (102)	146 (66)
110E24-20	24-1/2 (622)	22-7/8 (581)	15-1/16 (383)	23 (584)	4 (102)	161 (73)
135E24-20	24-1/2 (622)	22-7/8 (581)	15-1/16 (383)	23 (584)	4 (102)	167 (76)
155E24-20	24-1/2 (622)	22-7/8 (581)	15-1/16 (383)	23 (584)	4 (102)	168 (76)

Table 5 – Dimensions

\*135 and 155 size furnaces requires a 5 or 6-in. (127 or 152 mm) vent. Use a vent adapter between furnace and vent stack. See Installation Instructions for complete installation requirements.

#### Upflow Furnaces

The return-air duct must be connected to bottom, sides (left or right), or a combination of bottom and side(s) of main furnace casing (see Fig. 19 and Fig. 20). Bypass humidifier may be attached into unused return air side of the furnace casing (see Fig. 19 and Fig. 20). Not all horizontal furnaces are approved for side return air connections (see Fig. 20).



Fig. 18 – Downflow Return Air Configurations and Restrictions



Fig. 19 – Upflow Return Air Configurations and Restrictions



Fig. 20 – Horizontal Return Air Configurations and Restrictions

#### **GAS PIPING**

Gas piping must be installed in accordance with national and local codes. Refer to current edition of NFGC.

Installations must be made in accordance with all authorities having jurisdiction. If possible, the gas supply line should be a separate line running directly from meter to furnace.

NOTE: In the state of Massachusetts:

- 1. Gas supply connections MUST be performed by a licensed plumber or gas fitter.
- 2. When flexible connectors are used, the maximum length shall not exceed 36 inches (915 mm).
- When lever handle type manual equipment shutoff valves are used, they shall be T-handle valves.
- 4. The use of copper tubing for gas piping is NOT approved by the state of Massachusetts.

## ! WARNING

#### FIRE OR EXPLOSION HAZARD

Failure to follow this warning could result in personal injury, death, and/or property damage.

Never purge a gas line into a combustion chamber. Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections. A fire or explosion may result causing property damage, personal injury or loss of life.

Use proper length of pipe to avoid stress on gas control manifold and gas valve.

Gas valve inlet and/or inlet pipe must remain capped until gas supply line is permanently installed to protect the valve from moisture and debris. Also, install a sediment trap in the gas supply piping at the inlet to the gas valve.

Refer to Table 6 for recommended gas pipe sizing. Risers must be used to connect to furnace and to meter. Support all gas piping with appropriate straps, hangers, etc. Use a minimum of 1 hanger every 6 ft. (2 M). Joint compound (pipe dope) should be applied sparingly and only to male threads of joints. Pipe dope must be resistant to the action of propane gas.

NOMINAL IRON PIPE	INTERNAL DIAMETER	LENGTH OF PIPE - FT. (M)							
SIZE IN. (mm)	In. (mm)		20	30	40	50			
1/2 (13)	0.622 (16)	175 (53)	120 (37)	97 (30)	82 (25)	73 (22)			
3/4 (19)	0.824 (21)	360 (110)	250 (76)	200 (61)	170 (52)	151 (46)			
1 (25)	1.049 (27)	680 (207)	465 (142)	375 (114)	320 (98)	285 (87)			
1-1/4 (32)	1.380 (35)	1400 (427)	950 (290)	770 (235)	660 (201)	580 (177)			
1-1/2 (38)	1.610 (41)	2100 (640)	1460 (445)	1180 (360)	990 (301)	900 (274)			

Table 6 - Maximum Capacity of Pipe\*

\* Cubic ft. of natural gas per hr for gas pressures of 0.5 psig (14-In. W.C.) or less and a pressure drop of 0.5-In. W.C. (based on a 0.60 specific gravity gas). Ref: Chapter 6 current edition of ANSI Z223/NFPA 54.

## WARNING

#### FIRE OR EXPLOSION HAZARD

Failure to follow this warning could result in personal injury, death, and/or property damage.

If local codes allow the use of a flexible gas appliance connector, always use a new listed connector. Do not use a connector which has previously served another gas appliance. Black iron pipe shall be installed at the furnace gas control valve and extend a minimum of 2 in.(51 mm) outside the furnace.

## **CAUTION**

#### FURNACE OVERHEAT HAZARD

Failure to follow this caution may result in property damage. Connect gas pipe to gas valve using a backup wrench to avoid damaging gas controls and burner misalignment.

An accessible manual equipment shutoff valve **MUST** be installed external to furnace casing and within 6 ft. (2 M) of furnace. A 1/8-in. (3 mm) NPT plugged tapping, accessible for test gauge connection, **MUST**  be installed immediately upstream of gas supply connection to furnace and downstream of manual equipment shutoff valve.

**NOTE:** The furnace gas control valve inlet pressure tap connection is suitable to use as test gauge connection providing test pressure DOES NOT exceed maximum 0.5 psig (14-In. W.C.) stated on gas control valve (see Fig. 21).



Fig. 21 – Gas Control Valve

A06666

Some installations require gas entry on right side of furnace (as viewed in upflow.) (See Fig. 22).





Fig. 22 – Burner and Manifold

Install a sediment trap in riser leading to furnace (see Fig. 23). Connect a capped nipple into lower end of tee. Capped nipple should extend below level of furnace gas controls. Place a ground joint union between furnace gas control valve and exterior manual equipment gas shutoff valve.

A 1/8-in. (3 mm) NPT plugged tapping, accessible for test gauge connection, MUST be installed immediately upstream of gas supply connection to furnace and downstream of manual equipment shutoff valve.



Fig. 23 - Typical Gas Pipe Arrangement

Piping should be pressure and leak tested in accordance with NFGC in the United States, local, and national plumbing and gas codes before the furnace has been connected. After all connections have been made, purge lines and check for leakage at furnace prior to operating furnace.

If pressure exceeds 0.5 psig (14-In. W.C.), gas supply pipe must be disconnected from furnace and capped before and during supply pipe pressure test. If test pressure is equal to or less than 0.5 psig (14-In. W.C.), turn off electric shutoff switch located on furnace gas control valve and accessible manual equipment shutoff valve before and during supply pipe pressure test. After all connections have been made, purge lines and check for leakage at furnace prior to operating furnace.

The gas supply pressure shall be within the maximum and minimum inlet supply pressures marked on the rating plate with the furnace burners ON and OFF.

#### **ELECTRICAL CONNECTIONS**

See Fig. 24 for field wiring diagram showing typical field 115-v wiring. Check all factory and field electrical connections for tightness.

Field-supplied wiring shall conform with the limitations of  $63^{\circ}F$  ( $35^{\circ}C$ ) rise.

## WARNING

#### ELECTRICAL SHOCK, FIRE OR EXPLOSION HAZARD

Failure to follow safety warnings could result in dangerous operation, serious injury, death or property damage.

Improper servicing could result in dangerous operation, serious injury, death or property damage.

- Before servicing, disconnect all electrical power to furnace.

- When servicing controls, label all wires prior to disconnection. Reconnect wires correctly.

- Verify proper operation after servicing.

## NARNING

#### ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death. Blower access panel door switch opens 115-v power to control. No component operation can occur. Do not bypass or close switch with panel removed.

## WARNING

#### ELECTRICAL SHOCK AND FIRE HAZARD

Failure to follow this warning could result in personal injury, death, or property damage.

The cabinet MUST have an uninterrupted or unbroken ground according to current edition of NEC NFPA 70 or local codes to minimize personal injury if an electrical fault should occur. This may consist of electrical wire, conduit approved for electrical ground or a listed, grounded power cord (where permitted by local code) when installed in accordance with existing electrical codes. Refer to the power cord manufacturer's ratings for proper wire gauge. Do not use gas piping as an electrical ground.



#### FURNACE MAY NOT OPERATE

Failure to follow this caution may result in intermittent furnace operation. Furnace control must be grounded for proper operation or else control will lock out. Control must remain grounded through green/yellow wire routed to gas valve and manifold bracket screw.

#### **115-V WIRING**

A02035

Verify that the voltage, frequency, and phase correspond to that specified on unit rating plate. Also, check to be sure that service provided by utility is sufficient to handle load imposed by this equipment. Refer to rating plate or Table 7 for equipment electrical specifications.

**U.S. Installations:** Make all electrical connections in accordance with National Electrical Code (NEC) NFPA 70 and any local codes or ordinances that might apply.

Use a separate, fused branch electrical circuit with a properly sized fuse or circuit breaker for this furnace. See Table 7 for wire size and fuse specifications. A readily accessible means of electrical disconnect must be located within sight of the furnace.

**NOTE:** Proper polarity must be maintained for 115-v wiring. If polarity is incorrect, control LED status indicator light will flash rapidly and furnace will NOT operate.



same type or equivalent wire.



#### Fig. 24 – Heating and Cooling Application Wiring Diagram with 1-Stage Thermostat

## WARNING

#### FIRE HAZARD

Failure to follow this warning could result in personal injury, death, or property damage.

Do not connect aluminum wire between disconnect switch and furnace. Use only copper wire (see Fig. 25).



Fig. 25 – Field-Supplied External Electrical Box on Furnace Casing Table 7 – Electrical Data

Unit Size	Volts-			Minimum Wire	Maximum Wire Length <sup>‡</sup>		Maximum Fuse	
	Hertz- Phase	Maximum	Minimum	Ampacity#	Size AWG	feet	m	or CKT BKR Amps <sup>†</sup>
045E14-12	115-60-1	127	104	7.8	14	47	14.3	15
045E17-12	115-60-1	127	104	10.3	14	36	11	15
070E14-12	115-60-1	127	104	7.8	14	47	14.3	15
070E17-12	115-60-1	127	104	7.8	14	47	14.3	15
070E17-16	115-60-1	127	104	14.3	14	25	7.6	15
070E21-16	115-60-1	127	104	13.3	14	27	8.2	15
090E17-14	115-60-1	127	104	11	14	33	10.1	15
090E21-16	115-60-1	127	104	11	14	33	10.1	15
090E21-20	115-60-1	127	104	16.9	12	34	10.4	20
090E24-20	115-60-1	127	104	13.5	14	27	8.2	15
110E21-20	115-60-1	127	104	17.4	12	33	10.1	20
110E24-20	115-60-1	127	104	14	14	26	7.9	15
135E24-20	115-60-1	127	104	14	14	26	7.9	15
155E24-20	115-60-1	127	104	14	14	26	7.9	15

\* Permissible limits of the voltage range at which the unit operates satisfactorily.

# Unit ampacity = 125 percent of largest operating component's full load amps plus 100 percent of all other potential operating components' (EAC, humidifier, etc.) full load amps.

† Time-delay type is recommended.

‡ Length shown is as measured one way along wire path between unit and service panel for maximum 2 percent voltage drop.

#### J-BOX RELOCATION

**NOTE:** If factory location of J-Box is acceptable, go to next section (ELECTRICAL CONNECTION TO J-BOX).

**NOTE:** On 14-in. (356 mm) wide casing models, the J-Box shall not be relocated to other side of furnace casing when the vent pipe is routed within the casing.

1. Remove and save two screws holding J-Box.

**NOTE:** The J-Box cover need not be removed from the J-Box in order to move the J-Box. Do NOT remove green ground screw inside J-Box (see Fig. 26).

- 2. Cut wire tie on loop in furnace wires attached to J-box.
- 3. Move J-Box to desired location.
- 4. Fasten J-Box to casing with two screws removed in Step 1.
- 5. Route J-Box wires within furnace away from sharp edges, rotating parts and hot surfaces.



Fig. 26 – Relocating J-Box

Electrical Connection to J-Box Electrical Box on Furnace Casing Side

## WARNING

#### FIRE OR ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury, death, or property damage.

If field-supplied manual disconnect switch is to be mounted on furnace casing side, select a location where a drill or fastener cannot damage electrical or gas components.

- 1. Refer to Fig. 27 when installing an electrical box.
- 2. Select and remove a hole knockout in the casing where the electrical box is to be installed.

**NOTE:** Check that duct on side of furnace will not interfere with installed electrical box.

- 3. Remove the desired electrical box hole knockout and position the hole in the electrical box over the hole in the furnace casing.
- 4. Fasten the electrical box to casing by driving two field supplied screws from inside electrical box into casing steel.

# GROUND NEUTRAL

A190278

#### Fig. 27 – Field-Supplied Electrical Box on Furnace Casing

- 5. Remove and save two screws holding J-Box.
- Pull furnace power wires out of 1/2-in. (12 mm) diameter hole in J-Box. Do not loosen wires from strain-relief wire-tie on outside of J-Box.
- 7. Route furnace power wires through holes in casing and electrical box and into electrical box.
- 8. Pull field power wires into electrical box.
- 9. Remove cover from furnace J-Box.
- 10. Route field ground wire through holes in electrical box and casing, and into furnace J-Box.
- 11. Reattach furnace J-Box to furnace casing with screws removed in Step 4.
- 12. Secure field ground wire to J-Box green ground screw.
- 13. Complete electrical box wiring and installation. Connect line voltage leads (see Fig. 24). Use best practices (NEC in U.S. for wire bushings, strain relief, etc.)
- 14. Reinstall cover to J-Box. Do not pinch wires between cover and bracket.

#### Power Cord Installation in Furnace J-Box

**NOTE:** Power cords must be able to handle the electrical requirements listed in Table 7. Refer to power cord manufacturer's listings.

- 1. Remove cover from J-Box.
- 2. Route listed power cord through 7/8-in. (22 mm) diameter hole in J-Box.
- 3. Secure power cord to J-Box bracket with a strain relief bushing or a connector approved for the type of cord used.
- 4. Secure field ground wire to green ground screw on J-Box bracket.
- 5. Connect line voltage leads (see Fig. 24).
- 6. Reinstall cover to J-Box. Do not pinch wires between cover and bracket.

#### BX Cable Installation in Furnace J-Box

- 1. Remove cover from J-Box.
- 2. Route BX cable into 7/8-inch diameter hole in J-Box.
- 3. Secure BX cable to J-Box bracket with connectors approved for the type of cable used.
- 4. Secure field ground wire to green ground screw on J-Box bracket.
- 5. Connect line voltage leads (see Fig. 24).
- 6. Reinstall cover to J-Box. Do not pinch wires between cover and bracket.

#### 24-V Wiring

Make field 24-v connections at the 24-v terminal strip (see Fig. 20). Connect terminal Y for proper cooling operation (see Fig. 28). Use only AWG No. 18, color-coded, copper thermostat wire.

The 24-v circuit contains an automotive-type, 3-amp. fuse located on the control. Any direct shorts during installation, service, or maintenance could cause this fuse to blow. If fuse replacement is required, use ONLY a 3-amp. fuse of identical size.

#### ACCESSORIES

1. Electronic Air Cleaner (EAC)

Connect an accessory Electronic Air Cleaner (if used) using 1/4-in female quick connect terminals to the two male 1/4-in quick-connect terminals on the control board marked EAC-1 and EAC-2. The terminals are rated for 115 VAC, 1.0 amps maximum and are energized during blower motor operation (see Fig. 28).

2. Humidifier (HUM)

Connect an accessory 24 VAC, 0.5 amp. maximum humidifier (if used) to the 1/4-in male quick-connect HUM terminal and COM-24V screw terminal on the control board thermostat strip. The HUM terminal is energized when the pressure switch closes during a call for heat (see Fig. 28).

**NOTE:** DO NOT connect furnace control HUM terminal to HUM (humidifier) terminal on Thermidistat<sup>m</sup>, Zone Controller or similar device. See Thermidistat, Zone Controller, thermostat, or controller manufacturer's instructions for proper connection.



#### Fig. 28 – Furnace Control

THERMOSTAT SINGLE-STAGE FURNACE SINGLE-SPEED HEAT PUMP SINGLE-STAGE SINGLE-SPEED THERMOSTAT RVS COOLING 0/W2 N/A 0/W2 N/A Y1/W2 N/A Y1/W2 HEAT STAGE 1 W/W1 w A W COOL STAGE 1 Y/Y2 Y HEAT STAGE 2 W/W1 (FURNACE) COOL STAGE 1 Y/Y2 <u>Y</u>/Y2 FAN G G 24 VAC HOT R FAN G G R DEHUMIDIFY D 24 VAC HOT R R 24 VAC COMM С DEHUMIDIFY
 D COM П ним С 24 VAC COMM COM [] ним HUMIDIFY HUM N/A В HUMIDIFIER (24 VAC) HUMIDIFY HUM S1 OUTDOOR N/A в ECTION S2 S1 OUTDOOR OUTDOOR SENSOR See notes 2, 5, 7, 9, and 12 CONNECTION S2 1, 2, 4, 6, 7, 8, 9, 11, and 12

Single-Stage Furnace with Single-Speed Air Conditioner

Single-Stage Furnace with Single-Speed Heat Pump

Fig. 29 – Thermostat Wiring Diagrams

A190023

#### NOTES FOR THERMOSTAT WIRING DIAGRAMS

- 1. Heat pump MUST have a high pressure switch for HYBRID HEAT<sup>®</sup> dual fuel applications.
- 2. Refer to outdoor equipment Installation Instructions for additional information and setup procedure.
- 3. If the heat pump date code is 1501E or earlier, select the "ZONE" position on the two speed heat pump control. Heat pumps with date code 1601E and later do not have or require a "ZONE" selection.
- 4. Outdoor Air Temperature Sensor must be attached in all HYBRID HEAT<sup>®</sup> dual fuel applications.
- 5. Configure the thermostat for air conditioner installations. Refer to thermostat instructions.
- 6. Configure thermostat for heat pump installations. Refer to thermostat instructions.
- 7. Configure thermostat for single-stage compressor operation. Refer to thermostat instructions.
- 8. Configure thermostat for HYBRID HEAT<sup>®</sup> dual fuel operation. Refer to thermostat instructions.
- 9. NO connection should be made to the furnace HUM terminal when using a thermostat with a 24 volt humidifier output.
- 10. The RVS Sensing terminal "L" should not be connected. This is used internally to sense defrost operation.
- 11. If thermostat has internal control of heat pump balance point, DO NOT SELECT the "FURNACE INTERFACE" or "BALANCE POINT" option on the two-speed heat pump control board. Refer to thermostat instructions.
- 12. Thermostat signals may vary. Consult thermostat installation instructions for more information.

#### VENTING

The furnace shall be connected to a listed factory built chimney or vent, or a clay-tile lined masonry or concrete chimney. Venting into an unlined masonry chimney or concrete chimney is prohibited.

When an existing Category I furnace is removed or replaced, the original venting system may no longer be sized to properly vent the attached appliances. An improperly sized Category I venting system could cause the formation of condensate in the furnace and vent, leakage of condensate and combustion products, and spillage of combustion products into the living space.

Vent system or vent connectors may need to be resized. Vent systems or vent connectors, must be sized to approach minimum size as determined using appropriate table found in the NFGC.

#### **GENERAL VENTING REQUIREMENTS**

Follow all safety codes for proper vent sizing and installation requirements, including local building codes, the current edition of National Fuel Gas Code ANSI Z223.1/NFPA 54 (NFGC), Parts 12 and 13, the local building codes, and furnace and vent manufacturers' instructions.

These furnaces are design-certified as Category I furnaces in accordance with current edition of ANSI Z21.47/CSA 2.3 and operate with a non-positive vent static pressure to minimize the potential for vent gas leakage. Category I furnaces operate with a flue loss not less than 17 percent to minimize the potential for condensation in the venting system. These furnaces are approved for common venting and multistory venting with other fan assisted or draft hood equipped appliances in accordance with the NFGC, the local building codes, and furnace and vent manufacturers' instructions.

The following information and warning must be considered in addition to the requirements defined in the NFGC.

- 1. If a vent (common or dedicated) becomes blocked, the furnace will be shut off by the draft safeguard switch located on the vent elbow.
- Do not vent this Category I furnace into a single-wall dedicated or common vent. The dedicated or common vent is considered to be the vertical portion of the vent system that terminates outdoors.
- Vent connectors serving Category I furnaces shall not be connected into any portion of a mechanical draft system operating under positive pressure.
- 4. Do not vent this appliance with any solid fuel burning appliance.
- 5. Category I furnaces must be vented vertically or nearly vertically unless equipped with a listed power venter.
- 6. Do not vent this appliance into an unlined masonry chimney. (Refer to Chimney Inspection Chart, Fig. 30).

#### CHIMNEY INSPECTION CHART

For additional requirements refer to the National Fuel Gas Code NFPA 54/ANSI Z223.1 and ANSI/NFPA 211 Chimneys, Fireplaces, Vents, and Solid Fuel Burning Appliances



Fig. 30 – Chimney Inspection Chart

A10133

#### MASONRY CHIMNEY REQUIREMENTS

**NOTE:** These furnaces are CSA design-certified for use in exterior tile-lined masonry chimneys with a factory accessory Chimney Adapter Kit. Refer to the furnace rating plate for correct kit usage. The Chimney Adapter Kits are for use with ONLY furnaces having a Chimney Adapter Kit numbers marked on the furnace rating plate.

If a clay tile-lined masonry chimney is being used and it is exposed to the outdoors below the roof line, relining might be required. Chimneys shall conform to the Standard for Chimneys, Fireplaces, Vents, and Solid Fuel Burning Appliances current edition of ANSI/NFPA 211 and must be in good condition. 58SB0A/58SB1A: Installation, Start-Up, Operating and Service and Maintenance Instructions

**U.S.A.**— Refer to Sections 13.1.8 and 13.2.20 of the current edition of NFGC NFPA54/ANSI Z223.1 or the authority having jurisdiction to determine whether relining is required. If relining is required, use a properly sized listed metal liner, Type-B vent, or a listed alternative venting design.

**NOTE:** See the current edition of NFPA54/ANSI Z223.1, 13.1.8 and 13.2.20 regarding alternative venting design and the Exception, which cover installations such as the Chimney Adapter Kits, which are listed for use with these furnaces. See Product Data Sheet for accessory listing.

## WARNING

#### CARBON MONOXIDE POISONING HAZARD

Failure to follow the steps outlined below for each appliance connected to the venting system being placed into operation could result in carbon monoxide poisoning or death.

The following steps shall be followed for each appliance connected to the venting system being placed into operation, while all other appliances connected to the venting system are not in operation:

1.Seal any unused openings in venting system.

2.Inspect the venting system for proper size and horizontal pitch, as required in the current edition of National Fuel Gas Code, ANSI Z223.1/NFPA 54 and these instructions. Determine that there is no blockage or restriction, leakage, corrosion and other deficiencies, which could cause an unsafe condition.

3.As far as practical, close all building doors and windows and all doors between the space in which the appliance(s) connected to the venting system are located and other spaces of the building.

4.Close fireplace dampers.

5.Turn on clothes dryers and any appliance not connected to the venting system. Turn on any exhaust fans, such as range hoods and bathroom exhausts, so they are operating at maximum speed. Do not operate a summer exhaust fan.

6.Follow the lighting instructions. Place the appliance being inspected into operation. Adjust the thermostat so appliance is operating continuously.

7.Test for spillage from draft hood equipped appliances at the draft hood relief opening after 5 minutes of main burner operation. Use the flame of a match or candle.

8.If improper venting is observed during any of the above tests, the venting system must be corrected in accordance with the current edition of National Fuel Gas Code, ANSI Z223.1/NFPA 54.

9.After it has been determined that each appliance connected to the venting system properly vents when tested as outlined above, return doors, windows, exhaust fans, fireplace dampers and any other gas-fired burning appliance to their previous conditions of use.

The Chimney Adapter Kit is listed alternative venting system for these furnaces. See the kit instructions for complete details.

This furnace is permitted to be vented into a clay tile-lined masonry chimney that is exposed to the outdoors below the roof line, provided:

- 1. Vent connector is Type-B double-wall, and
- 2. This furnace is common vented with at least 1 draft hood equipped appliance, and
- 3. The combined appliance input rating is less than the maximum capacity given in Table 8, and
- 4. The input rating of each space heating appliance is greater than the minimum input rating given in Table 9 for the local 99% Winter Design Temperature. Chimneys having internal areas greater than 38 square inches require furnace input ratings greater than the input ratings of these furnaces. See footnote at bottom of Table 9, and
- 5. The authority having jurisdiction approves.

Table 8 – Combined Appliance Maximum Input Rating in Thousands of Btuh per Hour

VENT HEIGHT FT. (M)	INTERNAL AREA OF CHIMNEY IN <sup>2</sup> (MM <sup>2</sup> )								
<b>r i</b> . (19 <b>i</b> )	12 (7741)	19 (12258)	28 (18064)	38 (24516)					
6 (1.8)	74	119	178	257					
8 (2.4)	80	130	193	279					
10 (3.0)	84	138	207	299					
15 (4.5)	NR	152	233	334					
20 (6.0)	NR	NR	250	368					
30 (9.1)	NR	NR	NR	404					

If all of these conditions cannot be met, an alternative venting design shall be used, such as the listed chimney adapter kit with these furnaces, which are listed for use with the kit, a listed chimney-lining system, or a Type-B common vent.

 Table 9 – Minimum Allowable Input Rating of Space-Heating

 Appliance in Thousands of Btuh per Hour

VENT HEIGHT	IN	INTERNAL AREA OF CHIMNEY IN <sup>2</sup> . (MM <sup>2</sup> )											
FT (M)	12 (7741)	19 (12258)	28 (18064)	38 (24516)									
Local 99% Winter Design Temperature: 17 to 26°F (-8 to -3°C)													
6 (1.8)	0	55	99	141									
8 (2.4)	52	74	111	154									
10 (3.0)	NR	90	125	169									
15 (4.6)	NR	NR	167	212									
20 (6.1)	NR	NR	212	258									
30 (9.1)	NR	NR	NR	362									
Te	Local 99% V mperature: 5 to	Vinter Design 16°F* (-15 to -	9°C)										
6 (1.8)	NR	78	121	166									
8 (2.4)	NR	94	135	182									
10 (3.0)	NR	111	149	198									
15 (4.6)	NR	NR	193	247									
20 (6.1)	NR	NR	NR	293									
30 (9.1)	NR	NR	NR	377									
Ten	Local 99% V perature: -10 to	Vinter Design o 4°F* (-23 to -	16°C)										
6 (1.8)	NR	NR	145	196									
8 (2.4)	NR	NR	159	213									
10 (3.0)	NR	NR	175	231									
15 (4.6)	NR	NR	NR	283									
20 (6.1)	NR	NR	NR	333									
30 (9.1)	NR	NR	NR	NR									
Te	Local 99% V emperature: -11°	Vinter Design °F (-24°C) or lo	ower	1									
	ecommended for												

\*The 99.6% heating db temperatures found in the 1997 or 2001 ASHRAE Fundamentals Handbook, Climatic Design Information chapter, Table 1A (United States) or the 2005 ASHRAE Fundamentals handbook, Climatic Design Information chapter, and the CD-ROM included with the 2005 ASHRAE Fundamentals Handbook.

Inspections before the sale and at the time of installation will determine the acceptability of the chimney or the need for repair and/or (re)lining. Refer to the Fig. 30 to perform a chimney inspection. If the inspection of a previously used tile-lined chimney:

- a. Shows signs of vent gas condensation, the chimney should be relined in accordance with local codes and the authority having jurisdiction. The chimney should be relined with a listed metal liner, Type-B vent, or a listed chimney adapter kit shall be used to reduce condensation. If a condensate drain is required by local code, refer to the current edition of NFGC NFPA54/ANSI Z223.1, Section 12.10 for additional information on condensate drains.
- b. Indicates the chimney exceeds the maximum permissible size in the tables, the chimney should be rebuilt or relined to conform to the requirements of the equipment being installed and the authority having jurisdiction.

A chimney without a clay tile liner, which is otherwise in good condition, shall be rebuilt to conform to current edition of ANSI/NFPA 211 or be lined with a UL listed metal liner or UL listed Type-B vent. Relining with a listed metal liner or Type-B vent is considered to be a vent-in-a-chase.

If a metal liner or Type-B vent is used to line a chimney, no other appliance shall be vented into the annular space between the chimney and the metal liner.

#### EXTERIOR MASONRY CHIMNEY FAN + NAT INSTALLATIONS WITH TYPE-B DOUBLE-WALL VENT CONNECTORS <sup>©</sup>NFPA & AGA

#### APPLIANCE APPLICATION REQUIREMENTS

Appliance operation has a significant impact on the performance of the venting system. If the appliances are sized, installed, adjusted, and operated properly, the venting system and/or the appliances should not suffer from condensation and corrosion. The venting system and all appliances shall be installed in accordance with applicable listings, standards, and codes.

The furnace should be sized to provide 100 percent of the design heating load requirement plus any margin that occurs because of furnace model size capacity increments. Heating load estimates can be made using approved methods available from Air Conditioning Contractors of America (Manual J); American Society of Heating, Refrigerating, and Air-Conditioning Engineers; or other approved engineering methods. Excessive oversizing of the furnace could cause the furnace and/or vent to fail prematurely. When a metal vent or metal liner is used, the vent must be in good condition and be installed in accordance with the vent manufacturer's instructions.

To prevent condensation in the furnace and vent system, the following precautions must be observed:

- 1. The return-air temperature must be at least 60°F (16°C)db except for brief periods of time during warm-up from setback at no lower than 55°F (13°C) db or during initial start-up from a standby condition.
- 2. Adjust the gas input rate per the installation instructions. Low gas input rate causes low vent gas temperatures, causing condensation and corrosion in the furnace and/or venting system. Derating is permitted only for altitudes above 2000 ft. (610 M).
- 3. Adjust the air temperature rise to the midpoint of the rise range or slightly above. Low air temperature rise can cause low vent gas temperature and potential for condensation problems.
- 4. Set the thermostat heat anticipator or cycle rate to reduce short cycling.

## **CAUTION**

#### **BURN HAZARD**

Failure to follow this caution may cause personal injury.

Hot vent pipe is within reach of small children when installed in downflow position. See the following instruction.

Air for combustion must not be contaminated by halogen compounds which include chlorides, fluorides, bromides, and iodides. These compounds are found in many common home products such as detergent, paint, glue, aerosol spray, bleach, cleaning solvent, salt, and air freshener, and can cause corrosion of furnaces and vents. Avoid using such products in the combustion-air supply. Furnace use during construction of the building could cause the furnace to be exposed to halogen compounds, causing premature failure of the furnace or venting system due to corrosion.

Vent dampers on any appliance connected to the common vent can cause condensation and corrosion in the venting system. Do not use vent dampers on appliances common vented with this furnace.

#### ADDITIONAL VENTING REQUIREMENTS

A 4" (101 mm) round vent elbow is supplied with the furnace. A 5-inch (127 mm) or 6- inch (152 mm) vent connector may be required for some model furnaces. A field-supplied 4-inch-to-5-inch (101 - 127 mm) or 4-inch-to-6-inch (101 - 152 mm) sheet metal increaser fitting is required when 5-inch (127 mm) or 6-inch (152 mm) vent connector is used. See Fig. 31 - Fig. 43 Venting Orientation for approved vent configurations.

**NOTE:** Vent connector length for connector sizing starts at furnace vent elbow. The 4-inch vent elbow is shipped for upflow configuration and may be rotated for other positions. Remove the 3 screws that secure vent elbow to furnace, rotate furnace vent elbow to position desired, reinstall screws. The factory-supplied vent elbow does NOT count as part of the number of vent connector elbows.

## A CAUTION

#### **CUT HAZARD**

Failure to follow this caution may result in personal injury.

Sheet metal parts may have sharp edges or burrs. Use care and wear appropriate protective clothing, safety glasses and gloves when handling parts and servicing furnaces.

The vent connector can exit the furnace through one of 5 locations on the casing.

1. Attach the single wall vent connector to the furnace vent elbow, and fasten the vent connector to the vent elbow with at least two field-supplied, corrosion-resistant, sheet metal screws located 180° apart.

**NOTE:** An accessory flue extension is available to extend from the furnace elbow to outside the furnace casing. See Product Data Sheet for accessory listing. If flue extension is used, fasten the flue extension to the vent elbow with at least two field-supplied, corrosion-resistant, sheet metal screws located 180° apart. Fasten the vent connector to the flue extension with at least two field-supplied, corrosion resistant sheet metal screws located 180° apart.

- 2. Vent the furnace with the appropriate connector (see Fig. 31 Fig. 43).
- 3. Determine the correct location of the knockout to be removed.
- 4. Use a hammer and screwdriver to strike a sharp blow between the tie points and work the slug back and forth until the slug breaks free.

58SB0A/58SB1A: Installation, Start-Up, Operating and Service and Maintenance Instructions

An accessory Vent Guard Kit is REQUIRED for downflow applications where the vent exits through the lower portion of the furnace casing. See Fig. 34 and Product Data Sheet for accessory listing. Refer to the Vent Guard Kit Instructions for complete details.

The horizontal portion of the venting system shall slope upwards not less than 1/4-in. per linear ft. (21 mm/M) from the furnace to the vent and shall be rigidly supported every 5 ft. (2 M) or less with metal hangers or straps to ensure there is no movement after installation.

#### SIDEWALL VENTING

This furnace is not approved for direct sidewall horizontal venting.

Per section 12.4.3 of the current edition of NFPA54/ANSI Z223.1, any listed mechanical venter may be used, when approved by the authority having jurisdiction.

Select the listed mechanical venter to match the Btuh input of the furnace being vented. Follow all manufacturer's installation requirements for venting and termination included with the listed mechanical venter.

Caution!! For the following applications, use the minimum vertical vent heights as specified below. For all other applications, follow exclusively the National Fuel Gas Code.

FURNACE ORIENTATION	VENT ORIENTATION	FURNACE INPUT (BTUH/HR)	MIN. VENT DIAMETER IN. (mm)*	MIN. VERTICAL VENT HEIGHT FT. (M)**
Downflow	Vent elbow left, then up Fig. 34	154,000 132,000 110,000	5 (127)	12 (3.6)
Horizontal Left	Vent elbow right, then up Fig. 43	154,000 132,000	5 (127)	7 (2.1)
Horizontal Left	Vent Elbow up Fig. 41	154,000 132,000	5 (127)	7 (2.1)
Horizontal Left	Vent elbow right Fig. 40	154,000	5 (127)	7 (2.1)
Downflow	Vent elbow up then left Fig. 31	110,000	5 (127)	10 (3.0)
Downflow	Vent elbow up, then right Fig. 37	110,000	5 (127)	10 (3.0)

NOTE: All vent configurations must also meet National Fuel Gas Code venting requirements NFGC

\*4 in. (102 mm) inside casing or vent guard

\*\*Including 4 in. (102 mm) vent section(s)



SEE NOTES:1,2,3,4,5,7,8,9 on the page following these figures

Fig. 31 – Downflow Application-Vent Elbow Up then Left  $^{\rm A03210}$ 



on the pages following these figures

Fig. 32 - Upflow Application-Vent Elbow Right

A03209



Fig. 33 – Downflow Application-Vent Elbow Up



SEE NOTES: 1,2,4,5,6,7,8,9 on the page following these figures

Fig. 34 – Downflow Application-Vent Elbow Left then Up







SEE NOTES: 1,2,4,7,8,9 on the page following these figures

Fig. 36 – Upflow Application-Vent Elbow Up

A03208



SEE NOTES:1,2,3,4,5,7,8,9 on the page following these figures.





SEE NOTES: 1,2,4,7,8,9 on the page following these figures

Fig. 38 – Horizontal Right Application-Vent Elbow Right A03218



SEE NOTES: 1,2,4,5,7,8,9

Fig. 39 – Horizontal Right Application-Vent Elbow Left



SEE NOTES: 1,2,4,5,7,8,9 on the page following these figures

#### Fig. 40 – Horizontal Left Application-Vent Elbow Right



SEE NOTES: 1,2,4,5,7,8,9 on the page following these figures





SEE NOTES: 1,2,4,5,7,8,9 on the page following these figures







SEE NOTES: 1,2,4,5,7,8,9 on the page following these figures

A03214

#### Fig. 43 – Horizontal Left Application-Vent Elbow Right then Up

#### VENTING NOTES FOR Fig. 31 - Fig. 43

- 1. For common vent, vent connector sizing and vent material: United States-use the NFGC.
- 2. Immediately increase to 5-inch (127 mm) or 6-inch (152 mm) vent connector outside furnace casing when 5-inch (127 mm) vent connector is required, refer to Note 1 above.
- 3. Side outlet vent for upflow and downflow installations must use Type B vent immediately after exiting the furnace, except when factory-authorized, Downflow Vent Guard Kit, is used in the downflow position. See Product Data Sheet for accessory listing.
- 4. Type-B vent where required, refer to Note 1 above.
- 5. Four-inch single-wall (26 ga. min.) vent must be used inside furnace casing and when the Downflow Vent Guard Kit is used external to the furnace. See Product Data Sheet for accessory listing.
- 6. Factory-authorized accessory Downflow Vent Guard Kit required in downflow installations with lower vent configuration. See Product Data Sheet for accessory listing.
- 7. Chimney Adapter Kit may be required for exterior masonry chimney applications. Refer to Chimney Adapter Kit for sizing and complete application details. See Product Data Sheet for accessory listing.
- 8. Secure vent connector to furnace elbow with (2) corrosion-resistant sheet metal screws, spaced approximately 180° apart.
- Secure all other single wall vent connector joints with (3) corrosion resistant screws spaced approximately 120° apart. Secure Type-B vent connectors per vent connector manufacturer's recommendations.

## START-UP, ADJUSTMENT, AND SAFETY CHECK

#### GENERAL

WARNING

#### FIRE HAZARD

Failure to follow this warning could result in personal injury, death and/or property damage.

This furnace is equipped with manual reset limit switches in the gas control area. The switches open and shut off power to the gas valve if a flame rollout or overheating condition occurs in the gas control area. DO NOT bypass the switches. Correct inadequate combustion air supply problem before resetting the switches. 58SB0A/58SB1A: Installation, Start–Up, Operating and Service and Maintenance Instructions

- 1. Maintain 115-v wiring and ground. Improper polarity will result in rapid flashing LED and no furnace operation.
- 2. Make thermostat wire connections at the 24-v terminal block on the furnace control. Failure to make proper connections will result in improper operation (see Fig. 24).
- 3. Gas supply pressure to the furnace must be greater than 4.5-In. W.C. (0.16 psig) but not exceed 14-In. W.C. (0.5 psig).
- 4. Check all manual-reset switches for continuity.
- 5. Install blower compartment door. Door must be in place to operate furnace.
- 6. Replace outer door.

## CAUTION

#### **CUT HAZARD**

Failure to follow this caution may result in personal injury.

Sheet metal parts may have sharp edges or burrs. Use care and wear appropriate protective clothing, safety glasses and gloves when handling parts and servicing furnaces.

#### Start-Up Procedures



#### FIRE AND EXPLOSION HAZARD

Failure to follow this warning could cause personal injury, death and/or property damage.

Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections.

- 1. Purge gas lines after all connections have been made.
- 2. Check gas lines for leaks.

## WARNING

#### ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury, or death. Blower access door switch opens 115-v power to control. No component operation can occur unless switch is closed. Caution must be taken when manually closing this switch for service purposes.

#### 3. To Begin Component Self-Test:

Remove blower access door. Disconnect the thermostat R lead from the furnace control board. Manually close the blower door switch closed. Short (jumper) the COM-24v terminal on control to the TEST/TWIN 3/16-inch quick connect terminal on control until LED goes out (approximately 2 sec). Gas valve and humidifier will not be turned on (see Fig. 28).

**NOTE:** The furnace control allows all components, except the gas valve, to be run for short period of time. This feature helps diagnose a system problem in case of a component failure. Component test feature will not operate if any thermostat signal is present at the control.

- 4. Component test sequence is as follows (see service label attached to furnace or Fig. 44):
  - a. LED will display previous status code 4 times.
  - b. Inducer motor starts and continues to run until Step f of component test sequence.
  - c. Hot surface igniter is energized for 15 sec., then off.
  - d. Blower motor operates on HEAT speed for 10 sec.
  - e. Blower motor operates on COOL speed for 10 sec.
  - f. Inducer motor stops.
  - g. Reconnect R lead to furnace control board, release blower door switch and re-install blower door.
- 5. Operate furnace per instruction on door.
- 6. Verify furnace shut down by lowering thermostat setting below room temperature.
- 7. Verify furnace restarts by raising thermostat setting above room temperature.



Fig. 44 – Service Label

58SB0A/58SB1A: Installation, Start–Up, Operating and Service and Maintenance Instructions

#### Adjustments

Furnace gas input rate on rating plate is for installations at altitudes up to 2000 ft. (610 M). Furnace input rate must be within  $\pm$ -2 percent of furnace rating plate input.

## WARNING

#### FIRE HAZARD

Failure to follow this warning could result in injury, death and/or property damage.

DO NOT bottom out gas valve regulator adjusting screw. This can result in unregulated manifold pressure and result in excess overfire and heat exchanger failures.

1. Determine the correct gas input rate.

The input rating for altitudes above 2,000 ft. (610 M) must be reduced by 4 percent for each 1,000 ft. (305 M) above sea level. For installations below 2000 ft. (610 M), refer to the unit rating plate. For installations above 2000 ft. (610 M), multiply the input on the rating plate by the de-rate multiplier in Table 10 for the correct input rate.

## **CAUTION**

#### FURNACE DAMAGE HAZARD

Failure to follow this caution may result in reduced furnace life. DO NOT redrill orifices. Improper drilling (burrs, out-of-round holes, etc.) can cause excessive burner noise and misdirection of burner flames. This can result in flame impingement of heat exchangers, causing failures (see Fig. 45).



Fig. 45 – Orifice Hole Table 10 – Altitude Derate Multiplier for U.S.A.

ALTITUDE (FT. / M)	PERCENT OF DERATE	DERATE MULTIPLIER FACTOR*
0–2000 (0-610)	0	1.00
2001–3000 (610-914)	8-12	0.90
3001-4000 (914-1219)	12–16	0.86
4001–5000 (1219-1524)	16–20	0.82
5001-6000 (1524-1829)	20-24	0.78
6001-7000 (1829-2134)	24–28	0.74
7001-8000 (2134-2438)	28-32	0.70
8001–9000 (2438-2743)	32–36	0.66
9001–10,000 (2743-3048)	36–40	0.62

- Determine the correct orifice and manifold pressure adjustment. There are two different orifice and manifold adjustment tables. All models in all positions, except Low NOx models in downflow or horizontal positions, use Table 11 (22,000 Btuh/Burner). Low NOx models in the downflow or horizontal positions must use Table 12 (21,000 Btuh/Burner). See input listed on rating plate.
  - a. Obtain average yearly gas heat value (at installed altitude) from local gas supplier.
  - b. Obtain average yearly gas specific gravity from local gas supplier.
  - c. Find installation altitude in Table 11 or Table 12.
  - d. Find closest natural gas heat value and specific gravity in Table 11 or Table 12.
  - e. Follow heat value and specific gravity lines to point of intersection to find orifice size and manifold pressure settings for proper operation.
  - f. Check and verify burner orifice size in furnace. NEVER ASSUME ORIFICE SIZE. ALWAYS CHECK AND VERIFY.

**NOTE:** If orifice hole appears damaged or it is suspected to have been redrilled, check orifice hole with a numbered drill bit of correct size. Never redrill an orifice. A burr-free and squarely aligned orifice hole is essential for proper flame characteristics.

g. Replace orifice with correct size if required by Table 10, Table 11, Table 12 and Table 13. Use only factory-supplied orifices. See EXAMPLE 1.

XAMPLE 1: (0 to 2000 ft. (0 to 610 M) altitude)
or 22,000 Btuh per burner application use Table 11.
eating value = 1000 Btuh/cu ft.
pecific gravity $= 0.62$
herefore: Orifice No. 43*
lanifold pressure: 3.7-In. W.C.
Furnace is shipped with No. 43 orifices.
this example all main burner orifices are the correct
ze and do not need to be changed to obtain proper input ra

Adjust manifold pressure to obtain correct input rate.
 a. Turn gas valve ON/OFF switch to OFF.



#### ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death. Disconnect 115-v electrical power and install lockout tag before changing speed tap.

- b. Remove manifold pressure tap plug from gas valve (see Fig. 21).
- c. Connect a water column manometer or similar device to manifold pressure tap.
- d. Turn gas valve ON/OFF switch to ON.
- e. Manually close blower door switch.
- f. Set thermostat to call for heat.
- g. Remove regulator seal cap and turn regulator adjusting screw counterclockwise (out) to decrease input rate of clockwise (in) to increase input rate.

**NOTE:** DO NOT set manifold pressure less than 3.2-In. W.C. or more than 3.8-In. W.C. for natural gas at sea level. If manifold pressure is outside this range, change main burner orifices. Refer to Table 10, Table 11, Table 12 and Table 13.

h. Install regulator seal cap.

 Leave manometer or similar device connected and proceed to Step 4.

\* Derate multiplier factors are based on midpoint altitude for altitude range.

#### Table 11 – Orifice Size\* and Manifold Pressure (In. W.C.) for Gas Input Rate

(TABULATED I	DATA BASED ON	22,000 BTUH PER BURNER, DERATED 4%/1000 FT (305M) ABOVE SEA LEVEL)
ALTITUDE	AVG GAS	SPECIFIC GRAVITY OF NATURAL GAS

AT ALITITUDE (Btuck II)         Orifice No.         Manifold Pressure No.         Orifice Pressure No.         Manifold Pressure No.         Manifold Pressure No.         Manifold Pressure No.	1 1	ALIIIUDE	AVG. GAS				IC GRAVITY				
ft (m)         (Btu/cu ft)         No.         Pressure		RANGE	HEAT VALUE								
0         900         42         3.5         42         3.6         42         3.7         41         33           0         925         43         3.6         42         3.3         42         3.4         42         3.5         42         3.4           0         975         43         3.6         43         3.6         43         3.6         42         3.3         42         3.4         42         3.4         42         3.4         42         3.4         42         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.5         43         3.2         43         3.3         3.4         3.4         3.5         43         3.6         43         3.7         43         3.3         44         3.5         43         3.6         43         3.7         43         3.3         3.3         3.3         3.3         3.3         3.3         3.3         3.3         3.3         3.3         3.3											Manifold
0         925         42         3.3         42         3.4         42         3.5         42         3.6           975         43         3.6         43         3.6         43         3.6         42         3.4         42         3.4         42         3.4         42         3.4         42         3.4         42         3.4         42         3.4         42         3.4         43         3.5         43         3.6         43         3.5         43         3.6         43         3.5         43         3.4         43         3.5         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.3         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.3         43         3.4         43         3.5         43         3.3         43         3.4         43         3.5         43         3.3         43         3.4         43         3.3         43         3.3         43         3.3         43		ft (m)									Pressure
(i)         950         43         3.8         42         3.3         42         3.4         42         3.4           y         975         43         3.6         43         3.8         42         3.2         42         3.4         42         3.2         42         3.4         3.5         43         3.6         43         3.6         43         3.6         43         3.7         43         3.4         3.7         43         3.4         3.4         3.4         3.4         3.4         3.4         3.4         3.4         3.4         3.4         3.4         3.4         3.4         3.4         3.4         3.4         3.4         3.4         3.4         3.3         44         3.5         43         3.2         43         3.3           (610)         1075         44         3.3         44         3.5         43         3.6         42         3.6         42         3.3         42         3.3         42         3.4         3.4         3.3         3.3         43         3.4         3.3         3.4         3.3         3.4         3.3         3.4         3.3         3.4         3.3         3.4         3.3         3.3											3.5
Y         N         975         43         3.6         43         3.8         42         3.2         42         3.2           1000         43         3.5         43         3.6         43         3.7         43         3.3           2000         1055         44         3.6         43         3.2         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.2         43         3.3         43         3.4         43         3.2         43         3.2         43         3.2         43         3.2         43         3.2         43         3.3         43         3.4         43         3.2         43         3.3         43         3.4         43         3.5         43         3.6         43         3.7         43         3.3         43         3.4         43         3.5         43         3.6         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43											3.7
vg n         to         1000         43 (1025)         43 (44)         3.5 (3.3)         43 (43)         3.6 (43)         43 (44)         3.7 (43)         43 (44)         3.6 (43)           2000         10050         44 (44)         3.6 (610)         1075         44 (44)         3.6 (43)         43 (44)         3.2 (43)         43 (44)         3.2 (43)         43 (44)         3.2 (42)         43 (44)         3.2 (42)         43 (44)         3.6 (42)         3.6 (43)         43 (42)         3.6 (43)         43 (42)         3.6 (43)         43 (42)         3.6 (43)         43 (42)         3.6 (43)         43 (42)         3.6 (43)         3.7 (43)         43 (43)         3.7 (43)         43 (42)         3.7 (43)         43 (43)         43 (43)         3.7 (43)         43 (43)         3.7 (43)         43 (43)         3.7 (43)         43 (43)         3.7 (43)         43 (43)         43 (43)         3.7 (43)         43 (43)<		(0)									3.5
2000         1050         44         3.5         43         3.4         43         3.2         43         3.4         43         3.2         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.2         43         3.3         43         3.4         44         3.5         43         3.2         43         3.3           1100         44         3.3         44         3.5         43         3.7         43         3.3         43         3.4         42         3.3         42         3.4         42         3.3         43         3.4         42         3.3         43         3.4         42         3.3         43         3.4         43         3.7         43         3.4         3.3         43         3.4         43         3.5         43         3.0         43         3.1         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         43         3.5         43         3.0         43         3.1         43         3.3	خ										3.3
1020         1020         40         3.0         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         44         3.5         43         3.4         43         3.4         44         3.5         43         3.4         43         3.4         44         3.5         43         3.3         43         3.4         42         3.5         43         3.7         43         3.4         42         3.5         43         3.7         43         3.4         42         3.3         43         3.4         42         3.3         43         3.4         42         3.3         43         3.4         43         3.5         43         3.6         43         3.6         43         3.6         43         3.3         43         3.4         3.3         43         3.4         3.3         3.3         3.3         3.3         3.3         3.3         3.3         3.3         3.3         3.3         3.3         3.3         3.3         3.3         3.3         3.3	S.	to									3.8
(610)         1075         44         3.4         44         3.5         43         3.2         43         3.3           y         1100         44         3.3         44         3.4         44         3.5         43         3.2         43         3.3           2001 (611)         850         42         3.2         42         3.3         42         3.4         42         3.4         42         3.4         42         3.3         43         3.2         42         3.3         43         3.4         43         3.5         43         3.5         43         3.5         43         3.5         43         3.5         43         3.6         43         3.7         43         3.4         3.3         43         3.4         3.3         43         3.4         3.5         43         3.6         43         3.6         43         3.6         43         3.6         43         3.6         43         3.6         43         3.6         43         3.6         43         3.2         42         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.	1 2										3.6
Y         1100         44         3.3         44         3.4         44         3.5         43         3.2           2001 (611)         800         42         3.4         42         3.5         42         3.6         42         3.3           3000 (914)         875         43         3.7         43         3.8         42         3.2         42         3.2           950         43         3.7         43         3.6         43         3.7         43         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.4         3.3         3.3         43         3.4         3.3         3.3         43         3.4         3.3         3.4         3.3         3.4         3.3         3.4         3.3         3.4         3.3         3.4         3.3         3.4											3.5
Y         800         42         3.4         42         3.5         42         3.6         42         3.3           2001 (611)         850         43         3.7         43         3.8         42         3.4         42         3.4         42         3.4         42         3.4         42         3.4         42         3.4         42         3.4         42         3.4         42         3.4         42         3.4         42         3.4         42         3.4         42         3.4         42         3.4         42         3.4         42         3.4         42         3.4         42         3.4         43         3.4         43         3.5         43         3.4         43         3.5         43         3.4         43         3.5         43         3.4         43         3.6         43         3.6         43         3.6         43         3.6         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4		(610)									3.3
Y         825         42         3.2         42         3.3         42         3.4         42         3.3           10         b         850         43         3.7         43         3.6         43         3.7         43         3.6         43         3.7         43         3.6         43         3.7         43         3.6         43         3.7         43         3.6         43         3.7         43         3.6         43         3.7         43         3.6         43         3.7         43         3.6         43         3.7         43         3.7         43         3.7         43         3.7         43         3.7         43         3.7         43         3.7         43         3.7         43         3.7         43         3.7         43         3.7         43         3.7         43         3.7         43         3.7         43         3.7         43         3.7         43         3.7         43         3.7         43         3.4         3.7         43         3.4         3.7         43         3.4         3.7         43         3.4         3.7         43         3.4         3.7         43         3.4											3.2
Vin         2001 (611) to         850 3000 (914)         43 975         43 43         3.7         43 43         3.8 43         42 3.6         43 43         3.7         43 43         3.8 43           y         900         43         3.3         43         3.4         43         3.7         43         3.3           y         950         43         2.9         43         3.0         43         3.3         43         3.3           y         950         43         2.9         43         3.0         43         3.1         43         3.4           y         975         42         3.2         42         3.3         42         3.4         42         3.3           y         1000         43         3.6         43         3.8         42         3.2         42         3.3           y         915         825         43         3.4         43         3.5         43         3.4         43         3.4         3.4         3.3         3.4         3.3         3.4         3.3         3.4         3.3         3.4         3.3         3.4         3.4         3.4         3.3         3.4         3.3         3.4											3.7
Y         200 <sup>+</sup> (b1)         875         43         3.5         43         3.6         43         3.7         43         3.4           3000 (914)         900         43         3.3         43         3.4         43         3.5         43         3.4           950         43         2.9         43         3.0         43         3.1         43         3.4         3.3         43         3.4           975         43         2.8         43         2.9         43         3.0         43         3.1         43         3.4         3.5         43         3.4         42         3.4         42         3.4         42         3.4         42         3.4         42         3.4         43         3.4         3.5         43         3.4         43         3.4         43         3.4         43         3.4         43         3.4         3.3         3.4         3.3         3.4         3.3         3.4         3.3         3.4         3.3         3.3         3.3         3.3         3.3         3.3         3.3         3.3         3.3         3.3         3.3         3.3         3.3         3.3         3.3         3.3         3.3											3.5
vin         10         875         43         3.5         443         3.6         43         3.7         43         3.8           3000 (914)         900         43         3.3         43         3.4         3.3         43         3.4         3.5         43         3.3         43         3.4         3.5         43         3.3         43         3.4         3.5         43         3.3         43         3.4         3.5         43         3.3         43         3.4         3.5         43         3.1         43         3.5         43         3.1         43         3.5         43         3.1         43         3.5         43         3.4         42         3.2         42         3.3         43         3.4         42         3.4         42         3.4         42         3.4         42         3.4         42         3.4         43         3.4		2001 (611)		43	3.7	43	3.8	42	3.2	42	3.3
Y         925         43         3.1         43         3.2         43         3.3         43         3.4           975         43         2.8         43         3.0         43         3.0         43         3.1         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.4         42         3.3         42         3.4         42         3.3         43         3.4         43         3.4         43         3.3         43         3.4         43         3.3         43         3.4         43         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         3.3         43	∢										3.8
Y         925         43         3.1         43         3.2         43         3.3         43         3.4           975         43         2.8         43         3.0         43         3.0         43         3.1         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.3         43         3.4         42         3.3         42         3.4         42         3.3         43         3.4         43         3.4         43         3.3         43         3.4         43         3.3         43         3.4         43         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         3.3         43	S.I				3.3	43		43	3.5	43	3.6
Y         975         43         2.8         43         2.9         43         3.0         43         2.7           3001         800         43         2.6         43         2.7         43         2.8         43         2.4           3001         800         43         3.6         43         3.8         42         3.3         42         3.4         42         3.3           (915)         825         43         3.4         43         3.5         43         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43         3.3         43         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43         3.4         3.3         43 </td <td>  <b>-</b>  </td> <td> </td> <td></td> <td></td> <td></td> <td>43</td> <td>3.2</td> <td>43</td> <td>3.3</td> <td>43</td> <td>3.4</td>	<b>-</b>					43	3.2	43	3.3	43	3.4
Y         1000         43         2.6         43         2.7         43         2.8         43         2.4           3001         800         43         3.2         42         3.3         42         3.4         42         3.4         42         3.4         42         3.4         42         3.4         42         3.4         42         3.4         42         3.4         42         3.4         42         3.4         43         3.6         43         3.6         43         3.7         43         3.4         3.4         3.4			950	43	2.9	43	3.0	43	3.1	43	3.2
3001         775         42         3.2         42         3.3         42         3.4         42         3.3           (915)         825         43         3.6         43         3.8         42         3.4         42         3.3           (915)         825         43         3.4         43         3.5         43         3.4         43         3.7         43         3.3           4000         900         43         2.9         43         3.0         43         3.1         43         3.4         43         3.4           (1219)         925         43         2.7         43         2.8         43         2.9         43         3.0         43         3.1         43         3.4         3.3         3.4         3.3         3.4         3.3         3.4         3.3         43         3.4         3.3         3.4         3.3         3.4         3.4         3.3         3.4         3.4         3.3         3.4         3.3         3.4         3.3         3.4         3.3         3.4         3.3         3.4         3.3         3.4         3.3         3.4         3.3         3.4         3.3         3.4         3.3			975	43	2.8	43	2.9	43	3.0	43	3.1
3001         800         43         3.6         43         3.8         42         3.2         42         3.3           (915)         825         43         3.4         43         3.5         43         3.7         43         3.1           to         850         43         3.2         42         3.3         43         3.4         3.3         43         3.7         43         3.1           4000         900         43         2.9         43         3.0         43         3.1         43         3.3         43         3.4         3.3           (1219)         925         43         2.7         43         2.8         43         3.2         42         3.3           (1220)         800         43         3.2         43         3.5         43         3.4         43         3.4         3.3         3.3         43         3.4         3.3         3.3         43         3.4         43         3.5         43         3.2         42         3.3         3.3         43         3.4         3.3         3.3         43         3.4         3.3         3.3         43         3.4         3.3         3.3			1000	43	2.6	43	2.7	43	2.8	43	2.9
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$			775	42	3.2	42	3.3	42	3.4	42	3.5
Y         Io         850         43         3.2         43         3.3         43         3.4         43         3.4           4000         900         43         2.9         43         3.1         43         3.1         43         3.4         43         3.4           4000         900         43         2.9         43         3.0         43         3.1         43         3.1         43         3.4         3.3           (1219)         925         43         2.7         43         2.8         43         2.9         43         3.4         2.8         2.8         2.4         2.2         43         3.4         2.8         2.4         2.8         2.8         2.4         2.2         2.4         2.2         2.4         2.2         2.4         2.2         2.4         2.8         2.4         2.8         43         3.6         43         3.4         43         3.4         3.4         3.4         3.4         3.3         3.4         3.3         3.4         3.4         3.3         3.4         3.4         3.3         3.4         3.4         3.3         3.4         3.4         3.2         4.3         3.2         4.3		3001	800	43	3.6	43	3.8	42	3.2	42	3.3
4000 (1219)         900 925         43 43         2.9 43         43 2.6         3.0 43         43 2.8         43 43         2.9 43         43 2.8         43 43         2.9 43         43 3.1         43 3.3         3.1 43         43 3.3         3.1 43         43 3.3         3.1 43         43 3.3         3.1 43         43 3.3         3.1 43         43 3.3         3.1 43         43 3.4         3.1 43         43 3.6         43 3.3         2.8 43         43 3.6         43 3.3         2.8 43         43 3.6         43 3.3         3.6 43         43 3.6         43 3.3         3.6 43         3.6 43         3.6 43         3.6 43         3.6 43         43 3.6         43 3.3         3.6 43         43 3.6         43 3.3         3.6 43         43 3.6         43 3.3         3.6 43         43 3.0         43 3.3         3.6 43         43 3.0         43 3.3         3.6 43         43 3.6         43 3.3         3.6 43         43 3.3         3.6 43         43 3.6         43 3.3         3.6 43         43 3.6         43 3.3         43 3.6         43 3		(915)	825	43	3.4	43	3.5	43	3.7	43	3.8
4000 (1219)         900 925         43 43         2.9 43         43 2.7         43 43         2.9 43         43 2.8         43 43         2.9 43         43 2.8         43 43         2.9 43         43 2.8         43 43         2.9 43         43 2.8         43 43         2.9 43         43 43         2.8         43 43         2.4         43 3.3         3.6         43 43         3.6         43 3.3         3.6         43	S.A	to	850	43	3.2	43	3.3	43	3.4	43	3.6
(1219)         925         43         2.7         43         2.8         43         2.9         43         3.4           950         43         2.6         43         2.7         43         2.8         43         2.9         43         2.4           4001         775         43         3.6         43         3.8         42         3.2         42         2.3           (1220)         800         43         3.2         43         3.3         43         3.4         43         3.4         3.3         43         3.4         43         3.4         3.4         3.4         3.3         43         3.4         43         3.4         3.3         43         3.4         43         3.4         3.4         3.3         3.4         3.3         43         3.4         43         3.2         43         3.2         43         3.2         43         3.2         43         3.2         43         3.2         43         3.2         43         3.0         43         3.2         43         3.2         43         3.2         43         3.2         43         3.2         43         3.2         43         3.2         43         3.2<	5		875	43	3.0	43	3.1	43	3.3	43	3.4
950         43         2.6         43         2.7         43         2.8         43         2.1           4001         750         43         3.6         43         3.8         42         3.2         42         3.3           (1220)         800         43         3.2         43         3.3         43         3.4         43         3.6         43         3.2         42         3.3           10         825         43         3.0         43         3.1         43         3.4         43         3.3           5000         875         43         2.8         43         2.9         43         3.0         43         3.2         43         3.2           (1524)         900         43         2.5         43         2.6         43         2.7         43         2.6         43         2.7         43         2.4         3         2.5         43         2.6         43         3.4         3.3         43         3.4         3.3         3.4         3.3         3.4         3.3         3.4         3.3         3.4         3.3         3.4         3.3         3.4         3.3         3.4         3.3         3.		4000	900	43	2.9	43	3.0	43	3.1	43	3.2
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$		(1219)	925	43	2.7	43	2.8	43	2.9	43	3.0
$ \begin{array}{c c c c c c c c c c c c c c c c c c c $			950	43	2.6	43	2.7	43	2.8	43	2.8
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$			750	43	3.6	43	3.8	42	3.2	42	3.3
Y         No         825         43         3.0         43         3.1         43         3.2         43         3.3           5000         875         43         2.8         43         2.9         43         3.0         43         3.1           5000         875         43         2.7         43         2.8         43         2.9         43         3.2         43         3.2           (1524)         900         43         2.5         43         2.6         43         2.7         43         2.4           925         43         2.5         43         2.6         43         2.7         43         2.6         43         2.7         43         2.4           925         43         2.5         43         3.5         43         3.6         43         3.1           (1525)         775         43         3.0         43         3.1         43         3.2         43         3.2           10         800         43         2.6         43         2.7         43         3.0         43         3.1           6000         850         43         2.5         43         2.4		4001	775	43	3.4	43	3.5	43	3.6	43	3.8
5000         875         43         2.7         43         2.8         43         2.9         43         2.4           (1524)         900         43         2.5         43         2.6         43         2.7         43         2.4           925         43         2.5         43         2.6         43         2.5         43         2.6         43         2.7         43         2.1           900         43         2.5         43         2.6         43         2.6         43         2.6         43         2.7         43         2.1           900         725         43         3.4         43         3.5         43         3.6         43         3.1         43         3.4         43         3.1         43         3.2         43         3.3         1.3         1.43         3.2         2.4         3.3         1.43         3.2         2.6         43         2.2         43         2.5         43         2.6         43         2.6         43         2.1         1.43         3.3         43         2.4         2.4         2.4         2.3         2.4         2.4         2.4         2.4         2.4		(1220)	800	43	3.2	43	3.3	43	3.4	43	3.5
5000         875         43         2.7         43         2.8         43         2.9         43         2.4           (1524)         900         43         2.5         43         2.6         43         2.7         43         2.4           925         43         2.5         43         2.6         43         2.5         43         2.6         43         2.7         43         2.1           900         43         2.5         43         2.6         43         2.6         43         2.6         43         2.7         43         2.1           900         725         43         3.4         43         3.5         43         3.6         43         3.1         43         3.4         43         3.1         43         3.2         43         3.3         1.3         1.43         3.2         2.4         3.3         1.43         3.2         2.6         43         2.2         43         2.5         43         2.6         43         2.6         43         2.1         1.43         3.3         43         2.4         2.4         2.4         2.3         2.4         2.4         2.4         2.4         2.4	S.A	. to	825	43	3.0	43	3.1	43	3.2	43	3.3
(1524)         900         43         2.5         43         2.6         43         2.7         43         2.4           925         43         2.4         43         2.5         43         2.6         43         2.7         43         2.4           5001         725         43         3.4         43         3.5         43         3.6         43         3.1           (1525)         775         43         3.2         43         3.3         43         3.4         43         3.3         43         3.4         3.3         43         3.4         43         3.3         43         3.4         43         3.3         43         3.4         43         3.3         43         3.4         43         3.3         (1525)         775         43         3.0         43         3.1         43         3.0         43         3.2         43         3.0         43         3.2         43         3.2         43         3.0         43         3.2         43         2.4         43         2.6         43         2.7         43         2.6         43         2.3         43         3.2         43         3.2         43         2.4<	3		850	43	2.8	43	2.9	43	3.0	43	3.1
925         43         2.4         43         2.5         43         2.6         43         2.4           725         43         3.4         43         3.5         43         3.6         43         3.3           1         725         43         3.4         43         3.5         43         3.6         43         3.3           (1525)         775         43         3.0         43         3.1         43         3.2         43         3.3         43         3.4         43         3.3           (1525)         775         43         3.0         43         3.1         43         3.2         43         3.2           6000         850         43         2.6         43         2.7         43         2.8         43         2.2           6000         850         43         2.5         43         2.6         43         2.5         43         2.6         43         2.4         43         2.5         43         2.6         43         2.4         43         2.6         43         2.4         43         2.5         43         2.4         3.2         43         2.4         3.2         43		5000	875	43	2.7	43	2.8	43	2.9	43	2.9
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$		(1524)	900	43	2.5	43	2.6	43	2.7	43	2.8
S001         750         43         3.2         43         3.3         43         3.4         43         3.4           (1525)         775         43         3.0         43         3.1         43         3.2         43         3.3           to         800         43         2.8         43         2.9         43         3.0         43         3.2         43         3.3           6000         825         43         2.6         43         2.7         43         2.8         43         2.4         43         2.2         43         2.6         43         2.7         43         2.6         43         2.7         43         2.6         43         2.7         43         2.6         43         2.7         43         2.6         43         2.7         43         2.6         43         2.7         43         2.6         43         2.7         43         2.6         43         2.7         43         2.6         43         2.3         43         3.4         3.2         43         2.4         43         3.4         43         3.3         43         3.4         43         3.4         3.4         3.4         3.4			925	43	2.4	43	2.5	43	2.6	43	2.6
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$			725	43	3.4	43	3.5	43	3.6	43	3.7
$ \begin{array}{c c c c c c c c c c c c c c c c c c c $		5001	750	43	3.2	43	3.3	43	3.4	43	3.5
6000         850         43         2.5         43         2.6         43         2.7           (1829)         875         43         2.3         43         2.4         43         2.5         43         2.6         43         2.1           900         43         2.2         43         2.4         43         2.5         43         2.4           900         43         2.2         43         2.3         43         2.3         43         2.5         43         2.4           6001         675         43         3.4         43         3.5         43         3.6         43         3.3           6001         700         43         3.1         43         3.3         43         3.4         43         3.3           (1830)         725         43         2.7         43         2.8         43         2.9         43         3.0           10         750         43         2.7         43         2.8         43         2.9         43         3.1         43         2.4           10         775         43         2.6         43         2.7         43         2.7         43		(1525)	775	43	3.0	43	3.1	43	3.2	43	3.3
6000         850         43         2.5         43         2.6         43         2.7           (1829)         875         43         2.3         43         2.4         43         2.5         43         2.6         43         2.1           900         43         2.2         43         2.4         43         2.5         43         2.4           900         43         2.2         43         2.3         43         2.3         43         2.5         43         2.4           6001         675         43         3.4         43         3.5         43         3.6         43         3.3           6001         700         43         3.1         43         3.3         43         3.4         43         3.3           (1830)         725         43         2.7         43         2.8         43         2.9         43         3.0           10         750         43         2.7         43         2.8         43         2.9         43         3.1         43         2.4           10         775         43         2.6         43         2.7         43         2.7         43	S.A	to 1	800	43	2.8	43	2.9	43	3.0	43	3.1
(1829)         875         43         2.3         43         2.4         43         2.5         43         2.4           900         43         2.2         43         2.3         43         2.4         43         2.5         43         2.4           6001         75         43         3.4         43         3.5         43         3.4         43         3.5         43         3.4         3.5         43         3.4         43         3.5         43         3.4         43         3.5         43         3.4         43         3.3         43         3.4         43         3.3         43         3.4         43         3.3         43         3.4         43         3.3         43         3.4         43         3.3         43         3.4         43         3.3         43         3.4         43         3.3         43         3.4         43         3.3         43         3.4         43         3.4         43         2.9         43         3.4         43         2.9         43         3.4         43         2.9         43         3.4         43         2.4         43         2.4         43         2.4         43			825	43	2.6	43	2.7	43	2.8	43	2.9
900         43         2.2         43         2.3         43         2.3         43         2.4           6001         700         43         3.4         43         3.5         43         3.6         43         3.5           6001         700         43         3.1         43         3.3         43         3.6         43         3.3           (1830)         725         43         2.9         43         3.0         43         3.1         43         3.3         43         3.4         43         3.5           1         1750         43         2.7         43         2.8         43         2.9         43         3.0         43         3.1         43         3.5           1         750         43         2.7         43         2.8         43         2.9         43         3.4           1         750         43         2.6         43         2.7         43         2.4         43         2.7         43         2.4         43         2.4         43         2.7         43         2.4         43         2.5         43         2.4         43         2.4         43         2.4		6000	850	43	2.5	43	2.5	43	2.6	43	2.7
6001         675         43         3.4         43         3.5         43         3.6         43         3.1           6001         700         43         3.1         43         3.3         43         3.4         43         3.1           (1830)         725         43         2.9         43         3.0         43         3.1         43         3.1           5         to         750         43         2.7         43         2.8         43         2.9         43         3.0           5         to         775         43         2.6         43         2.7         43         2.8         43         2.9         43         3.0           7         7000         800         43         2.4         43         2.5         43         2.6         43         2.7         43         2.4         43         2.4         43         2.4         43         2.4         43         2.4         43         2.4         43         2.4         43         2.4         43         2.4         43         2.4         43         2.4         43         2.4         43         2.4         2.4         2.4         2.4		(1829)	875	43	2.3	43	2.4	43	2.5	43	2.6
6001         700         43         3.1         43         3.3         43         3.4         43         3.4           (1830)         725         43         2.9         43         3.0         43         3.1         43         3.4         43         3.4           (1830)         725         43         2.9         43         3.0         43         3.1         43         3.4           (1830)         725         43         2.9         43         3.0         43         3.1         43         3.4           (1830)         750         43         2.7         43         2.8         43         2.9         43         3.4           (100)         750         43         2.6         43         2.7         43         2.4         43         2.5         43         2.6         43         2.6         43         2.6         43         2.6         43         2.6         43         2.6         43         2.6         43         2.6         43         2.4         43         2.3         43         2.4         43         2.4         43         2.4         43         2.4         43         2.4         43         2			900	43	2.2	43	2.3	43	2.3	43	2.4
Image: system         Image:			675	43	3.4	43	3.5	43	3.6	43	3.7
\$\frac{1}{27}\$         to         750         43         2.7         43         2.8         43         2.9         43         3.0           \$\frac{1}{27}\$         to         775         43         2.6         43         2.7         43         2.4           \$\frac{1}{27}\$         43         2.6         43         2.7         43         2.4         2.4         2.5         43         2.7         43         2.4           \$\lambda 2133\$         825         43         2.3         43         2.3         43         2.4         43         2.3         43         2.4         43         2.3         43         2.4         43         2.3         43         2.4         43         2.3         43         2.4         43         2.3         43         2.4         43         2.3         43         2.4         43         2.3         43         2.4         43         2.3         43         2.4         43         2.3         43         2.4         43         2.3         43         2.4         43         2.3         43         2.4         43         2.3         43         2.4         43         2.3         43         2.4         43		6001	700	43	3.1	43	3.3	43	3.4	43	3.5
\$\frac{1}{27}\$         to         750         43         2.7         43         2.8         43         2.9         43         3.0           \$\frac{1}{27}\$         to         775         43         2.6         43         2.7         43         2.4           \$\frac{1}{27}\$         43         2.6         43         2.7         43         2.4         2.4         2.5         43         2.7         43         2.4           \$\lambda 2133\$         825         43         2.3         43         2.3         43         2.4         43         2.3         43         2.4         43         2.3         43         2.4         43         2.3         43         2.4         43         2.3         43         2.4         43         2.3         43         2.4         43         2.3         43         2.4         43         2.3         43         2.4         43         2.3         43         2.4         43         2.3         43         2.4         43         2.3         43         2.4         43         2.3         43         2.4         43         2.3         43         2.4         43         2.3         43         2.4         43		(1830)	725	43	2.9	43	3.0	43	3.1	43	3.2
7000         800         43         2.4         43         2.5         43         2.6         43         2.7           (2133)         825         43         2.3         43         2.3         43         2.4         43 <td< td=""><td>  ¥  </td><td></td><td></td><td>43</td><td></td><td>43</td><td></td><td>43</td><td></td><td>43</td><td>3.0</td></td<>	¥			43		43		43		43	3.0
7000         800         43         2.4         43         2.5         43         2.6         43         2.7           (2133)         825         43         2.3         43         2.3         43         2.4         43 <td< td=""><td>  <u> </u></td><td>to</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>43</td><td>2.8</td></td<>	<u> </u>	to								43	2.8
(2133) 825 43 2.3 43 2.3 43 2.4 43 2.5		7000		43						43	2.7
		(2133)		43						43	2.5
											2.4
A 10											A10180

(TABULATED DATA BASED ON 22,000 BTUH PER BURNER, DERATED 4%/1000 FT (305M) ABOVE SEA LEVEL)	
(TABGERTED DATA DAGED ON 22,000 DTOTT EN DONNEN, DENATED 4/10 1000 TT (00000) ABOVE GEA EEVEE)	

4	ALTITUDE	AVG. GAS	SPECIFIC GRAVITY OF NATURAL GAS							
	RANGE HEAT VALUE			0.58 0.60		0.60	(	).62	0.64	
		AT ALTITUDE	Orifice	Manifold	Orifice	Manifold	Orifice	Manifold	Orifice	Manifold
	ft (m)	(Btu/cu ft)	No.	Pressure	No.	Pressure	No.	Pressure	No.	Pressure
		650	43	3.1	43	3.2	43	3.4	43	3.5
	7001	675	43	2.9	43	3.0	43	3.1	43	3.2
	(2134)	700	43	2.7	43	2.8	43	2.9	43	3.0
U.S.A.	to	725	43	2.5	43	2.6	43	2.7	43	2.8
<u>"</u>		750	43	2.4	43	2.4	43	2.5	43	2.6
	8000	775	43	2.2	43	2.3	43	2.4	43	2.4
	(2438)	800	43	2.1	43	2.1	43	2.2	43	2.3
		825	48	3.7	43	2.0	43	2.1	43	2.2
		625	43	2.9	43	3.0	43	3.1	43	3.2
	8001	650	43	2.7	43	2.8	43	2.9	43	3.0
ai	(2439)	675	43	2.5	43	2.6	43	2.7	43	2.8
U.S.A.	to	700	43	2.3	43	2.4	43	2.5	43	2.6
>		725	43	2.2	43	2.2	43	2.3	43	2.4
	9000	750	43	2.0	43	2.1	43	2.2	43	2.2
	(2743)	775	48	3.6	48	3.7	43	2.0	43	2.1
	9001	600	43	2.7	43	2.8	43	2.9	43	3.0
	(2744)	625	43	2.5	43	2.6	43	2.6	43	2.7
U.S.A.	to	650	43	2.3	43	2.4	43	2.4	43	2.5
l Si		675	43	2.1	43	2.2	43	2.3	43	2.3
	10000	700	48	3.7	43	2.0	43	2.1	43	2.2
	(3048)	725	48	3.5	48	3.6	48	3.7	43	2.0
* Orific	ce numbers show	vn in <b>BOLD</b> are fac	tory-instal	led.						

A10180a

4. Verify natural gas input rate by clocking meter.

**NOTE:** Gas valve regulator adjustment cap must be in place for proper input to be clocked.

- a. Turn off all other gas appliances and pilots served by the meter.
- b. Run furnace for 3 minutes in heating operation.
- c. Measure time (in sec) for gas meter to complete 1 revolution and note reading. The 2 or 5 cubic feet dial provides a more accurate measurement of gas flow.

- d. Refer to Table 11 for cubic ft. of gas per hr.
- e. Multiply gas rate (cu ft./hr) by heating value (Btuh/cu ft.) to obtain input.
- f. If clocked rate does not match required input from Step 1, increase manifold pressure to increase input or decrease manifold pressure to decrease input. Repeat steps b through e until correct input is achieved. Reinstall regulator seal cap on gas valve.
- 5. Set temperature rise. The furnace must operate within the temperature rise ranges specified on the furnace rating plate. Do not exceed temperature rise range specified on unit rating plate. Determine the temperature rise as follows:

**NOTE:** Blower access door must be installed when taking temperature rise reading. Leaving blower access door off will result in incorrect temperature measurements.

- a. Place thermometers in return and supply ducts as close to furnace as possible. Be sure thermometers do not see radiant heat from heat exchangers. Radiant heat affects temperature rise readings. This practice is particularly important with straight-run ducts.
- b. When thermometer readings stabilize, subtract return-air temperature from supply-air temperature to determine air temperature rise.

NOTE: If the temperature rise is outside this range, first check:

- (1.) Gas input for heating operation.
- (2.) Derate for altitude if applicable.
- (3.) Return and supply ducts for excessive restrictions causing static pressures greater than 0.50-In. W.C.
- c. Adjust air temperature rise by adjusting blower speed. Increase blower speed to reduce temperature rise. Decrease blower speed to increase temperature rise
- d. Turn thermostat down below room temperature and remove blower access door.
- e. To change motor speed selection for heating, remove blower motor lead from control HEAT terminal (See Fig. 28). Select desired blower motor speed lead from one of the other terminals and relocate it to the HEAT terminal (See Table 4 for lead color identification). Reconnect original lead to SPARE terminal.
- f. If the same motor speed tap is needed for heating and cooling, a Jumper Wire accessory kit is available, see Product Data sheet for the current Jumper Wire accessory part number. The single wire end of the jumper will be connected to the desired blower motor speed lead. The two wire end of the jumper will be connected to the control board, connecting one wire to the HEAT (heating blower tap) terminal and the other will be connected to the COOL (cooling blower tap). Use the provided wire ties to secure the loose blower motor speed lead and any other loose wires, being careful not to put tension on any wire connectors. *α* Repeat steps a through e
- g. Repeat steps a through e.
- h. When correct input rate and temperature rise is achieved, turn gas valve ON/OFF switch to OFF.

## WARNING

#### FIRE HAZARD

Failure to follow this warning could result in personal injury, death, and/or property damage.

Reinstall manifold pressure tap plug in gas valve to prevent gas leak.

- i. Remove manometer or similar device from gas valve.
- j. Reinstall manifold pressure tap plug in gas valve. (1.)

#### Table 12 - Orifice Size\* And Manifold Pressure (In. W.C.) For Gas Input Rate

	RANGE	HEAT VALUE		0.58		0.60		).62		0.64
	RANGE	AT ALTITUDE								
	ft (m)	(Btu/cu ft)	Orifice	Manifold Pressure	Orifice	Manifold Pressure	Orifice	Manifold	Orifice	Manifold
	1	(Btu/cu π) 900	No. 42	3.2	No. 42	3.3	No. 42	Pressure 3.4	No. 42	Pressure 3.5
	0	925	42	3.2	42	3.8	42	3.4	42	3.3
		925 950	43	3.7	43		42	3.2	42	3.3
	(0)	950				3.6				
×	4-	975 1000	43 44	3.3 3.6	43 43	3.4	43	3.5	43	3.7
U.S.A.	to				43	3.3	43	3.4	43	3.5
	0000	1025	44	3.4	44	3.6	43	3.2	43	3.3
	2000	1050	44	3.3		3.4	44	3.5	43	3.2
	(610)	1075	45	3.8	44	3.2	44	3.3	44	3.4
		1100	46 43	3.8	45 42	3.7	44 42	3.2	44	3.3
		800 825	43	3.8 3.5	42	3.2 3.7	42	3.3 3.8	42 42	3.4 3.2
			43		43					
	2001 (611)	850	43	3.3 3.2	43	3.5	43 43	3.6	43	3.7
¥ ا	to	875				3.3		3.4	43	3.5
U.S.A.	3000 (914)	900	43	3.0	43	3.1	43	3.2	43	3.3
_ <b>_</b>		925 950	43 43	2.8 2.7	43 43	2.9 2.8	43	3.0	43	3.1
							43	2.9	43	2.9
		975 1000	43 43	2.5 2.4	43 43	2.6 2.5	43 43	2.7 2.6	43 43	2.8 2.7
	1	775	43	3.5	43	3.7	43	3.8	43	3.2
	3001	800	43	3.3	43	3.4	43	3.5	42	3.7
	(915)	825	43	3.1	43	3.4	43	3.3	43	3.4
đ	(913)	850	43	2.9	43	3.2	43	3.1	43	3.4
U.S.A.	to	875	43	2.5	43	2.9	43	3.0	43	3.1
	4000	900	43	2.6	43	2.5	43	2.8	43	2.9
	(1219)	925	43	2.5	43	2.6	43	2.0	43	2.3
	(1213)	950	43	2.3	43	2.4	43	2.5	43	2.6
		750	43	3.3	43	3.4	43	3.5	43	3.6
	4001	775	43	3.1	43	3.2	43	3.3	43	3.4
	(1220)	800	43	2.9	43	3.0	43	3.1	43	3.2
×		825	43	2.7	43	2.8	43	2.9	43	3.0
U.S.A.	to	850	43	2.6	43	2.7	43	2.8	43	2.8
	5000	875	43	2.4	43	2.5	43	2.6	43	2.7
	(1524)	900	43	2.3	43	2.4	43	2.5	43	2.5
	(	925	43	2.2	43	2.2	43	2.3	43	2.4
	1	725	43	3.1	43	3.2	43	3.3	43	3.4
	5001	750	43	2.9	43	3.0	43	3.1	43	3.2
	(1525)	775	43	2.7	43	2.8	43	2.9	43	3.0
4		800	43	2.5	43	2.6	43	2.7	43	2.8
U.S.A.	to	825	43	2.4	43	2.5	43	2.5	43	2.6
	6000	850	43	2.2	43	2.3	43	2.4	43	2.5
	(1829)	875	43	2.1	43	2.2	43	2.3	43	2.3
		900	43	2.0	43	2.1	43	2.1	43	2.2
		675	43	3.1	43	3.2	43	3.3	43	3.4
	6001	700	43	2.9	43	3.0	43	3.1	43	3.2
	(1830)	725	43	2.7	43	2.8	43	2.9	43	2.9
4		750	43	2.5	43	2.6	43	2.7	43	2.8
U.S.A.	to	775	43	2.3	43	2.4	43	2.5	43	2.6
-									43	
	7000	800	43	2.2	43	2.3	43	2.3	43	2.4
	7000 (2133)	800 825	43 43	2.2 2.1	43 43	2.3	43	2.3	43	2.4

(TABULATED	DATA BASED ON	21,000 BTUH PER BU	JRNER, DERATED 4%	6/1000 FT (305M) ABC	OVE SEA LEVEL)
ALTITUDE	AVG. GAS		SPECIFIC GRAVITY	OF NATURAL GAS	

A10181

10191

ALTITUDE AVG. GAS			SPECIFIC GRAVITY OF NATURAL GAS							
RANGE		HEAT VALUE	0.58		0.60		0.62		0.64	
		AT ALTITUDE	Orifice	Manifold	Orifice	Manifold	Orifice	Manifold	Orifice	Manifold
	ft (m)	(Btu/cu ft)	No.	Pressure	No.	Pressure	No.	Pressure	No.	Pressure
		650	43	2.9	43	3.0	43	3.1	43	3.2
	7001	675	43	2.7	43	2.7	43	2.8	43	2.9
	(2134)	700	43	2.5	43	2.6	43	2.6	43	2.7
U.S.A.	to	725	43	2.3	43	2.4	43	2.5	43	2.5
S.U	10	750	43	2.1	43	2.2	43	2.3	43	2.4
	8000	775	43	2.0	43	2.1	43	2.2	43	2.2
	(2438)	800	48	3.6	48	3.7	43	2.0	43	2.1
		825	48	3.3	48	3.5	48	3.6	48	3.7
		625	43	2.7	43	2.7	43	2.8	43	2.9
	8001	650	43	2.5	43	2.5	43	2.6	43	2.7
÷	(2439)	675	43	2.3	43	2.4	43	2.4	43	2.5
U.S.A.	to	700	43	2.1	43	2.2	43	2.3	43	2.3
		725	48	3.7	43	2.0	43	2.1	43	2.2
	9000	750	48	3.5	48	3.6	48	3.7	43	2.0
	(2743)	775	49	3.8	48	3.4	48	3.5	48	3.6
	9001	600	43	2.4	43	2.5	43	2.6	43	2.7
	(2744)	625	43	2.3	43	2.3	43	2.4	43	2.5
U.S.A.	to	650	43	2.1	43	2.2	43	2.2	43	2.3
ŝ	.0	675	48	3.6	48	3.8	43	2.1	43	2.1
	10000	700	48	3.4	48	3.5	48	3.6	48	3.7
	(3048)	725	49	3.7	49	3.8	48	3.4	48	3.5

## WARNING

#### FURNACE OVERHEATING HAZARD

Failure to follow this caution may result in reduced furnace life. Recheck temperature rise. It must be within limits specified on the rating plate. Recommended operation is at the mid-point of rise range or slightly above.

- 6. Set thermostat heat anticipator.
  - a. Mechanical thermostat Set thermostat heat anticipator to match the amp. draw of the electrical components in the R-W circuit. Accurate amp. draw readings can be obtained at the wires normally connected to thermostat subbase terminals, R and W. The thermostat anticipator should NOT be in the circuit while measuring current.
    - (1.) Remove thermostat from subbase or from wall.
    - (2.) Connect an amp. meter as shown in Fig. 46 across the R and W subbase terminals or R and W wires at wall.
    - (3.) Record amp. draw across terminals when furnace is in heating and after blower starts.
    - (4.) Set heat anticipator on thermostat per thermostat instructions and install on subbase or wall.
  - b. Electronic thermostat: Set cycle rate for 4 cycles per hr.



EXAMPLE: 5.0 AMPS ON AMMETER 10.5 AMPS FOR THERMOSTAT

Fig. 46 - Amp. Draw Check with Ammeter Table 13 – Gas Rate (Cu Ft./Hr.)

A96316

Table 15 – Gas Kate (Cu Ft./III.)								
SECONDS	SIZE OF TEST DIAL			SECONDS	SIZE OF TEST DIAL			
FOR 1 REVOLUTION	1 Cu Ft.	2 Cu Ft.	5 Cu Ft.	FOR 1 REVOLUTION	1 Cu Ft.	2 Cu Ft.	5 Cu Ft.	
10	360	720	1800	50	72	144	360	
11	327	655	1636	51	71	141	355	
12	300	600	1500	52	69	138	346	
13	277	555	1385	53	68	136	340	
14	257	514	1286	54	67	133	333	
15	240	480	1200	55	65	131	327	
16	225	450	1125	56	64	129	321	
17	212	424	1059	57	63	126	316	
18	200	400	1000	58	62	124	310	
19	189	379	947	59	61	122	305	
20	180	360	900	60	60	120	300	
21	171	343	857	62	58	116	290	
22	164	327	818	64	56	112	281	
23	157	313	783	66	54	109	273	
24	150	300	750	68	53	106	265	
25	144	288	720	70	51	103	257	
26	138	277	692	72	50	100	250	
27	133	267	667	74	48	97	243	
28	129	257	643	76	47	95	237	
29	124	248	621	78	46	92	231	

Manufacturer reserves the right to change, at any time, specifications and designs without notice and without obligations.

SECONDS	SIZE OF TEST DIAL			SECONDS	SIZE OF TEST DIAL		
FOR 1 REVOLUTION	1 Cu Ft.	2 Cu Ft.	5 Cu Ft.	FOR 1 REVOLUTION	1 Cu Ft.	2 Cu Ft.	5 Cu Ft.
30	120	240	600	80	45	90	225
31	116	232	581	82	44	88	220
32	113	225	563	84	43	86	214
33	109	218	545	86	42	84	209
34	106	212	529	88	41	82	205
35	103	206	514	90	40	80	200
36	100	200	500	92	39	78	196
37	97	195	486	94	38	76	192
38	95	189	474	96	38	75	188
39	92	185	462	98	37	74	184
40	90	180	450	100	36	72	180
41	88	176	439	102	35	71	178
42	86	172	429	104	35	69	173
43	84	167	419	106	34	68	170
44	82	164	409	108	33	67	167
45	80	160	400	110	33	65	164
46	78	157	391	112	32	64	161
47	76	153	383	116	31	62	155
48	75	150	375	120	30	60	150
49	73	147	367				

Table 13 – Gas Rate (Cu Ft./Hr.) (Continued)

 Adjust blower off delay The blower off delay has 4 adjustable settings from 90 sec to 180 sec. The blower off delay jumpers are located on the furnace control board (see Fig. 28).

To change the blower off delay setting, move the jumper from one set of pins on the control to the pins used for the selected blower off delay. Factory off delay setting is 120 sec.

8. Set airflow CFM for cooling

Select the desired blower motor speed lead for cooling airflow. See Table 4-Air Delivery-CFM (With Filter) for lead color identification.

#### **Check Safety Controls**

The flame sensor, gas valve, and pressure switch were all checked in the Start-up procedure section as part of normal operation.

1. Check Main Limit Switch(es)

This control shuts off combustion control system and energizes air-circulating blower motor, if furnace overheats. By using this method to check limit control, it can be established that limit is functioning properly and will operate if there is a restricted duct system or motor failure. If limit control does not function during this test, cause must be determined and corrected.

- a. Run furnace for at least 5 minutes.
- b. Gradually block off return air with a piece of cardboard or sheet metal until the limit trips.
- c. Unblock return air to permit normal circulation.
- d. Burners will re-light when furnace cools down.
- 2. Check draft safeguard switch.

The purpose of this control is to cause the safe shutdown of the furnace during certain blocked vent conditions.

a. Verify vent pipe is cool to the touch.

- b. Disconnect power to furnace and remove vent connector from furnace vent elbow.
- c. Restore power to furnace and set room thermostat above room temperature.
- d. After normal start-up, allow furnace to operate for 2 minutes, then block vent elbow in furnace 80 percent of vent area with a piece of flat sheet metal.
- e. Furnace should cycle off within 2 minutes. If gas does not shut off within 2 minutes, determine reason draft safeguard switch did not function properly and correct condition.
- f. Remove blockage from furnace vent elbow.
- g. Switch will auto-reset when it cools.
- h. Re-install vent connector.

**NOTE:** Should switch remain open longer than 3 minutes, furnace control board will lockout the furnace for 3 hours. To reset furnace control board, turn thermostat below room temperature or from HEAT to OFF and turn 115v power OFF, then back ON.

- 3. Check Pressure Switch
  - This control proves operation of the draft inducer blower.
  - a. Turn off 115-v power to furnace.
  - b. Disconnect inducer motor lead wires from wire harness.
  - c. Turn on 115-v power to furnace.
  - d. Set thermostat to "call for heat" and wait 1 minute. When pressure switch is functioning properly, hot surface igniter should NOT glow and control diagnostic light flashes a status code 31. If hot surface igniter glows when inducer motor is disconnected, shut down furnace immediately.
  - e. Determine reason pressure switch did not function properly and correct condition.
  - f. Turn off 115-v power to furnace.
  - g. Reconnect inducer motor wires, replace outer door, and turn on 115-v power.
  - h. Blower will run for 90 sec before beginning the call for heat again.
  - i. Furnace should ignite normally.

#### <u>Checklist</u>

- 1. Put away tools and instruments. Clean up debris.
- 2. Verify that blower OFF-DELAY time is selected as desired.
- 3. Verify that blower and burner access doors are properly installed.
- 4. Cycle test furnace with room thermostat.
- 5. Check operation of accessories per manufacturer's instructions.
- 6. Review User's Guide with owner.
- 7. Attach literature packet to furnace.

#### SERVICE AND MAINTENANCE PROCEDURES

Untrained personnel can perform basic maintenance functions such as cleaning and replacing air filters. All other operations must be performed by trained service personnel. A qualified service person should inspect the furnace once a year.

## WARNING

#### FIRE, INJURY, OR DEATH HAZARD

Failure to follow this warning could result in personal injury, death and/or property damage.

The ability to properly perform maintenance on this equipment requires certain knowledge, mechanical skills, tools, and equipment. If you do not possess these, do not attempt to perform any maintenance on this equipment other than those procedures recommended in the User's Manual. 58SB0A/58SB1A: Installation, Start–Up, Operating and Service and Maintenance Instructions

! WARNING

#### ELECTRICAL SHOCK, FIRE OR EXPLOSION HAZARD

Failure to follow this warning could result in personal injury or death. Before installing, modifying, or servicing system, main electrical disconnect switch must be in the OFF position and install a lockout tag. There may be more than one disconnect switch. Lock out and tag switch with a suitable warning label. Verify proper operation after servicing.

## **CAUTION**

#### **ELECTRICAL OPERATION HAZARD**

Failure to follow this caution may result in improper furnace operation or failure of furnace.

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation.

#### GENERAL

These instructions are written as if the furnace is installed in an upflow application. An upflow furnace application is where the blower is located below the combustion and controls section of the furnace, and conditioned air is discharged upward. Since this furnace can be installed in any of the 4 positions (see Fig. 5), you must revise your orientation to component location accordingly.

#### ELECTRICAL CONTROLS AND WIRING

The electrical ground and polarity for 115-v wiring must be properly maintained. Refer to Fig. 24 for field wiring information and to Fig. for furnace wiring information.

## ! WARNING

#### ELECTRICAL OPERATION HAZARD

Failure to follow this warning could result in personal injury or death. There may be more than one electrical supply to the furnace. Check accessories and cooling unit for additional electrical supplies that must be shut off during furnace servicing. Lock out and tag switch with a suitable warning label.

**NOTE:** If the polarity is not correct, the STATUS LED on the control will flash rapidly and prevent the furnace from heating. The control system also requires an earth ground for proper operation of the control and flame-sensing electrode.

The 24-v circuit contains an automotive-type, 3-amp. fuse located on the control (see Fig. 28). Any shorts of the 24-v wiring during installation, service, or maintenance will cause this fuse to blow. If fuse replacement is required, use ONLY a 3-amp. fuse. The control LED will display status code 24 when fuse needs to be replaced.

Proper instrumentation is required to service electrical controls. The control in this furnace is equipped with a Status Code LED (Light-Emitting Diode) to aid in installation, servicing, and troubleshooting. Status codes can be viewed at the sight glass in blower access door. The furnace control LED is either ON continuously, rapid flashing, or a code composed of 2 digits. The first digit is the number of short flashes, the second digit is the number of long flashes.

For an explanation of status codes, refer to service label located on blower access door, or Fig. 44 and the troubleshooting guide which can be obtained from your distributor.

#### For Controls With an Amber LED

The stored status code will not be erased from the control memory, if 115- or 24-v power is interrupted.

1. To retrieve status code, proceed with the following:

**NOTE:** NO thermostat signal may be present at control, and all blower-OFF delays must be completed.

- a. Leave 115-v power to furnace turned on.
- b. Remove outer access door.
- c. Look into blower access door sight glass for current LED status.
- d. BRIEFLY remove insulated terminal wire from the draft

safeguard (DSS) switch until LED goes out, then reconnect it. **NOTE:** If wire to LS or DSS is disconnected longer than 4 sec, main blower starts, and status code is overwritten with a limit circuit 33 code.

- 2. When above items have been completed, the LED flashes status code 4 times. Record this status code for further troubleshooting.
- 3. Check LED status. If no previous faults in history, control will flash status code 11.

#### **CARE AND MAINTENANCE**

## WARNING

#### FIRE OR EXPLOSION HAZARD

Failure to follow this warning could result in personal injury, death and/or property damage.

Never store anything on, near, or in contact with the furnace, such as: 1.Spray or aerosol cans, rags, brooms, dust mops, vacuum cleaners, or other cleaning tools.

2. Soap powders, bleaches, waxes or other cleaning compounds, plastic or plastic containers, gasoline, kerosene, cigarette lighter fluid, dry cleaning fluids, or other volatile fluids.

3.Paint thinners and other painting compounds, paper bags, or other paper products.

For continuing high performance and to minimize possible equipment failure, periodic maintenance must be performed on this equipment. Consult your local dealer about proper frequency of maintenance and the availability of a maintenance contract.



#### ELECTRICAL SHOCK AND FIRE HAZARD

Failure to follow this warning could result in personal injury, death or property damage.

Turn off the gas and electrical supplies to the unit and install lockout tag before performing any maintenance or service. Follow the operating instructions on the label attached to the furnace.



## CARBON MONOXIDE POISONING AND FIRE HAZARD

Failure to follow this warning could result in personal injury, death and/or property damage.

Never operate unit without a filter or with filter access door removed.

See Fig. 51 for a brief Troubleshooting Guide.



#### **CUT HAZARD**

Failure to follow this caution may result in personal injury.

Sheet metal parts may have sharp edges or burrs. Use care and wear appropriate protective clothing, safety glasses and gloves when handling parts and servicing furnaces.

The minimum maintenance on this furnace is as follows:

- 1. Check and clean/replace air filter each month or more frequently if required. Replace if torn.
- 2. Check blower motor and wheel for cleanliness each heating and cooling season. Clean as necessary.
- 3. Check electrical connections for tightness and controls for proper operation each heating season. Service as necessary.
- 4. Inspect burner compartment before each heating season for rust, corrosion, soot or excessive dust. If necessary, have furnace and burner serviced by a qualified service agency.
- Inspect the vent pipe/vent system before each heating season for rust, corrosion, water leakage, sagging pipes or broken fittings. Have vent pipes/vent system serviced by a qualified service agency.
- 6. Inspect any accessories attached to the furnace such as a humidifier or electronic air cleaner. Perform any service or maintenance to the accessories as recommended in the accessory instructions.

#### **CLEANING AND/OR REPLACING AIR FILTER**

The air filter arrangement will vary depending on the application. The filter is exterior to the furnace casing.

**NOTE:** If the filter has an airflow direction arrow, the arrow must point towards the blower.

Media cabinet filter procedures:

- 1. Turn off electrical supply to furnace before removing filter access door.
- 2. Remove filter cabinet door.
- 3. Slide filter out of cabinet.
- 4. If equipped with permanent, washable 3/4-in. (19 mm) filter, clean filter by spraying cold tap water through filter in opposite direction of airflow. Rinse filter and let dry. Oiling or coating of the filter is not recommended. See Table 14 for size information.
- 5. If equipped with factory-specified disposable media filter, replace only with media filter having the same part number and size. For expandable replacement media, refer to the instructions included with the replacement media.
- 6. Slide filter into cabinet.
- 7. Replace filter cabinet door.
- 8. Turn on electrical supply to furnace.

Ta	ble 14 – Filter Size Information (In. / mn	n)
ACE	FILTER SIZE (In. / mm)	

FURNACE	FILTER SIZ			
CASING WIDTH In. (mm)	Side Return	Bottom Return	FILTER TYPE	
14-1/2	16 x 25 x 3/4	14 x 25 x 3/4	Washable*	
(368)	(406 x 635 x 19)	(356 x 635 x 19)		
17-1/2	16 X 25 X 3/4	16 X 25 X 3/4	Washable*	
(445)	(406 x 635 x 19)	(406 x 635 x 19)		
21	16 x 25 x 3/4	20 X 25 X 3/4	Washable*	
(533)	(406 x 635 x 19)	(508 x 635 x 19)		
24	16 x 25 x 3/4	24 X 25 X 3/4	Washable*	
(610)	(406 x 635 x 19)	(610 x 635 x 19)		

\* Recommended

#### **BLOWER MOTOR AND WHEEL**



#### ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death. Blower access door switch opens 115-v power to control. No component operation can occur unless switch is closed. Caution must be taken when manually closing this switch for service purposes.

**NOTE:** The blower wheel should not be dropped or bent as balance will be affected. The following steps should be performed by a qualified service agency.

To ensure long life and high efficiency, clean accumulated dirt and grease from blower wheel and motor annually.

The inducer and blower motors are pre-lubricated and require no additional lubrication. These motors can be identified by the absence of oil ports on each end of the motor. The following steps should be performed by a qualified service agency.

Clean blower motor and wheel as follows:

- 1. Turn off electrical supply to furnace.
- 2. Remove outer door.
- 3. For downflow or horizontal furnaces having vent pipes within the furnace that pass in front of the blower access door:
  - a. Disconnect vent connector from furnace vent elbow.
  - b. Disconnect and remove short piece of vent pipe from within furnace.
- 4. Remove two screws from blower access door and remove blower access door.
- 5. All factory wires can be left connected, but field thermostat connections may need to be disconnected depending on their length and routing.

**NOTE:** The blower wheel should not be dropped or bent as balance will be affected.

- 6. Remove two screws holding blower assembly to blower deck and slide blower assembly out of furnace.
- 7. Clean blower wheel and motor using a vacuum with soft brush attachment. Blower wheel blades may be cleaned with a small paint or flux brush. Do not remove or disturb balance weights (clips) on blower wheel blades.
- 8. Vacuum any loose dust from blower housing, wheel and motor.
- 9. If a greasy residue is present on blower wheel, remove wheel from the blower housing and wash it with an appropriate degreaser.

**NOTE:** Before disassembly, mark blower motor, and blower housing so motor and each arm is positioned at the same location during reassembly.

To remove wheel:

- a. Disconnect power choke wires (if used) and ground wire attached to blower housing.
- b. Remove screws securing cutoff plate and remove cutoff plate from housing.
- c. Loosen set screw holding blower wheel on motor shaft (160+/-20 in.-lb. when reassembling).
- d. Remove bolts holding motor to blower housing and slide motor out of wheel (40+/-10 in.-lb. when reassembling).
- e. Remove blower wheel from housing.
- f. Clean wheel and housing.
- 10. Reassemble motor and blower by reversing steps 9f through 11a, finishing with 9a. Be sure to reattach ground wire to the blower housing.

**NOTE:** Refer to Table 4 for motor speed lead relocation if leads were not identified before disconnection.

58SB0A/58SB1A: Installation, Start-Up, Operating and Service and Maintenance Instructions

- 11. Verify that blower wheel is centered in blower housing and set screw contacts the flat portion of the motor shaft. Loosen set screw on blower wheel and reposition if necessary.
- 12. Spin the blower wheel by hand to verify that the wheel does not rub on the housing.
- 13. Reinstall blower assembly in furnace.
- 14. Reinstall two screws securing blower assembly to blower deck.

## **!** CAUTION

#### **UNIT DAMAGE HAZARD**

Failure to follow this caution may result in shortened heat exchanger life.

Heating fan speed(s) MUST be adjusted to provide proper air temperature rise as specified on the rating plate. Recommended operation is at the midpoint of the rise range or slightly above. Refer to "SET TEMPERATURE RISE" under START-UP, ADJUSTMENT, and SAFETY CHECK.

- 15. Refer to furnace wiring diagram, and connect thermostat leads if previously disconnected.
- 16. To check blower for proper rotation:
  - a. Turn on electrical supply.

## WARNING

#### ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury, or death. Blower access door switch opens 115-v power to furnace control. No component operation can occur unless switch is closed. Exercise caution to avoid electrical shock from exposed electrical components when manually closing this switch for service purposes.

b. Manually close blower access door switch.

**NOTE:** If thermostat terminals are jumpered at the time blower access door switch is closed, blower will run for 90 sec before beginning a heating or cooling cycle.

- c. Perform component self-test as shown at the bottom of the SERVICE label, located on the front of blower access door.
- d. Verify blower is rotating in the correct direction.
- 17. If furnace is operating properly, RELEASE BLOWER ACCESS DOOR SWITCH. Remove any jumpers or reconnect any disconnected thermostat leads. Replace blower access door.
- 18. Downflow or horizontal furnaces with vent pipe through furnace only:

a. Install and connect short piece of vent pipe inside furnace to existing vent.

- b. Connect vent connector to vent elbow.
- 19. Reinstall outer door.
- 20. Cycle furnace through one complete heating and cooling cycle. Verify the furnace temperature rise as shown in "Adjustments" Section. Adjust temperature rise as shown in "Adjustments" Section. If outdoor temperature is below 70°F, (21°C) turn off circuit breaker to outdoor unit before running furnace in the cooling cycle. Turn outdoor circuit breaker on after completing cooling cycle.

#### **CLEANING HEAT EXCHANGER**

#### The following steps should be performed by a qualified service agency:

**NOTE:** If the heat exchangers get a heavy accumulation of soot and carbon, they should be replaced rather than trying to clean them thoroughly. A heavy build-up of soot and carbon indicates that a problem exists which needs to be corrected, such as improper adjustment of manifold pressure, insufficient or poor quality combustion air, incorrect size or damaged manifold orifice(s), improper gas, or a restricted heat exchanger. Action must be taken to correct the problem.

If it becomes necessary to clean the heat exchangers because of dust or corrosion, proceed as follows:

- 1. Turn OFF gas and electrical power to furnace.
- 2. Remove outer access door.
- 3. Disconnect vent connector from furnace vent elbow.
- 4. For downflow or horizontal furnace having an internal vent pipe, remove internal vent pipe within the casing.
- 5. Disconnect wires to the following components. Mark wires to aid in reconnection of (be careful when disconnecting wires from switches because damage may occur):
  - a. Draft safeguard switch.
  - b. Inducer motor.
  - c. Pressure switch(es).
  - d. Limit over-temperature switch.
  - e. Gas valve.
  - f. Hot surface igniter.
  - g. Flame-sensing electrode.
  - h. Flame rollout switches.
- 6. Remove screws that fasten the collector box assembly to the cell panel. Be careful not to damage the collector box. Inducer assembly and elbow need not be removed from collector box.
- 7. Disconnect gas line from gas manifold.
- 8. Remove the 5 screws that attach the burner assembly to the cell panel. The gas valve and individual burners need not be removed from support assembly. Remove NOx baffles if installed.

**NOTE:** Be very careful when removing burner assembly to avoid breaking igniter. See Fig. 47 and Fig. 48 for correct igniter location.



Fig. 47 – Igniter Position-Top View



Fig. 48 – Igniter Position-Side View

**NOTE:** The materials needed in item 9 can usually be purchased at local hardware stores.

- 9. Using a field-provided 25-caliber rifle cleaning brush; a 36-in. (914 mm) long, 1/4" (6 mm) diameter steel spring cable; and a variable speed, reversible electric drill; and a vacuum cleaner, clean cells as follows:
  - a. Remove metal screw fitting from wire brush to allow insertion into cable.
  - b. Insert the twisted wire end of brush into end of spring cable, and crimp tight with crimping tool or crimp by striking with ball-peen hammer. TIGHTNESS IS VERY IMPORTANT.
    - (1.) Attach variable-speed, reversible drill to the end of spring cable (end opposite brush).
    - (2.) Insert brush end of cable into the outlet opening of cell and slowly rotate with drill. DO NOT force cable. Gradually insert cable into upper pass of cell (see Fig. 49).



Fig. 49 – Cleaning Heat Exchanger Cell

- (3.) Work cable in and out of cell 3 or 4 times to obtain sufficient cleaning. DO NOT pull cable with great force. Reverse drill and gradually work cable out.
- (4.) Insert brush end of cable in burner inlet opening of cell, and proceed to clean 2 lower passes of cell in same manner as upper pass.
- (5.) Repeat foregoing procedures until each cell in furnace has been cleaned.
- (6.) Using vacuum cleaner, remove residue from each cell.
- (7.) Using vacuum cleaner with soft brush attachment, clean burner assembly.
- (8.) Clean flame sensor with fine steel wool.
- (9.) Install NOx baffles (if removed).

(10.) Reinstall burner assembly. Center burners in cell openings.

- 10. Remove old sealant from cell panel and collector box flange.
- 11. Spray releasing agent on the heat exchanger cell panel where collector box assembly contacts cell panel.

**NOTE:** A releasing agent such as cooking spray or equivalent (must not contain corn or canola oil, aromatic or halogenated hydrocarbons or inadequate seal may occur) and RTV sealant (G.E. 162, 6702, or Dow-Corning 738) are needed before starting installation. DO NOT substitute any other type of RTV sealant. G.E. 162 (P771-9003) is available through RCD in 3-oz. tubes.

- 12. Apply new sealant to flange of collector box and attach to cell panel using existing screws, making sure all screws are secure.
- Reconnect wires to the following components. (Use connection diagram on wiring label, if wires were not marked for reconnection locations.):
  - a. Draft safeguard switch.
  - b. Inducer motor.
  - c. Pressure switch(es).
  - d. Limit over-temperature switch.
  - e. Gas valve.

A05025

- f. Hot surface igniter.
- g. Flame-sensing electrode.
- h. Flame rollout switches.
- i. Install NOx baffles (if removed).
- 14. Reinstall internal vent pipe, if applicable.
- 15. Reinstall vent connector on furnace vent elbow. Securely fasten vent connector to vent elbow with 2 field-supplied, corrosion-resistant, sheet metal screws located 180° apart.
- 16. Replace blower access door only, if it was removed.
- Set thermostat above room temperature and check furnace for proper operation.
- 18. Verify blower airflow and speed changes between heating and cooling.

## WARNING

#### FIRE OR EXPLOSION HAZARD

Failure to follow this warning could result in personal injury, death and/or property damage.

Never purge a gas line into a combustion chamber. Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections.

19. Check for gas leaks.

20. Replace outer access door.

#### SEQUENCE OF OPERATION

**NOTE:** Furnace control must be grounded for proper operation or control will lock out. Control is grounded through green/yellow wire routed to gas valve and manifold bracket screw.

Using the schematic diagram, follow the sequence of operation through the different modes. Read and follow the wiring diagram very carefully.

**NOTE:** If a power interruption occurs during a call for heat (W), the control will start a 90-sec blower-only ON period two seconds after power is restored, if the thermostat is still calling for gas heating. The amber LED light will flash code 12 during the 90-sec period, after which the LED will be ON continuous, as long as no faults are detected. After the 90-sec period, the furnace will respond to the thermostat normally.

The blower door must be installed for power to be conducted through the blower door interlock switch ILK to the furnace control CPU, transformer TRAN, inducer motor IDM, blower motor BLWM, hot-surface igniter HSI, and gas valve GV.

#### 1. Heating

The wall thermostat "calls for heat," closing the R-to-W circuit. The furnace control performs a self-check, verifies the pressure switch contacts PRS are open, and starts the inducer motor IDM.

- a. **Inducer Prepurge Period** As the inducer motor IDM comes up to speed, the pressure switch contacts PRS close, 24 VAC power is supplied for a field installed humidifier at the HUM terminal and the control begins a 15-sec prepurge period.
- b. **Igniter Warm-Up** At the end of the prepurge period, the Hot-Surface igniter HSI is energized for a 17-second igniter warm-up period.
- c. **Trial-for-Ignition Sequence** When the igniter warm-up period is completed, the main gas valve relay contacts GVR close to energize the gas valve GV, the gas valve opens, The gas valve GV permits gas flow to the burners where it is ignited by the HSI. Five seconds after the GVR closes, a 2-second flame proving period begins. The HSI igniter will remain energized until the flame is sensed or until the 2-second flame proving period begins.
- d. Flame-Proving When the burner flame is proved at the flame-proving sensor electrode FSE, the furnace control CPU begins the blower-ON delay period and continues to hold the gas valve GV open. If the burner flame is not proved within two seconds, the control CPU will close the gas valve GV, and the control CPU will repeat the ignition sequence for up to three more Trials-For-Ignition before going to Ignition-Lockout. Lockout will be reset automatically after three hours or by momentarily interrupting 115 vac power to the furnace, or by interrupting 24 vac power at SEC1 or SEC2 to the furnace control CPU (not at W, G, R, etc.) If flame is proved when flame should not be present, the furnace control CPU will lock out of Gas-Heating mode and operate the inducer motor IDM until flame is no longer proved.
- e. **Blower-On Delay** If the burner flame is proven, the blower motor is energized on HEAT speed 25 sec after the gas valve GV is energized.

Simultaneously, the electronic air cleaner terminal EAC-1 is energized and remains energized as long as the blower motor BLWM is energized.

- f. **Heat-Off Delay** When the thermostat is satisfied, the R-to-W circuit is opened, de-energizing the gas valve GV, stopping gas flow to the burners, and de-energizing the 24-v humidifier terminal 24VAC HUM. The inducer motor IDM will remain energized for a 5-second post-purge period. Then turn off the inducer motor and HUM (115-v) humidifier terminal. The blower motor BLWM and air cleaner terminal EAC 1 will remain energized for 90, 120, 150, or 180 seconds (depending on the HEAT-OFF delay selection). The furnace control CPU is factory-set for a 120-second Heat-Off Delay.
- g. **Blower-Off Delay** When the thermostat is satisfied, the R-to-W circuit is opened, de-energizing the gas valve GV, stopping gas flow to the burners, and de-energizing the humidifier terminal HUM. The inducer motor IDM will remain energized for a 5-second post-purge period. The blower motor BLWM and air cleaner terminal EAC-1 will remain energized for 90, 120, 150, or 180 seconds (depending on the blower-OFF delay selection). The furnace control CPU is factory-set for a 120-second blower-OFF delay.

#### 2. Cooling Mode

(See Fig. 24 for thermostat connections.) The thermostat closes the R-to-G-and-Y circuits. The R-to-Y circuit starts the outdoor unit, and the R-to-G and Y circuits start the furnace blower motor BLWM on COOL speed. The electronic air cleaner terminal EAC-1 is energized with 115 vac when the blower motor BLWM is

operating. When the thermostat is satisfied, the R-to-G-and-Y circuits are opened. The outdoor unit will stop, and the furnace blower motor BLWM will continue operating on the COOL speed for an additional 90 sec. Cut jumper J2 to reduce the cooling off-delay to 5 sec (see Fig. 28).

#### 3. Continuous Blower Mode

When the R-to-G circuit is closed by the thermostat, the blower motor BLWM will operate on continuous-blower speed FAN. Terminal EAC-1 is energized as long as the blower motor BLWM is energized.

During a call for heat, the blower BLWM will stop during igniter warm-up (17 sec), ignition, and blower-ON delay (25 sec), allowing the furnace heat exchangers to heat up more quickly, then restarts at the end of the blower-ON delay period at HEAT speed.

When the thermostat "calls for cooling", the blower motor BLWM will operate at COOL speed. When the thermostat is satisfied, the blower motor BLWM will operate an additional 90 sec, on COOL speed before reverting back to continuous blower speed.

When the R-to-G circuit is opened, the blower motor BLWM will continue operating for an additional 5 sec, if no other function requires blower motor BLWM operation.

#### 4. Heat Pump

When installed with a heat pump, the furnace control automatically changes the timing sequence to avoid long blower off times during demand defrost cycles. When the R-to-W-and-Y or R-to-W-and-Y-and-G circuits are energized the furnace control CPU will continue to turn on the blower motor BLWM at HEAT speed, and begin a heating cycle. The blower motor BLWM will remain on until the end of the prepurge period, then shut off for 24 sec then come back on at HEAT speed. When the W input signal disappears, the furnace control begins a normal inducer post-purge period and the blower switches to COOL speed after a 3 sec delay. If the R-to-W-and-Y-and-G signals disappear at the same time, the blower motor BLWM will remain on for the selected blower- OFF delay period. If the R-to-W-and-Y signals disappear, leaving the G signal, the blower motor BLWM will continue running the blower motor at HEAT speed after the selected blower-OFF delay period is completed.

#### Wiring Diagram

Fig. shows a schematic for the furnace wiring diagram.

#### **Troubleshooting**

Refer to the service label (see Fig. 44). The Troubleshooting Guide (see Fig. 51) can be a useful tool in isolating furnace operation problems. Beginning with the word "Start," answer each question and follow the appropriate arrow to the next item. The Guide will help to identify the problem or failed component. After replacing any component, verify correct operation sequence.

#### WIRING DIAGRAM



Fig. 50 - Wiring Diagram

A190268



## TROUBLESHOOTING

58SB0A/58SB1A: Installation, Start–Up, Operating and Service and Maintenance Instructions

A190024

#### 58SB0A/58SB1A: Installation, Start–Up, Operating and Service and Maintenance Instructions



Fig. 51 - Troubleshooting Guide

A05032

#### PARTS REPLACEMENT INFORMATION GUIDE

#### **CASING GROUP**

Outer door and Blower door Top filler plate Bottom filler plate Bottom enclosure

#### **ELECTRICAL GROUP**

Control bracket Junction box Limit switch(es) Circuit board Door switch Transformer Wiring harness 115v Wiring harness 24v

#### **BLOWER GROUP**

Blower cutoff Blower motor and Blower housing Blower wheel Grommet and Power choke (where used)

#### GAS CONTROL GROUP

Manifold Orifice Flame sensor Hot surface igniter Gas valve Manual reset limit switches Burner assembly and Burner support assembly

#### HEAT EXCHANGER GROUP

Heat exchanger cell Cell panel Lox NOx baffle (California models only)

#### INDUCER GROUP

Inducer motor and Inducer wheel Pressure switch Housing assembly Vent elbow assembly Draft safeguard switch

TO OBTAIN INFORMATION ON PARTS: Consult your installing dealer or classified section of your local telephone directory under "Heating Equipment" or "Air Conditioning Contractors and Systems" headings for dealer listing by brand name or contact:

#### **CARRIER CORPORATION**

**Consumer Relations Department** P.O. Box 4808 Syracuse, New York 13221-4808 1-800-CARRIER

Have available the model number, series number, and serial number located on the unit rating plate to ensure correct replacement part.

#### **Example of Model Number**

MODEL	HEATING SIZE	MOTOR	WIDTH	VOLTAGE	MINOR SERIES	COOLING AIRFLOW (CFM)	
58SB0A	045	E	17	-	-	12	

#### TRAINING

My Learning Center is your central location for professional residential HVAC training resources that help strengthen careers and businesses. We believe in providing high quality learning experiences both online and in the classroom.

Access My Learning Center with your HVACpartners credentials at www.mlctraining.com. Please contact us a mylearning@carrier.com with questions.

#### WARNING Ą

#### FIRE, EXPLOSION, ELECTRICAL SHOCK AND CARBON MONOXIDE POISONING HAZARD

Failure to follow this warning could result in dangerous operation, personal injury, death or property damage.

Improper installation, adjustment, alteration, service, or maintenance can cause personal injury, property damage, or death. Consult a qualified installer, service agency, or your local gas supplier for information or assistance. The qualified installer or service agency must use only factory-authorized replacement parts, kits, or accessories when modifying this product.

58SB0A/58SB1A: Installation, Start–Up, Operating and Service and Maintenance Instructions