# 675C--B Legacy™13.4 SEER2 Single-Packaged HYBRID HEAT® Dual Fuel System with Puron Advance™ (R-454B) Refrigerant Single Phase 2-5 Nominal Tons (Sizes 24-60)



# **Installation Instructions**

**IMPORTANT:** Effective January 1, 2023, all split system and packaged air conditioners must be installed pursuant to applicable regional efficiency standards issued by the Department of Energy.

**NOTE:** Read the entire instruction manual before starting the installation.

**NOTE:** Installer: Make sure the Owner's Manual and Service Instructions are left with the unit after installation.

#### **Table of Contents**

Safety Considerations 1
Introduction
Receiving and Installation2
Pre-Start-up
Start-up
Maintenance
Troubleshooting
Start-up Checklist 37



Fig. 1 – Unit 675C

A09033

# **Safety Considerations**

This unit is equipped with electrically powered safety measures. For the safety measures to be effective, the unit must be electrically powered at all times after installation, other than when servicing.

# • WARNING

# PERSONAL INJURY AND PROPERTY DAMAGE HAZARD

Continuous fan mode required for proper functioning. Installation must meet the Required Minimum Dissipation Airflow as outlined in the **Leak Dissipation System** section. Follow instructions in the Continuous Fan Speed Set-Up section to change speeds.

Improper installation, adjustment, alteration, service maintenance, or use can cause explosion, fire, electrical shock, or other conditions which

may cause death, personal injury, or property damage. Consult a qualified installer, service agency, or your distributor or branch for information or assistance. The qualified installer or agency must use factory-authorized kits or accessories when modifying this product. Refer to the individual instructions packaged with the kits or accessories when installing.

# WARNING

# PERSONAL INJURY AND PROPERTY DAMAGE HAZARD

For continued performance, reliability, and safety, the only approved accessories and replacement parts are those specified by the equipment manufacturer. The use of non-manufacturer approved parts and accessories could invalidate the equipment limited warranty and result in fire risk, equipment malfunction, and failure. Please review manufacturer's instructions and replacement part catalogs available from your equipment supplier.

Auxiliary devices which may be a POTENTIAL IGNITION SOURCE shall not be installed in the duct work. Examples of such POTENTIAL IGNITION SOURCES are hot surfaces with a temperature exceeding 1292°F (700°C) and electric switching devices.

Electrostatic air purifiers installed in the ductwork are permitted, if the purifier has an airflow sensor.

False ceilings or drop ceilings must not be used as a return air duct/plenum.

This self-contained unit is already charged with refrigerant for optimum performance, and shouldn't require any adjustments. Should any installation/service work on the A2L refrigerant system be needed, non-sparking tools are required. If the refrigerant system is opened, a refrigerant detector should be used to check for leaks. Open flames or other ignition sources should not be present, except during brazing. Brazing should only take place on refrigerant tubes that are open to the atmosphere or have been properly evacuated.

Follow all safety codes. Wear safety glasses, protective clothing, and work gloves. Have a fire extinguisher available. Read these instructions thoroughly and follow all warnings or cautions included in literature and attached to the unit. Consult local building codes, the current editions of the National Fuel Gas Code (NFGC) NFPA 54/ANSI Z223.1, and the National Electrical Code (NEC) NFPA 70.

In Canada refer to the current editions of the National Standards of Canada CAN/CSA-B149.1 and .2 Natural Gas and Propane Installation codes, and Canadian Electrical Code CSA C22.1

Recognize safety information. This is the safety-alert symbol  $\triangle$ . When you see this symbol on the unit and in instructions or manuals, be alert to the potential for personal injury. Understand these signal words: DANGER, WARNING, and CAUTION. These words are used with the safety-alert symbol. DANGER identifies the most serious hazards which will result in severe personal injury or death. WARNING signifies hazards which could result in personal injury or death. CAUTION is

used to identify unsafe practices which may result in minor personal injury or product and property damage. NOTE is used to highlight suggestions which will result in enhanced installation, reliability, or operation.

# WARNING

#### CARBON MONOXIDE POISONING HAZARD

Failure to follow this warning could result in personal injury and/or death.

Carbon Monoxide (CO) is a colorless, odorless, and tasteless poisonous gas that can be fatal when inhaled. Follow all installation, maintenance, and service instructions. See additional information below regarding the installation of a CO Alarm.

Most states is the USA and jurisdictions in Canada have laws that require the use of Carbon Monoxide (CO) alarms with fuel burning products. Examples of fuel burning products are furnaces, boilers, space heaters, generators, water heaters, stoves/ranges, clothes dryers, fireplaces, incinerators, automobiles, and other internal combustion engines. Even if there are no laws in your jurisdiction requiring a CO Alarm, it's highly recommended that whenever any fuel burning product is used in or around the home or business that the dwelling be equipped with a CO Alarm(s). The Consumer Product Safety Commission recommends the use of CO Alarm(s). The CO Alarm(s) must be installed, operated, and maintained according to the CO Alarm manufacturer's instructions. For more information about Carbon Monoxide, local laws, or to purchase a CO Alarm only, please visit the following website https://www.kidde.com

# **WARNING**

### ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death. Before installing or servicing system, always turn off main power to system and install lockout tag. There may be more than one disconnect switch. Turn off accessory heater power switch if applicable.

# WARNING

# FIRE, EXPLOSION, ELECTRICAL SHOCK AND CARBON MONOXIDE POISONING HAZARD

Failure to follow this warning could result in personal injury, death or property damage.

A qualified installer or agency must use only factory-authorized kits or accessories when modifying this product.

# ! WARNING

### CUT HAZARD

Failure to follow this caution may result in personal injury.

When removing access panels (see Fig. 24) or performing maintenance functions inside your unit, be aware of sharp sheet metal parts and screws. Although special care is taken to reduce sharp edges to a minimum, be extremely careful and wear appropriate protective clothing, safety glasses and gloves when handling parts or reaching into the unit.

# WARNING

# PERSONAL INJURY AND PROPERTY DAMAGE HAZARD

For continued performance, reliability, and safety, the only approved accessories and replacement parts are those specified by the equipment manufacturer. The use of non-manufacturer approved parts and accessories could invalidate the equipment limited warranty and result in fire risk, equipment malfunction, and failure. Please review manufacturer's instructions and replacement part catalogs available from your equipment supplier.



#### FIRE, INJURY, OR DEATH HAZARD

Failure to follow this warning could result in property damage, personal injury, or death.

This unit was manufactured to operate with natural gas. When fuel supply is liquid propane gas (LP), this unit MUST be converted with a factory approved LP conversion kit. See rating plate for approved conversion kits.

### Introduction

This unit (see Fig. 1) is a fully self-contained, combination Category I gas heating/electric heating and cooling unit designed for outdoor installation (See Fig. 2 and Fig. 3 for unit dimensions). All unit sizes have return and discharge openings for both horizontal and downflow configurations, and are factory shipped with all downflow duct openings covered. Units may be installed either on a rooftop, a cement slab, or directly on the ground, if local codes permit (See Fig. 4 for roof curb dimensions).

In gas heating mode, this unit is designed for a minimum continuous return-air temperature of 55°F (13°C) db and a maximum continuous return-air temperature of 80°F (27°C) db. Failure to follow these return-air temperature limits may affect reliability of heat exchangers, motors, and other components.

Models with an N in the fifth position of the model number are dedicated Low NOx units designed for California installations. These models meet the California maximum oxides of nitrogen (NOx) emissions requirements of 40 nanograms/joule or less as shipped from the factory and must be installed in California Air Quality Management Districts or any other regions in North America where a Low NOx rule exists.

# NOTICE

If the unit gasketing or insulation must be replaced, ensure the material used is compliant with the two agency requirements listed.

- 1. Insulation and adhesives shall meet NFPA 90.1 requirements for flame spread and smoke generation.
- 2. Cabinet insulation shall meet ASHRAE Standard 62.2.

# Receiving and Installation Transport and Storage Considerations

This unit employs Puron Advance (R-454B) refrigerant, which is flammable. Regulations may exist with respect to the transportation of this unit, including number of units and the configuration of the equipment in the load transported. Storage of unit should be in accordance with applicable regulations or instructions, whichever is more stringent. This includes the number of units that may be stored together. For disposal of unit, refer to national regulations, and follow the Decommissioning section in this manual.

### Step 1 – Check Equipment Identify Unit

The unit model number and serial number are stamped on the unit information plate. Check this information against shipping papers.

#### **Inspect shipment**

Inspect for shipping damage before removing packaging materials. If unit appears to be damaged or is torn loose from its anchorage, have it examined by transportation inspectors before removal. Forward claim papers directly to transportation company. Manufacturer is not responsible for any damage incurred in transit. Check all items against shipping list. Immediately notify the nearest equipment distribution office if any item is missing. To prevent loss or damage, leave all parts in original packages until installation.

If the unit is to be mounted on a curb in a downflow application, review Step 9 to determine which method is to be used to remove the downflow panels before rigging and lifting into place. The panel removal process may require the unit to be on the ground.

### Step 2 – Provide Unit Support

For hurricane tie downs, contact distributor for details and PE (Professional Engineering) Certificate if required.

### **Roof Curb**

Install accessory roof curb in accordance with instructions shipped with curb (See Fig. 4). Install insulation, cant strips, roofing, and flashing. Ductwork must be attached to curb.

**IMPORTANT:** The gasketing of the unit to the roof curb is critical for a water tight seal. Install gasketing material supplied with the roof curb. Improperly applied gasketing also can result in air leaks and poor unit performance.

Curb should be level to within 1/4 in. (6 mm). This is necessary for unit drain to function properly. Refer to accessory roof curb installation instructions for additional information as required.

Installation on older "G" series roof curbs.

Two accessory kits are available to aid in installing a new "G" series unit on an old "G" roof curb.

- 1. Accessory kit number CPADCURB001A00, (small chassis) and accessory kit number CPADCURB002A00, (large chassis) includes roof curb adapter and gaskets for the perimeter seal and duct openings. No additional modifications to the curb are required when using this kit.
- 2. An alternative to the adapter curb is to modify the existing curb by removing the outer horizontal flange and use accessory kit number CPGSKTKIT001A00 which includes spacer blocks (for easy alignment to existing curb) and gaskets for the perimeter seal and duct openings. This kit is used when existing curb is modified by removing outer horizontal flange.

# CAUTION

### UNIT/STRUCTURAL DAMAGE HAZARD

Failure to follow this caution may result in property damage.

Ensure there is sufficient clearance for saw blade when cutting the outer horizontal flange of the roof curb so there is no damage to the roof or flashing.



Fig. 2 – 24-30 Unit Dimensions

4

A240012

SD5989-4



Fig. 3 – 36-60 Unit Dimensions

A240013



A180216

UNIT SIZE	CATALOG NUMBER	A IN. (mm)	B IN. (mm)*	C IN. (mm)	D IN. (mm)	E IN. (mm)	F IN. (mm)	G IN. (mm)	H IN. (mm)
Small	CPRFCURB011B00	14 (356)	10 (254)	16 (406)	47 8 (1214)	32.4 (822)	27(69)	30.6 (778)	46 1 (1170)
Large	CPRFCURB013B00	14 (356)	14 (356)	10 (400)	47.0 (1214)	43.9 (1116)	2.7 (00)	42.2 (1072)	40.1 (1170)

NOTES:

1.Roof curb must be set up for unit being installed.

2.Seal strip must be applied, as required, to unit being installed.

3.Roof curb is made of 16-gauge steel.

4. Attach ductwork to curb (flanges of duct rest on curb).

5.Insulated panels: 1-in. (25.4 mm) thick fiberglass 1 lb. density.

**IMPORTANT:** Do not install large base pan units onto the small base pan (common curb). The center of gravity on a large base pan unit could overhang the curb causing an unsafe condition. Before installing any large base pan unit onto the common curb, check the "Y" distance in the product literature dimensional drawing to ensure that "Y" is greater than 14 in. (356 mm). Do not install any large base pan unit onto the common curb with a "Y" dimension (center of gravity) less than 14 in. (356 mm).

Fig. 4 - Roof Curb Dimensions

# CAUTION - NOTICE TO RIGGERS PRUDENCE - AVIS AUX MANIPULATEUR ACCESS PANELS MUST BE IN PLACEWHEN RIGGING.

ACCESS PANELS MUST BE IN PLACEWHEN RIGGING. PANNEAUX D'ACCES DOIT ÊTRE EN PLACE POUR MANIPULATION.

Use top skid as spreader bar. / Utiliser la palette du haut comme barre de répartition



Unit	2	4	3	0	Unit	36		42		48		60	
Onic	lb	kg	lb	kg	Offic	lb	kg	lb	kg	lb	kg	lb	kg
Rigging Weight	388	176	406	184	Rigging Weight	464	206	481	218	477	216	519	235

NOTE: See dimensional drawing for corner weight distribution.

#### Fig. 5 – Suggested Rigging

### Slab Mount

Place the unit on a solid, level pad that is at least 2 in. (51 mm) above grade. The pad should extend approximately 2 in. (51 mm) beyond the casing on all 4 sides of the unit. Do not secure the unit to the pad except when required by local codes.

### Step 3 – Field Fabricate Ductwork

Secure all ducts to roof curb and building structure on vertical discharge units. Do not connect ductwork to unit. For horizontal applications, unit is provided with flanges on the horizontal openings. All ductwork should be secured to the flanges. Insulate and weatherproof all external ductwork, joints, and roof openings with counter flashing and mastic in accordance with applicable codes.

Ducts passing through an unconditioned space must be insulated and covered with a vapor barrier.

If a plenum return is used on a vertical unit, the return should be ducted through the roof deck to comply with applicable fire codes.

Read unit rating plate for any required clearances around ductwork. Cabinet return-air static shall not exceed -.25 IN. W.C.

#### Step 4 – Provide Clearances

The required minimum operating and service clearances are shown in Fig. 2 and Fig. 3.

**IMPORTANT:** Do not restrict outdoor airflow. An air restriction at either the outdoor-air inlet or the fan discharge may be detrimental to compressor life.

The condenser fan pulls air through the condenser coil and discharges it through the top grille. Be sure that the fan discharge does not recirculate to the condenser coil. Do not locate the unit in either a corner or under an overhead obstruction. The minimum clearance under a partial overhang (such as a normal house overhang) is 48-in. (1219 mm) above the unit top. The maximum horizontal extension of a partial overhang must not exceed 48-in. (1219 mm).

Do not place the unit where water, ice, or snow from an overhang or roof will damage or flood the unit. Do not install the unit on carpeting or other combustible materials. The unit may be installed on wood flooring or on Class A, B, or C roof covering materials.

A09051

## Step 5 – Rig and Place Unit



PERSONAL INJURY OR PROPERTY DAMAGE HAZARD

Failure to follow this warning could result in personal injury, death or property damage.

When installing the unit on a rooftop, be sure the roof will support the additional weight. Locate unit such that incidental contact with flue hood is avoided.

Rigging and handling of this equipment can be hazardous for many reasons due to the installation location (roofs, elevated structures, etc.).

Only trained, qualified crane operators and ground support staff should handle and install this equipment.

When working with this equipment, observe precautions in the literature, on tags, stickers, and labels attached to the equipment, and any other safety precautions that might apply.

Training for operators of the lifting equipment should include, but not be limited to, the following:

- 1. Application of the lifter to the load, and adjustment of the lifts to adapt to various sizes or kinds of loads.
- 2. Instruction in any special operation or precaution.
- 3. Condition of the load as it relates to operation of the lifting kit, such as balance, temperature, etc.

Follow all applicable safety codes. Wear safety shoes and work gloves.

### Inspection

Prior to initial use, and at monthly intervals, all rigging shackles, clevis pins, and straps should be visually inspected for any damage, evidence of wear, structural deformation, or cracks. Particular attention should be paid to excessive wear at hoist hooking points and load support areas. Materials showing any kind of wear in these areas must not be used and should be discarded.

# WARNING

### UNIT FALLING HAZARD

Failure to follow this warning could result in personal injury or death. Never stand beneath rigged units or lift over people.

# WARNING

### PROPERTY DAMAGE HAZARD

Failure to follow this warning could result in personal injury/death or property damage.

When straps are taut, the clevis should be a minimum of 36 in. (914 mm) above the unit top cover.

# Rigging/Lifting of Unit (See Fig. 5)

Lifting holes are provided in base rails as shown in Fig. 2 and Fig. 3.

- 1. Leave top shipping skid on the unit for use as a spreader bar to prevent the rigging straps from damaging the unit. If the skid is not available, use a spreader bar of sufficient length to protect the unit from damage.
- 2. Attach shackles, clevis pins, and straps to the base rails of the unit. Be sure materials are rated to hold the weight of the unit (See Fig. 5).
- 3. Attach a clevis of sufficient strength in the middle of the straps. Adjust the clevis location to ensure unit is lifted level with the ground.

After the unit is placed on the roof curb or mounting pad, remove the top skid.

# Step 6 – Connect Condensate Drain

**NOTE:** When installing condensate drain connection be sure to comply with local codes and restrictions.

Unit disposes of condensate water through a 3/4 in. NPT fitting which exits through the compressor access panel (See Fig. 2 and Fig. 3 for location).

Condensate water can be drained directly onto the roof in rooftop installations (where permitted) or onto a gravel apron in ground level installations. Install a field-supplied condensate trap at end of condensate connection to ensure proper drainage. Make sure that the outlet of the trap is at least 1 in. (25 mm) lower than the drain-pan condensate connection to prevent the pan from overflowing (See Fig. 6). Prime the trap with water. When using a gravel apron, make sure it slopes away from the unit.

If the installation requires draining the condensate water away from the unit, install a 2-in. (51 mm) trap at the condensate connection to ensure proper drainage (See Fig. 6). Make sure that the outlet of the trap is at least 1 in. (25 mm) lower than the drain-pan condensate connection. This prevents the pan from overflowing.

Prime the trap with water. Connect a drain tube - using a minimum of 3/4-in. PVC or 3/4-in. copper pipe (all field-supplied) - at the outlet end of the 2-in. (51 mm) trap. Do not undersize the tube. Pitch the drain tube downward at a slope of at least 1-in. (25 mm) for every 10 ft (3 m) of horizontal run. Be sure to check the drain tube for leaks.



# Step 7 – Install Flue Hood

The flue assembly is secured and shipped in the return air duct. Remove duct cover to locate the assembly (See Fig. 8).

**NOTE:** Dedicated low NOx models MUST be installed in California Air Quality Management Districts where a Low NOx rule exists.

These models meet the California maximum oxides of nitrogen (NOx) emissions requirements of 40 nanograms/joule or less as shipped from the factory.

NOTE: Low NOx requirements apply only to natural gas installations.



#### CARBON MONOXIDE POISONING HAZARD

Failure to follow this warning could result in personal injury or death. The venting system is designed to ensure proper venting. The flue hood assembly must be installed as indicted in this section of the unit installation instructions.

Install the flue hood as follows:

- 1. This installation must conform with local building codes and with the National Fuel Gas Code (NFGC) NFPA 54 / ANSI Z223.1, (in Canada, CAN/CSA B149.1, and B149.2) latest revision. Refer to Provincial and local plumbing or wastewater codes and other applicable local codes.
- Remove flue hood from shipping location (inside the return section of the blower compartment-see Fig. 8). Remove the return duct cover to locate the flue hood. Place flue hood assembly over flue panel. Orient screw holes in flue hood with holes in the flue panel.
- 3. Secure flue hood to flue panel by inserting a single screw on the top flange and the bottom flange of the hood.

### Step 8 – Install Gas Piping

The gas supply pipe enters the unit through the access hole provided. The gas connection to the unit is made to the 1/2-in. (12.7 mm) FPT gas inlet on the gas valve.

Install a gas supply line that runs to the heating section. Refer to Table 2 and the NFGC for gas pipe sizing. Do not use cast-iron pipe. It is recommended that a black iron pipe is used. Check the local utility for recommendations concerning existing lines. Size gas supply piping for 0.5 IN. W.C. maximum pressure drop. Never use pipe smaller than the 1/2-in. (12.7 mm) FPT gas inlet on the unit gas valve.

For natural gas applications, the gas pressure at unit gas connection must not be less than 4.0 IN. W.C. or greater than 13 IN. W.C. while the unit is operating. For propane applications, the gas pressure must not be less than 11.0 IN. W.C. or greater than 13 IN. W.C. at the unit connection.

A 1/8-in. (3.2 mm) NPT plugged tapping, accessible for test gauge connection, must be installed immediately upstream of the gas supply connection to the gas valve.

8

When installing the gas supply line, observe local codes pertaining to gas pipe installations. Refer to the NFGC NFPA 54/ANSI Z223.1 latest edition (in Canada, CAN/CSA B149.1).

**NOTE:** In the state of Massachusetts:

- 1. Gas supply connections MUST be performed by a licensed plumber or gas fitter.
- 2. When flexible connectors are used, the maximum length shall not exceed 36 in. (915 mm).
- 3. When lever handle type manual equipment shutoff valves are used, they shall be T-handle valves.
- 4. The use of copper tubing for gas piping is NOT approved by the state of Massachusetts.

In the absence of local building codes, adhere to the following pertinent recommendations:

- 1. Avoid low spots in long runs of pipe. Grade all pipe 1/4 in. (6.35 mm) for every 15 ft (4.6 m) of length to prevent traps. Grade all horizontal runs downward to risers. Use risers to connect to heating section and to meter.
- 2. Protect all segments of piping system against physical and thermal damage. Support all piping with appropriate straps, hangers, etc. Use a minimum of one hanger every 6 ft (1.8 m). For pipe sizes larger than 1/2 in., (12.7 mm) follow recommendations of national codes.
- 3. Apply joint compound (pipe dope) sparingly and only to male threads of joint when making pipe connections. Use only pipe dope that is resistant to action of liquefied petroleum gases as specified by local and/or national codes. Never use Teflon tape.
- 4. Install sediment trap in riser leading to heating section (See Fig. 7). This drip leg functions as a trap for dirt and condensate.



Fig. 7 – Sediment Trap

C99020

- 5. Install an accessible, external, manual main shutoff valve in gas supply pipe within 6 ft (1.8 m) of heating section.
- 6. Install ground-joint union close to heating section between unit manual shutoff and external manual main shut-off valve.
- 7. Pressure test all gas piping in accordance with local and national plumbing and gas codes before connecting piping to unit.

**NOTE:** Pressure test the gas supply system after the gas supply piping is connected to the gas valve. The supply piping must be disconnected from the gas valve during the testing of the piping systems when test pressure is in excess of 0.5 psig. Pressure test the gas supply piping system at pressures equal to or less than 0.5 psig. The unit heating section must be isolated from the gas piping system by closing the external main manual shutoff valve and slightly opening the ground-joint union.

# **WARNING**

### FIRE OR EXPLOSION HAZARD

Failure to follow this warning could result in personal injury, death and/or property damage.

- Connect gas pipe to unit using a backup wrench to avoid damaging gas controls.
- Never purge a gas line into a combustion chamber. Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections. A fire or explosion may result causing property damage, personal injury or loss of life.
- Use proper length of pipe to avoid stress on gas control manifold.
- If a flexible connector is required or allowed by authority having jurisdiction, black iron pipe shall be installed at furnace gas valve and extend a minimum of 2 in. (51 mm) outside furnace casing.
- If codes allow a flexible connector, always use a new connector. do not use a connector which has previously serviced another gas appliance.
- 8. Check for gas leaks at the field-installed and factory-installed gas lines after all piping connections have been completed. Use a commercially available soap solution made specifically for the detection of leaks (or method specified by local codes and/or regulations).

# Step 9 – Install Duct Connections

The unit has duct flanges on the supply- and return-air openings on the side and bottom of the unit. For downshot applications, the ductwork connects to the roof curb (See Fig. 2 and Fig. 3 for connection sizes and locations).

# Configuring Units for Downflow (Vertical) Discharge

# WARNING

### ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death. Before installing or servicing system, always turn off main power to system and install lockout tag. There may be more than one disconnect switch.

- 1. Open all electrical disconnects before starting any service work.
- 2. Remove horizontal (metal) duct covers to access vertical (downflow) discharge duct knockouts in unit basepan. (See Fig. 8.)



# PROPERTY DAMAGE HAZARD

Failure to follow this caution may result in property damage. Collect ALL screws that were removed. Do not leave screws on rooftop as permanent damage to the roof may occur.

3. For single-phase models only, on the discharge side only, remove the insulation covering the downshot (plastic) knockout. Insulation is held in place with aluminum tape. Please note that large chassis units have 2 pieces of insulation, and only the piece over the downshot knockout needs to be removed. Discard insulation.

- 4. To remove the downshot (plastic) knockouts for both supply and returns, break front and right side connecting tabs with a screwdriver and hammer. Push cover down to break rear and left side tabs. These plastic knockouts are held in place with tabs similar to an electrical knockout. Discard plastic knockout covers.
- 5. Set unit on roof curb.
- 6. Verify that the downshot ducts are aligned with the downshot knockout areas.
- 7. Re-install horizontal (metal) covers as needed to seal unit. Ensure opensings are air and watertight.

**NOTE:** The design and installation of the duct system must be in accordance with the standards of the NFPA for installation of nonresidence-type air conditioning and ventilating systems, NFPA 90A or residence-type, NFPA 90B; and/or local codes and ordinances.

Adhere to the following criteria when selecting, sizing, and installing the duct system:

- 1. Units are shipped for horizontal duct installation (by removing duct covers).
- 2. Select and size ductwork, supply-air registers, and return-air grilles according to American Society of Heating, Refrigeration and Air Conditioning Engineers (ASHRAE) recommendations.
- 3. Use flexible transition between rigid ductwork and unit to prevent transmission of vibration. The transition may be screwed or bolted to duct flanges. Use suitable gaskets to ensure weather tight and airtight seal.
- 4. All units must have field-supplied filters or accessory filter rack installed in the return-air side of the unit. Recommended sizes for filters are shown in Table 1.
- 5. Size all ductwork for maximum required airflow (either heating or cooling) for unit being installed. Avoid abrupt duct size increases or decreases or performance may be affected.

- 6. Adequately insulate and weatherproof all ductwork located outdoors. Insulate ducts passing through unconditioned space, and use vapor barrier in accordance with latest issue of Sheet Metal and Air Conditioning Contractors National Association (SMACNA) and Air Conditioning Contractors of America (ACCA) minimum installation standards for heating and air conditioning systems. Secure all ducts to building structure.
- 7. Flash, weatherproof, and vibration-isolate all openings in building structure in accordance with local codes and good building practices.







A09076

Fig. 8 – Supply and Return Duct Opening

Manufacturer reserves the right to change, at any time, specifications and designs without notice and without obligations.

Unit Size	24060	30060	36090	42090			
Nominal Capacity - ton	2	2.5	3	3.5			
Shipping Weight (Ib)	388	406	464	481			
Shipping Weight (kg)	176	184	206	218			
Compressor / Quantity	Scroll / 1						
Refrigerant		R-4	454B				
Refrigerant Quantity (lb)	8.0	10.25	7.5	8.0			
Refrigerant Quantity (kg)	3.6	4.7	3.4	3.6			
Refrigerant Metering Device		Indoor TXV, Outd	oor Dual Accuraters				
Minimum Conditioned Space Area (sq. ft.)	122	167	122	122			
Orifice OD (in)	0.032 (2)	0.035 (2)	0.040 (2)	0.046 (2)			
Orifice OD (mm)	0.81 (2)	0.89 (2)	1.02 (2)	1.17 (2)			
Outdoor Coil							
Rows… Fins/in,	121	221	121	121			
Face Area (sq. ft.)	18.8	18.8	23.3	23.3			
Outdoor Fan							
Nominal Airflow (cfm)	3000	3200	3500	3500			
Diameter (in.)	24	24	26	26			
Diameter (mm)	610	610	660	660			
Motor hp (rpm)	1/10 (810)	1/5 (810)	1/5 (810)	1/5 (810)			
Indoor Coil							
Rows… Fins/in,	315	317	317	317			
face area (sq. ft.)	3.7	3.7	4.7	4.7			
Indoor Blower	213	293	213	213			
Required Minimum Dissipation Airflow (CFM)	750	950	1150	1350			
Nominal Airflow (CFM)	10 x 10	10 x 10	11 x 10	11 x 10			
Size (in.)	254 x 254	254 x 254	279 x 254	279 x 254			
Size (mm)	1/2	1/2	1/2	3/4			
Motor hp	172	172		0/1			
Furnace Section <sup>*</sup>							
Burner Orifice							
1-Phase Natural Gas Qty…Drill Size	344	344	338	338			
1-Phase Propane Gas Qty…Drill Size	355	355	353	353			
High Pressure Switch (psig)		650	+/- 15				
Cutout	it 420 +/- 25						
Reset (Auto)		420	11-20				
Loss-of-Charge/Low Pressure Switch (psig)	Low Pressure Switch (psig) 20 ±/- 5						
Cutout	45 +/- 10						
Reset (Auto)	45 +/- 10						
	1 each 24x16x1 in						
Return Air Filters <sup>†‡</sup>	2 each 20	0x12x1 in.	610x40	6x25 mm			
disposable	508x305	5x25 mm	24x1	4x1 in.			
			610x356x25 mm				

Table 1 – Physical Data

\*. Based on altitude of 0 to 2000 ft (0-610 m).

Required filter sizes shown are based on the larger of the AHRI (Air Conditioning Heating and Refrigeration Institute) rated cooling airflow or the heating airflow velocity of 300 to 350 ft/minute for high-capacity type. Air filter pressure drop for non-standard filters must not exceed 0.08 IN. W.C. If using accessory filter rack refer to filter rack installation instructions for correct filter size and quantity. **†**.

‡.

	Table 1 – Phy	ysical Data Cont'd)				
Unit Size	48090	48115	60115	60130		
Nominal Capacity - ton	4	4	5	5		
Shipping Weight (Ib)	477	477	519	519		
Shipping Weight (kg)	216	216	235	235		
Compressor / Quantity	<u>"</u>	Sci	roll / 1			
Refrigerant		R-	410A			
Refrigerant Quantity (lb)	8.	75	12	2.0		
Refrigerant Quantity (kg)	4.	0	5	.4		
Refrigerant Metering Device	Indoo Outdoor Dua	r TXV al Accuraters	Indoo Outdoor Du	r TXV, al Accuraters		
Minimum Conditioned Space Area (sq. ft.)	13	37	18	32		
Orifice ID (in) Orifice ID (mm)	N	Ά	N	/Α		
Orifice OD (in)	0.04	6 (2)	0.04	6 (2)		
Orifice OD (mm)	1.17	(2)	1.1	7(2)		
Outdoor Coil						
Rows Fins/in,	2	.21	2	.21		
Face Area (sq. ft.)	13	.6	17	7.5		
Outdoor Fan						
Nominal Airflow (CFM)	35	00	3500			
Diameter (in.)	2	6	26			
Diameter (mm)	66	60	6	50		
Motor hp	1/	/5	1/5			
Motor (rpm)	(81	0)	(810)			
Indoor Coil						
Rows Fins/in,		3	17			
face area (sq. ft.)			5.6			
Indoor Blower	0	20		10		
Required Minimum Dissipation Airliow (cim)	23	00 99	3	19		
Size (in )	10	00 / 10	1750 11 × 10			
Size (mm)	270 \	254	279 x 254			
Motor hp	2107		210	1		
Europa Section*		·				
Burner Orifice						
1 Phase Natural Gas Otv Drill Size	3 38	3 33	3 33	3 31		
1 Phase Propane Gas Qtv Drill Size	3 53	3 51	3 51	3 49		
High Pressure Switch (psig)	011100	001	001	010		
Cutout		650	+/- 15			
Reset (Auto)	420 +/- 25					
Loss-of-Charge/Low Pressure		-				
Switch (psig)						
Cutout		20	+/- 5			
Reset (Auto)		45	+/- 10			
Return Air Filters <sup>†</sup> <sup>‡</sup>		1 each 24x16	x1 (610x406x25)			
disposable		24x18x1 (	610x457x25)			

\*. \*Based on altitude of 0 to 2000 ft (0-610 m).

t. Required filter sizes shown are based on the larger of the AHRI (Air Conditioning Heating and Refrigeration Institute) rated cooling airflow or the heating airflow velocity of

300 to 350 fl/minute for high-capacity type. Air filter pressure drop for non-standard filters must not exceed 0.08 IN. W.C.

‡. If using accessory filter rack refer to filter rack installation instructions for correct filter size and quantity.

							um Gas	FIOW Ca	ipacity						
NOMINAL	INTERNAL		LENGTH OF PIPE, FT (m) <sup>†</sup>												
IRON PIPE,	DIAMETER	10	20	30	40	50	60	70	80	90	100	125	150	175	200
SIZE (IN.)	(IN.)	(3.0)	(6.1)	(9.1)	(12.2)	(15.2)	(18.3)	(21.3)	(24.4)	(27.4)	(30.5)	(31.1)	(45.7)	(53.3)	(61.0)
1/2	.622	175	120	97	82	73	66	61	57	53	50	44	40		—
3/4	.824	360	250	200	170	151	138	125	118	110	103	93	84	77	72
1	1.049	680	465	375	320	285	260	240	220	205	195	175	160	145	135
1-1/4	1.380	1400	950	770	600	580	530	490	460	430	400	360	325	300	280
1-1/2	1.610	2100	1460	1180	990	900	810	750	690	650	620	550	500	460	430

Table 2 – Maximum Gas Flow Capacity\*

\*. Capacity of pipe in cu ft of gas per hr for gas pressure of 0.5 psig or less. Pressure drop of 0.5-IN. W.C. (based on a 0.60 specific gravity gas). Refer to Table 2 and the NFGC NFPA 54/ANSI Z 223.1.

†. his length includes an ordinary number of fittings

#### 12

				01			
			GAS SUPPLY PR	MANIFOLD PRESSURE			
(BTUH)		Natural <sup>*</sup>		Prop	ane <sup>†</sup> *	(IN. W.C.)	
			Max	Min	Max	Natural{	Propane*†
60,000	3	4.0	13.0	11.0	13.0	3.2~3.8	10.0~11.0
90,000	3	4.5	13.0	11.0	13.0	3.2~3.8	10.0~11.0
115,000	3	4.5	13.0	11.0	13.0	3.2~3.8	10.0~11.0
130,000	3	4.5	13.0	11.0	13.0	3.2~3.8	10.0~11.0

# Table 3 – Heating Inputs

. Based on altitudes from sea level to 2000 ft (610 m) above sea level. In the U.S.A. for altitudes above 2000 ft (610 m), reduce input rating 4 percent for each additional 1000 ft (305 m) above sea level. In Canada, from 2000 ft (610 m) above sea level to 4500 ft (1372 m) above sea level, derate the unit 10 percent.

When a unit is converted to propane, different size orifices must be used. See separate, natural-to-propane conversion kit instructions.

# Step 10 – Install Electrical Connections

# ! WARNING

# ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death. The unit cabinet must have an uninterrupted, unbroken electrical ground. This ground may consist of an electrical wire connected to the unit ground screw in the control compartment, or conduit approved for electrical ground when installed in accordance with NEC, NFPA 70 National Fire Protection Association (latest edition) (in Canada, Canadian Electrical Code CSA C22.1) and local electrical codes.

# CAUTION

### UNIT COMPONENT DAMAGE HAZARD

Failure to follow this caution may result in damage to the unit being installed.

- Make all electrical connections in accordance with NEC NFPA 70 (latest edition) and local electrical codes governing such wiring. In Canada, all electrical connections must be in accordance with CSA standard C22.1 Canadian Electrical Code Part 1 and applicable local codes. Refer to unit wiring diagram.
- Use only copper conductor for connections between field-supplied electrical disconnect switch and unit. DO NOT USE ALUMINUM WIRE.
- 3. Be sure that high-voltage power to unit is within operating voltage range indicated on unit rating plate. Consult local power company for correction of improper voltage and/or phase imbalance.
- 4. Insulate low-voltage wires for highest voltage contained within conduit when low-voltage control wires are in same conduit as high-voltage wires.
- 5. Do not damage internal components when drilling through any panel to mount electrical hardware, conduit, etc.
- Route field power supply(s) away from areas that could be damaged by lawn and garden equipment or other accidental damage.

### High-Voltage Connections

When routing power leads into unit, use only copper wire between disconnect and unit. The high voltage leads should be in a conduit until they enter the duct panel; conduit termination at the duct panel must be watertight.

The unit must have a separate electrical service with a field-supplied, waterproof disconnect switch mounted at, or within sight from, the unit. Refer to the unit rating plate, NEC and local codes for maximum fuse/circuit breaker size and minimum circuit amps (ampacity) for wire sizing.

The field-supplied disconnect switch box may be mounted on the unit over the high-voltage inlet hole when the standard power and low-voltage entry points are used (See Fig. 2 and Fig. 3 for acceptable location).

**NOTE:** Field supplied disconnect switch box should be positioned so that it does not cover up any of the unit gas combustion supply air louvers.

See unit wiring label (Fig. 20 - Fig. 21) and Fig. 9 for reference when making high voltage connections. Proceed as follows to complete the high-voltage connections to the unit.

Single phase units:

- 1. Run the high-voltage (L1, L2) and ground lead into the control box.
- 2. Connect ground lead to chassis ground connection.
- 3. Locate the black and yellow wires connected to the line side of the contactor.
- 4. Connect field L1 to black wire on connection 11 of the compressor contactor.
- 5. Connect field wire L2 to yellow wire on connection 23 of the compressor contactor.

### Special Procedures for 208-V Operation

# WARNING

# ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death. Make sure the power supply to the unit is switched OFF before making any wiring changes. Tag the disconnect switch with a suitable warning label. With disconnect switch open, move black wire from transformer (3/16 in.) terminal marked 230 to terminal marked 200. This retaps transformer to primary voltage of 208 vac.

# WARNING

### ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death. Before making any wiring changes, make sure the gas supply is switched off first. Then switch off the power supply to the unit and install lockout tag.

# **Control Voltage Connections**

Do not use any type of power-stealing thermostat. Unit control problems may result.

Use no. 18 American Wire Gage (AWG) color-coded, insulated (35°C minimum) wires to make the control voltage connections between the thermostat and the unit. If the thermostat is located more than 100 ft (30.5 m) from the unit (as measured along the control voltage wires), use no. 16 AWG color-coded, insulated (35°C minimum) wires.

Locate the seven low voltage thermostat leads in 24 volt splice box. See Fig. 9 for connection diagram. Run the low-voltage leads from the

thermostat, through the control wiring inlet hole grommet (Fig. 2 and Fig. 3), and into the low-voltage splice box. Provide a drip loop before running wires through panel. Secure and strain relief all wires so that they do not interfere with operation of unit.





### Leak Dissipation System

This unit is equipped with the Puron Advance (R-454B) leak detection and dissipation system. This system is comprised of a refrigerant sensor, and dissipation control board.

The dissipation control board monitors the refrigerant sensor continuously. If a sufficient concentration of refrigerant is detected within the conditioned air stream, the dissipation board will remove any call for cooling or heating and energize continuous fan. Once the refrigerant concentration drops below the threshold, the dissipation board will do 3 things: 1) The continuous fan will remain on for 5 minutes, 2) Any call for cooling will still be removed, and 3) Any call for electrical resistance heat or gas heat (non-heat pump) will be allowed. If, after the 5 minute dissipation period, the refrigerant concentration remains below the threshold, the dissipation board will restore thermostat calls for cooling and blower operation.

#### Refrigerant Detection Sensor (RDS)

The refrigerant detection sensor is located in the blower compartment, near the evaporator coil (See Fig. 10 and Fig. 11).



Fig. 10 – Refrigerant Detection Sensor 24 & 30 Sizes



Refrigerant Detection Sensor (RDS)

Fig. 11 – Refrigerant Detection Sensor 36-60 Sizes

### Leak Dissipation Control Board (DSB)

The leak dissipation control board (Fig. 12) is located in the compressor compartment (Fig. 14 and Fig. 15). There are 2 LED indicators, which are viewable after removing the compressor access panel (Fig. 24). The amber LED provides system status.





Fig. 13 – Leak Dissipation Control Board Housing



Location of Leak Dissipation Control Board

Fig. 14 – Location of Leak Dissipation Control Board 24 and 30 Sizes



# Fig. 15 – Location of Leak Dissipation Control Board 36-60 Sizes Test Button

**IMPORTANT:** Press the Test Button for approximately ONE SECOND to enter Test Mode. Pressing the Test button for a longer period can possibly clear all fault code history (Table 4).

Table 4 - Dissipation	Board	<b>Test Button</b>	Functions
-----------------------	-------	--------------------	-----------

Hold Button Time (sec)	Function
1-4	Dissipation Mode for 60 sec
5-29	Display flash code history
30+	Flash code 6
3 rapid presses	Clear flash code history

A test button on the DSB may be used to verify proper dissipation system operation under each test condition listed below (Table 5). After pressing the test button, system will enter dissipation mode for 60 seconds to verify correct operation.

 Table 5 – Required Operational Checks to Ensure Proper

 Dissipation System Function

Tost #	T_Stat Call	Compressor	Indoor	Electric/Gas			
1651 #	1-Stat Call	Compressor	Fan	Heat			
Normal Operation							
1	None	Off	Off	Off			
2	Cool	On	On	Off			
3	Heat	Off	On	On			
	Dis	sipation Activa	ated				
4	None	Off	On	Off			
5	Cool	Cool Off		Off			
6	Heat	Off	On	Off			

#### **Required Minimum Dissipation Airflow**

The Required Minimum Dissipation Airflow is listed in Table 1, is based on refrigerant charge, and must be met or exceeded in Continuous Fan Mode. Refer to Table 9 for available blower speeds and the associated CFM performance.

# ! WARNING

# PERSONAL INJURY AND PROPERTY DAMAGE HAZARD

Required Minimum Dissipation Airflow must be met or exceeded with the continuous fan speed selected.

### Minimum Conditioned Space Area

The Minimum Conditioned Space Area (Table 1) is the smallest allowed area allowed to be served by this unit for proper dissipation and is based on the factory charge amount. The Minimum Conditioned Space Area must not be used in unit sizing, as the small area, will likely result in excessive short-cycling of the unit.

#### Example

A 36090 size unit will be installed in a residential home with a conditioned space of 1800 sq. ft. (Conditioned space to be served entirely by the unit). The low (blue) speed has been selected for continuous fan and runs at .6 in. W.C. external static pressure.

From Table 1, the minimum conditioned space area for the 36090 size is 122 sq. ft. Since 1800 sq. ft. is greater then 122 sq. ft., the conditioned space is sufficient.

Also from Table 1, the required minimum dissipation airflow for the 36090 size unit is 213 CFM. From Table 9, the unit is factory-shipped with continuous fan set to the low (blue) speed with an external static pressure of .6 in. W.C. is 800 CFM. Since 800 CFM is greater than 213 CFM, the low speed is sufficient to deliver the required minimum dissipation airflow.

### Balance Point Setting-Thermidistat or Hybrid Thermostat

BALANCE POINT TEMPERATURE-The "balance point" temperature is a setting which affects the operation of the heating mode. This is a field-selected input temperature (range 5 to 55°F) (-15 to 12°C) where the Thermidistat or dual fuel thermostat will monitor outdoor air temperature and decide whether to enable or disable the heat pump. If the outdoor temperature is above the "balance point", the heat pump will energize first to try to satisfy the indoor temperature demand. If the heat pump does not make a sufficient improvement within a reasonable time period (i.e. 15 minutes), then the gas furnace will come on to satisfy the indoor temperature demand. If the outdoor temperature is below the "balance point", the heat pump will not be allowed to operate (i.e. locked out), and the gas furnace will be used to satisfy the indoor temperature. There are three separate concepts which are related to selecting the final

"balance point" temperature. Read each of the following carefully to determine the best "balance point" in a hybrid installation:

- 1. Capacity Balance Temperature: This is a point where the heat pump cannot provide sufficient capacity to keep up with the indoor temperature demand because of declining outdoor temperature. At or below this point, the furnace is needed to maintain proper indoor temperature.
- 2. Economic Balance Temperature: Above this point, the heat pump is the most cost efficient to operate, and below this point the furnace is the most cost efficient to operate. This can be somewhat complicated to determine and it involves knowing the cost of gas and electricity, as well as the efficiency of the furnace and heat pump. For the most economical operation, the heat pump should operate above this temperature (assuming it has sufficient capacity) and the furnace should operate below this temperature.
- 3. Comfort Balance Temperature: When the heat pump is operating below this point, the indoor supply air feels uncomfortable (i.e. too cool). This is purely subjective and will depend on the homeowner's idea of comfort. Below this temperature the gas furnace should operate in order to satisfy the desire for indoor comfort.

#### **Transformer Protection**

The transformer is of the energy-limiting type. It is set to withstand a 30-sec. overload or shorted secondary condition. If an overload or short is present, correct overload condition and check for blown fuse on gas control board or Interface Fan Board. Replace fuse as required with correct size and rating.

### Pre-Start-up

# **WARNING**

### FIRE, EXPLOSION, ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury, death or property damage.

- 1. Follow recognized safety practices and wear protective goggles when checking or servicing refrigerant system.
- 2. Do not operate compressor or provide any electric power to unit unless compressor terminal cover is in place and secured.
- 3. Do not remove compressor terminal cover until all electrical sources are disconnected and tagged.
- Relieve and recover all refrigerant from system before touching or disturbing anything inside terminal box if refrigerant leak is suspected around compressor terminals.
- 5. Never attempt to repair soldered connection while refrigerant system is under pressure.
- Do not use torch to remove any component. System contains oil and refrigerant under pressure. To remove a component, wear protective goggles and proceed as follows:
  - a. Shut off electrical power to unit and install lockout tag.
  - b. Relieve and reclaim all refrigerant from system using both highand low-pressure ports.
  - c. Cut component connecting tubing with tubing cutter and remove component from unit.
  - d. Carefully unsweat remaining tubing stubs when necessary. Oil can ignite when exposed to torch flame.

Proceed as follows to inspect and prepare the unit for initial start-up:

- 1. Remove access panels (see Fig. 24).
- 2. Read and follow instructions on all WARNING, CAUTION, and INFORMATION labels attached to, or shipped with, unit.
- 3. Make the following inspections:

- a. Inspect for shipping and handling damages such as broken lines, loose parts, disconnected wires, etc.
- b. Inspect all field- and factory-wiring connections. Be sure that connections are completed and tight.
- c. Ensure wires do not touch refrigerant tubing or sharp sheet metal edges.
- d. Inspect coil fins. If damaged during shipping and handling, carefully straighten fins with a fin comb.

# WARNING

#### FIRE, EXPLOSION

Failure to follow this warning could result in personal injury, death or property damage.

Do not purge gas supply into the combustion chamber. Do not use a match or other open flame to check for gas leaks. Use a commercially available soap solution made specifically for the detection of leaks to check all connections. A fire or explosion may result causing property damage, personal injury or loss of life.

- 4. Verify the following conditions:
  - a. Make sure gas line is free of air. Before lighting the unit for the first time, perform the following with the gas valve in the "OFF" position:

**NOTE:** If the gas supply pipe was not purged before connecting the unit, it will be full of air. It is recommended that the ground joint union be loosened, and the supply line be allowed to purge until the odor of gas is detected. Never purge gas lines into a combustion chamber. Immediately upon detection of gas odor, retighten the union. Allow 5 minutes to elapse, then light unit.

- b. Make sure that condenser-fan blade is correctly positioned in fan orifice. Leading edge of condenser-fan blade should be 1/2 in. (12 mm) maximum from fan orifice.
- c. Make sure that air filter(s) is in place.
- d. Make sure that condensate drain trap is filled with water to ensure proper drainage.
- e. Make sure that all tools and miscellaneous loose parts have been removed.

### Start-up



#### FIRE, INJURY, OR DEATH HAZARD

Failure to follow this warning could result in property damage, personal injury, or death.

Do not bypass any of the safety controls in the unit, including but not limited to the main limit switch, rollout or burner rollout switch, and pressure switch/pressure transducer.

# Step 1 – Check for Refrigerant Leaks



#### **EXPLOSION HAZARD**

WARNING

Failure to follow this warning could result in death, serious personal injury, and/or property damage.

Never use air or gases containing oxygen for leak testing or operating refrigerant compressors. Pressurized mixtures of air or gases containing oxygen can lead to an explosion.

Work procedure for service:

- 1. All maintenance staff and others working in the local area shall be instructed on the nature of work being performed. Any nearby confined space work shall be avoided.
- 2. If any hot work is to be conducted on the refrigeration system or associated parts, a fire extinguisher shall be available on hand. A dry powder or CO2 fire extinguisher shall be located near the refrigerant charge recovery area.
- 3. Potential ignition sources, including cigarette smoking, must not be used by the technician and must be kept far away from the unit site.
- 4. Ensure that electrical power is available to run recovery equipment prior moving to the next step.
- 5. Using a R-454B leak detector, check around the area of the unit for presence of refrigerant. Note: Leak detector must be non-sparking and adequately sealed. Under no circumstances shall potential sources of ignition be used for detection of leaks, including leak detection equipment. A halide torch (or any other detector using a naked flame) shall not be used. Electronic leak detectors may be used to detect refrigerant leaks, but in the case of R-454B, the sensitivity may not be adequate or may need re-calibration (Detection equipment shall be calibrated in a refrigerant-free area). Leak detection equipment shall be calibrated to R-454B. If a leak above 20% of the LFL is found, proceed to recovery.
- 6. Shut off power to unit.
- 7. Before beginning recovery of the refrigerant:
  - a. Make sure that handling equipment is available, if needed, to handle the refrigerant recovery cylinders.
  - b. All personal protective equipment is available, and must be used correctly.
  - c. Recovery process must be performed by an EPA-certified technician.
  - d. All recovery equipment and cylinders must conform to appropriate standards and be suitable for the recovery of FLAMMABLE REFRIGERANTS (R-454B).
- Recovery process: Follow recovery process outlined in the DECOMMISIONING SECTION.
- 9. Should any installation/service work on the A2L refrigerant system be needed, non-sparking tools are required. If the refrigerant system is opened, a refrigerant detector should be used to check for leaks. Open flames or other ignition sources should not be present, except during brazing. Brazing should only take place on refrigerant tubes that are open to the atmosphere or have been properly evacuated.
- 10. Repair leak following accepted practices.
- 11. If compressor or compressor oil is to be removed, ensure that they have been evacuated to 200 microns or less to make certain that R-454B does not remain within the lubricant. The evacuation process shall be carried out prior to returning the compressor to the supplier. The crankcase electric heat may be used to accelerate the

compressor evacuation process. A torch must not be used. When oil is drained from a system, it shall be carried out safely.

**NOTE:** Install a new filter drier whenever the system has been opened for repair.

**NOTE:** Refrigerant cylinders used for charging must be kept in appropriate position and grounded to earth before charging. Hose length should be kept to a minimum. Care should be taken not to overcharge the system.

- 12. Add a small charge of Puron Advance (R-454B) refrigerant vapor to system and leak-test.
- 13. If no additional leaks are found, recover refrigerant from refrigerant system (Using Recovery steps outlined in the Decommissioning section) and evacuate to 500 microns.
- 14. Charge unit with Puron Advance (R-454B) refrigerant, using an accurate scale. Refer to unit rating plate for required charge. Do not overfill the system.
- 15. Label the system with the refrigerant charge amount.
- 16. Conduct follow-up leak test prior to leaving the job site.

### Step 2 – Unit Sequence of Operation

- a. Continuous Fan
  - (1.) Thermostat closes circuit R to G energizing the blower motor for continuous fan.
- b. Cooling Mode
  - (1.) If indoor temperature is above temperature set point thermostat closes circuits R to G, R to Y and R to O-The unit delivers cooling airflow.
- c. Heat Pump Heating Mode

Outdoor temperature above balance point setpoint of thermostat.

- (1.) On a call for heating, terminals "Y" and "G" of the Hybrid thermostat are energized. The "Y" signal is sent to the Defrost Board (DB) terminal "Y". The DB has a built in five minute anti-short cycle timer which will not allow the compressor to restart before the time delay has expired.
- (2.) "T2" energizes the compressor contactor via the High Pressure Switch (HPS) and Low Pressure Switch (LPS). The compressor and outdoor fan start. Thermostat "G" energizes the Interface Fan Board terminal "G". The blower motor is energized through contacts of the IFB.
- (3.) When the thermostat removes the "Y" and "G" calls, the compressor contactor and outdoor fan are de-energized. The evaporator motor is de-energized after a 90 sec. delay.
- d. Gas Heating Mode

Outdoor temperature below balance point setpoint of thermostat.

#### Heating Sequence of Operation (Single Phase Models)

#### (See Fig. 20 - Fig. 21 and unit wiring label)

On a call for heating, terminal W of the thermostat is energized, starting the induced-draft motor for a 5 second pre-purge. When the pressure switch senses that the induced-draft motor is moving sufficient combustion air, the burner sequence begins. This function is controlled by the integrated gas unit controller (IGC). The indoor (evaporator) –fan motor is energized 30 seconds after flame is established. When the thermostat is satisfied and W is de-energized, the burners stop firing and the indoor (evaporator) fan motor shuts off after a 90 second time-off delay. Please note that the IGC has the capability to automatically reduce the indoor fan motor on delay and increase the indoor fan motor off delay in the event of high duct static and/or a partially-clogged filter.

## Step 3 – Start-up Heating and Make Adjustments

# CAUTION

#### UNIT COMPONENT DAMAGE HAZARD

Failure to follow this caution may result in damage to the unit being installed.

Complete the required procedures given in the Pre-Start-Up section before starting the unit. Do not jumper any safety devices when operating the unit.

Complete the required procedures given in the Pre-Start-Up section before starting the unit. Do not jumper any safety devices when operating the unit. Make sure that burner orifices are properly aligned. Unstable operation my occur when the burner orifices in the manifold are misaligned.

Follow the lighting instructions on the heating section operation label (located on the inside of the control access panel) to start the heating section.

**NOTE:** Make sure that gas supply has been purged, and that all gas piping has been checked for leaks.



#### Fig. 17 – Monoport Burner

### **Check Heating Control**

Start and check the unit for proper heating control operation as follows (see furnace lighting instructions located on the inside of the control access panel):

1. Place room thermostat SYSTEM switch in the HEAT position and the fan switch is placed in AUTO position.

- 2. Set the heating temperature control of the thermostat above room temperature.
- 3. The induced-draft motor will start.
- 4. On a call for heating, the main burner should light within 5 sec. of the spark being energized. If the burners do not light, there is a 22-sec. delay before another 5-sec. try. If the burners still do not light, this sequence is repeated. If the burners do not light within 15 minutes from the initial call for heat, there is a lockout. To reset the control, break the 24-v power to W.
- 5. The evaporator fan will turn on 45 sec. after the flame has been established. The evaporator fan will turn off 45 sec. after the thermostat has been satisfied. Please note that the integrated gas unit controller (IGC) has the capability to automatically reduce the evaporator "ON" delay and increase the evaporator "OFF" delay in the event of high duct static and/or partially-clogged filter.

### Check Gas Input

Check gas input and manifold pressure after unit start-up (See Table 3). If adjustment is required proceed as follows:

• The rated gas inputs shown in Table 3 are for altitudes from sea level to 2000 ft (610 m) above sea level. These inputs are based on natural gas with a heating value of 1025 Btu/ft3 at 0.60 specific gravity, or propane gas with a heating value of 2500 Btu/ft3 at 1.5 specific gravity.

#### IN THE U.S.A.:

The input rating for altitudes above 2,000 ft (610 m) must be reduced by 4% for each 1,000 ft (305 m) above see level.

For installations below 2,000 ft (610 m), refer to the unit rating plate. For installations above 2,000 ft (610 m) multiply the input by on the rating plate by the derate multiplier in Table 6 for correct input rate.

Altitude ft (m)	Percent of Derate	Derate Multiplier Factor <sup>†</sup>
0-2000 (0-610)	0	1.00
2001-3000* (610-914)	8-12	0.90
3001-4000 (315-1219)	12-16	0.86
4001-5000 (1220-1524)	16-20	0.82
5001-6000 (1524-1829)	20-24	0.78
6001-7000 (1829-2134)	24-28	0.74
7001-8000 (2134-2438)	28-32	0.70
8001-9000 (2439-2743)	32-36	0.66
9001-10,000 (2744-3048)	36-40	0.62

Table 6 – Altitude Derate Multiplier for U.S.A.\*

\*. \* In Canada see Canadian Altitude Adjustment.

†. {Derate multiplier factors are based on midpoint altitude for altitude range.

#### IN CANADA:

The input rating for altitudes from 2,000 to 4,500 ft (610 m to 1372 m) above sea level must be derated 10% by an authorized Gas Conversion Station or Dealer.

# EXAMPLE:

90,000 Btu/hr Input Furnace Installed at 4300 ft (1311 m).

Furnace Input Rate at	v	Derate Multiplier	_	Furnace Input Rate at
Sea Level	X	Factor	=	Installation Altitude
90,000	Х	0.90	=	81,000

C99021

When the gas supply being used has a different heating value or specific gravity, refer to national and local codes, or contact your distributor to determine the required orifice size.

# **CAUTION**

#### UNIT DAMAGE HAZARD

Failure to follow this caution may result in reduced unit and/or component life.

Do Not redrill an orifice. Improper drilling (burrs, out-of-round holes, etc.) can cause excessive burner noise and misdirection of burner flame. If orifice hole appears damaged or it is suspected to have been redrilled, check orifice hole with a numbered drill bit of correct size.

#### Adjust Gas Input

The gas input to the unit is determined by measuring the gas flow at the meter or by measuring the manifold pressure. Measuring the gas flow at the meter is recommended for natural gas units. The manifold pressure must be measured to determine the input of propane gas units.

#### Measure Gas Flow (Natural Gas Units)

Minor adjustment to the gas flow can be made by changing the manifold pressure. The manifold pressure must be maintained between 3.2 and 3.8 IN. W.C.



Fig. 18 – Single-Stage Gas Valve

If larger adjustments are required, change main burner orifices following the recommendations of national and local codes.

**NOTE:** All other appliances that use the same meter must be turned off when gas flow is measured at the meter.

Proceed as follows:

- 1. Turn off gas supply to unit.
- 2. Remove pipe plug on manifold (See Fig. 16) and connect manometer. Turn on gas supply to unit.
- 3. Record number of seconds for gas meter test dial to make one revolution.
- 4. Divide number of seconds in Step 3 into 3600 (number of seconds in one hr).
- 5. Multiply result of Step 4 by the number of cubic feet (cu ft) shown for one revolution of test dial to obtain cubic feet (cu ft) of gas flow per hour.
- 6. Multiply result of Step 5 by Btu heating value of gas to obtain total measured input in Btuh. Compare this value with heating input shown in Table 3 (Consult the local gas supplier if the heating value of gas is not known).

EXAMPLE: Assume that the size of test dial is 1 cu ft, one revolution takes 32 sec, and the heating value of the gas is 1050 Btu/ft<sup>3</sup>. Proceed as follows:

- 1. 32 sec. to complete one revolution.
- 2. 3600 , 32 = 112.5.
- 3. 112.5 x 1 =112.5 ft3 of gas flow/hr.
- 4. 112.5 x 1050 = 118,125 Btuh input.

If the desired gas input is 115,000 Btuh, only a minor change in the manifold pressure is required.

Observe manifold pressure and proceed as follows to adjust gas input:

- 1. Remove regulator cover screw over plastic adjustment screw on gas valve (See Fig. 18).
- Turn plastic adjustment screw clockwise to increase gas input, or turn plastic adjustment screw counterclockwise to decrease input (See Fig. 18). Manifold pressure must be between 3.2 and 3.8 IN. W.C.

# WARNING

### FIRE AND UNIT DAMAGE HAZARD

Failure to follow this warning could result in personal injury or death and/or property damage.

Unsafe operation of the unit may result if manifold pressure is outside this range

- 3. Replace regulator cover screw on gas valve (See Fig. 18).
- 4. Turn off gas supply to unit. Remove manometer from pressure tap and replace pipe plug on gas valve. (See Fig. 16.) Turn on gas to unit and check for leaks.

#### Measure Manifold Pressure (Propane Units)

Refer to propane kit installation instructions for properly checking gas input.

**NOTE:** For installations below 2,000 ft (610 m), refer to the unit rating plate for proper propane conversion kit. For installations above 2,000 ft (610 m), contact your distributor for proper propane conversion kit.

#### **Check Burner Flame**

With control access panel (see Fig. 24) removed, observe the unit heating operation. Watch the burner flames to see if they are light blue and soft in appearance, and that the flames are approximately the same for each burner. Propane will have blue flame (See Fig. 18). Refer to the Maintenance section for information on burner removal.

#### Normal Operation

An LED (light-emitting diode) indicator is provided on the integrated gas unit controller (IGC) to monitor operation. The IGC is located by removing the control access panel (see Fig. 24). During normal operation, the LED is continuously on (See Table 7 for error codes).

### Airflow and Temperature Rise

The heating section for each size unit is designed and approved for heating operation within the temperature-rise range stamped on the unit rating plate.

Table 9 show the approved temperature rise range for each heating input, and the air delivery CFM at various temperature rises for a given external static pressure. The heating operation airflow must produce a temperature rise that falls within the approved range. For single phase units only, "High" blower speed is for high static cooling only and must not be used for gas heating.

Refer to Indoor Airflow and Airflow Adjustments section to adjust heating airflow when required.

#### Limit Switches

Normally closed limit switch (LS) completes the control circuit. Should the leaving-air temperature rise above the maximum allowable temperature, the limit switch opens and the control circuit "breaks." Any interruption in the control circuit instantly closes the gas valve and stops gas flow to the burners. The blower motor continues to run until LS resets.

When the air temperature at the limit switch drops to the low-temperature setting of the limit switch, the switch closes and completes the control circuit. The direct-spark ignition system cycles and the unit returns to normal heating operation.

STATUS CODE	LED INDICATION
Normal Operation2	On
No Power Hardware Failure	Off
Check fuse, low voltage circuit	1 Flash
Limit Switch Fault	2 Flashes
Flame Sense Fault	3 Flashes
Four Consecutive Limit Switch Faults	4 Flashes
Ignition Lockout Fault	5 Flashes
Pressure Switch Fault	6 Flashes
Rollout Switch Fault	7 Flashes
Internal Control Fault	8 Flashes
Temporary 1 hr auto reset1	9 Flashes

Table 7 – LED Indications

#### NOTES:

1. This code indicates an internal processor fault that will reset itself in one hr. Fault can be caused by stray RF signals in the structure or nearby. This is a UL requirement.

2. LED indicates acceptable operation. Do not change ignition control board.

3. When W is energized the burners will remain on for a minimum of 60 sec.

4. If more than one error mode exists they will be displayed on the LED in sequence.

#### Rollout Switch

The function of the rollout switch is to close the main gas valve in the event of flame rollout. The switch is located above the main burners. When the temperature at the rollout switch reaches the maximum allowable temperature, the control circuit trips, closing the gas valve and stopping gas flow to the burners. The indoor (evaporator) fan motor (IFM) and induced draft motor continue to run until switch is reset. The IGC LED will display FAULT CODE 7.

### Step 4 – Start-up Cooling and Make Adjustments

Complete the required procedures given in the Pre-Start-Up section before starting the unit. Do not jumper any safety devices when operating the unit. Do not operate the compressor when the outdoor temperature is below 40°F ( $4.4^{\circ}$ C) (unless accessory low-ambient kit is installed). Do not rapid-cycle the compressor. Allow 5 minutes between on cycles to prevent compressor damage.

#### **Checking Cooling Control Operation**

Start and check the unit for proper cooling control operation as follows:

- 1. Place room thermostat SYSTEM switch in OFF position. Observe that blower motor starts when FAN switch is placed in ON position and shuts down when FAN switch is placed in AUTO position.
- Place SYSTEM switch in COOL position and FAN switch in AUTO position. Set cooling control below room temperature. Observe that compressor, condenser fan, and evaporator blower motors start. Observe that cooling cycle shuts down when control setting is satisfied. The evaporator fan will continue to run for 90 sec.

#### **Checking and Adjusting Refrigerant Charge**

The refrigerant system is fully charged with Puron Advance (R-454B) refrigerant and is tested and factory sealed. Allow system to operate a minimum of 15 minutes before checking or adjusting charge.

# WARNING

### EXPLOSION HAZARD



Failure to follow this warning could result in death, serious personal injury, and/or property damage.

Never use air or gases containing oxygen for leak testing or operating refrigerant compressors. Pressurized mixtures of air or gases containing oxygen can lead to an explosion.

**NOTE:** Adjustment of the refrigerant charge is not required unless the unit is suspected of not having the proper Puron Advance (R-454B) charge. If adjusting charge, an R-454B leak detector must be actively monitoring during the process.

**NOTE:** Some units have fixed orifice refrigerant metering devices. There is a different charging procedure for both expansion devices. Refer to the correct procedure for your unit.

The charging label and the tables shown refer to system temperatures and pressures in cooling mode only. A refrigerant charging label is attached to the inside of the compressor access panel. (See Fig. 22 Subcool chart for units with TXV and superheat chart for units with fixed orifice.) The chart includes the required liquid line temperature at given discharge line pressures and outdoor ambient temperatures.

A superheat chart is attached to the inside of the compressor access panel for the unit with fixed metering device. Refer to the charging procedure on the label.

An accurate thermocouple- or thermistor-type thermometer, and a gauge manifold are required when using the subcooling charging method for evaluating the unit charge. Do not use mercury or small dial-type thermometers because they are not adequate for this type of measurement.

# CAUTION

#### UNIT DAMAGE HAZARD

Failure to follow this caution may result in unit damage.

When evaluating the refrigerant charge, an indicated adjustment to the specified factory charge must always be very minimal. If a substantial adjustment is indicated, an abnormal condition exists somewhere in the cooling system, such as insufficient airflow across either coil or both coils.

Proceed as follows:

- 1. Remove caps from low- and high-pressure service fittings.
- 2. Using hoses with valve core depressors, attach low- and high-pressure gauge hoses to low- and high-pressure service fittings, respectively.
- 3. Start unit in Cooling Mode and let unit run until system pressures stabilize.
- 4. Measure and record the following:
  - a. Outdoor ambient-air temperature (°F (°C) db).
  - b. Liquid line temperature (°F)(°C).
  - c. Discharge (high-side) pressure (psig).
  - d. Suction (low-side) pressure (psig) (for reference only).
- 5. Using "Cooling Charging Charts," compare outdoor-air temperature(°F (°C) db) with the discharge line pressure (psig) to determine desired system operating liquid line temperature (See Fig. 22).

6. Compare actual liquid line temperature with desired liquid line temperature. Using a tolerance of ± 2°F (±1.1°C), add refrigerant if actual temperature is more than 2°F (1.1°C) higher than proper liquid line temperature, or remove refrigerant if actual temperature is more than 2°F (1.1°C) lower than required liquid line temperature.

**NOTE:** If the problem causing the inaccurate readings is a refrigerant leak, refer to the Check for Refrigerant Leaks section.

# Indoor Airflow and Airflow Adjustments

# ! CAUTION

### UNIT OPERATION HAZARD

Failure to follow this caution may result in unit damage.

For cooling operation, the recommended airflow is 350 to 450 CFM for each 12,000 Btuh of rated cooling capacity. For heating operation, the airflow must produce a temperature rise that falls within the range stamped on the unit rating plate.

**NOTE:** Be sure that all supply-and return-air grilles are open, free from obstructions, and adjusted properly.

# WARNING

### ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death. Before making any indoor wiring adjustments, shut off gas supply. Then disconnect electrical power to the unit and install lockout tag before changing blower speed.

This unit has independent fan speeds for gas heating and cooling modes. Single phase units also have a dedicated continuous fan speed All models, have a field-selectable capability to run two different cooling speeds: A normal cooling fan speed (350-450 CFM/Ton) and an enhanced dehumidification fan speed (As low as 320 CFM/Ton) for use with either a dehumidistat or a thermostat that supports dehumidification.

This unit is factory-set for use with a single cooling fan speed. For single phase models, the cooling speed is marked "COOL" on the IGC (See Fig. 19). The factory-shipped settings are noted in Table 9. There are up to 3 additional speed tap wires available for use in either gas heating mode, cooling mode, or continuous fan mode (For color coding on the indoor fan motor leads, see Table 8). For single phase models, one of the additional speed tap wires is connected to the continuous fan, with the other 2 wires shipped loose in the control box near the IGC.

### Gas Heating Fan Speed Set-up (Single Phase Models):

To change the gas heating speed:

- 1. Remove existing speed tap wire from the "HEAT" terminal on the IGC.
- 2. Connect the desired speed tap wire on the "HEAT" terminal on the IGC board. "High" speed is for high static cooling only and must not be used for gas heating speed. Make sure that the speed chosen delivers temperature rise within the rise range listed on the unit.

# Cooling Fan Speed Set-up (Dehumidification feature not used) (Single Phase Models):

To change cooling speed:

1. Remove existing speed tap wire from the "COOL" terminal on the IGC board. Add the wet coil pressure drop in Table 10 to the system static to determine the correct cooling airflow speed in Table 9 that will deliver the nominal cooling airflow listed in Table 1 for each size.

2. Connect the desired speed tap wire on the "COOL" terminal on the IGC board.

# Dehumidification Cooling Fan Speed Set-up (Single Phase Models):

**IMPORTANT:** Dehumidification control must open control circuit on humidity rise above set point.

Use of the dehumidification cooling fan speed requires use of either a 24 VAC dehumidistat or a thermostat which includes control of a 24 VAC dehumidistat connection. In either case, the dehumidification control must open the control circuit on humidity rise above the dehumidification set point.

- 1. Move shunt jumper on IGC board to "DH" (See Fig. 19).
- 2. Refer to airflow table (Table 9) to determine allowable speeds for the dehumidification cooling fan speed. Speeds that are not allowed are shaded in Table 9.
- 3. Connect selected speed tap wire to "DHUM" terminal on the IGC board. Verify that static pressure is in the acceptable range for the speed tap to be used for dehumidification cooling.

### Continuous Fan Speed Set-up (Single Phase Models):

To change continuous fan speed:

- 1. Remove existing speed tap wire from the "FAN" terminal on the IGC.
- Connect the desired speed tap wire on the "FAN" terminal on the IGC board.

### Table 8 – Color Coding for Indoor Fan Motor Leads

Black = High Speed
Orange = Med-High Speed
Red = Med Speed
Pink = Med-Low Speed
Blue = Low Speed

# WARNING

# PERSONAL INJURY AND PROPERTY DAMAGE HAZARD

Continuous Fan Speed must meet or exceed the Required Minimum Dissipation Airflow (Table 1), Continuous fan speed selected must be connected to "FAN" terminal on IGC Board (Fig. 19).



Fig. 19 - Single Phase IGC Board

A14399

# Step 5 – Defrost Control Demand Defrost Mode

The defrost mode is factory set to an initial 60-minute time interval. It may also be adjusted to an initial interval of 30, 90, or 120 minutes. During operation, the control optimizes current defrost time based on the previous defrost interval and previous defrost period. If the previous defrost period is less than 2 minutes for two consecutive defrost cycles the control will lengthen the defrost interval by 15 minutes, up to a maximum of 120 minutes or 30 minutes greater than the original setpoint, whichever comes first. If the previous defrost period is more than 5 minutes for two consecutive defrost cycles the control will shorten the defrost interval by 15 minutes, down to a minimum of 30 minutes or 30 minutes from the original setpoint, whichever is first. After the defrost condition is satisfied, or after a maximum of 10 minutes in defrost mode, the unit will resume normal heating operation.

	Heating		_	Allowable	ESP (in. W.C.)										
Unit Size	Rise <sup>o</sup> F ( <sup>o</sup> C)	Motor Speed	Тар	Functions		0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1
					CFM	723	563	308							
					BHP	0.09	0.07	0.06							
		Low <sup>T</sup>	Blue	Alternate Cooling	Gas Heat Rise ( <sup>o</sup> F)	NA									
					Gas Heat Rise ( <sup>o</sup> C)	NA									
					CFM	829	766	696	606	538	470	406	341	283	220
		Madelaur	Dist	Alternate Cooling,	BHP	0.11	0.12	0.12	0.13	0.13	0.14	0.14	0.15	0.15	0.16
		Ivied-Low	PINK	Alternate Gas Heating	Gas Heat Rise ( <sup>o</sup> F)	54	NA								
					Gas Heat Rise ( <sup>o</sup> C)	30	NA								
24060	25 - 55				CFM	1065	1016	966	914	857	783	716	667	617	566
24000	(14 - 31)	**	Ded	Cooling,	BHP	0.19	0.20	0.20	0.21	0.22	0.23	0.23	0.24	0.24	0.25
		Medium	Rea	Alternate Gas Heating	Gas Heat Rise ( <sup>o</sup> F)	42	44	46	49	52	NA	NA	NA	NA	NA
					Gas Heat Rise ( <sup>o</sup> C)	23	24	26	27	29	NA	NA	NA	NA	NA
					CFM	1097	1048	999	949	893	833	751	701	651	603
		+	0	Gas Heating,	BHP	0.21	0.21	0.22	0.22	0.23	0.24	0.25	0.25	0.26	0.26
		Med-High+	Orange	Alternate Cooling	Gas Heat Rise ( <sup>o</sup> F)	41	43	45	47	50	54	NA	NA	NA	NA
					Gas Heat Rise ( <sup>o</sup> C)	23	24	25	26	28	30	NA	NA	NA	NA
		High	Black	High Static Cooling Only	CFM	1215	1173	1129	1085	1038	989	936	854	803	760
		riigii	Diack	Thigh Static Seeining Only	BHP	0.26	0.27	0.28	0.28	0.29	0.30	0.31	0.32	0.32	0.33
					CFM	643	552	455	348	225					
		Lowt	Blue		BHP	0.09	0.10	0.11	0.11	0.11					
		LOW	Dide		Gas Heat Rise ( <sup>o</sup> F)	NA									
					Gas Heat Rise ( <sup>o</sup> C)	NA									
					CFM	817	744	673	597	516	431	325	190		
		Modillow	Dink	Alternate Cooling,	BHP	0.14	0.15	0.15	0.16	0.17	0.17	0.18	0.18		
		Wed-LOW	FIIK	Alternate Gas Heating	Gas Heat Rise ( <sup>o</sup> F)	55	NA								
					Gas Heat Rise ( <sup>o</sup> C)	30	NA								
30060	25 - 55				CFM	1159	1104	1045	990	937	878	821	759	693	618
00000	(14 - 31)	Madium**	Ded	Gas Heating,	BHP	0.31	0.32	0.33	0.33	0.34	0.35	0.36	0.37	0.37	0.38
		Medium	Rea	Alternate Cooling	Gas Heat Rise ( <sup>o</sup> F)	39	40	43	45	48	51	54	NA	NA	NA
					Gas Heat Rise ( <sup>o</sup> C)	21	22	24	25	26	28	30	NA	NA	NA
					CFM	1201	1147	1095	1037	987	934	877	818	755	671
			Oranga	Cooling,	BHP	0.34	0.35	0.36	0.37	0.37	0.38	0.39	0.40	0.41	0.40
		Med-High+	Orange	Alternate Gas Heating	Gas Heat Rise ( <sup>o</sup> F)	37	39	41	43	45	48	51	55	NA	NA
				-	Gas Heat Rise ( <sup>o</sup> C)	21	22	23	24	25	27	28	30	NA	NA
		High	Black	High Static Cooling Only	CFM	1291	1236	1181	1131	1080	1033	978	909	792	661
		riigii	Diaon	Thigh Glade Cooling Only	BHP	0.41	0.42	0.43	0.43	0.44	0.45	0.46	0.45	0.43	0.40

Table 9 – Dry Coil Air Delivery\* - Horizontal and Downflow Discharge Sizes 24-60 208/230 VAC - 1 Phase

	Heating		-	Allowable			-		ESP (in.	W.C.)					
Jnit Size	Rise <sup>o</sup> F ( <sup>ŏ</sup> C)	Motor Speed	Тар	Functions		0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1
	. , ,				CFM	1069	1006	955	896	847	800	755	700	649	598
		. +		Alternate Cooling,	BHP	0.16	0.17	0.18	0.19	0.20	0.21	0.22	0.23	0.24	0.24
		Low	Blue	Alternate Gas Heating	Gas Heat Rise ( <sup>o</sup> F)	63	NA	NA	NA	NA	NA	NA	NA	NA	NA
				-	Gas Heat Rise ( <sup>o</sup> C)	35	NA	NA	NA	NA	NA	NA	NA	NA	NA
					CFM	1154	1100	1045	997	936	886	847	804	749	699
		Madlow	Dink	Alternate Cooling,	BHP	0.19	0.20	0.21	0.23	0.24	0.24	0.25	0.26	0.27	0.28
		wed-Low	PINK	Alternate Gas Heating	Gas Heat Rise ( <sup>o</sup> F)	58	61	64	NA	NA	NA	NA	NA	NA	NA
					Gas Heat Rise ( <sup>o</sup> C)	32	34	36	NA	NA	NA	NA	NA	NA	NA
36090	35 - 65				CFM	1295	1247	1199	1152	1104	1050	997	955	918	875
00000	(19 - 36)	M = =!:= **	Pod	Gas Heating,	BHP	0.26	0.27	0.28	0.29	0.30	0.31	0.32	0.33	0.33	0.34
		wealum	Reu	Alternate Cooling	Gas Heat Rise ( <sup>o</sup> F)	52	54	56	58	61	64	NA	NA	NA	NA
					Gas Heat Rise ( <sup>o</sup> C)	29	30	31	32	34	35	NA	NA	NA	NA
					CFM	1421	1374	1328	1283	1236	1188	1137	1089	1042	1011
		M	Orango	Cooling,	BHP	0.32	0.33	0.35	0.36	0.37	0.38	0.39	0.40	0.41	0.41
		Med-Hign+	Orange	Alternate Gas Heating	Gas Heat Rise ( <sup>o</sup> F)	47	49	50	52	54	56	59	61	64	NA
					Gas Heat Rise ( <sup>o</sup> C)	26	27	28	29	30	31	33	34	36	NA
		High	Black	High Static Cooling Only	CFM	1505	1464	1423	1380	1336	1292	1242	1199	1145	1096
		riigii	Diddit	Thigh Claub Cooling Only	BHP	0.38	0.39	0.40	0.42	0.43	0.43	0.44	0.45	0.46	0.47
					CFM	956	899	843	786	729	676	621	558	504	435
		Lowt	Blue		BHP	0.13	0.13	0.14	0.15	0.16	0.16	0.17	0.18	0.18	0.19
		LOW	2.40		Gas Heat Rise ( <sup>o</sup> F)	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
					Gas Heat Rise ( <sup>o</sup> C)	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
					CFM	1201	1153	1107	1060	1012	965	917	8/1	828	/82
		Med-Low	Pink		BHP	0.21	0.22	0.22	0.23	0.24	0.25	0.26	0.27	0.28	0.29
					Gas Heat Rise ( <sup>o</sup> F)	56	58	60	63	NA	NA	NA	NA	NA	NA
	05 05				Gas Heat Rise ( <sup>o</sup> C)	31	32	34	35	NA	NA	NA	NA	NA	NA
42090	35 - 65				CFM	1443	1402	1361	1322	1284	1243	1204	1164	1124	1084
	(19 - 36)	Medium <sup>**</sup>	Red	Gas Heating,	BHP	0.32	0.33	0.34	0.35	0.36	0.37	0.38	0.39	0.40	0.42
		Weddin		Alternate Cooling	Gas Heat Rise ( <sup>o</sup> F)	46	48	49	51	52	54	56	58	60	62
					Gas Heat Rise ( <sup>o</sup> C)	26	27	27	28	29	30	31	32	33	34
					CFM	1529	1491	1451	1411	1376	1338	1300	1261	1223	1185
		Mod High‡	Orange	Cooling,	BHP	0.37	0.39	0.40	0.41	0.42	0.43	0.44	0.45	0.46	0.47
		Med-High	orungo	Alternate Gas Heating	Gas Heat Rise ( <sup>o</sup> F)	44	45	46	47	49	50	52	53	55	57
					Gas Heat Rise ( <sup>o</sup> C)	24	25	26	26	27	28	29	29	30	31
		High	Black	High Static Cooling Only	CFM	1604	1565	1529	1490	1455	1421	1385	1348	1310	1274
			2.0.0.0	ing i claire cooring only	BHP	0.42	0.44	0.45	0.46	0.47	0.48	0.49	0.50	0.51	0.52

Table 9 – Dry Coil Air Delivery\* - Horizontal and Downflow Discharge Sizes 24-60 208/230 VAC - 1 Phase (Continued)

L	Heating		<b>T</b>	Allowable					ESP (in.	W.C.)					
Jnit Size	Rise <sup>o</sup> F ( <sup>ŏ</sup> C)	Motor Speed	Тар	Functions		0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1
					CFM	641	551	462	385	289	216	163	115		
		. +	DI		BHP	0.05	0.06	0.06	0.07	0.07	0.08	0.08	0.09		
		Low	Blue		Gas Heat Rise ( <sup>o</sup> F)	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
				-	Gas Heat Rise ( <sup>o</sup> C)	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
					CFM	1437	1395	1351	1307	1265	1221	1176	1132	1084	1039
		· · · · +	Dink	Gas Heating,	BHP	0.29	0.30	0.31	0.32	0.33	0.34	0.35	0.36	0.37	0.38
		Med-Low+	PINK	Alternate Cooling	Gas Heat Rise ( <sup>o</sup> F)	47	48	50	51	53	55	57	59	62	64
					Gas Heat Rise ( <sup>o</sup> C)	26	27	28	28	29	30	32	33	34	36
48090	35 - 65				CFM	1771	1735	1699	1664	1627	1592	1557	1522	1486	1450
40000	(19 - 36)	N.4	Dod	Cooling	BHP	0.51	0.52	0.53	0.55	0.56	0.57	0.58	0.59	0.61	0.62
		medium	Reu	Cooling,	Gas Heat Rise ( <sup>o</sup> F)	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
					Gas Heat Rise ( <sup>o</sup> C)	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
					CFM	1928	1897	1862	1830	1796	1764	1732	1698	1620	1512
		Madilliah	Oranga	Alternate Cooling	BHP	0.64	0.65	0.67	0.68	0.69	0.71	0.72	0.73	0.71	0.66
		wed-nign	Orange	Alternate Cooling	Gas Heat Rise ( <sup>o</sup> F)	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
					Gas Heat Rise ( <sup>o</sup> C)	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
		High	Black	High Static Cooling Only	CFM	2212	2167	2124	2061	1976	1892	1794	1699	1567	1438
		riigii	Black	Thigh claic cooming only	BHP	0.97	0.99	1.00	0.97	0.95	0.91	0.86	0.82	0.77	0.71
					CFM	641	551	462	385	289	216	163	115		
		Lowt	Blue	-	BHP	0.05	0.06	0.06	0.07	0.07	0.08	0.08	0.09		
		Low			Gas Heat Rise ( <sup>o</sup> F)	134	155	185	222	296	NA	NA	NA	NA	NA
					Gas Heat Rise ( <sup>O</sup> C)	/4	86	103	124	164	NA	NA	NA	NA	NA
					CFM	1437	1395	1351	1307	1265	1221	1176	1132	1084	1039
		Med-Low	Pink	Alternate Cooling,	BHP	0.29	0.30	0.31	0.32	0.33	0.34	0.35	0.36	0.37	0.38
				Alternate Gas Heating	Gas Heat Rise ( <sup>o</sup> F)	60	NA	NA	NA	NA	NA	NA	NA	NA	NA
					Gas Heat Rise ( <sup>o</sup> C)	33	NA	NA	NA	NA	NA	NA	NA	NA	NA
48115	30 - 60				CFM	1//1	1/35	1699	1664	1627	1592	1557	1522	1486	1450
	(17 - 33)	Medium <sup>**</sup>	Red	Cooling,	BHP	0.51	0.52	0.53	0.55	0.56	0.57	0.58	0.59	0.61	0.62
		Wedum		Alternate Gas Heating	Gas Heat Rise ( <sup>o</sup> F)	48	49	50	51	53	54	55	56	58	59
					Gas Heat Rise ( <sup>o</sup> C)	27	27	28	29	29	30	31	31	32	33
					CFM	1928	1897	1862	1830	1796	1764	1732	1698	1620	1512
		Med_High‡	Orange	Gas Heating,	BHP	0.64	0.65	0.67	0.68	0.69	0.71	0.72	0.73	0.71	0.66
		weu-riigit'	Sidingo	Alternate Cooling	Gas Heat Rise ( <sup>0</sup> F)	44	45	46	47	48	49	49	50	53	57
					Gas Heat Rise ( <sup>o</sup> C)	25	25	26	26	26	27	27	28	29	31
		High	Black	High Static Cooling Only	CFM	2212	2167	2124	2061	1976	1892	1794	1699	1567	1438
			2.0.0.1		BHP	0.97	0.99	1.00	0.97	0.95	0.91	0.86	0.82	0.77	0.71

Table 9 – Dry Coil Air Delivery\* - Horizontal and Downflow Discharge Sizes 24-60 208/230 VAC - 1 Phase (Continued)

	Heating			Allowable			0		ESP (in.	W.C.)					
Jnit Size	Rise <sup>o</sup> F ( <sup>o</sup> C)	Motor Speed	Тар	Functions		0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1
					CFM	641	551	462	385	289	216	163	115		
		. +			BHP	0.05	0.06	0.06	0.07	0.07	0.08	0.08	0.09		
		Low	Blue		Gas Heat Rise ( <sup>O</sup> F)	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
					Gas Heat Rise ( <sup>o</sup> C)	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
					CFM	1437	1395	1351	1307	1265	1221	1176	1132	1084	1039
		Madilaw	Dink		BHP	0.29	0.30	0.31	0.32	0.33	0.34	0.35	0.36	0.37	0.38
		Wed-Low	PINK		Gas Heat Rise ( <sup>O</sup> F)	60	NA	NA	NA	NA	NA	NA	NA	NA	NA
					Gas Heat Rise ( <sup>o</sup> C)	33	NA	NA	NA	NA	NA	NA	NA	NA	NA
60115	30 - 60				CFM	1914	1881	1848	1814	1780	1748	1716	1681	1619	1512
00110	(17 - 33)	M = =	Pod	Cooling,	BHP	0.62	0.64	0.65	0.67	0.68	0.69	0.71	0.72	0.71	0.66
		wealum	Reu	Alternate Gas Heating	Gas Heat Rise ( <sup>o</sup> F)	45	45	46	47	48	49	50	51	53	57
					Gas Heat Rise ( <sup>o</sup> C)	25	25	26	26	27	27	28	28	29	31
					CFM	1928	1897	1862	1830	1796	1764	1732	1698	1620	1512
		M. J. B	Oranga	Gas Heating,	BHP	0.64	0.65	0.67	0.68	0.69	0.71	0.72	0.73	0.71	0.66
		Med-High+	Orange	Alternate Cooling	Gas Heat Rise ( <sup>o</sup> F)	44	45	46	47	48	49	49	50	53	57
				_	Gas Heat Rise ( <sup>o</sup> C)	25	25	26	26	26	27	27	28	29	31
		High	Black	High Static Cooling Only	CFM	2212	2167	2124	2061	1976	1892	1794	1699	1567	1438
		riigi	DIACK	Thigh Otalic Ocoling Only	BHP	0.97	0.99	1.00	0.97	0.95	0.91	0.86	0.82	0.77	0.71
					CFM	641	551	462	385	289	216	163	115		
		Low	Blue		BHP	0.05	0.06	0.06	0.07	0.07	0.08	0.08	0.09		
		LOW	Dido		Gas Heat Rise ( <sup>o</sup> F)	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
					Gas Heat Rise ( <sup>o</sup> C)	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
					CFM	1437	1395	1351	1307	1265	1221	1176	1132	1084	1039
		Med-Low	Pink		BHP	0.29	0.30	0.31	0.32	0.33	0.34	0.35	0.36	0.37	0.38
		WCG-LOW	1 HIX		Gas Heat Rise ( <sup>o</sup> F)	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
					Gas Heat Rise ( <sup>o</sup> C)	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
60130	35 - 65				CFM	1914	1881	1848	1814	1780	1748	1716	1681	1619	1512
	(19 - 36)	Madium**	Red	Cooling,	BHP	0.62	0.64	0.65	0.67	0.68	0.69	0.71	0.72	0.71	0.66
		wedium	Reu	Alternate Gas Heating	Gas Heat Rise ( <sup>o</sup> F)	49	50	51	52	53	54	55	56	58	62
					Gas Heat Rise ( <sup>o</sup> C)	27	28	28	29	29	30	31	31	32	35
					CFM	1928	1897	1862	1830	1796	1764	1732	1698	1620	1512
		Mad Llink <sup>†</sup>	Orango	Gas Heating,	BHP	0.64	0.65	0.67	0.68	0.69	0.71	0.72	0.73	0.71	0.66
		weu-nign+	Stange	Alternate Cooling	Gas Heat Rise ( <sup>o</sup> F)	49	50	51	52	53	54	55	56	58	62
					Gas Heat Rise ( <sup>o</sup> C)	27	28	28	29	29	30	30	31	32	35
		High	Black	High Static Cooling Only	CFM	2212	2167	2124	2061	1976	1892	1794	1699	1567	1438
		<del>.</del>		ing chance cooming only	BHP	0.97	0.99	1.00	0.97	0.95	0.91	0.86	0.82	0.77	0.71

Table 9 – Dry Coil Air Delivery\* - Horizontal and Downflow Discharge Sizes 24-60 208/230 VAC - 1 Phase (Continued)

Shaded areas indicate speed/static combinations that are not permitted for dehumidification speed. \*Air delivery values are without air filter and are for dry coil (See Wet Coil Pressure Drop table).

"High Static Cooling" = Only to be used for cooling function (Not allowed for gas heating function)

<sup>†</sup> Factory-shipped continuous fan speed <sup>‡</sup> Factory-shipped gas heating speed

\*\*Factory-shipped cooling speed

"NA" = Not allowed for gas heating speed

NOTE: Deduct field-supplied air filter pressure drop and wet coil pressure drop to obtain static pressure available for ducting.

						Table	10 – Filt	ter Pres	sure Dro	p Table	(IN. W.C	C.)								
Cilter C			Cooling								Standa	rd CFM	(SCFM)							
Filter S	size in. (mm	1)	Tons	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100	2200
600 12x20 (305x508x)	0-1400 CFM x1+12x20x1 25+305x508>	:25)	2.0, 2.5	0.03	0.04	0.05	0.06	0.06	0.07	0.07	0.08	0.08	-	-	-	-	-	-	-	-
1200 16x24 (406x610x2	0-1800 CFM x1+14x24x1 25+356x610>	:25)	3.0, 3.5, 4.0	-	-	-	-	0.04	0.05	0.06	0.07	0.08	0.09	0.09	0.10	0.11	0.12	0.12	-	-
1500 16x24 (406x610x	0-2200 CFM x1+18x24x1 25+457x356>	:25)	5.0	-	-	-	-	-	-	-	-	-	0.04	0.06	0.08	0.10	0.11	0.13	0.14	0.15
						Tabl	e 11 – W	et Coil	Pressure	e Drop (l	IN. W.C.	)								
Unit				i					Standar	d CFM (S	SCFM)	-								
Size	600	700	800	900	1000	1100	120	0 1	300	1400	1500	160	0 1	700	1800	1900	200	0 2	100	2200
24	0.03	0.04	0.04	0.05	0.06															
30				0.05	0.06	0.07	0.08	8 (	0.11											
36				0.06	0.06	0.09	0.10	0 0	).11	0.14										
42					0.05	0.05	0.06	6 (	0.07	0.08	0.08	0.0	9 0	.09	0.11					
48							0.04	4 0	0.06	0.09	0.10	0.10	0 0	.11	0.12	0.13	0.1	4		
60											0.06	0.0	7 0	.01	0.08	0.09	0.1	0 0	.12	0.13
					Table	12 – Eco	nomize	r with 1	-in. Filte	r Pressu	re Drop	(IN. W.	C.)							
	N	<b>`</b>	Cooling								Standa	rd CFM (	(SCFM)							
Filter S	size in. (mm	)	Tons	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100	2200
600 12x20 (305x508x2	0-1400 CFM x1+12x20x1 25+305x508>	:25)	2.0, 2.5	-	-	0.08	0.09	0.10	0.11	0.11	0.13	0.14	-	-	-	-	-	-	-	-
120 16x24 (406x610x2	00-1800 CFM x1+14x24x1 25+356x610>	:25)	3.0, 3.5, 4.0	-	-	-	-	-	0.09	0.09	0.10	0.12	0.13	0.15	0.17	0.17	0.19	0.21	-	-
150 16x24 (406x610x)	00-2200 CFM x1+18x24x1 25+457x356>	:25)	5.0	-	-	-	-	-	-	-	-	-	0.15	0.17	0.18	0.20	0.21	0.22	0.23	0.23



Fig. 20 – 208/230-1-60 Connection Wiring Diagram

A240135

28

### LADDER WIRING DIAGRAM DANGER: ELECTRICAL SHOCK HAZARD DISCONNECT POWER BEFORE SERVICING



IGC

сснО

-IF USED

ССН

0~~



Fig. 21 – 208/230-1-60 Ladder Wiring Diagram

A240136

IGC

O L2

YE

BLK -

		Required Sub	ocooling °F(°C	C)					Re	quired Lic	quid Line	Temperature for a Specific	c Subcoolin	g (R-454I	B)			
		Outdoor Am	bient Tempe	rature °F(°C)				Require	d Subcoo	oling (°F)					Require	d Subcoo	ling (°C)	
Model Size	75 (24)	85 (29)	95 (35)	105 (41)	115 (46)	Pressure (psig)	5	10	15	20	25		Pressure (kPa)	3	6	8	11	14
024	9 (5.0)	9 (5.0)	9 (5.0)	9 (5.0)	8 (4.4)	189	65	60	55	50	45		1303	18	16	13	10	7
030	12 (6.7)	12 (6.7)	11 (6.1)	11 (6.1)	11 (6.1)	196	67	62	57	52	47		1351	19	17	14	11	8
036	20 (11.1)	20 (11.1)	20 (11.1)	18 (10.0)	16 (8.9)	203	69	64	59	54	49		1399	21	18	15	12	9
042	15 (8.3)	15 (8.3)	15 (8.3)	15 (8.3)	15 (8.3)	210	71	66	61	56	51		1448	22	19	16	13	11
048	17 (9.4)	17 (9.4)	17 (9.4)	18 (10.0)	18 (10.0)	217	73	68	63	58	53		1496	23	20	17	14	12
060	14 (7.8)	14 (7.8)	14 (7.8)	14 (7.8)	14 (7.8)	224	75 77	70	65	60	55 57		1544	24	21	18	16 17	13
						238	79	74	69	64	59		1641	26	22	21	18	15
Notes:						245	81	76	71	66	61		1689	27	24	22	10	16
						252	83	78	73	68	63		1737	28	26	23	20	17
System is	factory cha	arged to pro	vide prope	r subcooling	g	260	85	80	75	70	65		1792	29	27	24	21	18
performar	nce. If syste	m is opene	d or if perfo	rmance iss	ues are	268	87	82	77	72	67		1848	31	28	25	22	19
suspected	l. then subc	oolina mus	t be checke	ed		276	89	84	79	74	69		1903	32	29	26	23	21
		<b>J</b>				284	91	86	81	76	71		1958	33	30	27	24	22
Charging	Procedure					292	93	88	83	78	73		2013	34	31	28	26	23
onarging	riocedure.					300	95	90	85	80	/5		2068	35	32	29	27	24
				- 1- 1		309	97	92	87	82	77		2130	36	33	31	28	25
1 - Measu	re Discharg	e line press	sure by attac	cning a gau	ge to the	318	99 101	94	89	84 86	79 81		2192	38	34	32	29	20
service	e port.					336	103	98	93	88	83		2316	39	37	34	31	28
2 - Measu	re the Liqui	d line tempe	erature by a	ttaching a		345	105	100	95	90	85		2378	41	38	35	32	29
temper	ature sensi	ng device to	o it.			354	107	102	97	92	87		2440	42	39	36	33	31
3 - Insulat	e the tempe	rature sens	sing device	so that the	Outdoor	364	110	105	100	95	90		2509	43	41	38	35	32
Ambier	nt doesn't a	ffect the rea	ading			374	111	106	101	96	91		2578	44	41	38	36	33
4 - Refer to	o the reauir	ed Subcool	ling in the ta	able based o	on the	384	113	108	103	98	93		2647	45	42	39	37	34
model	size and the	Outdoor A	mbient tem	perature.		394	115	110	105	100	95		2716	46	43	41	38	35
5 Interno	late if the C	utdoor Am	hient temne	rature lies i	n hetween	404	117	112	107	102	97		2785	47	44	42	39	36
the tab		ataoor Ann	bient tempe	indiane neo i	in between	414	120	115	110	105	100		2004	40	40	42	41	39
6 Eind th	o Proceuro	Value in the	table corre	ocnondina t	a tha	424	120	117	112	103	102		2923	50	40	43	42	39
6 - Fina ui	e Pressure	value in the	a table corre	esponding t	othe	444	124	119	114	109	104		3061	51	48	46	43	40
measu	rea Pressur	e of the Col	mpressor D	ischarge IIr	ie.	454	126	121	116	111	106		3130	52	49	47	44	41
/ Read a	cross from	the Pressu	re reading t	o obtain the	Liquid	464	127	122	117	112	107		3199	53	50	47	44	42
line ten	nperature fo	or a require	d Subcoolin	ıg.		474	129	124	119	114	109	F144.300	3268	54	51	48	46	43
8 - Add Ch	narge if the	measured t	emperature	is higher th	nan the	484	131	126	121	116	111	6.322	3337	55	52	49	47	44
table va	alue.					494	132	127	122	117	112	6-75-666	3406	90	53	50	47	44
9 - Remov	e charge if	the measur	ed tempera	ture is lowe	r than the	504	134	129	124	119	114	87.45	3475	57	54	51	48	46
table v	alue.					514	136	131	126	121	116	HILD T	3544	58	55	52	49 50	47
						534	139	132	127	122	119	350344-701 REV	3681	59	57	54	51	48

To properly check or adjust charge, conditions must be favorable for subcooling charging. Favorable conditions exist when the outdoor temperature is between 75°F to 115°F (24°C and 46°C), and the indoor temperature is between 70°F and 80°F (21°C and 27°C). Follow the procedure above.

Fig. 22 – Cooling Charging Table-Subcooling

A240116

### Maintenance

To ensure continuing high performance and to minimize the possibility of premature equipment failure, periodic maintenance must be performed on this equipment. This combination heating/cooling unit should be inspected at least once each year by a qualified service person. To troubleshoot cooling or heating of units, refer to Table 13, Table 14 and Table 16.

**NOTE:** Consult your local dealer about the availability of a maintenance contract.

# ! WARNING

#### PERSONAL INJURY AND UNIT DAMAGE HAZARD

Failure to follow this warning could result in personal injury or death and unit component damage.

The ability to properly perform maintenance on this equipment requires certain expertise, mechanical skills, tools and equipment. If you do not possess these, do not attempt to perform any maintenance on this equipment, other than those procedures recommended in the Owner's Manual.

# WARNING

### ELECTRICAL SHOCK HAZARD

Failure to follow these warnings could result in personal injury or death:

- 1. Turn off electrical power to the unit and install a lockout tag before performing any maintenance or service on this unit.
- 2. Use extreme caution when removing panels and parts.
- 3. Never place anything combustible either on or in contact with the unit.
- 4. Should overheating occur or the gas supply fail to shut off, turn off external main manual gas valve to the unit. Then shut off electrical supply.

# **CAUTION**

### UNIT OPERATION HAZARD

Failure to follow this caution may result in improper operation. Errors made when reconnecting wires may cause improper and dangerous operation.

Label all wires prior to disconnecting when servicing.

The minimum maintenance requirements for this equipment are as follows:

- 1. Inspect air filter(s) each month. Clean or replace when necessary. Certain geographical locations may require more frequent inspections.
- 2. Inspect indoor coil, outdoor coil, drain pan, and condensate drain each cooling season for cleanliness. Clean when necessary.
- 3. Inspect blower motor and wheel for cleanliness at the beginning of each heating and cooling season. Clean when necessary. For first heating and cooling season, inspect blower wheel bi-monthly to determine proper cleaning frequency.
- Check electrical connections for tightness and controls for proper operation each heating and cooling season. Service when necessary. Ensure electrical wiring is not in contact with refrigerant tubing or sharp metal edges.
- 5. Check and inspect heating section before each heating season. Clean and adjust when necessary.

6. Check flue hood and remove any obstructions, if necessary.

### Air Filter

**IMPORTANT:** Never operate the unit without a suitable air filter in the return-air duct system. Always replace the filter with the same dimensional size and type as originally installed. (See Table 1 for recommended filter sizes.)

Inspect air filter(s) at least once each month and replace (throwaway-type) or clean (cleanable-type) at least twice during each heating and cooling season or whenever the filter(s) becomes clogged with dust and/or lint.

### Indoor Blower and Motor

**NOTE:** All motors are prelubricated. Do not attempt to lubricate these motors.

For longer life, operating economy, and continuing efficiency, clean accumulated dirt and grease from the blower wheel and motor annually.



### ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death. Disconnect and install a lockout tag on electrical power to the unit before cleaning the blower motor and wheel.

#### Cleaning the Blower Motor and Wheel.

- 1. Remove and disassemble blower assembly as follows:
  - a. Remove blower access panel (see Fig. 24).
  - b. Disconnect 5 pin plug and 4 pin plug from indoor blower motor. Remove capacitor if required.
  - c. On all units, remove blower assembly from unit. Remove screws securing blower to blower partition and slide assembly out. Be careful not to tear insulation in blower compartment.
  - d. Ensure proper reassembly by marking blower wheel and motor in relation to blower housing before disassembly.
  - e. Loosen setscrew(s) that secures wheel to motor shaft. Remove screws that secure motor mount brackets to housing, and slide motor and motor mount out of housing.
- 2. Remove and clean blower wheel as follows:
  - a. Ensure proper reassembly by marking wheel orientation.
  - b. Lift wheel from housing. When handling and/or cleaning blower wheel, be sure not to disturb balance weights (clips) on blower wheel vanes.
  - c. Remove caked-on dirt from wheel and housing with a brush. Remove lint and/or dirt accumulations from wheel and housing with vacuum cleaner, using soft brush attachment. Remove grease and oil with mild solvent.
  - d. Reassemble wheel into housing.
  - e. Reassemble motor into housing. Be sure setscrews are tightened on motor shaft flats and not on round part of shaft. Reinstall blower into unit. Reinstall capacitor.
  - f. Connect 5 pin plug and 4 pin plug to indoor blower motor.
  - g. Reinstall blower access panel (see Fig. 24).
- 3. Restore electrical power to unit. Start unit and check for proper blower rotation and motor speeds during heating and cooling cycles.



Fig. 23 – Blower Housing and Flue Collector Box



A09211

#### Induced Draft (combustion air) Blower Assembly

The induced-draft blower assembly consists of the inducer motor, the blower housing, and the induced-draft blower wheel.

Fig. 24 – Unit Access Panels

Clean periodically to assure proper airflow and heating efficiency. Inspect blower wheel every fall and periodically during the heating season. For the first heating season, inspect blower wheel bimonthly to determine proper cleaning frequency.

To inspect blower wheel, remove draft hood assembly. Shine a flashlight into opening to inspect wheel. If cleaning is required, remove induced-draft blower assembly as follows:

- 1. Remove control access panel (See Fig. 24).
- 2. Remove the 5 screws that attach induced-draft blower assembly to the flue collector box cover.
- 3. Slide the assembly out of the unit. (See Fig. 25). Clean the blower wheel. If additional cleaning is required, continue with Steps 4 and 5.
- 4. To remove blower wheel, remove 2 setscrews.
- 5. To remove inducer motor, remove screws that hold the inducer motor to the blower housing.
- 6. To reinstall, reverse the procedure outlined above.

#### Flue Gas Passageways

To inspect the flue collector box and upper areas of the heat exchanger:

- 1. Remove the induced draft blower assembly according to directions in the Induced Draft Blower Assembly section.
- 2. Remove the 11 screws holding the flue collector box cover (See Fig. 23) to the heat exchanger assembly. Inspect the heat exchangers.

3. Clean all surfaces, as required, using a wire brush.

#### Limit Switch

Remove blower access panel (see Fig. 24). Limit switch is located on the fan partition.

#### Burner Ignition

Unit is equipped with a direct spark ignition 100 percent lockout system. Ignition module (IGC) is located in the control box (See Fig. 23). Module contains a self-diagnostic LED. During servicing, refer to label diagram or Table 7 in these instructions for LED interpretation.

If lockout occurs, unit may be reset by either momentarily interrupting power supply to unit or by turning selector switch to OFF position at the thermostat.

#### Main Burners

At the beginning of each heating season, inspect for deterioration or blockage due to corrosion or other causes. Observe the main burner flames and adjust, if necessary.

Removal of Gas Train

To remove the gas train for servicing:

- 1. Shut off main gas valve.
- 2. Shut off power to unit and install lockout tag.
- 3. Remove control access panel (See Fig. 24).
- 4. Disconnect gas piping at unit gas valve.
- 5. Remove fan partition mounting bracket (2 screws located on the left side of control compartment on the fan partition panel). Slide bracket forward, bottom first to remove. (See Fig. 23).
- 6. Remove wires connected to gas valve. Mark each wire.
- 7. Remove ignitor and sensor wires at the ignitor module.
- 8. Remove the mounting screw that attaches the burner rack to the unit base (See Fig. 23).
- 9. Slide the burner rack out of the unit (See Fig. 23 and Fig. 26).
- 10. To reinstall, reverse the procedure outlined above.
- 11. Check all connections for leaks.

# WARNING

#### FIRE, EXPLOSION HAZARD

Failure to follow this warning could result in personal injury, death or property damage.

Do not purge gas supply into the combustion chamber. Do not use a match or other open flame to check for gas leaks. Use a commercially available soap solution made specifically for the detection of leaks to check all connections. A fire or explosion may result causing property damage, personal injury or loss of life.

#### Outdoor Coil, Indoor Coil, and Condensate Drain Pan

Inspect the outdoor coil, indoor coil, and condensate drain pan at least once each year. The coils are easily cleaned when dry; therefore, inspect and clean the coils either before or after each cooling season. Remove all obstructions, including weeds and shrubs, that interfere with the airflow through the condenser coil.

Straighten bent fins with a fin comb. If coated with dirt or lint, clean the coils with a vacuum cleaner, using the soft brush attachment. Be careful not to bend the fins. If coated with oil or grease, clean the coils with a mild detergent-and-water solution. Rinse coils with clear water, using a garden hose. Be careful not to splash water on motors, insulation, wiring, or air filter(s). For best results, spray outdoor coil fins from inside to outside the unit. On units with an outer and inner condenser coil, be sure to clean between the coils. Be sure to flush all dirt and debris from the unit base.

Inspect the drain pan and condensate drain line when inspecting the coils. Clean the drain pan and condensate drain by removing all foreign matter from the pan. Flush the pan and drain tube with clear water. Do not splash water on the insulation, motor, wiring, or air filter(s). If the drain tube is restricted, clear it with a "plumbers snake" or similar probe device. Ensure that the auxiliary drain port above the drain tube is also clear.



Fig. 25 – Removal of Motor and Blower Wheel









#### Outdoor Fan

# **!** CAUTION

### UNIT OPERATION HAZARD

Failure to follow this caution may result in damage to unit components. Keep the outdoor fan free from all obstructions to ensure proper cooling operation. Never place articles on top of the unit.

- 1. Remove 6 screws holding outdoor grille and motor to top cover.
- 2. Turn motor/grille assembly upside down on top cover to expose the fan blade.
- 3. Inspect the fan blades for cracks or bends.
- 4. If fan needs to be removed, loosen the setscrew and slide the fan off the motor shaft.
- 5. When replacing fan blade, position blade back to the same position as before.
- 6. Ensure that setscrew engages the flat area on the motor shaft when tightening.
- 7. Replace grille.

C99085

#### Electrical Controls and Wiring

Inspect and check the electrical controls and wiring annually. Be sure to turn off the gas supply, and then the electrical power to the unit. Verify continuity of earth grounding. Check that wiring will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

Remove access panels (see Fig. 24) to locate all the electrical controls and wiring.

Before working with or handling any electrical components, make sure that all capacitors are properly discharged to avoid possibility of sparking. Replace components only with parts specified by the manufacturer. Other parts may result in the ignition of refrigerant in the atmosphere from a leak. Check all electrical connections for tightness. Tighten all screw connections. If any discolored or burned connections are noticed, disassemble the connection, clean all the parts, re-strip the wire end and reassemble the connection properly and securely.

After inspecting the electrical controls and wiring, replace the access panels (see Fig. 24). Start the unit, and observe at least one complete heating cycle and one complete cooling cycle to ensure proper operation. If discrepancies are observed in any operating cycle, or if a suspected malfunction has occurred, check each electrical component with the proper electrical instrumentation. Refer to the unit wiring label when making these checkouts.

**NOTE:** Refer to the heating and/or cooling sequence of operation in this publication as an aid in determining proper control operation.

#### Refrigerant Circuit

Annually inspect all refrigerant tubing connections.



# EXPLOSION, PERSONAL INJURY AND ENVIRONMENTAL HAZARD

Failure to follow this warning could result in personal injury, death or property damage.System under pressure.

Relieve pressure and recover all refrigerant before system repair or final unit disposal. Use all service ports and open all flow-control devices, including solenoid valves.

If low cooling performance is suspected, leak-test all refrigerant tubing using an electronic leak-detector, calibrated for use with R-454B, or liquid-soap solution. Ensure that the detector is not a potential ignition source. A halide torch (or any other detector using a naked flame) must not be used. If a refrigerant leak is detected, refer to the Check for Refrigerant Leaks section.

If no refrigerant leaks are found and low cooling performance is suspected, refer to the Checking and Adjusting Refrigerant Charge section.

C99029



#### MAX DISTANCE BETWEEN TOP OF FAN GRILLE AND BOTTOM OF FAN BLADE

Sizo	"	۹"
Jize	IN.	mm
24	7.1	180
30	8.0	203
36	7.6	193
42	7.6	193
48	7.6	193
60	7.6	193

Fig. 28 - Fan Blade Position

#### Gas Input

The gas input does not require checking unless improper heating performance is suspected. If a problem exists, refer to the Start-Up section.

#### Indoor Airflow

The heating and/or cooling airflow does not require checking unless improper performance is suspected. If a problem exists, be sure that all supply- and return-air grilles are open and free from obstructions, and that the air filter is clean. When necessary, refer to the Indoor Airflow and Airflow Adjustments section to check the system airflow.

### **Check Defrost Thermostat**

The defrost thermostat is usually located on the lowest liquid leaving circuit of the left condenser coil (see Fig. 27). The thermostat closes at  $32^{\circ}F(0^{\circ}C)$  and opens at  $65^{\circ}F(18^{\circ}C)$ .

#### Puron Advance (R-454B) Items

#### <u>Metering Device</u> (Thermostatic Expansion Valve & Piston)

This unit uses both a hard shutoff, balance port TXV in the indoor coil and a piston in each side of the outdoor coil. The TXV maintains a constant superheat at the evaporator coil exit (cooling mode) resulting in higher overall system efficiency.

#### Pressure Switches

Pressure switches are protective devices wired into control circuit (low voltage). They shut off compressor if abnormally high or low pressures are present in the refrigeration circuit. These pressure switches are specifically designed to operate with Puron Advance (R-454B) systems. R-22 pressure switches must not be used as replacements for the Puron Advance (R-454B) system.

#### Loss of Charge Switch

This switch is located on the liquid line and protects against low suction pressures caused by such events as loss of charge, low airflow across indoor coil, dirty filters, etc. It opens on a pressure drop at about 20 psig. If system pressure is above this, switch should be closed. To check switch:

- 1. Turn off all power to unit.
- 2. Disconnect leads on switch.

3. Apply ohm meter leads across switch. You should have continuity on a good switch.

A08505

**NOTE:** Because these switches are attached to refrigeration system under pressure, it is not advisable to remove this device for troubleshooting unless you are reasonably certain that a problem exists. If switch must be removed, remove and recover all system charge so that pressure gauges read 0 psig. Never open system without breaking vacuum with dry nitrogen.

#### **High-Pressure Switch**

The high-pressure switch is located in the discharge line and protects against excessive condenser coil pressure. It opens at 650 psig.

High pressure may be caused by a dirty outdoor coil, failed fan motor, or outdoor air recirculation. To check switch:

- 1. Turn off all power to unit.
- 2. Disconnect leads on switch.
- 3. Apply ohm meter leads across switch. You should have continuity on a good switch.

#### Copeland Scroll Compressor (Puron Advance (R-454B) Refrigerant)

The compressor used in this product is specifically designed to operate with Puron Advance (R-454B) refrigerant and cannot be interchanged.

The compressor is an electrical (as well as mechanical) device. Exercise extreme caution when working near compressors. Power should be shut off, if possible, for most troubleshooting techniques. Refrigerants present additional safety hazards.



#### **EXPLOSION HAZARD**

WARNING

Failure to follow this warning could result in personal injury or death and/or property damage.

Wear safety glasses and gloves when handling refrigerants. Keep torches and other ignition sources away from refrigerants and oils.

34



Fig. 29 – Refrigerant Circuit

C99097

C03011



Accurater®Metering Device

Arrow indicates direction of flow





HPS – High Pressure Switch LCS – Loss of Charge Switch Accurater® Metering Device Arrow indicates direction of flow

#### Fig. 31 – Typical Heat Pump Operation, Heating Mode

The scroll compressor pumps refrigerant throughout the system by the interaction of a stationary and an orbiting scroll. The scroll compressor has no dynamic suction or discharge valves, and it is more tolerant of stresses caused by debris, liquid slugging, and flooded starts. The compressor is equipped with an internal pressure relief port. The pressure relief port is a safety device, designed to protect against extreme high pressure. The relief port has an operating range between 550 and 625 psig differential pressure.

# **WARNING**

#### UNIT OPERATION AND SAFETY HAZARD

Failure to follow this warning could result in personal injury or equipment damage.

This system uses Puron Advance (R-454B) refrigerant which has higher operating pressures than R-22 and other refrigerants. No other refrigerant may be used in this system. Gauge set, hoses, and recovery system must be designed to handle Puron Advance (R-454B). If you are unsure, consult the equipment manufacturer.

#### **Refrigerant System**

This information covers the refrigerant system including the compressor oil needed, servicing systems on roofs containing synthetic materials, the filter drier and refrigerant charging.

#### **Compressor Oil**

If additional oil is needed use Uniqema RL32-3MAF. If this oil is not available, use Copeland Ultra 32CC or Mobil Artic EAL22CC. This oil is extremely hygroscopic, meaning it absorbs water readily. POE oils can absorb 15 times as much water as other oils designed for HCFC and CFC refrigerants. Take all necessary precautions to avoid exposure of the oil to the atmosphere.

Servicing Systems on Roofs and with Synthetic materials

POE (polyolester) compressor lubricants are known to cause long term damage to some synthetic roofing materials.

Exposure, even if immediately cleaned up, may cause embrittlement (leading to cracking) to occur in one year or more. When performing any service that may risk exposure of compressor oil to the roof, take appropriate precautions to protect roofing. Procedures which risk oil leakage include, but are not limited to, compressor replacement, repairing refrigerant leaks, replacing refrigerant components such as filter drier, pressure switch, metering device, coil, accumulator, or reversing valve.

#### Synthetic Roof Precautionary Procedure

- 1. Cover extended roof working area with an impermeable polyethylene (plastic) drip cloth or tarp. Cover an approximate 10x10 ft (3x3 m) area.
- 2. Cover area in front of the unit service panel with a terry cloth shop towel to absorb lubricant spills and prevent run-offs, and protect drop cloth from tears caused by tools or components.
- Place terry cloth shop towel inside unit immediately under component(s) to be serviced and prevent lubricant run-offs through the louvered openings in the unit base.
- 4. Perform required service.
- 5. Remove and dispose of any oil contaminated material per local codes.

#### **Liquid Line Filter Drier**

This filter drier is specifically designed to operate with Puron Advance (R-454B). Use only factory-authorized components. Filter drier must be replaced whenever the refrigerant system is opened. When removing a filter drier, use a tubing cutter to cut the drier from the system. Do not unsweat a filter drier from the system. Heat from unsweating will release moisture and contaminants from drier into system.

#### Puron Advance (R-454B) Refrigerant Charging

Refer to unit information plate and charging chart. Some R-410A refrigerant cylinders contain a dip tube to allow liquid refrigerant to flow from cylinder in upright position. For cylinders equipped with a dip tube, charge Puron Advance (R-454B) units with cylinder in upright position and a commercial metering device in manifold hose. Charge refrigerant into suction-line.

### Check Defrost Thermostat

The defrost thermostat is usually located on the lowest liquid leaving circuit of the left condenser coil (see Fig. 32). The thermostat closes at  $32^{\circ}F(0^{\circ}C)$  and opens at  $65^{\circ}F(18^{\circ}C)$ .

The defrost thermostat signals heat pump that conditions are right for defrost or that conditions have changed to terminate defrost. It is a thermally actuated switch clamped to outdoor coil to sense its temperature. Normal temperature range is closed at  $32^{\circ} \pm 3^{\circ}F$  (0  $\pm$  1.7°C) and open at 65°  $\pm$  5°F (18  $\pm$  2.8°C).

**NOTE:** The defrost thermostat must be located on the liquid side of the outdoor coil on the bottom circuit and as close to the coil as possible. The factor location is on the left/back coil.





### Troubleshooting

### Sequence of Events - Dissipation Mode

- 1. Refrigerant leaks.
- 2. Sensor detects leak.
- 3. Dissipation board send system into Dissipation Mode (energizes G; de-energizes Y and W.) Dissipation board displays Flash Code 1 until refrigerant concentration decreases, at which point Flash Code 3 is displayed. (See Table 15)
- 4. Dissipation Mode continues for at least 10 minutes.
- 5. 5-minute ON delay for system equipment is enabled.
- 6. System resumes normal operation.

#### Flash Codes /Actions

For all flash codes, first try power cycling the system to remove the code.

#### No Power

Verify the wiring to/from pins 1 and 8 on the power harness plug. Check the 24V system wiring from the transformer.

#### Flashing 1

Check for refrigerant leaks using an independent R-454B detector. If no leaks are present, replace the sensor.

#### Flashing 2

Check both ends of the sensor wire harness to ensure proper attachment. Power cycle the system to check whether the flash code has been removed. If the flash code is still present, replace the sensor.

#### Flashing 3

Check for refrigerant leaks using an independent R-454B detector.

#### Flashing 4

If the code does not clear after power cycling the system, replace the dissipation board.

#### Flashing 5

If the code does not clear after power cycling the system, replace the sensor.

### Flashing 6

Press the test button repeatedly. Power cycle the system. If the button cannot be reset, replace the dissipation board.

#### Flashing 7

Verify wiring of all "Y" and "W" wires in the applicable wiring diagram.

### <u>Flashing 8</u>

Verify wiring of all "Y" and "W" wires in the applicable wiring diagram.

Use the Troubleshooting Guides (See Table 13, Table 14, and Table 16) if problems occur with these units.

# Start-up Checklist

Use Start-Up checklist to ensure proper start-up procedures are followed.

My Learning Center is your central location for professional residential HVAC training resources that help strengthen careers and businesses. We believe in providing high quality learning experiences both online and in the classroom.

Access My Learning Center with your HVACpartners credentials at www.MLCtraining.com. Please contact us at mylearning@carrier.com with questions.

#### Table 13 - Troubleshooting Guide - Cooling or Heat Pump Heating Mode

	8 8 1	0
SYMPTOM	CAUSE	REMEDY
	Power Failure	Call power company.
	Fuse blown or circuit breaker tripped	Replace fuse or reset circuit breaker.
Compressor and Outdoor fan will not start.	Defective thermostat, contactor, transformer, or control relay	Replace component.
	Insufficient line voltage	Determine cause and correct.
	Incorrect or faulty wiring	Check wiring diagram and rewire correctly.
	Thermostat setting too high	Lower thermostat setting below room temperature.
	Faulty wiring or loose connections in compressor circuit	Check wiring and repair or replace.
Compressor will not start but Outdoor fan runs.	Compressor motor burned out, seized, or internal overload open	Determine cause Replace compressor.
	Defective run/start capacitor, overload, start relay	Determine cause and replace.
	Refrigerant overcharge or undercharge	Recover refrigerant, evacuate system, and recharge to capacities shown on nameplate.
	Defective compressor	Replace and determine cause.
	Insufficient line voltage	Determine cause and correct.
Compressor cycles (other than normally	Blocked Outdoor	Determine cause and correct.
satisfying thermostat).	Defective run/start capacitor, overload or start relay	Determine cause and replace.
	Defective thermostat	Replace thermostat.
	Faulty Outdoor-fan motor or capacitor	Replace
	Damaged reversing valve	Determine cause and correct
	Restriction in refrigerant system	Locate restriction and remove
	Dirty air filter	Replace filter
		Decrease load or increase unit size
		Posot thormostat
	Low reingerant charge	Poplace compressor
Compressor operates continuously		Replace compressor.
	Air in system	recharge.
	Frosted coil with incorrect defrost operation	Check defrost time settings, Reset as necessary Check defrost temperature switch, Replace as necessary
	Outdoor coil dirty or restricted	Clean coil or remove restriction .
	Dirty air filter	Replace filter.
	Dirty Indoor or Outdoor coil	Clean coil.
Excessive head pressure	Refrigerant overcharged	Recover excess refrigerant.
	Air in system	Recover refrigerant, evacuate system, and recharge.
	Indoor or Outdoor air restricted or air short-cycling	Determine cause and correct.
	Low refrigerant charge	Check for leaks, repair, and recharge.
Head pressure too low.	Compressor IPR leaking	Replace compressor.
	Restriction in liquid tube	Remove restriction.
	High heat load	Check for source and eliminate.
	Compressor IPR leaking	Replace compressor.
Excessive suction pressure.	Refrigerant overcharged	Recover excess refrigerant.
	Reversing valve hung up or leaking internally	Replace valve
	Dirty air filter	Replace Filter.
	Low refrigerant charge	Check for leaks, repair, and recharge.
	Metering device or low side restricted	Remove source of restriction.
	Insufficient Indoor airflow	Increase air quantity. Check filter — replace if necessary.
Suction pressure too low.	Temperature too low in conditioned area	Reset thermostat.
	Outdoor ambient below 55 F (12.8 C)	Install low-ambient kit.
	Field-installed filter-drier restricted	Replace.
	(Heat) Outdoor coil frosted	Move timer on control board to 30 minutes between defrost cvcles
Compressor runs but outdoor fan does not	NC (normally closed) contacts on defrost board open	Check condition of relay on board Replace if necessary

SYMPTOM	CAUSE	REMEDY
	Water in gas line	Drain. Install drip leg.
	No power to furnace	Check power supply fuses, wiring or circuit breaker.
		Check transformer.
	No 24-v power supply to control circuit	NOTE: Some transformers have internal over-current protection
		that requires a cool-down period to reset.
Burners will not ignite	Mis-wired or loose connections	Check all wiring and wire nut connections
Damore will not ignite	Misaligned spark electrodes	Check flame ignition and sense electrode positioning.
	Wisalighed spark electrodes	Adjust as necessary.
		1. Check gas line for air. Purge as necessary. NOTE: After
	No gas at main burners	purging gas line of air, wait at least 5 minutes for any gas to
	No gao at main barriero	dissipate before attempting to light unit.
		2. Check gas valve.
	Dirty air filter	Clean or replace filter as necessary
	Gas input to furnace too low	Check gas pressure at manifold match with that on unit
		nameplate
Inadequate heating	Unit undersized for application	Replace with proper unit or add additional unit
	Restricted airflow	Clean or replace filter. Remove any restriction.
	Limit switch cycles main burners	Check rotation of blower, temperature rise of unit. Adjust as
	Link switch systes main burners	necessary.
		1. Tighten all screws around burner compartment
		<ol><li>Cracked heat exchanger. Replace.</li></ol>
Poor flame characteristics	Incomplete combustion results in: Aldehyde odors,	3. Unit over-fired. Reduce input (change orifices or adjust gas line
T our name characteristics	carbon monoxide, sooting flame, floating flame	or manifold pressure).
		<ol><li>Check burner alignment.</li></ol>
		5. Inspect heat exchanger for blockage. Clean as necessary.

#### Table 14 – Troubleshooting Guide–Heating

Table 15 – Dissipation Board Status Code Descriptions

STAT	US CODE DE	SCRIPTION	FOF	R DISS	<b>IPATION</b>	BOARD
	FLASH CODE CHA	<b>NRT</b>	PIN	COLOR	1-Stage Unit	2-Stage Unit
Yellow LED	Reason	Mode	1	Red	to unit 24VAC	to unit 24VAC
Solid	Normal Operation	Normal Operation	2	Green	to SPP unit G	to SPP unit G
Flashing 1	Sensor >= 20% LFL	Dissipation	4	Yellow	to SPP unit Y	to SPP unit Y1
Flashing 2	Sensor Open	Dissipation	5	Yellow	to TSTAT Y	to TSTAT Y1
Flashing 3	Normal Dissipation After Leak	Dissipation	6	Green White	to TSTAT G	to SPP unit W1
Flashing 4	No Power to G Output	Dissipation w/o Blower	8	Brown	to unit COM	to unit COM
Flashing 5	Fault with A2L Digital Sensor	Dissipation	See In	stallation Ir	nstructions For S	pecific Details*'
Flashing 6	Test Button Stuck (>30s)	Dissipation				
Flashing 7	Y or W Wiring Inverted	Normal Operation				Regim
Flashing 8	Y or W Shorted	Normal Operation				F¥ÿ2
		<u> </u>			350502-201	REV

A240111

Table 10 - Troubleshooting Guide-LED Status Codes				
SYMPTOM	CAUSE	REMEDY		
No Power Hardware failure (LED OFF)	Loss of power to control module (IGC)*.	Check 5-amp fuse son IGC*, power to unit, 24-v circuit breaker, and transformer. Units without a 24-v circuit breaker have an internal overload in the 24-v transformer. If the overload trips, allow 10 minutes for automatic reset.		
Check fuse, low voltage circuit (LED 1 flash)	Fuse is blown or missing or short circuit in secondary (24VAC) wiring.	Replace fuse if needed. Verify no short circuit in low voltage (24 VAC wiring).		
Limit switch faults (LED 2 flashes)	High temperature limit switch is open.	Check the operation of the indoor (evaporator) fan motor. Ensure that the supply-air temperature rise is in accordance with the range on the unit nameplate. Clean or replace filters.		
Flame sense fault (LED 3 flashes)	The IGC* sensed flame that should not be present.	Reset unit. If problem persists, replace control board.		
consecutive limit switch faults (LED 4 flashes)	Inadequate airflow to unit.	Check the operation of the indoor (evaporator) fan motor and that supply-air temperature rise agrees with range on unit nameplate information.		
Ignition lockout (LED 5 flashes)	Unit unsuccessfully attempted ignition for 15 minutes.	Check ignitor and flame sensor electrode spacing, gaps, etc. Ensure that fame sense and ignition wires are properly terminated. Verify that unit is obtaining proper amount of gas.		
Pressure Switch motor fault (LED 6 flashes)	Open pressure switch.	Verify wiring connections to pressure switch and inducer motor. Verify pressure switch hose is tightly connected to both inducer housing and pressure switch. Verify inducer wheel is properly attached to inducer motor shaft. Verify inducer motor shaft is turning.		
Rollout switch fault (LED 7 flashes)	Rollout switch has opened.	Rollout switch will automatically reset, but IGC* will continue to lockout unit. Check gas valve operation. Ensure that induced-draft blower wheel is properly secured to motor shaft. Inspect heat exchanger. Reset unit at unit disconnect.		
Internal control fault (LED 8 flashes)	Microprocessor has sensed an error in the software or hardware.	If error code is not cleared by resetting unit power, replace the IGC*.		
Temporary 1 hr auto reset (LED 9 flashes)	Electrical interference impeding IGC software	Reset 24-v. to control board or turn thermostat off, then on again. Fault will automatically reset itself in one (1) hour.		

#### Table 16 – Troubleshooting Guide–LED Status Codes

**IMPORTANT**: Refer to Table 14-Troubleshooting Guide-Heating for additional troubleshooting analysis.

#### LEGEND

IGC-Integrated Gas Unit Controller

LED-Light-Emitting Diode

# **CAUTION**

# ELECTROSTATIC DISCHARGE (ESD) PRECAUTIONS PROCEDURE RELIABILITY HAZARD

Failure to follow this caution may result in unit component damage. Electrostatic discharge can affect electronic components. Take precautions during furnace installation and servicing to protect the furnace electronic control. Precautions will prevent electrostatic discharges from personnel and hand tools which are held during the procedure. These precautions will help to avoid exposing the control to electrostatic discharge by putting the furnace, the control, and the person at the same electrostatic potential.

# Start-Up Checklist

(Remove and Store in Job Files)

### I. PRELIMINARY INFORMATION

MODEL NO .:	
SERIAL NO.:	
DATE:	

TECHNICIAN:

### II. PRESTART-UP (Insert check mark in box as each item is completed)

- ( ) VERIFY THAT ALL PACKING MATERIALS HAVE BEEN REMOVED FROM UNIT
- ( ) REMOVE ALL SHIPPING HOLD DOWN BOLTS AND BRACKETS PER INSTALLATION INSTRUCTIONS
- ( ) CHECK ALL ELECTRICAL CONNECTIONS AND TERMINALS FOR TIGHTNESS
- () CHECK GAS PIPING FOR LEAKS (WHERE APPLICABLE)
- ( ) CHECK THAT INDOOR (EVAPORATOR) AIR FILTER IS CLEAN AND IN PLACE
- ( ) VERIFY THAT UNIT INSTALLATION IS LEVEL
- ( ) CHECK FAN WHEEL, AND PROPELLER FOR LOCATION IN HOUSING/ORIFICE AND SETSCREW TIGHTNESS
- ( ) INSPECT TUBING

### **III. START-UP**

#### ELECTRICAL

SUPPLY VOLTAGE			
COMPRESSOR AMPS			
INDOOR (EVAPORATOR) FAN AMPS			
TEMPERATURES			
OUTDOOR (CONDENSER) AIR TEMPERATURE	DB		
RETURN-AIR TEMPERATUREDB	WB		
COOLING SUPPLY AIR DB	WB		
HEAT PUMP SUPPLY AIR			
GAS HEAT SUPPLY AIR			
PRESSURES			
GAS INLET PRESSURE	IN. W.C.		
GAS MANIFOLD PRESSURE	IN. W.C.		
REFRIGERANT SUCTION PSIG, SUCT	TION LINE TEMP*		
REFRIGERANT DISCHARGE PSIG, L	IQUID TEMP <sup>+</sup>		
( ) VERIFY REFRIGERANT CHARGE USING CHARGING CHARTS			
GAS HEAT TEMPERATURE RISE			
TEMPERATURE RISE (See Literature) RANGE			
MEASURED TEMPERATURE RISE			

\* Measured at suction inlet to compressor †Measured at liquid line leaving condenser.

## Decommissioning

This unit is designed to provide many years of comfort. Eventually, this unit will need to be replaced.

Work procedure for decommissioning:

- 1. All maintenance staff and others working in the local area shall be instructed on the nature of work being performed. Any nearby confined space work shall be avoided.
- 2. If any hot work is to be conducted on the refrigeration system or associated parts, a fire extinguisher shall be available on hand. A dry powder or CO2 fire extinguisher shall be located near the refrigerant charge recovery area.
- 3. Potential ignition sources, including cigarette smoking, must not be used by the technician and must be kept far away from the unit site.
- 4. Ensure that electrical power is available to run recovery equipment prior moving to the next step.
- 5. Using a R-454B leak detector, check around the area of the unit for presence of refrigerant. Note: Leak detector must be non-sparking and adequately sealed.
- 6. Shut off main gas shut-off valve to appliance.
- 7. Shut off power to unit and install lockout tag on the electrical whip to the unit.
- 8. Remove gas line to gas valve and cap.
- 9. Before beginning recovery of the refrigerant:
  - a. Make sure that handling equipment is available, if needed, to handle the refrigerant recovery cylinders.
  - b. All personal protective equipment is available, and must be used correctly.
  - c. Recovery process must be performed by an EPA-certified technician.
  - d. All recovery equipment and cylinders must conform to appropriate standards and be suitable for the recovery of FLAMMABLE REFRIGERANTS (R-454B).
- 10. Recovery process:
  - a. Technician must be present during the entire recovery process.
  - b. Use a recovery cylinder that is for R-454B and do not mix refrigerants. If possible, use an empty cylinder and cool before use. Cylinders shall be complete with pressure-relief valve and associated shut-off valves in good working order. Make sure the recovery cylinder is situated on the scale prior to recovery.
  - c. Note the original charge amount listed on the rating plate. Make sure that there are sufficient recovery cylinders available to recover all the charge.
  - d. Before using the recovery machine, check that it is suitable for use with FLAMMABLE REFRIGERANTS (R-454B), is in satisfactory working order, has been properly maintained, and

associated electrical components are sealed to prevent ignition in the event of a refrigerant release. If there are any doubts, please contact the recovery machine manufacturer before using.

- e. Connect recovery equipment to gauge ports on unit and to the recovery cylinder.
- f. In accordance with all recovery machine instructions, begin the recovery machine.
- g. Cylinders must not be overfilled (No more than 80% volume liquid charge). Do not exceed the maximum working pressure of the cylinder.
- h. When the cylinders have been filled correctly and the evacuation process is complete, close all cylinder valves are closed off.
- i. Record the amount of R-454B refrigerant recovered and note on the logs of each cylinder used.
- j. Cut out the form below and fill out, sign, and date. Affix the form in a prominent location on the unit using tape.

DECOMMISSIONED		
Model Number:		
Serial Number:		
UNIT EMPTIED OF REFRIGERANT		
Date:		
Signature:		

- k. If refrigerant was **not** recovered in decommission process. Do not fill out the decommissioned label above. Ensure all A2L labeling is still on unit.
- Recovered refrigerant shall not be charged into another REFRIGERATING SYSTEM unless it has been cleaned and checked.
- m.Recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery systems, and especially not in cylinders.
- n. If compressors or compressor oils are to be removed, ensure that they have been evacuated to 200 microns or less to make certain that R-454B does not remain within the lubricant. The evacuation process shall be carried out prior to returning the compressor to the supplier. The crankcase electric heat may be used to accelerate the compressor evacuation process. A torch must not be used. When oil is drained from a system, it shall be carried out safely.

Edition Date: 04/24