800SA/801SA 80% AFUE, Single Stage, Multi-Speed ECM, 4-Way Multipoise, Non-Condensing Gas Furnace



Installation, Start-Up, Operating and Service and Maintenance Instructions

NOTE: Read the entire instruction manual before starting the installation

installation.
TABLE OF CONTENTS
Table 1 – Dimensions
SAFETY CONSIDERATIONS
INTRODUCTION4
LOCATION
Table 2 – Minimum Free Area Required for Each Combustion Air
Opening or Duct to Outdoors
Table 3 – Minimum Space Volumes for 100% Combustion, Ventila-
tion, and Dilution from Indoors
INSTALLATION
Table 4 – Opening Dimensions - In. (mm)
AIR DUCTS
Table 5 – Air Delivery - CFM (With Filter)*
GAS PIPING14
Table 6 – Maximum Capacity of Pipe*
ELECTRICAL CONNECTIONS
Table 7 – Electrical Data
VENTING
Table 8 - Combined Appliance Maximum Input Rating
in Thousands of BTUh per Hour
Table 9 – Minimum Allowable Input Rating of Space-Heating Appli
ance in Thousands of BTUh per Hour
START-UP, ADJUSTMENT, AND SAFETY CHECK 25
WIRING DIAGRAM
Table 10 – Altitude Derate Multiplier for U.S.A
Table 11 - Orifice Size* and Manifold Pressure (In. W.C.) for Gas In
put Rate
Table 12 – Orifice Size* And Manifold Pressure (In. W.C.) For Gas
Input Rate
Table 13 – Gas Rate (Cu Ft./Hr.)
SERVICE AND MAINTENANCE PROCEDURES
CARE AND MAINTENANCE
Table 14 – Filter Size Information (In. / mm)
SEQUENCE OF OPERATION
TROUBLESHOOTING
PARTS REPLACEMENT INFORMATION GUIDE







Use of the AHRI Certified TM Mark indicates a manufacturer's participation in the program. For verification of certification for individual products, go to www.ahridirectory.org.

A200103

WARNING


CARBON MONOXIDE POISONING HAZARD

Failure to follow this warning could result in personal injury and/or death.

Carbon Monoxide (CO) is a colorless, odorless, and tasteless poisonous gas that can be fatal when inhaled. Follow all installation, maintenance, and service instructions. See additional information below regarding the installation of a CO Alarm.

Most states in the USA and jurisdictions in Canada have laws that require the use of Carbon Monoxide (CO) alarms with fuel burning products. Examples of fuel burning products are furnaces, boilers, space heaters, generators, water heaters, stoves/ranges, clothes dryers, fireplaces, incinerators, automobiles, and other internal combustion engines. Even if there are no laws in your jurisdiction requiring a CO Alarm, it's highly recommended that whenever any fuel burning product is used in or around the home or business that the dwelling be equipped with a CO Alarm(s). The Consumer Product Safety Commission recommends the use of CO Alarm(s). The CO Alarm(s) must be installed, operated, and maintained according to the CO Alarm manufacturer's instructions. For more information about Carbon Monoxide, local laws, or to purchase a CO Alarm online, please visit the following website. https://www.kidde.com.

Portions of the text and tables are reprinted from current edition of NFPA 54/ANSI Z223.1E, with permission of National Fire Protection Association, Quincy, MA 02269 and American Gas Association, Washington DC 20001. This reprinted material is not the complete and official position of the NFPA or ANSI on the referenced subject, which is represented only by the standard in its entirety.



A190084

NOTES:

- 1.Two additional 7/8-in. (22 mm) diameter holes are located in the top plate.
- 2.Minimum return-air openings at furnace, based on metal duct. If flex duct is used, see flex duct manufacturer's recommendations for equivalent diameters.
 - a. For 800 CFM-16-in. (406 mm) round or 14 1/2 x 12-in. (368 x 305 mm) rectangle.
 - b. For 1200 CFM-20-in. (508 mm) round or 14 1/2 x 19 1/2-in. (368 x 495 mm) rectangle.
 - c. For 1600 CFM-22-in. (559 mm) round or 14 1/2 x 22 1/16-in. (368 x 560mm) rectangle.
 - d. For airflow requirements above 1800 CFM, see Air Delivery table in Product Data Sheet literature for specific use of single side inlets. The use of both side inlets, a combination of 1 side and the bottom, or the bottom only will ensure adequate return air openings for airflow requirements above 1800 CFM.

Fig. 1 – Dimensional Drawing

Table 1 – Dimensions

Unit Size	A CABINET WIDTH	B OUTLET WIDTH	C TOP AND BOTTOM FLUE COLLAR	D BOTTOM INLET WIDTH	VENT CONNECTION SIZE	SHIP WT. LB. (KG)
36045E14	14-3/16 (360)	12-9/16 (319)	9-5/16 (237)	12-11/16 (322)	4 (102)	104 (47)
36045E17	17-1/2 (445)	15-7/8 (403)	11-9/16 (294)	16 (406)	4 (102)	119 (54)
36070E14	14-3/16 (360)	12-9/16 (319)	9-5/16 (237)	12-11/16 (322)	4 (102)	114 (52)
36070E17	17-1/2 (445)	15-7/8 (403)	11-9/16 (294)	16 (406)	4 (102)	120 (54)
48070E17	17-1/2 (445)	15-7/8 (403)	11-9/16 (294)	16 (406)	4 (102)	126 (57)
48070E21	21 (533)	19-3/8 (492)	13-5/16 (338)	19-1/2 (495)	4 (102)	142 (64)
42090E17	17-1/2 (445)	15-7/8 (403)	11-9/16 (294)	16 (406)	4 (102)	131 (49)
48090E21	21 (533)	19-3/8 (492)	13-5/16 (338)	19-1/2 (495)	4 (102)	137 (62)
60090E21	21 (533)	19-3/8 (492)	13-5/16 (338)	19-1/2 (495)	4 (102)	140 (64)
60090E24	24-1/2 (622)	22-7/8 (581)	15-1/16 (383)	23 (584)	4 (102)	146 (66)
60110E21	21 (533)	19-3/8 (492)	13-5/16 (338)	19-1/2 (495)	4 (102)	146 (66)
60110E24	24-1/2 (622)	22-7/8 (581)	15-1/16 (383)	23 (584)	4 (102)	161 (73)
60135E24	24-1/2 (622)	22-7/8 (581)	15-1/16 (383)	23 (584)	4 (102)	167 (76)
60155E24	24-1/2 (622)	22-7/8 (581)	15-1/16 (383)	23 (584)	4 (102)	168 (76)

^{*135} and 155 size furnaces requires a 5 or 6-in. (127 or 152 mm) vent. Use a vent adapter between furnace and vent stack. See Installation Instructions for complete installation requirements.

SAFETY CONSIDERATIONS

A WARNING

FIRE, EXPLOSION, ELECTRICAL SHOCK, AND CARBON MONOXIDE POISONING HAZARD

Failure to follow this warning could result in dangerous operation, serious injury, death, or property damage.

Improper installation, adjustment, alteration, service, maintenance, or use could cause carbon monoxide poisoning, explosion, fire, electrical shock, or other conditions which may cause personal injury or property damage. Consult a qualified service agency, local gas supplier, or your distributor or branch for information or assistance. The qualified service agency must use only factory-authorized and listed kits or accessories when modifying this product.

WARNING

FIRE, EXPLOSION, ELECTRICAL SHOCK, AND CARBON MONOXIDE POINSING HAZARD

Failure to follow this warning could result in dangerous operation, personal injury, death, or property damage.

Furnaces shall NOT be twinned (i.e. tandem or staged operation) unless approved in factory technical specifications literature for the furnace. A factory authorized, field-supplied Twinning Kit MUST be used. Consult furnace pre-sale literature for specific models approved for twinning and the correct twinning kit. Twinned furnaces must be installed on both a common supply AND a common return duct system as shown in the Twinning Kit Installation Instructions. Only two furnaces can be twinned on a common supply and return duct system using a factory authorized twinning kit.

CAUTION

FURNACE RELIABILITY HAZARD

Improper installation or misapplication of furnace may require excessive servicing or cause premature component failure.

Application of this furnace should be indoors with special attention given to vent sizing and material, gas input rate, air temperature rise, unit leveling, and unit sizing.

Improper installation, adjustment, alteration, service, maintenance, or use can cause explosion, fire, electrical shock, or other conditions which may cause death, personal injury, or property damage. Consult a qualified installer, service agency, or your distributor or branch for information or assistance. The qualified installer or agency must use factory-authorized kits or accessories when modifying this product. Refer to the individual instructions packaged with the kits or accessories when installing.

Follow all safety codes. Wear safety glasses, protective clothing, and work gloves. Have a fire extinguisher available. Read these instructions thoroughly and follow all warnings or cautions include in literature and attached to the unit. Consult local building codes, the current editions of the current edition of National Fuel Gas Code (NFGC) NFPA 54/ANSI Z223.1 and the current edition of National Electrical Code (NEC) NFPA 70

Recognize safety information. This is the safety-alert symbol \triangle . When you see this symbol on the unit and in instructions or manuals, be alert to the potential for personal injury.

Understand the signal words **DANGER**, **WARNING**, and **CAUTION**. These words are used with the safety-alert symbol. **DANGER** identifies

the most serious hazards which will result in severe personal injury or death. **WARNING** signifies hazards which could result in personal injury or death. **CAUTION** is used to identify unsafe practices which may result in minor personal injury or product and property damage. **NOTE** is used to highlight suggestions which will result in enhanced installation, reliability, or operation.

A CAUTION

CUT HAZARD

Failure to follow this caution may result in personal injury.

Sheet metal parts may have sharp edges or burrs. Use care and wear appropriate protective clothing, safety glasses and gloves when handling parts and servicing furnaces.

The following additional safety considerations should be followed for gas furnaces:

- 1. Use only with type of gas approved for this furnace. Refer to the furnace rating plate.
- 2. Install this furnace only in a location and position as specified in the "Location" section of these instructions.
- 3. Provide adequate combustion and ventilation air to the furnace space as specified in "Air for Combustion and Ventilation" section.
- 4. Combustion products must be discharged outdoors. Connect this furnace to an approved vent system only, as specified in the "Venting" section of these instructions.
- 5. Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections, as specified in the "Gas Piping" section.
- 6. Always install furnace to operate within the furnace's intended temperature-rise range with a duct system which has an external static pressure within the allowable range, as specified in the "Start-Up, Adjustments, and Safety Check" section. See furnace rating plate.
- 7. When a furnace is installed so that supply ducts carry air circulated by the furnace to areas outside the space containing the furnace, the return air shall also be handled by duct(s) sealed to the furnace casing and terminating outside the space containing the furnace. See "Air Ducts" section.
- 8. A gas-fired furnace for installation in a residential garage must be installed as specified in the warning box in the "Location" section.
- 9. The furnace may be used for construction heat provided that the furnace installation and operation complies with the first CAUTION in the LOCATION section of these instructions.
- 10. These Multipoise Gas-Fired Furnaces are CSA (formerly A.G.A. and C.G.A). design-certified for use with natural and propane gases (see furnace rating plate) and for installation in alcoves, attics, basements, closets, utility rooms, crawlspaces, and garages. The furnace is factory-shipped for use with natural gas. A CSA listed accessory gas conversion kit is required to convert furnace for use with propane gas.
- 11. See Fig. 2 for required clearances to combustible construction.
- 12. Maintain a 1-in. (25 mm) clearance from combustible materials to supply air ductwork for a distance of 36 inches (914 mm) horizontally from the furnace. See current edition of NFPA 90B or local code for further requirements.
- 13. These furnaces SHALL NOT be installed directly on carpeting, tile, or any other combustible material other than wood flooring. In downflow installations, factory accessory floor base MUST be used when installed on combustible materials and wood flooring. Special base is not required when this furnace is installed on manufacturer's Coil Assembly Part No. CAR, CAP, CNRV, and CNPV, or when Coil Box Part No. KCAKC is used. See Fig. 2 for clearance to combustible construction information.

INTRODUCTION




Fig. 2 – Clearances to Combustibles

This 4-way multipoise Category I fan-assisted furnace is CSA design-certified. A Category I fan-assisted furnace is an appliance equipped with an integral mechanical means to either draw or force products of combustion through the combustion chamber and/or heat exchanger. The furnace is factory-shipped for use with natural gas.

This furnace is not approved for installation in mobile homes, recreational vehicles, or outdoors. This furnace is designed for minimum continuous return-air temperature of 60°F (16°C) db or intermittent operation down to 55°F (13°C) db such as when used with a night setback thermostat. Return-air temperature must not exceed 80°F (27°C) db. Failure to follow these return-air temperature limits may affect reliability of heat exchangers, motors, and controls (see Fig. 3).

For accessory installation details, refer to the applicable instruction literature.

NOTE: Remove all shipping brackets and materials before operating the furnace.




Fig. 3 – Return Air Temperature

MARNING

FIRE HAZARD

Failure to follow this warning could result in personal injury, death and/or property damage.

Do not install the furnace on its back or hang furnace with control compartment facing downward. Safety control operation will be adversely affected. Never connect return-air ducts to the back of the furnace (see Fig. 4).




Fig. 4 - Prohibit Installation on Back

A02054

WARNING

FIRE HAZARD

Failure to follow this warning could result in personal injury, death, and/or property damage.

When the furnace is installed in a residential garage, the burners and ignition sources must be located at least 18 inches above the floor. The furnace must be located or protected to avoid damage by vehicles. When the furnace is installed in a public garage, airplane hangar, or other building having a hazardous atmosphere, the furnace must be installed in accordance with the NFGC (see Fig. 5).




Fig. 5 – Installation in a Garage

A93044

CODES AND STANDARDS

Follow all national and local codes and standards in addition to these instructions. The installation must comply with regulations of the serving gas supplier, local building, heating, plumbing, and other codes. In absence of local codes, the installation must comply with the national codes listed below and all authorities having jurisdiction.

In the United States, follow all codes and standards for the following:

<u>Safety</u>

USA: Current edition of National Fuel Gas Code (NFGC) NFPA 54/ANSI Z223.1 and the Installation Standards, Warm Air Heating and Air Conditioning Systems ANSI/NFPA 90B.

General Installation

Current edition of the NFGC and the NFPA 90B. For copies, contact the National Fire Protection Association Inc., Batterymarch Park, Quincy, MA 02269; (www.NFPA.org) or for only the NFGC, contact the

American Gas Association, 400 N. Capitol Street, N.W., Washington, DC 20001 (www.AGA.org).

Combustion and Ventilation Air

Current edition of NFGC NFPA54/ANSI Z223.1 Section 9.3, Air for Combustion and Ventilation.

Duct Systems

Air Conditioning Contractors Association (ACCA) Manual D, Sheet Metal and Air Conditioning Contractors National Association (SMACNA), or American Society of Heating, Refrigeration, and Air Conditioning Engineers (ASHRAE) 2005 Fundamentals Handbook Chapter 35 or 2004 HVAC Systems and Equipment Handbook Chapters 9 and 16.

Acoustical Lining and Fibrous Glass Duct

Current edition of SMACNA and NFPA 90B as tested by UL Standard 181 for Class I Rigid Air Ducts.

Gas Piping and Gas Pipe Pressure Testing

Current edition of NFGC NFPA54/ANSI Z223.1; chapters 5, 6, 7, and 8 and National Plumbing Codes.

Electrical Connections

Current edition of National Electrical Code (NEC) NFPA 70.

Venting

Current edition of NFGC NFPA 54 / ANSI Z223.1; Chapters 12 and 13.

ELECTROSTATIC DISCHARGE (ESD) PRECAUTIONS PROCEDURE

 Disconnect all power to the furnace. Multiple disconnects maybe required. DO NOT TOUCH THE CONTROL OR ANY WIRE CONNECTED TO THE CONTROL PRIOR TO DISCHARGING YOUR BODY'S ELECTROSTATIC CHARGE TO GROUND.

CAUTION

FURNACE RELIABILITY HAZARD

Improper installation or service of furnace may cause premature furnace component failure.

Electrostatic discharge can affect electronic components. Follow the Electrostatic Discharge Precautions Procedure listed below during furnace installation and servicing to protect the furnace electronic control. Precautions will prevent electrostatic discharges from personnel and hand tools which are held during the procedure. These precautions will help to avoid exposing the control to electrostatic discharge by putting the furnace, the control, and the person at the same electrostatic potential.

- Firmly touch the clean, unpainted, metal surface of the furnace chassis which is close to the control. Firmly touch the clean, unpainted, metal surface of the furnace chassis which is close to the control. Tools held in a person's hand during grounding will be satisfactorily discharged.
- 3. After touching the chassis, you may proceed to service the control or connecting wires as long as you do nothing to recharge your body with static electricity (for example; DO NOT move or shuffle your feet, do not touch ungrounded objects, etc.).
- 4. If you touch ungrounded objects (and recharge your body with static electricity), firmly touch a clean, unpainted metal surface of the furnace again before touching control or wires.
- 5. Use this procedure for installed and uninstalled (ungrounded) furnaces
- 6. Before removing a new control from its container, discharge your body's electrostatic charge to ground to protect the control from damage. If the control is to be installed in a furnace, follow items 1 through 4 before bringing the control or yourself in contact with the

- furnace. Put all used and new controls into containers before touching ungrounded objects.
- 7. An ESD service kit (available from commercial sources) may also be used to prevent ESD damage.

A CAUTION

PERSONAL INJURY AND/OR PROPERTY DAMAGE HAZARD

Improper use or installation of this furnace may cause premature furnace component failure.

This gas furnace may be used for heating buildings under construction provided that:

- -The furnace is permanently installed with all electrical wiring, piping, venting and ducting installed according to these installation instructions. A return air duct is provided, sealed to the furnace casing, and terminated outside the space containing the furnace. This prevents a negative pressure condition as created by the circulating air blower, causing a flame rollout and/or drawing combustion products into the structure.
- -The furnace is controlled by a thermostat. It may not be "hot wired" to provide heat continuously to the structure without thermostatic control.
- -Clean outside air is provided for combustion. This is to minimize the corrosive effects of adhesives, sealers and other construction materials. It also prevents the entrainment of drywall dust into combustion air, which can cause fouling and plugging of furnace components.
- -The temperature of the return air to the furnace is maintained between 55°F (13°C) and 80°F (27°C), with no evening setback or shutdown. The use of the furnace while the structure is under construction is deemed to be intermittent operation per our installation instructions.
- -The air temperature rise is within the rated rise range on the furnace rating plate, and the gas input rate has been set to the nameplate value.
- -The filters used to clean the circulating air during the construction process must be either changed or thoroughly cleaned prior to occupancy.
- -The furnace, ductwork and filters are cleaned as necessary to remove drywall dust and construction debris from all HVAC system components after construction is completed.
- -Verify proper furnace operating conditions including ignition, gas input rate, air temperature rise, and venting according to these installation instructions.

WARNING

CARBON MONOXIDE POISONING HAZARD

Failure to follow this warning could result in personal injury or death, and unit component damage.

Corrosive or contaminated air may cause failure of parts containing flue gas, which could leak into the living space. Air for combustion must not be contaminated by halogen compounds, which include fluoride, chloride, bromide, and iodide. These elements can corrode heat exchangers and shorten furnace life. Air contaminants are found in aerosol sprays, detergents, bleaches, cleaning solvents, salts, air fresheners, and other household products. Do not install furnace in a corrosive or contaminated atmosphere. Make sure all combustion and circulating air requirements are met, in addition to all local codes and ordinances.

LOCATION GENERAL

This multipoise furnace is shipped in packaged configuration. Some assembly and modifications are required when used in any of the four applications (see Fig. 6).




Fig. 6 – Multipoise Orientations

A02097

This furnace must:

- be installed so the electrical components are protected from water.
- not be installed directly on any combustible material other than wood flooring for upflow applications. Downflow installations require use of a factory-approved floor base or coil assembly when installed on combustible materials or wood flooring (refer to SAFETY CONSIDERATIONS).
- be located as close to the chimney or vent and attached to an air distribution system. Refer to Air Ducts section.
- be provided ample space for servicing and cleaning. Always comply
 with minimum fire protection clearances shown on the furnace
 clearance to combustible label.

The following types of furnace installations may require OUTDOOR AIR for combustion due to chemical exposures:

- · Commercial buildings
- · Buildings with indoor pools
- · Laundry rooms
- · Hobby or craft rooms, and
- · Chemical storage areas

If air is exposed to the following substances, it should not be used for combustion air, and outdoor air may be required for combustion:

- · Permanent wave solutions
- · Chlorinated waxes and cleaners
- · Chlorine based swimming pool chemicals
- · Water softening chemicals
- · De-icing salts or chemicals
- · Carbon tetrachloride
- Halogen type refrigerants
- Cleaning solvents (such as perchloroethylene)
- Printing inks, paint removers, varnishes, etc.
- · Hydrochloric acid
- · Cements and glues
- · Antistatic fabric softeners for clothes dryers
- · Masonry acid washing materials

All fuel-burning equipment must be supplied with air for fuel combustion. Sufficient air must be provided to avoid negative pressure in the equipment room or space. A positive seal must be made between the furnace cabinet and the return-air duct to prevent pulling air from the burner area and from draft safeguard opening.

LOCATION RELATIVE TO COOLING EQUIPMENT

The cooling coil must be installed parallel with, or on the downstream side of the unit to avoid condensation in the heat exchangers. When installed parallel with the furnace, dampers or other flow control must prevent chilled air from entering the furnace. If the dampers are manually operated, they must be equipped with means to prevent operation of either unit unless the damper is in the full-heat or full-cool position.

A CAUTION

FURNACE CORROSION HAZARD

Failure to follow this caution may result in furnace damage.

Air for combustion must not be contaminated by halogen compounds, which include fluoride, chloride, bromide, and iodide. These elements can corrode heat exchangers and shorten furnace life. Air contaminants are found in aerosol sprays, detergents, bleaches, cleaning solvents, salts, air fresheners, and other household products.

AIR FOR COMBUSTION AND VENTILATION

Provisions for adequate combustion, ventilation, and dilution air must be provided in accordance with:

 U.S. installations: Section 9.3 of the current edition of NFGC NFPA54/ANSI Z223.1, Air for Combustion and Ventilation, and applicable provisions of the local building codes.

WARNING

CARBON MONOXIDE POISONING HAZARD

Failure to follow this warning could result in personal injury or death. The operation of exhaust fans, kitchen ventilation fans, clothes dryers, attic exhaust fans or fireplaces could create a NEGATIVE PRESSURE CONDITION at the furnace. Make-up air MUST be provided for the ventilation devices, in addition to that required by the furnace. Refer to Carbon Monoxide Poisoning Hazard warning in venting section of these instructions to determine if an adequate amount of make-up air is available.


The requirements for combustion and ventilation air depend upon whether or not the furnace is located in a space having a volume of at least 50 cubic feet per 1,000 BTUh input rating for all gas appliances installed in the space.

- Spaces having less than 50 cubic feet per 1,000 BTUh require the OUTDOOR COMBUSTION AIR METHOD.
- Spaces having at least 50 cubic feet per 1,000 BTUh may use the INDOOR COMBUSTION AIR, STANDARD or KNOWN AIR INFILTRATION METHOD.

Outdoor Combustion Air Method

- Provide the space with sufficient air for proper combustion, ventilation, and dilution of flue gases using permanent horizontal or vertical duct(s) or opening(s) directly communicating with the outdoors or spaces that freely communicate with the outdoors.
- Fig. 7 illustrates how to provide TWO OUTDOOR OPENINGS, one inlet and one outlet combustion and ventilation air opening, to the outdoors
 - a. One opening **MUST** commence within 12-in. (300 mm) of the ceiling and the second opening **MUST** commence within 12-in. (300 mm) of the floor.
 - b. Size openings and ducts per Fig. 7 and Table 2.
 - c. TWO HORIZONTAL DUCTS require 1 square inch of free area per 2,000 BTUh (1,100 mm2/kW) of combined input for all gas appliances in the space per Fig. 7 and Table 2.
 - d. TWO OPENINGS OR VERTICAL DUCTS require 1 square inch of free area per 4,000 BTUh (550 mm2/kW) for combined input of all gas appliances in the space per Fig. 7 and Table 2.
- 3. ONE OUTDOOR OPENING requires:


- a. 1 square inch of free area per 3,000 BTUh (734 mm2/kW) for combined input of all gas appliances in the space per Table 2 and
- b. Not less than the sum of the areas of all vent connectors in the space.



*Minimum dimensions of 3 in. (76 mm).

NOTE: Use any of the following combinations of openings: A&B, C&D, D&E, F&G

Fig. 7 – Air for Combustion, Ventilation, and Dilution for Outdoors



*Minimum opening size is 100 in.2 with minimum dimensions of 3^{A03175} (76 mm).

*Minimum of 3 in. (76 mm), when type -B1 vent is used.

Fig. 8 – Air for Combustion, Ventilation, and Dilution from Indoors

The opening shall commence within 12" (300 mm) of the ceiling. Appliances in the space shall have clearances of at least 1" (25 mm) from the sides and back and 6" (150 mm) from the front. The opening shall directly communicate with the outdoors or shall communicate through a vertical or horizontal duct to the outdoors or spaces (crawl or attic) that freely communicate with the outdoors.

- -Indoor Combustion Air NFPA & AGA
- -Standard and Known-Air-Infiltration Rate Methods
- -Indoor air is permitted for combustion, ventilation, and dilution, if the **Standard** or **Known-Air-Infiltration** Method is used.

! WARNING

CARBON MONOXIDE POISONING HAZARD

Failure to follow this warning could result in death and/or personal injury.

Many homes require air to be supplied from outdoors for furnace combustion, ventilation, and dilution of flue gases. The furnace combustion air supply must be provided in accordance with this instruction manual.

Table 2 - Minimum Free Area Required for Each Combustion Air Opening or Duct to Outdoors

A03174

FURNACE	TWO HORIZONTAL DUCTS (1 SQ. IN./2,000 BTUH) (1,100 SQ. MM/KW)		SINGLE DUCT (1 SQ. IN./3,(734 SQ. I	000 BTUH)	TWO OPENINGS OR VERTICAL DUCTS (1 SQ. IN./4,000 BTUH) (550 SQ. MM/KW)		
INPUT (BTUH)	Free Area of Opening and Duct (sq. in. / sq. mm)	Round Duct Diameter (in./mm)	Free Area of Opening and Duct (sq. In. / sq. mm)	Round Duct Diameter (in. / mm)	Free Area of Opening and Duct (sq. In. / sq. mm)	Round Duct Diameter (In./mm)	
44,000	22 (14193)	6 (152)	14.7 (9484)	5 (127)	11 (7097)	4 (102)	
66,000	33 (21290)	7 (178)	22 (14193)	6 (152)	16.5 (10645)	5 (127)	
88,000	44 (28387)	8 (203)	29.3 (18903)	7 (178)	22 (14193)	6 (152)	
110,000	55 (35484)	9 (229)	36.7 (23677)	7 (178)	27.5 (17742)	6 (152)	
132,000	66 (42581)	10 (254)	44 (28387)	8 (203)	33 (21290)	7 (178)	
154,000	77 (49677)	10 (254)	51.3 (33096)	9 (229)	38.5 (24839)	8 (203)	

EXAMPLES: Determining Free Area

FURNACE		WATER HEATER		TOTAL INPUT		
110,000	+	30,000	=	(140,000 divided by 4,000)	=	35.0 Sq. In. for each two Vertical Ducts or Openings
66,000	+	40,000	=	(106,000 divided by 3,000)	=	35.3 Sq. In. for a Single Duct or Opening
88,000	+	30,000	=	(118,000 divided by 2,000)	=	59.0 Sq. In. for each of two Horizontal Ducts

The Standard Method

Use the Standard Method if:

- The space has no less volume than 50 cubic feet per 1,000 BTUh of the maximum input ratings for all gas appliances installed in the space and
- 2. The air infiltration rate is not known to be less than 0.40 air changes per hour (ACH).

Use the **Known Air Infiltration Rate Method** if the infiltration rate is known to be:

- 1. Less than 0.40 ACH and
- 2. Equal to or greater than 0.10 ACH

Infiltration rates greater than 0.60 ACH shall not be used. The minimum required volume of the space varies with the number of ACH and shall be determined per Table 3 or Equations 1 and 2. Determine the minimum required volume for each appliance in the space and add the volumes together to get the total minimum required volume for the space.

Table 3 - Minimum Space Volumes were determined by using the following equations from the current edition of National Fuel Gas Code ANSI Z223.1/NFPA 54:

 For other than fan-assisted appliances, such as a draft hood-equipped water heater:

Volume Other =
$$\frac{21 \text{ft}^3}{\text{ACH}} \left(\frac{\text{I}_{\text{other}}}{1000 \text{ Btu/hr}} \right)$$

2. For fan-assisted appliances such as this furnace:

Volume =
$$\frac{15\text{ft}^3}{\text{ACH}} \left(\frac{\text{I}_{\text{fan}}}{1000 \text{ Btu/hr}} \right)$$

If the following is applied to either equation:

 Iother = combined input of all other than fan-assisted appliances in BTUh/hr

A04003

- Ifan = combined input of all fan-assisted appliances in BTUh/hr
- ACH = air changes per hour (ACH shall not exceed 0.60.)

The following requirements apply to the **Standard Method** and to the **Known Air Infiltration Rate Method**.

- 1. Adjoining rooms can be considered part of a space if:
 - a. There are no closeable doors between rooms.
 - b. Combining spaces on same floor level. Each opening shall have free area of at least 1 in.²/1,000 BTUh (2,000 mm²/kW) of the total input rating of all gas appliances in the space, but not less than 100 in.² (0.06 m²). One opening shall commence within 12" (300 mm) of the ceiling and the second opening shall commence within 12" (300 mm) of the floor. The minimum dimension of air openings shall be at least 3 in. (80 mm) (see Fig. 8).
 - c. Combining space on different floor levels. The volumes of spaces on different floor levels shall be considered as communicating spaces if connected by one or more permanent openings in doors or floors having free area of at least 2 in.²/1,000 BTUh (4,400 mm²/kW) of total input rating of all gas appliances.

Table 3 – Minimun	Snace Vo	lumes for 1	100% C	ombustion	Ventilation	and Dilution	from Indoors
Table 5 – Millilliuli	I Space vo	iumes ioi i	LUU /0 C	viii vusuvii.	venunauon.	anu Dhuuuuh	HUMI HUMUUS

A04002

ACH*	_	IAN FAN-ASSIST BTUH GAS INPU		FAN-ASSISTED TOTAL (1,000'S BTUH GAS INPUT RATE)						
жен	30	40	50	44	66	88	110	132		
	Space Volume (ft. ³)									
0.60	1,050	1,400	1,750	1,100	1,650	2,200	2,750	3,300		
0.50	1,260	1,680	2,100	1,320	1,980	2,640	3,300	3,960		
0.40	1,575	2,100	2,625	1,650	2,475	3,300	4,125	4,950		
0.30	2,100	2,800	3,500	2,200	3,300	4,400	5,500	6,600		
0.20	3,150	4,200	5,250	3,300	4,950	6,600	8,250	9,900		
0.10	6,300	8,400	10,500	6,600	9,900	13,200	16,500	19,800		
0.00	NP	NP	NP	NP	NP	NP	NP	NP		

- *. Air Changes/Hour
- 2. An attic or crawlspace may be considered a space that freely communicates with the outdoors provided there are adequate permanent ventilation openings directly to outdoors having free area of at least 1-in.²/4,000 BTUh of total input rating for all gas appliances in the space.
- 3. In spaces that use the Indoor Combustion Air Method, infiltration should be adequate to provide air for combustion, permanent ventilation and dilution of flue gases. However, in buildings with unusually tight construction, additional air MUST be provided using the methods described in the Outdoor Combustion Air Method section.
- 4. Unusually tight construction is defined as construction with:
 - a. Walls and ceilings exposed to the outdoors have a continuous, sealed vapor barrier. Openings are gasketed or sealed and
 - b. Doors and openable windows are weatherstripped and
 - c. Other openings are caulked or sealed. These include joints around window and door frames, between sole plates and floors, between wall-ceiling joints, between wall panels, at penetrations for plumbing, electrical and gas lines, etc.

Combination of Indoor and Outdoor Air

- Indoor openings shall comply with the Indoor Combustion Air Method below and,
- Outdoor openings shall be located as required in the Outdoor Combustion Air Method mentioned previously and,
- 3. Outdoor openings shall be sized as follows:
 - a. Calculate the Ratio of all Indoor Space volume divided by required volume for Indoor Combustion Air Method below.
 - Outdoor opening size reduction Factor is 1 minus the Ratio in a. above.
 - c. Minimum size of Outdoor openings shall be the size required in Outdoor Combustion Air Method above multiplied by reduction Factor in b. above. The minimum dimension of air openings shall be not less than 3 in. (80 mm).

INSTALLATION UPFLOW INSTALLATION

Bottom Return Air Inlet

These furnaces are shipped with bottom closure panel installed in bottom return-air opening. Remove and discard this panel when bottom return air is used. To remove bottom closure panel, perform the following:

- 1. Tilt or raise furnace and remove two screws holding bottom filler panel (see Fig. 9).
- 2. Rotate bottom filler panel downward to release holding tabs.
- 3. Remove bottom closure panel.
- 4. Reinstall bottom filler panel and screws.




Fig. 9 - Removing Bottom Closure Panel

A10273

Side Return Air Inlet

These furnaces are shipped with bottom closure panel installed in bottom return-air opening. This panel MUST be in place when only side return air is used.

NOTE: Side return-air openings can be used in UPFLOW and most HORIZONTAL configurations. Do not use side return-air openings in DOWNFLOW configuration.

Leveling Legs (If Desired)

In upflow position with side return inlet(s), leveling legs may be used (see Fig. 10). Install field-supplied, 5/16 x 1-1/2 in. (8 x 38 mm) (max) corrosion-resistant machine bolts, washers and nuts.




Fig. 10 – Leveling Legs

A89014

NOTE: Bottom closure must be used when leveling legs are used. It may be necessary to remove and reinstall bottom closure panel to install leveling legs. To remove bottom closure panel, see Item 1. in Bottom Return Air Inlet section.

To install leveling legs:

- Position furnace on its back. Locate and drill a hole in each bottom corner of furnace (see Fig. 10).
- 2. For each leg, install nut on bolt and then install bolt and nut in hole. (Install flat washer if desired.)
- Install another nut on other side of furnace base. (Install flat washer if desired.)
- 4. Adjust outside nut to provide desired height, and tighten inside nut to secure arrangement.

5. Reinstall bottom closure panel if removed.

DOWNFLOW INSTALLATION

NOTE: For downflow applications, this furnace is approved for use on combustible flooring when any one of the following 3 accessories are used:

- · Special Base, KGASB
- · Cased Coil Assembly Part No. CNPV, CNRV, CAP, or CAR
- · Coil Box Part No. KCAKC
- 1. Determine application being installed from Table 4.
- 2. Construct hole in floor (see Table 4 and Fig. 11).
- 3. Construct plenum to dimensions specified (see Table 4 and Fig. 11).
- 4. If downflow subbase KGASB is used, install as shown (see Table 12). If Coil Assembly Part No. CNPV, CNRV, CAP and CNR or Coil Box Part No. KCAKC is used, install as shown (see Fig. 13).

NOTE: It is required that the perforated supply-air duct flanges be completely folded over or removed from furnace when installing the furnace on a factory-supplied cased coil or coil box. To remove the supply-air duct flange, use wide duct pliers or hand seamers to bend flange back and forth until it breaks off. Be careful of sharp edges. Refer to Duct Flanges (Fig. 17) in the "Air Ducts" section.)




Fig. 11 - Floor and Plenum Opening Dimensions

A96283

Bottom Return Air Inlet

These furnaces are shipped with bottom closure panel installed in bottom return-air opening. Remove and discard this panel when bottom return air is used. To remove bottom closure panel, perform the following:

- 1. Tilt or raise furnace and remove two screws holding bottom filler panel (see Fig. 9).
- 2. Rotate bottom filler panel downward to release holding tabs.
- 3. Remove bottom closure panel.
- 4. Reinstall bottom filler panel and screws




Fig. 12 – Furnace, Plenum, and Subbase Installed on a **Combustible Floor**




Fig. 13 - Furnace, Plenum, and Coil Assembly or Coil Box Installed on a Combustible Floor

A08556

FURNACE		PLENUM	OPENING	FLOOR C	PENING
CASING WIDTH	APPLICATION	A	В	C	D
	Upflow Applications on Combustible or Noncombustible Flooring	12-11/16	21-5/8	13-5/16	22-1/4
	(subbase not required)	(322)	(549)	(338)	(565)
	Downflow Applications on Noncombustible Flooring	12-9/16	19	13-3/16	19-5/8
14-3/16	(subbase not required)	(319)	(483)	(335)	(498)
(360)	Downflow Applications on Combustible Flooring	11-13/16	19	13-7/16	20-5/8
	(subbase required)	(284)	(483)	(341)	(600)
	Downflow Applications on Combustible Flooring with Cased Coil	12-5/16	19	13-5/16	20
	(subbase not required)	(319)	(483)	(338)	(508)
	Upflow Applications on Combustible or Noncombustible Flooring	16	21-5/8	16-5/8	22-1/4
17–1/2 (445)	(subbase not required)	(406)	(549)	(422)	(565)
	Downflow Applications on Noncombustible Flooring	15-7/8	19	16-1/2	19-5/8
	(subbase not required)	(403)	(483)	(419)	(498)
	Downflow Applications on Combustible Flooring	15-1/8	19	16-3/4	20-5/
	(subbase required)	(384)	(483)	(425)	(600)
	Downflow Applications on Combustible Flooring with Cased Coil	15-1/2	19	16-1/2	20
	(subbase not required)	(394)	(483)	(419)	(508)
	Upflow Applications on Combustible or Noncombustible Flooring	19-1/2	21-5/8	20-1/8	22-1/4
	(subbase not required)	(495)	(549)	(511)	(565)
	Downflow Applications on Noncombustible Flooring	19-3/8	19	20	19-5/
21	(subbase not required)	(492)	(483)	(508)	(498)
(533)	Downflow Applications on Combustible Flooring	18-5/8	19	20-1/4	20-5/8
	(subbase required)	(473)	(483)	(514)	(600)
	Downflow Applications on Combustible Flooring with Cased Coil	19	19	20	20
	(subbase not required)	(483)	(483)	(508)	(508)
	Upflow Applications on Combustible or Noncombustible Flooring	23	21-1/8	23-5/8	22-1/4
	(subbase not required)	(584)	(537)	(600)	(565)
	Downflow Applications on Noncombustible Flooring	22-7/8	19	23-1/2	19-5/8
24-1/2	(subbase not required)	(581)	(483)	(597)	(498)
(622)	Downflow Applications on Combustible flooring	22-1/8	19	23-3/4	20-5/8
-	(subbase required)	(562)	(483)	(603)	(600)
ļ	Downflow Applications on Combustible Flooring with Cased Coil	22-1/2	19	23-1/2	20
	(subbase not required)	(572)	(483)	(597)	(508)

WARNING

FIRE, EXPLOSION, AND CARBON MONOXIDE POISONING HAZARD

Failure to follow this warning could result in personal injury, death, and/or property damage.

Do not install the furnace on its back or hang furnace with control compartment facing downward. Safety control operation will be adversely affected. Never connect return-air ducts to the back of the furnace.

HORIZONTAL INSTALLATION

The furnace can be installed horizontally in an attic or crawl space on either the left-hand (LH) or right-hand (RH) side. The furnace can be hung from floor joists, rafters or trusses or installed on a non-combustible platform, blocks, bricks or pad.

Suspended Furnace Support

The furnace may be supported under each end with threaded rod, angle iron or metal plumber's strap as shown (see Fig. 15 and Fig. 16). Secure angle iron to bottom of furnace as shown. Heavy-gauge sheet metal straps (plumber's straps) may be used to suspend the furnace from each bottom corner. To prevent screws from pulling out, use 2 #8 x 3/4-in. (19

mm) screws into the side and 2 #8 x 3/4-in. (19 mm) screws in the bottom of the furnace casing for each strap (see Fig. 15 and Fig. 16). If the screws are attached to ONLY the furnace sides and not the bottom, the straps must be vertical against the furnace sides and not pull away from the furnace sides, so that the strap attachment screws are not in tension (are loaded in shear) for reliable support.

Platform Furnace Support

Construct working platform at location where all required furnace clearances are met (see Fig. 2 and Fig. 14). For furnaces with 1-in. (25 mm) clearance requirement on side, set furnace on noncombustible blocks, bricks or angle iron. For crawl space installations, if the furnace is not suspended from the floor joists, the ground underneath furnace must be level and the furnace set on blocks or bricks.




Fig. 14 – Typical Attic Installation




Fig. 15 – Horizontal Unit Suspension

Roll-Out Protection

Provide a minimum 17-3/4 in. x 22 in. (451 mm x 559 mm) piece of sheet metal for flame roll-out protection in front of burner area for furnaces closer than 12 inches (305 mm) above the combustible deck or suspended furnaces closer than 12 inches (305 mm) to joists. The sheet metal MUST extend underneath the furnace casing by 1 in. (25 mm) with the door removed.

The bottom closure panel on furnaces of widths 17-1/2 in. (445 mm) and larger may be used for flame roll-out protection when bottom of furnace is used for return air connection. See Fig. 14 for proper orientation of roll-out shield.




Fig. 16 - Horizontal Suspension with Straps

A10131

Bottom Return Air Inlet

These furnaces are shipped with bottom closure panel installed in bottom return-air opening. Remove and discard this panel when bottom return air is used. To remove bottom closure panel, perform the following:

- 1. Tilt or raise furnace and remove two screws holding bottom filler panel (see Fig. 9).
- 2. Rotate bottom filler panel downward to release holding tabs.
- 3. Remove bottom closure panel.
- 4. Reinstall bottom filler panel and screws. Side Return Air Inlet

Side Return Air Inlet

These furnaces are shipped with bottom closure panel installed in bottom return-air opening. This panel MUST be in place when side return air inlet(s) is used without a bottom return air inlet.

Not all horizontal furnaces are approved for side return air connections (see Fig. 20).

FILTER ARRANGEMENT

WARNING

CARBON MONOXIDE AND POISONING HAZARD

Failure to follow this warning could result in personal injury, or death. Never operate a furnace without a filter or with filter access door removed.

There are no provisions for an internal filter rack in these furnaces.

A field-supplied accessory external filter is required.

Refer to the instructions supplied with the external filter rack for assembly and installation options.

AIR DUCTS

GENERAL REQUIREMENTS

The duct system should be designed and sized according to accepted national standards such as those published by: Air Conditioning Contractors Association (ACCA), Sheet Metal and Air Conditioning Contractors National Association (SMACNA) or American Society of Heating, Refrigerating and Air Conditioning Engineers (ASHRAE) or consult The Air Systems Design Guidelines reference tables available from your local distributor. The duct system should be sized to handle the required system design CFM at the design external static pressure. The furnace airflow rates are provided in Table 5-AIR DELIVERY-CFM (With Filter).

When a furnace is installed so that the supply ducts carry air circulated by the furnace to areas outside the space containing the furnace, the return air shall also be handled by duct(s) sealed to the furnace casing and terminating outside the space containing the furnace.

Secure ductwork with proper fasteners for type of ductwork used. Seal supply- and return-duct connections to furnace with code approved tape or duct sealer.

NOTE: Flexible connections should be used between ductwork and furnace to prevent transmission of vibration. Ductwork passing through unconditioned space should be insulated and sealed to enhance system performance. When air conditioning is used, a vapor barrier is recommended.

Maintain a 1-in. (25 mm) clearance from combustible materials to supply air ductwork for a distance of 36 in. (914 mm) horizontally from the furnace. See NFPA 90B or local code for further requirements.

Ductwork Acoustical Treatment

NOTE: Metal duct systems that do not have a 90 degree elbow and 10 ft. (3 M) of main duct to the first branch take-off may require internal acoustical lining. As an alternative, fibrous ductwork may be used if constructed and installed in accordance with the latest edition of SMACNA construction standard on fibrous glass ducts. Both acoustical lining and fibrous ductwork shall comply with NFPA 90B as tested by UL Standard 181 for Class 1 Rigid air ducts.

SUPPLY AIR CONNECTIONS

For a furnace not equipped with a cooling coil, the outlet duct shall be provided with a removable access panel. This opening shall be accessible when the furnace is installed and shall be of such a size that the heat exchanger can be viewed for possible openings using light assistance or a probe can be inserted for sampling the airstream. The cover attachment shall prevent leaks.

Upflow and Horizontal Furnaces

Connect supply-air duct to flanges on furnace supply-air outlet. Bend flange upward to 90° with wide duct pliers (see Fig. 17). The supply-air duct must be connected to ONLY the furnace supply-outlet-air duct flanges or air conditioning coil casing (when used). DO NOT cut main furnace casing side to attach supply air duct, humidifier, or other accessories. All accessories MUST be connected to duct external to furnace main casing.

NOTE: For horizontal applications, the top-most flange may be bent past 90 degrees to allow the evaporator coil to hang on the flange temporarily while the remaining attachment and sealing of the coil are performed.

Downflow Furnaces

Connect supply-air duct to supply-air outlet on furnace. Bend flange inward past 90° with wide duct pliers (see Fig. 17). The supply-air duct must be connected to ONLY the furnace supply outlet or air conditioning coil casing (when used). When installed on combustible material, supply-air duct must be connected to ONLY the factory-approved accessory subbase or a factory-approved air conditioning coil casing. DO NOT cut main furnace casing to attach supply side air duct, humidifier, or other accessories. All accessories MUST be connected to duct external to furnace casing.

Return Air Connections

A CAUTION

FIRE HAZARD

Failure to follow this warning could cause personal injury, death and/or property damage.

Never connect return-air ducts to the back of the furnace. Follow instructions below.




Fig. 17 – Duct Flanges

A190346

Downflow Furnaces

The return-air duct must be connected to return-air opening bottom inlet (see Fig. 1). DO NOT cut into casing sides (left or right). Side opening is permitted for only upflow and most horizontal furnaces (see Fig. 18). Bypass humidifier connections should be made at ductwork or coil casing sides exterior to furnace.

Table 5 - Air Delivery - CFM (With Filter)*

Construct Cons	Furnace	Wire Lead	Function			Test Airf	low Delive	ry @ Vari	ious Exter	nal Static	Pressures		
Yellow All Cooling or all Heating 990 945 920 890 855 815 770 770 500 60	Furnace										0.8	0.9	1
Scientified Compage	ļ										975	935	895
Blue	26045E14		<u> </u>								735	690	645
Red All Ceoling, Do not use for heating 1370 1353 1293 2255 2156 1856 3485 3485 3485 3490 2491 2490 2491	30043E14		<u> </u>								475 415	430 375	385 335
Circuity Cooling, Denot use for heating. 1370 1335 1298 1255 1215 1175 1185	ļ		<u> </u>								305	235	- 333
Vellow			_								1095	1055	1020
September Sept	ļ		<u> </u>								825	780	730
Red	36045E17		<u> </u>								600	545	495
Gray Cooling, Do not use for heating. 1205 1170 1143 11105 1070 1095 1090 395 395 3960 3025 885 885 845 896 765 730 685 685 765 730 685 685 765 730 685 685 765 730 685 685 765 730 685 685 765 730 685 685 765 730 685 685 765 730 685 685 765 730 685 685 765 730 685 685 765 730 685 685 765 730 685 685 765 730 685 685 765 730 685 685 785			<u> </u>	760					515	460	410	355	300
Blue Hesting or alt Cooling 1095 1060 1030 995 960 925 885 885 885 730 685 685 670 685		Red	Alt Cooling. Do not use for heating.	610	500	445	375	320		200	135	-	-
Section			Cooling. Do not use for heating.							1000	960	925	885
Orange	ļ		<u> </u>								840	800	735
Red	36070E14		<u> </u>								620	560	510
Gray Cooling, Do not use for heating 1188 1140 1095 1055 1005 906 915 85 360 750 685 6											380	305	245
Yellow			= = = = = = = = = = = = = = = = = = = =								230	190	140
Blue			<u> </u>								865 650	820 600	780 555
Orange	36070F17		<u> </u>								640	590	535
Red	30070L17		<u> </u>								435	385	335
Gray Cooling Do not use for heating. 1650 1615 1580 1545 1515 1480 1445 1480 1481 1491 1480 1481 1492 1480 1481 1492 1480 1481 1492 1480 1481 1492 1480 1481 1492 1480 1481 1492 1480 1481 1492 1480 1492 1480 1492 1492 1480 1492 1	ļ		<u> </u>								205	-	-
Vellow											1415	1380	1350
Alt Cooling or alt Heating 1255 1215 1175 1130 1090 1090 1010 9 1010 9 1010											1140	1100	1065
Red	48070E17	Orange	Alt Cooling or alt Heating	1255	1215	1175	1130	1090	1090	1010	970	930	895
Material Cooling	ļ	Blue	Heating or alt Cooling								880	840	800
Yellow			_								785	740	700
Blue			<u> </u>								1405	1360	1310
Orange	40070E21		<u> </u>								1135	1085	1030
Red	48070E21		<u> </u>								975 770	915	860
Gray	ļ		<u> </u>								595	705 530	645 455
Yellow											1080	1025	815
Heating or alt Cooling 1220 1185 1150 1105 1065 1025 975 9	ļ		<u> </u>								1005	955	815
Orange	42090E17		<u> </u>								915	840	740
Gray			<u> </u>								655	590	535
Yellow		Red	Alt Cooling. Do not use for heating.	945	905	855	800	750	670	600	540	490	435
Blue Heating or alt Cooling 1440 1395 1350 1305 1255 1200 1145 100			<u> </u>								1260	1135	995
Orange Alt Cooling or alt Heating 1260 1210 1160 1105 1050 990 935 88			<u> </u>								1075	1020	640
Red	48090E21		<u> </u>								1090	1040	950
Gray	ļ		<u> </u>								880	820	755
Yellow											650 1805	585 1745	520 1680
Blue	ļ		<u> </u>								1500	1435	1375
Orange Alt Cooling or alt Heating 1390 1315 1240 1175 1095 1030 970 990	60090E21										1260	1200	1140
Red	00070221		<u> </u>								900	825	760
Yellow			<u> </u>								690	615	555
Blue Heating or alt Cooling 1580 1510 1445 1385 1320 1240 1175 11		Gray	Cooling. Do not use for heating.	2190	2135	2075	2015	1960	1900	1835	1775	1705	1630
Orange Alt Cooling or alt Heating 1305 1220 1160 1075 1000 930 865 77 Red Alt Cooling. Do not use for heating. 1210 1075 1000 915 845 765 675 59 Gray Cooling. Do not use for heating. 2255 2205 2150 2100 2040 1985 1920 18 Blue Heating or alt Cooling 1945 1890 1830 1770 1715 1655 1600 15 Orange Alt Cooling or alt Heating 1600 1525 1465 1400 1335 1275 1210 11 Orange Alt Cooling. Do not use for heating. 1420 1340 1280 1200 1140 1065 1005 90 Red Alt Cooling. Do not use for heating. 1280 1205 1140 1055 990 910 840 70 Blue Heating or alt Cooling 1995 1930 1865 1800 1740 1670	ļ	Yellow	Alt Cooling or alt Heating	1870	1810	1745	1685	1625	1565	1495	1420	1345	1280
Red	60090E24	Blue	<u> </u>								1115	1050	970
Gray Cooling. Do not use for heating. 2255 2205 2150 2100 2040 1985 1920 1885 1920 1885 1920 1885 1920 1885 1920 1885 1920 1885 1920 1885 1920 1885 1920 1885 1920 1885 1920 1885 1920 1885 1880 1885 1880 1880 1880 1885 1885 1880 1885 1880 1885 1880 1885 1880 1885 1880 1885 1880 1885 1880 1885 1880 1885 1880 1885 1880 1885 1880 1885 1880 1885 1880 1885 1880 1885 1880 1885 1880 1885 1880 1885 1880 1885			<u> </u>								770	690	610
Blue Heating or alt Cooling 1945 1890 1830 1770 1715 1655 1600 155 1601 155 155 1601											595	515	425
Yellow Alt Cooling or alt Heating 1600 1525 1465 1400 1335 1275 1210 11											1835	1735	1615
Orange Alt Cooling. Do not use for heating. 1420 1340 1280 1200 1140 1065 1005 99 Red Alt Cooling. Do not use for heating. 1280 1205 1140 1055 990 910 840 76 Gray Cooling. Do not use for heating. 2250 2190 2130 2070 2005 1950 1885 18 Blue Heating or alt Cooling 1995 1930 1865 1800 1740 1670 1605 15 Yellow Alt Cooling or alt Heating 1540 1460 1385 1305 1235 1165 1095 16 Red Alt Cooling. Do not use for heating. 1345 1195 1135 1055 980 820 735 660 55 Red Alt Cooling. Do not use for heating. 1335 1075 965 890 820 735 660 55 Gray Cooling. Do not use for heating. 2065 2005 1940 1875 <	60110E21		<u> </u>								1545 1150	1480 1080	1430 1015
Red Alt Cooling. Do not use for heating. 1280 1205 1140 1055 990 910 840 76 Gray Cooling. Do not use for heating. 2250 2190 2130 2070 2005 1950 1885 18 Blue Heating or alt Cooling 1995 1930 1865 1800 1740 1670 1605 15 Vellow Alt Cooling or alt Heating 1540 1460 1385 1305 1235 1165 1095 10 Orange Alt Cooling. Do not use for heating. 1345 1195 1135 1055 980 920 845 77 Red Alt Cooling. Do not use for heating. 1335 1075 965 890 820 735 660 53 Gray Cooling. Do not use for heating. 2065 2005 1940 1875 1810 1740 1670 16 Blue Heating or alt Cooling 1825 1760 1695 1630 1560 1490	00110E21		<u> </u>								925	865	790
Gray Cooling. Do not use for heating. 2250 2190 2130 2070 2005 1950 1885 1885 1886 1890 1895 1995											760	695	630
Blue Heating or alt Cooling 1995 1930 1865 1800 1740 1670 1605 15											1820	1755	1685
60110E24 Yellow Alt Cooling or alt Heating 1540 1460 1385 1305 1235 1165 1095 10 Orange Alt Cooling. Do not use for heating. 1345 1195 1135 1055 980 920 845 7' Red Alt Cooling. Do not use for heating. 1335 1075 965 890 820 735 660 53 Gray Cooling. Do not use for heating. 2065 2005 1940 1875 1810 1740 1670 16 Blue Heating or alt Cooling 1825 1760 1695 1630 1560 1490 1420 13 60135E24 Yellow Alt Cooling or alt Heating 1760 1690 1625 1555 1485 1415 1345 12											1535	1465	1400
Orange Alt Cooling. Do not use for heating. 1345 1195 1135 1055 980 920 845 7 Red Alt Cooling. Do not use for heating. 1335 1075 965 890 820 735 660 53 Gray Cooling. Do not use for heating. 2065 2005 1940 1875 1810 1740 1670 16 Blue Heating or alt Cooling 1825 1760 1695 1630 1560 1490 1420 13 60135E24 Yellow Alt Cooling or alt Heating 1760 1690 1625 1555 1485 1415 1345 12	60110E24		<u> </u>								1035	955	890
Gray Cooling. Do not use for heating. 2065 2005 1940 1875 1810 1740 1670 16 Blue Heating or alt Cooling 1825 1760 1695 1630 1560 1490 1420 13 60135E24 Yellow Alt Cooling or alt Heating 1760 1690 1625 1555 1485 1415 1345 12		Orange	<u> </u>								770	695	620
Blue Heating or alt Cooling 1825 1760 1695 1630 1560 1490 1420 13 60135E24 Yellow Alt Cooling or alt Heating 1760 1690 1625 1555 1485 1415 1345 12		Red									580	505	440
60135E24 Yellow Alt Cooling or alt Heating 1760 1690 1625 1555 1485 1415 1345 12			<u> </u>								1600	1530	1470
	(010577)		<u> </u>								1350	1275	1205
, la la casa de la cas	60135E24		<u> </u>								1275	1200	1130
											1130	1065	995
											805	735	670
											1780	1710	1645
	60155E24		<u> </u>								1615 1395	1540 1320	1460 1250
	00133124		<u> </u>								995	930	850
											600	530	465

^{1.} A filter is required for each return-air inlet. Airflow performance included 3/4-in. (19 mm) washable filter (see accessory list). To determine airflow performance without this filter, assume an additional 0.1 In. W.C. available external static pressure.

^{2.} Adjust the blower speed tabs as necessary for the proper air temperature rise for each installation.

^{3. --} Indicates unstable operating conditions.

^{4.} If the same motor speed tap is needed for heating and cooling, a Jumper Wire accessory kit is available. (See Product Data Sheet for the current Jumper Wire accessory part number). See Function column for applicable limitations.

Upflow Furnaces

The return-air duct must be connected to bottom, sides (left or right), or a combination of bottom and side(s) of main furnace casing (see Fig. 19 and Fig. 20). Bypass humidifier may be attached into unused return air side of the furnace casing (see Fig. 19 and Fig. 20). Not all horizontal furnaces are approved for side return air connections (see Fig. 20).




Fig. 18 – Downflow Return Air Configurations and Restrictions $^{A02163}\,$




Fig. 19 – Upflow Return Air Configurations and Restrictions




Fig. 20 – Horizontal Return Air Configurations and Restrictions $^{\rm A02162}$

GAS PIPING

Gas piping must be installed in accordance with national and local codes. Refer to current edition of NFGC.

Installations must be made in accordance with all authorities having jurisdiction. If possible, the gas supply line should be a separate line running directly from meter to furnace.

NOTE: In the state of Massachusetts:

- Gas supply connections MUST be performed by a licensed plumber or gas fitter.
- 2. When flexible connectors are used, the maximum length shall not exceed 36 inches (915 mm).

- When lever handle type manual equipment shutoff valves are used, they shall be T-handle valves.
- The use of copper tubing for gas piping is NOT approved by the state of Massachusetts.

MARNING

FIRE OR EXPLOSION HAZARD

Failure to follow this warning could result in personal injury, death, and/or property damage.

Never purge a gas line into a combustion chamber. Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections. A fire or explosion may result causing property damage, personal injury or loss of life.

Use proper length of pipe to avoid stress on gas control manifold and gas valve.

Gas valve inlet and/or inlet pipe must remain capped until gas supply line is permanently installed to protect the valve from moisture and debris. Also, install a sediment trap in the gas supply piping at the inlet to the gas valve.

Refer to Table 6 for recommended gas pipe sizing. Risers must be used to connect to furnace and to meter. Support all gas piping with appropriate straps, hangers, etc. Use a minimum of 1 hanger every 6 ft. (2 M). Joint compound (pipe dope) should be applied sparingly and only to male threads of joints. Pipe dope must be resistant to the action of propane gas.

Table 6 - Maximum Capacity of Pipe*

NOMINAL IRON PIPE	INTERNAL DIAMETER	LENGTH OF PIPE - FT. (M)						
SIZE IN. (mm)	In. (mm)	10	20	30	40	50		
1/2 (13)	0.622 (16)	175 (53)	120 (37)	97 (30)	82 (25)	73 (22)		
3/4 (19)	0.824 (21)	360 (110)	250 (76)	200 (61)	170 (52)	151 (46)		
1 (25)	1.049 (27)	680 (207)	465 (142)	375 (114)	320 (98)	285 (87)		
1-1/4 (32)	1.380 (35)	1400 (427)	950 (290)	770 (235)	660 (201)	580 (177)		
1-1/2 (38)	1.610 (41)	2100 (640)	1460 (445)	1180 (360)	990 (301)	900 (274)		

* Cubic ft. of natural gas per hr for gas pressures of 0.5 psig (14-In. W.C.) or less and a pressure drop of 0.5-In. W.C. (based on a 0.60 specific gravity gas). Ref: Chapter 6 current edition of ANSI Z223/NFPA 54.

↑ WARNING

FIRE OR EXPLOSION HAZARD

Failure to follow this warning could result in personal injury, death, and/or property damage.

If local codes allow the use of a flexible gas appliance connector, always use a new listed connector. Do not use a connector which has previously served another gas appliance. Black iron pipe shall be installed at the furnace gas control valve and extend a minimum of 2 in.(51 mm) outside the furnace.

CAUTION

FURNACE OVERHEAT HAZARD

Failure to follow this caution may result in property damage.

Connect gas pipe to gas valve using a backup wrench to avoid damaging gas controls and burner misalignment.

An accessible manual equipment shutoff valve MUST be installed external to furnace casing and within 6 ft. (2 M) of furnace. A 1/8-in. (3

mm) NPT plugged tapping, accessible for test gauge connection, **MUST** be installed immediately upstream of gas supply connection to furnace and downstream of manual equipment shutoff valve.

NOTE: The furnace gas control valve inlet pressure tap connection is suitable to use as test gauge connection providing test pressure DOES NOT exceed maximum 0.5 psig (14-In. W.C.) stated on gas control valve (see Fig. 21).




Fig. 21 – Gas Control Valve

Some installations require gas entry on right side of furnace (as viewed in upflow.) (See Fig. 22).

TOP VIEW OF BURNER AND MANIFOLD ASSEMBLY




Fig. 22 – Burner and Manifold

Install a sediment trap in riser leading to furnace (see Fig. 23). Connect a capped nipple into lower end of tee. Capped nipple should extend below level of furnace gas controls. Place a ground joint union between furnace gas control valve and exterior manual equipment gas shutoff valve.

A 1/8-in. (3 mm) NPT plugged tapping, accessible for test gauge connection, MUST be installed immediately upstream of gas supply connection to furnace and downstream of manual equipment shutoff valve.




Fig. 23 - Typical Gas Pipe Arrangement

A02035

A06666

Piping should be pressure and leak tested in accordance with NFGC in the United States, local, and national plumbing and gas codes before the furnace has been connected. After all connections have been made, purge lines and check for leakage at furnace prior to operating furnace.

If pressure exceeds 0.5 psig (14-In. W.C.), gas supply pipe must be disconnected from furnace and capped before and during supply pipe pressure test. If test pressure is equal to or less than 0.5 psig (14-In. W.C.), turn off electric shutoff switch located on furnace gas control valve and accessible manual equipment shutoff valve before and during supply pipe pressure test. After all connections have been made, purge lines and check for leakage at furnace prior to operating furnace.

The gas supply pressure shall be within the maximum and minimum inlet supply pressures marked on the rating plate with the furnace burners ON and OFF.

ELECTRICAL CONNECTIONS

See Fig. 24 for field wiring diagram showing typical field 115-v wiring. Check all factory and field electrical connections for tightness.

Field-supplied wiring shall conform with the limitations of 63°F (35°C) rise.

WARNING

ELECTRICAL SHOCK, FIRE OR EXPLOSION HAZARD

Failure to follow safety warnings could result in dangerous operation, serious injury, death or property damage.

Improper servicing could result in dangerous operation, serious injury, death or property damage.

- Before servicing, disconnect all electrical power to furnace.
- When servicing controls, label all wires prior to disconnection. Reconnect wires correctly.
- Verify proper operation after servicing.

WARNING

ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death. Blower access panel door switch opens 115-v power to control. No component operation can occur. Do not bypass or close switch with panel removed.

WARNING

ELECTRICAL SHOCK AND FIRE HAZARD

Failure to follow this warning could result in personal injury, death, or property damage.

The cabinet MUST have an uninterrupted or unbroken ground according to current edition of NEC NFPA 70 or local codes to minimize personal injury if an electrical fault should occur. This may consist of electrical wire, conduit approved for electrical ground or a listed, grounded power cord (where permitted by local code) when installed in accordance with existing electrical codes. Refer to the power cord manufacturer's ratings for proper wire gauge. Do not use gas piping as an electrical ground.

CAUTION

FURNACE MAY NOT OPERATE

Failure to follow this caution may result in intermittent furnace operation.

Furnace control must be grounded for proper operation or else control will lock out. Control must remain grounded through green/yellow wire routed to gas valve and manifold bracket screw.

115-V WIRING


Verify that the voltage, frequency, and phase correspond to that specified on unit rating plate. Also, check to be sure that service provided by utility is sufficient to handle load imposed by this equipment. Refer to rating plate or Table 7 for equipment electrical specifications.

U.S. Installations: Make all electrical connections in accordance with National Electrical Code (NEC) NFPA 70 and any local codes or ordinances that might apply.

Use a separate, fused branch electrical circuit with a properly sized fuse or circuit breaker for this furnace. See Table 7 for wire size and fuse specifications. A readily accessible means of electrical disconnect must be located within sight of the furnace.

NOTE: Proper polarity must be maintained for 115-v wiring. If polarity is incorrect, control LED status indicator light will flash rapidly and furnace will NOT operate.

> FIELD 24-V WIRING FIELD 115-, 208/230-, 46
> FACTORY 24-V WIRING 460-V WIRING **FACTORY 115-V WIRING**



- Connect Y-terminal in furnace as shown for proper blower operation.
- Some thermostats require a "C" terminal connection as shown.
- 3. If any of the original wire, as supplied, must be replaced, use same type or equivalent wire.

Fig. 24 – Heating and Cooling Application Wiring Diagram with 1-Stage Thermostat Table 7 – Electrical Data

Unit Size	Unit Size Volts- Hertz- Phase		Operating Voltage* Range		Minimum Wire Size AWG	Maxim Ler	Maximum Fuse or CKT				
	Hertz- Fliase	Maximum	Minimum	Ampacity †	SizeAWG	feet	m	BKR Amps**			
36045E14	115-60-1	127	104	7.8	14	47	14.3	15			
36045E17	115-60-1	127	104	10.3	14	36	11	15			
36070E14	115-60-1	127	104	7.8	14	47	14.3	15			
36070E17	115-60-1	127	104	7.8	14	47	14.3	15			
48070E17	115-60-1	127	104	14.3	14	25	7.6	15			
48070E21	115-60-1	127	104	13.3	14	27	8.2	15			
42090E17	115-60-1	127	104	11	14	33	10.1	15			
48090E21	115-60-1	127	104	11	14	33	10.1	15			
60090E21	115-60-1	127	104	16.9	12	34	10.4	20			
60090E24	115-60-1	127	104	13.5	14	27	8.2	15			
60110E21	115-60-1	127	104	17.4	12	33	10.1	20			
60110E24	115-60-1	127	104	14	14	26	7.9	15			
60135E24	115-60-1	127	104	14	14	26	7.9	15			
60155E24	115-60-1	127	104	14	14	26	7.9	15			

- Permissible limits of the voltage range at which the unit operates satisfactorily.
- Unit ampacity = 125 percent of largest operating component's full load amps plus 100 percent of all other potential operating components' (EAC, humidifier, etc.) full load
- Length shown is as measured one way along wire path between unit and service panel for maximum 2 percent voltage drop.
- Time-delay type is recommended.

WARNING

FIRE HAZARD

Failure to follow this warning could result in personal injury, death, or property damage.

Do not connect aluminum wire between disconnect switch and furnace. Use only copper wire (see Fig. 25).




Fig. 25 – Field-Supplied External Electrical Box on Furnace Casing J-BOX RELOCATION

NOTE: If factory location of J-Box is acceptable, go to next section (ELECTRICAL CONNECTION TO J-BOX).

NOTE: On 14-in. (356 mm) wide casing models, the J-Box shall not be relocated to other side of furnace casing when the vent pipe is routed within the casing.

1. Remove and save two screws holding J-Box.

NOTE: The J-Box cover need not be removed from the J-Box in order to move the J-Box. Do NOT remove green ground screw inside J-Box (see Fig. 26).

- 2. Cut wire tie on loop in furnace wires attached to J-box.
- 3. Move J-Box to desired location.
- 4. Fasten J-Box to casing with two screws removed in Step 1.
- Route J-Box wires within furnace away from sharp edges, rotating parts and hot surfaces.




Fig. 26 - Relocating J-Box

Electrical Connection to J-Box Electrical Box on Furnace Casing Side

WARNING

FIRE OR ELECTRICAL SHOCK HAZARD


Failure to follow this warning could result in personal injury, death, or property damage.

If field-supplied manual disconnect switch is to be mounted on furnace casing side, select a location where a drill or fastener cannot damage electrical or gas components.

- 1. Refer to Fig. 27 when installing an electrical box.
- 2. Select and remove a hole knockout in the casing where the electrical box is to be installed.

NOTE: Check that duct on side of furnace will not interfere with installed electrical box.

- 3. Remove the desired electrical box hole knockout and position the hole in the electrical box over the hole in the furnace casing.
- 4. Fasten the electrical box to casing by driving two field supplied screws from inside electrical box into casing steel.



A19027

Fig. 27 – Field-Supplied Electrical Box on Furnace Casing

- 5. Remove and save two screws holding J-Box.
- Pull furnace power wires out of 1/2-in. (12 mm) diameter hole in J-Box. Do not loosen wires from strain-relief wire-tie on outside of J-Box.
- 7. Route furnace power wires through holes in casing and electrical box and into electrical box.
- 8. Pull field power wires into electrical box.
- 9. Remove cover from furnace J-Box.
- Route field ground wire through holes in electrical box and casing, and into furnace J-Box.
- 11. Reattach furnace J-Box to furnace casing with screws removed in Step 4.
- 12. Secure field ground wire to J-Box green ground screw.
- 13. Complete electrical box wiring and installation. Connect line voltage leads (see Fig. 24). Use best practices (NEC in U.S. for wire bushings, strain relief, etc.)
- Reinstall cover to J-Box. Do not pinch wires between cover and bracket.

Power Cord Installation in Furnace J-Box

NOTE: Power cords must be able to handle the electrical requirements listed in Table 7. Refer to power cord manufacturer's listings.

- 1. Remove cover from J-Box.
- Route listed power cord through 7/8-in. (22 mm) diameter hole in J-Box.
- Secure power cord to J-Box bracket with a strain relief bushing or a connector approved for the type of cord used.

- 4. Secure field ground wire to green ground screw on J-Box bracket.
- 5. Connect line voltage leads (see Fig. 24).
- Reinstall cover to J-Box. Do not pinch wires between cover and bracket.

BX Cable Installation in Furnace J-Box

- 1. Remove cover from J-Box.
- 2. Route BX cable into 7/8-inch diameter hole in J-Box.
- Secure BX cable to J-Box bracket with connectors approved for the type of cable used.
- 4. Secure field ground wire to green ground screw on J-Box bracket.
- 5. Connect line voltage leads (see Fig. 24).
- Reinstall cover to J-Box. Do not pinch wires between cover and bracket.

24-V Wiring

Make field 24-v connections at the 24-v terminal strip (see Fig. 20). Connect terminal Y for proper cooling operation (see Fig. 28). Use only AWG No. 18, color-coded, copper thermostat wire.

The 24-v circuit contains an automotive-type, 3-amp. fuse located on the control. Any direct shorts during installation, service, or maintenance

could cause this fuse to blow. If fuse replacement is required, use ONLY a 3-amp. fuse of identical size.

ACCESSORIES

1. Electronic Air Cleaner (EAC)

Connect an accessory Electronic Air Cleaner (if used) using 1/4-in female quick connect terminals to the two male 1/4-in quick-connect terminals on the control board marked EAC-1 and EAC-2. The terminals are rated for 115 VAC, 1.0 amps maximum and are energized during blower motor operation (see Fig. 28).

2. Humidifier (HUM)

Connect an accessory 24 VAC, 0.5 amp. maximum humidifier (if used) to the 1/4-in male quick-connect HUM terminal and COM-24V screw terminal on the control board thermostat strip. The HUM terminal is energized when the pressure switch closes during a call for heat (see Fig. 28).

NOTE: DO NOT connect furnace control HUM terminal to HUM (humidifier) terminal on Thermidistat[™], Zone Controller or similar device. See Thermidistat, Zone Controller, thermostat, or controller manufacturer's instructions for proper connection.






Fig. 28 - Furnace Control





Single-Stage Furnace with Single-Speed Air Conditioner

Single-Stage Furnace with Single-Speed Heat Pump

A200134

Fig. 29 - Thermostat Wiring Diagrams

NOTES FOR THERMOSTAT WIRING DIAGRAMS

- 1. Heat pump MUST have a high pressure switch for HYBRID HEAT® dual fuel applications.
- 2. Refer to outdoor equipment Installation Instructions for additional information and setup procedure.
- 3. If the heat pump date code is 1501E or earlier, select the "ZONE" position on the two speed heat pump control. Heat pumps with date code 1601E and later do not have or require a "ZONE" selection.
- 4. Outdoor Air Temperature Sensor must be attached in all HYBRID HEAT® dual fuel applications.
- 5. Configure the thermostat for air conditioner installations. Refer to thermostat instructions.
- 6. Configure thermostat for heat pump installations. Refer to thermostat instructions.
- 7. Configure thermostat for single-stage compressor operation. Refer to thermostat instructions.
- 8. Configure thermostat for HYBRID HEAT® dual fuel operation. Refer to thermostat instructions.
- 9. NO connection should be made to the furnace HUM terminal when using a thermostat with a 24 volt humidifier output.
- 10. The RVS Sensing terminal "L" should not be connected. This is used internally to sense defrost operation.
- 11. If thermostat has internal control of heat pump balance point, DO NOT SELECT the "FURNACE INTERFACE" or "BALANCE POINT" option on the two-speed heat pump control board. Refer to thermostat instructions.
- 12. Thermostat signals may vary. Consult thermostat installation instructions for more information.

VENTING

The furnace shall be connected to a listed factory built chimney or vent, or a clay-tile lined masonry or concrete chimney. Venting into an unlined masonry chimney or concrete chimney is prohibited.

When an existing Category I furnace is removed or replaced, the original venting system may no longer be sized to properly vent the attached appliances. An improperly sized Category I venting system could cause the formation of condensate in the furnace and vent, leakage of condensate and combustion products, and spillage of combustion products into the living space.

Vent system or vent connectors may need to be resized. Vent systems or vent connectors, must be sized to approach minimum size as determined using appropriate table found in the NFGC.

GENERAL VENTING REQUIREMENTS

Follow all safety codes for proper vent sizing and installation requirements, including local building codes, the current edition of National Fuel Gas Code ANSI Z223.1/NFPA 54 (NFGC), Parts 12 and 13, the local building codes, and furnace and vent manufacturers' instructions.

These furnaces are design-certified as Category I furnaces in accordance with current edition of ANSI Z21.47/CSA 2.3 and operate with a non-positive vent static pressure to minimize the potential for vent gas leakage. Category I furnaces operate with a flue loss not less than 17 percent to minimize the potential for condensation in the venting system. These furnaces are approved for common venting and multistory venting with other fan assisted or draft hood equipped appliances in accordance

with the NFGC, the local building codes, and furnace and vent manufacturers' instructions.

The following information and warning must be considered in addition to the requirements defined in the NFGC.

- 1. If a vent (common or dedicated) becomes blocked, the furnace will be shut off by the draft safeguard switch located on the vent elbow.
- Do not vent this Category I furnace into a single-wall dedicated or common vent. The dedicated or common vent is considered to be the vertical portion of the vent system that terminates outdoors.
- Vent connectors serving Category I furnaces shall not be connected into any portion of a mechanical draft system operating under positive pressure.
- 4. Do not vent this appliance with any solid fuel burning appliance.
- 5. Category I furnaces must be vented vertically or nearly vertically unless equipped with a listed power venter.
- Do not vent this appliance into an unlined masonry chimney. (Refer to Chimney Inspection Chart, Fig. 30).

CHIMNEY INSPECTION CHART

For additional requirements refer to the National Fuel Gas Code NFPA 54/ANSI Z223.1 and ANSI/NFPA 211 Chimneys, Fireplaces, Vents, and Solid Fuel Burning Appliances




Fig. 30 – Chimney Inspection Chart

MASONRY CHIMNEY REQUIREMENTS

NOTE: These furnaces are CSA design-certified for use in exterior tile-lined masonry chimneys with a factory accessory Chimney Adapter Kit. Refer to the furnace rating plate for correct kit usage. The Chimney Adapter Kits are for use with ONLY furnaces having a Chimney Adapter Kit numbers marked on the furnace rating plate.

If a clay tile-lined masonry chimney is being used and it is exposed to the outdoors below the roof line, relining might be required. Chimneys shall conform to the Standard for Chimneys, Fireplaces, Vents, and Solid Fuel Burning Appliances current edition of ANSI/NFPA 211 and must be in good condition.

U.S.A.— Refer to Sections 13.1.8 and 13.2.20 of the current edition of NFGC NFPA54/ANSI Z223.1 or the authority having jurisdiction to determine whether relining is required. If relining is required, use a properly sized listed metal liner, Type-B vent, or a listed alternative venting design.

NOTE: See the current edition of NFPA54/ANSI Z223.1, 13.1.8 and 13.2.20 regarding alternative venting design and the Exception, which cover installations such as the Chimney Adapter Kits, which are listed for use with these furnaces. See Product Data Sheet for accessory listing.

WARNING

CARBON MONOXIDE POISONING HAZARD

Failure to follow the steps outlined below for each appliance connected to the venting system being placed into operation could result in carbon monoxide poisoning or death.

The following steps shall be followed for each appliance connected to the venting system being placed into operation, while all other appliances connected to the venting system are not in operation:

1.Seal any unused openings in venting system.

2.Inspect the venting system for proper size and horizontal pitch, as required in the current edition of National Fuel Gas Code, ANSI Z223.1/NFPA 54 and these instructions. Determine that there is no blockage or restriction, leakage, corrosion and other deficiencies, which could cause an unsafe condition.

3.As far as practical, close all building doors and windows and all doors between the space in which the appliance(s) connected to the venting system are located and other spaces of the building.

4. Close fireplace dampers.

5. Turn on clothes dryers and any appliance not connected to the venting system. Turn on any exhaust fans, such as range hoods and bathroom exhausts, so they are operating at maximum speed. Do not operate a summer exhaust fan.

6.Follow the lighting instructions. Place the appliance being inspected into operation. Adjust the thermostat so appliance is operating continuously.

7.Test for spillage from draft hood equipped appliances at the draft hood relief opening after 5 minutes of main burner operation. Use the flame of a match or candle.

8.If improper venting is observed during any of the above tests, the venting system must be corrected in accordance with the current edition of National Fuel Gas Code, ANSI Z223.1/NFPA 54.

9.After it has been determined that each appliance connected to the venting system properly vents when tested as outlined above, return doors, windows, exhaust fans, fireplace dampers and any other gas-fired burning appliance to their previous conditions of use.

The Chimney Adapter Kit is listed alternative venting system for these furnaces. See the kit instructions for complete details.

This furnace is permitted to be vented into a clay tile-lined masonry chimney that is exposed to the outdoors below the roof line, provided:

- 1. Vent connector is Type-B double-wall, and
- 2. This furnace is common vented with at least 1 draft hood equipped appliance, and
- 3. The combined appliance input rating is less than the maximum capacity given in Table 8, and
- 4. The input rating of each space heating appliance is greater than the minimum input rating given in Table 9 for the local 99% Winter Design Temperature. Chimneys having internal areas greater than 38 square inches require furnace input ratings greater than the input ratings of these furnaces. See footnote at bottom of Table 9, and
- 5. The authority having jurisdiction approves.

Table 8 – Combined Appliance Maximum Input Rating in Thousands of BTUh per Hour

VENT HEIGHT FT. (M)	INTERNAL AREA OF CHIMNEY IN ² (MM ²)							
11.(11)	12 (7741)	19 (12258)	28 (18064)	38 (24516)				
6 (1.8)	74	119	178	257				
8 (2.4)	80	130	193	279				
10 (3.0)	84	138	207	299				
15 (4.5)	NR	152	233	334				
20 (6.0)	NR	NR	250	368				
30 (9.1)	NR	NR	NR	404				

If all of these conditions cannot be met, an alternative venting design shall be used, such as the listed chimney adapter kit with these furnaces, which are listed for use with the kit, a listed chimney-lining system, or a Type-B common vent.

Table 9 – Minimum Allowable Input Rating of Space-Heating Appliance in Thousands of BTUh per Hour

	IN		CA OF CHIMN	EY
VENT HEIGHT			MM ²)	
FT (M)	12	19	28	38
	(7741)	(12258)	(18064)	(24516)
		Vinter Design		
	mperature: 17			
6 (1.8)	0	55	99	141
8 (2.4)	52	74	111	154
10 (3.0)	NR	90	125	169
15 (4.6)	NR	NR	167	212
20 (6.1)	NR	NR	212	258
30 (9.1)	NR	NR	NR	362
		Vinter Design		
Tei	nperature: 5 to	16°F* (-15 to -	9°C)	
6 (1.8)	NR	78	121	166
8 (2.4)	NR	94	135	182
10 (3.0)	NR	111	149	198
15 (4.6)	NR	NR	193	247
20 (6.1)	NR	NR	NR	293
30 (9.1)	NR	NR	NR	377
	Local 99% V	Vinter Design		
Tem	perature: -10 to	o 4°F* (-23 to -	16°C)	
6 (1.8)	NR	NR	145	196
8 (2.4)	NR	NR	159	213
10 (3.0)	NR	NR	175	231
15 (4.6)	NR	NR	NR	283
20 (6.1)	NR	NR	NR	333
30 (9.1)	NR	NR	NR	NR
	Local 99% V	Vinter Design		
Te	mperature: -11°	F (-24°C) or lo	wer	
Not re	commended for	any vent config	uration.	

*The 99.6% heating db temperatures found in the 1997 or 2001 ASHRAE Fundamentals Handbook, Climatic Design Information chapter, Table 1A (United States) or the 2005 ASHRAE Fundamentals handbook, Climatic Design Information chapter, and the CD-ROM included with the 2005 ASHRAE Fundamentals Handbook. Inspections before the sale and at the time of installation will determine the acceptability of the chimney or the need for repair and/or (re)lining. Refer to the Fig. 30 to perform a chimney inspection. If the inspection of a previously used tile-lined chimney:

- a. Shows signs of vent gas condensation, the chimney should be relined in accordance with local codes and the authority having jurisdiction. The chimney should be relined with a listed metal liner, Type-B vent, or a listed chimney adapter kit shall be used to reduce condensation. If a condensate drain is required by local code, refer to the current edition of NFGC NFPA54/ANSI Z223.1, Section 12.10 for additional information on condensate drains.
- b. Indicates the chimney exceeds the maximum permissible size in the tables, the chimney should be rebuilt or relined to conform to the requirements of the equipment being installed and the authority having jurisdiction.

A chimney without a clay tile liner, which is otherwise in good condition, shall be rebuilt to conform to current edition of ANSI/NFPA 211 or be lined with a UL listed metal liner or UL listed Type-B vent. Relining with a listed metal liner or Type-B vent is considered to be a vent-in-a-chase.

If a metal liner or Type-B vent is used to line a chimney, no other appliance shall be vented into the annular space between the chimney and the metal liner.

EXTERIOR MASONRY CHIMNEY FAN + NAT INSTALLATIONS WITH TYPE-B DOUBLE-WALL VENT CONNECTORS ©NFPA & AGA APPLIANCE APPLICATION REQUIREMENTS

Appliance operation has a significant impact on the performance of the venting system. If the appliances are sized, installed, adjusted, and operated properly, the venting system and/or the appliances should not suffer from condensation and corrosion. The venting system and all appliances shall be installed in accordance with applicable listings, standards, and codes.

The furnace should be sized to provide 100 percent of the design heating load requirement plus any margin that occurs because of furnace model size capacity increments. Heating load estimates can be made using approved methods available from Air Conditioning Contractors of America (Manual J); American Society of Heating, Refrigerating, and Air-Conditioning Engineers; or other approved engineering methods. Excessive oversizing of the furnace could cause the furnace and/or vent to fail prematurely. When a metal vent or metal liner is used, the vent must be in good condition and be installed in accordance with the vent manufacturer's instructions.

To prevent condensation in the furnace and vent system, the following precautions must be observed:

- The return-air temperature must be at least 60°F (16°C)db except for brief periods of time during warm-up from setback at no lower than 55°F (13°C) db or during initial start-up from a standby condition.
- Adjust the gas input rate per the installation instructions. Low gas input rate causes low vent gas temperatures, causing condensation and corrosion in the furnace and/or venting system. Derating is permitted only for altitudes above 2000 ft. (610 M).
- 3. Adjust the air temperature rise to the midpoint of the rise range or slightly above. Low air temperature rise can cause low vent gas temperature and potential for condensation problems.
- Set the thermostat heat anticipator or cycle rate to reduce short cycling.

! CAUTION

BURN HAZARD

Failure to follow this caution may cause personal injury.

Hot vent pipe is within reach of small children when installed in downflow position. See the following instruction.

Air for combustion must not be contaminated by halogen compounds which include chlorides, fluorides, bromides, and iodides. These compounds are found in many common home products such as detergent, paint, glue, aerosol spray, bleach, cleaning solvent, salt, and air freshener, and can cause corrosion of furnaces and vents. Avoid using such products in the combustion-air supply. Furnace use during construction of the building could cause the furnace to be exposed to halogen compounds, causing premature failure of the furnace or venting system due to corrosion.

Vent dampers on any appliance connected to the common vent can cause condensation and corrosion in the venting system. Do not use vent dampers on appliances common vented with this furnace.

ADDITIONAL VENTING REQUIREMENTS

A 4" (101 mm) round vent elbow is supplied with the furnace. A 5-inch (127 mm) or 6- inch (152 mm) vent connector may be required for some model furnaces. A field-supplied 4-inch-to-5-inch (101 - 127 mm) or 4-inch-to-6-inch (101 - 152 mm) sheet metal increaser fitting is required when 5-inch (127 mm) or 6-inch (152 mm) vent connector is used. See Fig. 31 - Fig. 43 Venting Orientation for approved vent configurations.

NOTE: Vent connector length for connector sizing starts at furnace vent elbow. The 4-inch vent elbow is shipped for upflow configuration and may be rotated for other positions. Remove the 3 screws that secure vent elbow to furnace, rotate furnace vent elbow to position desired, reinstall screws. The factory-supplied vent elbow does NOT count as part of the number of vent connector elbows.

A CAUTION

CUT HAZARD

Failure to follow this caution may result in personal injury.

Sheet metal parts may have sharp edges or burrs. Use care and wear appropriate protective clothing, safety glasses and gloves when handling parts and servicing furnaces.

The vent connector can exit the furnace through one of 5 locations on the casing.

 Attach the single wall vent connector to the furnace vent elbow, and fasten the vent connector to the vent elbow with at least two field-supplied, corrosion-resistant, sheet metal screws located 180° apart.

NOTE: An accessory flue extension is available to extend from the furnace elbow to outside the furnace casing. See Product Data Sheet for

accessory listing. If flue extension is used, fasten the flue extension to the vent elbow with at least two field-supplied, corrosion-resistant, sheet metal screws located 180° apart. Fasten the vent connector to the flue extension with at least two field-supplied, corrosion resistant sheet metal screws located 180° apart.

- 2. Vent the furnace with the appropriate connector (see Fig. 31 Fig. 43).
- 3. Determine the correct location of the knockout to be removed.
- Use a hammer and screwdriver to strike a sharp blow between the tie points and work the slug back and forth until the slug breaks free.

An accessory Vent Guard Kit is REQUIRED for downflow applications where the vent exits through the lower portion of the furnace casing. See Fig. 35 and Product Data Sheet for accessory listing. Refer to the Vent Guard Kit Instructions for complete details.

The horizontal portion of the venting system shall slope upwards not less than 1/4-in. per linear ft. (21 mm/M) from the furnace to the vent and shall be rigidly supported every 5 ft. (2 M) or less with metal hangers or straps to ensure there is no movement after installation.

SIDEWALL VENTING

This furnace is not approved for direct sidewall horizontal venting.

Per section 12.4.3 of the current edition of NFPA54/ANSI Z223.1, any listed mechanical venter may be used, when approved by the authority having jurisdiction.

Select the listed mechanical venter to match the BTUh input of the furnace being vented. Follow all manufacturer's installation requirements for venting and termination included with the listed mechanical venter.


Caution!! For the following applications, use the minimum vertical vent heights as specified below. For all other applications, follow exclusively the National Fuel Gas Code.

FURNACE ORIENTATION	VENT ORIENTATION	FURNACE INPUT (BTUH/HR)	MIN. VENT DIAMETER IN. (mm)*	MIN. VERTICAL VENT HEIGHT FT. (M) [†]
Downflow	Vent elbow left, then up Fig. 35	154,000 132,000 110,000	5 (127)	12 (3.6)
Horizontal Left	Vent elbow right, then up Fig. 43	154,000 132,000	5 (127)	7 (2.1)
Horizontal Left	Vent Elbow up Fig. 41	154,000 132,000	5 (127)	7 (2.1)
Horizontal Left	Vent elbow right Fig. 40	154,000	5 (127)	7 (2.1)
Downflow	Vent elbow up then left Fig. 31	110,000	5 (127)	10 (3.0)
Downflow	Vent elbow up, then right Fig. 38	110,000	5 (127)	10 (3.0)

^{*. 4} in. (102 mm) inside casing or vent guard


NOTE: All vent configurations must also meet National Fuel Gas Code venting requirements NFGC

^{†.} Including 4 in. (102 mm) vent section(s)




SEE NOTES:1,2,3,4,5,7,8,9 on the page following these figures

Fig. 31 – Downflow Application-Vent Elbow Up then Left $^{\rm A03210}$



SEE NOTES: 1,2,3,4,7,8,9 on the pages following these figures

Fig. 32 – Upflow Application-Vent Elbow Right



SEE NOTES: 1,2,4,5,7,8,9


Fig. 33 – Horizontal Right Application-Vent Elbow Left



SEE NOTES: 1,2,4,5,7,8,9 on the page following these figures


Fig. 34 – Downflow Application-Vent Elbow Up





SEE NOTES: 1,2,4,5,6,7,8,9 on the page following these figures


Fig. 35 - Downflow Application-Vent Elbow Left then Up A03207



SEE NOTES: 1,2,4,7,8,9 on the page following these figures


Fig. 36 – Horizontal Left Application-Vent Elbow Left

A03213




SEE NOTES: 1,2,4,7,8,9 on the page following these figures

Fig. 37 – Upflow Application-Vent Elbow Up




SEE NOTES:1,2,3,4,5,7,8,9 on the page following these figures.

 $\textbf{Fig. 38-Downflow Application-Vent Elbow Up then } \textbf{Right}^{A03212}$




SEE NOTES: 1,2,4,7,8,9 on the page following these figures

 $\textbf{Fig. 39} - \textbf{Horizontal Right Application-Vent Elbow Right} \ ^{A03218}$




SEE NOTES: 1,2,4,5,7,8,9 on the page following these figures

 $\textbf{Fig. 40-Horizontal Left Application-Vent Elbow Right} \quad ^{A03216}$



SEE NOTES: 1,2,4,5,7,8,9 on the page following these figures


Fig. 41 – Horizontal Left Application-Vent Elbow Up



SEE NOTES: 1,2,4,5,7,8,9 on the page following these figures

A03219

Fig. 42 - Horizontal Right Application-Vent Elbow Left then Up



SEE NOTES: 1,2,4,5,7,8,9 on the page following these figures

A0321

Fig. 43 – Horizontal Left Application-Vent Elbow Right then Up

VENTING NOTES FOR Fig. 31 - Fig. 43

- 1. For common vent, vent connector sizing and vent material: United States-use the NFGC.
- 2. Immediately increase to 5-inch (127 mm) or 6-inch (152 mm) vent connector outside furnace casing when 5-inch (127 mm) vent connector is required, refer to Note 1 above.
- 3. Side outlet vent for upflow and downflow installations must use Type B vent immediately after exiting the furnace, except when factory-authorized, Downflow Vent Guard Kit, is used in the downflow position. See Product Data Sheet for accessory listing.
- 4. Type-B vent where required, refer to Note 1 above.
- 5. Four-inch single-wall (26 ga. min.) vent must be used inside furnace casing and when the Downflow Vent Guard Kit is used external to the furnace. See Product Data Sheet for accessory listing.
- 6. Factory-authorized accessory Downflow Vent Guard Kit required in downflow installations with lower vent configuration. See Product Data Sheet for accessory listing.
- 7. Chimney Adapter Kit may be required for exterior masonry chimney applications. Refer to Chimney Adapter Kit for sizing and complete application details. See Product Data Sheet for accessory listing.
- 8. Secure vent connector to furnace elbow with (2) corrosion-resistant sheet metal screws, spaced approximately 180° apart.
- 9. Secure all other single wall vent connector joints with (3) corrosion resistant screws spaced approximately 120° apart. Secure Type-B vent connectors per vent connector manufacturer's recommendations.

START-UP, ADJUSTMENT, AND SAFETY CHECK GENERAL

⚠ WARNING

FIRE HAZARD

Failure to follow this warning could result in personal injury, death and/or property damage.

This furnace is equipped with manual reset limit switches in the gas control area. The switches open and shut off power to the gas valve if a flame rollout or overheating condition occurs in the gas control area. DO NOT bypass the switches. Correct inadequate combustion air supply problem before resetting the switches.

- 1. Maintain 115-v wiring and ground. Improper polarity will result in rapid flashing LED and no furnace operation.
- 2. Make thermostat wire connections at the 24-v terminal block on the furnace control. Failure to make proper connections will result in improper operation (see Fig. 24).
- 3. Gas supply pressure to the furnace must be greater than 4.5-In. W.C. (0.16 psig) but not exceed 14-In. W.C. (0.5 psig).
- 4. Check all manual-reset switches for continuity.
- Install blower compartment door. Door must be in place to operate furnace.
- 6. Replace outer door.

A CAUTION

CUT HAZARD

Failure to follow this caution may result in personal injury.

Sheet metal parts may have sharp edges or burrs. Use care and wear appropriate protective clothing, safety glasses and gloves when handling parts and servicing furnaces.

Start-Up Procedures

MARNING

FIRE AND EXPLOSION HAZARD

Failure to follow this warning could cause personal injury, death and/or property damage.

Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections.

- 1. Purge gas lines after all connections have been made.
- 2. Check gas lines for leaks.

MARNING

ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury, or death. Blower access door switch opens 115-v power to control. No component operation can occur unless switch is closed. Caution must be taken when manually closing this switch for service purposes.

3. To Begin Component Self-Test:

Remove blower access door. Disconnect the thermostat R lead from the furnace control board. Manually close the blower door switch closed. Short (jumper) the COM-24v terminal on control to the TEST/TWIN 3/16-inch quick connect terminal on control until LED goes out (approximately 2 sec). Gas valve and humidifier will not be turned on (see Fig. 28).

NOTE: The furnace control allows all components, except the gas valve, to be run for short period of time. This feature helps diagnose a system problem in case of a component failure. Component test feature will not operate if any thermostat signal is present at the control.

- 4. Component test sequence is as follows (see service label attached to furnace or Fig. 44):
 - a. LED will display previous status code 4 times.
 - Inducer motor starts and continues to run until Step f of component test sequence.
 - c. Hot surface igniter is energized for 15 sec., then off.
 - d. Blower motor operates on HEAT speed for 10 sec.
 - e. Blower motor operates on COOL speed for 10 sec.
 - f. Inducer motor stops.
 - g. Reconnect R lead to furnace control board, release blower door switch and re-install blower door.
- 5. Operate furnace per instruction on door.
- 6. Verify furnace shut down by lowering thermostat setting below room temperature.
- Verify furnace restarts by raising thermostat setting above room temperature.




Fig. 44 – Service Label

WIRING DIAGRAM




Fig. 45 – Wiring Diagram

Adjustments

Furnace gas input rate on rating plate is for installations at altitudes up to 2000 ft. (610 M). Furnace input rate must be within +/-2 percent of furnace rating plate input.

MARNING

FIRE HAZARD

Failure to follow this warning could result in injury, death and/or property damage.

DO NOT bottom out gas valve regulator adjusting screw. This can result in unregulated manifold pressure and result in excess overfire and heat exchanger failures.

1. Determine the correct gas input rate.

The input rating for altitudes above 2,000 ft. (610 M) must be reduced by 4 percent for each 1,000 ft. (305 M) above sea level. For installations below 2000 ft. (610 M), refer to the unit rating plate. For installations above 2000 ft. (610 M), multiply the input on the rating plate by the de-rate multiplier in Table 10 for the correct input rate.

A CAUTION

FURNACE DAMAGE HAZARD

Failure to follow this caution may result in reduced furnace life.

DO NOT redrill orifices. Improper drilling (burrs, out-of-round holes, etc.) can cause excessive burner noise and misdirection of burner flames. This can result in flame impingement of heat exchangers, causing failures (see Fig. 46).




Fig. 46 – Orifice Hole Table 10 – Altitude Derate Multiplier for U.S.A.

DERATE PERCENT MULTIPLIER ALTITUDE OF DERATE FACTOR* (FT. / M) 0-2000 (0-610) 1.00 2001-3000 (610-914) 0.90 8-12 3001-4000 (914-1219) 12-16 0.86 4001-5000 (1219-1524) 16-20 0.82 5001-6000 (1524-1829) 20 - 240.78 6001-7000 (1829-2134) 24-28 0.74 7001-8000 (2134-2438) 28-32 0.70 0.66 8001-9000 (2438-2743) 32-36 9001-10,000 (2743-3048)

- *. Derate multiplier factors are based on midpoint altitude for altitude range
- Determine the correct orifice and manifold pressure adjustment.
 There are two different orifice and manifold adjustment tables. All models in all positions, except Low NOx models in downflow or horizontal positions, use Table 11 (22,000 BTUh/Burner).

Low NOx models in the downflow or horizontal positions must use Table 12 (21,000 BTUh/Burner). See input listed on rating plate.

- a. Obtain average yearly gas heat value (at installed altitude) from local gas supplier.
- b. Obtain average yearly gas specific gravity from local gas supplier.
- c. Find installation altitude in Table 11 or Table 12.
- d. Find closest natural gas heat value and specific gravity in Table 11 or Table 12.
- e. Follow heat value and specific gravity lines to point of intersection to find orifice size and manifold pressure settings for proper operation.
- f. Check and verify burner orifice size in furnace. NEVER ASSUME ORIFICE SIZE. ALWAYS CHECK AND VERIFY.

NOTE: If orifice hole appears damaged or it is suspected to have been redrilled, check orifice hole with a numbered drill bit of correct size. Never redrill an orifice. A burr-free and squarely aligned orifice hole is essential for proper flame characteristics.

g. Replace orifice with correct size if required by Table 10, Table 11, Table 12 and Table 13. Use only factory-supplied orifices. See EXAMPLE 1.

EXAMPLE 1: (0 to 2000 ft. (0 to 610 M) altitude)

For 22,000 BTUh per burner application use Table 11.

Heating value = 1000 BTUh/cu ft.

Specific gravity = 0.62

Therefore: Orifice No. 43*

Manifold pressure: 3.7-In. W.C.

*Furnace is shipped with No. 43 orifices.

In this example all main burner orifices are the correct size and do not need to be changed to obtain proper input rate.

- 3. Adjust manifold pressure to obtain correct input rate.
 - a. Turn gas valve ON/OFF switch to OFF.

WARNING

ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death. Disconnect 115-v electrical power and install lockout tag before changing speed tap.

- b. Remove manifold pressure tap plug from gas valve (see Fig. 21).
- c. Connect a water column manometer or similar device to manifold pressure tap.
- d. Turn gas valve ON/OFF switch to ON.
- e. Manually close blower door switch.
- f. Set thermostat to call for heat.
- g. Remove regulator seal cap and turn regulator adjusting screw counterclockwise (out) to decrease input rate of clockwise (in) to increase input rate.

NOTE: DO NOT set manifold pressure less than 3.2-In. W.C. or more than 3.8-In. W.C. for natural gas at sea level. If manifold pressure is outside this range, change main burner orifices. Refer to Table 10, Table 11, Table 12 and Table 13.

- h. Install regulator seal cap.
- Leave manometer or similar device connected and proceed to Step 4
- 4. Verify natural gas input rate by clocking meter.

NOTE: Gas valve regulator adjustment cap must be in place for proper input to be clocked.

- a. Turn off all other gas appliances and pilots served by the meter.
- b. Run furnace for 3 minutes in heating operation.

- c. Measure time (in sec) for gas meter to complete 1 revolution and note reading. The 2 or 5 cubic feet dial provides a more accurate measurement of gas flow.
- d. Refer to Table 11 for cubic ft. of gas per hr.
- e. Multiply gas rate (cu ft./hr) by heating value (BTUh/cu ft.) to obtain input.
- f. If clocked rate does not match required input from Step 1, increase manifold pressure to increase input or decrease manifold pressure to decrease input. Repeat steps b through e until correct input is achieved. Reinstall regulator seal cap on gas valve.
- 5. Set temperature rise. The furnace must operate within the temperature rise ranges specified on the furnace rating plate. Do not exceed temperature rise range specified on unit rating plate. Determine the temperature rise as follows:

NOTE: Blower access door must be installed when taking temperature rise reading. Leaving blower access door off will result in incorrect temperature measurements.

- a. Place thermometers in return and supply ducts as close to furnace as possible. Be sure thermometers do not see radiant heat from heat exchangers. Radiant heat affects temperature rise readings. This practice is particularly important with straight-run ducts.
- When thermometer readings stabilize, subtract return-air temperature from supply-air temperature to determine air temperature rise.

NOTE: If the temperature rise is outside this range, first check:

- (1.) Gas input for heating operation.
- (2.) Derate for altitude if applicable.
- (3.) Return and supply ducts for excessive restrictions causing static pressures greater than 0.50-In. W.C.
- Adjust air temperature rise by adjusting blower speed. Increase blower speed to reduce temperature rise. Decrease blower speed to increase temperature rise
- d. Turn thermostat down below room temperature and remove blower access door.
- e. To change motor speed selection for heating, remove blower motor lead from control HEAT terminal (See Fig. 28). Select desired blower motor speed lead from one of the other terminals and relocate it to the HEAT terminal (See Table 5 for lead color identification). Reconnect original lead to SPARE terminal.
- f. If the same motor speed tap is needed for heating and cooling, a Jumper Wire accessory kit is available, see Product Data Sheet for the current Jumper Wire accessory part number. The single wire end of the jumper will be connected to the desired blower motor speed lead. The two wire end of the jumper will be connected to the control board, connecting one wire to the HEAT (heating blower tap) terminal and the other will be connected to the COOL (cooling blower tap). Use the provided wire ties to secure the loose blower motor speed lead and any other loose wires, being careful not to put tension on any wire connectors.
- g. Repeat steps a through e.
- h. When correct input rate and temperature rise is achieved, turn gas valve ON/OFF switch to OFF.

A WARNING

FIRE HAZARD

Failure to follow this warning could result in personal injury, death, and/or property damage.

Reinstall manifold pressure tap plug in gas valve to prevent gas leak.

- i. Remove manometer or similar device from gas valve.
- j. Reinstall manifold pressure tap plug in gas valve.

Table 11 – Orifice Size* and Manifold Pressure (In. W.C.) for Gas Input Rate

Name			DATA BASED ON	22,000 B	TUH PER BL					VE SEA	LEVEL)
	′										
		RANGE									
Yes 900 42 3.5 42 3.6 42 3.7 41 3.5 (0) 955 43 3.8 42 3.3 42 3.4 42 3.7 41 3.5 (0) 950 43 3.8 42 3.3 42 3.4 42 3.2 42 3.3 3.8 42 3.2 3.4 42 3.2 42 3.3 3.8 42 3.3 42 3.4 42 3.2 42 3.3 3.8 42 3.2 42 3.3 3.8 3.8 42 3.2 42 3.3 3.8 42 3.3 3.6 43 3.5 43 3.6 43 3.5 43 3.5 43 3.6 43 3.5 43 3.6 42 3.5 43 3.6 42 3.3 3.3 42 3.4 43 3.5 43 3.6 42 3.7 43 3.6										l	
Yeg 1		π (m)									
Part		_				l				l	
to 1000 43 3.6 43 3.6 43 3.8 42 3.2 42 3.3 1025 43 3.3 43 3.6 43 3.6 43 3.7 43 3.6											
The color 1000		(0)								l	
1020	نه					l					
1020	Š.	to									
(610)	"										
1100		1								l	
QDI (611) 800 42 3.4 42 3.5 42 3.6 42 3.7 2001 (611) 875 43 3.7 43 3.8 42 3.2 42 3.3 1 to 900 43 3.5 43 3.6 43 3.7 43 3.8 950 43 3.3 43 3.4 43 3.5 43 3.6 43 3.7 43 3.8 950 43 3.3 43 3.4 43 3.5 43 3.1 43 3.4 43 3.5 43 3.6 95 43 3.2 43 3.0 43 3.1 43 3.4 43 3.0 43 3.1 43 3.4 43 3.2 43 3.0 43 3.1 43 3.2 43 3.0 43 3.1 43 3.4 42 3.4 42 3.4 42 3.2 43 3.3		(610)								ı	
YODA 825 42 3.2 42 3.3 42 3.4 42 3.5 201 (611) 850 43 3.7 43 3.8 42 3.2 42 3.3 3000 (914) 900 43 3.3 43 3.4 43 3.5 43 3.6 950 43 3.1 43 3.2 43 3.3 43 3.4 3.3 43 3.4 3.3 43 3.4 3.3 43 3.4 3.3 43 3.4 43 3.3 43 3.4 3.4 3.4 3.3 43 3.4 43 3.2 43 3.0 43 3.1 43 3.2 43 3.0 43 3.2 42 3.3 42 3.4 3.3 42 3.2 42 3.3 42 3.4 43 3.2 43 3.3 43 3.4 42 3.5 43 3.6 43 3.5 <											
\$\frac{9}{9}						l				l	
100 101 101 101 102 103										l	
No 875 43 3.5 43 3.6 43 3.7 43 3.8 3000 (914) 9900 43 3.3 43 3.4 43 3.5 43 3.6 975 43 2.9 43 3.0 43 3.1 43 3.2 975 42 3.2 42 3.3 43 3.4 43 2.8 43 2.9 43 3.0 43 3.1 43 3.2 1000 43 2.6 43 2.7 43 2.8 43 2.9 3001 800 43 3.6 42 3.2 42 3.3 42 3.4 42 3.5 4001 850 43 3.2 43 3.5 43 3.7 43 3.8 4000 900 43 2.9 43 3.0 43 3.1 43 3.4 43 3.8 4001 775 <td></td> <td>2001 (611)</td> <td></td> <td></td> <td></td> <td>l</td> <td></td> <td></td> <td></td> <td></td> <td></td>		2001 (611)				l					
Part	∢					l	3.6			l	
Part	l S.				3.3	43	3.4	43	3.5	43	3.6
YOD 43 2.8 43 2.9 43 3.0 43 3.1 YOD 1000 43 2.6 43 2.7 43 2.8 43 2.9 3001 800 43 3.6 42 3.3 42 3.2 42 3.3 42 3.2 42 3.3 42 3.2 42 3.3 3.8 42 3.2 42 3.3 3.8 42 3.2 42 3.3 3.8 42 3.2 42 3.3 3.8 42 3.2 42 3.3 3.8 42 3.2 42 3.3 3.8 3.6 43 3.2 43 3.3 43 3.4 43 3.6 43 3.0 43 3.1 43 3.4 43 3.8 43 2.9 43 3.0 43 3.6 43 3.8 43 2.9 43 3.0 43 3.1 43 3.2 43	-	0000 (014)	925	43	3.1	43	3.2	43	3.3	43	3.4
1000			950	43	2.9	43		43	3.1	43	3.2
1775			975	43	2.8	43	2.9	43	3.0	43	3.1
3001 800 43 3.6 43 3.8 42 3.2 42 3.3 (915) 825 43 3.4 43 3.5 43 3.7 43 3.8 10 875 43 3.0 43 3.1 43 3.3 43 3.4 4000 900 43 2.9 43 3.0 43 3.1 43 3.2 4000 950 43 2.6 43 2.7 43 2.8 43 2.9 4001 775 43 3.6 43 3.5 43 3.6 43 3.5 10 825 43 3.2 43 3.3 43 3.4 43 3.5 10 825 43 3.2 43 3.3 43 3.4 43 3.5 10 825 43 3.0 43 3.1 43 3.2 43 3.5 10 825 43 3.0 43 3.1 43 3.2 43 3.5 10 825 43 3.0 43 3.1 43 3.2 43 3.3 10 825 43 3.0 43 3.1 43 3.2 43 3.3 10 825 43 3.0 43 3.1 43 3.2 43 3.3 10 825 43 2.7 43 2.8 43 2.9 43 3.0 10 825 43 2.7 43 2.8 43 2.9 43 3.0 10 825 43 2.7 43 2.8 43 2.9 43 3.0 10 825 43 3.4 43 3.5 43 3.6 43 3.1 10 825 43 3.4 43 3.5 43 3.6 43 3.1 10 825 43 2.7 43 2.8 43 2.9 43 3.0 10 825 43 3.4 43 3.5 43 3.6 43 3.7 10 825 43 3.4 43 3.5 43 3.6 43 3.7 10 825 43 3.4 43 3.5 43 3.6 43 3.7 10 825 43 3.4 43 3.5 43 3.6 43 3.7 10 800 43 2.8 43 2.9 43 3.0 43 3.1 10 825 43 2.3 43 2.5 43 2.6 43 2.7 10 800 43 2.8 43 2.9 43 3.0 43 3.1 10 800 43 2.3 43 2.5 43 2.5 43 2.6 10 800 43 2.3 43 2.4 43 2.5 43 2.5 43 2.6 10 800 43 2.3 43 2.4 43 2.5 43 2.6 10 800 43 2.3 43 2.4 43 2.5 43 2.5 43 2.6 10 750 43 3.1 43 3.3 43 3.4 43 3.5 10 750 43 3.1 43 3.3 43 3.4 43 3.5 10 750 43 3.1 43 3.3 43 3.4 43 3.5 10 750 43 2.7 43 2.8 43 2.9 43 3.0 10 750 43 2.7 43 2.8 43 2.9 43 3.0 10 750 43			1000	43	2.6	43	2.7	43	2.8	43	2.9
(915) 825 43 3.4 43 3.5 43 3.7 43 3.8 3.8 400 875 43 3.2 43 3.3 43 3.4 43 3.5 43 3.6 43 3.6 4000 900 43 2.9 43 3.0 43 3.1 43 3.1 43 3.2 43 3.0 43 3.1 43 3.2 43 3.0 43 3.1 43 3.2 43 3.0 43 3.1 43 3.2 43 3.0 43 3.1 43 3.2 43 3.0 43 3.1 43 3.2 43 3.0 43 3.1 43 3.2 43 3.0 43 3.1 43 3.2 43 3.0 43 3.1 43 3.2 43 3.0 43 3.1 43 3.2 43 3.1 43 3.2 43 3.1 43 3.2 43 3.1 43 3.2 43 3.1 43 3.2 43 3.3 43 3.4 43 3.5 43 3.6 43 3.8 43 3.2 43 3.3 43 3.4 43 3.5 43 3.2 43 3.3 43 3.4 43 3.5 43 3.5 43 3.2 43 3.3 43 3.4 43 3.5			775	42	3.2	42	3.3	42	3.4	42	3.5
Q ∩ D to 850 (43) 3.2 (43) 3.3 (43) 43 (3.3) 3.4 (43) 3.4 (43) 3.4 (43) 3.4 (43) 3.4 (43) 3.4 (43) 3.4 (43) 3.4 (43) 3.4 (43) 3.4 (43) 3.4 (43) 3.4 (43) 3.4 (43) 3.4 (43) 3.2 (43) 3.1 (43) 3.3 (43) 3.4 (43) 3.0 (43) 3.1 (43) 3.3 (43) 3.0 (43) 3.0 (43) 3.2 (43) 3.2 (42) 3.3 (42) 3.2 (42) 3.3 (42) 3.8 (42) 3.2 (42) 3.3 (42) 3.8 (42) 3.2 (42) 3.3 (42) 3.8 (42) 3.2 (42) 3.3 (42) 3.8 (42) 3.2 (42) 3.3 (42) 3.8 (42) 3.2 (42) 3.3 (42) 3.8 (42) 3.2 (42) 3.3 (42) 3.8 (42) 3.2 (42) 3.3 (43) 3.4 (43) 3.5 (43) 3.3 (43) 3.4 (43) 3.5 (43) 3.3 (43) 3.4 (43) 3.5 (43) 3.3 (43) 3.4 (43) 3.5 (43) 3.3 (43) 3.4 (43) 3.5 (43) 3.3 (43) 3.4 (43) 3.5 (43) 3.5 (43) 3.0 (43) 3.1 (43) 3.2 (43) 3.3 (43) 3.4 (43) 3.5		3001	800	43	3.6	43	3.8	42	3.2	42	3.3
4000 900 43 2.9 43 3.0 43 3.1 43 3.2 (1219) 925 43 2.7 43 2.8 43 2.9 43 3.0 950 43 2.6 43 2.7 43 2.8 43 2.9 43 3.0 4001 775 43 3.6 43 3.5 42 3.2 42 3.3 4001 775 43 3.4 43 3.5 43 3.6 43 3.8 (1220) 800 43 3.2 43 3.3 43 3.4 43 3.5 to 825 43 3.0 43 3.1 43 3.2 43 3.3 to 825 43 3.0 43 3.1 43 3.2 43 3.3 (1524) 900 43 2.5 43 2.6 43 2.7 43 2.8 925 43 2.4 43 2.5 43 2.6 43 2.6 (1524) 900 43 3.2 43 3.3 43 3.4 43 3.5 5001 750 43 3.4 43 3.5 43 3.6 43 3.7 5001 750 43 3.2 43 3.3 43 3.4 43 3.5 10 800 43 2.8 43 2.9 43 3.0 43 3.1 10 800 43 2.8 43 2.9 43 3.0 43 3.1 10 825 43 2.6 43 2.7 43 2.8 43 2.9 6000 850 43 2.5 43 2.5 43 2.6 43 2.7 6001 750 43 3.2 43 3.3 43 3.4 43 3.5 6000 850 43 2.5 43 2.5 43 2.6 43 2.7 900 43 2.2 43 2.3 43 2.3 43 2.3 400 400 400 400 400 400 400	ر ا	(915)	825	43	3.4	43	3.5	43	3.7	43	3.8
4000 900 43 2.9 43 3.0 43 3.1 43 3.2 (1219) 925 43 2.7 43 2.8 43 2.9 43 3.0 950 43 2.6 43 2.7 43 2.8 43 2.9 43 3.0 4001 775 43 3.6 43 3.5 42 3.2 42 3.3 4001 775 43 3.4 43 3.5 43 3.6 43 3.8 (1220) 800 43 3.2 43 3.3 43 3.4 43 3.5 to 825 43 3.0 43 3.1 43 3.2 43 3.3 to 825 43 3.0 43 3.1 43 3.2 43 3.3 (1524) 900 43 2.5 43 2.6 43 2.7 43 2.8 925 43 2.4 43 2.5 43 2.6 43 2.6 (1524) 900 43 3.2 43 3.3 43 3.4 43 3.5 5001 750 43 3.4 43 3.5 43 3.6 43 3.7 5001 750 43 3.2 43 3.3 43 3.4 43 3.5 10 800 43 2.8 43 2.9 43 3.0 43 3.1 10 800 43 2.8 43 2.9 43 3.0 43 3.1 10 825 43 2.6 43 2.7 43 2.8 43 2.9 6000 850 43 2.5 43 2.5 43 2.6 43 2.7 6001 750 43 3.2 43 3.3 43 3.4 43 3.5 6000 850 43 2.5 43 2.5 43 2.6 43 2.7 900 43 2.2 43 2.3 43 2.3 43 2.3 400 400 400 400 400 400 400	S.A	to.	850	43	3.2	43	3.3	43	3.4	43	3.6
(1219) 925	=		875	43	3.0	43	3.1	43	3.3	43	3.4
Part		4000	900	43	2.9	43	3.0	43	3.1	43	3.2
4001 750 43 3.6 43 3.8 42 3.2 42 3.3 401 775 43 3.4 43 3.5 43 3.6 43 3.8 401 775 43 3.4 43 3.5 43 3.4 43 3.5 10 825 43 3.0 43 3.1 43 3.2 43 3.3 5000 875 43 2.8 43 2.9 43 3.0 43 3.1 43 3.0 43 3.1 5000 875 43 2.7 43 2.8 43 2.9 43 2.9 43 2.9 (1524) 900 43 2.5 43 2.6 43 2.7 43 2.8 43 2.9 43 2.2 925 43 2.4 43 2.5 43 2.6 43 2.7 43 2.8 43		(1219)	925	43	2.7	43	2.8	43	2.9	43	3.0
4001											
(1220)				43	3.6	l	3.8		3.2		3.3
Q D D D D D D D D D D D D D D D D D D D											3.8
South Sout	. ا	(1220)				43	3.3		3.4	43	3.5
South Sout	S.A	to.	825	43	3.0	43	3.1	43	3.2	43	3.3
(1524) 900 43 2.5 43 2.6 43 2.7 43 2.8 2.6 43 2.7 43 2.8 43 2.9 43 3.0 43 3.1 43 3.2 43 3.1 43 3.2 43 3.1 43 3.2 43 3.1 43 3.2 43 3.1 43 3.2 43 3.1 43 2.6 43 2.7 43 2.8 43 2.9 43 2.6 43 2.7 43 2.8 43 2.9 43 2.6 43 2.7 43 2.8 43 2.9 43 3.0 43 3.1 43 3.1 43 3.2 44 3 3.5 43 2.9 43 3.0 43 3.1 43 3.1 43 3.1 43 3.2 44 33 2.5 43 2.6 43 2.7 43 2.8 43 2.9 43 3.0 43 3.1 43	-										
Part		5000	875	43	2.7	43	2.8	43	2.9	43	2.9
1		(1524)	900	43	2.5	43	2.6	43	2.7	43	2.8
Solid 750			925	43	2.4	43	2.5	43	2.6	43	2.6
(1525) 775 43 3.0 43 3.1 43 3.2 43 3.3 to 825 43 2.6 43 2.7 43 2.8 43 2.9 6000 850 43 2.5 43 2.5 43 2.6 43 2.7 (43 2.8 43 2.9 (1829) 875 43 2.3 43 2.3 43 2.5 43 2.6 43 2.6 (1829) 875 43 2.3 43 2.4 43 2.5 43 2.6 2.6 (1829) 6000 43 2.2 43 2.3 43 2.3 43 2.3 43 2.4 (1830) 725 43 3.1 43 3.5 43 3.5 (1830) 725 43 2.9 43 3.1 43 3.3 43 3.4 43 3.5 (1830) 725 43 2.9 43 3.0 43 3.1 43 3.2 (1830) 725 43 2.9 43 2.9 43 3.0 43 3.1 43 3.2 (1830) 725 43 2.7 43 2.8 43 2.9 43 3.0 (1830) 725 43 2.7 43 2.8 43 2.9 43 3.0 (1830) 725 43 2.6 43 2.7 43 2.8 43 2.9 43 3.0 (1830) 800 43 2.4 43 2.5 43 2.5 43 2.7 43 2.8 (1830) 825 43 2.3 43 2.3 43 2.5 43 2.5 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.5 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.5 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.5 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.5 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.5 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.5 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.5 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.3 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.3 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.3 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.3 43 2.3 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.3 43 2.4 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.3 43 2.3 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.3 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.3 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.3 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.3 43 2.3 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.3 43 2.3 43 2.5 (1830) 825 43 2.3 43 2.3 43 2.3 43 2.3 43 2.5 (1830) 825 43 2.3 43										l	
Q D D D D D D D D D D D D D D D D D D D						l				l	
6000 850 43 2.5 43 2.5 43 2.6 43 2.7 (1829) 875 43 2.3 43 2.4 43 2.5 43 2.6 2.6 2.6 2.6 2.6 2.3 43 2.4 43 2.5 43 2.6 2.6 2.6 2.3 43 2.4 2.3 43 2.4 2.3 43 2.4 2.3 43 2.4 2.3 43 2.4 2.3 43 2.4 2.3 43 2.4 2.3 43 2.4 2.5 2.5 2.3 43 2.4 2.3 2.5 2.5 2.5 2.5 2.5 2.5 2.5 2.5 2.5 2.5	اد ا	(1525)	775	43	3.0	43	3.1	43	3.2	43	3.3
6000 850 43 2.5 43 2.5 43 2.6 43 2.7 (1829) 875 43 2.3 43 2.4 43 2.5 43 2.6 2.6 2.6 2.6 2.6 2.3 43 2.4 43 2.5 43 2.6 2.6 2.6 2.3 43 2.4 2.3 43 2.4 2.3 43 2.4 2.3 43 2.4 2.3 43 2.4 2.3 43 2.4 2.3 43 2.4 2.3 43 2.4 2.5 2.5 2.3 43 2.4 2.3 2.5 2.5 2.5 2.5 2.5 2.5 2.5 2.5 2.5 2.5	S.	l to		43	2.8	43	2.9	43	3.0	43	3.1
(1829) 875 43 2.3 43 2.4 43 2.5 43 2.6 900 43 2.2 43 2.3 43 2.3 43 2.4 43 2.3 43 2.4 43 2.3 43 2.4 43 2.4 43 2.3 43 2.4 43 2.4 43 2.5 43 2.4 43 2.4 43 2.5 43 2.4 43 2.5 4	=		825	43	2.6	43	2.7	43	2.8	43	2.9
900 43 2.2 43 2.3 43 2.3 43 2.4 6001 700 43 3.1 43 3.5 43 3.4 43 3.5 (1830) 725 43 2.9 43 3.0 43 3.1 43 3.2 10 750 43 2.7 43 2.8 43 2.9 43 3.0 7000 800 43 2.4 43 2.5 43 2.6 43 2.7 (2133) 825 43 2.3 43 2.3 43 2.4 43 2.5 2.3 43 2.4 43 2.5 43 2.6 43 2.7 (2133) 825 43 2.3 43 2.3 43 2.4 43 2.5		6000	850	43	2.5	43	2.5	43	2.6	43	2.7
675 43 3.4 43 3.5 43 3.6 43 3.7 (1830) 725 43 2.9 43 3.0 43 3.1 43 3.2 (1830) 725 43 2.9 43 3.0 43 3.1 43 3.2 (1830) 725 43 2.9 43 2.8 43 2.9 43 3.0 (1830) 750 43 2.7 43 2.8 43 2.9 43 3.0 (1830) 750 43 2.6 43 2.7 43 2.7 43 2.8 (1830) 7000 800 43 2.4 43 2.5 43 2.6 43 2.7 (1830) 825 43 2.3 43 2.3 43 2.4 43 2.5		(1829)					2.4				2.6
4 (1830) 700 43 3.1 43 3.3 43 3.4 43 3.5 4 (1830) 725 43 2.9 43 3.0 43 3.1 43 3.2 4 to 750 43 2.7 43 2.8 43 2.9 43 3.0 7000 800 43 2.6 43 2.7 43 2.6 43 2.5 43 2.6 43 2.5 43 2.4 43 2.5				43	2.2	43	2.3	43	2.3	43	2.4
(1830) 725 43 2.9 43 3.0 43 3.1 43 3.2 (1830) 750 43 2.7 43 2.8 43 2.9 43 3.0 (10 775 43 2.6 43 2.7 43 2.7 43 2.8 (2133) 825 43 2.3 43 2.3 43 2.4 43 2.5			675	43	3.4	43	3.5	43	3.6	43	3.7
GO DI (1) 750 43 2.7 43 2.8 43 2.9 43 3.0 700 800 43 2.6 43 2.7 43 2.7 43 2.8 7000 800 43 2.4 43 2.5 43 2.6 43 2.7 (2133) 825 43 2.3 43 2.3 43 2.4 43 2.5		6001	700	43	3.1	43	3.3	43	3.4	43	3.5
7000 800 43 2.4 43 2.5 43 2.6 43 2.7 (2133) 825 43 2.3 43 2.3 43 2.4 43 2.5	١.	(1830)	725	43	2.9	43	3.0	43	3.1	43	3.2
7000 800 43 2.4 43 2.5 43 2.6 43 2.7 (2133) 825 43 2.3 43 2.3 43 2.4 43 2.5	S.A	l to	750	43	2.7	43	2.8	43	2.9	43	3.0
(2133) 825 43 2.3 43 2.3 43 2.4 43 2.5	=	l "	775	43	2.6	43	2.7	43	2.7	43	2.8
		7000	800	43	2.4	43	2.5	43	2.6	43	2.7
850 43 2.1 43 2.2 43 2.3 43 2.4		(2133)			2.3	43	2.3	43	2.4	43	2.5
			850	43	2.1	43	2.2	43	2.3	43	2.4

A10180

	(TABULATED DATA BASED ON 22,000 BTUH PER BURNER, DERATED 4%/1000 FT (305M) ABOVE SEA LEVEL) ALTITUDE AVG. GAS SPECIFIC GRAVITY OF NATURAL GAS									
	ALTITUDE	AVG. GAS			SPECIF	IC GRAVITY	OF NAT	URAL GAS		
	RANGE HEAT VALUE).58	0.60		0.62		0.64	
		AT ALTITUDE	Orifice	Manifold	Orifice	Manifold	Orifice	Manifold	Orifice	Manifold
	ft (m)	(Btu/cu ft)	No.	Pressure	No.	Pressure	No.	Pressure	No.	Pressure
		650	43	3.1	43	3.2	43	3.4	43	3.5
	7001	675	43	2.9	43	3.0	43	3.1	43	3.2
	(2134)	700	43	2.7	43	2.8	43	2.9	43	3.0
U.S.A.	to	725	43	2.5	43	2.6	43	2.7	43	2.8
%	10	750	43	2.4	43	2.4	43	2.5	43	2.6
	8000	775	43	2.2	43	2.3	43	2.4	43	2.4
	(2438)	800	43	2.1	43	2.1	43	2.2	43	2.3
		825	48	3.7	43	2.0	43	2.1	43	2.2
		625	43	2.9	43	3.0	43	3.1	43	3.2
	8001	650	43	2.7	43	2.8	43	2.9	43	3.0
aí.	(2439)	675	43	2.5	43	2.6	43	2.7	43	2.8
U.S.A.	to	700	43	2.3	43	2.4	43	2.5	43	2.6
"		725	43	2.2	43	2.2	43	2.3	43	2.4
	9000	750	43	2.0	43	2.1	43	2.2	43	2.2
	(2743)	775	48	3.6	48	3.7	43	2.0	43	2.1
	9001	600	43	2.7	43	2.8	43	2.9	43	3.0
	(2744)	625	43	2.5	43	2.6	43	2.6	43	2.7
U.S.A.	to	650	43	2.3	43	2.4	43	2.4	43	2.5
l S.	"	675	43	2.1	43	2.2	43	2.3	43	2.3
	10000	700	48	3.7	43	2.0	43	2.1	43	2.2
	(3048)	725	48	3.5	48	3.6	48	3.7	43	2.0

* Orifice numbers shown in **BOLD** are factory-installed.

A10180A

Table 12 – Orifice Size* And Manifold Pressure (In. W.C.) For Gas Input Rate

(TABULATED DATA BASED ON 21,000 BTUH PER BURNER, DERATED 4%/1000 FT (305M) ABOVE SEA LEVEL)

	ALTITUDE	ATA BASED ON 21,000 BTUH PER BURNER, DERATED 4%/1000 FT (305M) ABOVE SEA LEVEL) AVG. GAS SPECIFIC GRAVITY OF NATURAL GAS								
1	RANGE									204
						0.60		0.62		
	ft (m)	AT ALTITUDE (Btu/cu ft)	Orifice No.	Manifold Pressure	Orifice No.	Manifold Pressure	Orifice No.	Manifold Pressure	Orifice No.	Manifold Pressure
\vdash	1 (111)	900	42	3.2	42	3.3	42	3.4	42	3.5
	0	925	43	3.7	43	3.8	42	3.2	42	3.3
	(0)	950	43	3.5	43	3.6	43	3.7	43	3.8
	(0)	975	43	3.3	43	3.4	43	3.5	43	3.7
₹	to	1000	44	3.6	43	3.3	43	3.4	43	3.5
U.S.A.	"	1025	44	3.4	44	3.6	43	3.2	43	3.3
-	2000	1050	44	3.3	44	3.4	44	3.5	43	3.2
	(610)	1075	45	3.8	44	3.2	44	3.3	44	3.4
	(0.0)	1100	46	3.8	45	3.7	44	3.2	44	3.3
$\overline{}$		800	43	3.8	42	3.2	42	3.3	42	3.4
		825	43	3.5	43	3.7	43	3.8	42	3.2
		850	43	3.3	43	3.5	43	3.6	43	3.7
	2001 (611)	875	43	3.2	43	3.3	43	3.4	43	3.5
≼	to	900	43	3.0	43	3.1	43	3.2	43	3.3
U.S.A.	3000 (914)	925	43	2.8	43	2.9	43	3.0	43	3.1
		950	43	2.7	43	2.8	43	2.9	43	2.9
		975	43	2.5	43	2.6	43	2.7	43	2.8
		1000	43	2.4	43	2.5	43	2.6	43	2.7
		775	43	3.5	43	3.7	43	3.8	42	3.2
	3001	800	43	3.3	43	3.4	43	3.5	43	3.7
	(915)	825	43	3.1	43	3.2	43	3.3	43	3.4
l ∢		850	43	2.9	43	3.0	43	3.1	43	3.2
U.S.A.	to	875	43	2.8	43	2.9	43	3.0	43	3.1
-	4000	900	43	2.6	43	2.7	43	2.8	43	2.9
	(1219)	925	43	2.5	43	2.6	43	2.7	43	2.7
	` ′	950	43	2.4	43	2.4	43	2.5	43	2.6
		750	43	3.3	43	3.4	43	3.5	43	3.6
	4001	775	43	3.1	43	3.2	43	3.3	43	3.4
	(1220)	800	43	2.9	43	3.0	43	3.1	43	3.2
ı≼		825	43	2.7	43	2.8	43	2.9	43	3.0
U.S.A.	to	850	43	2.6	43	2.7	43	2.8	43	2.8
-	5000	875	43	2.4	43	2.5	43	2.6	43	2.7
	(1524)	900	43	2.3	43	2.4	43	2.5	43	2.5
		925	43	2.2	43	2.2	43	2.3	43	2.4
		725	43	3.1	43	3.2	43	3.3	43	3.4
	5001	750	43	2.9	43	3.0	43	3.1	43	3.2
	(1525)	775	43	2.7	43	2.8	43	2.9	43	3.0
U.S.A.	to	800	43	2.5	43	2.6	43	2.7	43	2.8
l s.	"	825	43	2.4	43	2.5	43	2.5	43	2.6
	6000	850	43	2.2	43	2.3	43	2.4	43	2.5
	(1829)	875	43	2.1	43	2.2	43	2.3	43	2.3
		900	43	2.0	43	2.1	43	2.1	43	2.2
		675	43	3.1	43	3.2	43	3.3	43	3.4
	6001	700	43	2.9	43	3.0	43	3.1	43	3.2
١	(1830)	725	43	2.7	43	2.8	43	2.9	43	2.9
U.S.A.	to	750	43	2.5	43	2.6	43	2.7	43	2.8
ا ت		775	43	2.3	43	2.4	43	2.5	43	2.6
	7000	800	43	2.2	43	2.3	43	2.3	43	2.4
	(2133)	825	43	2.1	43	2.1	43	2.2	43	2.3
		850	48	3.7	43	2.0	43	2.1	43	2.1

A10181

(TABULATED	DATA BASED ON	21,000 BTUH PER BURNER, DERATED 4%/1000 FT (305M) ABOVE SEA LEVEL)
ALTITUDE	AVG. GAS	SPECIFIC GRAVITY OF NATURAL GAS

	ALTITUDE	AVG. GAS	, <u> </u>			IC GRAVITY				
	RANGE	HEAT VALUE		0.58		0.60	(0.62	0.64	
		AT ALTITUDE	Orifice	Manifold	Orifice	Manifold	Orifice	Manifold	Orifice	Manifold
	ft (m)	(Btu/cu ft)	No.	Pressure	No.	Pressure	No.	Pressure	No.	Pressure
	1	650	43	2.9	43	3.0	43	3.1	43	3.2
	7001	675	43	2.7	43	2.7	43	2.8	43	2.9
	(2134)	700	43	2.5	43	2.6	43	2.6	43	2.7
U.S.A.	to	725	43	2.3	43	2.4	43	2.5	43	2.5
l S.	"	750	43	2.1	43	2.2	43	2.3	43	2.4
	8000	775	43	2.0	43	2.1	43	2.2	43	2.2
	(2438)	800	48	3.6	48	3.7	43	2.0	43	2.1
		825	48	3.3	48	3.5	48	3.6	48	3.7
		625	43	2.7	43	2.7	43	2.8	43	2.9
	8001	650	43	2.5	43	2.5	43	2.6	43	2.7
نها	(2439)	675	43	2.3	43	2.4	43	2.4	43	2.5
U.S.A.	to	700	43	2.1	43	2.2	43	2.3	43	2.3
"		725	48	3.7	43	2.0	43	2.1	43	2.2
	9000	750	48	3.5	48	3.6	48	3.7	43	2.0
	(2743)	775	49	3.8	48	3.4	48	3.5	48	3.6
	9001	600	43	2.4	43	2.5	43	2.6	43	2.7
١	(2744)	625	43	2.3	43	2.3	43	2.4	43	2.5
U.S.A.	to	650	43	2.1	43	2.2	43	2.2	43	2.3
5	."	675	48	3.6	48	3.8	43	2.1	43	2.1
	10000	700	48	3.4	48	3.5	48	3.6	48	3.7
	(3048)	725	49	3.7	49	3.8	48	3.4	48	3.5

* Orifice numbers shown in BOLD are factory-installed.

A10181

WARNING

FURNACE OVERHEATING HAZARD

Failure to follow this caution may result in reduced furnace life.

Recheck temperature rise. It must be within limits specified on the rating plate. Recommended operation is at the mid-point of rise range or slightly above.

- 6. Set thermostat heat anticipator.
 - a. Mechanical thermostat Set thermostat heat anticipator to match
 the amp. draw of the electrical components in the R-W circuit.
 Accurate amp. draw readings can be obtained at the wires
 normally connected to thermostat subbase terminals, R and W.
 The thermostat anticipator should NOT be in the circuit while
 measuring current.
 - (1.) Remove thermostat from subbase or from wall.
 - (2.) Connect an amp. meter as shown in Fig. 47 across the R and W subbase terminals or R and W wires at wall.
 - (3.) Record amp. draw across terminals when furnace is in heating and after blower starts.
 - (4.) Set heat anticipator on thermostat per thermostat instructions and install on subbase or wall.
 - b. Electronic thermostat: Set cycle rate for 4 cycles per hr.




Fig. 47 – Amp. Draw Check with Ammeter Table 13 – Gas Rate (Cu Ft./Hr.)

A96316

Table 13 – Gas Rate (Cu Ft./Hr.) (Continued)

SECONDS	SIZE OF TEST DIAL			SECONDS	SIZE OF TEST DIAL			
FOR 1 REVOLUTION	1 Cu Ft.	2 Cu Ft.	5 Cu Ft.	FOR 1 REVOLUTION	1 Cu Ft.	2 Cu Ft.	5 Cu Ft.	
42	86	172	429	104	35	69	173	
43	84	167	419	106	34	68	170	
44	82	164	409	108	33	67	167	
45	80	160	400	110	33	65	164	
46	78	157	391	112	32	64	161	
47	76	153	383	116	31	62	155	
48	75	150	375	120	30	60	150	
49	73	147	367					

- 7. Adjust blower off delay The blower off delay has 4 adjustable settings from 90 sec to 180 sec. The blower off delay jumpers are located on the furnace control board (see Fig. 28).
 - To change the blower off delay setting, move the jumper from one set of pins on the control to the pins used for the selected blower off delay. Factory off delay setting is 120 sec.
- Set airflow CFM for cooling
 Select the desired blower motor speed lead for cooling airflow. See
 Table 5-Air Delivery-CFM (With Filter) for lead color
 identification.

Check Safety Controls

The flame sensor, gas valve, and pressure switch were all checked in the Start-up procedure section as part of normal operation.

- 1. Check Main Limit Switch(es)
 - This control shuts off combustion control system and energizes air-circulating blower motor, if furnace overheats. By using this method to check limit control, it can be established that limit is functioning properly and will operate if there is a restricted duct system or motor failure. If limit control does not function during this test, cause must be determined and corrected.
 - a. Run furnace for at least 5 minutes.
 - b. Gradually block off return air with a piece of cardboard or sheet metal until the limit trips.
 - c. Unblock return air to permit normal circulation.
 - d. Burners will re-light when furnace cools down.
- 2. Check draft safeguard switch.

The purpose of this control is to cause the safe shutdown of the furnace during certain blocked vent conditions.

- a. Verify vent pipe is cool to the touch.
- b. Disconnect power to furnace and remove vent connector from furnace vent elbow.
- c. Restore power to furnace and set room thermostat above room temperature.
- d. After normal start-up, allow furnace to operate for 2 minutes, then block vent elbow in furnace 80 percent of vent area with a piece of flat sheet metal.
- e. Furnace should cycle off within 2 minutes. If gas does not shut off within 2 minutes, determine reason draft safeguard switch did not function properly and correct condition.
- f. Remove blockage from furnace vent elbow.
- g. Switch will auto-reset when it cools.
- h. Re-install vent connector.

NOTE: Should switch remain open longer than 3 minutes, furnace control board will lockout the furnace for 3 hours. To reset furnace control board, turn thermostat below room temperature or from HEAT to OFF and turn 115v power OFF, then back ON.

3. Check Pressure Switch

This control proves operation of the draft inducer blower.

- a. Turn off 115-v power to furnace.
- b. Disconnect inducer motor lead wires from wire harness.
- c. Turn on 115-v power to furnace.

- d. Set thermostat to "call for heat" and wait 1 minute. When pressure switch is functioning properly, hot surface igniter should NOT glow and control diagnostic light flashes a status code 31. If hot surface igniter glows when inducer motor is disconnected, shut down furnace immediately.
- e. Determine reason pressure switch did not function properly and correct condition.
- f. Turn off 115-v power to furnace.
- g. Reconnect inducer motor wires, replace outer door, and turn on 115-v power.
- h. Blower will run for 90 sec before beginning the call for heat again.
- i. Furnace should ignite normally.

Checklist

- 1. Put away tools and instruments. Clean up debris.
- 2. Verify that blower OFF-DELAY time is selected as desired.
- 3. Verify that blower and burner access doors are properly installed.
- 4. Cycle test furnace with room thermostat.
- 5. Check operation of accessories per manufacturer's instructions.
- 6. Review User's Guide with owner.
- 7. Attach literature packet to furnace.

SERVICE AND MAINTENANCE PROCEDURES

Untrained personnel can perform basic maintenance functions such as cleaning and replacing air filters. All other operations must be performed by trained service personnel. A qualified service person should inspect the furnace once a year.

WARNING

FIRE, INJURY, OR DEATH HAZARD

Failure to follow this warning could result in personal injury, death and/or property damage.

The ability to properly perform maintenance on this equipment requires certain knowledge, mechanical skills, tools, and equipment. If you do not possess these, do not attempt to perform any maintenance on this equipment other than those procedures recommended in the User's Manual.

MARNING

ELECTRICAL SHOCK, FIRE OR EXPLOSION HAZARD

Failure to follow this warning could result in personal injury or death. Before installing, modifying, or servicing system, main electrical disconnect switch must be in the OFF position and install a lockout tag. There may be more than one disconnect switch. Lock out and tag switch with a suitable warning label. Verify proper operation after servicing.

A CAUTION

ELECTRICAL OPERATION HAZARD

Failure to follow this caution may result in improper furnace operation or failure of furnace.

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation.

GENERAL

These instructions are written as if the furnace is installed in an upflow application. An upflow furnace application is where the blower is located below the combustion and controls section of the furnace, and

conditioned air is discharged upward. Since this furnace can be installed in any of the 4 positions (see Fig. 6), you must revise your orientation to component location accordingly.

ELECTRICAL CONTROLS AND WIRING

The electrical ground and polarity for 115-v wiring must be properly maintained. Refer to Fig. 24 for field wiring information and to Fig. 45 for furnace wiring information.

A WARNING

ELECTRICAL OPERATION HAZARD

Failure to follow this warning could result in personal injury or death. There may be more than one electrical supply to the furnace. Check accessories and cooling unit for additional electrical supplies that must be shut off during furnace servicing. Lock out and tag switch with a suitable warning label.

NOTE: If the polarity is not correct, the STATUS LED on the control will flash rapidly and prevent the furnace from heating. The control system also requires an earth ground for proper operation of the control and flame-sensing electrode.

The 24-v circuit contains an automotive-type, 3-amp. fuse located on the control (see Fig. 28). Any shorts of the 24-v wiring during installation, service, or maintenance will cause this fuse to blow. If fuse replacement is required, use ONLY a 3-amp. fuse. The control LED will display status code 24 when fuse needs to be replaced.

Proper instrumentation is required to service electrical controls. The control in this furnace is equipped with a Status Code LED (Light-Emitting Diode) to aid in installation, servicing, and troubleshooting. Status codes can be viewed at the sight glass in blower access door. The furnace control LED is either ON continuously, rapid flashing, or a code composed of 2 digits. The first digit is the number of short flashes, the second digit is the number of long flashes.

For an explanation of status codes, refer to service label located on blower access door, or Fig. 44 and the troubleshooting guide which can be obtained from your distributor.

See Fig. 51 for a brief Troubleshooting Guide.

For Controls With an Amber LED

The stored status code will not be erased from the control memory, if 115- or 24-v power is interrupted.

1. To retrieve status code, proceed with the following:

NOTE: NO thermostat signal may be present at control, and all blower-OFF delays must be completed.

- a. Leave 115-v power to furnace turned on.
- b. Remove outer access door.
- c. Look into blower access door sight glass for current LED status.
- d. BRIEFLY remove insulated terminal wire from the draft safeguard (DSS) switch until LED goes out, then reconnect it.

NOTE: If wire to LS or DSS is disconnected longer than 4 sec, main blower starts, and status code is overwritten with a limit circuit 33 code.

- 2. When above items have been completed, the LED flashes status code 4 times. Record this status code for further troubleshooting.
- 3. Check LED status. If no previous faults in history, control will flash status code 11.

CARE AND MAINTENANCE

A WARNING

FIRE OR EXPLOSION HAZARD

Failure to follow this warning could result in personal injury, death and/or property damage.

Never store anything on, near, or in contact with the furnace, such as:

- 1. Spray or aerosol cans, rags, brooms, dust mops, vacuum cleaners, or other cleaning tools.
- Soap powders, bleaches, waxes or other cleaning compounds, plastic or plastic containers, gasoline, kerosene, cigarette lighter fluid, dry cleaning fluids, or other volatile fluids.
- 3. Paint thinners and other painting compounds, paper bags, or other paper products.

For continuing high performance and to minimize possible equipment failure, periodic maintenance must be performed on this equipment. Consult your local dealer about proper frequency of maintenance and the availability of a maintenance contract.

WARNING

ELECTRICAL SHOCK AND FIRE HAZARD

Failure to follow this warning could result in personal injury, death or property damage.

Turn off the gas and electrical supplies to the unit and install lockout tag before performing any maintenance or service. Follow the operating instructions on the label attached to the furnace.

WARNING

CARBON MONOXIDE POISONING AND FIRE HAZARD

Failure to follow this warning could result in personal injury, death and/or property damage.

Never operate unit without a filter or with filter access door removed.

A CAUTION

CUT HAZARD

Failure to follow this caution may result in personal injury.

Sheet metal parts may have sharp edges or burrs. Use care and wear appropriate protective clothing, safety glasses and gloves when handling parts and servicing furnaces.

The minimum maintenance on this furnace is as follows:

- Check and clean/replace air filter each month or more frequently if required. Replace if torn.
- 2. Check blower motor and wheel for cleanliness each heating and cooling season. Clean as necessary.
- 3. Check electrical connections for tightness and controls for proper operation each heating season. Service as necessary.
- 4. Inspect burner compartment before each heating season for rust, corrosion, soot or excessive dust. If necessary, have furnace and burner serviced by a qualified service agency.
- Inspect the vent pipe/vent system before each heating season for rust, corrosion, water leakage, sagging pipes or broken fittings. Have vent pipes/vent system serviced by a qualified service agency.

Inspect any accessories attached to the furnace such as a humidifier
or electronic air cleaner. Perform any service or maintenance to the
accessories as recommended in the accessory instructions.

CLEANING AND/OR REPLACING AIR FILTER

The air filter arrangement will vary depending on the application. The filter is exterior to the furnace casing.

NOTE: If the filter has an airflow direction arrow, the arrow must point towards the blower.

Media cabinet filter procedures:

- Turn off electrical supply to furnace before removing filter access
 door.
- 2. Remove filter cabinet door.
- 3. Slide filter out of cabinet.
- 4. If equipped with permanent, washable 3/4-in. (19 mm) filter, clean filter by spraying cold tap water through filter in opposite direction of airflow. Rinse filter and let dry. Oiling or coating of the filter is not recommended. See Table 14 for size information.
- If equipped with factory-specified disposable media filter, replace only with media filter having the same part number and size. For expandable replacement media, refer to the instructions included with the replacement media.
- 6. Slide filter into cabinet.
- 7. Replace filter cabinet door.
- 8. Turn on electrical supply to furnace.

Table 14 – Filter Size Information (In. / mm)

FURNACE	FILTER SIZ		
CASING			
WIDTH			FILTER
In. (mm)	Side Return	Bottom Return	TYPE*
14-1/2	16 x 25 x 3/4	14 x 25 x 3/4	Washable
(368)	(406 x 635 x 19)	(356 x 635 x 19)	Washable
17-1/2	16 X 25 X 3/4	16 X 25 X 3/4	Washable
(445)	(406 x 635 x 19)	(406 x 635 x 19)	Washabic
21	16 x 25 x 3/4	20 X 25 X 3/4	Washable
(533)	(406 x 635 x 19)	(508 x 635 x 19)	Washable
24	16 x 25 x 3/4	24 X 25 X 3/4	Washable
(610)	(406 x 635 x 19)	(610 x 635 x 19)	wasiiauie

^{*.} Recommended

BLOWER MOTOR AND WHEEL

WARNING

ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death. Blower access door switch opens 115-v power to control. No component operation can occur unless switch is closed. Caution must be taken when manually closing this switch for service purposes.

NOTE: The blower wheel should not be dropped or bent as balance will be affected. The following steps should be performed by a qualified service agency.

To ensure long life and high efficiency, clean accumulated dirt and grease from blower wheel and motor annually.

The inducer and blower motors are pre-lubricated and require no additional lubrication. These motors can be identified by the absence of oil ports on each end of the motor. The following steps should be performed by a qualified service agency.

Clean blower motor and wheel as follows:

- 1. Turn off electrical supply to furnace.
- 2. Remove outer door.
- 3. For downflow or horizontal furnaces having vent pipes within the furnace that pass in front of the blower access door:

- a. Disconnect vent connector from furnace vent elbow.
- b. Disconnect and remove short piece of vent pipe from within furnace
- Remove two screws from blower access door and remove blower access door.
- All factory wires can be left connected, but field thermostat connections may need to be disconnected depending on their length and routing.

NOTE: The blower wheel should not be dropped or bent as balance will be affected.

- 6. Remove two screws holding blower assembly to blower deck and slide blower assembly out of furnace.
- 7. Clean blower wheel and motor using a vacuum with soft brush attachment. Blower wheel blades may be cleaned with a small paint or flux brush. Do not remove or disturb balance weights (clips) on blower wheel blades.
- 8. Vacuum any loose dust from blower housing, wheel and motor.
- 9. If a greasy residue is present on blower wheel, remove wheel from the blower housing and wash it with an appropriate degreaser.

NOTE: Before disassembly, mark blower motor, and blower housing so motor and each arm is positioned at the same location during reassembly.

To remove wheel:

- a. Disconnect power choke wires (if used) and ground wire attached to blower housing.
- Remove screws securing cutoff plate and remove cutoff plate from housing.
- Loosen set screw holding blower wheel on motor shaft (160+/-20 in.-lb. when reassembling).
- d. Remove bolts holding motor to blower housing and slide motor out of wheel (40+/-10 in.-lb. when reassembling).
- e. Remove blower wheel from housing.
- f. Clean wheel and housing.
- 10. Reassemble motor and blower by reversing steps 9f through 11a, finishing with 9a. Be sure to reattach ground wire to the blower housing.

NOTE: Refer to Table 5 for motor speed lead relocation if leads were not identified before disconnection.

- 11. Verify that blower wheel is centered in blower housing and set screw contacts the flat portion of the motor shaft. Loosen set screw on blower wheel and reposition if necessary.
- 12. Spin the blower wheel by hand to verify that the wheel does not rub on the housing.
- 13. Reinstall blower assembly in furnace.
- 14. Reinstall two screws securing blower assembly to blower deck.

CAUTION

UNIT DAMAGE HAZARD

Failure to follow this caution may result in shortened heat exchanger life.

Heating fan speed(s) MUST be adjusted to provide proper air temperature rise as specified on the rating plate. Recommended operation is at the midpoint of the rise range or slightly above. Refer to "SET TEMPERATURE RISE" under START-UP, ADJUSTMENT, and SAFETY CHECK.

- Refer to furnace wiring diagram, and connect thermostat leads if previously disconnected.
- 16. To check blower for proper rotation:
 - a. Turn on electrical supply.

WARNING

ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury, or death. Blower access door switch opens 115-v power to furnace control. No component operation can occur unless switch is closed. Exercise caution to avoid electrical shock from exposed electrical components when manually closing this switch for service purposes.

b. Manually close blower access door switch.

NOTE: If thermostat terminals are jumpered at the time blower access door switch is closed, blower will run for 90 sec before beginning a heating or cooling cycle.

- Perform component self-test as shown at the bottom of the SERVICE label, located on the front of blower access door.
- d. Verify blower is rotating in the correct direction.
- 17. If furnace is operating properly, RELEASE BLOWER ACCESS DOOR SWITCH. Remove any jumpers or reconnect any disconnected thermostat leads. Replace blower access door.
- 18. Downflow or horizontal furnaces with vent pipe through furnace only:
 - a. Install and connect short piece of vent pipe inside furnace to existing vent.
 - b. Connect vent connector to vent elbow.
- 19. Reinstall outer door.
- 20. Cycle furnace through one complete heating and cooling cycle. Verify the furnace temperature rise as shown in "Adjustments" Section. Adjust temperature rise as shown in "Adjustments" Section. If outdoor temperature is below 70°F, (21°C) turn off circuit breaker to outdoor unit before running furnace in the cooling cycle. Turn outdoor circuit breaker on after completing cooling cycle.

CLEANING HEAT EXCHANGER

The following steps should be performed by a qualified service agency:

NOTE: If the heat exchangers get a heavy accumulation of soot and carbon, they should be replaced rather than trying to clean them thoroughly. A heavy build-up of soot and carbon indicates that a problem exists which needs to be corrected, such as improper adjustment of manifold pressure, insufficient or poor quality combustion air, incorrect size or damaged manifold orifice(s), improper gas, or a restricted heat exchanger. Action must be taken to correct the problem.

If it becomes necessary to clean the heat exchangers because of dust or corrosion, proceed as follows:

- 1. Turn OFF gas and electrical power to furnace.
- 2. Remove outer access door.
- 3. Disconnect vent connector from furnace vent elbow.
- 4. For downflow or horizontal furnace having an internal vent pipe, remove internal vent pipe within the casing.
- 5. Disconnect wires to the following components. Mark wires to aid in reconnection of (be careful when disconnecting wires from switches because damage may occur):
 - a. Draft safeguard switch.
 - b. Inducer motor.
 - c. Pressure switch(es).
 - d. Limit over-temperature switch.
 - e. Gas valve.
 - f. Hot surface igniter.
 - g. Flame-sensing electrode.
 - h. Flame rollout switches.

- Remove screws that fasten the collector box assembly to the cell panel. Be careful not to damage the collector box. Inducer assembly and elbow need not be removed from collector box.
- 7. Disconnect gas line from gas manifold.
- 8. Remove the 5 screws that attach the burner assembly to the cell panel. The gas valve and individual burners need not be removed from support assembly. Remove NOx baffles if installed.

NOTE: Be very careful when removing burner assembly to avoid breaking igniter. See Fig. 48 and Fig. 49 for correct igniter location.




Fig. 48 – Igniter Position-Top View

A05026




Fig. 49 – Igniter Position-Side View

A05025

NOTE: The materials needed in item 9 can usually be purchased at local hardware stores.

- Using a field-provided 25-caliber rifle cleaning brush; a 36-in. (914 mm) long, 1/4" (6 mm) diameter steel spring cable; and a variable speed, reversible electric drill; and a vacuum cleaner, clean cells as follows:
 - a. Remove metal screw fitting from wire brush to allow insertion into cable.
 - b. Insert the twisted wire end of brush into end of spring cable, and crimp tight with crimping tool or crimp by striking with ball-peen hammer. TIGHTNESS IS VERY IMPORTANT.
 - Attach variable-speed, reversible drill to the end of spring cable (end opposite brush).
 - (2.) Insert brush end of cable into the outlet opening of cell and slowly rotate with drill. DO NOT force cable. Gradually insert cable into upper pass of cell (see Fig. 50).




Fig. 50 – Cleaning Heat Exchanger Cell

- (3.) Work cable in and out of cell 3 or 4 times to obtain sufficient cleaning. DO NOT pull cable with great force. Reverse drill and gradually work cable out.
- (4.) Insert brush end of cable in burner inlet opening of cell, and proceed to clean 2 lower passes of cell in same manner as upper pass.
- (5.) Repeat foregoing procedures until each cell in furnace has been cleaned.
- (6.) Using vacuum cleaner, remove residue from each cell.
- (7.) Using vacuum cleaner with soft brush attachment, clean burner assembly.
- (8.) Clean flame sensor with fine steel wool.
- (9.) Install NOx baffles (if removed).
- (10.) Reinstall burner assembly. Center burners in cell openings.
- 10. Remove old sealant from cell panel and collector box flange.
- 11. Spray releasing agent on the heat exchanger cell panel where collector box assembly contacts cell panel.

NOTE: A releasing agent such as cooking spray or equivalent (must not contain corn or canola oil, aromatic or halogenated hydrocarbons or inadequate seal may occur) and RTV sealant (G.E. 162, 6702, or Dow-Corning 738) are needed before starting installation. DO NOT substitute any other type of RTV sealant. G.E. 162 (P771-9003) is available through RCD in 3-oz. tubes.

- 12. Apply new sealant to flange of collector box and attach to cell panel using existing screws, making sure all screws are secure.
- 13. Reconnect wires to the following components. (Use connection diagram on wiring label, if wires were not marked for reconnection locations.):
 - a. Draft safeguard switch.
 - b. Inducer motor.
 - c. Pressure switch(es).
 - d. Limit over-temperature switch.
 - e. Gas valve.
 - f. Hot surface igniter.
 - g. Flame-sensing electrode.
 - h. Flame rollout switches.
 - i. Install NOx baffles (if removed).
- 14. Reinstall internal vent pipe, if applicable.
- 15. Reinstall vent connector on furnace vent elbow. Securely fasten vent connector to vent elbow with 2 field-supplied, corrosion-resistant, sheet metal screws located 180° apart.
- 16. Replace blower access door only, if it was removed.
- Set thermostat above room temperature and check furnace for proper operation.
- Verify blower airflow and speed changes between heating and cooling.

⚠ WARNING

FIRE OR EXPLOSION HAZARD

Failure to follow this warning could result in personal injury, death and/or property damage.

Never purge a gas line into a combustion chamber. Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections.

- 19. Check for gas leaks.
- 20. Replace outer access door.

SEQUENCE OF OPERATION

NOTE: Furnace control must be grounded for proper operation or control will lock out. Control is grounded through green/yellow wire routed to gas valve and manifold bracket screw.

Using the schematic diagram, follow the sequence of operation through the different modes. Read and follow the wiring diagram very carefully.

NOTE: If a power interruption occurs during a call for heat (W), the control will start a 90-sec blower-only ON period two seconds after power is restored, if the thermostat is still calling for gas heating. The amber LED light will flash code 12 during the 90-sec period, after which the LED will be ON continuous, as long as no faults are detected. After the 90-sec period, the furnace will respond to the thermostat normally.

The blower door must be installed for power to be conducted through the blower door interlock switch ILK to the furnace control CPU, transformer TRAN, inducer motor IDM, blower motor BLWM, hot-surface igniter HSI, and gas valve GV.

1. Heating

The wall thermostat "calls for heat," closing the R-to-W circuit. The furnace control performs a self-check, verifies the pressure switch contacts PRS are open, and starts the inducer motor IDM.

- a. **Inducer Prepurge Period** As the inducer motor IDM comes up to speed, the pressure switch contacts PRS close, 24 VAC power is supplied for a field installed humidifier at the HUM terminal and the control begins a 15-sec prepurge period.
- b. **Igniter Warm-Up** At the end of the prepurge period, the Hot-Surface igniter HSI is energized for a 17-second igniter warm-up period.
- c. Trial-for-Ignition Sequence When the igniter warm-up period is completed, the main gas valve relay contacts GVR close to energize the gas valve GV, the gas valve opens, The gas valve GV permits gas flow to the burners where it is ignited by the HSI. Five seconds after the GVR closes, a 2-second flame proving period begins. The HSI igniter will remain energized until the flame is sensed or until the 2-second flame proving period begins.
- d. Flame-Proving When the burner flame is proved at the flame-proving sensor electrode FSE, the furnace control CPU begins the blower-ON delay period and continues to hold the gas valve GV open. If the burner flame is not proved within two seconds, the control CPU will close the gas valve GV, and the control CPU will repeat the ignition sequence for up to three more Trials-For-Ignition before going to Ignition-Lockout.

 Lockout will be reset automatically after three hours or by momentarily interrupting 115 vac power to the furnace, or by interrupting 24 vac power at SEC1 or SEC2 to the furnace control CPU (not at W, G, R, etc.) If flame is proved when flame should not be present, the furnace control CPU will lock out of Gas-Heating mode and operate the inducer motor IDM until flame is no longer proved.
- e. Blower-On Delay If the burner flame is proven, the blower motor is energized on HEAT speed 25 sec after the gas valve GV is energized.
 Simultaneously, the electronic air cleaner terminal EAC-1 is energized and remains energized as long as the blower motor

BLWM is energized.

- f. **Heat-Off Delay** When the thermostat is satisfied, the R-to-W circuit is opened, de-energizing the gas valve GV, stopping gas flow to the burners, and de-energizing the 24-v humidifier terminal 24VAC HUM. The inducer motor IDM will remain energized for a 5-second post-purge period. Then turn off the inducer motor and HUM (115-v) humidifier terminal. The blower motor BLWM and air cleaner terminal EAC 1 will remain energized for 90, 120, 150, or 180 seconds (depending on the HEAT-OFF delay selection). The furnace control CPU is factory-set for a 120-second Heat-Off Delay.
- g. Blower-Off Delay When the thermostat is satisfied, the R-to-W circuit is opened, de-energizing the gas valve GV, stopping gas flow to the burners, and de-energizing the

humidifier terminal HUM. The inducer motor IDM will remain energized for a 5-second post-purge period. The blower motor BLWM and air cleaner terminal EAC-1 will remain energized for 90, 120, 150, or 180 seconds (depending on the blower-OFF delay selection). The furnace control CPU is factory-set for a 120-second blower-OFF delay.

2. Cooling Mode

(See Fig. 24 for thermostat connections.) The thermostat closes the R-to-G-and-Y circuits. The R-to-Y circuit starts the outdoor unit, and the R-to-G and Y circuits start the furnace blower motor BLWM on COOL speed. The electronic air cleaner terminal EAC-1 is energized with 115 vac when the blower motor BLWM is operating. When the thermostat is satisfied, the R-to-G-and-Y circuits are opened. The outdoor unit will stop, and the furnace blower motor BLWM will continue operating on the COOL speed for an additional 90 sec. Cut jumper J2 to reduce the cooling off-delay to 5 sec (see Fig. 28).

3. Continuous Blower Mode

When the R-to-G circuit is closed by the thermostat, the blower motor BLWM will operate on continuous-blower speed FAN. Terminal EAC-1 is energized as long as the blower motor BLWM is energized.

During a call for heat, the blower BLWM will stop during igniter warm-up (17 sec), ignition, and blower-ON delay (25 sec), allowing the furnace heat exchangers to heat up more quickly, then restarts at the end of the blower-ON delay period at HEAT speed.

When the thermostat "calls for cooling", the blower motor BLWM will operate at COOL speed. When the thermostat is satisfied, the blower motor BLWM will operate an additional 90 sec, on COOL speed before reverting back to continuous blower speed.

When the R-to-G circuit is opened, the blower motor BLWM will continue operating for an additional 5 sec, if no other function requires blower motor BLWM operation.

4. Heat Pump

When installed with a heat pump, the furnace control automatically changes the timing sequence to avoid long blower off times during demand defrost cycles. When the R-to-W-and-Y or R-to-W-and-Y-and-G circuits are energized the furnace control CPU will continue to turn on the blower motor BLWM at HEAT speed, and begin a heating cycle. The blower motor BLWM will remain on until the end of the prepurge period, then shut off for 24 sec then come back on at HEAT speed. When the W input signal disappears, the furnace control begins a normal inducer post-purge period and the blower switches to COOL speed after a 3 sec delay. If the R-to-W-and-Y-and-G signals disappear at the same time, the blower motor BLWM will remain on for the selected blower- OFF delay period. If the R-to-W-and-Y signals disappear, leaving the G signal, the blower motor BLWM will continue running the blower motor at HEAT speed after the selected blower-OFF delay period is completed.


Wiring Diagram

Fig. 45 shows a schematic for the furnace wiring diagram.

Troubleshooting

Refer to the service label (see Fig. 44). The Troubleshooting Guide (see Fig. 51) can be a useful tool in isolating furnace operation problems. Beginning with the word "Start," answer each question and follow the appropriate arrow to the next item. The Guide will help to identify the problem or failed component. After replacing any component, verify correct operation sequence.

TROUBLESHOOTING






Fig. 51 – Troubleshooting Guide

PARTS REPLACEMENT INFORMATION GUIDE CASING GROUP

Outer door and Blower door

Top filler plate

Bottom filler plate

Bottom enclosure

ELECTRICAL GROUP

Control bracket

Junction box

Limit switch(es)

Circuit board

Door switch

Transformer

Wiring harness 115v

Wiring harness 24v

BLOWER GROUP

Blower cutoff

Blower motor and Blower housing

Blower wheel

Grommet and Power choke (where used)

GAS CONTROL GROUP

Manifold

Orifice

Flame sensor

Hot surface igniter

Gas valve

Manual reset limit switches

Burner assembly and Burner support assembly

HEAT EXCHANGER GROUP

Heat exchanger cell

Cell panel

Low NOx baffle (California models only)

INDUCER GROUP

Inducer motor and Inducer wheel

Pressure switch

Housing assembly

Vent elbow assembly

Draft safeguard switch

TO OBTAIN INFORMATION ON PARTS: Consult your installing dealer or a licensed Heating and Air Conditioning company of your choice:

BRYANT HEATING & COOLING SYSTEMS

a division of Carrier Corporation

7310 West Morris Street

Indianapolis, IN 46231 U.S.A.

Have available the model number, series number, and serial number located on the unit rating plate to ensure correct replacement part.

EXAMPLE OF MODEL NUMBER

MODEL	COOLING CAPACITY	HEATING CAPACITY	MOTOR	WIDTH	VOLTAGE	FEATURES / MINOR SERIES
800SA	36	045	E	17	Α	-A

TRAINING

My Learning Center is your central location for professional residential HVAC training resources that help strengthen careers and businesses. We believe in providing high quality learning experiences both online and in the classroom.

Access My Learning Center with your HVACpartners credentials at www.mlctraining.com.

Please contact us a mylearning@carrier.com with questions.

A WARNING

FIRE, EXPLOSION, ELECTRICAL SHOCK AND CARBON MONOXIDE POISONING HAZARD

Failure to follow this warning could result in dangerous operation, personal injury, death or property damage.

Improper installation, adjustment, alteration, service, or maintenance can cause personal injury, property damage, or death. Consult a qualified installer, service agency, or your local gas supplier for information or assistance. The qualified installer or service agency must use only factory-authorized replacement parts, kits, or accessories when modifying this product.

© 2021 Carrier. All rights reserved.

A Carrier Company

Replaces: II800SA-05 REV A

Catalog No: II800SA-05 REV B

Edition Date: 08/21