

TOSHIBA

Carrier

AIR CONDITIONER (SPLIT TYPE) Installation Manual



1129250101

Indoor Unit

Model name:

For commercial use
Pour usage commercial
Para uso comercial

4-way Cassette type

RAV-HB121UTP-UL

RAV-HB181UTP-UL


RAV-HB241UTP-UL

RAV-HB301UTP-UL

RAV-HB361UTP-UL

RAV-HB421UTP-UL

RAV-HB481UTP-UL



Installation Manual	1	English
Manuel d'Installation	26	Français
Manual de Instalación	51	Español

Original instruction

Please read this Installation Manual carefully before installing the Air Conditioner.

- This Manual describes the installation method of the indoor unit.
- For installation of the outdoor unit, follow the Installation Manual attached to the outdoor unit.
- For precaution for safety, follow the Installation Manual attached to the outdoor unit.

ADOPTION OF NEW REFRIGERANT

This Air Conditioner uses R454B an environmentally friendly refrigerant.

Contents

1	Precautions for safety	3
2	Accessory parts	7
3	Selection of installation place	8
4	Installation	9
5	Drain piping	11
6	Refrigerant piping	13
7	Electrical connection	14
8	Applicable controls	16
9	Test run	20
10	Maintenance	21
11	Troubleshooting	22

Thank you for purchasing this air conditioner.

Please read carefully through these instructions that contain important information and ensure that you understand them.

After completing the installation work, hand over this Installation Manual as well as the Owner's Manual provided with the outdoor unit to the user, and ask the user to keep them in a safe place for future reference.

Generic Denomination: Air Conditioner

Definition of Qualified Installer or Qualified Service Person

The air conditioner must be installed, maintained, repaired and removed by a qualified installer or qualified service person. When any of these jobs is to be done, ask a qualified installer or qualified service person to do them for you. A qualified installer or qualified service person is an agent who has the qualifications and knowledge described in the table below.

Agent	Qualifications and knowledge which the agent must have
Qualified installer	<ul style="list-style-type: none">• The qualified installer is a person who installs, maintains, relocates and removes the air conditioners. He or she has been trained to install, maintain, relocate and remove the air conditioners, he or she has been instructed in such operations by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to these operations.• The qualified installer who is allowed to do the electrical work involved in installation, relocation and removal has the qualifications pertaining to this electrical work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to electrical work on the air conditioners, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work.• The qualified installer who is allowed to do the refrigerant handling and piping work involved in installation, relocation and removal has the qualifications pertaining to this refrigerant handling and piping work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to refrigerant handling and piping work on the air conditioners, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work.• The qualified installer who is allowed to work at heights has been trained in matters relating to working at heights with the air conditioners, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work.
Qualified service person	<ul style="list-style-type: none">• The qualified service person is a person who installs, repairs, maintains, relocates and removes the air conditioners. He or she has been trained to install, repair, maintain, relocate and remove the air conditioners, he or she has been instructed in such operations by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to these operations.• The qualified service person who is allowed to do the electrical work involved in installation, repair, relocation and removal has the qualifications pertaining to this electrical work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to electrical work on the air conditioners, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work.• The qualified service person who is allowed to do the refrigerant handling and piping work involved in installation, repair, relocation and removal has the qualifications pertaining to this refrigerant handling and piping work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to refrigerant handling and piping work on the air conditioners, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work.• The qualified service person who is allowed to work at heights has been trained in matters relating to working at heights with the air conditioners, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work.

Definition of Protective Gear



When the air conditioner is to be transported, installed, maintained, repaired or removed, wear protective gloves and "Safety" work clothing.

In addition to such normal protective gear, wear the protective gear described below when undertaking the special work detailed in the table below.

Failure to wear the proper protective gear is dangerous because you will be more susceptible to injury, burns, electric shocks and other injuries.





Work undertaken	Protective gear worn
All types of work	Protective gloves "Safety" working clothing
Electrical-related work	Gloves to provide protection for electricians and from heat Insulating shoes Clothing to provide protection from electric shock
Work done at heights (19.7" (50 cm) or more)	Helmets for use in industry
Transportation of heavy objects	Shoes with additional protective toe cap
Repair of outdoor unit	Gloves to provide protection for electricians and from heat

These safety cautions describe important matters concerning safety to prevent injury to users or other people and damages to property. Please read through this manual after understanding the contents below (meanings of indications), and be sure to follow the description.






Indication	Meaning of Indication
 WARNING	Text set off in this manner indicates that failure to adhere to the directions in the warning could result in serious bodily harm (*1) or loss of life if the product is handled improperly.
 CAUTION	Text set off in this manner indicates that failure to adhere to the directions in the caution could result in slight injury (*2) or damage to property (*3) if the product is handled improperly.

- *1: Serious bodily harm indicates loss of eyesight, injury, burns, electric shock, bone fracture, poisoning, and other injuries which leave aftereffect and require hospitalization or long-term treatment as an outpatient.
*2: Slight injury indicates injury, burns, electric shock, and other injuries which do not require hospitalization or long-term treatment as an outpatient.
*3: Damage to property indicates damage extending to buildings, household effects, domestic livestock, and pets.

■ Warning indications on the Air Conditioner Unit

	WARNING (Risk of fire)	This mark is for R32 refrigerant only. Refrigerant type is written on nameplate of outdoor unit. In case that refrigerant type is R32, this unit uses a flammable refrigerant. If refrigerant leaks and comes in contact with fire or heating part, it will create harmful gas and there is risk of fire.
		Read the OWNER'S MANUAL carefully before operation.
		Service personnel are required to carefully read the OWNER'S MANUAL and INSTALLATION MANUAL before operation.
		Further information is available in the OWNER'S MANUAL, INSTALLATION MANUAL, and the like.

■ Warning indications on the air conditioner unit

Warning indication		Description
	WARNING ELECTRICAL SHOCK HAZARD Disconnect all remote electric power supplies before servicing.	WARNING ELECTRICAL SHOCK HAZARD Disconnect all remote electric power supplies before servicing.
	WARNING Moving parts. Do not operate unit with grille removed. Stop the unit before the servicing.	WARNING Moving parts. Do not operate unit with grille removed. Stop the unit before the servicing.
	CAUTION High temperature parts. You might get burned when removing this panel.	CAUTION High temperature parts. You might get burned when removing this panel.
	CAUTION Do not touch the aluminum fins of the unit. Doing so may result in injury.	CAUTION Do not touch the aluminium fins of the unit. Doing so may result in injury.
	CAUTION BURST HAZARD Open the service valves before the operation, otherwise there might be the burst.	CAUTION BURST HAZARD Open the service valves before the operation, to avoid unnecessary pressure built up which could lead to explosion.

1 Precautions for safety

The manufacturer shall not assume any liability for the damage caused by not observing the description of this manual.

⚠ WARNING

General

- Before starting to install the air conditioner, read through the Installation Manual carefully, and follow its instructions to install the air conditioner.
- Only a qualified installer or qualified service person is allowed to do installation work. Inappropriate installation may result in water leakage, electric shock or fire.
- Do not use any refrigerant different from the one specified for complement or replacement. Otherwise, abnormally high pressure may be generated in the refrigeration cycle, which may result in a failure or explosion of the product or an injury to your body.
- Before opening the intake grille of the indoor unit or service panel of the outdoor unit, set the circuit breaker to the OFF position. Failure to set the circuit breaker to the OFF position may result in electric shocks through contact with the interior parts. Only a qualified installer or qualified service person is allowed to remove the intake grille of the indoor unit or service panel of the outdoor unit and do the work required.
- Before carrying out the installation, maintenance, repair or removal work, set the circuit breaker to the OFF position. Otherwise, may result in electric shocks.
- Place a "Work in progress" sign near the circuit breaker while the installation, maintenance, repair or removal work is being carried out. There is a danger of electric shocks if the circuit breaker is set to ON by mistake.
- Only a qualified installer or qualified service person is allowed to undertake work at heights using a stand of 19.7" (50 cm) or more or to remove the intake grille of the indoor unit to undertake work.

- Wear protective gloves and safety work clothing during installation, servicing and removal.
- Do not touch the aluminium fin of the unit. You may injure yourself if you do so. If the fin must be touched for some reason, first put on protective gloves and safety work clothing, and then proceed.
- When work is performed at heights, use a ladder which complies with the ISO 14122 standard, and follow the procedure in the ladder's instructions. Also wear a helmet for use in industry as protective gear to undertake the work.
- Before cleaning the filter set the circuit breaker to OFF without fail, and place a "Work in progress" sign near the circuit breaker before proceeding with the work.
- Before working at heights, put a sign in place so that no-one will approach the work location, before proceeding with the work. Parts and other objects may fall from above, possibly injuring a person below. While carrying out the work, wear a helmet for protection from falling objects.
- The refrigerant used by this air conditioner is the R454B.
- The air conditioner must be transported in stable condition. If any part of the product is broken, contact the dealer.
- When the air conditioner must be transported by hand, carry it by two or more people.
- Do not move or repair any unit by yourself. Must be done by qualified installer or qualified service person. Special precaution should be taken when removing the cover for the unit to avoid electric shock from high voltage lines.
- This appliance is intended to be used by expert or trained users in shops, in light industry, or for commercial use by lay persons.

Selection of installation location

- When the air conditioner is installed in a small room, provide appropriate measures to ensure that the concentration of refrigerant leakage occur in the room does not exceed the critical level.
- Do not install in a location where flammable gas leaks are possible. If the gas leak and accumulate around the unit, it may ignite and cause a fire.
- To transport the air conditioner, wear shoes with additional protective toe caps.
- To transport the air conditioner, do not take hold of the bands around the packing carton. You may injure yourself if the bands should break.
- Install the indoor unit at least 8'2" (2.5 m) above the floor level since otherwise the users may injure themselves or receive electric shocks if they poke their fingers or other objects into the indoor unit while the air conditioner is running.
- Do not place any combustion appliance in a place where it is directly exposed to the wind of air conditioner, otherwise it may cause imperfect combustion.

Installation

- When the indoor unit is to be suspended, the designated hanging bolts (M10 or W3/8") and nuts (M10 or W3/8") must be used.
- Install the air conditioner securely in a location where the base can sustain the weight adequately. If the strength is not enough, the unit may fall down resulting in injury.
- Follow the instructions in the Installation Manual to install the air conditioner. Failure to follow these instructions may cause the product to fall down or topple over or give rise to noise, vibration, water leakage or other trouble.
- If refrigerant gas has leaked during the installation work, ventilate the room immediately. If the leaked refrigerant gas comes in contact with fire, noxious gas may generate.

EN

- Use forklift to carry in the air conditioner units and use winch or hoist at installation of them.

Refrigerant piping

- Install the refrigerant pipe securely during the installation work before operating the air conditioner. If the compressor is operated with the valve open and without refrigerant pipe, the compressor sucks air and the refrigeration cycles is over pressurized, which may cause a injury.
- Tighten the flare nut with a torque wrench in the specified manner. Excessive tighten of the flare nut may cause a crack in the flare nut after a long period, which may result in refrigerant leakage.
- After the installation work, confirm that refrigerant gas does not leak. If refrigerant gas leaks into the room and flows near a fire source, such as a cooking range, noxious gas may be generated.
- When the air conditioner has been installed or relocated, follow the instructions in the Installation Manual and purge the air completely so that no gases other than the refrigerant will be mixed in the refrigerating cycle. Failure to purge the air completely may cause the air conditioner to malfunction.
- Nitrogen gas must be used for the airtight test.
- The charge hose must be connected tightly and in a proper manner.

Electrical wiring

- Only a qualified installer or qualified service person is allowed to carry out the electrical work of the air conditioner. Under no circumstances must this work be done by an unqualified individual since failure to carry out the work properly may result in electric shocks and/or electrical leaks.

- To connect the electrical wires, repair the electrical parts or undertake other electrical jobs, wear gloves to provide protection for electricians and from heat, insulating shoes and clothing to provide protection from electric shocks. Failure to wear this protective gear may result in electric shocks.
- Use wiring that meets the specifications in the Installation Manual and the stipulations in the local regulations and laws. Use of wiring which does not meet the specifications may give rise to electric shocks, electrical leakage, smoking and/or a fire.
- Connect earth wire. (Grounding work)
Incomplete grounding causes an electric shock.
- Do not connect grounding wires to gas pipes, water pipes, and lightning conductor or telephone grounding wires.
- After completing the repair or relocation work, check that the grounding wires are connected properly.
- Install a circuit breaker that meets the specifications in the Installation Manual and the stipulations in the local regulations and laws.
- Install the circuit breaker where it can be easily accessed by the agent.
- Under no circumstances the power wire must not be extended. Connection trouble in the places where the wire is extended may give rise to smoking and/or a fire.
- Electrical wiring work shall be conducted according to law and regulation in the community and Installation Manual. Failure to do so may result in electrocution or short circuit.

Test run

- Before operating the air conditioner after having completed the work, check that the electrical control box cover of the indoor unit and service panel of the outdoor unit are closed, and set the circuit breaker to the ON position. You may receive an electric shock if the power is turned on without first conducting these checks.
- If there is any kind of trouble (such as an error display has appeared, smell of burning, abnormal sounds, the air conditioner fails to cool or heat or water is leaking) has occurred in the air conditioner, do not touch the air conditioner but set the circuit breaker to the OFF position, and contact a qualified service person. Take steps to ensure that the power will not be turned on (by marking "out of service" near the circuit breaker, for instance) until qualified service person arrives. Continuing to use the air conditioner in the trouble status may cause mechanical problems to escalate or result in electric shocks or other trouble.
- After the work has finished, use an insulation tester set (500V Megger) to check the resistance is 1MΩ or more between the charge section and the non-charge metal section (Earth / Ground section). If the resistance value is low, a disaster such as a leak or electric shock is caused at user's side.
- Upon completion of the installation work, check for refrigerant leaks and check the insulation resistance and water drainage. Then conduct a test run to check that the air conditioner is operating properly.

Explanations given to user

- Upon completion of the installation work, tell the user where the circuit breaker is located. If the user does not know where the circuit breaker is, he or she will not be able to turn it off in the event that trouble has occurred in the air conditioner.
- If the fan grille is damaged, do not approach the outdoor unit but set the circuit breaker to the OFF position, and contact a qualified service person to have the repairs done. Do not set the circuit breaker to the ON position until the repairs are completed.
- After the installation work, follow the Owner's Manual to explain to the customer how to use and maintain the unit.

Relocation

- Only a qualified installer or qualified service person is allowed to relocate the air conditioner. It is dangerous for the air conditioner to be relocated by an unqualified individual since a fire, electric shocks, injury, water leakage, noise and/or vibration may result.
- When carrying out the pump-down work shut down the compressor before disconnecting the refrigerant pipe. Disconnecting the refrigerant pipe with the service valve left open and the compressor still operating will cause air or other gas to be sucked in, raising the pressure inside the refrigeration cycle to an abnormally high level, and possibly resulting in rupture, injury or other trouble.

EN

⚠ CAUTION

New refrigerant air conditioner installation

- This air conditioner adopts refrigerant R454B which does not destroy ozone layer.
- The characteristics of R454B refrigerant are; easy to absorb water, oxidizing membrane or oil. Accompanied with the new refrigerant, refrigerating oil has also been changed. Therefore, do not let water, dust, former refrigerant, or refrigerating oil enter the refrigerating cycle during installation work.
- To prevent charging an incorrect refrigerant and refrigerating oil, the sizes of connecting sections of charging port of the main unit and installation tools are changed from those for the conventional refrigerant.
- Accordingly the exclusive tools are required for the new refrigerant (R454B).
- For connecting pipes, use new and clean piping designed for R454B, and please care so that water or dust does not enter.










To disconnect the appliance from main power supply.

- This appliance must be connected to the main power supply by means of a switch with a contact separation of at least 0.1" (3 mm).

The installation fuse (all types can be used) must be used for the power supply line of this conditioner.

2 Accessory parts

■ Accessory parts

Part name	Q'ty	Shape	Usage
Installation Manual	1	This manual	(For hand over to customers)
Owner's Manual	1		(For hand over to customers)
Insulation pipe	2		For insulation of pipe connecting section
Installation pattern	1	—	For confirmation of ceiling opening and indoor unit position
Installation template	--		For positioning of ceiling position
Washer	4		For hanging-down unit
Eccentric washer	4		For hanging-down unit
Hose band	1		For connecting drain pipe
Flexible hose	1		For adjusting center of drain pipe
Insulation	1		For insulation of drain connecting section
Electrical cover 2 holes	1		For connecting 2 power supply

■ Separate sold parts

- The Ceiling panel and remote controller are sold separately. For the installation of these products, follow the Installation Manuals supplied with them.
- The wireless type remote controller is designed to be installed by attaching a wireless remote controller kit (sold separately) to the standard panel. (The wireless remote controller kit consists of a wireless remote controller and adjust corner caps with a receiver section.)

3 Selection of installation place

⚠ WARNING

- **Install the air conditioner at enough strong place to withstand the weight of the unit.**
If the strength is not enough, the unit may fall down resulting in injury.
- **Install the air conditioner at a height 8'2" (2.5 m) or more from the floor.**
If you insert your hands or others directly into the unit while the air conditioner operates, it is dangerous because you may contact with revolving fan or active electricity.

⚠ CAUTION

- **Do not install the air conditioner in a location subject to a risk of exposure to a combustible gas.**
If a combustible gas leaks and stays around the unit, a fire may occur.

Upon approval of the customer, install the air conditioner in a place that satisfies the following conditions

- Place where the unit can be installed horizontally.
- Place where a sufficient servicing space can be ensured for safety maintenance and check.
- Place where drained water will not cause any problem.


Avoid installing in the following places

- Place exposed to air with high salt content (seaside area), or place exposed to large quantities of sulfide gas (hot spring).
(Should the unit be used in these places, special protective measures are needed.)
- A restaurant kitchen where a lot of oil is used or place near machines in a factory (Oil adhering to the heat exchanger and resin part (turbo fan) in the indoor unit may reduce the performance, generate mist or dew drop, or deform or damage resin parts.)
- Places where iron or other metal dust is present. If iron or other metal dust adheres to or collects on the interior of the air conditioner, it may spontaneously combust and start a fire.
- Place where organic solvent is used nearby.
- Place close to a machine generating high frequency.
- Place where the discharged air blows directly into the window of the neighbor house. (Outdoor unit)
- Place where noise of the outdoor unit is easily transmitted.
(When install the outdoor unit on the boundary with the neighbor, pay due attention to the level of noise.)
- Place with poor ventilation. (Before air ducting work, check whether value of air volume, static pressure and duct resistance are correct.)
- Do not use the air conditioner for special purposes such as preserving food, precision instruments, or art objects, or where breeding animals or growing plants are kept. (This may degrade the quality of preserved materials.)
- Place where any of high-frequency appliances (including inverter devices, private power generators, medical equipment, and communication equipment) and inverter-type fluorescent light is installed.
(A malfunction of the air conditioner, abnormal control, or problems due to noise to such appliances / equipment may occur.)
- When the wireless remote controller is used in a room equipped with an inverter-type fluorescent light or at a place exposed to direct sunlight, signals from the remote controller may not be received correctly.
- Place where organic solvent is used.
- Place near a door or window exposed to humid outside air (Dew dropping may form).
- Place where special spray is used frequently.

■ Installation space

Secure the specified space in the figure for installation and servicing.

Model	A in (mm)
HB121, HB181, HB241 Type	10.7" (271) or more
HB301, HB361, HB421, HB481 Type	13.1" (334) or more



■ Selection of installation place

In case of continued operation of the indoor unit under high-humidity conditions as described below, dew may condense and water may drop.
Especially, high-humidity atmosphere (dew point temperature: 73.4°F (23°C) or more) may generate dew inside the ceiling.

1. Unit is installed inside the ceiling with slated roof.
2. Unit is installed at a location using inside of the ceiling as fresh air take-in path.
3. Kitchen

◆ Advice

- Set a service check opening panel at right side of the unit (size: 17.7" × 17.7" (450 × 450 mm) or more) for piping, maintenance, and servicing.
- If installing a unit at such place, put insulating material (glass wool, etc.) additionally on all the positions of the indoor unit which come to contact with high-humidity atmosphere.

REQUIREMENT

When the humidity inside the ceiling seems to be higher than 80%, attach a heat insulator to the side (top)surface of the indoor unit. (Use a heat insulator that is 0.4"(10 mm) or more thick.)

■ Ceiling height

Model	Possible installed ceiling height
HB121, HB181, HB241 Type	UP to 12'6" (3.8 m)
HB301, HB361, HB421, HB481 Type	UP to 15'1" (4.6 m)

When the height of the ceiling exceeds the distance of the item Standard / 4-way in Table as below, the hot air is difficult to reach the floor.
Therefore, it is necessary to change the setup value of the high ceiling switch or discharge direction.
The high-ceiling setting is also necessary when installing separately sold filters.

REQUIREMENT

- When using the air conditioner with 2-way / 3-way discharge system, a strong wind blows directly if the ceiling height is lower than the standard.
Therefore, change the setting switch according to height of the ceiling.
- When using the high ceiling (1) or (3) with 4-way discharge system, the draft is apt to be felt due to drop of the discharge temperature.

▼ Height list of ceiling possible to be installed


(ft.m)

Model RAV-	HB121 to HB241			HB301 to HB481			Setup of high ceiling
Discharge direction	4-way	3-way	2-way	4-way	3-way	2-way	SET DATA
Standard (At shipment)	9'10"(3.0)	10'10"(3.3)	11'10"(3.6)	12'10"(3.9)	13'9"(4.2)	14'9"(4.5)	0000
High ceiling (1)	10'10"(3.3)	11'6"(3.5)	12'6"(3.8)	13'9"(4.2)	14'5"(4.4)	15'1"(4.6)	0001
High ceiling (3)	11'10"(3.6)	12'6"(3.8)	—	14'9"(4.5)	15'1"(4.6)	—	0003


The lighting time of the filter sign (notification of filter cleaning) on the remote controller can be changed according to installation conditions.
When it is difficult to obtain satisfactory heating due to location place of the indoor unit or the structure of the room, the detection temperature of heating can be raised.

■ Discharge direction

As shown in the figure below, air discharge directions can be selected according to the shape of the room and the location of the indoor unit installation.



- Use a shielding plate kit (sold separately) to change discharge directions.
Discharge directions are limited. Follow the Installation Manual supplied with the shielding plate kit.



4 Installation


REQUIREMENT

Strictly comply with the following rules to prevent damage of the indoor units and human injury.

- Do not put a heavy article on the indoor unit. (Even units are packaged)
- Carry in the indoor unit as it is packaged if possible. If carrying in the indoor unit unpacked by necessity, be sure to use buffering cloth, etc. to not damage the unit.
- To move the indoor unit, hold the hooking metals (4 positions) only.
Do not apply force to the other parts (refrigerant pipe, drain pan, foamed parts, or resin parts, etc.).
- Carry the package by two or more persons, and do not bundle it with plastic band at positions other than specified.

■ External view

(Unit: in (mm))



Model	A	B	C	D
HB121, HB181	10.1" (256)	4.7" (120)	Ø1/4" (6.4)	Ø1/2" (12.7)
HB241	10.1" (256)	4.7" (120)	Ø3/8" (9.5)	Ø5/8" (15.9)
HB301, HB361, HB421, HB481	12.6" (319)	7.2" (183)	Ø3/8" (9.5)	Ø5/8" (15.9)

■ Opening a ceiling and installation of hanging bolts

- Consider the piping / wiring after the unit is hung when determining the location of the indoor unit installation and orientation.
- After the location of the indoor unit installation has been determined, open the ceiling and install hanging bolts.
- The dimensions of the ceiling opening and hanging bolt pitches are given in the outline drawing and the attached installation pattern.
- When a ceiling already exists, lay the drain pipe, refrigerant pipe, indoor unit / outdoor unit connection wires, and remote controller wires to their connection locations before hanging the indoor unit.

Procure hanging bolts and nuts for installing the indoor unit (these are not supplied).

Hanging bolt	M10 or W3/8"	4 pieces
Nut	M10 or W3/8"	12 pieces

◆ How to use the installation pattern (accessory)

The installation pattern is provided inside the packaging cap.


<For existing ceiling>

Use the installation pattern positioning a ceiling opening and hanging bolts.

<For new ceiling>

Use the installation pattern to position the ceiling opening when hanging a ceiling.

- After the hanging bolts have been installed, install the indoor unit.
- Hook the four holes in the installation pattern to the panel fixing screws of the indoor unit.
- When hanging a ceiling, open the ceiling along the outside dimensions of the installation pattern.



◆ Treatment of ceiling

The ceiling differs according to structure of building. For details, consult your constructor or interior finish contractor.

In the process after the ceiling board has been removed, it is important to reinforce ceiling foundation (frame) and to keep horizontal level of installed ceiling correctly in order to prevent vibration of ceiling board.


- Cut and remove the ceiling foundation.
- Reinforce the cut surface of ceiling foundation, and add ceiling foundation for fixing the end of ceiling board.

◆ Installation of hanging bolt





Use M10 hanging bolts (4 pcs, locally procured). Matching to the existing structure, set pitch according to size in the unit external view as shown below.

New concrete slab	
Install the bolts with insert brackets or anchor bolts.	
	(Blade type bracket)
	(Slide type bracket)
	(Pipe hanging anchor bolt)
Steel frame structure	
Use existing angles or install new support angles.	
	Hanging bolt
	Support angle
Existing concrete slab	
Use a hole-in anchors, hole-in plugs, or a hole-in bolts.	

◆ Installation of ceiling opening and hanging bolt




- Attach a nut (M10 or W3/8": not supplied) and the Ø1.3" (34 mm) washer (supplied) to each hanging bolt.
 - Insert a washer on both sides of the T groove of the hanging bracket of the indoor unit, and hang the indoor unit.
 - Check that the four sides of the indoor unit are level using a level vial (levelness: 0.2" (5 mm) or less).
 - Detach the installation template (accessory) from the installation pattern.
 - Using the installation gauge, check and adjust the positional relation between the indoor unit and the ceiling opening (1) (0.4" to 1.4" (10 to 35 mm) : 4 sides) and the hanging-up height (2) (0.5" (12 mm) : 4 corners).
- (How to use the installation gauge is printed on the gauge.)



REQUIREMENT

Before installation of the indoor unit, be sure to remove the tape for transportation between the fan and the bell mouth. Running the unit without removing the tape may damage the fan motor.



Be sure to remove the tape for transportation between the fan and the bell mouth.

■ Installation of ceiling panel (Sold separately)

Install the ceiling panel according to Installation Manual attached with it after piping / wiring work has completed.
Check that installation of indoor unit and ceiling opening part is correct, and then install it.

REQUIREMENT

- Joint the connecting sections of ceiling panel, ceiling surface, ceiling panel and indoor unit closely. Any gap between them will cause air leakage and the generate condensation or water leakage.
- Remove the adjust corner caps at the four corners of the ceiling panel, and then install the ceiling panel onto the indoor unit.
- Make sure that the claws of the four adjust corner caps are securely fit.
* Improper fitting of the claws may cause water leakage.

■ Installation of remote controller (Sold separately)


For installation of the wired remote controller, follow the Installation Manual attached with the remote controller.

- Pull out the remote controller cord together with the refrigerant pipe or drain pipe.
Be sure to pass the remote controller cord through upper side of the refrigerant pipe and drain pipe.
- Do not leave the remote controller at a place exposed to the direct sunlight and near a stove.

■ Wireless type

The sensor of indoor unit with wireless remote controller can receive a signal by distance within approx. 26'2" (8 m). Based upon it, determine a place where the remote controller is operated and the installation place.

- Operate the remote controller, confirm that the indoor unit receives a signal surely, and then install it.
- Keep 3'3" (1 m) or more from the devices such as television, stereo, etc.
(Disturbance of image or noise may generate.)
- To prevent a malfunction, select a place where is not influenced by a fluorescent light or direct sunlight.
- Two or more (Up to 6 units) indoor units with wireless type remote controller can be installed in the same room.




■ Installation of Electrical cover 2 holes


REQUIREMENT

- In case of group control, electrical cover 1 hole type need to change to electrical cover 2 holes type.


1. Remove screw A for the fixation of the electrical control box cover and loosened screw B. Slide the cover inside so that the hook part can be removed (The electrical control box cover remain being hooked on the hinge.)
2. Remove the wiring cover mounting screws (1 locations), and a wiring cover is removed.




3. Remove screw for the fixation of the wire box.



4. Remove screw 4 locations for the fixation cover pipe and a cover pipe removed.



5. Remove electrical cover 1 hole and insert electrical cover 2 holes from accessory on the pipe cover and then screw it with original screw.



5 Drain piping

⚠ CAUTION

Following the Installation Manual, perform the drain piping work so that water is properly drained, and apply a insulation so as not to cause a dew dropping.
Inappropriate piping work may result in water leakage in the room and wet of furniture.

■ Pipe material, size and insulation


Require the following materials for piping and insulation at site.

Pipe material	Hard vinyl chloride pipe VP25 (Outer diameter 1.3" (32 mm))
Insulation	Foam polyethylene : Thickness 0.4" (10 mm) or more

■ Flexible hose


Use the attached flexible hose to adjust center discrepancy of the hard vinyl chloride pipe or to adjust the angle.

- Do not use the flexible hose as stretched, or do not deform it more extent than that in the following figure.
- Be sure to fix the soft end of the flexible hose with the attached hose band.
- Use the flexible hose on a horizontal level.




REQUIREMENT


- Be sure to perform insulation of the drain pipes of the indoor unit.
- Never forget to perform insulation of the connecting part with the indoor unit.
An incomplete insulation causes dew dropping.
- Set the drain pipe with downward slope (1/100 or more), and do not make swelling or trap on the piping.
It may cause an abnormal sound.




- For length of the traversing drain pipe, restrict to 65'7" (20 m) or less.
In case of a long pipe, provide support brackets with interval of 4'11" to 6'7" (1.5 to 2 m) in order to prevent waving.



- Set the collective piping as shown in the below figure.




- Be sure not to apply force to the connecting part of the drain pipe.
- The hard vinyl-chloride pipe cannot be directly connected to the drain pipe connecting port of the indoor unit.
For connection with the drain pipe connecting port, be sure to use / fix the attached flexible hose with the hose band, otherwise a damage or water leak is caused on the drain pipe connecting port.



Adhesive inhibited :

Use the attached flexible hose and hose band for connecting the drain hose to the clear drain socket.
If applying the adhesive, socket will be damaged and cause water leakage.



Connecting drain pipe

- Connect a hard socket (locally procured) to the hard socket of the attached supplied flexible hose.
- Connect a drain pipe (locally procured) to the connected hard socket.


REQUIREMENT

- Connect hard vinyl chloride pipes securely using an adhesive for vinyl chloride to avoid water leakage.
- It takes some time until the adhesive is dried and hardened (refer to the manual of the adhesive). Do not apply stress to the joint with the drain pipe during this time period.

Drain up

When a down-gradient cannot be secured for the drain pipe, drain-up piping is possible.

- The height of the drain pipe must be 33.5" (850 mm) or less from the bottom of the ceiling.
- Take the drain pipe out of the drain pipe joint with the indoor unit in 11.8" (300 mm) or less, and bend up the pipe vertically.
- Immediately after the pipe is bent up vertically, lay the pipe making a down-gradient.
- Set downward grading immediately after raising up vertically.



Check the draining

In the test run, check that water drain is properly performed and water does not leak from the connecting part of the pipes.


Be sure to check draining also when installed in heating period.

Using a pitcher or hose, pour water (1.5L to 2L (1/3 to 0.5 gallon)) into the discharge port before installation of the ceiling panel.

Pour water gradually so that water does not spread on the motor of the drain pump.


CAUTION

Pour water gently so that it does not spread around inside the indoor unit, which may cause a malfunction.




- After the electric work has finished, pour water during Cool mode operation.
- If the electric work has not yet finished, pull out the float switch connector (CN34 : Red) from the electrical control box, and check draining by plugging the single phase 208/230V power to the terminal blocks (L1) and (L2).
If doing so, the drain pump motor operates.
(Never apply 208/230V to (A, B) otherwise a trouble of P.C. Board occurs.)

- Test water drain while checking the operation sound of the drain pump motor.
(If the operation sound changes from continuous sound to intermittent sound, water is normally drained.)
After the check, the drain pump motor runs, connecting the float switch connector.
(In case of check by pulling out the float switch connector, be sure to return the connector to the original position.)



Insulation

- As shown in the figure, cover the flexible hose and hose band with the attached insulation up to the bottom of the indoor unit without gap.
- Cover the drain pipe seamlessly with a insulation locally procured so that it overlaps with the attached insulation of the drain connecting section.



- * Direct the slits and seams of the insulation upward to avoid water leakage.

6 Refrigerant piping

⚠ CAUTION

When the refrigerant pipe is long, provide support brackets at intervals of 8'2" to 9'10" (2.5 m to 3 m) to clamp the refrigerant pipe. Otherwise, abnormal sound may be generated.
Use the flare nut attached with the indoor unit or R454B flare nut.

■ Permissible piping length and height difference

They vary depending on the outdoor unit. For details, refer to the Installation Manual attached to the outdoor unit.

■ Pipe size

Model		HB121, HB181	HB241 to HB481
Pipe size (Dia. : in(mm))	Gas side	1/2"(12.7)	5/8"(15.9)
	Liquid side	1/4"(6.4)	3/8"(9.5)


■ Connecting refrigerant piping

Flaring

- Cut the pipe with a pipe cutter.
Remove burrs completely.
(Remaining burrs may cause gas leakage.)
- Insert a flare nut into the pipe, and flare the pipe.
Use the flare nut provided with the unit or the one used for the R454B refrigerant. The flaring dimensions for R454B are different from the ones used for the conventional R22 refrigerant. A new flare tool manufactured for use with the R454B refrigerant is recommended, but the conventional tool can still be used if the projection margin of the copper pipe is adjusted to be as shown in the following table.

Projection margin in flaring: B (Unit: in (mm))

Outer dia. of copper pipe	R454B tool used	Conventional tool used
1/4"(6.4), 3/8"(9.5)	0 to 0.04"(1.1)	0.04"(1.0) to 0.06"(1.5)
1/2"(12.7), 5/8"(15.9)		




Flaring diameter size: A (Unit: in (mm))

Outer dia. of copper pipe	A ⁺⁰ / _{-0.02(0.4)}
1/4"(6.4)	0.4"(9.1)
3/8"(9.5)	0.5"(13.2)
1/2"(12.7)	0.7"(16.6)
5/8"(15.9)	0.8"(19.7)



- * In case of flaring for R454B with the conventional flare tool, pull it out approx. 0.02" (0.5 mm) more than that for R22 to adjust to the specified flare size. The copper pipe gauge is useful for adjusting projection margin size.
- The sealed gas was sealed at the atmospheric pressure so when the flare nut is removed, there will no "whooshing" sound: This is normal and is not indicative of trouble.
- Use two wrenches to connect the indoor unit pipe.



Work using double spanner

- Use the tightening torque levels as listed in the following table.

Outer dia. of connecting pipe (in (mm))	Tightening torque (ft·lbs (N·m))
1/4" (6.4)	10.1 to 13.0 (14 to 18)
3/8" (9.5)	24.6 to 30.4 (34 to 42)
1/2" (12.7)	35.4 to 44.1 (49 to 61)
5/8" (15.9)	45.5 to 55.7 (63 to 77)

- Tightening torque of flare pipe connections.
Pressure of R454B is higher than that of R22. (Approx. 1.6 times) Therefore, using a torque wrench, tighten the flare pipe connecting sections which connect the indoor and outdoor units of the specified tightening torque.
Incorrect connections may cause not only a gas leak, but also a trouble of the refrigeration cycle.

⚠ CAUTION

Tightening with an excessive torque may crack the nut depending on installation conditions.

◆ Piping with outdoor unit

Shape of valve differs according to the outdoor unit. For details of installation, refer to the Installation Manual of the outdoor unit.

■ Airtight test / Air purge, etc.

For airtight test, air purge, addition of refrigerant, and gas leak check, refer to the Installation Manual attached to the outdoor unit.

REQUIREMENT

Do not supply power to the indoor unit until the airtight test and vacuuming are completed. (If the indoor unit is powered on, the pulse motor valve is fully closed, which extends the time for vacuuming.)

◆ Open the valve fully

Open the valve of the outdoor unit fully.
For details, refer to the Installation Manual attached to the outdoor unit.

◆ Insulation process


Apply insulation for the pipes separately at liquid side and gas side.

For the insulation to the pipes at gas side, be sure to use the material with heat-resisting temperature 248°F (120°C) or higher.

Using the attached insulation material, apply the insulation to the pipe connecting section of the indoor unit securely without gap.

REQUIREMENT

- Apply the insulation to the pipe connecting section of the indoor unit securely up to the root without exposure of the pipe. (The pipe exposed to the outside causes water leak.)
- Wrap insulation with its slits facing up (ceiling side).



7 Electrical connection

⚠ WARNING

- Use the specified wires for wiring connect the terminals. Securely fix them to prevent external forces applied to the terminals from affecting the terminals.
Incomplete connection or fixation may cause a fire or other trouble.
- Connect earth wire. (grounding work)
Incomplete grounding cause an electric shock.
Do not connect earth wires to gas pipes, water pipes, lightning conductor or telephone earth wires.
- Appliance shall be installed in accordance with national wiring regulations.
Capacity shortage of power circuit or incomplete installation may cause an electric shock or a fire.

⚠ CAUTION

- For power supply specifications, follow the Installation Manual of outdoor unit.
- Do not connect 208/230V~60Hz power to the terminal blocks (A, B) for control wiring.
Otherwise, the system will fail.
- Do not damage or scratch the conductive core and inner insulator of power and system interconnection wires during peeling them.
- Perform the electric wiring so that it does not come to contact with the high-temperature part of the pipe.
The coating may melt resulting in an accident.
- Do not turn on the power of the indoor unit until vacuuming of the refrigerant pipes completes.

■ System interconnection wires specifications

System interconnection wires*	AWG 16 or more (H07RN-F or 60245 IEC 66)	Up to 229'7"(70 m)
-------------------------------	---	-----------------------


*Number of wire × wire size

Remote controller wiring

Remote controller wiring, remote controller inter-unit wiring	Wire size: AWG 20 to AWG 16	
Total wire length of remote controller wiring and remote controller inter-unit wiring = $L + L_1 + L_2 + \dots + L_n$	In case of wired type only	Up to 1640'5"(500 m)
	In case of wireless type included	Up to 1312'4"(400 m)
Total wire length of remote controller inter-unit wiring = $L_1 + L_2 + \dots + L_n$		Up to 656'2"(200 m)

⚠ CAUTION

When connecting to the central control device dedicated to TCC-Link, it is necessary to change to TCC-Link using a wired remote controller. Set according to the Communication type procedure of "8 Applicable controls".



Max. number of connect-able indoor units, and communication type

	Unit type			
	RAV-HM ***	RAV-HM ***	*	*
Indoor unit				
Remote controller	U series	*	U series	*
Remote sensor				
Communication type	TU2C-Link	TCC-Link		
Max. number of connect-able units	16	8		


*: Other than RAV-HM *** and U series

■ Wiring between indoor unit and outdoor unit


1. Figure below shows the wiring connections between the indoor and outdoor units and between the indoor units and remote controller. The wires indicated by the broken lines or dot-and-dash lines are provided at the locally.
2. Refer to the both indoor and outdoor unit wiring diagrams.
3. The power of the indoor unit is supplied from the outdoor unit.

Wiring diagram


Single system



Simultaneous twin system



Simultaneous triple and double twin system



* Use 2-core shield wire (MVVS AWG 20 to AWG 16) for the remote controller wiring in the simultaneous twin simultaneous triple and simultaneous double twin systems to prevent noise problems. Connect both ends of the shield wire to earth leads.

* Connect earth wires for each indoor unit in the simultaneous twin, simultaneous triple and simultaneous double twin systems.



EN

■ Wire connection

REQUIREMENT

- Connect the wires matching the terminal numbers. Incorrect connection causes a trouble.
- Pass the wires through the bushing of wire connection holes of the indoor unit.
- Keep a margin (Approx. 3.9"(100 mm)) on a wire to hang down the electrical control box at servicing or other purpose.
- The low-voltage circuit is provided for the remote controller. (Do not connect the high-voltage circuit)


1. Remove the cover of the electrical control box by taking off the mounting screws (2 positions) and pushing the hooking section. (The cover of the electrical control box remains hanged to the hinge.)
2. Connect the system interconnection wires and remote controller wire to the terminal block of the electrical control box.
3. Tighten the screws of the terminal block, and fix the wires with cord clamp attached to the electrical control box.
(Do not apply tension to the connecting section of the terminal block.)
4. Using the attached heat insulation material, seal the pipe connecting port. Otherwise, dewing may be caused.
5. Mount the cover of the electrical control box without pinching wires.
(Mount the cover after wiring on the ceiling panel.)



■ Remote controller wiring

Strip off approx. 0.4"(9 mm) the wire to be connected.

Wiring diagram




■ Wiring on the ceiling panel

As per the Installation Manual of the ceiling panel, connect the connector (20P: White) of the ceiling panel to the connector (CN510: White) onto the P.C. Board within the electrical control box.


⚠ WARNING

For the synchronous twin and synchronous triple systems, perform the following to conform to EMC standards.

▼ Synchronous twin system



▼ Synchronous triple system



* Use 2-core shield wire (MVVS AWG 20 to AWG 16 or more) for the remote controller wiring in the synchronous twin and synchronous triple systems to prevent noise problems. Be sure to connect both ends of the shield wire to the earth.

* Connect earth wire for each indoor unit in the synchronous twin and synchronous triple systems.

8 Applicable controls

REQUIREMENT

When the air conditioner is used for the first time, it will take some moments after the power has been turned on before the remote control becomes available for operations: This is normal and is not indicative of trouble.

• Concerning the automatic addresses (The automatic addresses are set up by performing operations on the outdoor interface circuit board.)

While the automatic addresses are being set up, no remote control operations can be performed. Setup takes up to 10 minutes (usually about 5 minutes).

• When the power is turned on after automatic address setup

It takes up to 10 minutes (usually about 3 minutes) for the outdoor unit to start operating after the power has been turned on.

Before the air conditioner was shipped from the factory, all units are set to [STANDARD] (factory default). If necessary, change the indoor unit settings.

The settings are changed by operating the wired remote control.


* The settings cannot be changed using only a wireless remote control, simple remote control or group control remote control by itself so install a wired remote control separately as well.

■ Easy I.D.N setting


Sets various functions related to air conditioners.

REQUIREMENT

Be sure to stop operation of the air conditioners.



- 1 Push [Menu] to open the "Menu"
- 2 Push and hold [Menu] and [Set/Fix] at the same time to open "Field setting menu"
→ Push and hold 4 seconds.



- 3 In the "Field setting menu" screen, push [Left] and [Right] to select "Easy I.D.N setting", and then push [Set/Fix]
→ The fans and louvers of the indoor units operate.

When doing group connections:

→ The fans and louvers of the selected indoor units operate.

- 4 Push [Left] and [Right] to select an item
→ Push [Left] and [Right] to switch to the setting you want, or set a numerical value.

- 5 After setting each item, push [Set/Fix]
→ The changes are fixed, and the "Field setting menu" screen returns.
→ "X" appears while data is changing.

When doing group connections:

→ After finishing "Easy I.D.N setting" for each unit, push [Set/Fix] to fix the changes and return to the unit selection screen. In the unit selection screen, push [Return] to briefly display "X", and then return to the "Field setting menu" screen.

■ Installing indoor unit on high ceiling

When an indoor unit is installed on a ceiling higher than the standard height, make the high-ceiling setting for air volume adjustment.


Follow the "Easy I.DN setting" procedure (1 → 2 → 3 → 4 → 5).

- Select "1. High ceiling adjustment" from the "Easy I.DN setting" menu.
- Select the Set data for high ceiling adjustment from the "Height list of ceiling possible to be installed" table on page 4 in this manual.

Remote control-less setting

Change the high-ceiling setting with the DIP switch on the P.C. Board.

* Once the Set data has been changed, though it can be freely set to 1 or 3, to reset it to 0 (factory default), it need changing using remote control (sold separately). After set data change, an air conditioner is operated. After setting has been completed, restart the air conditioner.



Set data	Ceiling height	SW501-1	SW501-2
0	Standard (Factory default)	OFF	OFF
1	High ceiling (1)	ON	OFF
3	High ceiling (3)	OFF	ON

To restore the factory defaults

To return the DIP switch settings to the factory defaults, set SW501-1 and SW501-2 to OFF, connect a separately sold wired remote control, and then set the Set data to "0".

■ Filter sign setting

According to the installation condition, the lighting time of the filter sign (Notification of filter cleaning) can be changed.

Follow to the "Easy I.DN setting" procedure (1 → 2 → 3 → 4 → 5).

- Select "2. Filter sign timer" from the "Easy I.DN setting" menu.
- Select the Set data for "Filter sign timer" from following table.

Set data	Filter sign lighting time
0	None
1	150 H
2	2500 H (Factory default)
3	5000 H
4	10000 H

■ To secure better effect of heating

When it is difficult to obtain satisfactory heating due to installation place of the indoor unit or structure of the room, the detection temperature of heating can be raised. Also use a circulator or other device to circulate heat air near the ceiling.

Follow to the "Easy I.DN setting" procedure (1 → 2 → 3 → 4 → 5).

- Select "3. Heating temp. shift" from the "Easy I.DN setting" menu.
- Select the Set data for "Heating temp. shift" from following table.

Set data	Detection temp shift value
+0K	No shift
+1K	1.8°F (+1°C)
+2K	3.6°F (+2°C) (Factory default)
+3K	5.4°F (+3°C)
+4K	7.2°F (+4°C)
+5K	9.0°F (+5°C)
+6K	10.8°F (+6°C)

■ 46 °F (8 °C) operation

Pre-heating operation can be set for cold regions where room temperature drops to below zero.

Follow to the "Easy I.DN setting"

(1 → 2 → 3 → 4 → 5).

- For the "Dode (DN)" in Procedure 3, specify [00D1].
- For the "Data" in Procedure.

SET DATA	46 °F (8 °C) Operation setting
0000	None (Factory default)
0001	46 °F (8 °C) Operation setting

■ TA sensor selection

The temperature sensor of the indoor unit senses room temperature usually. Set the remote control sensor to sense the temperature around the remote control.

Select items following the "Easy I.DN setting" procedure

(1 → 2 → 3 → 4 → 5).

- Select "4. TA sensor selection" from the "Easy I.DN setting" menu.
- Select the Set data for "TA sensor selection" from following table.

Set data	TA sensor selection
Body	Sensor of the indoor unit (Factory default)
RC	Sensor of the remote control

- When "RC" is selected, lights up. However, it is not displayed when it is set as a sub-remote control.
- When flashes, the remote control sensor is defective. Select the Set data "Body" or replace the remote control.

■ Group control

In a group control, a remote control can control up to maximum 8 or 16 units. (Depending on the outdoor unit.)


- The wired remote control only can control a group control. The wireless remote control is unavailable for this control.
- For wiring procedure and wires of the individual line (Identical refrigerant line) system, refer to "7. Electrical connection" in this Manual.
- Wiring between indoor units in a group is performed in the following procedure.
- Connect the indoor units by connecting the remote control wires from the remote control terminal blocks (A, B) of the indoor unit connected with a remote control to the remote control terminal blocks (A, B) of the other indoor unit. (Non-polarity)
- For address setup, refer to the Installation Manual attached to the outdoor unit.

■ Wind direction

* Set the wind direction.

⚠ CAUTION

Refer to the instructions (for the wind direction adjustment) in the Owner's Manual supplied with the indoor unit before setting.



* Display while swinging


1 Press [<] and [>] to switch to the "Wind direction" screen (horizontal louvers)

2 Press [▲] and [▼] to select wind direction



Operation mode	Settable angles
Heat, Fan, Auto (Heat)	(1), (2), (3), (4), (5), Swing
Cool, Dry, Auto (Cool)	(1), (2), (3), Swing

■ Turning on/off the louver swing



* Display when swinging (up / down) is cancelled "Fan", "Heat"



* Display when swinging (up / down) is cancelled "Cool", "Dry"


1 During swing operation, press [<] and [>] to switch to the "Wind direction" screen

2 Press [▲] or [▼]
→ The louvers stop at the position when [▲] or [▼] is pressed.

→ When [▼] is pressed in the display when swing was cancelled, the louvers go to wind direction position (1), when [▲] is pressed, the louvers go to position (3) during "Cool" or "Dry" operation, and go to position (5) during "Fan" or "Heat" operation, and vertical louvers go to position (7).


■ Individual louver

* For 4-way cassette types, the wind direction and swing operation of each louver can be set individually.




1 Select "Individual louver", and press [Set/Fix]

2 Press [<] and [>] to select louvers



3 Press [▲] and [▼] to select wind direction

4 Press [Return]
→ Return to "Menu".





NOTE

- For models that "Individual louver" is not available, the message "No function" is displayed.
- Press [▲] and [▼] while swinging to stop the louver and cancel swinging, press [▲] or [▼] again to select an wind direction.
- "No function" is displayed when "Louver lock" is set. That louver cannot do "Individual louver".

■ Swing type

* Select the louver swing type from the standard swing, dual swing or cyclic swing. Carry out the setting operation while the indoor unit is stopped. (Turn off the air conditioning unit before starting the setting operation.)



1 Select "Louver setting", and press [Set/Fix]

2 Press [▲] and [▼] to select "Swing type", and then press [Set/Fix]

3 In the "Swing type" screen, press [▲] and [▼] to select a mode

4 Press [Set/Fix]
→ Return to the "Louver setting" screen.

5 Press [Return]
→ "No function" is displayed.
→ When doing group connections, the screen for selecting units is displayed, so press [Return] to display "No function".





EN

NOTE

- For models that "Louver setting" is not available, the message "No function" is displayed.
- Press [] to not fix the changes, so conditions are as before changes, and return to the "Louver setting" screen.

■ Louver lock


* The direction of the louver can be locked individually. Carry out the setting operation while the indoor unit is stopped. (Turn off the air conditioning unit before starting the setting operation.)



- Select "Louver setting", and press []
- Press [] and [] to select "Louver lock", and then press []
- Press [] and [] to select louvers
- Press [] and [] to select a louver angle (wind direction)
 → Press [] to raise a louver and press [] to lower a louver.
- Press []
 → Return to the "Louver setting" screen.
- Press []
 → "⌂" is displayed.
 → When doing group connections, the screen for selecting units is displayed, so press [] to display "⌂".

NOTE

- For models that "Louver setting" is not available, the message "No function" is displayed.
- Press [] to not fix the changes, so conditions are as before changes, and return to the "Louver setting" screen.
- To cancel "Louver lock", press [] and [] to set louver not locked for the louver angle of each louver.
- When the operation mode is "Cool" or "Dry", performing "Louver lock" at position (4) or (5) may cause condensation.
- "⌂" is displayed when "Louver lock" is set.



- Push [] to open the "Menu".
- Push and hold [] and [] at the same time to open "Field setting menu".
 → Push and hold 4 seconds.
- In the "Field setting menu" screen, push [] and [] to select "DN setting", and then push [].
- Push [] and [] to select "Indoor unit", and the push [].
 → "Indoor unit" was selected, the fans and louvres of the indoor units operate.

<Line (system) address>

- Push [] to black highlight the code (DN), and then push [] and [] to set the code number to 12.
- Push [] to black highlight the data, and then push [] and [] to set a system address.
 (Match the address with the address on the interface P.C. Board of the header outdoor unit in the same refrigerant line.)
- After finishing setting the data of the code (DN), push [].
 → "Continue?" is displayed.

<Indoor unit address>

- To set the data of Indoor unit address, push [].
- Push [] to black highlight the code (DN), and then push [] and [] to set the code number to 13.

- Push [] to black highlight the data, and then push [] and [] to set a Indoor unit address.

- After finishing setting the data of the code (DN), push [].
 → "Continue?" is displayed.

<Group address>

- To set the data of Indoor unit address, push [].
- Push [] to black highlight the code (DN), and then push [] and [] to set the code number to 14.
- Push [] to black highlight the data, and then push [] and [] to set a group address.
 If the indoor unit is individual, set the address to 0000 ; header unit, 0001 ; follower unit, 0002.

Individual : 0000
 Header unit : 0001
 Follower unit : 0002 } In case of group control

- After finishing setting the data of the code (DN), push [].
 → "Continue?" is displayed.

- To not do other settings, push [].
 → If the "Indoor unit" or "Outdoor unit" selection screen is displayed before "⌂" is displayed, push [].
 → "⌂" appears while data is changing.
 → The changes are fixed, and the "Field setting menu" screen returns.

9 Test run

■ Before test run

- Before turning on the circuit breaker, carry out the following procedure.
 - By using 500 V-megger, check that resistance of 1 MΩ or more exists between the terminal block L1 to L2 and the ground (grounding). If resistance of less than 1 MΩ is detected, do not run the unit.
 - Check the valve of the outdoor unit being opened fully.
- To protect the compressor at activation time, leave power-ON for 12 hours or more before operating.
- Before starting a test run, be sure to set addresses following the Installation Manual supplied with the outdoor unit.

■ Execute a test run

Operate the unit with the remote control as usual. For the procedure of the operation, refer to the attached Owner's Manual to the outdoor unit.


A forced test run can be executed in the following procedure even if the operation stops by thermostat -OFF.

In order to prevent a serial operation, the forced test run is released after 60 minutes have passed and returns to the usual operation.

⚠ CAUTION


- Do not use the forced test run for cases other than the test run because it applies an excessive load to the devices.

Wired remote control




- Push [Menu] to open the "Menu"
- Push and hold [Menu] and [Set/Fix] at the same time to open "Field setting menu"

→ Push and hold 4 seconds.



- In the "Field setting menu" screen, push [Up] and [Set/Fix] to select "Test mode", and then push [Set/Fix]

→ Test mode is set, and returns to the "Field setting menu" screen. Push the [Return] button 2 times, to open screen (2).



- Push [ON/OFF ON/OFF]

→ Operation starts, and in test mode screen (1) opens. (While stopped, it is screen (2))
 → Test mode is done while the operating mode is set to "Cool" or "Heat".
 → The temperature cannot be set in test mode.
 → Check codes are displayed in the normal way.

- After completing test mode, in the "Field setting menu" screen, push [Up] and [Set/Fix] to select "Test mode", and then push [Set/Fix]
 → Screen (3) appears.
 → Push [Set/Fix] to end test mode and do normal operation.

NOTE

Test mode ends 60 minutes after test mode was started, and the main screen returns.

■ Wireless remote controller (RBC-AX32U series)


Test run (forced cooling operation)

REQUIREMENT

Finish the forced cooling operation in a short time because it applies excessive strength to the air conditioner.

▼ How to perform forced cooling operation

- When TEMPORARY button is pushed for 10 seconds or more, "Pi!" sound is heard and the operation changes to a forced cooling operation. After approx. 3 minutes, a cooling operation starts forcibly. Check cool air starts blowing. If the operation does not start, check wiring again.
- To stop a test operation, push TEMPORARY button once again (approx. 1 second).
 • Check wiring / piping of the indoor and outdoor units in forced cooling operation.




10 Maintenance

CAUTION

Before maintenance, be sure to turn off the leakage breaker.


Cleaning of air filter

- If  is displayed on the remote controller, maintain the air filter.
- Clogging of the air filter reduce cooling / heating performance.

Cleaning of panel and air filter

Preparation:

1. Turn off the air conditioner by the remote controller.
2. Open the air intake grille.
 - Slide the button of the air intake grille inward, and open the air intake grille slowly while holding it.




Cleaning of air filters

If the air filters are not cleaned, it not only reduce the cooling a performance of air conditioner but causes a failure in the air conditioner such as water falling in drops.

Preparation:

1. Stop the operation by remote controller.
2. Dismount the air filter.




Use a vacuum cleaner to remove dust from the filters or wash them with water.

- After rinsing the air filters with water, dry them in the shade.
- Set the air filter into the air conditioner.

Clean the panel and air filter with water:

- Wipe down the panel and air filter with a sponge or towel moistened with a kitchen detergent. (Do not use any metallic brush for cleaning.)
- Carefully rinse the panel and air filter to wash out the detergent.
- After rinsing the panel and air filter with water, dry it in the shade.

1. Close the air intake grille.
 - Close the air intake grille, slide the knob outward, and fix the air intake grille securely





2. Turn on the circuit breaker, then push the ON/OFF button on the remote controller to start the operation.
3. After cleaning, perform Filter Sign Reset.

CAUTION


Do not start the air conditioner while leaving air filter removed.

Filter sign reset



- If the air conditioners are operated while "Filter check." is displayed, then "Filter check." is displayed. Push an operation button while it is displayed or leave it for at least 5 seconds and the display will disappear.


When the filter check mark is displayed (filter check reset)



- 1 In "Menu", select "Filter sign reset", and push [ Set/Fix]
- 2 Push [ Set/Fix]

11 Troubleshooting


■ Confirm and check



When a trouble occurs in the air conditioner, the check code and the indoor unit number flash on the display of the remote control.

* The check code is only displayed during the operation.

When the check code and indoor unit number are displayed, pushing [Return] opens the "Check" screen.



In the "Check" screen, push [Set/Fix] to show the contacts.

Push [Menu] to display "Model information".

■ Contact information for repairs

You can look for contact information for repairs.

Information (1/2)	
1. Model information	
2. Service information	
Return Set	

- 1 In the "Information" screen, push [] and [] to select "Service information", and then push [Set/Fix]

■ Error codes and parts to be checked

Wired remote controller display	Wireless remote controller Sensor block display of receiving unit	Main defective parts		Judging device	Parts to be checked / error description	Air conditioner status
Indication	Operation Timer Ready GR GR OR	Flashing				
E01			No header remote controller	Remote controller	Incorrect remote controller setting --- The header remote controller has not been set (including two remote controllers).	*
			Remote controller communication error		No signal can be received from the indoor unit.	
E02			Remote controller transmission error	Remote controller	System interconnection wires, indoor P.C. Board, remote controller --- No signal can be sent to the indoor unit.	*
E03			Indoor unit-remote controller regular communication error	Indoor	Remote controller, network adapter, indoor P.C. Board --- No data is received from the remote controller or network adapter.	Auto-reset
E04			Indoor unit-outdoor unit serial communication error	Indoor	System interconnection wires, indoor P.C. Board, outdoor P.C. Board --- Serial communication error between indoor unit and outdoor unit	Auto-reset
			IPDU-CDB communication error			
E08			Duplicated indoor addresses *	Indoor	Indoor address setting error --- The same address as the self-address was detected.	Auto-reset
E09			Duplicated header remote controllers	Remote controller	Remote controller address setting error --- Two remote controllers are set as header in the double remote controller control. (* The header indoor unit stops raising alarm and follower indoor units continue to operate.)	*
E10			CPU-CPU communication error	Indoor	Indoor P.C. Board --- Communication error between main MCU and motor microcomputer MCU	
E18			Header unit follower unit regular communication error	Indoor	Indoor P.C. Board --- Regular communication is not possible between header and follower indoor units or between twin header (main) and follower (sub) units.	Auto-reset
E31			IPDU communication error	Outdoor	Communication error between IPDU and CDB	Entire stop
F01		ALT	Indoor unit heat exchanger sensor (TCJ) error	Indoor	Heat exchanger sensor (TCJ), indoor P.C. Board --- Open-circuit or short-circuit of the heat exchanger sensor (TCJ) was detected.	Auto-reset
F02		ALT	Indoor unit heat exchanger sensor (TC) error	Indoor	Heat exchanger sensor (TC), indoor P.C. Board --- Open-circuit or short-circuit of the heat exchanger sensor (TC) was detected.	Auto-reset
F04		ALT	Outdoor unit discharge temp. sensor (TD) error	Outdoor	Outdoor temp. sensor (TD), outdoor P.C. Board --- Open-circuit or short-circuit of the discharge temp. sensor was detected.	Entire stop
F06		ALT	Outdoor unit temp. sensor (TE/TS) error	Outdoor	Outdoor temp. sensors (TE/TS), outdoor P.C. Board --- Open-circuit or short-circuit of the heat exchanger temp. sensor was detected.	Entire stop
F07		ALT	TL sensor error	Outdoor	TL sensor may be displaced, disconnected or short-circuited.	Entire stop
F08		ALT	Outdoor unit outside air temp. sensor error	Outdoor	Outdoor temp. sensor (TO), outdoor P.C. Board --- Open-circuit or short-circuit of the outdoor air temp. sensor was detected.	Operation continued
F10		ALT	Indoor unit room temp. sensor (TA) error	Indoor	Room temp. sensor (TA), indoor P.C. Board --- Open-circuit or short-circuit of the room temp. sensor (TA) was detected.	Auto-reset

EN

Wired remote controller display	Wireless remote controller Sensor block display of receiving unit		Main defective parts	Judging device	Parts to be checked / error description	Air conditioner status
	Operation Timer Ready GR GR OR	Flashing				
F12	● ● ○	ALT	TS sensor error	Outdoor	TS sensor may be displaced, disconnected or short-circuited.	Entire stop
F13	● ● ○	ALT	Heat sink sensor error	Outdoor	Abnormal temperature was detected by the temp. sensor of the IGBT heat sink.	Entire stop
F15	● ● ○	ALT	Temp. sensor connection error	Outdoor	Temp. sensor (TE/TS) may be connected incorrectly.	Entire stop
F29	● ● ●	SIM	Indoor unit, other P.C. Board error	Indoor	Indoor P.C. Board --- EEPROM error	Auto-reset
F31	● ● ○	SIM	Outdoor unit P.C. Board	Outdoor	Outdoor P.C. Board --- In the case of EEPROM error.	Entire stop
H01	● ● ●		Outdoor unit compressor breakdown	Outdoor	Current detect circuit, power voltage --- Minimum frequency was reached in the current releasing control or short-circuit current (Idc) after direct excitation was detected	Entire stop
H02	● ● ●		Outdoor unit compressor lock	Outdoor	Compressor circuit --- Compressor lock was detected.	Entire stop
H03	● ● ●		Outdoor unit current detect circuit error	Outdoor	Current detect circuit, outdoor unit P.C. Board --- Abnormal current was detected in AC-CT or a phase loss was detected.	Entire stop
H04	● ● ●		Case thermostat operation (1)	Outdoor	Malfunction of the case thermostat	Entire stop
H06	● ● ●		Outdoor unit low-pressure system error	Outdoor	Current, high-pressure switch circuit, outdoor P.C. Board --- Pressure sensor error was detected or low-pressure protective operation was activated.	Entire stop
L03	● ● ●	SIM	Duplicated header indoor units ★	Indoor	Indoor address setting error --- There are two or more header units in the group.	Entire stop
L07	● ● ●	SIM	Group line in individual indoor unit ★	Indoor	Indoor address setting error --- There is at least one group-connected indoor unit among individual indoor units.	Entire stop
L08	● ● ●	SIM	Indoor group address not set ★	Indoor	Indoor address setting error --- Indoor address group has not been set.	Entire stop
L09	● ● ●	SIM	Indoor unit capacity not set	Indoor	Indoor unit capacity has not been set.	Entire stop
L10	● ● ●	SIM	Outdoor unit P.C. Board	Outdoor	In the case of outdoor P.C. Board jumper wire (for service) setting error	Entire stop
L20	● ● ●	SIM	LAN communication error	Network adapter central control	Address setting, central control remote controller, network adapter --- Duplication of address in central control communication	Auto-reset
L29	● ● ●	SIM	Other outdoor unit error	Outdoor	Other outdoor unit error	Entire stop
					1) Communication error between IPDU MCU and CDB MCU 2) Abnormal temperature was detected by the heat sink temp. sensor in IGBT.	Entire stop
L30	● ● ●	SIM	Abnormal external input into indoor unit (interlock)	Indoor	External devices, outdoor unit P.C. Board --- Abnormal stop due to incorrect external input into CN80	Entire stop
L31	● ● ●	SIM	Phase sequence error, etc.	Outdoor	Power supply phase sequence, outdoor unit P.C. Board --- Abnormal phase sequence of the 3-phase power supply	Operation continued (thermostat at OFF)

Wired remote controller display	Wireless remote controller Sensor block display of receiving unit		Main defective parts	Judging device	Parts to be checked / error description	Air conditioner status
	Operation Timer Ready GR GR OR	Flashing				
P01	● ● ●	ALT	Indoor unit fan error	Indoor	Indoor fan motor, indoor P.C. Board --- Indoor AC fan error (fan motor thermal relay activated) was detected.	Entire stop
P03	● ● ●	ALT	Outdoor unit discharge temp. error	Outdoor	An error was detected in the discharge temp. releasing control.	Entire stop
P04	● ● ●	ALT	Outdoor unit high-pressure system error	Outdoor	High-pressure switch --- The IOL was activated or an error was detected in the high-pressure releasing control using the TE.	Entire stop
P05	● ● ●	ALT	Open phase detected	Outdoor	The power wire may be connected incorrectly. Check open phase and voltages of the power supply.	Entire stop
P07	● ● ●	ALT	Heat sink overheat	Outdoor	Abnormal temperature was detected by the temp. sensor of the IGBT heat sink.	Entire stop
P10	● ● ●	ALT	Indoor unit water overflow detected	Indoor	Drain pipe, clogging of drainage, float switch circuit, indoor P.C. Board --- Drainage is order or the float switch was activated.	Entire stop
P12	● ● ●	ALT	The fan error of the indoor unit	Indoor	Abnormal operation of the indoor fan motor, indoor P.C. Board, or indoor DC fan (over current or lock, etc.) is detected.	Entire stop
P15	● ● ●	ALT	Gas leakage detected	Outdoor	There may be gas leakage from the pipe or connecting part. Check for gas leakage.	Entire stop
P19	● ● ●	ALT	4-way valve error	Outdoor (Indoor)	4-way valve, indoor temp. sensors (TC/TCJ) --- An error was detected due to temperature drop of the indoor unit heat exchanger sensor when heating.	Auto-reset
P20	● ● ●	ALT	High-pressure protective operation	Outdoor	High-pressure protection	Entire stop
P22	● ● ●	ALT	Outdoor unit fan error	Outdoor	Outdoor unit fan motor, outdoor unit P.C. Board --- An error (overcurrent, locking, etc.) was detected in the outdoor unit fan drive circuit.	Entire stop
P26	● ● ●	ALT	Outdoor unit inverter Idc activated	Outdoor	IGBT, outdoor unit P.C. Board, inverter wiring, compressor --- Short-circuit protection for compressor drive circuit devices (G-Tr/IGBT) was activated.	Entire stop
P29	● ● ●	ALT	Outdoor unit position error	Outdoor	Outdoor unit P.C. Board, high-pressure switch --- Compressor motor position error was detected.	Entire stop
P31	● ● ●	ALT	Other indoor unit error	Indoor	Another indoor unit in the group is raising an alarm. E03/L07/L03/L08 alarm check locations and error description	Auto-reset

○ : Lighting ● : Flashing ● : OFF ★ : The air conditioner automatically enters the auto-address setting mode.
 ALT : When two LEDs are flashing, they flash alternately. SIM : When two LEDs are flashing, they flash in synchronization.
 Receiving unit display OR : Orange GR : Green

Warnings on Refrigerant Leakage

Check of Concentration Limit

The room in which the air conditioner is to be installed requires a design that in the event of refrigerant gas leaking out, its concentration will not exceed a set limit.

The refrigerant R454B which is used in the air conditioner is safe, without the toxicity or combustibility of ammonia, and is not restricted by laws to be imposed which protect the ozone layer. However, since it contains more than air, it poses the risk of suffocation if its concentration should rise excessively. Suffocation from leakage of R454B is almost non-existent. With the recent increase in the number of high concentration buildings, however, the installation of multi air conditioner systems is on the increase because of the need for effective use of floor space, individual control, energy conservation by curtailing heat and carrying power etc.

Most importantly, the multi air conditioner system is able to replenish a large amount of refrigerant compared with conventional individual air conditioners. If a single unit of the multi conditioner system is to be installed in a small room, select a suitable model and installation procedure so that if the refrigerant accidentally leaks out, its concentration does not reach the limit (and in the event of an emergency, measures can be made before injury can occur).


In a room where the concentration may exceed the limit, create an opening with adjacent rooms, or install mechanical ventilation combined with a gas leak detection device. The concentration is as given below.

$$\frac{\text{Total amount of refrigerant (lbs (kg))}}{\text{Min. volume of the indoor unit installed room (ft}^3 \text{ (m}^3\text{))}} \leq \text{Concentration limit (lbs/ft}^3 \text{ (kg/m}^3\text{))}$$

The concentration limit of R454B which is used in multi air conditioners is 0.019 lbs/ft³ (0.3 kg/m³).

▼ NOTE 1

If there are 2 or more refrigerating systems in a single refrigerating device, the amounts of refrigerant should be as charged in each independent device.



For the amount of charge in this example:


The possible amount of leaked refrigerant gas in rooms A, B and C is 22 lbs (10 kg).

The possible amount of leaked refrigerant gas in rooms D, E and F is 33 lbs (15 kg).

▼ NOTE 2


The standards for minimum room volume are as follows.

- 1) No partition (shaded portion)




Important

- 2) When there is an effective opening with the adjacent room for ventilation of leaking refrigerant gas (opening without a door, or an opening 0.15% or larger than the respective floor spaces at the top or bottom of the door).




- 3) If an indoor unit is installed in each partitioned room and the refrigerant piping is interconnected, the smallest room of course becomes the object. But when a mechanical ventilation is installed interlocked with a gas leakage detector in the smallest room where the density limit is exceeded, the volume of the next smallest room becomes the object.



▼ NOTE 3

The minimum indoor floor area compared with the amount of refrigerant is roughly as follows: (When the ceiling is 8'9" ft (2.7 m) high)



Confirmation of indoor unit setup

Prior to delivery to the customer, check the address and setup of the indoor unit, which has been installed in this time and fill the check sheet (Table below). Data of four units can be entered in this check sheet. Copy this sheet according to the No. of the indoor units. If the installed system is a group control system, use this sheet by entering each line system into each Installation Manual attached to the other indoor units.

REQUIREMENT

This check sheet is required for maintenance after installation. Fill this sheet and then pass this Installation Manual to the customers.

Indoor unit setup check sheet

Indoor unit		Indoor unit		Indoor unit	
Room name	Room name	Room name	Room name	Room name	Room name
Model	Model	Model	Model	Model	Model
Check indoor unit address. (For check method, refer to APPLICABLE CONTROLS in this manual.)					
*In case of a single system, it is unnecessary to enter the indoor address. (CODE NO.: Line [12], Indoor [13], Group [14], Central control [03])					
Line	Indoor	Group	Line	Indoor	Group
Central control address		Central control address		Central control address	
Various setup		Various setup		Various setup	
Have you changed high ceiling setup? If not, fill check mark [x] in [NO CHANGE], and fill check mark [x] in [ITEM] if changed, respectively. (For check method, refer to APPLICABLE CONTROLS in this manual.) * In case of replacement of jumper blocks on indoor microcomputer P.C. Board, setup is automatically changed.					
High ceiling setup (CODE NO. [5d])		High ceiling setup (CODE NO. [5d])		High ceiling setup (CODE NO. [5d])	
<input type="checkbox"/> NO CHANGE <input type="checkbox"/> STANDARD <input type="checkbox"/> HIGH CEILING 1 <input type="checkbox"/> HIGH CEILING 3		<input type="checkbox"/> NO CHANGE <input type="checkbox"/> STANDARD <input type="checkbox"/> HIGH CEILING 1 <input type="checkbox"/> HIGH CEILING 3		<input type="checkbox"/> NO CHANGE <input type="checkbox"/> STANDARD <input type="checkbox"/> HIGH CEILING 1 <input type="checkbox"/> HIGH CEILING 3	
Have you changed lighting time of filter sign? If not, fill check mark [x] in [NO CHANGE], and fill check mark [x] in [ITEM] if changed, respectively. (For check method, refer to APPLICABLE CONTROLS in this manual.)					
Filter sign lighting time (CODE NO. [0t1])		Filter sign lighting time (CODE NO. [0t1])		Filter sign lighting time (CODE NO. [0t1])	
<input type="checkbox"/> NO CHANGE <input type="checkbox"/> NONE <input type="checkbox"/> 150H <input type="checkbox"/> 2500H <input type="checkbox"/> 5000H <input type="checkbox"/> 10000H		<input type="checkbox"/> NO CHANGE <input type="checkbox"/> NONE <input type="checkbox"/> 150H <input type="checkbox"/> 2500H <input type="checkbox"/> 5000H <input type="checkbox"/> 10000H		<input type="checkbox"/> NO CHANGE <input type="checkbox"/> NONE <input type="checkbox"/> 150H <input type="checkbox"/> 2500H <input type="checkbox"/> 5000H <input type="checkbox"/> 10000H	
Have you changed detected temp. shift value? If not, fill check mark [x] in [NO CHANGE], and fill check mark [x] in [ITEM] if changed, respectively. (For check method, refer to APPLICABLE CONTROLS in this manual.)					
Detected temp. shift value setup (CODE NO. [0b])		Detected temp. shift value setup (CODE NO. [0b])		Detected temp. shift value setup (CODE NO. [0b])	
<input type="checkbox"/> NO CHANGE <input type="checkbox"/> NO SHIFT <input type="checkbox"/> +1.8°F (+1°C) <input type="checkbox"/> +3.6°F (+2°C) <input type="checkbox"/> +5.4°F (+3°C) <input type="checkbox"/> +7.2°F (+4°C) <input type="checkbox"/> +9.0°F (+5°C) <input type="checkbox"/> +10.8°F (+6°C)		<input type="checkbox"/> NO CHANGE <input type="checkbox"/> NO SHIFT <input type="checkbox"/> +1.8°F (+1°C) <input type="checkbox"/> +3.6°F (+2°C) <input type="checkbox"/> +5.4°F (+3°C) <input type="checkbox"/> +7.2°F (+4°C) <input type="checkbox"/> +9.0°F (+5°C) <input type="checkbox"/> +10.8°F (+6°C)		<input type="checkbox"/> NO CHANGE <input type="checkbox"/> NO SHIFT <input type="checkbox"/> +1.8°F (+1°C) <input type="checkbox"/> +3.6°F (+2°C) <input type="checkbox"/> +5.4°F (+3°C) <input type="checkbox"/> +7.2°F (+4°C) <input type="checkbox"/> +9.0°F (+5°C) <input type="checkbox"/> +10.8°F (+6°C)	
Incorporation of parts sold separately		Incorporation of parts sold separately		Incorporation of parts sold separately	
Have you incorporated the following parts sold separately? If incorporated, fill check mark [x] in each [ITEM]. (When incorporating, the setup change is necessary in some cases. For setup change method, refer to Installation Manual attached to each part sold separately.)					
<input type="checkbox"/> Others () <input type="checkbox"/> Others ()		<input type="checkbox"/> Others () <input type="checkbox"/> Others ()		<input type="checkbox"/> Others () <input type="checkbox"/> Others ()	

CARRIER AIR CONDITIONING (THAILAND) CO., LTD.

144/9 MOO 5, BANGKADI INDUSTRIAL PARK, TIVANON ROAD, TAMBOL BANGKADI, AMPHUR MUANGPATHUMTHANI, PATHUMTHANI 12000, THAILAND



1129250101