TOSHIBA Carrier


AIR CONDITIONER (SPLIT TYPE) Installation Manual


Indoor Unit

Model name:

High-Wall Type

RAV-HB301KRTP-UL RAV-HB361KRTP-UL For commercial use Pour usage commercial Para uso comercial







1130850104_EN-FR-ES.indb c1 4/21/2567 BE 17:30

Please read this Installation Manual carefully before installing the Air Conditioner.

- This Manual describes the installation method of the indoor unit.
- For installation of the outdoor unit, follow the Installation Manual attached to the outdoor unit.

ADOPTION OF NEW REFRIGERANT

This Air Conditioner uses R454B an environmentally friendly refrigerant.

Contents

1	PRECAUTIONS FOR SAFETY	. 5
2	ACCESSORY PARTS	11
3	SELECTION OF INSTALLATION PLACE	12
4	INSTALLATION OF INDOOR UNIT	14
5	CUTTING A HOLE AND MOUNTING INSTALLATION PLATE	16
6	PIPING AND DRAIN HOSE INSTALLATION	17
7	INDOOR UNIT FIXING	20
8	DRAINAGE	20
-	REFRIGERANT PIPING	
	ELECTRICAL CONNECTION	
	APPLICABLE CONTROLS	
12	TEST RUN	40
13	MAINTENANCE	42
14	TROUBLESHOOTING	44

1-EN **– 1 –**

Thank you for purchasing this air conditioner.

Please read carefully through these instructions that contain important information and ensure that you understand them.

After reading these instructions, be sure to keep them in a safe place together with the Owner's Manual and Installation Manual supplied with your product.

Generic Denomination: Air Conditioner

Definition of Qualified Installer or Qualified Service Person

The air conditioner must be installed, maintained, repaired and removed by a qualified installer or qualified service person. When any of these jobs is to be done, ask a qualified installer or qualified service person to do them for you.

A qualified installer or qualified service person is an agent who has the qualifications and knowledge described in the table below.

Agent	Qualifications and knowledge which the agent must have			
Qualified installer	 The qualified installer is a person who installs, maintains, relocates and removes the air conditioners. He or she has been trained to install, maintain, relocate and remove the air conditioners, he or she has been instructed in such operations by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to these operations. The qualified installer who is allowed to do the electrical work involved in installation, relocation and removal has the qualifications pertaining to this electrical work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to electrical work on the air conditioners, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. The qualified installer who is allowed to do the refrigerant handling and piping work involved in installation, relocation and removal has the qualifications pertaining to this refrigerant handling and piping work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to refrigerant handling and piping work on the air conditioners, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. The qualified installer who is allowed to work at heights has been instructed in matters relating to working at heights with the air conditioners, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. 			
Qualified service person	 The qualified service person is a person who installs, repairs, maintains, relocates and removes the air conditioners. He or she has been trained to install, repair, maintain, relocate and remove the air conditioners, he or she has been instructed in such operations by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to these operations. The qualified service person who is allowed to do the electrical work involved in installation, repair, relocation and removal has the qualifications pertaining to this electrical work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to electrical work on the air conditioners, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. The qualified service person who is allowed to do the refrigerant handling and piping work involved in installation, repair, relocation and removal has the qualifications pertaining to this refrigerant handling and piping work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to refrigerant handling and piping work on the air conditioners, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. The qualified service person who is allowed to work at heights has been trained in matters relating to working at heights with the air conditioners, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. 			

ΕN

-2- 2-EN

4/21/2567 BE 17:30

Definition of Protective Gear

When the air conditioner is to be transported, installed, maintained, repaired or removed, wear protective gloves and 'Safety' work clothing.

In addition to such normal protective gear, wear the protective gear described below when undertaking the special work detailed in the table below.

Failure to wear the proper protective gear could lead to injury, burns, electric shocks and other injuries.

Work undertaken	Protective gear worn
All types of work	Protective gloves 'Safety' working clothing
Electrical-related work	Gloves to provide protection for electricians and from heat Insulating shoes Clothing to provide protection from electric shock
Work done at heights (19.7" (50 cm))	Helmets for use in industry
Transportation of heavy objects	Shoes with additional protective toe cap

These safety cautions describe important matters concerning safety to prevent injury to users or other people and damages to property. Please read through this manual after understanding the contents below (meanings of indications), and be sure to follow the description.

Indication	Meaning of Indication
WARNING Text set off in this manner indicates that failure to adhere to the directions in the warning result in serious bodily harm (*1) or loss of life if the product is handled improperly.	
⚠ CAUTION	Text set off in this manner indicates that failure to adhere to the directions in the caution could result in slight injury (*2) or damage to property (*3) if the product is handled improperly.

- *1: Serious bodily harm indicates loss of eyesight, injury, burns, electric shock, bone fracture, poisoning, and other injuries which leave aftereffect and require hospitalization or long-term treatment as an outpatient.
- *2: Slight injury indicates injury, burns, electric shock, and other injuries which do not require hospitalization or long-term treatment as an outpatient.
- *3: Damage to property indicates damage extending to buildings, household effects, domestic livestock, and pets.

Warning indications on the Air Conditioner Unit

	WARNING (Risk of fire)	This mark is for R32 refrigerant only. Refrigerant type is written on nameplate of outdoor unit. In case that refrigerant type is R32, this unit uses a flammable refrigerant. If refrigerant leaks and comes in contact with fire or heating part, it will create harmful gas and there is risk of fire.	
	Read the OWNER'S MANUAL carefully before operation.		
	Service personnel are required to carefully read the OWNER'S MANUAL and INSTALLATION MANUAL before operation.		
[]i	Further information is available in the OWNER'S MANUAL, INSTALLATION MANUAL, and the like.		

3-EN - 3 -

■ Warning indications on the air conditioner unit

Warning indication Description **WARNING** WARNING **ELECTRICAL SHOCK HAZARD ELECTRICAL SHOCK HAZARD** Disconnect all remote electric power supplies Disconnect all remote electric power supplies before servicing. before servicing. **WARNING WARNING** Moving parts Moving parts. Do not operate unit with grille Do not operate unit with grille removed. removed. Stop the unit before the servicing. Stop the unit before the servicing. **CAUTION CAUTION** High temperature parts. High temperature parts. You might get burned You might get burned when removing this panel. when removing this panel. **CAUTION CAUTION** Do not touch the aluminum Do not touch the aluminium fins of the unit. fins of the unit. Doing so may result in injury. Doing so may result in injury. **CAUTION CAUTION BURST HAZARD BURST HAZARD** Open the service valves before Open the service valves before the operation, to avoid unnecessary the operation, otherwise there pressure built up which could lead to explosion. might be the burst.

FN

-4- 4-EN

1 PRECAUTIONS FOR SAFETY

- Ensure that all Local, National and International regulations are satisfied.
- Read this "PRECAUTIONS FOR SAFETY" carefully before Installation.
- The precautions described below include the important items regarding safety. Observe them without fail.
- After the installation work, perform a trial operation (test run) to check for any problem.
 - Follow the Owner's Manual to explain how to use and maintain the unit to the customer.
- Turn off the main power supply switch (or breaker) before the unit maintenance.
- Ask the customer to keep the Installation Manual together with the Owner's Manual.

The manufacturer shall not assume any liability for the damage caused by not observing the description of this manual.



General

- Before starting to install the air conditioner, read through the Installation Manual carefully, and follow its instructions to install the air conditioner.
- Only a qualified installer or qualified service person is allowed to do installation work. Inappropriate installation may result in water or refrigerant leakage, electric shock or fire.
- Do not use any refrigerant different from the one specified for complement or replacement. Otherwise, abnormally high pressure may be generated in the refrigeration cycle, which may result in a failure or explosion of the product or an injury to your body.
- Before opening the front panel of the indoor unit set the circuit breaker to the OFF position. Failure to set the circuit breaker to the OFF position may result in electric shocks through contact with the interior parts. Only a qualified installer or qualified service person is allowed to remove the front panel of the indoor unit and do the work required.
- Before carrying out the installation, maintenance, repair or removal work, be sure to set the circuit breaker to the OFF position. Otherwise, may result in electric shocks.
- Place a "Work in progress" sign near the circuit breaker while the installation, maintenance, repair or removal work is being carried out. There is a danger of electric shocks if the circuit breaker is set to ON by mistake.
- Only a qualified installer or qualified service person is allowed to undertake work at heights using a stand of 19.7" (50 cm) or more or to remove the front panel of the indoor unit to undertake work.
- Wear protective gloves and safety work clothing during installation, servicing and removal.

5-EN - 5 -

- Do not touch the aluminium fin of the unit. You may injure yourself if you do so. If the fin must be touched for some reason, first put on protective gloves and safety work clothing, and then proceed.
- When work is performed at heights, use a ladder which complies with the ISO 14122 standard, and follow the procedure in the ladder's instructions.
 Also wear a helmet for use in industry as protective gear to undertake the work.
- Before cleaning the filter set the circuit breaker to OFF without fail, and place a "Work in progress" sign near the circuit breaker before proceeding with the work.
- Before working at heights, put a sign in place so that no-one will approach the work location, before proceeding with the work. Parts and other objects may fall from above, possibly injuring a person below. While carrying out the work, wear a helmet for protection from falling objects.
- The refrigerant used by this air conditioner is the R454B.
- The air conditioner must be transported in stable condition. If any part of the product is broken, contact the dealer.
- When the air conditioner must be transported by hand, carry it by two or more people.
- Do not move or repair any unit by yourself. Must be done by qualified installer or qualified service person. Special precaution should be taken when removing the cover for the unit to avoid electric shock from high voltage lines.
- This appliance is intended to be used by expert or trained users in shops, in light industry, or for commercial use by lay persons.

Selection of installation location

- When the air conditioner is installed in a small room, provide appropriate measures to ensure that the concentration of refrigerant leakage occur in the room does not exceed the critical level.
- Do not install the air conditioner in a location that may be subject to a risk
 of exposure to a combustible gas. If a combustible gas leaks and becomes
 concentrated around the unit, a fire may occur.
- To transport the air conditioner, wear shoes with additional protective toe caps.
- To transport the air conditioner, do not take hold of the bands around the packing carton. You may injure yourself if the bands should break.
- Do not place any combustion appliance in a place where it is directly exposed to the wind of air conditioner, otherwise it may cause imperfect combustion.
- Do not install in a location where flammable gas leaks are possible. If the gas leak and accumulate around the unit, it may ignite and cause a fire.
- Install the indoor unit at least 8'2" (2.5 m) above the floor level since otherwise the users may injure themselves or receive electric shocks if they poke their fingers or other objects into the indoor unit while the air conditioner is running.

ΕN

-6- 6-EN

Installation

- Install the air conditioner securely in a location where the base can sustain the weight adequately. If the strength is not enough, the unit may fall down resulting in injury.
- Follow the instructions in the Installation Manual to install the air conditioner. Failure to follow these instructions may cause the product to fall down or topple over or give rise to noise, vibration, water leakage or other trouble.
- If refrigerant gas has leaked during the installation work, ventilate the room immediately. If the leaked refrigerant gas comes in contact with fire, noxious gas may generate.
- Use forklift to carry in the air conditioner units and use winch or hoist at installation of them.

Refrigerant piping

- Install the refrigerant pipe securely during the installation work before operating the air conditioner. If the compressor is operated with the valve open and without refrigerant pipe, the compressor sucks air and the refrigeration cycles is over pressurized, which may cause a injury.
- Tighten the flare nut with a torque wrench in the specified manner.
 Over tightening of the flare nut may cause a crack in the flare nut after a long period, which may result in refrigerant leakage.
- After the installation work, confirm that refrigerant gas does not leak.
 If refrigerant gas leaks into the room and flows near a fire source, such as a cooking range, noxious gas may be generated.
- When the air conditioner has been installed or relocated, follow the
 instructions in the Installation Manual and purge the air completely so that no
 gases other than the refrigerant will be mixed in the refrigerating cycle.
 Failure to purge the air completely may cause the air conditioner to
 malfunction.
- Nitrogen gas must be used for the airtight test.
- The charge hose must be connected in such a way that it is not slack.

Electrical wiring

- Only a qualified installer or qualified service person is allowed to carry out
 the electrical work of the air conditioner. Under no circumstances must this
 work be done by an unqualified individual since failure to carry out the work
 properly may result in electric shocks and/or electrical leaks.
- To connect the electrical wires, repair the electrical parts or undertake other electrical jobs, wear gloves to provide protection for electricians and from heat, insulating shoes and clothing to provide protection from electric shocks. Failure to wear this protective gear may result in electric shocks.
- Use wiring that meets the specifications in the Installation Manual and the stipulations in the local regulations and laws. Use of wiring which does not meet the specifications may give rise to electric shocks, electrical leakage, smoking and/or a fire.

7-EN - 7 -

- Connect earth wire. (grounding wire)
 Incomplete grounding causes an electric shock.
- Do not connect grounding wires to gas pipes, water pipes, and lightning conductor or telephone grounding wires.
- After completing the repair or relocation work, check that the grounding wires are connected properly.
- Install a circuit breaker that meets the specifications in the Installation Manual and the stipulations in the local regulations and laws.
- Install the circuit breaker where it can be easily accessed by the agent.
- Under no circumstances the power wire must not be extended. Connection trouble in the places where the wire is extended may give rise to smoking and/or a fire.
- Electrical wiring work shall be conducted according to law and regulation in the community and Installation Manual. Failure to do so may result in electrocution or short circuit.

Test run

- Before operating the air conditioner after having completed the work, check that the electrical control box cover of the indoor unit and service panel of the outdoor unit are closed, and set the circuit breaker to the ON position. You may receive an electric shock if the power is turned on without first conducting these checks.
- If there is any kind of trouble (such as an error display has appeared, smell of burning, abnormal sounds, the air conditioner fails to cool or heat or water is leaking) has occurred in the air conditioner, do not touch the air conditioner but set the circuit breaker to the OFF position, and contact a qualified service person. Take steps to ensure that the power will not be turned on (by marking "out of service" near the circuit breaker, for instance) until qualified service person arrives. Continuing to use the air conditioner in the trouble status may cause mechanical problems to escalate or result in electric shocks or other trouble.
- After the work has finished, use an insulation tester set (500V Megger) to check the resistance is $1M\Omega$ or more between the charge section and the non-charge metal section (Earth / Ground section). If the resistance value is low, a disaster such as a leak or electric shock is caused at user's side.
- Upon completion of the installation work, check for refrigerant leaks and check the insulation resistance and water drainage. Then conduct a test run to check that the air conditioner is operating properly.

ΕN

-8- 8-EN

Explanations given to user

- Upon completion of the installation work, tell the user where the circuit breaker is located. If the user does not know where the circuit breaker is, he or she will not be able to turn it off in the event that trouble has occurred in the air conditioner.
- If the fan grille is damaged, do not approach the outdoor unit but set the circuit breaker to the OFF position, and contact a qualified service person to have the repairs done. Do not set the circuit breaker to the ON position until the repairs are completed.
- After the installation work, follow the Owner's Manual to explain to the customer how to use and maintain the unit.

Relocation

- Only a qualified installer or qualified service person is allowed to relocate
 the air conditioner. It is dangerous for the air conditioner to be relocated by
 an unqualified individual since a fire, electric shocks, injury, water leakage,
 noise and/or vibration may result.
- While carrying out the pump-down work shut down the compressor before disconnecting the refrigerant pipe. Disconnecting the refrigerant pipe with the service valve left open and the compressor still operating will cause air or other gas to be sucked in, raising the pressure inside the refrigeration cycle to an abnormally high level, and possibly resulting in rupture, injury or other trouble.

9-EN - 9 -

♠ CAUTION

New refrigerant air conditioner installation

- This air conditioner adopts refrigerant R454B which does not destroy ozone layer.
- The characteristics of R454B refrigerant are; easy to absorb water, oxidizing membrane or oil. Accompanied with the new refrigerant, refrigerating oil has also been changed. Therefore, during installation work, be sure that water, dust, former refrigerant, or refrigerating oil does not enter the refrigerating cycle.
- To prevent charging an incorrect refrigerant and refrigerating oil, the sizes of connecting sections of charging port of the main unit and installation tools are changed from those for the conventional refrigerant.
- Accordingly the exclusive tools are required for the new refrigerant (R454B).
- For connecting pipes, use new and clean piping designed for R454B, and please care so that water or dust does not enter.

To disconnect the appliance from main power supply.

• This appliance must be connected to the main power supply by means of a switch with a contact separation of at least 0.1" (3 mm)

The installation fuse (all types can be used) must be used for the power supply line of this air conditioner.

Install the indoor unit at least 8'2" (2.5 m) above the floor level since otherwise the users may injure themselves or receive electric shocks if they poke their fingers or other objects into the indoor unit while the air conditioner is running.

ΕN

– 10 – 10-EN

2 ACCESSORY PARTS

Part name	Q'ty	Shape	Usage
Installation Manual	1	This manual	(For hand over to customers)
Owner's Manual	1		(For hand over to customers)
Installation plate	1		
Wireless remote controller	1		
Batteries size AAA	2		
Remote controller holder	1		
Mounting screw Ø5/32" (4 mm) × 1.0" (25 mm)	6	()mmmm>	
Flat head wood screw Ø1/8" (3.1 mm) × 0.6" (16 mm)	2		
Screw Ø5/32" (4 mm) × 0.4" (10 mm)	3		
Insulation	1		
Eletrical cover 2 holes	1		

11-EN - 11 -

$oldsymbol{3}$ SELECTION OF INSTALLATION PLACE

MARNING

Install the air conditioner at enough strong place to withstand the weight of the unit.
 If the strength is not enough, the unit may fall down resulting in injury.

♠ CAUTION

 Do not install the air conditioner in a location subject to a risk of exposure to a combustible gas.

If a combustible gas leaks and stays around the unit, a fire may occur.

Upon approval of the customer, install the air conditioner in a place that satisfies the following conditions.

- · Place where the unit can be installed horizontally.
- Place where a sufficient servicing space can be ensured for safety maintenance and check.
- Place where drained water will not cause any problem.

Avoid installing in the following places.


Select a location for the indoor unit where the cool or warm air will circulate evenly. Avoid installation in the following kinds of locations.

- · Saline area (coastal area).
- Locations with acidic or alkaline atmospheres (such as areas with hot springs, factories where chemicals or pharmaceuticals are made and places where the exhaust air from combustion appliances will be sucked into the unit).
- Doing so may cause the heat exchanger (its aluminum fins and copper pipes) and other parts to become corroded.
- Locations with atmospheres with mist of cutting oil or other types of machine oil.
 Doing so may cause the heat exchanger to become corroded, mists caused by the blockage of the heat exchanger to be generated, the plastic parts to be damaged, the heat insulators to peel off, and other such problems to result.
- Places where iron or other metal dust is present. If iron or other metal dust adheres to or collects on the interior of the air conditioner, it may spontaneously combust and start a fire.
- Locations where vapors from food oils are formed (such as kitchens where food oils are used). Blocked filters may cause the air conditioner's performance to deteriorate, condensation to form, the plastic parts to be damaged, and other such problems to result.
- Locations near obstructions such as ventilation openings or lighting fixtures where the flow of the blown air will be disrupted (a disruption of the air flow may cause the air conditioner's performance to deteriorate or the unit to shut down).
- Locations where an in-house power generator is used for the power supply.
 The power line frequency and voltage may fluctuate, and the air conditioner may not work properly as a result.
- · On truck cranes, ships or other moving conveyances.
- The air conditioner must not be used for special applications (such as for storing food, plants, precision instruments or art works).
 - (The quality of the items stored may be degraded.)
- Locations where high frequencies are generated (by inverter equipment, in-house power generators, medical equipment or communication equipment).
 - (Malfunctioning or control trouble in the air conditioner or noise may adversely affect the equipment's operation.)
- Locations where there is anything under the unit installed that would be compromised by wetness. (If the drain has become blocked or when the humidity is over 80%, condensation from the indoor unit will drip, possibly causing damage to anything underneath.)
- In the case of the wireless type of system, rooms with the inverter type of fluorescent lighting or locations exposed to direct sunlight.
 - (The signals from the wireless remote controller may not be sensed.)
- Locations where organic solvents are being used.
- The air conditioner cannot be used for liquid carbonic acid cooling or in chemical plants.
- Location near doors or windows where the air conditioner may come into contact with high-temperature, high-humidity outdoor air.
 - (Condensation may occur as a result.)
- Locations where special sprays are used frequently.

ΕN

– 12 – 12-EN

■ Installation diagram of Indoor unit



■ Installation space

The indoor unit shall be installed at least 8'2" (2.5 m) height.

Also it must be avoided to put anything on top of the indoor unit.

- *1 Reserve space required to install the indoor unit and for service work.

 Keep 2.0" (50 mm) or more for clearance between top plate of the indoor unit and the ceiling surface.
- *2 Provide a space as shown for service clearance for the cross flow fan.

■ Installation place

- · A place which provides the spaces around the indoor unit as shown in the above diagram.
- · A place where there is no obstacle near the air inlet and outlet.
- · A place that allows easy installation of the piping to the outdoor unit.
- · A place which allows the front panel to be opened.


↑ CAUTION

- · Direct sunlight to the indoor unit's wireless receiver should be avoided.
- The microprocessor in the indoor unit should not be too close to RF noise sources. (For details, see the Owner's Manual.)

13-EN - 13 -

■ Wireless remote controller

- · A place where there are no obstacles such as a curtain that may block the signal from the indoor unit.
- Do not install the remote controller in a place exposed to direct sunlight or close to a heating source, such as a stove.
- Keep the remote controller at least 3'3" (1 m) apart from the nearest TV set or stereo equipment. (This is necessary to prevent image disturb-bounces or noise interference.)
- The location of the remote controller should be determined as shown below.



*: Axial distance

4 INSTALLATION OF INDOOR UNIT

! WARNING

Install the air conditioner certainly to sufficiently withstand the weight. If the strength is insufficient, the unit may fall down resulting in human injury. Perform a specified installation work to guard against strong wind or earthquake. An incomplete installation can cause accidents by the units falling and dropping.

REQUIREMENT

Strictly comply with the following rules to prevent damage of the indoor units and human injury.

- Do not put a heavy article on the indoor unit. (Even units are packaged)
- Carry in the indoor unit as it is packaged if possible. If carrying in the indoor unit unpacked by necessity, be sure to use buffering cloth, etc. to not damage the unit.
- To move the indoor unit, do not apply force to the refrigerant pipe, drain pan, foamed parts, or resin parts, etc.
- Carry the package by two or more persons, and do not bundle it with plastic band at positions other than specified.

Be careful to the following items when installating the unit.

Considering air discharge direction, select an installation place where discharge air can circulate evenly
in a room. Avoid to install the unit at place with "NO GOOD" mark in the right figure.

OK

NO GOOD

Bad installation place
Cooled well all over.

Screen

Screen

- 14 - 14-EN


ΕN

■ Installation of eletrical cover 2 holes type


REQUIREMENT

In case of group control, electrical cover 1 hole type need to change to electrical cover 2 holes type.


- Step to remove the electrical cover 1 hole.
- 1) The electical cover 1 hole can be removed by removing the screw securing the electical cover 1 hole and them pulling out the electical cover 1 hole.




2) Remove the electrical cover 1 hole by direction backside of unit.



3) Remove the EDGE-SADDLE take off from electrical cover 1 hole.



• Step to install the electrical cover 1 hole (Option connect power supply 2 holes)




15-EN - 15 -

5 CUTTING A HOLE AND MOUNTING INSTALLATION PLATE

■ Cutting a hole

In case of installing the refrigerant pipes from the rear:


 Decide the hole position for piping at 4.3" (110 mm) from the arrow mark (⇒) on the installation plate and drill a hole at a slight downward slant toward outdoor side.



NOTE

 When drilling a wall that contains a metal lath, wire lath or metal plate, be sure to use a pipe hole brim ring sold separately.

■ Mounting the installation plate




When the installation plate is directly mounted on the wall

- Securely fit the installation plate onto the wall by screwing it in the upper and lower parts to hook up the indoor unit.
- To mount the installation plate on a concrete wall with anchor bolts, utilize the anchor bolt holes as illustrated in the above figure.
- 3. Install the installation plate horizontally in the wall.

CAUTION

When installing the installation plate with a mounting screw, do not use the anchor bolt hole. Otherwise the unit may fall down and result in personal injury and property damage.



A CAUTION

Failure to firmly install the unit may result in personal injury and property damage if the unit falls.

- In case of block, brick, concrete or similar type walls, make 0.2" (5 mm) dia. holes in the wall.
- Insert clip anchors for appropriate mounting screws.

NOTE

 Secure four corners and lower parts of the installation plate with 6 mounting screws to install it.


– 16 – 16-EN

ΕN

6 PIPING AND DRAIN HOSE INSTALLATION

■ Piping and drain hose forming

* Since dewing results in a machine trouble, make sure to insulate both connecting pipes. (Use polyethylene foam as insulating material.)



1. Die-cutting front panel slit


Cut out the slit on the left or right side of the front panel for the left or right connection and the slit on the bottom left or right side of the front panel for the bottom left or right connection with a pair of nippers.

2. Changing drain hose

For leftward connection, bottom-leftward connection and rear-leftward connection's piping, it is necessary to change the drain hose and drain cap.

How to remove the drain hose


- The drain hose can be removed by removing the screw securing the drain hose and then pulling out the drain hose.
- When removing the drain hose, be careful of any sharp edges of steel plate.
 The edges can injuries.
- To install the drain hose, insert the drain hose firmly until the connection part contacts with heat insulator, and then secure it with original screw.



17-EN - 17 -


How to remove the drains cap

Clip the drain cap by needle-nose pliers and pull out.




How to fix the drains cap

1) Insert hexagonal wrench (dia. 0.2" (4 mm)) in a centre head.



2) Firmly insert drains cap.





Firmly insert the drain hose and drain cap; otherwise, water may leak.

How to remove the drain hose


- 1) Remove the front panel.
- 2) Remove the screws of drain hose.
- 3) Pull out the drain hose.

▼ In case of right or left piping

• After scribing slits of the front panel with a knife or a marking-off pin, cut them with a pair of nippers or an equivalent tool.



- 1) Put the drain hose.
- 2) Screw the drain hose to the indoor unit.
- 3) Install the front panel.




ΕN

– 18 – 18-EN

▼ In case of bottom right or bottom left piping

 After scribing slits of the front panel with a knife or a marking-off pin, cut them with a pair of nippers or an equivalent tool.




▼ Left-hand connection with piping

Bend the connecting pipe so that it is laid within 1.7" (43 mm) above the wall surface. If the connecting pipe is laid exceeding 1.7" (43 mm) above the wall surface, the indoor unit may unstably be set on the wall. When bending the connecting pipe, make sure to use a spring bender so as not to crush the pipe.

Bend the connecting pipe within a radius of 1.2" (30 mm).

To connect the pipe after installation of the unit (figure)




NOTE

If the pipe is bent incorrectly, the indoor unit may unstably be set on the wall. After passing the connecting pipe through the pipe hole, connect the connecting pipe to the auxiliary pipes and wrap the facing tape around them.

! CAUTION

• Bind the auxiliary pipes (two) and power supply wiring and control wiring with facing tape tightly. In case of leftward piping and rear-leftward piping, bind the auxiliary pipes (two) only with facing tape.




- · Carefully arrange pipes so that any pipe does not stick out of the rear plate of the indoor unit.
- Carefully connect the auxiliary pipes and connecting pipes to one another and cut off the insulating tape wound on the connecting pipe to avoid double-taping at the joint; moreover, seal the joint with the vinyl tape, etc.
- Since dew results in a machine trouble, make sure to insulate both the connecting pipes. (Use polyethylene foam as insulating material.)
- When bending a pipe, carefully do it, not to crush it.


19-EN - **19** -

7 INDOOR UNIT FIXING

- 1. Pass the pipe through the hole in the wall, and hook the indoor unit on the installation plate at the upper hooks.
- Swing the indoor unit to right and left to confirm that it is firmly hooked up on the installation plate.
- While pressing the indoor unit onto the wall, hook it at the lower part on the installation plate. Pull the indoor unit toward you to confirm that it is firmly hooked up on the installation plate.




 For detaching the indoor unit from the installation plate, pull the indoor unit toward you while pushing its bottom up at the specified parts.



REQUIREMENT

The lower part of indoor unit may float, due to the condition of piping and you cannot fix it to the installation plate. In that case, use the screws provided to fix the unit and the installation plate. Especially when the pipes are pulled out from the left side, the unit must be screwed to the installation plate.





8 DRAINAGE

1. Run the drain hose sloped downwards.

NOTE

- Hole should be made at a slight downward slant on the outdoor side.
- 2. Put water in the drain pan and make sure that the water is drained out of doors.
- 3. When connecting extension drain hose, insulate the connecting part of extension drain hose with shield pipe.






⚠ CAUTION

Arrange the drain pipe for proper drainage from the unit

Improper drainage can result in dew-dropping.

This air conditioner has the structure designed to drain water collected from dew, which forms on the back of the indoor unit, to the drain pan. Therefore, do not store the power cord and other parts at a height above the drain guide.



ΕN

- 20 - 20-EN

9 REFRIGERANT PIPING

■ Refrigerant Piping

- 1. Use copper pipe with 0.03" (0.8 mm) or more thickness. (In case pipe size is dia. 5/8" (15.9 mm), with 0.04" (1.0 mm) or more.)
- Flare nut and flare works are also different from those of the conventional refrigerant. Take out the flare nut attached to the main unit of the air conditioner, and use it.

REQUIREMENT

When the refrigerant pipe is long, provide support brackets at intervals of 8'2" - 9'10" (2.5 - 3 m) to clamp the refrigerant pipe. Otherwise, abnormal sound may be generated



IMPORTANT 4 POINTS FOR PIPING WORK

- 1. Remove dust and moisture from the inside of the connecting pipes.
- 2. Tight connection (between pipes and unit)
- 3. Evacuate the air in the connecting pipes using VACUUM PUMP.
- 4. Check the gas leakage. (Connected points)

■ Pipe size

(dia.: in (mm))

RAV	PIPE SIZE		
KAV	Gas side	Liquid side	
HB301, HB361	5/8" (15.9)	3/8" (9.5)	

■ Permissible Piping Length and Height Difference

They vary according to the outdoor unit. For details, refer to the Installation Manual attached to the outdoor unit.

Flaring

- Cut the pipe with a pipe cutter.
 Remove burrs completely.
 Remaining burrs may cause gas leakage.
- As the flaring sizes of R454B differ from those of refrigerant R22, the flare tools newly manufactured for R454B are recommended. However, the conventional tools can be used by adjusting projection margin of the copper pipe.

• Insert a flare nut into the pipe, and flare the pipe.

▼ Projection margin in flaring: B (Unit: in (mm)) RIDGID (Clutch type)

Outer dia. of copper pipe	Tool used	Conventional tool used
1/4" (6.4) ,	0.02"-0.04"	0.04"-0.06"
3/8" (9.5)	(0.5-1.0)	(1.0-1.5)
1/2" (12.7) ,	0.02"-0.04"	0.06"-0.08"
5/8" (15.9)	(0.5-1.1)	(1.5-2.0)

▼ Flaring dia. meter size: A (Unit: in (mm))

Outer dia. of copper pipe	A +0 -0.4	
Outer dia: or copper pipe	R454B	
1/4" (6.4)	0.4" (9.1)	
3/8" (9.5)	0.5" (13.2)	
1/2" (12.7)	0.7" (16.6)	
5/8" (15.9)	0.8" (19.7)	

A CAUTION

- Do not scratch the inner surface of the flared part when removing burrs.
- Flare processing under the condition of scratches on the inner surface of flare processing part will cause refrigerant gas leak.
- Check that the flared part is not scratched, deformed, stepped, or flattened, and that there are no chips adhered or other problems, after flare processing.
- Do not apply refrigerating machine oil to the flare surface.

21-EN **– 21 –**

* In case of flaring for R454B with the conventional flare tool, pull it out approx. 0.02" (0.5 mm) more than that for R22 to adjust to the specified flare size. The copper pipe gauge is useful for adjusting projection margin size.



Tightening connection



 Do not apply excessive torque. Otherwise, the nut may crack depending on the conditions.

(Unit: in (mm))

Outer dia. of copper pipe	Tightening torque
1/4" (6.4 mm) (dia.)	10-13 (14-18)
3/8" (9.5 mm) (dia.)	24-31 (33-42)
1/2" (12.7 mm) (dia.)	37-46 (50-62)
5/8" (15.9 mm) (dia.)	50-60 (68-82)

▼ Tightening torque of flare pipe connections

Pressure of R454B is higher than that of R22. (Approx. 1.6 times) Therefore, using a torque wrench, tighten the flare pipe connecting sections which connect the indoor and outdoor units of the specified tightening torque.

Incorrect connections may cause not only a gas leak, but also a trouble of the refrigeration cycle. Align the centres of the connecting pipes and tighten the flare nut as far as possible with your fingers. Then tighten the nut with a spanner and torque wrench as shown in the figure.



Work using double spanner

REQUIREMENT

Tightening with an excessive torque may crack the nut depending on installation conditions. Tighten the nut within the specified tightening torque.

Piping with outdoor unit


Shape of valve differs according to the outdoor unit.

For details of installation, refer to the Installation Manual of the outdoor unit.

Insulation

Insulation for the pipes should be done separately for the liquid side and gas side. Because both of the liquid and gas side pipes become a low temperature during cooling operation, sufficient insulation should be done to prevent condensation.

- Insulation with a heat resistance of 248°F (120°C) or more must be used for the gas side pipe.
- The pipe connection section of the indoor unit must be insulation securely and compactly with the attached insulation.



REQUIREMENT

Apply the insulation to the pipe connecting section of the indoor unit securely up to the root without exposure of the pipe. (the pipe exposed to the outside causes water leak.)

■ Airtight test/Air purge, etc.

For airtight test, air purge, addition of refrigerant, and gas leak check, follow the Installation Manual attached to the outdoor unit.

Open fully valves of the outdoor unit

Open the valve of the outdoor unit fully. A hexagonal wrench is required for opening the valve.

For details, refer to the Installation Manual attached to the outdoor unit.

ΕN

- 22 - 22-EN

4/21/2567 BE 17:30

■ Gas leak check

Check with a leak detector or soap water whether gas leaks or not, from the pipe connecting section or cap of the valve.

REQUIREMENT


Use a leak detector manufactured exclusively HFC refrigerant (R454B, R134a, etc.).

■ Wireless remote controller A-B selection

Using 2 wireless remote controllers for the respective air conditioners, when the 2 air conditioners are closely installed.

Wireless remote controller B setup

- 1 Push TEMPORARY ® button on the indoor unit to turn the air conditioner ON.
- 2 Point the wireless remote controller at the indoor unit.
- 3 Push and hold cHK button on the wireless remote controller by the tip of the pencil. "00" will be shown on the display.
- 4 Push local during pushing chike . "B" will be shown on the display and "00" will be disappear and the air conditioner will turn OFF. The wireless remote controller B is memorized.



NOTE

- Repeat above step to reset wireless remote controller to be A.
- The wireless remote controllers do not display "A"
- The factory default of the wireless remote controllers is "A".

23-EN - 23 -

10 ELECTRICAL CONNECTION

WARNING

- Use the specified wires for wiring connect the terminals. Securely fix them to prevent external forces applied to the terminals from affecting the terminals.
- Incomplete connection or fixation may cause a fire or other trouble.Connect earth wire. (grounding work)
 - Incomplete grounding cause an electric shock.
 - Do not connect earth wires to gas pipes, water pipes, lightning conductor or telephone earth wires.
- Appliance shall be installed in accordance with national wiring regulations.
 Capacity shortage of power circuit or incomplete installation may cause an electric shock or a fire.

! CAUTION

- · For power supply specifications, follow the Installation Manual of outdoor unit.
- Do not connect 208/230V~60Hz power to the terminal blocks (A, B) for control wiring.
 Otherwise, the system will fail.
- Do not damage or scratch the conductive core and inner insulator of power and system interconnection wires while peeling them.
- Perform the electric wiring so that it does not come to contact with the high-temperature part of the pipe.

The coating may melt resulting in an accident.

• Do not turn on the power of the indoor unit until vacuuming of the refrigerant pipes completes.

System interconnection wires specifications

System interconnection wires*	AWG16 or more (H07RN-F or 60245 IEC 66)	Up to 229' 7" (70 m)
-------------------------------	--	----------------------

^{*}Number of wire × wire size

Remote controller wiring


Remote controller wiring, remote controller inter-unit wiring	Wire size: 2 × AWG20 to AWG16	
	la anna africina d'Eura a auto	
Total wire length of remote controller wiring	In case of wired type only	Up to 1640' 5" (500 m)
Total wire length of remote controller wiring and remote controller inter-unit wiring	2 remote controllers	Up to 984' 3" (300 m)
L + L1 + L2 + Ln	2 remote controllers including a wireless remote controller	Up to 1312' 4" (400 m)
otal wire length of remote controller inter-unit wiring = L1 + L2 + Ln		Up to 656' 2" (200 m)

ΕN

- 24 - 24-EN

A CAUTION

When connecting to the central control device dedicated to TCC-Link, it is necessary to change to TCC-Link using a wired remote controller. Set according to the Communication type procedure of "11 Applicable controls".



Max. number of connect-able indoor units, and communication type

	Unit type			
Indoor unit	RAV-HM ***	RAV-HM ***	*	*
Remote controller Remote sensor	U series	*	U series	*
Communication type	TU2C-Link		TCC-Link	
Max. number of connect-able units	16	8		

^{*:} Other than RAV-HM *** and U series

25-EN **– 25 –**

■ Wiring between indoor unit and outdoor unit

Figure below shows the wiring connections between the indoor and outdoor units and between the indoor units and remote controller. The wires indicated by the broken lines or dot-and-dash lines are provided at the locally.

Remote controller


Indoor side

Outdoor side


- Refer to the both indoor and outdoor unit wiring diagrams.
- The power of the indoor unit is supplied from the outdoor unit.

Wiring diagram






▼ Simultaneous twin system



▼ Simultaneous triple and double twin system




- * Use 2-core shield wire (MVVS AWG20 to AWG16) for the remote controller wiring in the simultaneous twin, simultaneous triple and simultaneous double twin systems to prevent noise problems. Be sure to connect both ends of the shield wire to grounding wires.
- Connect grounding wires for each indoor unit in the simultaneous twin, simultaneous triple and simultaneous double twin systems.

■ Wired remote controller wiring

As the wired remote controller wire has non-polarity, there is no problem if connections to indoor unit terminal blocks A and B are reversed.

▼ Wiring diagram



- 26 -26-EN

ΕN

■ Wiring Connection

How to connect the power supply wiring and control wiring

The power supply wire and the control wire can be connected without removing the front panel.


REQUIREMENT


Connect the power supply wire after connecting the control wire for this model.

- Remove the air inlet grille.
 Open the air inlet grille upward and pull it toward you.
- 2. Remove the terminal cover and the clamp base.
- Insert the power supply wire and control wire (according to the local rule) into the pipe hole on the wall.
- Take the power supply wire out of the cable slot on the rear panel so that it protrudes about 5.9" (150 mm) from the front.
- 5. Insert the control wire fully into the control/wired remote controller terminal block (13), (14), (A), (B) and secure it tightly with screws.
- 6. Clamp the control wire with the cord clamp.
- 7. Install the clamp base with a screw.
- Insert the power supply wire fully into the terminal block and secure it tightly with screws. Tightening torque: 0.9 ft•lbs (1.2 N•m) Secure the ground line with the ground screw.
- 9. Clamp the power supply wire with the cord clamp.
- 10. Attach the terminal cover and the air inlet grille to the indoor unit.


A CAUTION


- Be sure to refer to the wiring diagram attached inside the front panel.
- Check local electrical cords an also any specific wiring instructions and limitations.
- Do not catch the control wire when installing the clamp base.





<Stripping length of the power supply wire>





27-EN **- 27 -**

■ Wiring connection (twin, triple, double twin system)

- 1 Connect a header unit by following the procedure of wiring connection for single system.
- 2 Connect system interconnection wire 1 and 2 of follower unit to terminal 1 and 2 on terminal block respectively.
 System interconnection wire 3 is not used.
- 3 Connect the grounding wire to the ground screw located on the underside of the electrical control box.
- 4 Clamp the system interconnection wire with the cord clamp.
- 5 Attach the terminal cover and the air intake grille to the indoor unit.

▼ When using optional wired remote controller

The system interconnection wire and the wired remote controller wire can be connected without removing the front panel.

- 1 Remove the air intake grille.
 Open the air intake grille upward and pull it toward you.
- 2 Remove the terminal cover and the clamp
- 3 Insert the system interconnection wire and wired remote controller wire (according to the local rule) into the pipe hole on the wall.
- 4 Take the system interconnection wire and wired remote controller wire out of the cable slot on the rear panel so that it protrudes about 5.9" (150 mm) from the front.
- Insert the wired remote controller wire fully into the wired remote controller / central control terminal block, (A), (B) and secure it tightly with screws.
 - Strip off approx. 0.3" (9 mm) the wire to be connected.
 - Non polarity, 2 core wire is used for wiring of the wired remote controller. (AWG20 to AWG16 wires)

- 6 Clamp the wired remote controller wire with the cord clamp.
- 7 Install the clamp base with a screw.
- 8 Insert the system interconnection wire fully into the terminal block and secure it tightly with screws.
 - Tightening torque: 0.9 ft•lbs (1.2 N•m) Secure the grounding wire with the ground screw.
- 9 Clamp the system interconnection wire with the cord clamp.
- 10 Attach the terminal cover and the air intake grille to the indoor unit.

CAUTION

- Be sure to refer to the wiring diagram attached inside the front panel.
- Check local electrical cords and also any specific wiring instructions and limitations.
- Do not catch the wired remote controller wire when installing the clamp base.

ΕN

– 28 – 28-EN

■ Wiring connection (twin, triple, double twin system)

- 1 Connect a header unit by following the procedure of wiring connection for single system.
- 2 Connect system interconnection wire 1 and 2 of follower unit to terminal 1 and 2 on terminal block respectively.
 System interconnection wire 3 is not used.
- 3 Connect the grounding wire to the ground screw located on the underside of the electrical control box.
- 4 Clamp the system interconnection wire with the cord clamp.
- 5 Attach the terminal cover and the air intake grille to the indoor unit.

▼ When using optional wired remote controller

The system interconnection wire and the wired remote controller wire can be connected without removing the front panel.

- Remove the air intake grille.
 Open the air intake grille upward and pull it toward you.
- 2 Remove the terminal cover and the clamp
- 3 Insert the system interconnection wire and wired remote controller wire (according to the local rule) into the pipe hole on the wall
- 4 Take the system interconnection wire and wired remote controller wire out of the cable slot on the rear panel so that it protrudes about 5.9" (150 mm) from the front.
- Insert the wired remote controller wire fully into the wired remote controller / central control terminal block, (A), (B) and secure it tightly with screws.
 - Strip off approx. 0.3" (9 mm) the wire to be connected.
 - Non polarity, 2 core wire is used for wiring of the wired remote controller. (AWG20 to AWG16 wires)

- 6 Clamp the wired remote controller wire with the cord clamp.
- 7 Install the clamp base with a screw.
- 8 Insert the system interconnection wire fully into the terminal block and secure it tightly with screws.
 - Tightening torque: 0.9 ft•lbs (1.2 N•m) Secure the grounding wire with the ground screw.
- 9 Clamp the system interconnection wire with the cord clamp.
- **10** Attach the terminal cover and the air intake grille to the indoor unit.

A CAUTION

- Be sure to refer to the wiring diagram attached inside the front panel.
- Check local electrical cords and also any specific wiring instructions and limitations.
- Do not catch the wired remote controller wire when installing the clamp base.

29-EN **– 29 –**

11 APPLICABLE CONTROLS

REQUIREMENT

When the air conditioner is used for the first time, it will take some moments after the power has been turned on before the remote control becomes available for operations: This is normal and is not indicative of trouble.

(The automatic addresses are set up by performing operations on the outdoor interface circuit board.)

While the automatic addresses are being set up, no remote control operations can be performed. Setup takes up to 10 minutes (usually about 5 minutes).

· Concerning the automatic addresses

 When the power is turned on after automatic address setup.

It takes up to 10 minutes (usually about 3 minutes) for the outdoor unit to start operating after the power has been turned on.

Before the air conditioner was shipped from the factory, all units are set to [STANDARD] (factory default). If necessary, change the indoor unit settings.

The settings are changed by operating the wired remote control.

* The settings cannot be changed using only a wireless remote control, simple remote control or group control remote control by itself so install a wired remote control separately as well.

■ Easy I.DN setting


Sets various functions related to air conditioners.

REQUIREMENT

Be sure to stop operation of the air conditioners.



- **1** Push [Menu] to open the "Menu"
- 2 Push and hold [Menu] and [▶] at the same time to open "Field setting menu"
 - → Push and hold 4 seconds.



- In the "Field setting menu" screen, push [⋈] and [⋈] to select "Easy I.DN setting", and then push [□ Set/Fix]
 - → The fans and louvres of the indoor units operate.

When doing group connections:

- → The fans and louvres of the selected indoor units operate.
- 4 Push [∧] and [∨] to select an item
 - → Push [] and [] to switch to the setting you want, or set a numerical value.
- 5 After setting each item, push [☐ Set/Fix]
 - → The changes are fixed, and the "Field setting menu" screen returns.
 - → "\noting" appears while data is changing.

When doing group connections:

→ After finishing "Easy I.DN setting" for each unit, push [Set/Fix] to fix the changes and return to the unit selection screen. In the unit selection screen, push [Return] to briefly display "X", and then return to the "Field setting menu" screen.

ΕN

- 30 - 30-EN

Installing indoor unit on high ceiling

When an indoor unit is installed on a ceiling higher than the standard height, make the high-ceiling setting for air volume adjustment.


Follow the "Easy I.DN setting" procedure $(1 \rightarrow 2 \rightarrow 3 \rightarrow 4 \rightarrow 5)$.

- Select "1. High ceiling adjustment" from the "Easy I.DN setting" menu.
- Select the Set data for high ceiling adjustment from the "Height list of ceiling possible to be installed" table on page 4 in this manual.

Remote control-less setting

Change the high-ceiling setting with the DIP switch on the P.C. Board.

* Once the Set data has been changed, though it can be freely set to 1 or 3, to reset it to 0 (factory default), it need changing using remote control (sold separately). After set data change, an air conditioner is operated. After setting has been completed, restart the air conditioner.



Set data	Ceiling height	SW501-1	SW501-2
0	Standard (Factory default)	OFF	OFF
1	High ceiling (1)	ON	OFF
3	High ceiling (3)	OFF	ON

To restore the factory defaults

To return the DIP switch settings to the factory defaults, set SW501-1 and SW501-2 to OFF, connect a separately sold wired remote control, and then set the Set data to "0".

■ Filter sign setting

According to the installation condition, the lighting time of the filter sign (Notification of filter cleaning) can be changed.

Follow to the "Easy I.DN setting" procedure (1 \rightarrow 2 \rightarrow 3 \rightarrow 4 \rightarrow 5).

- Select "2. Filter sign timer" from the "Easy I.DN setting" menu.
- Select the Set data for "Filter sign timer" from following table.

Set data	Filter sign lighting time	
0	None	
1	150 H	
2	2500 H (Factory default)	
3	5000 H	
4	10000 H	

31-EN - 31 -

■ To secure better effect of heating

When it is difficult to obtain satisfactory heating due to installation place of the indoor unit or structure of the room, the detection temperature of heating can be raised. Also use a circulator or other device to circulate heat air near the ceiling. Follow to the "Easy I.DN setting" procedure $(1 \rightarrow 2 \rightarrow 3 \rightarrow 4 \rightarrow 5)$.

- Select "3. Heating temp. shift" from the "Easy I.DN setting" menu.
- Select the Set data for "Heating temp. shift" from following table.

Set data	Detection temp shift value	
+0K	No shift	
+1K	1.8°F (+1°C)	
+2K	3.6°F (+2°C) (Factory default)	
+3K	5.4°F (+3°C)	
+4K	7.2°F (+4°C)	
+5K	9.0°F (+5°C)	
+6K	10.8°F (+6°C)	

■ 46°F (8°C) operation

Pre-heating operation can be set for cold regions where room temperature drops to below zero.

Follow to the "Easy I.DN setting" $(1 \rightarrow 2 \rightarrow 3 \rightarrow 4 \rightarrow 5)$.

- For the "Dode (DN)" in Procedure 3, specify [00D1].
- · For the "Data" in Procedure.

SET DATA	46°F (8°C) Operation setting	
0000	None (Factory default)	
0001	46°F (8°C) Operation setting	

■ TA sensor selection

The temperature sensor of the indoor unit senses room temperature usually. Set the remote control sensor to sense the temperature around the remote control.

Select items following the "Easy I.DN setting" procedure

$$(1 \rightarrow 2 \rightarrow 3 \rightarrow 4 \rightarrow 5)$$
.

- Select "4. TA sensor selection" from the "Easy I.DN setting" menu.
- Select the Set data for "TA sensor selection" from following table.

Set data	TA sensor selection
Body	Sensor of the indoor unit (Factory default)
RC	Sensor of the remote control

- When "RC" is selected, I lights up. However, it is not displayed when it is set as a sub-remote control.
- When slashes, the remote control sensor is defective. Select the Set data "Body" or replace the remote control.

■ Group control

In a group control, a remote control can control up to maximum 8 or 16 units. (Depending on the outdoor unit.)

- The wired remote control only can control a group control. The wireless remote control is unavailable for this control.
- For wiring procedure and wires of the individual line (Identical refrigerant line) system, refer to "10. Electrical connection" in this Manual.
- Wiring between indoor units in a group is performed in the following procedure.
- Connect the indoor units by connecting the remote control wires from the remote control terminal blocks (A, B) of the indoor unit connected with a remote control to the remote control terminal blocks (A, B) of the other indoor unit. (Non-polarity)
- For address setup, refer to the Installation Manual attached to the outdoor unit.

ΕN

- 32 - 32-EN

■ Group control


Simultaneous twin, triple or double twin system

A combination with an outdoor unit allows simultaneous ON / OFF operation of the indoor units.


The following system patterns are available.

- Two indoor units for the twin system
- Three indoor units for the triple system
- Four indoor units for the double-twin system


▼ Twin system



▼ Triple system



▼ Double twin



- · For wiring procedure and wiring method, follow to the "Electrical connection" in this manual.
- When the power supply has been turned on, the automatic address setup starts and which indicates that address is being set up flashes on the display part.

During setup of automatic address, the remote controller operation is not accepted.


Required time up to the finish of automatic addressing is approx. 5 minutes.

33-EN - **33** -

Group control for system of multiple units

One remote controller can control maximum 8 indoor units as a group.

▼ Group control in single system



- For wiring procedure and wiring method of the individual line (identical refrigerant line) system, follow to "Electrical connection".
- Wiring between lines is performed in the following procedure.
 Connect the terminal block (A / B) of the indoor unit connected with a remote controller to the terminal blocks (A / B) of the indoor units of other indoor units by wiring the inter-unit wire of the remote controller.
- When the power supply has been turned on, the automatic address setup starts and which indicates
 that address is being set up flashes on the display part in about 3 minutes. During setup of automatic
 address, the remote controller operation is not accepted.


Required time up to the finish of automatic addressing is approx. 5 minutes.

NOTE

In some cases, it is necessary to change the address manually after setup of the automatic address according to the system configuration of the group control.

• The follow mentioned system configuration is a case when complex systems in which systems of the simultaneous twin and simultaneous triple unit is controlled as a group by a remote controller.

(Example) Group control for complex system



The above address is set by the automatic addressing when the power is turned on. However, line addresses and indoor addresses are set randomly. For this reason, change the setting to match line addresses with indoor addresses.


ΕN

- 34 - 34-EN

[Procedure example]

Manual address setup procedure

While the operation stops, change the setup. (Stop the operation of the unit.)



- **1** Push [\equiv Menu] to open the "Menu".
- - → Push and hold 4 seconds.
- 4 Push [] and [] to select "Indoor unit", and the push [Set/Fix].
 - → "Indoor unit" was selected, the fans and louvres of the indoor units operate.

<Line (system) address>

- Push [<] to black highlight the code (DN), and then push [^] and [✓] to set the code number to 12.</p>
- Push [>] to black highlight the data, and then push [^] and [<] to set a system address.</p>

(Match the address with the address on the interface P.C. Board of the header outdoor unit in the same refrigerant line.)

- 7 After finishing setting the data of the code (DN), push [Set/Fix].
 - → "Continue?" is displayed.

<Indoor unit address>

- 8 To set the data of Indoor unit address, push [Set/Fix].
- 9 Push [<] to black highlight the code (DN), and then push [↑] and [∨] to set the code number to 13.
- 10 Push [>] to black highlight the data, and then push [↑] and [∨] to set a Indoor unit address.
- 11 After finishing setting the data of the code (DN), push [Set/Fix].
 - → "Continue?" is displayed.

<Group address>

- 12 To set the data of Indoor unit address, push [Set/Fix].
- 13 Push [] to black highlight the code (DN), and then push [] and [] to set the code number to 14.
- 14 Push [>] to black highlight the data, and then push [^] and [<] to set a group address.</p>
 If the indoor unit is individual, set the address to 0000; header unit, 0001; follower unit, 0002.

Individual : 0000
Header unit : 0001
Follower unit : 0002

In case of group control

15 After finishing setting the data of the code.

(DN), push [Set/Fix].

→ "Continue?" is displayed.

35-EN - **35** -

16 To not do other settings, push [☐ Return].

- → If the "Indoor unit" or "Outdoor unit" selection screen is displayed before " \(\sum \)" is displayed, push [\(\sum \) Return].
- \rightarrow " Ξ " appears while data is changing.
- → The changes are fixed, and the "Field setting menu" screen returns.


■ Central control system

Air conditioners at multiple locations can be controlled individually for each refrigeration system from a control room.

Central control is not available with the supplied wireless remote controller. Use the optional wired remote controller.

▼ Wiring for central control

The terminal block for central control wiring ($(\cline{\beta}_3)$ and $(\cline{\beta}_4)$) is the same as that for optional wired remote controller. Connect the central control wire to the terminals ($(\cline{\beta}_3)$ and $(\cline{\beta}_4)$) on the terminal block in the same way as the optional wired remote controller. For details, refer to the Installation Manual of the applicable central control system.




ΕN

- 36 - 36-EN

▼ Centrally control the system by the SDI series on their own setting for the terminating resistor is required.


- · Use switch SW01 for the setting.
- · Make the terminating resistor setting only for the indoor unit with the smallest line address number.




37-EN - **37** -

How to set the SW01

- **1** Remove the front panel.
 - Before removing the front panel, direct the horizontal louver to the direction shown in the figure below.
 - Remove the screws securing the front panel, and detach it from the indoor unit.
- 2 Remove the earth wire, TC sensor, TCJ sensor motor lead (louver motor, fan motor).
- 3 Remove the screws and detach the electrical control box.



4 Remove the electrical control box cover and set bit1 of SW01 on the board to ON. (Do not touch SW02 as it is used for other setting.)



5 Assemble the removed parts by reversing steps 1 to 3.

Insert the sensors and motor lead (louver motor, fan motor) into the original positions.



Connect the sensor and the motor lead certainly back to the previous position. If they are not properly connected, the system will not operate or other errors may occur.


ΕN

– 38 – 38-EN

▼ Centrally control the system by connecting to the TCC-LINK central control system.

Setting central control addresses

When air conditioners of the SDI, DI series are connected to the TCC-LINK central control system for central control using this product, set the addresses of indoor units using the following procedure.



39-EN - **39** -

12 TEST RUN

■ Before test run

- Before turning on the circuit breaker, carry out the following procedure.
 - 1) By using 500 V-megger, check that resistance of 1 M Ω or more exists between the terminal block L1 to L2 and the ground (grounding). If resistance of less than 1 M Ω is detected, do not run the unit.
 - 2) Check the valve of the outdoor unit being opened fully.
- To protect the compressor at activation time, leave power-ON for 12 hours or more be for operating.
- Before starting a test run, be sure to set addresses following the Installation Manual supplied with the outdoor unit.

■ Execute a test run

Operate the unit with the remote control as usual. For the procedure of the operation, refer to the attached Owner's Manual to the outdoor unit. A forced test run can be executed in the following procedure even if the operation stops by thermostat -OFF.

In order to prevent a serial operation, the forced test run is released after 60 minutes have passed and returns to the usual operation.



 Do not use the forced test run for cases other than the test run because it applies an excessive load to the devices.

Wired remote control



- 1 Push [Menu] to open the "Menu"
- 2 Push and hold [Menu] and [□] at the same time to open "Field setting menu"
 - → Push and hold 4 seconds.




- In the "Field setting menu" screen, push [⋈] and [⋈] to select "Test mode", and then push [□ Set/Fix]
 - → Test mode is set, and returns to the "Field setting menu" screen. Push the [☐ Return] button 2 times, to open screen (2).

ΕN

- 40 - 40-EN







4 Push [ON/OFF ON/OFF]

- → Operation starts, and in test mode screen (1) opens.
 - (While stopped, it is screen (2))
- → Test mode is done while the operating mode is set to "Cool" or "Heat".
- → The temperature cannot be set in test mode.
- → Check codes are displayed in the normal way.
- 5 After completing test mode, in the "Field setting menu" screen, push [▶] and [▶] to select "Test mode", and then push [Set/Fix]
 - → Screen (3) appears.
 - → Push [□ Set/Fix] to end test mode and do normal operation.

NOTE

Test mode ends 60 minutes after test mode was started, and the main screen returns.


In case of wireless remote controller (Forced test operation is performed in a different way)

REQUIREMENT

- For the operation procedure, be sure to follow the Owner's Manual.
- Finish the forced cooling operation in a short time because it applies excessive strength to the air conditioner.
- A test operation of forced heating is unavailable. Perform a test operation by heating operation using the switches of the remote controller.
 However heating operation may be not
 - However heating operation may be not carried out according to the temperature conditions.

Check wiring/piping of indoor and outdoor units

- When pushing [RESET] button for 10 seconds or more, "Pi!" sound is heard and the operation changes to a forced cooling operation. After approx. 3 minutes, a cooling operation starts forcedly. Check cool air starts blowing. If the operation does not start, check wiring again.
- 2. To stop a test operation, push [RESET] button once again (Approx. 1 second). The louver closes and the operation stops.
 - Check wiring/piping of the indoor and outdoor units in forced cooling operation.



· Check transmission of remote controller

- Push "START/STOP" button of the remote controller to check an operation can also start by the remote controller.
 - "Cooling" operation by the remote controller may be unavailable according to the temperature conditions.

41-EN - 41 -

13 MAINTENANCE

◆ Daily maintenance


Cleaning of air filter

If mathred ma

- 1 Push the button to stop the operation, then turn off the circuit breaker.

 After the cooling or dry operation, the ventilation fan keeps running for self-cleaning. Push the button twice to stop the operation.
- 2 Take out the air filter
 - Open the air intake grille until it stops, and slightly raise the hook on the lower centre of the air filter.

The air intake grille should not be opened further; otherwise, the arms may come off and the air intake grille may fall down.



- 3 Cleaning with water or vacuum cleaner
 - If dirt is heavy, clean the air filter by tepid water with neutral detergent or water.
 - After cleaning with water, dry the air filter sufficiently in a shade place.

- 4 Mount the air filter
- Turn on the circuit breaker, then push the button on the remote controller to start the operation.
- 6 After cleaning, perform "Filter Sign Reset".



Do not start the air conditioner while leaving air filter removed.

▼ Filter sign reset





If the air conditioners are operated while "■!"
is displayed, then "Filter check." is displayed.
Push an operation button while it is displayed
or leave it for at least 5 seconds and the display
will disappear.

When the filter check mark is displayed (filter check reset)



- 1 In "Menu", select "Filter sign reset", and push [□ Set/Fix]
- **2** Push [□ Set/Fix]

ΕN

- 42 - 42-EN



- Do not start the air conditioner while leaving air filter removed.
- Push the filter reset button. (Imindication will be turn off.)

◆ Periodic maintenance

For environmental conservation, it is strongly recommended that the indoor and outdoor units of the air conditioner in use be cleaned and maintained regularly to ensure efficient operation of the air conditioner. When the air conditioner is operated for a long time, periodic maintenance (once a year) is recommended. Furthermore, regularly check the outdoor unit for rust and scratches, and remove them or apply rustproof treatment, if necessary.

As a general rule, when an indoor unit is operated for 8 hours or more daily, clean the indoor unit and outdoor unit at least once every 3 months. Ask a professional for this cleaning / maintenance work. Such maintenance can extend the life of the product though it involves the owner's expense. Failure to clean the indoor and outdoor units regularly will result in poor performance, freezing, water leakage, and even compressor failure.

Inspection before maintenance

Following inspection must be carried out by a qualified installer or qualified service person.

Part	Inspection method
Heat exchanger	Access from inspection opening and remove the access panel. Examine the heat exchanger if there is any clogging or damages.
Fan motor	Access from inspection opening and check if any abnormal noise can be heard.
Fan	Access from inspection opening and remove the access panel. Examine the fan if there are any waggles, damages or adhesive dust.
Filter	Go to installed location and check if there are any stains or breaks on the filter.
Drain pan	Access from inspection opening and remove the access panel. Check if there is any clogging or drain water is polluted.


▼ Maintenance List

Part	Unit	Check (visual / auditory)	Maintenance
Heat exchanger	Indoor / outdoor	Dust / dirt clogging, scratches	Wash the heat exchanger when it is clogged.
Fan motor	Indoor / outdoor	Sound	Take appropriate measures when abnormal sound is generated.
Filter	Indoor	Dust / dirt, breakage	Wash the filter with water when it is contaminated. Replace it when it is damaged.
Fan	Indoor	Vibration, balance Dust / dirt, appearance	Replace the fan when vibration or balance is terrible. Brush or wash the fan when it is contaminated.
Air intake / discharge grilles	Indoor / outdoor	Dust / dirt, scratches	Fix or replace them when they are deformed or damaged.
Drain pan	Indoor	Dust / dirt clogging, drain contamination	Clean the drain pan and check the downward slope for smooth drainage.
Ornamental panel, louvers	Indoor	Dust / dirt, scratches	Wash them when they are contaminated or apply repair coating.
Exterior	Outdoor	• Rust, peeling of insulator • Peeling / lift of coat	Apply repair coating.

43-EN - 43 -

14 TROUBLESHOOTING

Confirm and check



When a trouble occurs in the air conditioner, the check code and the indoor unit number flash on the display of the remote control.

* The check code is only displayed during the operation.

When the check code and indoor unit number are displayed, pushing [Return] opens the "Check" screen.



In the "Check" screen, push [\square Set/Fix] to show the contacts.

Push [Menu] to display "Model information".

■ Contact information for repairs

You can look for contact information for repairs.



In the "Information" screen, push [⋈] and [⋈] to select "Service information", and then push [□ Set/Fix]

ΕN

- 44 - 44-EN



- Do not start the air conditioner while leaving air filter removed.
- Push the filter reset button. (Imindication will be turn off.)

◆ Periodic maintenance

For environmental conservation, it is strongly recommended that the indoor and outdoor units of the air conditioner in use be cleaned and maintained regularly to ensure efficient operation of the air conditioner. When the air conditioner is operated for a long time, periodic maintenance (once a year) is recommended. Furthermore, regularly check the outdoor unit for rust and scratches, and remove them or apply rustproof treatment, if necessary.

As a general rule, when an indoor unit is operated for 8 hours or more daily, clean the indoor unit and outdoor unit at least once every 3 months. Ask a professional for this cleaning / maintenance work. Such maintenance can extend the life of the product though it involves the owner's expense. Failure to clean the indoor and outdoor units regularly will result in poor performance, freezing, water leakage, and even compressor failure.

Inspection before maintenance

Following inspection must be carried out by a qualified installer or qualified service person.

Part	Inspection method
Heat exchanger	Access from inspection opening and remove the access panel. Examine the heat exchanger if there is any clogging or damages.
Fan motor	Access from inspection opening and check if any abnormal noise can be heard.
Fan	Access from inspection opening and remove the access panel. Examine the fan if there are any waggles, damages or adhesive dust.
Filter	Go to installed location and check if there are any stains or breaks on the filter.
Drain pan	Access from inspection opening and remove the access panel. Check if there is any clogging or drain water is polluted.

▼ Maintenance List

Part	Unit	Check (visual / auditory)	Maintenance
Heat exchanger	Indoor / outdoor	Dust / dirt clogging, scratches	Wash the heat exchanger when it is clogged.
Fan motor	Indoor / outdoor	Sound	Take appropriate measures when abnormal sound is generated.
Filter	Indoor	Dust / dirt, breakage	Wash the filter with water when it is contaminated. Replace it when it is damaged.
Fan	Indoor	Vibration, balance Dust / dirt, appearance	Replace the fan when vibration or balance is terrible. Brush or wash the fan when it is contaminated.
Air intake / discharge grilles	Indoor / outdoor	Dust / dirt, scratches	Fix or replace them when they are deformed or damaged.
Drain pan	Indoor	Dust / dirt clogging, drain contamination	Clean the drain pan and check the downward slope for smooth drainage.
Ornamental panel, louvers	Indoor	Dust / dirt, scratches	Wash them when they are contaminated or apply repair coating.
Exterior	Outdoor	• Rust, peeling of insulator • Peeling / lift of coat	Apply repair coating.

45-EN - 45 -

■ Error codes and parts to be checked

Wired remote controller display	Wireless remote controller Sensor block display of receiving unit		splay of	Main defective parts	Judging	Parts to be checked / error description	Air conditioner	
Indication	Operation Rea GR GF	dy	Flashing		device		status	
E01	o •	•		No header remote controller	Remote controller	Incorrect remote controller setting The header remote controller has not been set (including two remote controllers).	*	
				Remote controller communication error	Controller	No signal can be received from the indoor unit.		
E02	© •	•		Remote controller transmission error	Remote controller	System interconnection wires, indoor P.C. Board, remote controller No signal can be sent to the indoor unit.	*	
E03	o •	•		Indoor unit-remote controller regular communication error	Indoor	Remote controller, network adapter, indoor P.C. Board No data is received from the remote controller or network adapter.	Auto-reset	
E04) (0)		Indoor unit-outdoor unit serial communication error	Indoor	System interconnection wires, indoor P.C. Board, outdoor P.C. Board Serial	Auto-reset	
				IPDU-CDB communication error		communication error between indoor unit and outdoor unit		
E08	© •	•		Duplicated indoor addresses ★	Indoor	door Indoor address setting error The same address as the self-address was detected.		
E09	© • •			Duplicated header	Remote	Remote controller address setting error Two remote controllers are set as header in the double-remote controller control.	*	
				remote controllers	controller	(* The header indoor unit stops raising alarm and follower indoor units continue to operate.)		
E10	© •	•		CPU-CPU communication error	Indoor	Indoor P.C. Board Communication error between main MCU and motor microcomputer MCU.	Auto-reset	
E18	© •	•		Header unit follower unit regular communication error	Indoor	Indoor P.C. Board Regular communication is not possible between header and follower indoor units or between twin header (main) and follower (sub) units.	Auto-reset	
E31	• •	0		IPDU communication error	Outdoor	Communication error between IPDU and CDB.	Entire stop	
F01	0 0	•	ALT	Indoor unit heat exchanger sensor (TCJ) error	Indoor	Heat exchanger sensor (TCJ), indoor P.C. Board Open-circuit or short-circuit of the heat exchanger sensor (TCJ) was detected.	Auto-reset	
F02	0 0	•	ALT	Indoor unit heat exchanger sensor (TC) error	Indoor	Heat exchanger sensor (TC), indoor P.C. Board Open-circuit or short-circuit of the heat exchanger sensor (TC) was detected.	Auto-reset	
F04	0 0	0	ALT	Outdoor unit discharge temp. sensor (TD) error	Outdoor	Outdoor temp. sensor (TD), outdoor P.C. Board Open-circuit or short-circuit of the discharge temp. sensor was detected.	Entire stop	
F06	0 0	0	ALT	Outdoor unit temp. sensor (TE / TS) error	Outdoor	Outdoor temp. sensors (TE / TS), outdoor P.C. Board Open-circuit or short-circuit of the heat exchanger temp. sensor was detected.	Entire stop	
F07	0 0	0	ALT	TL sensor error	Outdoor	TL sensor may be displaced, disconnected or short-circuited.	Entire stop	
F08	0 0	0	ALT	Outdoor unit outside air temp. sensor error	Outdoor	Outdoor temp. sensor (TO), outdoor P.C. Board Open-circuit or short-circuit of the outdoor air temp. sensor was detected.	Operation continued	

EN

- 46 - 46-EN

Wired remote controller display	Wireless remote controller Sensor block display of receiving unit Operation Timer Ready GR GR OR Flashing		ote Sen		splay of	Main defective parts	Judging	Parts to be checked / error description	Air conditioner	
Indication			Flashing	device			status			
F10	0	0	•	ALT	Indoor unit room temp. sensor (TA) error Indoor unit room temp. Indoor Board Open-circuit or short-circuit of the room temp. sensor (TA) was detected.		Auto-reset			
F12	0	0	0	ALT	TS sensor error	Outdoor	TS sensor may be displaced, disconnected or short-circuited.	Entire-stop		
F13	0	0	0	ALT	Heat sink sensor error	Outdoor	Abnormal temperature was detected by the temp. sensor of the IGBT heat sink.	Entire stop		
F15	0	0	0	ALT	Temp. sensor connection error	Outdoor	Temp. sensor (TE / TS) may be connected incorrectly.	Entire stop		
F29	0	0	•	SIM	Indoor unit, other P.C. Board error	Indoor	Indoor P.C. Board EEPROM error.	Auto-reset		
F31	0	0	0	SIM	Outdoor unit P.C. Board	Outdoor	Outdoor P.C. Board In the case of EEPROM error.	Entire stop		
H01	•	0	•		Outdoor unit compressor breakdown	Outdoor	Current detect circuit, power voltage Minimum frequency was reached in the current releasing control or short-circuit current (ldc) after direct excitation was detected.	Entire stop		
H02	•	0	•		Outdoor unit compressor lock	Outdoor	Compressor circuit Compressor lock was detected.	Entire stop		
H03	•	0	•		Outdoor unit current detect circuit error	Outdoor	Current detect circuit, outdoor unit P.C. Board Abnormal current was detected in AC-CT or a phase loss was detected.	Entire stop		
H04	•	0	•		Case thermostat operation	Outdoor	Malfunction of the case thermostat	Entire stop		
H06	•	0	•		Outdoor unit low-pressure system error	Outdoor	Current, high-pressure switch circuit, outdoor P.C. Board Pressure sensor error was detected or low-pressure protective operation was activated.	Entire stop		
L03	0	•	0	SIM	Duplicated header indoor units ★	Indoor	Indoor address setting error There are two or more header units in the group.	Entire stop		
L07	0	•	0	SIM	Group line in individual indoor unit ★	Indoor	Indoor address setting error There is at least one group-connected indoor unit among individual indoor units.	Entire stop		
L08	0	•	0	SIM	Indoor group address not set ★	Indoor	Indoor address setting error Indoor address group has not been set.	Entire stop		
L09	0	•	0	SIM	Indoor unit capacity not set	Indoor	Indoor unit capacity has not been set.	Entire stop		
L10	0	0	0	SIM	Outdoor unit P.C. Board	Outdoor	In the case of outdoor P.C. Board jumper wire (for service) setting error.	Entire stop		
L20	0	0	0	SIM	LAN communication error	Network adapter central control	Address setting, central control remote controller, network adapter Duplication of address in central control communication.	Auto-reset		
							Other outdoor unit error.	Entire stop		
L29	0	0	0	0	0	SIM	Other outdoor unit error	Outdoor	Communication error between IPDU MCU and CDB MCU.	Entire stop
							Abnormal temperature was detected by the heat sink temp. sensor in IGBT.	Littile Stop		
L30	0	0	0	SIM	Abnormal external input into indoor unit (interlock)	Indoor	External devices, outdoor unit P.C. Board Abnormal stop due to incorrect external input into CN80.	Entire stop		
L31	0	0	0	SIM	Phase sequence error, etc.	Outdoor	Power supply phase sequence, outdoor unit P.C. Board Abnormal phase sequence of the 3-phase power supply.	Operation continued (thermostat OFF)		

47-EN **- 47 -**

Wired remote controller display	Wireless remote controller Sensor block display of receiving unit Operation Timer Ready GR GR OR Flashing		splay of	Main defective parts	Judging device	Parts to be checked / error description	Air conditioner	
Indication			Flashing				Status	
P01	•	0	0	ALT	Indoor unit fan error	Indoor	Indoor fan motor, indoor P.C. Board Indoor AC fan error (fan motor thermal relay activated) was detected.	Entire stop
P03	0	•	0	ALT	Outdoor unit discharge temp. error	Outdoor	An error was detected in the discharge temp. releasing control.	Entire stop
P04	0	•	0	ALT	Outdoor unit high-pressure system error	Outdoor	High-pressure switch The IOL was activated or an error was detected in the high-pressure releasing control using the TE.	Entire stop
P05	0	•	0	ALT	Open phase detected	Outdoor	The power wire may be connected incorrectly. Check open phase and voltages of the power supply.	Entire stop
P07	0	•	0	ALT	Heat sink overheat	Outdoor	Abnormal temperature was detected by the temp. sensor of the IGBT heat sink.	Entire stop
P10	•	©	0	ALT	Indoor unit water overflow detected	Indoor	Drain pipe, clogging of drainage, float switch circuit, indoor P.C. Board Drainage is out of order or the float switch was activated.	Entire stop
P12	•	0	0	ALT	Abnormal operation of the fan of the indoor unit	Indoor	Abnormal operation of the indoor fan motor, indoor P.C. Board, or indoor DC fan (over current or lock, etc.) is detected.	Entire stop
P15	0	•	0	ALT	Gas leakage detected	Outdoor	There may be gas leakage from the pipe or connecting part. Check for gas leakage.	Entire stop
P19	0	•	0	ALT	4-way valve error	Outdoor (Indoor)	4-way valve, indoor temp. sensors (TC / TCJ) An error was detected due to temperature drop of the indoor unit heat exchanger sensor during heating.	Auto-reset
P20	0	•	0	ALT	High-pressure protective operation	Outdoor	High-pressure protection.	Entire stop
P22	0	•	©	ALT	Outdoor unit fan error	Outdoor	Outdoor unit fan motor, outdoor unit P.C. Board An error (overcurrent, locking, etc.) was detected in the outdoor unit fan drive circuit.	Entire stop
P26	0	•	0	ALT	Outdoor unit inverter ldc activated	Outdoor	IGBT, outdoor unit P.C. Board, inverter wiring, compressor Short-circuit protection for compressor drive circuit devices (G-Tr / IGBT) was activated.	Entire stop
P29	0	•	0	ALT	Outdoor unit position error	Outdoor	Outdoor unit P.C. Board, high-pressure switch Compressor motor position error was detected.	Entire stop
P31	0			ALT	Other indoor unit error	Indoor	Another indoor unit in the group is raising an alarm.	Entire stop
F31			U	ALI	Other indoor unit error	muuu	E03 / L07 / L03 / L08 alarm check locations and error description.	Auto-reset

O: Lighting ⊚: Flashing ●: OFF ★: The air conditioner automatically enters the auto-address setting mode.

ALT: When two LEDs are flashing, they flash alternately. SIM: When two LEDs are flashing, they flash in synchronization.

Receiving unit display OR: Orange GR: Green

ΕN

CARRIER AIR C	ONDITIONIN	G (THAILA	ND) CO., L	TD.
144/9 MOO 5, BANGKADI INDUSTRIAL PARK				

1130850104_EN-FR-ES.indb c2 4/21/2567 BE 17:30

1130850104