



Installation, Start-Up and Service Instructions

SAFETY CONSIDERATIONS

Installing, starting up, and servicing this equipment can be hazardous due to system pressures, electrical components, and equipment location.

Only trained, qualified installers and service mechanics should install, start up, and service this equipment.

Untrained personnel can perform basic maintenance functions, such as cleaning coils. All other operations should be performed by trained service personnel.

When working on the equipment, observe precautions in the literature, and on tags, stickers, and labels attached to the equipment.

- Follow all safety codes.
- Wear safety glasses and work gloves.
- Use care in handling, rigging, and setting bulky equipment.



ELECTRIC SHOCK HAZARD.

Open all remote disconnects before servicing this equipment.

IMPORTANT: This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with these instructions may cause radio interference. It has been tested and found to comply with the limits of a Class A computing device as defined by FCC (Federal Communications Commission, U.S.A.) regulations, Subpart J of Part 15, which are designed to provide reasonable protection against such interference when operated in a commercial environment.

CONTENTS

	Page		Page
SAFETY CONSIDERATIONS	1	Operation Sequence	56
INTRODUCTION	2	• LOAD SHED	
INSTALLATION	2-48	• TEMPERATURE RESET	
Step 1 — Rig and Place the Unit	2	• HEAD PRESSURE CONTROL	
Step 2 — Join Modules A and B		• REMOTE ON-OFF	
(230-420 Units Only)	30	• REMOTE ALARM	
Step 3 — Check Compressor Mounting	30	SERVICE	62-74
Step 4 — Cooler Fluid and Drain Piping		Diagnostics and Troubleshooting	62
Connections	30	Refrigerant Circuit	62
• PREPARATION FOR YEAR-ROUND OPERATION		• LEAK TESTING	
• PREPARATION FOR WINTER SHUTDOWN		• DEHYDRATION	
Step 5 — Make Electrical Connections	31	• REFRIGERANT CHARGE	
• FIELD POWER CONNECTIONS		Electronic Components	63
• FIELD CONTROL POWER CONNECTIONS		• CONTROL COMPONENTS	
Step 6 — Install Accessories	48	• 30GU040-110 AND 230B-315B UNIT	
• ELECTRICAL		CONTROL BOX	
• LOW-AMBIENT OPERATION		• 30GU130-210, 230A-315A, AND 330A/B-420A/B	
• HOT GAS BYPASS		UNIT CONTROL AND MAIN POWER BOXES	
• MISCELLANEOUS ACCESSORIES		Compressors	63
PRE-START-UP	49-54	• COMPRESSOR REMOVAL	
System Check	49	• OIL CHARGE	
Quick Test	49	Cooler	64
• A. QUICK TEST STEPS 1-15: UNIT CONFIGURATION		• COOLER REMOVAL	
• B. QUICK TEST STEPS 16-30: THERMISTORS		• REPLACING COOLER	
AND SET POINT POTENTIOMETERS		• SERVICING COOLER	
• C. QUICK TEST STEPS 31-42: OUTPUT RELAYS		Condenser Coils	67
START-UP AND OPERATION	54-62	• COIL CLEANING	
Digital Display Action	54	Condenser Fans	67
Actual Start-Up	55	Refrigerant Feed Components	67
Operating Limitations	55	• ELECTRONIC EXPANSION VALVE (EXV)	
• TEMPERATURES		• MOISTURE-LIQUID INDICATOR	
• VOLTAGE		• FILTER DRIER	
• MINIMUM FLUID LOOP VOLUME		• LIQUID LINE SOLENOID VALVE	
• FLOW RATE REQUIREMENTS		• LIQUID LINE SERVICE VALVE	

CONTENTS (cont)

Thermistors	Page 72
• LOCATION	
• TO REPLACE THERMISTOR T2 (Cooler)	
• TO REPLACE THERMISTORS T1, T5, T6, T7, AND T8	
• THERMISTORS T3 AND T4	
• THERMISTOR/TEMPERATURE SENSOR CHECK	
Safety Devices	73
• COMPRESSOR PROTECTION	
• LOW OIL PRESSURE PROTECTION	
• CRANKCASE HEATERS	
• COOLER PROTECTION	
Relief Devices	74
• HIGH-SIDE PROTECTION	
• LOW-SIDE PROTECTION	
• PRESSURE RELIEF VALVES	
Other Safeties	74
START-UP CHECKLIST	CL-1 to CL-4

INTRODUCTION

These instructions cover installation, start-up, and service of 30GU040-420 Flotronic™ liquid chillers with electronic controls.

Unit sizes 230-420 are modular units which are shipped in separate sections as modules A and B. Installation directions specific to these units are noted in these instructions. For modules 230B-315B, follow all general instructions as noted for unit sizes 080-110. For **all** remaining modules, follow instructions for unit sizes 130-210. See Table 1 for a listing of unit sizes and modular combinations.

Table 1 — Unit Sizes and Modular Combinations

UNIT MODEL 30GU	NOMINAL TONS	SECTION A UNIT 30GU	SECTION B UNIT 30GU
040	25	—	—
045	28	—	—
050	34	—	—
060	40	—	—
070	48	—	—
080	55	—	—
090	60	—	—
100	70	—	—
110	75	—	—
130	85	—	—
150	100	—	—
170	110	—	—
190	120	—	—
210	140	—	—
230	155	150	080
245	160	150	090
255	170	150	100
270	180	170	100
290	195	190	110
315	215	210	110
330	220	170	170
360	240/230*	190	190/170*
390	260	210	190
420	280	210	210

*60 Hz units/50 Hz units

Inspect the unit upon arrival for damage. If damage is found, file a claim right away with the shipping company. When considering location for the unit, be sure to consult National Electrical Code (NEC, U.S.A.) and local code requirements. Allow sufficient space for airflow, wiring, piping, and

service. See Fig. 1-6. See Fig. 7 for optional non-fused disconnect location on 130-210, 230A-315A, and 330A/B-420A/B units. Be sure surface beneath the unit is level, and is capable of supporting the operating weight of the unit. See Fig. 8-11 and Tables 2A-3B for unit mounting and operating weights.

NOTE: To facilitate refrigerant vent piping, unit sizes 130-210, 230A-315A, and 330A/B-420A/B will have fusible plugs with 3/8-in. SAE (Society of Automotive Engineers, U.S.A.) flares if required by local codes.

INSTALLATION

Step 1 — Rig and Place the Unit — These units are designed for overhead rigging and *it is important that this method be used*. Holes are provided in frame base channels, marked for rigging (see rigging label on unit). It is recommended that field-supplied 2-in. Schedule 40 steel pipes be passed through these holes, extending beyond frame enough to attach cables or chains on both sides for size 040-110 and 230B-315B units. All other units come with 6 lifting lugs. Use spreader bars to keep cables or chains clear of unit sides. As further protection for the coil faces, plywood sheets may be placed against sides of unit, behind cables or chains. Run cables or chains to a central suspension point so that angle from horizontal is not less than 45 degrees. Raise and set unit down carefully. See Fig. 8-11 for rigging centers of gravity.

⚠ CAUTION

1. Do not use forklift trucks on these units.
2. Modular (230-420) units **MUST** be rigged and placed as separate sections.

For shipping, some domestic units and all export units are mounted on a wooden skid under entire base of unit. Skid can be removed before unit is moved to installation site. *Lift the unit from above to remove skid*. See Fig. 8-11 for rigging centers of gravity. On export units, the top skid can be used as the spreader bars. If the unit is shipped with coil protection, it must be removed before start-up. The shipping bag for export units must be removed before start-up. On export units with a full crate, the crate sides must be removed to aid in rigging.


If overhead rigging is not available, the unit can be moved on rollers or dragged. When unit is moved on rollers, the unit skid, if equipped, must be removed. To lift the unit, use jacks at the rigging points. Use a minimum of 3 rollers to distribute the load. If the unit is to be dragged, lift the unit as described above, and place unit on a pad. *Apply moving force to the pad, and not the unit*. When in its final location, raise the unit and remove the pad.

Locate the unit so that the condenser airflow is unrestricted both above and on the sides of the unit. See Fig. 1-6 for required clearances. The unit may be mounted on a level pad directly on the base rails or on a raised perimeter rail around the unit. If unit is mounted on a raised perimeter rail, fasten the unit to the rail using the mounting holes provided.


NOTE: Once the unit is in place, check to be sure unit is level so that oil will equalize properly.

IMPORTANT: When placing unit modules for unit sizes 330-420, either end of module A can be placed next to either end of module B. When placing unit modules for unit sizes 230-315, make sure modules are placed to permit access to the control box located in module B.


Instructions continued on page 30.




TOP VIEW



SIDE VIEW



VIEW A-A
TOP VIEW OF CONTROL BOX SHELF
WITH FIELD POWER SUPPLY CONNECTIONS.



END VIEW

LEGEND

C — Copper Fins, Copper Tubing
Mtg — Mounting





NOTES:

- Unit must have clearances for airflow as follows:
TOP — Do not restrict in any way.
ENDS — [1524] 5 ft
SIDES — [1829] 6 ft
- 2.00" dia holes are recommended for parallel conductors on 040 and 045 (208/230 V) units
- 3/8" dia hole is recommended for single entry power on 050 (208/230 V) units.
- Mounting holes may be used to mount unit to concrete pad. They are not recommended for spring isolator location.
- If spring isolators are used, a perimeter support channel between the unit and the isolators is recommended.
- Dimensions in [] are millimeters.
- Thru-the-door handles for non-fused disconnect option on 380/415 v and 460 v units only. When unit has non-fused disconnect option, power-side door opens from right side, NOT left side as shown for standard units.

UNIT 30GU	FIELD POWER SUPPLY CONNECTIONS			
	Voltage	Hz	Diameter	Qty
040,045	208/230	60	3/8" [92.0]	1
050	208/230	60	2 1/2" [63.5]	2
040-050	460	60	2 1/2" [63.5]	1
040-050	575	60	2 1/2" [63.5]	1
040-050	380	60	2 1/2" [63.5]	1
040,045	346	50	2 1/2" [63.5]	1
050	346	50	3/8" [92.0]	1
040,045	380/415	50	2 1/2" [63.5]	1
050	380/415	50	3/8" [92.0]	1

UNIT 30GU	DIMENSIONS			
	"A"	"B"	"C"	"D"
040	3'-5 1/16" [1059]	3'-10 13/16" [1189]	4'-5 1/2" [1359]	1'-11 1/8" [587.5]
040C	3'-5 7/8" [1064]	3'-11" [1194]	4'-5 1/2" [1359]	1'-11 1/8" [587.5]
045	3'-6 1/16" [1069]	3'-10 13/16" [1189]	5'-5 1/2" [1663]	1'-5 9/16" [436.6]
045C	3'-6 3/16" [1072]	3'-11" [1194]	5'-5 1/2" [1663]	1'-5 9/16" [436.6]
050	3'-5 7/8" [1064]	3'-11" [1194]	5'-5 1/2" [1663]	1'-5 9/16" [436.6]
050C	3'-6" [1067]	3'-11 9/16" [1199]	5'-5 1/2" [1663]	1'-5 9/16" [436.6]

Fig. 1 — Dimensions, 30GU040-050



LEGEND

C — Copper Fins, Copper Tubing
Mtg — Mounting

NOTES:

- Dimensions in [] are millimeters.
- Unit must have clearances for airflow as follows:
TOP — Do not restrict in any way.
ENDS — [1524] 5 ft
SIDES — [1829] 6 ft
- Mounting holes may be used to mount unit to concrete pad. They are not recommended for spring isolator location
- If spring isolators are used, a perimeter support channel between the unit and the isolators is recommended.
- Thru-the-door handles for non-fused disconnect option on 380/415 v and 460 v units only. When unit has non-fused disconnect option, power-side door opens from right side, NOT left side as shown for standard units

UNIT 30GU	FIELD POWER SUPPLY CONNECTIONS			
	Voltage	Hz	Diameter	Qty
060	208/230	60	2 1/2" [63.5]	2
070	208/230	60	3 5/8" [92.0]	2
060	460	60	2 1/2" [63.5]	1
070	460	60	3 5/8" [92.0]	1
060,070	575	60	2 1/2" [63.5]	1
060,070	380	60	3 5/8" [92.0]	1
060,070	346	50	3 5/8" [92.0]	1
060,070	380/415	50	3 5/8" [92.0]	1

UNIT 30GU	DIMENSIONS	
	"A"	"B"
060	3'-6 7/8" [1090]	4'-10 5/16" [1481]
060C	3'-7" [1092]	4'-10 9/16" [1488]
070	3'-6" [1067]	4'-10 1/2" [1486]
070C	3'-6 3/16" [1072]	4'-10 7/8" [1496]


Fig. 2 — Dimensions, 30GU060,070

NOTES:


- Unit must have clearances for airflow (from solid surfaces) as follows:
Top — Do not restrict in any way
Ends — 5 ft [1524 mm]
Sides — 6 ft [1829 mm]
- Mounting holes may be used to mount unit to concrete pad. They are not recommended for spring isolator location
- If spring isolators are used, a perimeter support channel between the unit and the isolators is recommended
- Dimensions in [] are in millimeters
- Thru-the-door handles for non-fused disconnect option on 380/415 v and 460 v units only When unit has non-fused disconnect option, power-side door opens from right side, NOT left side as shown for standard units

CENTER OF GRAVITY
(ft-in.)


30GU UNIT SIZE	080,230B	090,245B
A	5-9 ⁹ / ₁₆ [1769]	5-7 ⁹ / ₁₆ [1710]
B	3-6 [1067]	3-2 ³ / ₄ [984]




VIEW A-A
TOP VIEW OF CONTROL BOX SHELF
WITH FIELD POWER SUPPLY CONNECTIONS



TOP VIEW



END VIEW



SIDE VIEW

Fig. 3 — Dimensions; 30GU080,090,230B,245B

NOTES:

- Unit must have clearances for airflow (from solid surfaces) as follows:
Top — Do not restrict in any way
Ends — 5 ft [1524 mm]
Sides — 6 ft [1829 mm]
- Mounting holes may be used to mount unit to concrete pad. They are not recommended for spring isolator location
- If spring isolators are used, a perimeter support channel between the unit and the isolators is recommended
- Dimensions in [] are in millimeters
- Thru-the-door handles for non-fused disconnect option on 380/415 v and 460 v units only. When unit has non-fused disconnect option, power-side door opens from right side, NOT left side as shown for standard units




Fig. 4 — Dimensions; 30GU100,110,255B-315B

DIMENSIONS (ft-in.)

30GU UNIT SIZE	A	B	C	D	E	F	G	H
190,290A,360A (50 Hz), 360A/B (60 Hz),390B	11-4 [3454]	4-2½ [1283]	1-5⅝ [448]	6- 37/16 [1916]	7-8¼ [2343]	8⅝ [219]	1- 9 [533.4]	6- 47/16 [1941.3]
210,315A, 390A,420A/B	11-3⅝ [3444]	4-2⅞ [1285]	1-67/16 [468]	5-11½ [1816]	8-2⅞ [2504]	9½ [242]	1-11 [584]	5-11½ [1816.2]

NOTES

- Unit must have clearances for airflow (from solid surfaces) as follows
Top — Do not restrict in any way
Ends — 5 ft [1524 mm]
Sides — 6 ft [1829 mm]
- Mounting holes may be used to mount unit to concrete pad. They are not recommended for spring isolator location
- If spring isolators are used, a perimeter support channel between the unit and the isolators is recommended
- Dimensions in [] are in millimeters








Fig. 6 — Dimensions; 30GU190,210,290A,315A,360A (50 Hz),360A/B (60 Hz),390A/B,420A/B



NON-FUSED DISCONNECT OPTION

Fig. 7 — Location of Optional Non-Fused Disconnect; 130-210 and 230A-315A, 330A/B-420A/B Units (130-170, 230A-270A, 330A/B, 360B 50 Hz Shown)



*Points A-D are in the corners of the unit. See Fig 1 and 2 for dimensions

60 Hz

30GU UNIT SIZE	CONDENSER COIL	LB				KG			
		A	B	C	D	A	B	C	D
040	C-AL	972	876	807	895	441	397	366	406
	C-C	1044	948	879	968	473	430	399	439
045	C-AL	999	895	845	943	453	406	383	428
	C-C	1071	967	917	1015	486	438	416	460
050	C-AL	1047	948	884	976	475	430	401	443
	C-C	1155	1057	992	1085	524	479	450	492
060	C-AL	1258	1130	1130	1113	570	512	505	562
	C-C	1362	1234	1217	1344	618	560	552	609
070	C-AL	1332	1212	1184	1301	604	550	537	590
	C-C	1489	1369	1340	1458	675	621	608	661

50 Hz

30GU UNIT SIZE	CONDENSER COIL	LB				KG			
		A	B	C	D	A	B	C	D
040	C-AL	992	886	808	904	450	402	366	410
	C-C	1064	959	880	976	482	435	399	443
045	C-AL	1065	934	812	925	483	424	368	420
	C-C	1137	1007	883	998	515	457	401	452
050	C-AL	1074	968	889	986	487	439	403	447
	C-C	1182	1076	997	1095	536	488	452	496
060	C-AL	1269	1151	1123	1238	575	522	509	561
	C-C	1373	1255	1227	1342	623	569	556	609
070	C-AL	1508	1369	1226	1350	684	621	556	612
	C-C	1664	1526	1383	1508	755	692	627	684


LEGEND

C-AL — Copper Tubing — Aluminum Fins
C-C — Copper Tubing — Copper Fins

RIGGING CENTER OF GRAVITY

30GU UNIT SIZE	040		045		050		060		070	
	in.	mm	in.	mm	in.	mm	in.	mm	in.	mm
X Dimension	46.8	1189	46.8	1189	47.0	1194	58.3	1481	58.5	1486
Y Dimension	41.7	1059	42.1	1069	41.9	1064	42.9	1090	42.0	1067

Fig. 8 — Unit Mounting Weights (Approximate); 30GU040-070



*Points A-D are in the corners of the unit. See Fig 3 and 4 for dimensions

60 Hz

30GU UNIT SIZE	CONDENSER COIL	LB				KG			
		A	B	C	D	A	B	C	D
080,230B	C-AL	1624	1690	1666	1650	738	768	757	750
	C-C	1797	1880	1847	1831	817	854	840	832
090,245B	C-AL	1817	1793	1720	1685	826	815	782	766
	C-C	1997	1970	1893	1880	908	895	860	855
100,255B,270B	C-AL	2185	2185	2120	2120	993	993	964	964
	C-C	2420	2420	2360	2360	1100	1100	1073	1073
110,290B,315B	C-AL	2191	2217	2136	2116	996	1007	970	962
	C-C	2428	2454	2374	2354	1104	1115	1079	1070

50 Hz

30GU UNIT SIZE	CONDENSER COIL	LB				KG			
		A	B	C	D	A	B	C	D
080,230B	C-AL	1650	1730	1680	1660	750	786	764	755
	C-C	1830	1910	1863	1842	832	868	847	837
090,245B	C-AL	1833	1864	1724	1714	833	847	784	779
	C-C	2014	2040	1907	1899	915	927	867	863
100,255B,270B	C-AL	2222	2222	2133	2133	1010	1010	970	970
	C-C	2460	2460	2370	2370	1118	1118	1077	1077
110,290B,315B	C-AL	2271	2271	2149	2149	1032	1032	976	976
	C-C	2508	2508	2387	2387	1140	1140	1085	1085


LEGEND

C-AL — Copper Tubing — Aluminum Fins
C-C — Copper Tubing — Copper Fins

RIGGING CENTER OF GRAVITY

30GU UNIT SIZE	080,230B		090,245B		100,110,255B-315B	
	in.	mm	in.	mm	in.	mm
X Dimension	69 6	1768	67.3	1710	87 8	2229
Y Dimension	42 0	1067	38.8	984	40 0	1016

Fig. 9 — Unit Mounting Weights (Approximate) 30GU080-110 and 230B-315B



60 Hz

30GU UNIT SIZE	CONDENSER COIL	LB							
		A	B	C	D	E	F	G	H
130	C-AL	923	1466	1156	825	1411	1365	1469	1439
	C-C	1051	1593	1283	952	1601	1556	1659	1622
150,230A-255A	C-AL	926	1563	1160	834	1438	1375	1747	1438
	C-C	1053	1690	1287	961	1628	1566	1938	1629
170,270A,330A/B	C-AL	962	1732	1333	862	1497	1629	1816	1462
	C-C	1089	1860	1460	990	1688	1819	2007	1653
190,290A,360A/B,390B	C-AL	1346	1942	1793	1111	1385	1799	1733	1567
	C-C	1536	2132	1983	1301	1575	1989	1923	1757
210,315A,390A,420A/B	C-AL	1376	2128	1871	1120	1407	1846	2037	1595
	C-C	1566	2318	2061	1310	1597	2036	2227	1784

60 Hz

30GU UNIT SIZE	CONDENSER COIL	KG							
		A	B	C	D	E	F	G	H
130	C-AL	419	666	525	375	641	620	668	650
	C-C	478	723	583	433	728	707	754	737
150,230A-255A	C-AL	420	710	527	379	653	625	794	653
	C-C	478	768	585	436	285	711	880	740
170,270A,330A/B	C-AL	437	787	605	392	680	740	825	664
	C-C	495	845	663	450	767	826	912	751
190,290A,360A/B,390B	C-AL	611	882	815	505	629	817	787	712
	C-C	698	969	901	591	715	904	874	798
210,315A,390A,420A/B	C-AL	625	967	850	509	639	384	925	725
	C-C	711	1053	937	595	725	925	1012	810

LEGEND

C-AL — Copper Tubing — Aluminum Fins
C-C — Copper Tubing — Copper Fins


*And associated modules

NOTE: Dimensions in () are in millimeters

RIGGING CENTER OF GRAVITY

UNIT 30GU SIZE	130		150,230A-255A		170,270A,330A/B		190,290A,360A/B,390B		210,315A,390A,420A/B	
	in.	mm	in.	mm	in.	mm	in.	mm	in.	mm
X Dimension	112 5	2858	112.1	2849	112 8	2865	136.0	3454	135.6	3444
Y Dimension	49.9	1267	50 5	1283	50.5	1283	50 5	1283	50 6	1285

Fig. 10 — Unit Mounting Weights (Approximate); 30GU130-210, 230A-315A, 330A/B-420A/B (60 Hz)



50 Hz

30GU UNIT SIZE	CONDENSER COIL	LB							
		A	B	C	D	E	F	G	H
130	C-AL	928	1569	1160	834	1438	1375	1764	1444
	C-C	1056	1696	1287	961	1628	1566	1954	1635
150,230A-255A	C-AL	948	1591	1160	834	1438	1375	1829	1502
	C-C	1075	1719	1287	961	1628	1566	2020	1692
170,270A,330A/B,360B	C-AL	963	1744	1348	873	1527	1673	1849	1466
	C-C	1090	1871	1475	1000	1718	1864	2040	1657
190,290A,360A,390B	C-AL	1365	1953	1807	1127	1430	1839	1765	1621
	C-C	1555	2143	1997	1316	1620	2029	1955	1811
210,315A,390A,420A/B	C-AL	1383	2151	1876	1128	1430	1860	2102	1615
	C-C	1573	2341	2066	1318	1620	2050	2292	1805

50 Hz

30GU UNIT SIZE	CONDENSER COIL	KG							
		A	B	C	D	E	F	G	H
130	C-AL	422	714	527	379	654	625	802	656
	C-C	480	770	585	436	740	711	888	743
150,230A-255A	C-AL	430	723	527	379	653	625	831	682
	C-C	486	781	585	437	740	711	918	769
170,270A,330A/B,360B	C-AL	437	792	612	397	694	760	840	666
	C-C	495	850	670	454	780	847	927	753
190,290A,360A,390B	C-AL	620	887	821	512	650	835	802	736
	C-C	707	974	907	598	736	922	977	823
210,315A,390A,420A/B	C-AL	628	977	852	512	650	845	955	734
	C-C	715	1064	940	599	736	931	1042	820

LEGEND

C-AL — Copper Tubing — Aluminum Fins
C-C — Copper Tubing — Copper Fins

*And associated modules

NOTE: Dimensions in () are in millimeters

RIGGING CENTER OF GRAVITY

30GU UNIT SIZE	130		150,230A-255A		170,270A, 330A/B,360B		190,290A, 360A,390B		210,315A,390A, 420A/B	
	in.	mm	in.	mm	in.	mm	in.	mm	in.	mm
X Dimension	112.5	2858	112.1	2849	112.8	2865	136.0	3454	135.6	3444
Y Dimension	49.9	1267	50.5	1283	50.5	1283	50.5	1283	50.6	1285

Fig. 11 — Unit Mounting Weights (Approximate); 30GU130-210, 230A-315A, 330A/B-420A/B (50 Hz)

Table 2A — Physical Data — 60 Hz, English

30GU UNIT SIZE	040	045	050	060	070	080	090	100	110
SYSTEM MODULES									
APPROX OPERATING WEIGHT — lb									
C-AL	3550	3681	3856	4740	5028	6630	7015	8610	8660
C-C	3938	3969	4289	5157	5656	7355	7740	9560	9610
REFRIGERANT CHARGE — lb									
R-134a Ckt A Total/Over Clear Glass Ckt B	53/16 60/15	53/16 60/15	68/17 79/16	67/19 76/21	96/20 96/20	102/20 102/20	102/20 102/20	129/25 129/25	129/25 129/25
COMPRESSORS, Type...rpm									
06E* (Qty) Ckt A	(1) 150	(1) 150	(1) 165	(1) 175	(1) 199	(1) 175, (1) 150	(1) 165, (1) 150	(1) 165, (1) 175	(1) 165, (1) 199
(Qty) Ckt B	(1) 150	(1) 165	(1) 175	(1) 199	(1) 199	(1) 199	(2) 165	(1) 165, (1) 175	(1) 165, (1) 175
Oil Charge — Compressor/pt									
Capacity Control Steps (Standard Unit)									
% Cap. Ckt A	4	4	4	4	4	6	8	8	8
Ckt B	50	42	48	43	50	56	47	50	54
Minimum Step Capacity (%)	50	58	52	57	50	44	53	46	46
Ckt B	25	21	32	29	33	22	18	15	14
CONDENSER FANS — Type									
Standard/Low Noise									
Fan Speed — rpm									
No. Blades...Diameter — in.									
No. Fans...Total kW									
Total Airflow — cfm									
High Static									
Fan Speed — rpm									
No. Blades...Diameter — in.									
No. Fans...Total kW									
Total Airflow...cfm**									
CONDENSER COILS — Type									
Tubes (Copper), OD — in.									
No. Rows — Ckt A or B									
Face Area sq ft — Ckt A and B Total									
Max Working Pressure Refrigerant — psig									
COOLER — No. ...Type									
Weight (empty) — lb									
No. Refrigerant Circuits									
Net Fluid Volume — Gal. (includes nozzles)									
Max Working Pressure									
Refrigerant Side/Fluid Side — psig									
FLUID CONNECTIONS — in.									
Inlet and Outlet									
Drain (NPT)									

LEGEND

C-AL — Copper Tubing — Aluminum Fins Condenser Coil
C-C — Copper Tubing — Copper Fins Condenser Coil
Ckt — Circuit
ESP — External Static Pressure
OD — Outside Diameter

*06E150 compressors have 4 cylinders; all others have 6.

†Recommended oil is an ISO (International Standards Organization) viscosity grade 68, inhibited polyolester-based (POE), synthetic compressor oil.

**Based on rated ESP of 0.4 in. wg or 1.0 in. wg as appropriate.

NOTE: When facing the compressors, Circuit A is on the right and Circuit B is on the left.

Table 2A — Physical Data — 60 Hz, English (cont)

30GU UNIT SIZE												
SYSTEM MODULES												
	130	150	170	190	210	230			245			
						A	B	Total	A	B	Total	
APPROX OPERATING WEIGHT — lb												
C-AL	10,046	10,481	11,293	12,676	13,380	10,481	6630	17,111	10,481	7015	17,496	
C-C	11,318	11,753	12,565	14,195	14,899	11,753	7355	19,108	11,753	7740	19,493	
REFRIGERANT CHARGE — lb												
R-134a	162/33.5	162/39	162/46	190/32	190/40	162/39	102/20	—/—	162/39	102/20	—/—	
Ckt A Total/Over Clear Glass	162/33.5	162/39	162/46	190/32	190/40	162/39	102/20	—/—	162/39	102/20	—/—	
Ckt B												
COMPRESSORS, Type...rpm	Reciprocating, Semi-Hermetic...1750											
08E* (Qty) Ckt A	(1) 175, (1) 199	(3) 165	(3) 175	(1) 165, (1) 175, (1) 199	(3) 165, (1) 175	(3) 165	(1) 150, (1) 175	—	(3) 165	(1) 165, (1) 150	—	
(Qty) Ckt B	(1) 175, (1) 199	(2) 199	(3) 175	(1) 165 (1) 175, (1) 199	(1) 175, (2) 199	(2) 199	(1) 199	—	(2) 199	(2) 165	—	
Oil Charge — Compressor/pt	150/17, 165/19, 175/19, 199/19											
Capacity Control Steps (Standard Unit)	8	10	12	6	7	10	6	—	10	8	—	
% Cap. Ckt A	50	50	50	50	50	50	56	—	50	47	—	
Ckt B	50	50	50	50	50	50	44	—	50	53	—	
Minimum Step Capacity (%)	14	11	11	14	12	11	22	—	11	18	—	
CONDENSER FANS — Type	Propeller, Direct Drive											
Standard/Low Noise	1140	1140	1140	1140	1740	1140	1140	—	1140	1140	—	
Fan Speed — rpm	4...30	4...30	4...30	4...30	4...30	4...30	4...30	—	4...30	4...30	—	
No. Blades...Diameter — in.	10...15.9	10...15.9	10...15.9	12...19.1	12...19.1	10...15.9	6...9.4	16...25.3	10...15.9	6...9.4	16...25.3	
No. Fans...Total kW	100,000	100,000	100,000	120,000	120,000	100,000	57,000	157,000	100,000	57,000	157,000	
Total Airflow — cfm												
High Static	1740	1740	1740	1740	1740	1740	1750	—	1740	1750	—	
Fan Speed — rpm	12...30	12...30	12...30	12...30	12...30	12...30	12...30	—	12...30	12...30	—	
No. Blades...Diameter — in.	10...37.0	10...37.0	10...37.0	12...44.4	12...44.4	10...37.0	6...22.2	16...59.2	10...37.0	6...22.2	16...59.2	
No. Fans...Total kW	100,000	100,000	100,000	120,000	120,000	100,000	60,000	160,000	100,000	60,000	160,000	
Total Airflow...cfm**												
CONDENSER COILS — Type	Vertical and Horizontal, Plate Fin, Enhanced Tubing											
Tubes (Copper), OD — in.	0.375	0.375	0.375	0.375	0.375	0.375	0.375	—	0.375	0.375	—	
No. Rows — Ckt A or B	3	3	3	3	3	3	3	—	3	3	—	
Face Area sq ft — Ckt A and B Total	225.1	225.1	225.1	268.9	268.9	225.1	128.3	353.4	225.1	128.3	353.4	
Max Working Pressure Refrigerant — psig	450	450	450	450	450	450	450	—	450	450	—	
COOLER — No. ...Type	One Per Module...Direct Expansion, Shell and Tube											
Weight (empty) — lb	1320	1320	1630	1630	1665	1320	745	2065	1320	745	2065	
No. Refrigerant Circuits	2	2	2	2	2	2	2	4	2	2	4	
Net Fluid Volume — Gal. (includes nozzles)	52.0	52.0	61.0	61.0	70.4	52.0	24.5	76.5	52.0	24.5	76.5	
Max Working Pressure	278/300	278/300	278/300	278/300	278/300	278/300	278/300	—/—	278/300	278/300	—/—	
Refrigerant Side/Fluid Side — psig												
FLUID CONNECTIONS — in.	6	6	6	6	6	6	4	—	6	4	—	
Inlet and Outlet Drain (NPT)				¾		¾		—	¾		—	

LEGEND

C-AL — Copper Tubing — Aluminum Fins Condenser Coil
C-C — Copper Tubing — Copper Fins Condenser Coil
Ckt — Circuit
ESP — External Static Pressure
OD — Outside Diameter

*08E150 compressors have 4 cylinders; all others have 6.

†Recommended oil is an ISO (International Standards Organization) viscosity grade 68, inhibited polyolester-based (POE), synthetic compressor oil.

**Based on rated ESP of 0.4 in. wg or 1.0 in. wg as appropriate.

NOTE: When facing the compressors, Circuit A is on the right and Circuit B is on the left.

Table 2A — Physical Data — 60 Hz, English (cont)

30 GU UNIT SIZE	255			270			290			315		
	A	B	Total	A	B	Total	A	B	Total	A	B	Total
SYSTEM MODULES												
APPROX OPERATING WEIGHT — lb												
C-AL	10,481	8610	19,091	11,293	8610	19,903	12,676	8660	21,336	13,380	8660	22,040
C-C	11,753	9560	21,313	12,565	9560	22,125	14,195	9610	23,805	14,899	9610	24,509
REFRIGERANT CHARGE — lb												
R-134a	162/39	129/25	—/—	162/46	129/25	—/—	190/32	129/25	—/—	190/40	129/25	—/—
Ckt A Total/Over Clear Glass	162/39	129/25	—/—	162/46	129/25	—/—	190/32	129/25	—/—	190/40	129/25	—/—
Ckt B												
COMPRESSORS, Type...rpm												
06E* (Qty) Ckt A	(3) 165	(1) 165, (1) 175	—	(3) 175	(1) 165, (1) 175	—	(1) 165, (1) 175, (1) 199	(1) 165, (1) 199	—	(3) 165, (1) 175	(1) 165, (1) 199	—
(Qty) Ckt B	(2) 199	(1) 165, (1) 175	—	(3) 175	(1) 165, (1) 175	—	(1) 165, (1) 175, (1) 199	(1) 165, (1) 175	—	(1) 175, (2) 199	(1) 165, (1) 175	—
Oil Charge — Compressor/pt												
Capacity Control Steps (Standard Unit)												
% Cap.	10	8	—	12	8	—	6	8	—	7	8	—
Ckt A	50	50	—	50	50	—	50	54	—	50	54	—
Ckt B	50	50	—	50	50	—	50	46	—	50	46	—
Minimum Step Capacity (%)	11	15	—	11	15	—	14	14	—	12	14	—
CONDENSER FANS — Type												
Standard/Low Noise												
Fan Speed — rpm	1140	1140	—	1140	1140	—	1140	1140	—	1740	1140	—
No. Blades...Diameter — in.	4...30	4...30	—	4...30	4...30	—	4...30	4...30	—	4...30	4...30	—
No. Fans...Total kW	10...15.9	8...12.7	18...28.6	10...15.9	8...12.7	18...28.6	12...19.1	8...12.7	20...31.8	12...19.1	8...12.7	20...31.8
Total Airflow — cfm	100,000	76,000	176,000	100,000	76,000	176,000	120,000	76,000	196,000	120,000	76,000	196,000
High Static												
Fan Speed — rpm	1740	1750	—	1740	1750	—	1740	1750	—	1740	1750	—
No. Blades...Diameter — in.	12...30	12...30	—	12...30	12...30	—	12...30	12...30	—	12...30	12...30	—
No. Fans...Total kW	10...37.0	8...29.6	18...66.6	10...37.0	8...29.6	18...66.6	12...44.4	8...29.6	20...74.0	12...44.4	8...29.6	20...74.0
Total Airflow...cfm**	100,000	80,000	180,000	100,000	80,000	180,000	120,000	80,000	200,000	120,000	80,000	200,000
CONDENSER COILS — Type												
Tubes (Copper), OD — in.	0.375	0.375	—	0.375	0.375	—	0.375	0.375	—	0.375	0.375	—
No. Rows — Ckt A or B	3	3	—	3	3	—	3	3	—	3	3	—
Face Area sq ft — Ckt A and B Total	225.1	168	393.1	225.1	168	393.1	268.9	168	436.9	268.9	168.0	436.9
Max Working Pressure Refrigerant — psig	450	450	—	450	450	—	450	450	—	450	450	—
COOLER — No. ...Type												
Weight (empty) — lb	1320	860	2180	1630	860	2490	1630	860	2490	1865	860	2725
No. Refrigerant Circuits	2	2	4	2	2	4	2	2	4	2	2	4
Net Fluid Volume — Gal. (includes nozzles)	52.0	30.3	82.3	61.0	30.3	91.3	61.0	30.3	91.3	70.4	30.3	100.7
Max Working Pressure												
Refrigerant Side/Fluid Side — psig	278/300	278/300	—/—	278/300	278/300	—/—	278/300	278/300	—/—	278/300	278/300	—/—
FLUID CONNECTIONS — in.												
Inlet and Outlet	6	5	—	6	5	—	6	5	—	6	5	—
Drain (NPT)	3/4	3/4	—	3/4	3/4	—	3/4	3/4	—	3/4	3/4	—

LEGEND

C-AL — Copper Tubing — Aluminum Fins Condenser Coil
C-C — Copper Tubing — Copper Fins Condenser Coil
Ckt — Circuit
ESP — External Static Pressure
OD — Outside Diameter

*06E150 compressors have 4 cylinders; all others have 6.

†Recommended oil is an ISO (International Standards Organization) viscosity grade 68, inhibited polyolester-based (POE), synthetic compressor oil.

**Based on rated ESP of 0.4 in. wg or 1.0 in. wg as appropriate.

NOTE: When facing the compressors, Circuit A is on the right and Circuit B is on the left.

Table 2A — Physical Data — 60 Hz, English (cont)

30GU UNIT SIZE	330			350			390			420		
	A	B	Total	A	B	Total	A	B	Total	A	B	Total
SYSTEM MODULES												
APPROX OPERATING WEIGHT — lb												
C-AL	11,293	11,293	22,586	12,676	12,676	25,352	13,380	12,676	26,056	13,380	13,380	26,760
C-C	12,565	12,565	25,130	14,195	14,195	28,390	14,899	14,195	29,094	14,899	14,899	29,798
REFRIGERANT CHARGE — lb												
R-134a	162/46	162/46	—/—	190/32	190/32	—/—	190/40	190/32	—/—	190/40	190/40	—/—
Ckt A Total/Over Clear Glass	162/46	162/46	—/—	190/32	190/32	—/—	190/40	190/32	—/—	190/40	190/40	—/—
Ckt B												
COMPRESSORS, Type...rpm												
06E* (Qty) Ckt A	(3) 175	(3) 175	—	(1) 165, (1) 175, (1) 199	(1) 165, (1) 175, (1) 199	—	(3) 165, (1) 175, (1) 199	(1) 165, (1) 175, (1) 199	—	(3) 165, (1) 175, (1) 199	(1) 165, (1) 175, (1) 199	—
(Qty) Ckt B	(3) 175	(3) 175	—	(1) 165, (1) 175, (1) 199	(1) 165, (1) 175, (1) 199	—	(1) 175, (2) 199	(1) 165, (1) 175, (1) 199	—	(1) 175, (2) 199	(1) 175, (2) 199	—
Oil Charge — Compressor/pt												
Capacity Control Steps (Standard Unit)												
% Cap. Ckt A	12	12	—	6	6	—	7	6	—	7	50	—
Ckt B	50	50	—	50	50	—	50	50	—	50	50	—
Minimum Step Capacity (%)	11	11	—	14	14	—	12	14	—	12	12	—
CONDENSER FANS — Type												
Standard/Low Noise												
Fan Speed — rpm	1140	1140	—	1140	1140	—	1740	1140	—	1740	1740	—
No. Blades...Diameter — in.	4...30	4...30	—	4...30	4...30	—	4...30	4...30	—	4...30	4...30	—
No. Fans...Total kW	10...15.9	10...15.9	20...31.8	12...19.1	12...19.1	24...38.2	12...19.1	12...19.1	24...38.2	12...19.1	12...19.1	24...38.2
Total Airflow — cfm	100,000	100,000	200,000	120,000	120,000	240,000	120,000	120,000	240,000	120,000	120,000	240,000
High Static												
Fan Speed — rpm	1740	1740	—	1740	1740	—	1740	1740	—	1740	1740	—
No. Blades...Diameter — in.	12...30	12...30	—	12...30	12...30	—	12...30	12...30	—	12...30	12...30	—
No. Fans...Total kW	10...37.0	10...37.0	20...74	12...44.4	12...44.4	24...88.8	12...44.4	12...44.4	24...88.8	12...44.4	12...44.4	24...88.8
Total Airflow...cfm**	100,000	100,000	200,000	120,000	120,000	240,000	120,000	120,000	240,000	120,000	120,000	240,000
CONDENSER COILS — Type												
Tubes (Copper), OD — in.	0.375	0.375	—	0.375	0.375	—	0.375	0.375	—	0.375	0.375	—
No. Rows — Ckt A or B	3	3	—	3	3	—	3	3	—	3	3	—
Face Area sq ft — Ckt A and B Total	225.1	225.1	450.2	268.9	268.9	537.8	268.9	268.9	537.8	268.9	268.9	537.8
Max Working Pressure Refrigerant — psig	450	450	—	450	450	—	450	450	—	450	450	—
COOLER — No. ...Type												
Weight (empty) — lb	1630	1630	3260	1630	1630	3260	1865	1630	3495	1865	1865	3730
No. Refrigerant Circuits	2	2	4	2	2	4	2	2	4	2	2	4
Net Fluid Volume — Gal. (includes nozzles)	61.0	61.0	122	61.0	61.0	122	70.4	61.0	131.4	70.4	70.4	140.8
Max Working Pressure	278/300	278/300	—/—	278/300	278/300	—/—	278/300	278/300	—/—	278/300	278/300	—/—
Refrigerant Side/Fluid Side — psig												
FLUID CONNECTIONS — in.												
Inlet and Outlet	6	6	—	6	6	—	6	6	—	6	6	—
Drain (NPT)	3/4	3/4	—	3/4	3/4	—	3/4	3/4	—	3/4	3/4	—

LEGEND

C-AL — Copper Tubing — Aluminum Fins Condenser Coil
C-C — Copper Tubing — Copper Fins Condenser Coil
Ckt — Circuit
ESP — External Static Pressure
OD — Outside Diameter

*06E150 compressors have 4 cylinders; all others have 6.

†Recommended oil is an ISO (International Standards Organization) viscosity grade 68, inhibited polyolester-based (POE), synthetic compressor oil.

**Based on rated ESP of 0.4 in. wg or 1.0 in. wg as appropriate.

NOTE: When facing the compressors, Circuit A is on the right and Circuit B is on the left.

Table 2B — Physical Data — 60 Hz, SI

30GU UNIT SIZE	040	045	050	060	070	080	090	100	110
SYSTEM MODULES	—	—	—	—	—	—	—	—	—
APPROX OPERATING WEIGHT — kg									
C-AL	1610	1669	1749	2150	2280	3013	3189	3914	3935
C-C	1741	1800	1945	2339	2565	3343	3518	4346	4368
REFRIGERANT CHARGE — kg									
R-134a	24.0/7.2	24.0/7.2	30.8/7.7	30.4/8.6	43.5/9.0	46.3/9.0	46.3/9.0	58.5/11.5	58.5/11.5
Ckt A Total/Over Clear Glass	27.2/6.8	27.0/7.2	35.8/7.2	34.5/9.5	43.5/9.0	46.3/9.0	46.3/9.0	58.5/11.5	58.5/11.5
Ckt B									
COMPRESSORS, Type...r/s									
06E* (Qty) Ckt A	(1) 150	(1) 150	(1) 165	(1) 175	(1) 199	Reciprocating, Semi-Hermetic...29.2	(1) 150, (1) 165	(1) 165, (1) 175	(1) 165, (1) 199
(Qty) Ckt B	(1) 150	(1) 165	(1) 175	(1) 199	(1) 199	(1) 199	(2) 165	(1) 165, (1) 175	(1) 165, (1) 175
Oil Charge — Compressor/L						150/8.0, 165/9.0, 175/9.0, 199/9.0			
Capacity Control Steps (Standard Unit)									
% Cap.	4	4	4	4	4	6	8	8	8
Ckt A	50	42	48	43	50	56	47	50	54
Ckt B	50	58	52	57	50	44	53	50	46
Minimum Step Capacity (%)	25	21	32	29	33	22	18	15	14
CONDENSER FANS — Type									
Standard/Low Noise									
Fan Speed — r/s									
No. Blades...Diameter — mm									
No. Fans...Total kW	4...6.2	4...6.2	4...6.2	6...9.3	6...9.3	6...9.4	6...9.4	8...12.7	8...12.7
Total Airflow — L/s	16 517	16 517	16 045	24 540	24 068	26 898	26 898	35 864	35 864
High Static									
Fan Speed — r/s									
No. Blades...Diameter — mm									
No. Fans...Total kW	4...14.8	4...14.8	4...14.8	6...22.2	6...22.2	6...22.2	6...22.2	8...29.6	8...29.6
Total Airflow...L/s**	18 876	18 876	18 876	28 314	28 314	28 314	28 315	37 750	37 750
CONDENSER COILS — Type									
Tubes (Copper), OD — mm	2	2	3	2	3	3	3	3	3
No. Rows — Ckt A or B	7 48	7 48	7 48	10.84	10.84	11.92	11.92	15.61	15.61
Face Area m ² — Ckt A and B Total									
Max Working Pressure Refrigerant — kPa									
COOLER — No. ...Type									
Weight (empty) — kg	220	247	247	281	281	338	338	391	391
No. Refrigerant Circuits	2	2	2	2	2	2	2	2	2
Net Fluid Volume — L (includes nozzles)	41.3	51.2	51.2	68.3	68.3	92.9	92.9	114.6	114.6
Max Working Pressure									
Refrigerant Side/Fluid Side — kPa									
FLUID CONNECTIONS — in.									
Inlet and Outlet	3	3	3	4	4	4	4	5	5
Drain (NPT)						3/4			

LEGEND

C-AL — Copper Tubing — Aluminum Fins Condenser Coil
C-C — Copper Tubing — Copper Fins Condenser Coil
Ckt — Circuit
ESP — External Static Pressure
OD — Outside Diameter

*06E150 compressors have 4 cylinders; all others have 6.

†Recommended oil is an ISO (International Standards Organization) viscosity grade 68, inhibited polyolester-based (POE), synthetic compressor oil.

**Based on rated ESP of 100 Pa or 250 Pa as appropriate.

NOTE: When facing the compressors, Circuit A is on the right and Circuit B is on the left.

Table 2B — Physical Data — 60 Hz, SI (cont)

30GU UNIT SIZE SYSTEM MODULES	210				230				245			
	130	150	170	190	210	230	245	250	260	270	280	290
APPROX OPERATING WEIGHT — kg C-AL C-C	4566 5144	4754 5342	5133 5711	5761 6452	6081 6772	3013 3343	3189 3518	3743 4188	4474 5042	4754 5342	5042 5630	5342 5930
REFRIGERANT CHARGE — kg R-134a Ckt A Total/Over Clear Glass Ckt B	73.5/16.1 73.5/16.1	73.5/18.0 73.5/18.0	73.5/21.1 73.5/21.1	86.2/14.8 86.2/14.8	86.2/18.3 86.2/18.3	46.3/9.0 46.3/9.0	48.3/9.0 48.3/9.0	50.3/9.0 50.3/9.0	53.3/9.0 53.3/9.0	56.3/9.0 56.3/9.0	59.3/9.0 59.3/9.0	62.3/9.0 62.3/9.0
COMPRESSORS, Type...r/s	Reciprocating, Semi-Hermetic...29.2											
00E* (Qty) Ckt A	(1) 175, (1) 199	(3) 165	(3) 175	(1) 165, (1) 175, (1) 199	(3) 165, (1) 175	(1) 150, (1) 175	(1) 165, (1) 150	(1) 175	(3) 165	(3) 165	(1) 165, (1) 150	(1) 165
(Qty) Ckt B	(1) 175, (1) 199	(2) 199	(3) 175	(1) 165, (1) 175, (1) 199	(1) 175, (2) 199	(1) 199	(2) 199	(1) 199	(2) 199	(2) 199	(2) 165	(2) 165
Oil Charge† — Compressor/L	150/8.0, 165/9.0, 175/9.0, 199/9.0											
Capacity Control Steps (Standard Unit)	8	10	12	6	7	6	8	10	10	10	8	8
% Cap. Ckt A	50	50	50	50	50	56	56	50	50	50	47	47
Ckt B	14	11	11	14	12	22	18	11	11	11	18	18
Minimum Step Capacity (%)	Propeller, Direct Drive											
CONDENSER FANS — Type	Vertical and Horizontal, Plate Fin, Enhanced Tubing											
Standard/Low Noise	19	19	19	19	19	19	19	19	19	19	19	19
Fan Speed — r/s	4...762	4...762	4...762	4...762	4...762	4...762	4...762	4...762	4...762	4...762	4...762	4...762
No. Blades...Diameter — mm	10...15.9	10...15.9	10...15.9	12...19.1	12...19.1	6...9.4	6...9.4	10...15.9	10...15.9	10...15.9	6...9.4	6...9.4
No. Fans...Total kW	47 190	47 190	47 190	56 630	56 630	26 898	26 898	47 190	47 190	47 190	26 898	26 898
Total Airflow — L/s	29	29	29	29	29	29	29	29	29	29	29	29
High Static	12...762	12...762	12...762	12...762	12...762	12...762	12...762	12...762	12...762	12...762	12...762	12...762
Fan Speed — r/s	10...37.0	10...37.0	10...37.0	12...44.4	12...44.4	6...22.2	6...22.2	10...37.0	10...37.0	10...37.0	6...22.2	6...22.2
No. Blades...Diameter — mm	47 190	47 190	47 190	56 630	56 630	28 315	28 315	47 190	47 190	47 190	28 315	28 315
No. Fans...Total kW	9.53	9.53	9.53	9.53	9.53	9.53	9.53	9.53	9.53	9.53	9.53	9.53
Total Airflow...L/s**	3	3	3	3	3	3	3	3	3	3	3	3
CONDENSER COILS — Type	20.92	20.92	20.92	20.92	20.92	11.92	11.92	20.92	20.92	20.92	11.92	11.92
Tubes (Copper), OD — mm	3103	3103	3103	3103	3103	3103	3103	3103	3103	3103	3103	3103
No. Rows — Ckt A or B	600	600	741	741	848	338	338	600	600	600	338	338
Face Area m ² — Ckt A and B Total	197	197	229	229	267	92.9	92.9	197.0	197.0	197.0	92.9	92.9
Max Working Pressure Refrigerant — kPa	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068
COOLER — No. ...Type	One...Direct Expansion, Shell and Tube											
Weight (empty) — kg	600	600	741	741	848	338	338	600	600	600	338	338
No. Refrigerant Circuits	2	2	2	2	2	2	2	2	2	2	2	2
Net Fluid Volume — L (includes nozzles)	197	197	229	229	267	92.9	92.9	197.0	197.0	197.0	92.9	92.9
Max Working Pressure	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068
Refrigerant Side/Fluid Side — kPa	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068
FLUID CONNECTIONS — in.	6	6	6	6	6	4	4	6	6	6	4	4
Inlet and Outlet	Victaulic Type											
Drain (NPT)	3/4											

LEGEND

C-AL — Copper Tubing — Aluminum Fins Condenser Coil
C-C — Copper Tubing — Copper Fins Condenser Coil
Ckt — Circuit
ESP — External Static Pressure
OD — Outside Diameter

*06E150 compressors have 4 cylinders; all others have 6.

†Recommended oil is an ISO (International Standards Organization) viscosity grade 68, inhibited polyolester-based (POE), synthetic compressor oil.

**Based on rated ESP of 100 Pa or 250 Pa as appropriate.

NOTE: When facing the compressors, Circuit A is on the right and Circuit B is on the left.

Table 2B — Physical Data — 60 Hz, SI (cont)

30GU UNIT SIZE		255			270			290			315		
SYSTEM MODULES		A	B	Total	A	B	Total	A	B	Total	A	B	Total
APPROX OPERATING WEIGHT — kg													
C-AL		4754	3914	8668	5133	3914	9047	5761	3935	9696	6081	3935	10016
C-C		5342	4346	9688	5711	4346	10057	6452	4368	10820	6772	4368	11140
REFRIGERANT CHARGE — kg													
R-134a		73.5/18.0	58.5/11.5	—/—	73.5/21.1	58.5/11.5	—/—	86.2/14.8	58.5/11.5	—/—	86.2/18.3	58.5/11.5	—/—
Ckt A Total/Over Clear Glass		73.5/18.0	58.5/11.5	—/—	73.5/21.1	58.5/11.5	—/—	86.2/14.8	58.5/11.5	—/—	86.2/18.3	58.5/11.5	—/—
COMPRESSORS, Type.../r/s													
06E* (Qty) Ckt A		(3) 165	(1) 165, (1) 175	—	(3) 175	(1) 165, (1) 175	—	(1) 165, (1) 175, (1) 199	(1) 165, (1) 199	—	(3) 165, (1) 175	(1) 165, (1) 199	—
(Qty) Ckt B		(2) 199	(1) 165, (1) 175	—	(3) 175	(1) 165, (1) 175	—	(1) 165, (1) 175, (1) 199	(1) 165, (1) 175	—	(1) 175, (2) 199	(1) 165, (1) 175	—
Oil Charge† — Compressor/L													
Capacity Control Steps (Standard Unit)		10	8	—	12	8	—	6	8	—	7	8	—
% Cap.		50	50	—	50	50	—	50	54	—	50	54	—
Minimum Step Capacity (%)		11	15	—	11	15	—	14	14	—	12	14	—
CONDENSER FANS — Type													
Standard/Low Noise		19	19	—	19	19	—	19	19	—	19	19	—
Fan Speed — r/s		4...762	4...762	—	4...762	4...762	—	4...762	4...762	—	4...762	4...762	—
No. Blades...Diameter — mm		10...15.9	8...12.7	18...28.6	10...15.9	8...12.7	18...28.6	12...19.1	8...12.7	20...31.8	12...19.1	8...12.7	20...31.8
No. Fans...Total kW		47 190	35 864	85 054	47 190	35 864	83 054	56 630	35 864	92 494	56 630	35 864	92 494
Total Airflow — L/s		47 190	35 864	85 054	47 190	35 864	83 054	56 630	35 864	92 494	56 630	35 864	92 494
High Static													
Fan Speed — r/s		29	29	—	29	29	—	29	29	—	29	29	—
No. Blades...Diameter — mm		12...762	12...762	—	12...762	12...762	—	12...762	12...762	—	12...762	12...762	—
No. Fans...Total kW		10...37.0	8...29.6	18...66.6	10...37.0	8...29.6	18...66.6	12...44.4	8...29.6	20...74.0	12...44.4	8...29.6	20...74.0
Total Airflow...L/s*		47 190	37 750	84 940	47 190	37 750	84 940	56 630	37 750	94 380	56 630	37 750	94 380
CONDENSER COILS — Type													
Tubes (Copper), OD — mm		9.53	9.53	—	9.53	9.53	—	9.53	9.53	—	9.53	9.53	—
No. Rows — Ckt A or B		3	3	—	3	3	—	3	3	—	3	3	—
Face Area m² — Ckt A and B Total		20.92	15.61	36.53	20.92	15.61	36.53	20.92	15.61	36.53	20.92	15.61	36.53
Max Working Pressure Refrigerant — kPa		3103	3103	—	3103	3103	—	3103	3103	—	3103	3103	—
COOLER — No. ... Type													
Weight (empty) — kg		600	391	991	741	391	1132	741	391	1132	848	391	1239
No. Refrigerant Circuits		2	2	4	2	2	4	2	2	4	2	2	4
Net Fluid Volume — L (includes nozzles)		197.0	114.6	311.6	229	114.6	343.6	229.0	114.6	343.6	267.0	114.6	381.6
Max Working Pressure		1916/2068	1916/2068	—/—	1916/2068	1916/2068	—/—	1916/2068	1916/2068	—/—	1916/2068	1916/2068	—/—
Refrigerant Side/Fluid Side — kPa		1916/2068	1916/2068	—/—	1916/2068	1916/2068	—/—	1916/2068	1916/2068	—/—	1916/2068	1916/2068	—/—
FLUID CONNECTIONS — in.													
Inlet and Outlet		6	5	—	6	5	—	6	5	—	6	5	—
Drain (NPT)		3/4	3/4	—	3/4	3/4	—	3/4	3/4	—	3/4	3/4	—

LEGEND

C-AL — Copper Tubing — Aluminum Fins Condenser Coil
C-C — Copper Tubing — Copper Fins Condenser Coil
Ckt — Circuit
ESP — External Static Pressure
OD — Outside Diameter

*06E150 compressors have 4 cylinders; all others have 6.

†Recommended oil is an ISO (International Standards Organization) viscosity grade 68, inhibited polyolester-based (POE), synthetic compressor oil.

**Based on rated ESP of 100 Pa or 250 Pa as appropriate.

NOTE: When facing the compressors, Circuit A is on the right and Circuit B is on the left.

Table 2B — Physical Data — 60 Hz, SI (cont)

30GU UNIT SIZE	330			360			390			420		
	A	B	total	A	B	total	A	B	total	A	B	total
SYSTEM MODULES												
APPROX OPERATING WEIGHT — kg												
C-AL	5133	5133	10 266	5761	5761	11 522	6081	5761	11 842	6081	6081	12 162
C-C	5711	5711	11 422	6452	6452	12 904	6772	6452	13 224	6772	6772	13 544
REFRIGERANT CHARGE — kg												
R-134a	73.5/21.1	73.5/21.1	—/—	86.2/14.8	86.2/14.8	—/—	86.2/18.3	86.2/14.8	—/—	86.2/18.3	86.2/18.3	—/—
Ckt A Total/Over Clear Glass	73.5/21.1	73.5/21.1	—/—	86.2/14.8	86.2/14.8	—/—	86.2/18.3	86.2/14.8	—/—	86.2/18.3	86.2/18.3	—/—
Ckt B												
COMPRESSORS, Type...r/s												
06E* (Qty) Ckt A	(3) 175	(3) 175	—	(1) 165, (1) 175, (1) 199	(1) 165, (1) 175, (1) 199	—	(3) 165, (1) 175, (1) 199	(1) 165, (1) 175, (1) 199	—	(3) 165, (1) 175, (1) 199	(1) 165, (1) 175, (1) 199	—
(Qty) Ckt B	(3) 175	(3) 175	—	(1) 165, (1) 175, (1) 199	(1) 165, (1) 175, (1) 199	—	(1) 175, (2) 199	(1) 165, (1) 175, (1) 199	—	(1) 175, (2) 199	(1) 175, (2) 199	—
Oil Charge† — Compressor/L												
Capacity Control Steps (Standard Unit)												
% Cap.	12	12	—	6	6	—	7	6	—	7	7	—
Ckt A	50	50	—	50	50	—	50	50	—	50	50	—
Ckt B	50	50	—	50	50	—	50	50	—	50	50	—
Minimum Step Capacity (%)	11	11	—	14	14	—	12	14	—	12	12	—
CONDENSER FANS — Type												
Standard/Low Noise												
Fan Speed — r/s	19	19	—	19	19	—	19	19	—	19	19	—
No. Blades...Diameter — mm	4...762	4...762	—	4...762	4...762	—	4...762	4...762	—	4...762	4...762	—
No. Fans...Total kW	10...15.9	10...15.9	20...31.8	12...19.1	12...19.1	24...38.2	12...19.1	12...19.1	24...38.2	12...19.1	12...19.1	24...38.2
Total Airflow — L/s	47 190	47 190	94 380	56 630	56 630	113 260	56 630	56 630	113 260	56 630	56 630	113 260
High Static												
Fan Speed — r/s	29	29	—	29	29	—	29	29	—	29	29	—
No. Blades...Diameter — mm	12...762	12...762	—	12...762	12...762	—	12...762	12...762	—	12...762	12...762	—
No. Fans...Total kW	10...37.0	10...37.0	20...74.0	12...44.4	12...44.4	24...88.8	12...44.4	12...44.4	24...88.8	12...44.4	12...44.4	24...88.8
Total Airflow...L/s**	47 190	47 190	94 380	56 630	56 630	113 260	56 630	56 630	113 260	56 630	56 630	113 260
CONDENSER COILS — Type												
Tubes (Copper), OD — mm	9.53	9.53	—	9.53	9.53	—	9.53	9.53	—	9.53	9.53	—
No. Rows — Ckt A or B	3	3	—	3	3	—	3	3	—	3	3	—
Face Area m² — Ckt A and B Total	20.92	20.92	41.84	20.92	20.92	41.84	20.92	20.92	41.84	20.92	20.92	41.84
Max Working Pressure Refrigerant — kPa	3103	3103	—	3103	3103	—	3103	3103	—	3103	3103	—
COOLER — No. ...Type												
Weight (empty) — kg	741	741	1482	741	741	1482	848	741	1589	848	848	1696
No. Refrigerant Circuits	2	2	4	2	2	4	2	2	4	2	2	4
Net Fluid Volume — L (includes nozzles)	229	229	458	229	229	458	267.0	229.0	496	267.0	257.0	534
Max Working Pressure	1916/2068	1916/2068	—/—	1916/2068	1916/2068	—/—	1916/2068	1916/2068	—/—	1916/2068	1916/2068	—/—
Refrigerant Side/Fluid Side — kPa												
FLUID CONNECTIONS — in.												
Inlet and Outlet	6	6	—	6	6	—	6	6	—	6	6	—
Drain (NPT)	3/4	3/4	—	3/4	3/4	—	3/4	3/4	—	3/4	3/4	—

LEGEND

C-AL — Copper Tubing — Aluminum Fins Condenser Coil
C-C — Copper Tubing — Copper Fins Condenser Coil
Ckt — Circuit
ESP — External Static Pressure
OD — Outside Diameter

*06E150 compressors have 4 cylinders; all others have 6.

†Recommended oil is an ISO (International Standards Organization) viscosity grade 68, inhibited polyolester-based (POE), synthetic compressor oil.

**Based on rated ESP of 100 Pa or 250 Pa as appropriate.

NOTE: When facing the compressors, Circuit A is on the right and Circuit B is on the left.

Table 3A — Physical Data — 50 Hz, English

30GU UNIT SIZE	040	045	050	060	070	080	090	100	110
SYSTEM MODULES	—	—	—	—	—	—	—	—	—
APPROX OPERATING WEIGHT — lb									
C-AL	3,550	3,736	3,916	4,780	5,453	6,720	7,135	8,710	8,840
C-C	3,878	4,024	4,349	5,197	6,081	7,445	7,860	9,660	9,790
REFRIGERANT CHARGE — lb									
R-134a	53/16	53/16	68/17	67/19	96/20	102/20	102/20	129/25	129/25
Ckt A Total/Over Clear Glass	60/15	60/16	79/16	76/21	96/21	102/20	102/20	129/25	129/25
COMPRESSORS, Type...rpm									
06E* (Qty) Ckt A	(1) 150	(1) 165	(1) 175	(1) 199	(2) 165	(1) 165, (1) 199	(1) 165, (1) 199	(1) 165, (1) 199	(2) 199
(Qty) Ckt B	(1) 165	(1) 175	(1) 199	(1) 199	(1) 199	(1) 199	(1) 165, (1) 175	(1) 165, (1) 199	(2) 199
Oil Charge† — Compressor/pt						150/17, 165/19, 175/19, 199/19			
Capacity Control Steps (Standard Unit)									
% Cap.	4	4	4	4	7	6	8	8	8
Ckt A	42	48	43	50	58	62	54	50	50
Ckt B	58	52	57	50	42	38	46	50	50
Minimum Step Capacity (%)	21	32	29	33	19	16	14	13	17
CONDENSER FANS — Type									
Standard/Low Noise									
Fan Speed — rpm									
No. Blades...Diameter — in.									
No. Fans...Total kW									
Total Airflow — cfm									
High Static									
Fan Speed — rpm									
No. Blades...Diameter — in.									
No. Fans...Total kW									
Total Airflow...cfm**									
CONDENSER COILS — Type									
Tubes (Copper), OD — in.									
No. Rows — Ckt A or B									
Face Area sq ft — Ckt A and B Total									
Max Working Pressure Refrigerant — psig									
COOLER — No. ...Type									
Weight (empty) — lb									
No. Refrigerant Circuits									
Net Fluid Volume — Gal. (includes nozzles)									
Max Working Pressure									
Refrigerant Side/Fluid Side — psig									
FLUID CONNECTIONS — in.									
Inlet and Outlet									
Drain (NPT)									

LEGEND

C-AL — Copper Tubing — Aluminum Fins Condenser Coil
C-C — Copper Tubing — Copper Fins Condenser Coil
Ckt — Circuit
ESP — External Static Pressure
OD — Outside Diameter

*06E150 compressors have 4 cylinders; all others have 6.

†Recommended oil is an ISO (International Standards Organization) viscosity grade 68, inhibited polyolester-based (POE), synthetic compressor oil.

**Based on rated ESP of 0.4 in. wg or 1.0 in. wg as appropriate.

NOTE: When facing the compressors, Circuit A is on the right and Circuit B is on the left.

Table 3A — Physical Data — 50 Hz, English (cont)

30GU UNIT SIZE		130	150	170	190	210	230		245	
SYSTEM MODULES							A	B	A	B
APPROX OPERATING WEIGHT — lb							total		Total	
C-AL										
C-C										
REFRIGERANT CHARGE — lb										
R-134a										
Ckt A Total/Over Clear Glass										
Ckt B										
COMPRESSORS, Type...rpm										
06E* (Qty) Ckt A										
(Qty) Ckt B										
Oil Charge† — Compressor/pt										
Capacity Control Steps (Standard Unit)										
% Cap. Ckt A										
Ckt B										
Minimum Step Capacity (%)										
CONDENSER FANS — Type										
Standard/Low Noise										
Fan Speed — rpm										
No. Blades...Diameter — in.										
No. Fans...Total kW										
Total Airflow — cfm										
High Static										
Fan Speed — rpm										
No. Blades...Diameter — in.										
No. Fans...Total kW										
Total Airflow...cfm**										
CONDENSER COILS — Type										
Tubes (Copper), OD — in.										
No. Rows — Ckt A or B										
Face Area sq ft — Ckt A and B Total										
Max Working Pressure Refrigerant — psig										
COOLER — No. ...Type										
Weight (empty) — lb										
No. Refrigerant Circuits										
Net Fluid Volume — Gal. (includes nozzles)										
Max Working Pressure										
Refrigerant Side/Fluid Side — psig										
FLUID CONNECTIONS — in.										
Inlet and Outlet										
Drain (NPT)										

LEGEND

C-AL — Copper Tubing — Aluminum Fins Condenser Coil
C-C — Copper Tubing — Copper Fins Condenser Coil
Ckt — Circuit
ESP — External Static Pressure
OD — Outside Diameter

*06E150 compressors have 4 cylinders; all others have 6.

†Recommended oil is an ISO (International Standards Organization) viscosity grade 68, inhibited polyolester-based (POE), synthetic compressor oil.
**Based on rated ESP of 0.4 in. wg or 1.0 in. wg as appropriate.

NOTE. When facing the compressors, Circuit A is on the right and Circuit B is on the left.

Table 3A — Physical Data — 50 Hz, English (cont)

30GU UNIT SIZE	255			270			290			315		
	A	B	Total	A	B	Total	A	B	Total	A	B	Total
SYSTEM MODULES												
APPROX OPERATING WEIGHT — lb												
C-AL	10,676	8710	19,386	11,443	8710	20,153	12,906	8840	21,746	13,545	8840	22,385
C-C	11,948	9660	21,608	12,715	9660	22,375	14,425	9790	24,215	15,064	9790	24,854
REFRIGERANT CHARGE — lb												
R-134a	162/39	129/25	—/—	162/46	129/25	—/—	190/32	129/25	—/—	190/40	129/25	—/—
Ckt A Total/Over Clear Glass	162/39	129/25	—/—	162/46	129/25	—/—	190/32	129/25	—/—	190/40	129/25	—/—
COMPRESSORS, Type...rpm												
06E* (Qty) Ckt A	(3) 199	(1) 165, (1) 199	—	(2) 175, (1) 199	(1) 165, (1) 199	—	(3) 199	(2) 199	—	(2) 165, (2) 199	(2) 199	—
(Qty) Ckt B	(2) 199	(1) 165, (1) 199	—	(1) 175, (2) 199	(1) 165, (1) 199	—	(3) 199	(2) 199	—	(3) 199	(2) 199	—
Oil Charge† — Compressor/pt												
Capacity Control Steps (Standard Unit)												
% Cap.	10	8	—	12	8	—	6	8	—	7	8	—
Ckt A	60	50	—	48	50	—	50	50	—	52	50	—
Ckt B	13	50	—	52	50	—	50	50	—	48	50	—
Minimum Step Capacity (%)												
CONDENSER FANS — Type												
Standard/Low Noise												
Fan Speed — rpm	950	950	—	950	950	—	950	950	—	950	950	—
No. Blades...Diameter — in.	6...30	6...30	—	6...30	6...30	—	6...30	6...30	—	6...30	6...30	—
No. Fans...Total kW	10...15.9	8...12.7	18...28.6	10...15.9	8...12.7	18...28.6	12...19.1	8...12.7	20...31.8	12...19.1	8...12.7	20...31.8
Total Airflow — cfm	100,000	76,000	176,000	100,000	76,000	176,000	120,000	76,000	196,000	120,000	76,000	196,000
High Static												
Fan Speed — rpm	1445	1445	—	1445	1750	—	1445	1445	—	1445	1445	—
No. Blades...Diameter — in.	6...30	12...30	—	6...30	12...30	—	12...30	12...30	—	12...30	12...30	—
No. Fans...Total kW	10...37.0	8...29.6	18...66.6	10...37.0	8...29.6	18...66.6	12...44.4	8...29.6	20...74.0	12...44.4	8...29.6	20...74.0
Total Airflow...cfm**	100,000	80,000	180,000	100,000	80,000	180,000	120,000	80,000	200,000	120,000	80,000	200,000
CONDENSER COILS — Type												
Tubes (Copper), OD — in.	0.375	0.375	—	0.375	0.375	—	0.375	0.375	—	0.375	0.375	—
No. Rows — Ckt A or B	3	3	—	3	3	—	3	3	—	3	3	—
Face Area sq ft — Ckt A and B Total	225.1	168.0	393.1	225.1	168.0	393.1	268.9	168.0	436.9	268.9	168.0	436.9
Max Working Pressure Refrigerant — psig	450	450	—	450	450	—	450	450	—	450	450	—
COOLER — No. ...Type												
Weight (empty) lb	1320	860	2180	1630	860	2490	1630	860	2490	1865	860	2725
No. Refrigerant Circuits	2	2	4	2	2	4	2	2	4	2	2	4
Net Fluid Volume — Gal. (includes nozzles)	52.0	30.3	82.3	61.0	30.3	91.3	61.0	30.3	91.3	70.4	30.3	100.7
Max Working Pressure												
Refrigerant Side/Fluid Side — psig	278/300	278/300	—/—	278/300	278/300	—/—	278/300	278/300	—/—	278/300	278/300	—/—
FLUID CONNECTIONS — in.												
Inlet and Outlet	6	5	—	6	5	—	6	5	—	6	5	—
Drain (NPT)	3/4	3/4	—	3/4	3/4	—	3/4	3/4	—	3/4	3/4	—

LEGEND

C-AL — Copper Tubing — Aluminum Fins Condenser Coil
C-C — Copper Tubing — Copper Fins Condenser Coil
Ckt — Circuit
ESP — External Static Pressure
OD — Outside Diameter

*06E150 compressors have 4 cylinders; all others have 6.
†Recommended oil is an ISO (International Standards Organization) viscosity grade 68, inhibited polyolester-based (POE), synthetic compressor oil.
**Based on rated ESP of 0.4 in. wg or 1.0 in. wg as appropriate.

NOTE: When facing the compressors, Circuit A is on the right and Circuit B is on the left.

Table 3A — Physical Data — 50 Hz, English (cont)

30GU UNIT SIZE		330			360			390			420		
SYSTEM MODULES		A	B	Total	A	B	Total	A	B	Total	A	B	Total
APPROX OPERATING WEIGHT — lb													
C-AL		11,443	11,443	22,886	12,906	11,443	24,349	13,545	12,906	26,451	13,545	13,545	27,090
C-C		12,715	12,715	25,430	14,425	12,715	27,140	15,064	14,425	29,489	15,064	15,064	30,128
REFRIGERANT CHARGE — lb													
R-134a		162/46	162/46	—/—	190/32	162/46	—/—	190/40	190/32	—/—	190/40	190/40	—/—
Ckt A Total/Over Clear Glass		162/46	162/46	—/—	190/32	162/46	—/—	190/40	190/32	—/—	190/40	190/40	—/—
COMPRESSORS, Type...rpm													
06E* (Qty) Ckt A		(1) 175, (1) 199	(2) 175, (1) 199	—	(3) 199	(2) 175, (1) 199	—	(2) 165, (2) 199	(3) 199	—	(2) 165, (2) 199	(2) 165, (2) 199	—
(Qty) Ckt B		(1) 175, (2) 199	(1) 175, (2) 199	—	(3) 199	(1) 175, (2) 199	—	(3) 199	(3) 199	—	(3) 199	(3) 199	—
Oil Charge† — Compressor/pt													
Capacity Control Steps (Standard Unit)		12	12	—	6	12	—	7	6	—	7	7	—
% Cap. Ckt A		48	48	—	50	48	—	52	50	—	52	52	—
Ckt B		52	52	—	50	52	—	48	50	—	48	48	—
Minimum Step Capacity (%)		10	10	—	17	10	—	10	17	—	10	10	—
CONDENSER FANS — Type													
Standard/Low Noise													
Fan Speed — rpm		950	950	—	950	950	—	950	950	—	950	950	—
No. Blades...Diameter — in.		6...30	6...30	—	6...30	6...30	—	6...30	6...30	—	6...30	6...30	—
No. Fans...Total kW		10...15.9	10...15.9	20...15.9	12...19.1	10...15.9	22...35	12...19.1	12...19.1	24...38.2	12...19.1	12...19.1	24...38.2
Total Airflow — cfm		100,000	100,000	200,000	120,000	100,000	220,000	120,000	120,000	240,000	120,000	120,000	240,000
High Static													
Fan Speed — rpm		1445	1445	—	1445	1445	—	1445	1445	—	1445	1445	—
No. Blades...Diameter — in.		6...30	6...30	—	12...30	6...30	—	12...30	12...30	—	12...30	12...30	—
No. Fans...Total kW		10...37.0	10...37.0	20...74.0	12...44.4	10...37	22...81.4	12...44.4	12...44.4	24...88.8	12...44.4	12...44.4	24...88.8
Total Airflow...cfm**		100,000	100,000	200,000	120,000	100,000	220,000	120,000	120,000	240,000	120,000	120,000	240,000
CONDENSER COILS — Type													
Tubes (Copper), OD — in.		0.375	0.375	—	0.375	0.375	—	0.375	0.375	—	0.375	0.375	—
No. Rows — Ckt A or B		3	3	—	3	3	—	3	3	—	3	3	—
Face Area sq ft — Ckt A and B Total		225.1	225.1	450.2	268.9	225.1	494	268.9	268.9	537.8	268.9	268.9	537.8
Max Working Pressure Refrigerant — psig		450	450	—	450	450	—	450	450	—	450	450	—
COOLER — No. ... Type													
Weight (empty) — lb		1630	1630	3260	1630	1630	3260	1630	1630	3260	1630	1630	3260
No. Refrigerant Circuits		2	2	4	2	2	4	2	2	4	2	2	4
Net Fluid Volume — Gal. (includes nozzles)		61.0	61.0	122.0	61.0	61.0	122	70.4	61.0	131.4	70.4	70.4	140.8
Max Working Pressure		278/300	278/300	—/—	278/300	278/300	—/—	278/300	278/300	—/—	278/300	278/300	—/—
Refrigerant Side/Fluid Side — psig		278/300	278/300	—/—	278/300	278/300	—/—	278/300	278/300	—/—	278/300	278/300	—/—
FLUID CONNECTIONS — in.													
Inlet and Outlet		6	6	—	6	6	—	6	6	—	6	6	—
Drain (NPT)		3/4	3/4	—	3/4	3/4	—	3/4	3/4	—	3/4	3/4	—

LEGEND

C-AL — Copper Tubing — Aluminum Fins Condenser Coil
C-C — Copper Tubing — Copper Fins Condenser Coil
Ckt — Circuit
ESP — External Static Pressure
OD — Outside Diameter

*06E150 compressors have 4 cylinders; all others have 6.

†Recommended oil is an ISO (International Standards Organization) viscosity grade 68, inhibited polyolester-based (POE), synthetic compressor oil.
**Based on rated ESP of 0.4 in. wg or 1.0 in. wg as appropriate.

NOTE: When facing the compressors, Circuit A is on the right and Circuit B is on the left.

Table 3B — Physical Data — 50 Hz, SI

30GU UNIT SIZE	040	045	050	060	070	080	090	100	110
SYSTEM MODULES	—	—	—	—	—	—	—	—	—
APPROX OPERATING WEIGHT — kg									
C-AL	1628	1694	1776	2168	2473	3055	3243	3960	4018
C-C	1759	1825	1972	2357	2758	3384	3573	4390	4450
REFRIGERANT CHARGE — kg									
R-134a	24.0/7.2	24.0/7.2	30.8/7.7	30.4/8.6	43.5/9.0	46.3/9.0	46.3/9.0	58.5/11.5	58.5/11.5
Ckt A Total/Over Clear Glass	27.2/6.8	27.0/7.2	35.8/7.2	34.5/9.5	43.5/9.0	46.3/9.0	46.3/9.0	58.5/11.5	58.5/11.5
COMPRESSORS, Type...r/s									
06E* (Qty) Ckt A	(1) 150	(1) 165	(1) 175	(1) 199	(1) 199	Reciprocating, Semi-Hermetic...24.2	(1) 165, (1) 199	(1) 165, (1) 199	(2) 199
(Qty) Ckt B	(1) 165	(1) 175	(1) 199	(1) 199	(1) 199	(1) 199	(1) 165, (1) 175	(1) 165, (1) 199	(2) 199
Oil Charge† — Compressor/L						150/8.0, 165/9.0, 175/9.0, 199 (9.0)			
Capacity Control Steps (Standard Unit)									
% Cap.	4	4	4	4	4	6	8	8	8
Ckt A	42	48	43	50	58	62	54	50	50
Ckt B	58	52	57	50	42	38	46	50	50
Minimum Step Capacity (%)	21	32	29	33	19	16	14	13	17
CONDENSER FANS — Type									
Standard/Low Noise									
Fan Speed — r/s									
No. Blades...Diameter — mm									
No. Fans...Total kW									
Total Airflow — L/s	4...6.2	4...6.2	4...6.2	6...9.3	6...9.3	6...9.4	6...9.4	8...12.7	8...12.7
High Static	16 517	16 517	16 045	24 540	24 068	26 898	26 898	35 864	35 864
Fan Speed — r/s									
No. Blades...Diameter — mm									
No. Fans...Total kW	4...14.8	4...14.8	4...14.8	6...22.2	6...22.2	6...22.2	6...22.2	8...29.6	8...29.6
Total Airflow...L/s**	18 876	18 876	18 876	28 314	28 314	28 315	28 315	37 750	37 750
CONDENSER COILS — Type									
Tubes (Copper), OD — mm									
No. Rows — Ckt A or B	2	2	3	2	3	3	3	3	3
Face Area m ² — Ckt A and B Total	7 48	7 48	7 48	10.84	10.84	11.92	11.92	15.61	15.61
Max Working Pressure Refrigerant — kPa									
COOLER — No. ...Type									
Weight (empty) — kg	220	247	247	281	281	338	338	391	391
No. Refrigerant Circuits	2	2	2	2	2	2	2	2	2
Net Fluid Volume — L (includes nozzles)	41.3	51.2	51.2	68.3	68.3	92.9	92.9	114.6	114.6
Max Working Pressure									
Refrigerant Side/Fluid Side — kPa									
FLUID CONNECTIONS — in.									
Inlet and Outlet	3	3	3	4	4	4	4	5	5
Drain (NPT)									

LEGEND

C-AL — Copper Tubing — Aluminum Fins Condenser Coil
C-C — Copper Tubing — Copper Fins Condenser Coil
Ckt — Circuit
ESP — External Static Pressure
OD — Outside Diameter

*06E150 compressors have 4 cylinders; all others have 6.

†Recommended oil is an ISO (International Standards Organization) viscosity grade 68, inhibited polyolester-based (POE), synthetic compressor oil.

**Based on rated ESP of 100 Pa or 250 Pa as appropriate.

NOTE: When facing the compressors, Circuit A is on the right and Circuit B is on the left.

Table 3B — Physical Data — 50 Hz, SI (cont)

30GU UNIT SIZE		130	150	170	190	210	230		245	
SYSTEM MODULES							A	B	A	B
APPROX OPERATING WEIGHT — kg										Total
C-AL		4778	4852	5201	5866	6156	4852	3055	4852	3243
C-C		5335	5430	5779	6556	6847	5430	3384	5430	4390
REFRIGERANT CHARGE — kg										
R-134a		73.5/16.1	73.5/18.0	73.5/21.1	86.2/14.8	86.2/18.3	73.5/18.0	46.3/9.0	73.5/18.0	46.3/9.0
Ckt A		73.5/16.1	73.5/18.0	73.5/21.1	86.2/14.8	86.2/18.3	73.5/18.0	46.3/9.0	73.5/18.0	46.3/9.0
Ckt B										
COMPRESSORS, Type...r/s										
06E*		(1) 165, (2) 175	(3) 199	(2) 175, (1) 199	(3) 199	(2) 165, (2) 199	(3) 199	(1) 165, (1) 199	(3) 199	(1) 165, (1) 199
(Qty) Ckt A		(2) 199	(2) 199	(1) 175, (2) 199	(3) 199	(3) 199	(2) 199	(1) 199	(2) 199	(1) 165, (1) 175
(Qty) Ckt B										
Oil Charge† — Compressor/L										
Capacity Control Steps (Standard Unit)										
% Cap.		10	10	12	6	7	10	6	10	8
Ckt A		52	60	48	50	52	60	38	60	54
Ckt B		48	40	52	50	48	40	16	40	46
Minimum Step Capacity (%)		10	13	10	17	10	13	16	13	14
CONDENSER FANS — Type										
Standard/Low Noise										
Fan Speed — r/s		15.8	15.8	15.8	15.8	15.8	15.8	15.8	15.8	15.8
No. Blades...Diameter — mm		6...762	6...762	6...762	6...762	6...762	6...762	6...762	6...762	6...762
No. Fans...Total kW		10...15.9	10...15.9	10...15.9	10...15.9	10...15.9	10...15.9	10...15.9	10...15.9	10...15.9
Total Airflow — L/s		47 190	47 190	47 190	56 630	56 630	47 190	26 898	47 190	26 898
High Static										
Fan Speed — r/s		24.1	24.1	24.1	24.1	24.1	24.1	29	24.1	29
No. Blades...Diameter — mm		12...762	12...762	12...762	12...44.4	12...762	12...762	12...762	12...762	12...762
No. Fans...Total kW		10...37.0	10...37.0	10...37.0	12...44.4	12...44.4	10...37.0	6...22.2	10...37.0	6...22.2
Total Airflow...L/s**		47 190	47 190	47 190	56 630	56 630	47 190	28 315	47 190	28 315
CONDENSER COILS — Type										
Tubes (Copper), OD — mm		9.53	9.53	9.53	9.53	9.53	9.53	9.53	9.53	9.53
No. Rows — Ckt A or B		3	3	3	3	3	3	3	3	3
Face Area m ² — Ckt A and B Total		20.92	20.92	20.92	24.98	24.98	20.92	11.92	20.92	11.92
Max Working Pressure Refrigerant — kPa		3103	3103	3103	3103	3103	3103	3103	3103	3103
COOLER — No. ...Type										
Weight (empty) — kg		600	600	741	741	848	600	338	600	338
No. Refrigerant Circuits		2	2	2	2	2	2	2	2	2
Net Fluid Volume — L (Includes nozzles)		197	197	229	229	267	197.0	92.9	197.0	92.9
Max Working Pressure		1916/2068	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068	1916/2068
Refrigerant Side/Fluid Side — kPa										
FLUID CONNECTIONS — in.										
Inlet and Outlet		6	6	6	6	6	6	4	6	4
Drain (NPT)				3/4			3/4	3/4	3/4	3/4

LEGEND

C-AL — Copper Tubing — Aluminum Fins Condenser Coil
C-C — Copper Tubing — Copper Fins Condenser Coil
Ckt — Circuit
ESP — External Static Pressure
OD — Outside Diameter

*06E150 compressors have 4 cylinders; all others have 6.
†Recommended oil is an ISO (International Standards Organization) viscosity grade 68, inhibited polyolester-based (POE), synthetic compressor oil.
**Based on rated ESP of 100 Pa or 250 Pa as appropriate.

NOTE: When facing the compressors, Circuit A is on the right and Circuit B is on the left.

Table 3B — Physical Data — 50 Hz, SI (cont)

30GU UNIT SIZE		255			270			290			315		
SYSTEM MODULES		A	B	Total	A	B	Total	A	B	Total	A	B	Total
APPROX OPERATING WEIGHT — kg													
C-AL		4852	3960	8812	5201	3960	9 161	5866	4018	9 884	6156	4018	10 174
C-C		5430	4390	9820	5779	4390	10 169	6556	4450	11 006	6847	4450	11 297
REFRIGERANT CHARGE — kg													
R-134a		73.5/18.0	58.5/11.5	—/—	73.5/21.1	58.5/11.5	—/—	86.2/14.8	58.5/11.5	—/—	86.2/18.3	58.5/11.5	—/—
Ckt A Total/Over Clear Glass		73.5/18.0	58.5/11.5	—/—	73.5/21.1	58.5/11.5	—/—	86.2/14.8	58.5/11.5	—/—	86.2/18.3	58.5/11.5	—/—
COMPRESSORS, Type...r/s													
06E* (Qty) Ckt A		(3) 199	(1) 165, (1) 199	—	(2) 175, (1) 199	(1) 165, (1) 199	—	(3) 199	(2) 199	—	(2) 165, (2) 199	(2) 199	—
(Qty) Ckt B		(2) 199	(1) 165, (1) 199	—	(1) 175, (2) 199	(1) 165, (1) 199	—	(3) 199	(2) 199	—	(3) 199	(2) 199	—
Oil Charge — Compressor/L													
Capacity Control Steps (Standard Unit)		10	8	—	12	8	—	6	8	—	7	8	—
% Cap. Ckt A		60	50	—	48	50	—	50	50	—	52	50	—
Ckt B		40	50	—	52	50	—	17	50	—	48	50	—
Minimum Step Capacity (%)		13	13	—	10	13	—	17	17	—	10	17	—
CONDENSER FANS — Type													
Standard/Low Noise		15.8	15.8	—	15.8	15.8	—	15.8	15.8	—	15.8	15.8	—
Fan Speed — r/s		6...762	6...762	—	6...762	6...762	—	6...762	6...762	—	6...762	6...762	—
No. Blades...Diameter — mm		10...15.9	8...12.7	18...28.6	10...15.9	8...12.7	18...28.6	12...19.1	8...12.7	20...31.8	12...19.1	8...12.7	20...31.8
No. Fans...Total kW		47 190	35 864	83 054	47 190	35 864	83 054	56 630	35 864	92 494	56 630	35 864	92 494
Total Airflow — L/s		47 190	35 864	83 054	47 190	35 864	83 054	56 630	35 864	92 494	56 630	35 864	92 494
High Static		24.1	29	—	24.1	29	—	24.1	29	—	24.1	29	—
Fan Speed — r/s		12...762	12...762	—	12...762	12...762	—	12...762	12...762	—	12...762	12...762	—
No. Blades...Diameter — mm		10...37.0	8...29.6	18...66.6	10...37.0	8...29.6	18...66.6	12...44.4	8...29.6	20...74.0	12...44.4	8...29.6	20...74.0
No. Fans...Total kW		47 190	37 750	84 940	47 190	37 750	84 940	56 630	37 750	94 380	56 630	37 750	94 380
Total Airflow...L/s**		47 190	37 750	84 940	47 190	37 750	84 940	56 630	37 750	94 380	56 630	37 750	94 380
CONDENSER COILS — Type													
Tubes (Copper), OD — mm		9.53	9.53	—	9.53	9.53	—	9.53	9.53	—	9.53	9.53	—
No. Rows — Ckt A or B		3	3	—	3	3	—	3	3	—	3	3	—
Face Area m ² — Ckt A and B Total		20.92	15.61	36.53	20.92	15.61	36.53	24.98	15.61	40.59	24.98	15.61	40.59
Max Working Pressure Refrigerant — kPa		3103	3103	—	3103	3103	—	3103	3103	—	3103	3103	—
COOLER — No. ...Type													
Weight (empty) — kg		600	391	991	741	391	1132	741	391	1132	848	391	1239
No. Refrigerant Circuits		2	2	4	2	2	4	2	2	4	2	2	4
Net Fluid Volume — L (includes nozzles)		197.0	114.6	311.6	229	114.6	343.6	229.0	114.6	343.6	267.0	114.6	381.6
Max Working Pressure		1916/2068	1916/2068	—/—	1916/2068	1916/2068	—/—	1916/2068	1916/2068	—/—	1916/2068	1916/2068	—/—
Refrigerant Side/Fluid Side — kPa		1916/2068	1916/2068	—/—	1916/2068	1916/2068	—/—	1916/2068	1916/2068	—/—	1916/2068	1916/2068	—/—
FLUID CONNECTIONS — in.													
Inlet and Outlet		6	5	—	6	5	—	6	5	—	6	5	—
Drain (NPT)		3/4	3/4	—	3/4	3/4	—	3/4	3/4	—	3/4	3/4	—

LEGEND

C-AL — Copper Tubing — Aluminum Fins Condenser Coil
C-C — Copper Tubing — Copper Fins Condenser Coil
Ckt — Circuit
ESP — External Static Pressure
OD — Outside Diameter

*06E150 compressors have 4 cylinders; all others have 6.

†Recommended oil is an ISO (International Standards Organization) viscosity grade 68, inhibited polyolester-based (POE), synthetic compressor oil.

**Based on rated ESP of 100 Pa or 250 Pa as appropriate.

NOTE: When facing the compressors, Circuit A is on the right and Circuit B is on the left.

Table 3B — Physical Data — 50 Hz, SI (cont)

30GU UNIT SIZE			330			360			390			420		
SYSTEM MODULES			A	B	Total	A	B	Total	A	B	Total	A	B	Total
APPROX OPERATING WEIGHT — kg														
C-AL	5201	5201	10 402	5866	5201	11 067	6156	5866	12 022	6156	5866	12 022	6156	12 312
C-C	5779	5779	11 558	6556	5779	12 235	6847	6556	13 403	6847	6556	13 403	6847	13 694
REFRIGERANT CHARGE — kg														
R-134a	73.5/21.1	73.5/21.1	—/—	86.2/14.8	73.5/21.1	—/—	86.2/18.3	86.2/14.8	—/—	86.2/18.3	86.2/14.8	—/—	86.2/18.3	—/—
Ckt A	73.5/21.1	73.5/21.1	—/—	86.2/14.8	73.5/21.1	—/—	86.2/18.3	86.2/14.8	—/—	86.2/18.3	86.2/14.8	—/—	86.2/18.3	—/—
Ckt B	73.5/21.1	73.5/21.1	—/—	86.2/14.8	73.5/21.1	—/—	86.2/18.3	86.2/14.8	—/—	86.2/18.3	86.2/14.8	—/—	86.2/18.3	—/—
COMPRESSORS, Type...r/s														
06E* (Qty) Ckt A	(2) 175, (1) 199	(2) 175, (1) 199	—	(3) 199	(2) 175, (1) 199	—	(2) 165, (2) 199	(3) 199	(3) 199	(2) 165, (2) 199	(3) 199	(3) 199	(2) 165, (2) 199	—
(Qty) Ckt B	(1) 175, (2) 199	(1) 175, (2) 199	—	(3) 199	(1) 175, (2) 199	—	(3) 199	(3) 199	(3) 199	(3) 199	(3) 199	(3) 199	(3) 199	—
Oil Charge† — Compressor/L														
Capacity Control Steps (Standard Unit)														
% Cap. Ckt A	12	12	—	6	12	—	7	6	—	7	6	—	7	—
Ckt B	48	48	—	50	48	—	52	50	—	52	50	—	52	—
Minimum Step Capacity (%)	52	52	—	17	52	—	10	17	—	10	17	—	10	—
Ckt B	10	10	—	17	10	—	10	17	—	10	17	—	10	—
CONDENSER FANS — Type														
Standard/Low Noise														
Fan Speed — r/s	15.8	15.8	—	15.8	15.8	—	15.8	15.8	—	15.8	15.8	—	15.8	—
No. Blades...Diameter — mm	6...762	6...762	—	6...762	6...762	—	6...762	6...762	—	6...762	6...762	—	6...762	—
No. Fans...Total kW	10...15.9	10...15.9	20...31.8	12...19.1	10...15.9	22...35	12...19.1	12...19.1	24...38.2	12...19.1	12...19.1	24...38.2	12...19.1	24...38.2
Total Airflow — L/s	47 190	47 190	94 380	56 630	47 190	103 820	56 630	56 630	113 260	56 630	56 630	113 260	56 630	113 260
High Static														
Fan Speed — r/s	24.1	24.1	—	24.1	24.1	—	24.1	24.1	—	24.1	24.1	—	24.1	—
No. Blades...Diameter — mm	12...762	12...762	—	12...762	12...762	—	12...762	12...762	—	12...762	12...762	—	12...762	—
No. Fans...Total kW	10...37.0	10...37.0	20...74	12...44.4	10...37.0	22...81.4	12...44.4	12...44.4	24...88.8	12...44.4	12...44.4	24...88.8	12...44.4	24...88.8
Total Airflow...L/s**	47 190	47 190	94 380	56 630	47 190	103 820	56 630	56 630	113 260	56 630	56 630	113 260	56 630	113 260
CONDENSER COILS — Type														
Tubes (Copper), OD — mm	9.53	9.53	—	9.53	9.53	—	9.53	9.53	—	9.53	9.53	—	9.53	—
No. Rows — Ckt A or B	3	3	—	3	3	—	3	3	—	3	3	—	3	—
Face Area m² — Ckt A and B Total	20.92	20.92	41.84	24.98	20.92	45.9	24.98	24.98	49.96	24.98	24.98	49.96	24.98	49.96
Max Working Pressure Refrigerant — kPa	3103	3103	—	3103	3103	—	3103	3103	—	3103	3103	—	3103	—
COOLER — No. Type														
Weight (empty) — kg	741	741	1482	741	741	1482	741	741	1589	741	741	1589	741	1696
No. Refrigerant Circuits	2	2	4	2	2	4	2	2	4	2	2	4	2	4
Net Fluid Volume — L (includes nozzles)	229	229	458	229	229	458	267	229	496	267	229	496	267	534
Max Working Pressure Refrigerant Side/Fluid Side — kPa	1916/2068	1916/2068	—/—	1916/2068	1916/2068	—/—	1916/2068	1916/2068	—/—	1916/2068	1916/2068	—/—	1916/2068	—/—
FLUID CONNECTIONS — in.														
Inlet and Outlet	6	6	—	6	6	—	6	6	—	6	6	—	6	—
Drain (NPT)	3/4	3/4	—	3/4	3/4	—	3/4	3/4	—	3/4	3/4	—	3/4	—

LEGEND

C-AL — Copper Tubing — Aluminum Fins Condenser Coil
 C-C — Copper Tubing — Copper Fins Condenser Coil
 Ckt — Circuit
 ESP — External Static Pressure
 OD — Outside Diameter

*06E150 compressors have 4 cylinders; all others have 6.

†Recommended oil is an ISO (International Standards Organization) viscosity grade 68, inhibited polyolester-based (POE), synthetic compressor oil.

**Based on rated ESP of 100 Pa or 250 Pa as appropriate.

NOTE: When facing the compressors, Circuit A is on the right and Circuit B is on the left.

Step 2 — Join Modules A and B (230-420 Units Only)

— If accessory trim kit has been purchased to join the modules together, install it now. Refer to accessory installation instructions for installation details.

Step 3 — Check Compressor Mounting — Compressors are mounted on rails. Each rail is mounted on springs (one at each end, and one between each compressor) when applicable. For shipping, the rails are secured to the frame base at each support. Before start-up, loosen the hold-down bolts so that the compressor rails float freely. See Fig. 12-15 for views of compressor mounting.

Step 4 — Cooler Fluid and Drain Piping Connections — When facing cooler side of unit, inlet (return) fluid connection is on the right. It is recommended that a screen strainer with a minimum size of 20 mesh be installed ahead of the cooler inlet to prevent debris from damaging internal tubes of cooler. Outlet (supply) fluid connection is on the left. The cooler has fluid-side Victaulic-type connections (follow connection directions as provided by the coupling manufacturer). If compressor and cooler grilles have been added, holes must be cut in grilles for field piping and insulation.




Fig. 12 — Compressor Mounting View, 30GU040-070 Units




Fig. 13 — Compressor Mounting View, 30GU080-420 Units




Fig. 14 — Compressor Mounting Bolt, 30GU040-070 Units




Fig. 15 — Compressor Mounting Bolts, 30GU080-420 Units

NOTE: For sizes 130-210 and associated modular units (see Table 1), be sure that cooler piping does not interfere with the electrical connections.

Although cooler has an air vent, it is recommended that field-supplied air vents be installed in system to facilitate servicing. Field-supplied shut-off valves should also be installed to facilitate servicing and flow balancing. Locate valves in return and supply cooler fluid lines as close to the chiller as possible. Locate air vents at highest point of the cooler fluid system.

Upon completion of the field piping installation, in areas where the piping is exposed to 32 F (0° C) or lower ambient temperatures, freeze-up protection is recommended using inhibited ethylene glycol or other suitable corrosion-inhibited anti-freeze solution and electric heater tapes. Heater tapes should have a rating for area ambient temperatures, and should be covered with a suitable thickness of closed-cell insulation. Route power for the heater tapes from a separate fused disconnect. Mount the disconnect within sight from the unit per NEC or local codes. Label disconnect as heater tape power source with warning that power must not be turned off except when servicing the unit.

IMPORTANT: Before starting unit, be sure all of the air has been purged from the system.

A drain connection is located at leaving fluid (supply) end of cooler. See Fig. 1-6 for connection location.

PREPARATION FOR YEAR-ROUND OPERATION — If unit is to operate all year, add sufficient inhibited ethylene glycol or other suitable corrosion-inhibited anti-freeze solution to the cooler fluid to prevent freeze-up under cold operating conditions. Consult local water authority on characteristics of area water and a recommended inhibitor for the cooler fluid loop.

PREPARATION FOR WINTER SHUTDOWN — *Do not shut off control power disconnect during off-season shutdown.*

At end of cooling season:

1. If unit has optional heater tapes on cooler, remove fuse no. 1.

⚠ CAUTION

Failure to remove fuse no. 1 before draining heater-equipped coolers can result in heater tape and insulation damage.

2. Drain the fluid from the system.
3. Replace the drain plug and add 2 gallons (8 liters) (040-110 and associated modular units), 3 gallons (11.4 liters) (130-190 and associated modular units), or 4 gallons (15.1 liters) (210 and associated modular units) of inhibited ethylene glycol or other suitable corrosion-inhibited anti-freeze solution to the cooler to prevent freezing of any remaining water in system. Anti-freeze can be added through the vent on top of cooler.
4. Open one of the thermistor connections to allow air to escape the vessel and the anti-freeze to enter.
5. At the beginning of the next cooling season, refill cooler, add recommended inhibitor, and replace fuse no. 1 if previously removed.

Step 5 — Make Electrical Connections — The electrical characteristics of the available power supply must agree with the unit nameplate rating. Supply voltage must be within the limits shown. The control box is divided into field power side on the right, and control power supply on the left (when facing control box) on sizes 040-110 and associated modular units. (See Table 1.) On sizes 130-210 and associated modular units (see Table 1), the power box is located on the cooler side of the unit, and the control box is located on the compressor side.

FIELD POWER CONNECTIONS (See Fig. 16-21) — All power wiring must comply with applicable local and national codes. Install field-supplied, branch circuit fused disconnect(s) of a type that can be locked off or open. Disconnect(s) must be located within sight from and readily accessible from unit in compliance with NEC Article 440-14. See Tables 4A-7 for unit electrical data.

IMPORTANT: The 30GU 380/415 v and 460 v units have a factory-installed option for a non-fused disconnect for power and control entry. If the unit is equipped with this option, all field wiring should be to the non-fused disconnect rather than the terminal blocks.

30GU040-110 and 230B-315B Units — All field power enters the unit through the control box at the left end when facing the compressors. An access hole is under the control box. All units have a single location for power connection (except sizes 050-070, 208/230 v units, which have 2) to simplify the field power wiring. Maximum wire size that the unit terminal block will accept is 500 kcmil. Unit may use copper, copper-clad aluminum, or aluminum conductors at all voltages, except 30GU110, 290B, and 315B 346-3-50 units and 30GU110, 290B, and 315B 380/415-3-50 part-wind units. These units require copper-only conductors.

For 208/230-3-60 (050-420) units, larger than 500 kcmil conductors are required. Power must be supplied by 6 parallel conductors for these units.

30GU130-210, 230A-315A, and 330-420 Units — The field power wiring enters the unit through the left side of the cooler side power box. The control power enters the control box on the compressor side of the unit.

NOTE: If optional non-fused disconnect is installed, power wiring must enter through center panel of unit (disconnect location).

IMPORTANT: Do not obstruct the field cooler connections when installing field power into the power box. Use 90-degree liquid-tight conduit fittings to connect field power to the unit and avoid the cooler piping area.

All units have a single location for power connection (one per module on 230-420 units) to simplify field power wiring. The maximum acceptable wire size for the terminal block is 500 kcmil. Copper, copper-clad aluminum, or aluminum conductors are acceptable for all units except 30GU210, 315A, 390A, and 420A/B 208/230-3-60 units. These units require copper conductors. For 208/230-3-60 units, 9 parallel conductors are required. All other voltages require 6 parallel conductors.

LEGEND AND NOTES FOR WIRING DIAGRAMS (FIG 16-21)

LEGEND

EQUIP	— Equipment
GND	— Ground
Kcmil	— Thousand Circular Mils
NEC	— National Electrical Code (U.S.A.)
TB	— Terminal Block
----	Field Power Wiring
- - - -	Field Control Wiring
_____	Factory Installed Wiring

NOTES:

1. Factory wiring is in accordance with NEC. Field modifications or additions must be in compliance with all applicable codes.
2. Wiring for main field power supply must be rated 75° C minimum. Use copper, copper-clad aluminum, or aluminum conductors for all units, except use copper conductors only for the following units: 30GU110, 290B, and 315B 346-v; 30GU110, 290B, and 315B 380/415-v part-wind start; 30GU210, 315A, 390A, 420A/B 208/230-v part-wind start and across-the-line start
3. Dimensions in [] are millimeters




Fig. 16 — Field Power Wiring; Unit Sizes 040-070




Fig. 17 — Field Power Wiring; Unit Sizes 080-110




Fig. 18 — Field Power Wiring; Unit Sizes 130-210





Fig. 20 — Field Power Wiring; Unit Sizes 230A-315A, 330A/B-420A/B



LEGEND

NEC — National Electrical Code (U.S.A.)

NOTE: See Fig. 7 for location of non-fused disconnect on unit

Fig. 19 — Field Power Wiring; Unit Sizes 130-210, 230A-315A, 330A/B-420A/B with Non-Fused Disconnect Option




Fig. 21 — Field Power Wiring; Unit Sizes 230B-315B

FIELD CONTROL POWER CONNECTIONS (See Fig. 22-24) — *For 208/230-, 460- and 575-3-60 units:* If the accessory transformer is not used, provide a 115-1-60 power source for the control circuit, through a field-supplied fused disconnect (per NEC). This conductor *must be copper only*. Control power enters the control box through a 7/8-in. (22.2-mm) conduit connection located on the right side of the control section.

For 30GU040-110 and 230B-315B units with 380-3-60 or 380/415-3-50 power: Control circuit voltage is taken from the line voltage, therefore, no additional power supply is required. If a separate power source is required, follow these instructions and disconnect the wires between the control and power terminal blocks.

Units with a power supply of 380-3-60 have 230-1-60 control circuit power, which is taken from the unit's power supply voltage. Units with a power supply of 380/415-3-50 have 230-1-50 control circuit power, which is also taken from the unit's power supply voltage. For control circuit current draw, see Table 5.

For 30GU040-110 and 230B-315B Units with 346-3-50 power: A separate 230-1-50 control power source is required. Provide a 230-1-50 power source for the control circuit through a field-supplied fused disconnect (per NEC or local code). This conductor *must be copper only*. Control power enters the control box through a 7/8-in. (22 mm) conduit connection located on the right side of the control section.

For 30GU130-210, 230A-315A, and 330A/B-420A/B units with 380-3-60 or 380/415-3-50 power: Control voltage is tapped from line to neutral. No additional power supply is required. If a separate power source is required, follow these

instructions and disconnect the wires between the control and power terminal blocks.

Units with a power supply of 380-3-60 have 230-1-60 control circuit power, which is taken from the unit's power supply voltage. Units with a power supply of 380/415-3-50 have 230-1-50 control circuit power, which is also taken from the unit's power supply voltage. For control circuit current draw, see Table 5.

For 30GU130-210, 230A-315A, and 330A/B-420A/B Units with 346-3-50 power: A separate 230-1-50 control power source is required. Provide a 230-1-50 power source for the control circuit through a field-supplied fused disconnect (per NEC or local code). This conductor *must be copper only*. Control power enters the control box through a 7/8-in. (22 mm) conduit connection located on the right side of the control section.

All Units: Control circuit power draw includes the compressor crankcase heaters at 180 w each, up to 8 cooler heaters (if equipped) at 210 w each, and the electronic board heater (if equipped) at 120 w.

⚠ CAUTION

Crankcase heaters, cooler heaters, and board heater are all wired into the control circuit ahead of the control circuit switch. Therefore, they are always active even if the control circuit switch is off.

An interlock circuit for external safeties, such as the chilled fluid flow switch (CWFS), remote on-off, and chilled fluid pump interlock (CWPI) is provided between terminals TB6-3 and TB6-4 for field use. To use this circuit, remove the factory jumper and install the switches.

LEGEND AND NOTES FOR WIRING DIAGRAMS (FIG. 22-24)

LEGEND	
A	— Alarm
CWFS	— Chilled Water (Fluid) Flow Switch
CWPI	— Chilled Water (Fluid) Pump Interlock
EQUIP	— Equipment
NEC	— National Electrical Code
O.A.	— Outdoor Air
TB	— Terminal Block
----	Field Power Wiring
----	Field Control Wiring
----	Factory Installed Wiring

NOTES:

- 1 Factory wiring is in accordance with NEC (U S A) Field modifications or additions must be in compliance with all applicable codes
- 2 Wiring for main field power supply must be rated 75° C minimum. Use copper, copper-clad aluminum, or aluminum conductors for all units, except use copper conductors only for the following units:
30GU110, 290B, 315B 346-v, 30GU110, 290B, 315B 380/415-v part-wind start; 30GU210, 315A, 390A, 420A/B 208/230-v part-wind start and across-the-line start

- 3 Power for control circuit should be supplied from a separate source through a field-supplied fused disconnect with 30-amp maximum protection for 115-v circuits, and 5 amp (040-110 and associated modular units) or 10-amp (130-210 and associated modular units) maximum protection for 230-v control circuit. For a unit with cooler heaters, the field-supplied disconnect must have 30-amp maximum protection for 115-v control circuits, and 15-amp maximum protection for 230-v control circuit. See Table 5. Connect control circuit power to terminals 1 and 2 of TB4. Connect neutral side of supply to terminal 2 of TB4. Control circuit conductors for all units must be copper only
4. Terminals 3 and 4 of TB6 are for field connection for remote ON-OFF control, CWPI, and CWFS. The contacts must be rated for dry circuit application capable of reliably switching a 5 vdc, .5 mA load. Remove jumper between 3 and 4 of TB6 if remote ON-OFF is installed
- 5 The maximum load allowed for the remote alarm circuit is 75 va sealed, 360 va inrush at 115- or 230-v, depending on model. Remove resistor across terminals 1 and 2 of TB5 (040-110 and 230B-315B units) when using remote alarm
- 6 Dimensions in [] are millimeters




Fig. 22 — Field Control Power Wiring; Unit Sizes 040-070




Fig. 23 — Field Control Power Wiring; Unit Sizes 080-110, 230B-315B




Fig. 24 — Field Control Power Wiring; Unit Sizes 130-210, 230A-315A, 330A/B-420A/B

LEGEND AND NOTES FOR TABLES 4A - 7

LEGEND

FLA	— Full Load Amps (Fan Motors)
ICF	— Maximum Instantaneous Current Flow during starting (the point in the starting sequence where the sum of the LRA for the starting compressor, plus the total RLA for all running compressors, plus the total FLA for all running fan motors is maximum)
kW	— Total condenser fan motor power input
LRA	— Locked Rotor Amps
MCA	— Minimum Circuit Amps (for wire sizing) — complies with NEC Section 430-24
MOCP	— Maximum Overcurrent Protective Device Amps
NEC	— National Electrical Code, U S A
PW	— Part Wind
RLA	— Rated Load Amps (Compressors)
XL	— Across-the-Line



*Units are suitable for use on electrical systems where voltage supplied to the unit terminals is not below or above the listed minimum and maximum limits. Maximum allowable phase imbalance is: voltage, 2%, amps, 10%.

†Contact your local representative for 575-v part-wind details.

NOTES:

1. All modules have single point primary power connection. (Each module requires its own power supply.) Main power must be supplied from a field-supplied disconnect.
2. The unit control circuit power (115 v, single-phase for 208/230-, 460-, and 575-v units; 230 v, single-phase for all other voltages) must be supplied from a separate source through a field-supplied disconnect. The control circuit transformer accessory may be applied to power from primary unit power.

3. Crankcase and cooler heaters are wired into the control circuit so they are always operable as long as the control circuit power supply disconnect is on, even if any safety device is open, and the unit ON/OFF switch is in the OFF position.
4. Units have the following power wiring terminal blocks and parallel conductors:

UNIT SIZE	VOLTAGE	TERMINAL BLOCKS	PARALLEL CONDUCTORS
040 to 110, 230B to 315B	208/230	1	3 (040,045), 6 (all others)
	460	1	3
	575	1	3
	380	1	3
	346	1	3
	380/415	1	3
130 to 210, 230A to 315A, 330A/B to 420A/B	208/230	3	9
	460	2	6
	575	2	6
	380	2	6
	346	2	6
	380/415	2	6

5. Maximum incoming wire size for each terminal block is 500 kcmil.
6. Power draw of control circuits includes both crankcase heaters and cooler heaters (where used). Each compressor has a crankcase heater which draws 180 w of power. Units ordered with cooler heater option have 2 (040-050), 4 (060,070), or 8 (080-420) cooler heaters, 210 w each and a 120 w circuit board heater (040-070).

Table 4A — Unit Electrical Data, 30GU040-210 Units

UNIT SIZE 30GU	VOLTAGE			STANDARD CONDENSER FAN						HIGH STATIC CONDENSER FAN					
				MCA		MOCP		ICF		MCA		MOCP		ICF	
	Nameplate V-Hz (3 Phase)	Supplied*		XL	PW	XL	PW	XL	PW	XL	PW	XL	PW	XL	PW
040	208/230-60	187	253	148.7	148.7	200	200	361.2	248.2	185.3	185.3	225	225	397.8	284.8
	380-60	342	418	80.6	76.1	100	100	201.5	136.5	94.6	90.1	110	110	215.5	150.5
	460-60	414	506	76.0	71.5	100	90	181.9	122.9	90.2	85.7	110	110	196.1	137.1
	575-60	518	633	66.9	†	90	†	135.3	†	74.1	†	90	†	142.5	†
	346-50	325	380	101.9	101.9	125	125	304.8	200.8	119.1	119.1	150	150	322.0	218.0
	380/415-50	342	440	84.2	80.5	110	110	213.9	142.9	101.4	97.7	125	125	231.1	160.1
045	208/230-60	187	253	163.1	163.1	225	225	423.2	285.2	199.7	199.7	250	250	459.8	321.8
	380-60	342	418	87.8	84.1	110	110	235.5	157.5	101.8	98.1	125	125	249.5	171.5
	460-60	414	506	83.2	79.5	110	110	212.9	141.9	97.4	93.8	125	125	227.1	156.1
	575-60	518	633	73.3	†	100	†	157.3	†	80.5	†	100	†	164.5	†
	346-50	325	380	118.6	118.6	150	150	321.5	217.5	135.8	135.8	175	175	338.7	234.7
	380/415-50	342	440	101.1	101.4	125	125	269.9	179.3	118.3	118.6	150	150	286.8	196.5
050	208/230-60	187	253	200.3	200.3	250	250	535.7	357.7	236.9	236.9	300	300	572.3	394.3
	380-60	342	418	107.1	105.0	150	125	297.2	196.9	121.1	119.0	150	150	311.2	210.9
	460-60	414	506	100.1	100.4	125	125	268.6	178.3	114.3	114.6	150	150	282.8	192.5
	575-60	518	633	88.0	83.4	110	110	206.4	139.8	95.2	90.6	125	125	213.6	147.0
	346-50	325	380	161.9	161.9	225	225	462.5	302.5	179.1	179.1	250	250	479.7	319.7
	380/415-50	342	440	131.7	127.4	175	175	360.6	239.9	148.9	144.6	200	200	377.8	257.1
060	208/230-60	187	253	265.4	265.4	350	350	731.1	487.1	320.4	320.4	400	400	786.1	542.1
	380-60	342	418	167.4	167.6	225	225	450.9	298.3	188.4	188.6	250	250	471.9	319.3
	460-60	414	506	136.1	131.8	175	175	365.0	244.3	157.5	157.5	200	200	386.4	265.7
	575-60	518	633	115.4	109.8	150	150	300.9	199.7	126.2	120.6	150	150	311.7	210.5
	346-50	325	380	205.3	205.3	250	250	505.9	345.9	231.1	231.1	300	300	531.7	371.7
	380/415-50	342	440	155.0	144.9	200	200	383.9	257.4	180.8	170.7	225	225	409.7	283.2
070	208/230-60	187	253	292.3	292.3	400	400	758.0	514.0	347.3	347.3	450	450	813.0	569.0
	380-60	342	418	200.7	202.1	250	250	484.2	332.8	221.7	223.1	300	300	505.2	353.8
	460-60	414	506	153.4	143.3	200	175	382.3	255.8	174.8	164.7	200	200	403.7	277.2
	575-60	518	633	125.7	121.4	150	150	311.2	211.3	136.5	132.2	175	175	322.0	222.1
	346-50	325	380	215.6	215.6	250	250	516.2	356.2	241.4	241.4	300	300	542.0	382.0
	380/415-50	342	440	163.3	155.1	200	200	392.2	267.6	189.1	180.9	225	225	418.0	293.4

Table 4A — Unit Electrical Data, 30GU040-210 (cont)

UNIT SIZE 30GU	VOLTAGE			STANDARD CONDENSER FAN						HIGH STATIC CONDENSER FAN					
				MCA		MOCF		ICF		MCA		MOCF		ICF	
	Nameplate V-Hz (3 Phase)	Supplied*		XL	PW	XL	PW	XL	PW	XL	PW	XL	PW	XL	PW
080	208/230-60	187	253	321 8	321 8	400	400	787 5	543 5	376.8	376 8	450	450	842 5	598 5
	380-60	342	418	196.3	194 5	250	250	479 8	325.2	217 3	215 5	250	250	500.8	346 2
	460-60	414	506	165 0	158 7	225	200	393 9	271 2	186.4	180 1	225	225	415 3	292 6
	575-60	518	633	139 1	†	175	†	324 6	†	149 9	†	175	†	335.4	†
	346-50	325	380	250 2	250 2	300	300	550 8	390 8	276.0	276 0	350	350	576 6	416 6
	380/415-50	342	440	189.6	178.2	250	225	418.5	290.7	215.4	204.0	250	250	444 3	316 5
090	208/230-60	187	253	309 7	309 7	350	350	569 8	431 8	364.7	364 7	400	400	624 8	486 8
	380-60	342	418	164.8	158 5	175	175	312 5	231 9	185 8	179 5	200	200	333.5	252 9
	460-60	414	506	157 8	151 5	175	175	287 5	213 9	179.2	172 9	200	200	308 9	235 3
	575-60	518	633	137 7	†	150	†	221 7	†	148 5	†	175	†	232.5	†
	346-50	325	380	260.5	260.5	300	300	561 1	401 1	286 3	286 3	350	350	586 9	426.9
	380/415-50	342	440	206 9	200.0	250	250	435.8	312 5	232.7	225 8	250	250	461 6	338 3
100	208/230-60	187	253	378 3	378 3	450	450	713 7	535 7	451 7	451 7	500	500	787 1	609 1
	380-60	342	418	202 8	198 8	225	225	392.9	290 7	230 8	226 8	250	250	420 9	318 7
	460-60	414	506	189 1	189 4	225	225	357 6	267.3	217 7	218 0	250	250	386 2	295 9
	575-60	518	633	166 9	158 5	200	175	285 3	214 9	181.3	172 9	200	200	299 7	229 3
	346-50	325	380	303 9	303 9	350	350	604 5	444 5	338 3	338 3	400	400	638.9	478.9
	380/415-50	342	440	230 2	217.5	250	250	459.1	330 0	264 6	251 9	300	300	493 5	364.4
110	208/230-60	187	253	412.0	412.0	500	500	877 7	633 7	485 4	485.4	600	600	951.1	707.1
	380-60	342	418	244 4	242.0	300	300	527 9	372 7	272 4	270 0	350	300	555 9	400 7
	460-60	414	506	210.7	203 8	250	250	439.6	316.3	239 3	232.4	300	250	468 2	344.9
	575-60	518	633	179 8	173 0	225	200	365.3	262.9	194.2	187 4	225	225	379 7	277 3
	346-50	325	380	373.1	373.1	450	450	673.7	513.7	407.5	407.5	450	450	708 1	548.1
	380/415-50	342	440	282.8	263.7	300	300	511.7	376.2	317.2	298.1	350	350	546.1	410.6
130	208/230-60	187	253	491 1	491 1	600	600	956 8	712.8	582 7	582 7	600	600	1048 4	804.4
	380-60	342	418	307 3	307.5	350	350	590.8	438.2	342.3	342 5	400	400	625.8	473.2
	460-60	414	506	251.6	244 1	300	300	480.5	356 6	287.2	279.7	300	300	516 1	392.2
	575-60	518	633	212 3	201 6	250	225	397 8	291.5	230 2	219.6	250	250	415.8	309.5
	346-50	325	380	357 6	357.6	400	400	658 2	498.2	400.6	400 6	450	450	701 2	541.2
	380/415-50	342	440	288.8	280.0	300	300	517.7	392.5	331.8	323.0	350	350	560.7	435.5
150	208/230-60	187	253	517 8	517.8	600	600	983 5	739.5	609 4	609 4	700	700	1075 1	831.1
	380-60	342	418	320 1	317 6	350	350	603.6	448.3	355 1	352.6	400	400	638 6	483 3
	460-60	414	506	268 2	254 2	300	300	497 1	366 7	303 8	289 8	350	300	532.7	402 3
	575-60	518	633	225.7	219 6	250	250	411 2	309.5	243 7	237 6	250	250	429.2	327 5
	346-50	325	380	461 4	461 4	500	500	762 0	602.0	504 4	504 4	600	600	805 0	645.0
	380/415-50	342	440	349.7	326.1	400	350	578.6	438.6	392.7	369.1	450	400	621 6	481.6
170	208/230-60	187	253	607.5	607.5	700	700	942 9	764.9	699 1	699 1	700	700	1034.5	856.5
	380-60	342	418	323 4	319 6	350	350	513.5	411.5	358.4	354.6	400	400	548.5	446.5
	460-60	414	506	299.9	308.0	300	350	468.4	385.9	335.5	343.6	350	350	504 0	421.5
	575-60	518	633	262 1	242 1	300	250	380 5	298 5	280 1	260 1	300	300	398.5	316 5
	346-50	325	380	437.1	437 1	500	500	737 7	577 7	480 1	480 1	500	500	780.7	620 7
	380/415-50	342	440	358.7	348.0	400	400	587.6	460.5	401.7	391.0	450	400	630.6	503.5
190	208/230-60	187	253	637 7	637.7	700	700	1104 4	859 4	747.7	747.7	800	800	1213 4	969 4
	380-60	342	418	384.3	381 9	450	450	667.8	512 6	426.3	423 9	500	500	709.8	554.6
	460-60	414	506	326 2	316 1	350	350	555 1	428 6	369.0	358 9	400	400	597 9	471 4
	575-60	518	633	276.7	264 8	300	300	462.2	354 7	298 3	286 4	300	300	483 8	376 3
	346-50	325	380	549.7	549 7	600	600	850 3	690.3	601 3	601.3	700	700	901 9	741.9
	380/415-50	342	440	416.6	388.5	450	400	645.5	501.0	468.2	440.1	500	450	697.1	552.6
210	208/230-60	187	253	705 6	705.6	800	800	1171.3	927 3	815.6	815 6	1000	1000	1281 3	1037.3
	380-60	342	418	418.9	415.2	450	450	702.4	545 9	460.9	457 2	500	500	744 4	587.9
	460-60	414	506	360 8	349.4	400	400	589.7	461 9	403.6	392.2	450	400	632 5	504 7
	575-60	518	633	305 5	293 0	350	300	491 0	382 9	327 1	314 6	350	350	512 6	404 5
	346-50	325	380	560 0	560.0	600	600	860 6	700 6	611.6	611.6	700	700	912.2	752.2
	380/415-50	342	440	424 9	398 7	450	450	653 8	511.2	476 5	450.3	500	500	705 4	562 8

(See Legend and Notes, page 37)

START-UP CHECKLIST FOR FLOTRONIC™ CHILLER SYSTEMS
(Remove and use for job file)

A. Preliminary Information

JOB NAME _____

LOCATION _____

INSTALLING CONTRACTOR _____

DISTRIBUTOR _____

START-UP PERFORMED BY _____

EQUIPMENT: Chiller: MODEL # _____ SERIAL # _____

COMPRESSORS:

CIRCUIT A

1) M# _____

S# _____

MTR# _____

2) M# _____

S# _____

MTR# _____

3) M# _____

S# _____

MTR# _____

4) M# _____

S# _____

MTR# _____

CIRCUIT B

1) M# _____

S# _____

MTR# _____

2) M# _____

S# _____

MTR# _____

3) M# _____

S# _____

MTR# _____

COOLER:

MODEL # _____

MANUFACTURED BY _____

SERIAL # _____

DATE _____

TYPE OF EXPANSION VALVES (check one): EXV _____ TXV _____

AIR-HANDLING EQUIPMENT:

MANUFACTURER _____

MODEL # _____

SERIAL # _____

ADDITIONAL AIR-HANDLING UNITS AND ACCESSORIES _____

B. Preliminary Equipment Check (YES or NO)

IS THERE ANY SHIPPING DAMAGE? _____ IF SO, WHERE _____

B. Preliminary Equipment Check (cont)

WILL THIS DAMAGE PREVENT UNIT START-UP? _____

HAVE COMPRESSOR BASE RAIL ISOLATORS ALL BEEN PROPERLY ADJUSTED? _____

CHECK POWER SUPPLY. DOES IT AGREE WITH UNIT? _____

HAS THE CIRCUIT PROTECTION BEEN SIZED AND INSTALLED PROPERLY? (refer to Installation Instructions) _____

ARE THE POWER WIRES TO THE UNIT SIZED AND INSTALLED PROPERLY? (refer to Installation Instructions) _____

HAS THE GROUND WIRE BEEN CONNECTED? _____

ARE ALL TERMINALS TIGHT? _____

CHECK AIR SYSTEMS (YES or NO)

ARE ALL AIR HANDLERS OPERATING? (refer to air-handling equipment Installation and Start-Up Instructions) _____

ARE ALL CHILLED FLUID VALVES OPEN? _____

IS THE FLUID PIPING CONNECTED PROPERLY? _____

HAS ALL AIR BEEN VENTED FROM THE COOLER LOOP? _____

IS THE CHILLED WATER (FLUID) PUMP (CWP) OPERATING? _____

IS THE CWP ROTATION CORRECT? _____

CWP MOTOR AMPERAGE: Rated _____ Actual _____

C. Unit Start-Up (insert check mark as each item is completed)

CHECK THAT THE CHILLER HAS BEEN PROPERLY INTERLOCKED WITH THE AUXILIARY CONTACTS OF THE CHILLED FLUID PUMP STARTER. _____

ASSURE THAT THE UNIT IS SUPPLIED WITH CORRECT CONTROL VOLTAGE POWER (115 V for 208/230, 460, and 575 V units; 230 v for 346, 380, and 380/415 V units). _____

ASSURE CRANKCASE HEATERS HAVE BEEN ENERGIZED FOR A MINIMUM OF **24 HOURS** PRIOR TO START-UP.

ASSURE COMPRESSOR OIL LEVEL IS CORRECT. _____

ASSURE BOTH LIQUID LINE SERVICE VALVES ARE BACKSEATED. _____

ASSURE **ALL** COMPRESSOR DISCHARGE SERVICE VALVES ARE BACKSEATED. _____

ASSURE **ALL** COMPRESSOR SUCTION SERVICE VALVES ARE BACKSEATED. _____

LOOSEN COMPRESSOR SHIPPING HOLDDOWN BOLTS. _____

LEAK CHECK **THOROUGHLY**: CHECK ALL COMPRESSORS, CONDENSER MANIFOLDS AND HEADERS, EXVs, TXVs, SOLENOID VALVES, FILTER DRIERS, FUSIBLE PLUGS, THERMISTORS, AND COOLER HEADS, WITH GE H-10-B ELECTRONIC LEAK DETECTOR. _____

LOCATE, REPAIR, AND REPORT ANY R-134a LEAKS. _____

C. Unit Start-Up (cont)

CHECK VOLTAGE IMBALANCE: AB_____ AC_____ BC_____

AB + AC + BC (divided by 3) = AVERAGE VOLTAGE = _____ V

MAXIMUM DEVIATION FROM AVERAGE VOLTAGE = _____

VOLTAGE IMBALANCE = $\frac{(\text{MAX. DEVIATION})}{\text{AVERAGE VOLTAGE}} \times 100 = \text{_____ \% VOLTAGE IMBALANCE}$

IF OVER 2% VOLTAGE IMBALANCE, DO NOT ATTEMPT TO START CHILLER!
CALL LOCAL POWER COMPANY FOR ASSISTANCE.

ASSURE THAT INCOMING POWER VOLTAGE TO CHILLER MODULES IS WITHIN RATED UNIT VOLTAGE RANGE. _____

SYSTEM FLUID VOLUME IN LOOP: TYPE SYSTEM:

AIR CONDITIONING — MINIMUM 3 GAL PER NOMINAL TON (3.25 L PER kW) = _____ GAL (L)

PROCESS COOLING — MINIMUM 6 GAL PER NOMINAL TON (6.50 L PER kW) = _____ GAL (L)

CHECK PRESSURE DROP ACROSS COOLER.

FLUID ENTERING COOLER: _____ PSIG (kPa)

FLUID LEAVING COOLER: _____ PSIG (kPa)

(PSIG DIFFERENCE) x 2.31 = FT OF FLUID PRESSURE DROP = _____

PLOT COOLER PRESSURE DROP ON PERFORMANCE DATA CHART (LOCATED IN PRODUCT DATA LITERATURE) TO DETERMINE TOTAL GPM (L/s).

TOTAL GPM (L/s) = _____

UNIT'S RATED MIN GPM (L/s) = _____

GPM (L/s) PER TON = _____

UNIT'S RATED MIN PRESSURE DROP =
(Refer to product data literature.)

JOB'S SPECIFIED GPM (L/s) (if available): _____

IF UNIT HAS LOW FLUID FLOW, FIND SOURCE OF PROBLEM: CHECK FLUID PIPING, IN-LINE FLUID STRAINER, SHUT-OFF VALVES, CWP ROTATION, ETC.

COOLER LOOP PROTECTION IF REQUIRED:

GALLONS (LITERS) OF BRINE ADDED: _____

PIPING INCLUDES ELECTRIC TAPE HEATERS (Y/N): _____

VISUALLY CHECK PROCESSOR BOARD FOR THE FOLLOWING:

ASSURE ALL DIP SWITCHES ARE PROPERLY SET. _____

INSPECT ALL THERMISTORS AND EXV CABLES FOR POSSIBLE CROSSED WIRES. _____

CHECK TO BE SURE THAT ALL WELL-TYPE THERMISTORS ARE FULLY INSERTED INTO THEIR RESPECTIVE WELLS. _____

ARE ALL RIBBON CABLES AND PIN CONNECTORS TIGHT?(Y/N) _____

ARE RELAY BOARDS AND DISPLAY SET POINT BOARD CONNECTIONS TIGHT? _____

CHECK DIP SWITCH POSITIONS:

ON	OFF	ON	OFF
1 _____	_____	5 _____	_____
2 _____	_____	6 _____	_____
3 _____	_____	7 _____	_____
4 _____	_____	8 _____	_____

C. Unit Start-Up (cont)

TO START THE CHILLER: (insert check mark as each item is completed)

TURN THE ON/OFF SWITCH TO ON POSITION. _____

ENSURE THE SET POINT BOARD LED DISPLAYS NUMBER "20." _____

PUSH THE DISPLAY BUTTON ONCE TO ENTER QUICK TEST MODE. _____

SET POINT BOARD SHOULD DISPLAY NUMBER "88." _____

FOLLOW THE CONTROLS AND TROUBLESHOOTING LITERATURE QUICK TEST INSTRUCTIONS. BE SURE TO CHECK FOR PROPER FAN ROTATION ON QUICK TEST STEPS 3.1. AND 3.2.

QUICK TEST NUMBER READOUTS — INDICATE RESULTS BELOW:

STEPS #	1. _____	8. _____	1.5. _____	2.2. _____	2.9. _____	3.6. _____
	2. _____	9. _____	1.6. _____	2.3. _____	3.0. _____	3.7. _____
	3. _____	1.0. _____	1.7. _____	2.4. _____	3.1. _____	3.8. _____
	4. _____	1.1. _____	1.8. _____	2.5. _____	3.2. _____	3.9. _____
	5. _____	1.2. _____	1.9. _____	2.6. _____	3.3. _____	4.0. _____
	6. _____	1.3. _____	2.0. _____	2.7. _____	3.4. _____	4.1. _____
	7. _____	1.4. _____	2.1. _____	2.8. _____	3.5. _____	4.2. _____

MEASURE THE FOLLOWING WHILE MACHINE IS IN STABLE OPERATING CONDITION.

CIRCUIT A

CIRCUIT B

OIL PRESSURE	_____	_____
SUCTION PRESSURE	_____	_____
SUCTION LINE TEMP	_____	_____
DISCHARGE PRESSURE	_____	_____
DISCHARGE LINE TEMP	_____	_____

USING A DC VOLT-METER AND VOLTAGE VS. TEMPERATURE CHART: MEASURE THE VOLTAGE AT THE J1 THERMISTOR CONNECTIONS ON THE PROCESSOR BOARD WHILE THE UNIT IS OPERATING. INDICATE THE CORRESPONDING VOLTAGE AND TEMPERATURE FOR EACH THERMISTOR:

T1 = _____	VDC = _____
T2 = _____	VDC = _____
T3 = _____	VDC = _____
T4 = _____	VDC = _____
T5 = _____	VDC = _____
T6 = _____	VDC = _____
T7 = _____	VDC = _____
T8 = _____	VDC = _____

NOTES:

Table 4B — Unit Electrical Data, 30GU230-420 Units

UNIT SIZE 30GU	VOLTAGE			MODULE A											
				Standard Condenser Fan						High Static Condenser Fan					
				MCA		MOCP		ICF		MCA		MOCP		ICF	
	Nameplate V-Hz (3 Phase)	Supplied*		XL	PW	XL	PW	XL	PW	XL	PW	XL	PW	XL	PW
		Min	Max												
230A	208/230-60	187	253	517.8	517.8	600	600	983.5	739.5	609.4	609.4	700	700	1075.1	831.1
	380-60	342	418	320.1	317.6	350	350	603.6	448.3	355.1	352.6	400	400	638.6	483.3
	460-60	414	506	268.2	254.2	300	300	497.1	366.7	303.8	289.8	350	300	532.7	402.3
	575-60	518	633	225.7	219.6	250	250	411.2	309.5	243.7	237.6	250	250	429.2	327.5
	346-50	325	380	461.4	461.4	500	500	762.0	602.0	504.4	504.4	600	600	805.0	645.0
	380/415-50	342	440	349.7	326.1	400	350	578.6	438.6	392.7	369.1	450	400	621.6	481.6
245A	208/230-60	187	253	517.8	517.8	600	600	983.5	739.5	609.4	609.4	700	700	1075.1	831.1
	380-60	342	418	320.1	317.6	350	350	603.6	448.3	355.1	352.6	400	400	638.6	483.3
	460-60	414	506	268.2	254.2	300	300	497.1	366.7	303.8	289.8	350	300	532.7	402.3
	575-60	518	633	225.7	219.6	250	250	411.2	309.5	243.7	237.6	250	250	429.2	327.5
	346-50	325	380	461.4	461.4	500	500	762.0	602.0	504.4	504.4	600	600	805.0	645.0
	380/415-50	342	440	349.7	326.1	400	350	578.6	438.6	392.7	369.1	450	400	621.6	481.6
255A	208/230-60	187	253	517.8	517.8	600	600	983.5	739.5	609.4	609.4	700	700	1075.1	831.1
	380-60	342	418	320.1	317.6	350	350	603.6	448.3	355.1	352.6	400	400	638.6	483.3
	460-60	414	506	268.2	254.2	300	300	497.1	366.7	303.8	289.8	350	300	532.7	402.3
	575-60	518	633	225.7	219.6	250	250	411.2	309.5	243.7	237.6	250	250	429.2	327.5
	346-50	325	380	461.4	461.4	500	500	762.0	602.0	504.4	504.4	600	600	805.0	645.0
	380/415-50	342	440	349.7	326.1	400	350	578.6	438.6	392.7	369.1	450	400	621.6	481.6
270A	208/230-60	187	253	607.5	607.5	700	700	942.9	764.9	699.1	699.1	700	700	1034.5	856.5
	380-60	342	418	323.4	319.6	350	350	513.5	411.5	358.4	354.6	400	400	548.5	446.5
	460-60	414	506	299.9	308.0	300	350	468.4	385.9	335.5	343.6	350	350	504.0	421.5
	575-60	518	633	262.1	242.1	300	250	380.5	298.5	280.1	260.1	300	300	398.5	316.5
	346-50	325	380	437.1	437.1	500	500	737.7	577.7	480.1	480.1	500	500	780.7	620.7
	380/415-50	342	440	358.7	348.0	400	400	587.6	460.5	401.7	391.0	450	400	630.6	503.5
290A	208/230-60	187	253	637.7	637.7	700	700	1104.4	859.4	747.7	747.7	800	800	1213.4	969.4
	380-60	342	418	384.3	381.9	450	450	667.8	512.6	426.3	423.9	500	500	709.8	554.6
	460-60	414	506	326.2	316.1	350	350	555.1	428.6	369.0	358.9	400	400	597.9	471.4
	575-60	518	633	276.7	264.8	300	300	462.2	354.7	298.3	286.4	300	300	483.8	376.3
	346-50	325	380	549.7	549.7	600	600	850.3	690.3	601.3	601.3	700	700	901.9	741.9
	380/415-50	342	440	416.6	388.5	450	400	645.5	501.0	468.2	440.1	500	450	697.1	552.6
315A	208/230-60	187	253	705.6	705.6	800	800	1171.3	927.3	815.6	815.6	1000	1000	1281.3	1037.3
	380-60	342	418	418.9	415.2	450	450	702.4	545.9	460.9	457.2	500	500	744.4	587.9
	460-60	414	506	360.8	349.4	400	400	589.7	461.9	403.6	392.2	450	400	632.5	504.7
	575-60	518	633	305.5	293.0	350	300	491.0	382.9	327.1	314.6	350	350	512.6	404.5
	346-50	325	380	560.0	560.0	600	600	860.6	700.6	611.6	611.6	700	700	912.2	752.2
	380/415-50	342	440	424.9	398.7	450	450	653.8	511.2	476.5	450.3	500	500	705.4	562.8
330A	208/230-60	187	253	607.5	607.5	700	700	942.9	764.9	699.1	699.1	700	700	1034.5	856.5
	380-60	342	418	323.4	319.6	350	350	513.5	411.5	358.4	354.6	400	400	548.5	446.5
	460-60	414	506	299.9	308.0	300	350	468.4	385.9	335.5	343.6	350	350	504.0	421.5
	575-60	518	633	262.1	242.1	300	250	380.5	298.5	280.1	260.1	300	300	398.5	316.5
	346-50	325	380	437.1	437.1	500	500	737.7	577.7	480.1	480.1	500	500	780.7	620.7
	380/415-50	342	440	358.7	348.0	400	400	587.6	460.5	401.7	391.0	450	400	630.6	503.5
360A	208/230-60	187	253	637.7	637.7	700	700	1104.4	859.4	747.7	747.7	800	800	1213.4	969.4
	380-60	342	418	384.3	381.9	450	450	667.8	512.6	426.3	423.9	500	500	709.8	554.6
	460-60	414	506	326.2	316.1	350	350	555.1	428.6	369.0	358.9	400	400	597.9	471.4
	575-60	518	633	276.7	264.8	300	300	462.2	354.7	298.3	286.4	300	300	483.8	376.3
	346-50	325	380	549.7	549.7	600	600	850.3	690.3	601.3	601.3	700	700	901.9	741.9
	380/415-50	342	440	416.6	388.5	450	400	645.5	501.0	468.2	440.1	500	450	697.1	552.6
390A	208/230-60	187	253	705.6	705.6	800	800	1171.3	927.3	815.6	815.6	1000	1000	1281.3	1037.3
	380-60	342	418	418.9	415.2	450	450	702.4	545.9	460.9	457.2	500	500	744.4	587.9
	460-60	414	506	360.8	349.4	400	400	589.7	461.9	403.6	392.2	450	400	632.5	504.7
	575-60	518	633	305.5	293.0	350	300	491.0	382.9	327.1	314.6	350	350	512.6	404.5
	346-50	325	380	560.0	560.0	600	600	860.6	700.6	611.6	611.6	700	700	912.2	752.2
	380/415-50	342	440	424.9	398.7	450	450	653.8	511.2	476.5	450.3	500	500	705.4	562.8
420A	208/230-60	187	253	705.6	705.6	800	800	1171.3	927.3	815.6	815.6	1000	1000	1281.3	1037.3
	380-60	342	418	418.9	415.2	450	450	702.4	545.9	460.9	457.2	500	500	744.4	587.9
	460-60	414	506	360.8	349.4	400	400	589.7	461.9	403.6	392.2	450	400	632.5	504.7
	575-60	518	633	305.5	293.0	350	300	491.0	382.9	327.1	314.6	350	350	512.6	404.5
	346-50	325	380	560.0	560.0	600	600	860.6	700.6	611.6	611.6	700	700	912.2	752.2
	380/415-50	342	440	424.9	398.7	450	450	653.8	511.2	476.5	450.3	500	500	705.4	562.8

(See Legend and Notes, page 37.)

Table 4B — Unit Electrical Data, 30GU230-420 Units (cont)

UNIT SIZE 30GU	VOLTAGE			MODULE B											
				Standard Condenser Fan						High Static Condenser Fan					
				MCA		MOCP		ICF		MCA		MOCP		ICF	
	Nameplate V-Hz (3 Phase)	Supplied*		XL	PW	XL	PW	XL	PW	XL	PW	XL	PW	XL	PW
		Min	Max												
230B	208/230-60	187	253	321 8	321 8	400	400	787 5	543.5	376 8	376.8	450	450	842 5	598 5
	380-60	342	418	196 3	194 5	250	250	479 8	325 2	217.3	215 5	250	250	500.8	346.2
	460-60	414	506	165.0	158 7	225	200	393 9	271.2	186 4	180 1	225	225	415 3	292.6
	575-60	518	633	139 1	†	175	†	324.6	†	149.9	†	175	†	335 4	†
	346-50	325	380	250 2	250.2	300	300	550 8	390 8	276.0	276 0	350	350	576 6	416.6
	380/415-50	342	440	189.6	178.2	250	225	418.5	290.7	215.4	204.0	250	250	444.3	316.5
245B	208/230-60	187	253	309 7	309 7	350	350	569 8	431 8	364.7	364 7	400	400	624 8	486 8
	380-60	342	418	164 8	158 5	175	175	312 5	231 9	185.8	179 5	200	200	333 5	252 9
	460-60	414	506	157 8	151 5	175	175	287.5	213 9	179 2	172 9	200	200	308 9	235.3
	575-60	518	633	137.7	†	150	†	221 7	†	148 5	†	175	†	232 5	†
	346-50	325	380	260.5	260.5	300	300	561.1	401 1	286 3	286 3	350	350	586.9	426 9
	380/415-50	342	440	206.9	200.0	250	250	435 8	312.5	232.7	225.8	250	250	461.6	338.3
255B	208/230-60	187	253	378 3	378 3	450	450	713 7	535 7	451.7	451 7	500	500	787 1	609 1
	380-60	342	418	202.8	198.8	225	225	392.9	290 7	230 8	226 8	250	250	420.9	318 7
	460-60	414	506	189 1	189 4	225	225	357 6	267 3	217 7	218 0	250	250	386 2	295.9
	575-60	518	633	166.9	158 5	200	175	285 3	214.9	181 3	172.9	200	200	299 7	229.3
	346-50	325	380	303 9	303.9	350	350	604.5	444.5	338.3	338 3	400	400	638.9	478 9
	380/415-50	342	440	230.2	217.5	250	250	459.1	330 0	264.6	251.9	300	300	493.5	364.4
270B	208/230-60	187	253	378.3	378 3	450	450	713 7	535.7	451 7	451 7	500	500	787 1	609 1
	380-60	342	418	202.8	198.8	225	225	392 9	290 7	230 8	226 8	250	250	420.9	318 7
	460-60	414	506	189 1	189 4	225	225	357 6	267.3	217.7	218.0	250	250	386.2	295.9
	575-60	518	633	166.9	158 5	200	175	285.3	214.9	181 3	172.9	200	200	299 7	229.3
	346-50	325	380	303.9	303 9	350	350	604.5	444 5	338 3	338.3	400	400	638.9	478 9
	380/415-50	342	440	230.2	217.5	250	250	459.1	330.0	264.6	251.9	300	300	493.5	364.4
290B	208/230-60	187	253	412 0	412 0	500	500	877.7	633.7	485 4	485 4	600	600	951 1	707 1
	380-60	342	418	244.4	242.0	300	300	527 9	372 7	272.4	270 0	350	300	555 9	400 7
	460-60	414	506	210 7	203 8	250	250	439.6	316 3	239.3	232.4	300	250	468.2	344.9
	575-60	518	633	179.8	173.0	225	200	365 3	262.9	194.2	187.4	225	225	379.7	277 3
	346-50	325	380	373 1	373.1	450	450	673.7	513 7	407 5	407.5	450	450	708.1	548 1
	380/415-50	342	440	282.8	263.7	300	300	511.7	376.2	317.2	298.1	350	350	546.1	410.6
315B	208/230-60	187	253	412 0	412.0	500	500	877 7	633.7	485 4	485 4	600	600	951 1	707 1
	380-60	342	418	244.4	242.0	300	300	527 9	372.7	272 4	270.0	350	300	555 9	400 7
	460-60	414	506	210 7	203 8	250	250	439 6	316 3	239 3	232 4	300	250	468.2	344.9
	575-60	518	633	179 8	173 0	225	200	365.3	262.9	194.2	187.4	225	225	379.7	277.3
	346-50	325	380	373.1	373 1	450	450	673.7	513.7	407.5	407 5	450	450	708 1	548 1
	380/415-50	342	440	282.8	263.7	300	300	511.7	376.2	317.2	298.1	350	350	546.1	410.6
330B	208/230-60	187	253	607 5	607 5	700	700	942.9	764.9	699.1	699.1	700	700	1034.5	856 5
	380-60	342	418	323.4	319.6	350	350	513.5	411.5	358 4	354 6	400	400	548 5	446.5
	460-60	414	506	299 9	308 0	300	350	468 4	385.9	335.5	343.6	350	350	504.0	421.5
	575-60	518	633	262 1	242 1	300	250	380.5	298.5	280.1	260.1	300	300	398 5	316.5
	346-50	325	380	437.1	437.1	500	500	737.7	577.7	480.1	480 1	500	500	780 7	620 7
	380/415-50	342	440	358.7	348.0	400	400	587.6	460.5	401.7	391.0	450	400	630.6	503.5
360B	208/230-60	187	253	637.7	637 7	700	700	1104 4	859 4	747 7	747.7	800	800	1213.4	969 4
	380-60	342	418	384.3	381.9	450	450	667.8	512.6	426.3	423 9	500	500	709 8	554.6
	460-60	414	506	326 2	316 1	350	350	555 1	428.6	369.0	358.9	400	400	597.9	471.4
	575-60	518	633	276 7	264 8	300	300	462.2	354.7	298.3	286 4	300	300	483.8	376 3
	346-50	325	380	437.1	437.1	500	500	737 7	577.7	480.1	480 1	500	500	780 7	620.7
	380/415-50	342	440	358.7	348.0	400	400	587.6	460.5	401.7	391.0	450	400	630.6	503.5
390B	208/230-60	187	253	637 7	637 7	700	700	1104.4	859.4	747 7	747 7	800	800	1213 4	969 4
	380-60	342	418	384 3	381 9	450	450	667.8	512 6	426 3	423.9	500	500	709 8	554.6
	460-60	414	506	326 2	316.1	350	350	555.1	428 6	369.0	358.9	400	400	597 9	471 4
	575-60	518	633	276 7	264 8	300	300	462.2	354 7	298.3	286 4	300	300	483 8	376.3
	346-50	325	380	549.7	549.7	600	600	850.3	690.3	601 3	601 3	700	700	901.9	741.9
	380/415-50	342	440	416 6	388.5	450	400	645.5	501.0	468.2	440.1	500	450	697.1	552.6
420B	208/230-60	187	253	705.6	705.6	800	800	1171.3	927.3	815.6	815.6	1000	1000	1281.3	1037.3
	380-60	342	418	418.9	415.2	450	450	702 4	545.9	460.9	457 2	500	500	744 4	587.9
	460-60	414	506	360.8	349 4	400	400	589.7	461.9	403.6	392.2	450	400	632 5	504.7
	575-60	518	633	305.5	293.0	350	300	491.0	382 9	327.1	314.6	350	350	512.6	404 5
	346-50	325	380	560 0	560 0	600	600	860 6	700.6	611.6	611 6	700	700	912 2	752 2
	380/415-50	342	440	424.9	398 7	450	450	653.8	511 2	476.5	450.3	500	500	705.4	562 8

(See Legend and Notes, page 37.)

Table 5 — Control Circuit

UNIT POWER SUPPLY (V-Ph-Hz)	CONTROL POWER			AMPS			
	V-Ph-Hz	Min	Max	30GU040-110 and 230B-315B Units		30GU130-210,230A-315A, and 330A/B-420A/B Units	
				With Cooler Heater	Without Cooler Heater	With Cooler Heater	Without Cooler Heater
203/230-3-60	115-1-60	104	127	30	30	30	30
460-3-60	115-1-60	104	127	30	30	30	30
575-3-60	115-1-60	104	127	30	30	30	30
380-3-60	230-1-60	207	254	15	5	15	10
346-3-50	230-1-50	198	254	15	5	15	10
380/415-3-50	230-1-50	198	254	15	5	15	10

See Legend and Notes, page 37

Table 6A — Compressor Electrical Data, 30GU040-210

UNIT SIZE 30GU	NAMEPLATE VOLTAGE (3 Phase)	COMPRESSOR NUMBERS													
		A1		A2		A3		A4		B1		B2		B3	
		RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA
040-XL	208/230-60	56.4	283	—	—	—	—	—	—	56.4	283	—	—	—	—
	380-60	28.9	157	—	—	—	—	—	—	28.9	157	—	—	—	—
	460-60	28.9	142	—	—	—	—	—	—	28.9	142	—	—	—	—
	575-60	23.7	98	—	—	—	—	—	—	23.7	98	—	—	—	—
	346-50	28.2	164	—	—	—	—	—	—	44.9	259	—	—	—	—
	380/415-50	28.9	142	—	—	—	—	—	—	34.6	173	—	—	—	—
040-PW	208/230-60	56.4	170	—	—	—	—	—	—	56.4	170	—	—	—	—
	380-60	26.9	94	—	—	—	—	—	—	26.9	94	—	—	—	—
	460-60	26.9	85	—	—	—	—	—	—	26.9	85	—	—	—	—
	575-60	53.2	59	—	—	—	—	—	—	53.2	59	—	—	—	—
	346-50	28.2	98	—	—	—	—	—	—	44.9	155	—	—	—	—
	380/415-50	26.9	85	—	—	—	—	—	—	33.3	104	—	—	—	—
045-XL	208/230-60	56.4	283	—	—	—	—	—	—	67.9	345	—	—	—	—
	380-60	28.9	157	—	—	—	—	—	—	34.6	191	—	—	—	—
	460-60	28.9	142	—	—	—	—	—	—	34.6	173	—	—	—	—
	575-60	23.7	98	—	—	—	—	—	—	28.8	120	—	—	—	—
	346-50	44.9	259	—	—	—	—	—	—	44.9	259	—	—	—	—
	380/415-50	34.6	173	—	—	—	—	—	—	43.6	223	—	—	—	—
045-PW	208/230-60	56.4	170	—	—	—	—	—	—	67.9	207	—	—	—	—
	380-60	26.9	94	—	—	—	—	—	—	33.3	115	—	—	—	—
	460-60	26.9	85	—	—	—	—	—	—	33.3	104	—	—	—	—
	575-60	53.2	59	—	—	—	—	—	—	28.2	72	—	—	—	—
	346-50	44.9	155	—	—	—	—	—	—	44.9	155	—	—	—	—
	380/415-50	33.3	104	—	—	—	—	—	—	44.9	134	—	—	—	—
050-XL	208/230-60	67.9	345	—	—	—	—	—	—	88.5	446	—	—	—	—
	380-60	34.6	191	—	—	—	—	—	—	45.5	247	—	—	—	—
	460-60	34.6	173	—	—	—	—	—	—	43.6	223	—	—	—	—
	575-60	28.8	120	—	—	—	—	—	—	36.5	164	—	—	—	—
	346-50	44.9	259	—	—	—	—	—	—	79.5	400	—	—	—	—
	380/415-50	43.6	223	—	—	—	—	—	—	60.9	305	—	—	—	—
050-PW	208/230-60	67.9	207	—	—	—	—	—	—	88.5	268	—	—	—	—
	380-60	33.3	115	—	—	—	—	—	—	44.9	148	—	—	—	—
	460-60	33.3	104	—	—	—	—	—	—	44.9	134	—	—	—	—
	575-60	28.2	72	—	—	—	—	—	—	33.3	98	—	—	—	—
	346-50	44.9	155	—	—	—	—	—	—	79.5	240	—	—	—	—
	380/415-50	44.9	134	—	—	—	—	—	—	56.4	183	—	—	—	—
060-XL	208/230-60	88.5	446	—	—	—	—	—	—	115.4	610	—	—	—	—
	380-60	45.5	247	—	—	—	—	—	—	78.8	382	—	—	—	—
	460-60	43.6	223	—	—	—	—	—	—	60.9	305	—	—	—	—
	575-60	36.5	164	—	—	—	—	—	—	46.8	244	—	—	—	—
	346-50	79.5	400	—	—	—	—	—	—	79.5	400	—	—	—	—
	380/415-50	60.9	305	—	—	—	—	—	—	60.9	305	—	—	—	—
060-PW	208/230-60	88.5	268	—	—	—	—	—	—	115.4	366	—	—	—	—
	380-60	44.9	148	—	—	—	—	—	—	79.4	230	—	—	—	—
	460-60	44.9	134	—	—	—	—	—	—	56.4	183	—	—	—	—
	575-60	33.3	98	—	—	—	—	—	—	44.9	146	—	—	—	—
	346-50	79.5	240	—	—	—	—	—	—	79.5	240	—	—	—	—
	380/415-50	56.4	183	—	—	—	—	—	—	56.4	183	—	—	—	—
070-XL	208/230-60	115.4	610	—	—	—	—	—	—	115.4	610	—	—	—	—
	380-60	78.8	382	—	—	—	—	—	—	78.8	382	—	—	—	—
	460-60	60.9	305	—	—	—	—	—	—	60.9	305	—	—	—	—
	575-60	46.8	244	—	—	—	—	—	—	46.8	244	—	—	—	—
	346-50	44.9	259	44.9	259	—	—	—	—	79.5	400	—	—	—	—
	380/415-50	34.6	173	34.6	173	—	—	—	—	60.9	305	—	—	—	—
070-PW	208/230-60	115.4	366	—	—	—	—	—	—	115.4	366	—	—	—	—
	380-60	79.4	230	—	—	—	—	—	—	79.4	230	—	—	—	—
	460-60	56.4	183	—	—	—	—	—	—	56.4	183	—	—	—	—
	575-60	44.9	146	—	—	—	—	—	—	44.9	146	—	—	—	—
	346-50	44.9	155	44.9	155	—	—	—	—	79.5	240	—	—	—	—
	380/415-50	33.3	104	33.3	104	—	—	—	—	56.4	183	—	—	—	—

(See Legend and Notes, page 37)

Table 6A — Compressor Electrical Data, 30GU040-210 (cont)

UNIT SIZE 30GU	NAMEPLATE VOLTAGE (3 Phase)	COMPRESSOR NUMBERS													
		A1		A2		A3		A4		B1		B2		B3	
		RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA
080-XL	208/230-60	88.5	446	56.4	283	—	—	—	—	115.4	610	—	—	—	—
	380-60	45.5	247	28.9	157	—	—	—	—	78.8	382	—	—	—	—
	460-60	43.6	223	28.9	142	—	—	—	—	60.9	305	—	—	—	—
	575-60	36.5	164	23.7	98	—	—	—	—	46.8	244	—	—	—	—
	346-50	44.9	259	79.5	400	—	—	—	—	79.5	400	—	—	—	—
	380/415-50	34.6	173	60.9	305	—	—	—	—	60.9	305	—	—	—	—
080-PW	208/230-60	88.5	268	56.4	170	—	—	—	—	115.4	366	—	—	—	—
	380-60	44.9	148	26.9	94	—	—	—	—	79.4	230	—	—	—	—
	460-60	44.9	134	26.9	85	—	—	—	—	56.4	183	—	—	—	—
	575-60	33.3	98	53.2	59	—	—	—	—	44.9	146	—	—	—	—
	346-50	44.9	155	79.5	240	—	—	—	—	79.5	240	—	—	—	—
	380/415-50	33.3	104	56.4	183	—	—	—	—	56.4	183	—	—	—	—
090-XL	208/230-60	67.9	345	56.4	283	—	—	—	—	67.9	345	67.9	345	—	—
	380-60	34.6	191	28.9	157	—	—	—	—	34.6	191	34.6	191	—	—
	460-60	34.6	173	28.9	142	—	—	—	—	34.6	173	34.6	173	—	—
	575-60	28.8	120	23.7	98	—	—	—	—	28.8	120	28.8	120	—	—
	346-50	44.9	259	79.5	400	—	—	—	—	44.9	259	44.9	259	—	—
	380/415-50	34.6	173	60.9	305	—	—	—	—	34.6	173	43.6	223	—	—
090-PW	208/230-60	67.9	207	56.4	170	—	—	—	—	67.9	207	67.9	207	—	—
	380-60	33.3	115	26.9	94	—	—	—	—	33.3	115	33.3	115	—	—
	460-60	33.3	104	26.9	85	—	—	—	—	33.3	104	33.3	104	—	—
	575-60	28.2	72	53.2	59	—	—	—	—	28.2	72	28.2	72	—	—
	346-50	44.9	155	79.5	240	—	—	—	—	44.9	155	44.9	155	—	—
	380/415-50	33.3	104	56.4	183	—	—	—	—	33.3	104	44.9	134	—	—
100-XL	208/230-60	67.9	345	88.5	446	—	—	—	—	67.9	345	88.5	268	—	—
	380-60	34.6	191	45.5	247	—	—	—	—	34.6	191	44.9	148	—	—
	460-60	34.6	173	43.6	223	—	—	—	—	34.6	173	44.9	134	—	—
	575-60	28.8	120	36.5	164	—	—	—	—	28.8	120	33.3	98	—	—
	346-50	44.9	259	79.5	400	—	—	—	—	44.9	259	79.5	240	—	—
	380/415-50	34.6	173	60.9	305	—	—	—	—	34.6	173	56.4	183	—	—
100-PW	208/230-60	67.9	207	88.5	268	—	—	—	—	67.9	207	88.5	268	—	—
	380-60	33.3	115	44.9	148	—	—	—	—	33.3	115	44.9	148	—	—
	460-60	33.3	104	44.9	134	—	—	—	—	33.3	104	44.9	134	—	—
	575-60	28.2	72	33.3	98	—	—	—	—	28.2	72	33.3	98	—	—
	346-50	44.9	155	79.5	240	—	—	—	—	44.9	155	79.5	240	—	—
	380/415-50	33.3	104	56.4	183	—	—	—	—	33.3	104	56.4	183	—	—
110-XL	208/230-60	67.9	345	115.4	610	—	—	—	—	67.9	345	88.5	446	—	—
	380-60	34.6	191	78.8	382	—	—	—	—	34.6	191	45.5	247	—	—
	460-60	34.6	173	60.9	305	—	—	—	—	34.6	173	43.6	223	—	—
	575-60	28.8	120	46.8	244	—	—	—	—	28.8	120	36.5	164	—	—
	346-50	79.5	400	79.5	400	—	—	—	—	79.5	400	79.5	400	—	—
	380/415-50	60.9	305	60.9	305	—	—	—	—	60.9	305	60.9	305	—	—
110-PW	208/230-60	67.9	207	115.4	366	—	—	—	—	67.9	207	88.5	268	—	—
	380-60	33.3	115	79.4	230	—	—	—	—	33.3	115	44.9	148	—	—
	460-60	33.3	104	56.4	183	—	—	—	—	33.3	104	44.9	134	—	—
	575-60	28.2	72	44.9	146	—	—	—	—	28.2	72	33.3	98	—	—
	346-50	79.5	240	79.5	240	—	—	—	—	79.5	240	79.5	240	—	—
	380/415-50	56.4	183	56.4	183	—	—	—	—	56.4	183	56.4	183	—	—
130-XL	208/230-60	88.5	446	115.4	610	—	—	—	—	88.5	446	115.4	610	—	—
	380-60	45.5	247	78.8	382	—	—	—	—	45.5	247	78.8	382	—	—
	460-60	43.6	223	60.9	305	—	—	—	—	43.6	223	60.9	305	—	—
	575-60	36.5	164	46.8	244	—	—	—	—	36.5	164	46.8	244	—	—
	346-50	44.9	259	44.9	259	44.9	259	—	—	79.5	400	79.5	400	—	—
	380/415-50	34.6	173	43.6	223	43.6	223	—	—	60.9	305	60.9	305	—	—
130-PW	208/230-60	88.5	268	115.4	366	—	—	—	—	88.5	268	115.4	366	—	—
	380-60	44.9	148	79.4	230	—	—	—	—	44.9	148	79.4	230	—	—
	460-60	44.9	134	56.4	183	—	—	—	—	44.9	134	56.4	183	—	—
	575-60	33.3	98	44.9	146	—	—	—	—	33.3	98	44.9	146	—	—
	346-50	44.9	155	44.9	155	44.9	155	—	—	79.5	240	79.5	240	—	—
	380/415-50	33.3	104	44.9	134	44.9	134	—	—	56.4	183	56.4	183	—	—
150-XL	208/230-60	67.9	345	67.9	345	67.9	345	—	—	115.4	610	115.4	610	—	—
	380-60	34.6	191	34.6	191	34.6	191	—	—	78.8	382	78.8	382	—	—
	460-60	34.6	173	34.6	173	34.6	173	—	—	60.9	305	60.9	305	—	—
	575-60	28.8	120	28.8	120	28.8	120	—	—	46.8	244	46.8	244	—	—
	346-50	79.5	400	79.5	400	79.5	400	—	—	79.5	400	79.5	400	—	—
	380/415-50	60.9	305	60.9	305	60.9	305	—	—	60.9	305	60.9	305	—	—
150-PW	208/230-60	67.9	207	67.9	207	67.9	207	—	—	115.4	366	115.4	366	—	—
	380-60	33.3	115	33.3	115	33.3	115	—	—	79.4	230	79.4	230	—	—
	460-60	33.3	104	33.3	104	33.3	104	—	—	56.4	183	56.4	183	—	—
	575-60	28.2	72	28.2	72	28.2	72	—	—	44.9	146	44.9	146	—	—
	346-50	79.5	240	79.5	240	79.5	240	—	—	79.5	240	79.5	240	—	—
	380/415-50	56.4	183	56.4	183	56.4	183	—	—	56.4	183	56.4	183	—	—

(See Legend and Notes, page 37)

Table 6A — Compressor Electrical Data, 30GU040-210 (cont)

UNIT SIZE 30GU	NAMEPLATE VOLTAGE (3 Phase)	COMPRESSOR NUMBERS													
		A1		A2		A3		A4		B1		B2		B3	
		RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA
170-XL	208/230-60	88.5	446	88.5	446	88.5	446	—	—	88.5	446	88.5	446	88.5	446
	380-60	45.5	247	45.5	247	45.5	247	—	—	45.5	247	45.5	247	45.5	247
	460-60	43.6	223	43.6	223	43.6	223	—	—	43.6	223	43.6	223	43.6	223
	575-60	36.5	164	36.5	164	36.5	164	—	—	36.5	164	36.5	164	36.5	164
	346-50	44.9	259	44.9	259	79.5	400	—	—	44.9	259	79.5	400	79.5	400
	380/415-50	34.6	173	34.6	173	60.9	305	—	—	43.6	223	60.9	305	60.9	305
170-PW	208/230-60	88.5	268	88.5	268	88.5	268	—	—	88.5	268	88.5	268	88.5	268
	380-60	44.9	148	44.9	148	44.9	148	—	—	44.9	148	44.9	148	44.9	148
	460-60	44.9	134	44.9	134	44.9	134	—	—	44.9	134	44.9	134	44.9	134
	575-60	33.3	98	33.3	98	33.3	98	—	—	33.3	98	33.3	98	33.3	98
	346-50	44.9	155	44.9	155	79.5	240	—	—	44.9	155	79.5	240	79.5	240
	380/415-50	44.9	134	44.9	134	56.4	183	—	—	44.9	134	56.4	183	56.4	183
190-XL	208/230-60	67.9	345	88.5	446	115.4	610	—	—	67.9	345	88.5	446	115.4	610
	380-60	34.6	191	45.5	247	78.8	382	—	—	34.6	191	45.5	247	78.8	382
	460-60	34.6	173	43.6	223	60.9	305	—	—	34.6	173	43.6	223	60.9	305
	575-60	28.8	120	36.5	164	46.8	244	—	—	28.8	120	36.5	164	46.8	244
	346-50	79.5	400	79.5	400	79.5	400	—	—	79.5	400	79.5	400	79.5	400
	380/415-50	60.9	305	60.9	305	60.9	305	—	—	60.9	305	60.9	305	60.9	305
190-PW	208/230-60	67.9	207	88.5	268	115.4	366	—	—	67.9	207	88.5	268	115.4	366
	380-60	33.3	115	44.9	148	79.4	230	—	—	33.3	115	44.9	148	79.4	230
	460-60	33.3	104	44.9	134	56.4	183	—	—	33.3	104	44.9	134	56.4	183
	575-60	28.2	72	33.3	98	44.9	146	—	—	28.2	72	33.3	98	44.9	146
	346-50	79.5	240	44.9	155	79.5	240	—	—	79.5	240	79.5	240	79.5	240
	380/415-50	56.4	183	44.9	134	56.4	183	—	—	56.4	183	56.4	183	56.4	183
210-XL	208/230-60	67.9	345	67.9	345	67.9	345	67.9	345	88.5	446	115.4	610	115.4	610
	380-60	34.6	191	34.6	191	34.6	191	34.6	191	45.5	247	78.8	382	78.8	382
	460-60	34.6	173	34.6	173	34.6	173	34.6	173	43.6	223	60.9	305	60.9	305
	575-60	28.8	120	28.8	120	28.8	120	28.8	120	36.5	164	46.8	244	46.8	244
	346-50	44.9	259	44.9	259	79.5	400	79.5	400	79.5	400	79.5	400	79.5	400
	380/415-50	34.6	173	34.6	173	60.9	305	60.9	305	60.9	305	60.9	305	60.9	305
210-PW	208/230-60	67.9	207	67.9	207	67.9	207	88.5	268	88.5	268	115.4	366	115.4	366
	380-60	33.3	115	33.3	115	33.3	115	44.9	148	44.9	148	79.4	230	79.4	230
	460-60	33.3	104	33.3	104	33.3	104	44.9	134	44.9	134	56.4	183	56.4	183
	575-60	28.2	72	28.2	72	28.2	72	33.3	98	33.3	98	44.9	146	44.9	146
	346-50	44.9	155	44.9	155	79.5	240	79.5	240	79.5	240	79.5	240	79.5	240
	380/415-50	33.3	104	33.3	104	56.4	183	56.4	183	56.4	183	56.4	183	56.4	183

(See Legend and Notes, page 37.)

Table 6B — Compressor Electrical Data, 30GU230-420

UNIT SIZE 30GU	NAMEPLATE VOLTAGE (3 Phase)	MODULE A													
		Compressor Numbers													
		A1		A2		A3		A4		B1		B2		B3	
		RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA
230A-XL	208/230-60	67.9	345	67.9	345	67.9	345	—	—	115.4	610	115.4	610	—	—
	380-60	34.6	191	34.6	191	34.6	191	—	—	78.8	382	78.8	382	—	—
	460-60	34.6	173	34.6	173	34.6	173	—	—	60.9	305	60.9	305	—	—
	575-60	28.8	120	28.8	120	28.8	120	—	—	46.8	244	46.8	244	—	—
	346-50	79.5	400	79.5	400	79.5	400	—	—	79.5	400	79.5	400	—	—
	380/415-50	60.9	305	60.9	305	60.9	305	—	—	60.9	305	60.9	305	—	—
230A-PW	208/230-60	67.9	207	67.9	207	67.9	207	—	—	115.4	366	115.4	366	—	—
	380-60	33.3	115	33.3	115	33.3	115	—	—	79.4	230	79.4	230	—	—
	460-60	33.3	104	33.3	104	33.3	104	—	—	56.4	183	56.4	183	—	—
	575-60	28.2	72	28.2	72	28.2	72	—	—	44.9	146	44.9	146	—	—
	346-50	79.5	240	79.5	240	79.5	240	—	—	79.5	240	79.5	240	—	—
	380/415-50	56.4	183	56.4	183	56.4	183	—	—	56.4	183	56.4	183	—	—
245A-XL	208/230-60	67.9	345	67.9	345	67.9	345	—	—	115.4	610	115.4	610	—	—
	380-60	34.6	191	34.6	191	34.6	191	—	—	78.8	382	78.8	382	—	—
	460-60	34.6	173	34.6	173	34.6	173	—	—	60.9	305	60.9	305	—	—
	575-60	28.8	120	28.8	120	28.8	120	—	—	46.8	244	46.8	244	—	—
	346-50	79.5	400	79.5	400	79.5	400	—	—	79.5	400	79.5	400	—	—
	380/415-50	60.9	305	60.9	305	60.9	305	—	—	60.9	305	60.9	305	—	—
245A-PW	208/230-60	67.9	207	67.9	207	67.9	207	—	—	115.4	366	115.4	366	—	—
	380-60	33.3	115	33.3	115	33.3	115	—	—	79.4	230	79.4	230	—	—
	460-60	33.3	104	33.3	104	33.3	104	—	—	56.4	183	56.4	183	—	—
	575-60	28.2	72	28.2	72	28.2	72	—	—	44.9	146	44.9	146	—	—
	346-50	79.5	240	79.5	240	79.5	240	—	—	79.5	240	79.5	240	—	—
	380/415-50	56.4	183	56.4	183	56.4	183	—	—	56.4	183	56.4	183	—	—
255A-XL	208/230-60	67.9	345	67.9	345	67.9	345	—	—	115.4	610	115.4	610	—	—
	380-60	34.6	191	34.6	191	34.6	191	—	—	78.8	382	78.8	382	—	—
	460-60	34.6	173	34.6	173	34.6	173	—	—	60.9	305	60.9	305	—	—
	575-60	28.8	120	28.8	120	28.8	120	—	—	46.8	244	46.8	244	—	—
	346-50	79.5	400	79.5	400	79.5	400	—	—	79.5	400	79.5	400	—	—
	380/415-50	60.9	305	60.9	305	60.9	305	—	—	60.9	305	60.9	305	—	—
255A-PW	208/230-60	67.9	207	67.9	207	67.9	207	—	—	115.4	366	115.4	366	—	—
	380-60	33.3	115	33.3	115	33.3	115	—	—	79.4	230	79.4	230	—	—
	460-60	33.3	104	33.3	104	33.3	104	—	—	56.4	183	56.4	183	—	—
	575-60	28.2	72	28.2	72	28.2	72	—	—	44.9	146	44.9	146	—	—
	346-50	79.5	240	79.5	240	79.5	240	—	—	79.5	240	79.5	240	—	—
	380/415-50	56.4	183	56.4	183	56.4	183	—	—	56.4	183	56.4	183	—	—
270A-XL	208/230-60	88.5	446	88.5	446	88.5	446	—	—	88.5	446	88.5	446	88.5	446
	380-60	45.5	247	45.5	247	45.5	247	—	—	45.5	247	45.5	247	45.5	247
	460-60	43.6	223	43.6	223	43.6	223	—	—	43.6	223	43.6	223	43.6	223
	575-60	36.5	164	36.5	164	36.5	164	—	—	36.5	164	36.5	164	36.5	164
	346-50	44.9	259	44.9	259	79.5	400	—	—	44.9	259	79.5	400	79.5	400
	380/415-50	34.6	173	34.6	173	60.9	305	—	—	43.6	223	60.9	305	60.9	305
270A-PW	208/230-60	88.5	268	88.5	268	88.5	268	—	—	88.5	268	88.5	268	88.5	268
	380-60	44.9	148	44.9	148	44.9	148	—	—	44.9	148	44.9	148	44.9	148
	460-60	44.9	134	44.9	134	44.9	134	—	—	44.9	134	44.9	134	44.9	134
	575-60	33.3	98	33.3	98	33.3	98	—	—	33.3	98	33.3	98	33.3	98
	346-50	44.9	155	44.9	155	79.5	240	—	—	44.9	155	79.5	240	79.5	240
	380/415-50	44.9	134	44.9	134	56.4	183	—	—	44.9	134	56.4	183	56.4	183
290A-XL	208/230-60	67.9	345	88.5	446	115.4	610	—	—	67.9	345	88.5	446	115.4	610
	380-60	34.6	191	45.5	247	78.8	382	—	—	34.6	191	45.5	247	78.8	382
	460-60	34.6	173	43.6	223	60.9	305	—	—	34.6	173	43.6	223	60.9	305
	575-60	28.8	120	36.5	164	46.8	244	—	—	28.8	120	36.5	164	46.8	244
	346-50	79.5	400	79.5	400	79.5	400	—	—	79.5	400	79.5	400	79.5	400
	380/415-50	60.9	305	60.9	305	60.9	305	—	—	60.9	305	60.9	305	60.9	305
290A-PW	208/230-60	67.9	207	88.5	268	115.4	366	—	—	67.9	207	88.5	268	115.4	366
	380-60	33.3	115	44.9	148	79.4	230	—	—	33.3	115	44.9	148	79.4	230
	460-60	33.3	104	44.9	134	56.4	183	—	—	33.3	104	44.9	134	56.4	183
	575-60	28.2	72	33.3	98	44.9	146	—	—	28.2	72	33.3	98	44.9	146
	346-50	79.5	240	44.9	155	79.5	240	—	—	79.5	240	79.5	240	79.5	240
	380/415-50	56.4	183	44.9	134	56.4	183	—	—	56.4	183	56.4	183	56.4	183

(See Legend and Notes, page 37)

Table 6B — Compressor Electrical Data, 30GU230-420 (cont)

UNIT SIZE 30GU	NAMEPLATE VOLTAGE (3 Phase)	MODULE B													
		Compressor Numbers													
		A1		A2		A3		A4		B1		B2		B3	
		RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA
230B-XL	208/230-60	88.5	446	56.4	283	—	—	—	—	115.4	610	—	—	—	—
	380-60	45.5	247	28.9	157	—	—	—	—	78.8	382	—	—	—	—
	460-60	43.6	223	28.9	142	—	—	—	—	60.9	305	—	—	—	—
	575-60	36.5	164	23.7	98	—	—	—	—	46.8	244	—	—	—	—
	346-50	44.9	259	79.5	400	—	—	—	—	79.5	400	—	—	—	—
	380/415-50	34.6	173	60.9	305	—	—	—	—	60.9	305	—	—	—	—
230B-PW	208/230-60	88.5	268	56.4	170	—	—	—	—	115.4	366	—	—	—	—
	380-60	44.9	148	26.9	94	—	—	—	—	79.4	230	—	—	—	—
	460-60	44.9	134	26.9	85	—	—	—	—	56.4	183	—	—	—	—
	575-60	33.3	98	53.2	59	—	—	—	—	44.9	146	—	—	—	—
	346-50	44.9	155	79.5	240	—	—	—	—	79.5	240	—	—	—	—
	380/415-50	33.3	104	56.4	183	—	—	—	—	56.4	183	—	—	—	—
245B-XL	208/230-60	67.9	345	56.4	283	—	—	—	—	67.9	345	67.9	345	—	—
	380-60	34.6	191	28.9	157	—	—	—	—	34.6	191	34.6	191	—	—
	460-60	34.6	173	28.9	142	—	—	—	—	34.6	173	34.6	173	—	—
	575-60	28.8	120	23.7	98	—	—	—	—	28.8	120	28.8	120	—	—
	346-50	44.9	259	79.5	400	—	—	—	—	44.9	259	44.9	259	—	—
	380/415-50	34.6	173	60.9	305	—	—	—	—	34.6	173	43.6	223	—	—
245B-PW	208/230-60	67.9	207	56.4	170	—	—	—	—	67.9	207	67.9	207	—	—
	380-60	33.3	115	26.9	94	—	—	—	—	33.3	115	33.3	115	—	—
	460-60	33.3	104	26.9	85	—	—	—	—	33.3	104	33.3	104	—	—
	575-60	28.2	72	53.2	59	—	—	—	—	28.2	72	28.2	72	—	—
	346-50	44.9	155	79.5	240	—	—	—	—	44.9	155	44.9	155	—	—
	380/415-50	33.3	104	56.4	183	—	—	—	—	33.3	104	44.9	134	—	—
255B-XL	208/230-60	67.9	345	88.5	446	—	—	—	—	67.9	345	88.5	268	—	—
	380-60	34.6	191	45.5	247	—	—	—	—	34.6	191	44.9	148	—	—
	460-60	34.6	173	43.6	223	—	—	—	—	34.6	173	44.9	134	—	—
	575-60	28.8	120	36.5	164	—	—	—	—	28.8	120	33.3	98	—	—
	346-50	44.9	259	79.5	400	—	—	—	—	44.9	259	79.5	240	—	—
	380/415-50	34.6	173	60.9	305	—	—	—	—	34.6	173	56.4	183	—	—
255B-PW	208/230-60	67.9	207	88.5	268	—	—	—	—	67.9	207	88.5	268	—	—
	380-60	33.3	115	44.9	148	—	—	—	—	33.3	115	44.9	148	—	—
	460-60	33.3	104	44.9	134	—	—	—	—	33.3	104	44.9	134	—	—
	575-60	28.2	72	33.3	98	—	—	—	—	28.2	72	33.3	98	—	—
	346-50	44.9	155	79.5	240	—	—	—	—	44.9	155	79.5	240	—	—
	380/415-50	33.3	104	56.4	183	—	—	—	—	33.3	104	56.4	183	—	—
270B-XL	208/230-60	67.9	345	88.5	446	—	—	—	—	67.9	345	88.5	268	—	—
	380-60	34.6	191	45.5	247	—	—	—	—	34.6	191	44.9	148	—	—
	460-60	34.6	173	43.6	223	—	—	—	—	34.6	173	44.9	134	—	—
	575-60	28.8	120	36.5	164	—	—	—	—	28.8	120	33.3	98	—	—
	346-50	44.9	259	79.5	400	—	—	—	—	44.9	259	79.5	240	—	—
	380/415-50	34.6	173	60.9	305	—	—	—	—	34.6	173	56.4	183	—	—
270B-PW	208/230-60	67.9	207	88.5	268	—	—	—	—	67.9	207	88.5	268	—	—
	380-60	33.3	115	44.9	148	—	—	—	—	33.3	115	44.9	148	—	—
	460-60	33.3	104	44.9	134	—	—	—	—	33.3	104	44.9	134	—	—
	575-60	28.2	72	33.3	98	—	—	—	—	28.2	72	33.3	98	—	—
	346-50	44.9	155	79.5	240	—	—	—	—	44.9	155	79.5	240	—	—
	380/415-50	33.3	104	56.4	183	—	—	—	—	33.3	104	56.4	183	—	—
290B-XL	208/230-60	67.9	345	115.4	610	—	—	—	—	67.9	345	88.5	446	—	—
	380-60	34.6	191	78.8	382	—	—	—	—	34.6	191	45.5	247	—	—
	460-60	34.6	173	60.9	305	—	—	—	—	34.6	173	43.6	223	—	—
	575-60	28.8	120	46.8	244	—	—	—	—	28.8	120	36.5	164	—	—
	346-50	79.5	400	79.5	400	—	—	—	—	79.5	400	79.5	400	—	—
	380/415-50	60.9	305	60.9	305	—	—	—	—	60.9	305	60.9	305	—	—
290B-PW	208/230-60	67.9	207	115.4	366	—	—	—	—	67.9	207	88.5	268	—	—
	380-60	33.3	115	79.4	230	—	—	—	—	33.3	115	44.9	148	—	—
	460-60	33.3	104	56.4	183	—	—	—	—	33.3	104	44.9	134	—	—
	575-60	28.2	72	44.9	146	—	—	—	—	28.2	72	33.3	98	—	—
	346-50	79.5	240	79.5	240	—	—	—	—	79.5	240	79.5	240	—	—
	380/415-50	56.4	183	56.4	183	—	—	—	—	56.4	183	56.4	183	—	—

(See Legend and Notes, page 37)

Table 6B — Compressor Electrical Data, 30GU230-420 (cont)

UNIT SIZE 30GU	NAMEPLATE VOLTAGE (3 Phase)	MODULE A													
		Compressor Numbers													
		A1		A2		A3		A4		B1		B2		B3	
		RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA
315A-XL	208/230-60	67.9	345	67.9	345	67.9	345	67.9	345	88.5	446	115.4	610	115.4	610
	380-60	34.6	191	34.6	191	34.6	191	34.6	191	45.5	247	78.8	382	78.8	382
	460-60	34.6	173	34.6	173	34.6	173	34.6	173	43.6	223	60.9	305	60.9	305
	575-60	28.8	120	28.8	120	28.8	120	28.8	120	36.5	164	46.8	244	46.8	244
	346-50	44.9	259	44.9	259	79.5	400	79.5	400	79.5	400	79.5	400	79.5	400
	380/415-50	34.6	173	34.6	173	60.9	305	60.9	305	60.9	305	60.9	305	60.9	305
315A-PW	208/230-60	67.9	207	67.9	207	67.9	207	88.5	268	88.5	268	115.4	366	115.4	366
	380-60	33.3	115	33.3	115	33.3	115	44.9	148	44.9	148	79.4	230	79.4	230
	460-60	33.3	104	33.3	104	33.3	104	44.9	134	44.9	134	56.4	183	56.4	183
	575-60	28.2	72	28.2	72	28.2	72	33.3	98	33.3	98	44.9	146	44.9	146
	346-50	44.9	155	44.9	155	79.5	240	79.5	240	79.5	240	79.5	240	79.5	240
	380/415-50	33.3	104	33.3	104	56.4	183	56.4	183	56.4	183	56.4	183	56.4	183
330A-XL	208/230-60	88.5	446	88.5	446	88.5	446	—	—	88.5	446	88.5	446	88.5	446
	380-60	45.5	247	45.5	247	45.5	247	—	—	45.5	247	45.5	247	45.5	247
	460-60	43.6	223	43.6	223	43.6	223	—	—	43.6	223	43.6	223	43.6	223
	575-60	36.5	164	36.5	164	36.5	164	—	—	36.5	164	36.5	164	36.5	164
	346-50	44.9	259	44.9	259	79.5	400	—	—	44.9	259	79.5	400	79.5	400
	380/415-50	34.6	173	34.6	173	60.9	305	—	—	43.6	223	60.9	305	60.9	305
330A-PW	208/230-60	88.5	268	88.5	268	88.5	268	—	—	88.5	268	88.5	268	88.5	268
	380-60	44.9	148	44.9	148	44.9	148	—	—	44.9	148	44.9	148	44.9	148
	460-60	44.9	134	44.9	134	44.9	134	—	—	44.9	134	44.9	134	44.9	134
	575-60	33.3	98	33.3	98	33.3	98	—	—	33.3	98	33.3	98	33.3	98
	346-50	44.9	155	44.9	155	79.5	240	—	—	44.9	155	79.5	240	79.5	240
	380/415-50	44.9	134	44.9	134	56.4	183	—	—	44.9	134	56.4	183	56.4	183
360A-XL	208/230-60	67.9	345	88.5	446	115.4	610	—	—	67.9	345	88.5	446	115.4	610
	380-60	34.6	191	45.5	247	78.8	382	—	—	34.6	191	45.5	247	78.8	382
	460-60	34.6	173	43.6	223	60.9	305	—	—	34.6	173	43.6	223	60.9	305
	575-60	28.8	120	36.5	164	46.8	244	—	—	28.8	120	36.5	164	46.8	244
	346-50	79.5	400	79.5	400	79.5	400	—	—	79.5	400	79.5	400	79.5	400
	380/415-50	60.9	305	60.9	305	60.9	305	—	—	60.9	305	60.9	305	60.9	305
360A-PW	208/230-60	67.9	207	88.5	268	115.4	366	—	—	67.9	207	88.5	268	115.4	366
	380-60	33.3	115	44.9	148	79.4	230	—	—	33.3	115	44.9	148	79.4	230
	460-60	33.3	104	44.9	134	56.4	183	—	—	33.3	104	44.9	134	56.4	183
	575-60	28.2	72	33.3	98	44.9	146	—	—	28.2	72	33.3	98	44.9	146
	346-50	79.5	240	44.9	155	79.5	240	—	—	79.5	240	79.5	240	79.5	240
	380/415-50	56.4	183	44.9	134	56.4	183	—	—	56.4	183	56.4	183	56.4	183
390A-XL	208/230-60	67.9	345	67.9	345	67.9	345	67.9	345	88.5	446	115.4	610	115.4	610
	380-60	34.6	191	34.6	191	34.6	191	34.6	191	45.5	247	78.8	382	78.8	382
	460-60	34.6	173	34.6	173	34.6	173	34.6	173	43.6	223	60.9	305	60.9	305
	575-60	28.8	120	28.8	120	28.8	120	28.8	120	36.5	164	46.8	244	46.8	244
	346-50	44.9	259	44.9	259	79.5	400	79.5	400	79.5	400	79.5	400	79.5	400
	380/415-50	34.6	173	34.6	173	60.9	305	60.9	305	60.9	305	60.9	305	60.9	305
390A-PW	208/230-60	67.9	207	67.9	207	67.9	207	88.5	268	88.5	268	115.4	366	115.4	366
	380-60	33.3	115	33.3	115	33.3	115	44.9	148	44.9	148	79.4	230	79.4	230
	460-60	33.3	104	33.3	104	33.3	104	44.9	134	44.9	134	56.4	183	56.4	183
	575-60	28.2	72	28.2	72	28.2	72	33.3	98	33.3	98	44.9	146	44.9	146
	346-50	44.9	155	44.9	155	79.5	240	79.5	240	79.5	240	79.5	240	79.5	240
	380/415-50	33.3	104	33.3	104	56.4	183	56.4	183	56.4	183	56.4	183	56.4	183
420A-XL	208/230-60	67.9	345	67.9	345	67.9	345	67.9	345	88.5	446	115.4	610	115.4	610
	380-60	34.6	191	34.6	191	34.6	191	34.6	191	45.5	247	78.8	382	78.8	382
	460-60	34.6	173	34.6	173	34.6	173	34.6	173	43.6	223	60.9	305	60.9	305
	575-60	28.8	120	28.8	120	28.8	120	28.8	120	36.5	164	46.8	244	46.8	244
	346-50	44.9	259	44.9	259	79.5	400	79.5	400	79.5	400	79.5	400	79.5	400
	380/415-50	34.6	173	34.6	173	60.9	305	60.9	305	60.9	305	60.9	305	60.9	305
420A-PW	208/230-60	67.9	207	67.9	207	67.9	207	88.5	268	88.5	268	115.4	366	115.4	366
	380-60	33.3	115	33.3	115	33.3	115	44.9	148	44.9	148	79.4	230	79.4	230
	460-60	33.3	104	33.3	104	33.3	104	44.9	134	44.9	134	56.4	183	56.4	183
	575-60	28.2	72	28.2	72	28.2	72	33.3	98	33.3	98	44.9	146	44.9	146
	346-50	44.9	155	44.9	155	79.5	240	79.5	240	79.5	240	79.5	240	79.5	240
	380/415-50	33.3	104	33.3	104	56.4	183	56.4	183	56.4	183	56.4	183	56.4	183

(See Legend and Notes, page 37.)

Table 6B — Compressor Electrical Data, 30GU230-420 (cont)

UNIT SIZE 30GU	NAMEPLATE VOLTAGE (3 Phase)	MODULE B													
		Compressor Numbers													
		A1		A2		A3		A4		B1		B2		B3	
		RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA	RLA	LRA
315B-XL	208/230-60	67.9	345	115.4	610	—	—	—	—	67.9	345	88.5	446	—	—
	380-60	34.6	191	78.8	382	—	—	—	—	34.6	191	45.5	247	—	—
	460-60	34.6	173	60.9	305	—	—	—	—	34.6	173	43.6	223	—	—
	575-60	28.8	120	46.8	244	—	—	—	—	28.8	120	36.5	164	—	—
	346-50	79.5	400	79.5	400	—	—	—	—	79.5	400	79.5	400	—	—
	380/415-50	60.9	305	60.9	305	—	—	—	—	60.9	305	60.9	305	—	—
315B-PW	208/230-60	67.9	207	115.4	366	—	—	—	—	67.9	207	88.5	268	—	—
	380-60	33.3	115	79.4	230	—	—	—	—	33.3	115	44.9	148	—	—
	460-60	33.3	104	56.4	183	—	—	—	—	33.3	104	44.9	134	—	—
	575-60	28.2	72	44.9	146	—	—	—	—	28.2	72	33.3	98	—	—
	346-50	79.5	240	79.5	240	—	—	—	—	79.5	240	79.5	240	—	—
	380/415-50	56.4	183	56.4	183	—	—	—	—	56.4	183	56.4	183	—	—
330B-XL	208/230-60	88.5	446	88.5	446	88.5	446	—	—	88.5	446	88.5	446	88.5	446
	380-60	45.5	247	45.5	247	45.5	247	—	—	45.5	247	45.5	247	45.5	247
	460-60	43.6	223	43.6	223	43.6	223	—	—	43.6	223	43.6	223	43.6	223
	575-60	36.5	164	36.5	164	36.5	164	—	—	36.5	164	36.5	164	36.5	164
	346-50	44.9	259	44.9	259	79.5	400	—	—	44.9	259	79.5	400	79.5	400
	380/415-50	34.6	173	34.6	173	60.9	305	—	—	43.6	223	60.9	305	60.9	305
330B-PW	208/230-60	88.5	268	88.5	268	88.5	268	—	—	88.5	268	88.5	268	88.5	268
	380-60	44.9	148	44.9	148	44.9	148	—	—	44.9	148	44.9	148	44.9	148
	460-60	44.9	134	44.9	134	44.9	134	—	—	44.9	134	44.9	134	44.9	134
	575-60	33.3	98	33.3	98	33.3	98	—	—	33.3	98	33.3	98	33.3	98
	346-50	44.9	155	44.9	155	79.5	240	—	—	44.9	155	79.5	240	79.5	240
	380/415-50	44.9	134	44.9	134	56.4	183	—	—	44.9	134	56.4	183	56.4	183
360B-XL	208/230-60	67.9	345	88.5	446	115.4	610	—	—	67.9	345	88.5	446	115.4	610
	380-60	34.6	191	45.5	247	78.8	382	—	—	34.6	191	45.5	247	78.8	382
	460-60	34.6	173	43.6	223	60.9	305	—	—	34.6	173	43.6	223	60.9	305
	575-60	28.8	120	36.5	164	46.8	244	—	—	28.8	120	36.5	164	46.8	244
	346-50	79.5	400	79.5	400	79.5	400	—	—	79.5	400	79.5	400	79.5	400
	380/415-50	60.9	305	60.9	305	60.9	305	—	—	60.9	305	60.9	305	60.9	305
360B-PW	208/230-60	67.9	207	88.5	268	115.4	366	—	—	67.9	207	88.5	268	115.4	366
	380-60	33.3	115	44.9	148	79.4	230	—	—	33.3	115	44.9	148	79.4	230
	460-60	33.3	104	44.9	134	56.4	183	—	—	33.3	104	44.9	134	56.4	183
	575-60	28.2	72	33.3	98	44.9	146	—	—	28.2	72	33.3	98	44.9	146
	346-50	79.5	240	44.9	155	79.5	240	—	—	79.5	240	79.5	240	79.5	240
	380/415-50	56.4	183	44.9	134	56.4	183	—	—	56.4	183	56.4	183	56.4	183
390B-XL	208/230-60	67.9	345	88.5	446	115.4	610	—	—	67.9	345	88.5	446	115.4	610
	380-60	34.6	191	45.5	247	78.8	382	—	—	34.6	191	45.5	247	78.8	382
	460-60	34.6	173	43.6	223	60.9	305	—	—	34.6	173	43.6	223	60.9	305
	575-60	28.8	120	36.5	164	46.8	244	—	—	28.8	120	36.5	164	46.8	244
	346-50	79.5	400	79.5	400	79.5	400	—	—	79.5	400	79.5	400	79.5	400
	380/415-50	60.9	305	60.9	305	60.9	305	—	—	60.9	305	60.9	305	60.9	305
390B-PW	208/230-60	67.9	207	88.5	268	115.4	366	—	—	67.9	207	88.5	268	115.4	366
	380-60	33.3	115	44.9	148	79.4	230	—	—	33.3	115	44.9	148	79.4	230
	460-60	33.3	104	44.9	134	56.4	183	—	—	33.3	104	44.9	134	56.4	183
	575-60	28.2	72	33.3	98	44.9	146	—	—	28.2	72	33.3	98	44.9	146
	346-50	79.5	240	44.9	155	79.5	240	—	—	79.5	240	79.5	240	79.5	240
	380/415-50	56.4	183	44.9	134	56.4	183	—	—	56.4	183	56.4	183	56.4	183
420B-XL	208/230-60	67.9	345	67.9	345	67.9	345	67.9	345	88.5	446	115.4	610	115.4	610
	380-60	34.6	191	34.6	191	34.6	191	34.6	191	45.5	247	78.8	382	78.8	382
	460-60	34.6	173	34.6	173	34.6	173	34.6	173	43.6	223	60.9	305	60.9	305
	575-60	28.8	120	28.8	120	28.8	120	28.8	120	36.5	164	46.8	244	46.8	244
	346-50	44.9	259	44.9	259	79.5	400	79.5	400	79.5	400	79.5	400	79.5	400
	380/415-50	34.6	173	34.6	173	60.9	305	60.9	305	60.9	305	60.9	305	60.9	305
420B-PW	208/230-60	67.9	207	67.9	207	67.9	207	88.5	268	88.5	268	115.4	366	115.4	366
	380-60	33.3	115	33.3	115	33.3	115	44.9	148	44.9	148	79.4	230	79.4	230
	460-60	33.3	104	33.3	104	33.3	104	44.9	134	44.9	134	56.4	183	56.4	183
	575-60	28.2	72	28.2	72	28.2	72	33.3	98	33.3	98	44.9	146	44.9	146
	346-50	44.9	155	44.9	155	79.5	240	79.5	240	79.5	240	79.5	240	79.5	240
	380/415-50	33.3	104	33.3	104	56.4	183	56.4	183	56.4	183	56.4	183	56.4	183

(See Legend and Notes, page 37.)

Table 7 — Condenser Fan Electrical Data

UNIT SIZE 30GU	NAMEPLATE VOLTAGE (V-Ph-Hz)	STANDARD/LOW NOISE CONDENSER FANS					HIGH STATIC CONDENSER FANS				
		Total Quantity	Hp	kW	(Quantity) FLA (ea)	(Quantity) LRA (ea)	Total Quantity	Hp	kW	(Quantity) FLA (ea)	(Quantity) LRA (ea)
040	208/230-60	4	1	0.746	(2) 6.6, (2) 5.5	(2) 31.6, (2) 30.0	4	5	3.73	(4) 14.6	(4) 41.6
	460-60				(2) 3.3, (2) 2.8	(2) 31.6, (2) 30.0				(4) 6.3	(4) 41.6
	575-60				(4) 3.4	(4) 30.0				(4) 5.2	(4) 42.0
	380-60				(4) 3.9	(4) 20.9				(4) 7.4	(4) 54.0
	346-50				(4) 4.4	(4) 20.9				(4) 8.7	(4) 53.0
	380/415-50				(4) 3.4	(4) 30.0				(4) 7.3	(4) 41.0
045	208/230-60	4	1	0.746	(2) 6.6, (2) 5.5	(2) 31.6, (2) 30.0	4	5	3.73	(4) 14.6	(4) 41.6
	460-60				(2) 3.3, (2) 2.8	(2) 31.6, (2) 30.0				(4) 6.3	(4) 41.6
	575-60				(4) 3.4	(4) 30.0				(4) 5.2	(4) 42.0
	380-60				(4) 3.9	(4) 20.9				(4) 7.4	(4) 54.0
	346-50				(4) 4.4	(4) 20.9				(4) 8.7	(4) 53.0
	380/415-50				(4) 3.4	(4) 30.0				(4) 7.3	(4) 41.0
050	208/230-60	4	1	0.746	(2) 6.6, (2) 5.5	(2) 31.6, (2) 30.0	4	5	3.73	(4) 14.6	(4) 41.6
	460-60				(2) 3.3, (2) 2.8	(2) 31.6, (2) 30.0				(4) 6.3	(4) 41.6
	575-60				(4) 3.4	(4) 30.0				(4) 5.2	(4) 42.0
	380-60				(4) 3.9	(4) 20.9				(4) 7.4	(4) 54.0
	346-50				(4) 4.4	(4) 20.9				(4) 8.7	(4) 53.0
	380/415-50				(4) 3.4	(4) 30.0				(4) 7.3	(4) 41.0
060	208/230-60	6	1	0.746	(4) 6.6, (2) 5.5	(4) 31.6, (2) 30.0	6	5	3.73	(6) 14.6	(6) 41.6
	460-60				(4) 3.3, (2) 2.8	(4) 31.6, (2) 30.0				(6) 6.3	(6) 41.6
	575-60				(6) 3.4	(6) 30.0				(6) 5.2	(6) 42.0
	380-60				(6) 3.9	(6) 20.9				(6) 7.4	(6) 54.0
	346-50				(6) 4.4	(6) 20.9				(6) 8.7	(6) 53.0
	380/415-50				(6) 3.4	(6) 30.0				(6) 7.3	(6) 41.0
070	208/230-60	6	1	0.746	(4) 6.6, (2) 5.5	(4) 31.6, (2) 30.0	6	5	3.73	(6) 14.6	(6) 41.6
	460-60				(4) 3.3, (2) 2.8	(4) 31.6, (2) 30.0				(6) 6.3	(6) 41.6
	575-60				(6) 3.4	(6) 30.0				(6) 5.2	(6) 42.0
	380-60				(6) 3.9	(6) 20.9				(6) 7.4	(6) 54.0
	346-50				(6) 4.4	(6) 20.9				(6) 8.7	(6) 53.0
	380/415-50				(6) 3.4	(6) 30.0				(6) 7.3	(6) 41.0
080,090, 230B,245B	208/230-3-60	6	1	0.746	(4) 6.6, (2) 5.5	(4) 31.6, (2) 30.0	6	5	3.73	(6) 14.6	(6) 41.6
	460-3-60				(4) 3.3, (2) 2.8	(4) 31.6, (2) 30.0				(6) 6.3	(6) 41.6
	575-3-60				(6) 3.4	(6) 30.0				(6) 5.2	(6) 42.0
	380-3-60				(6) 3.9	(6) 20.9				(6) 7.4	(6) 54.0
	346-3-50				(6) 4.4	(6) 20.9				(6) 8.7	(6) 53.0
	380/415-3-50				(6) 3.4	(6) 30.0				(6) 7.3	(6) 41.0
100,110, 255B,270B, 290B,315B	208/230-3-60	8	1	0.746	(6) 6.6, (2) 5.5	(6) 31.6, (2) 30.0	8	5	3.73	(8) 14.6	(8) 41.6
	460-3-60				(6) 3.3, (2) 2.8	(6) 31.6, (2) 30.0				(8) 6.3	(8) 41.6
	575-3-60				(8) 3.4	(8) 30.0				(8) 5.2	(8) 42.0
	380-3-60				(8) 3.9	(8) 20.9				(8) 7.4	(8) 54.0
	346-3-50				(8) 4.4	(8) 20.9				(8) 8.7	(8) 53.0
	380/415-3-50				(8) 3.4	(8) 30.0				(8) 7.3	(8) 41.0
130-170 230A-270A, 330A/B,360B (50 Hz)	208/230-3-60	10	1	0.746	(6) 6.6, (4) 5.5	(6) 31.6, (4) 30.0	10	5	3.73	(10) 14.6	(10) 41.6
	460-3-60				(6) 3.3, (4) 2.8	(6) 31.6, (4) 30.0				(10) 6.3	(10) 41.6
	575-3-60				(10) 3.4	(10) 30.0				(10) 5.2	(10) 42.0
	380-3-60				(10) 3.9	(10) 20.9				(10) 7.4	(10) 54.0
	346-3-50				(10) 4.4	(10) 20.9				(10) 8.7	(10) 53.0
	380/415-3-50				(10) 3.4	(10) 30.0				(10) 7.3	(10) 41.0
190-210, 290A,315A, 360A, 360B (60 Hz), 390A/B,420A/B	208/230-3-60	12	1	0.746	(8) 6.6, (4) 5.5	(8) 31.6, (4) 30.0	12	5	3.73	(12) 14.6	(12) 41.6
	460-3-60				(8) 3.3, (4) 2.8	(8) 31.6, (4) 30.0				(12) 6.3	(12) 41.6
	575-3-60				(12) 3.4	(12) 30.0				(12) 5.2	(12) 42.0
	380-3-60				(12) 3.9	(12) 20.9				(12) 7.4	(12) 54.0
	346-3-50				(12) 4.4	(12) 20.9				(12) 8.7	(12) 53.0
	380/415-3-50				(12) 3.4	(12) 30.0				(12) 7.3	(12) 41.0

(See Legend and Notes, page 37)

Step 6 — Install Accessories

ELECTRICAL — A number of electrical accessories are available to provide the following optional features (for details, refer to the Controls and Troubleshooting book):

- Accessory temperature reset board and accessory thermistor (used for any of the following types of temperature reset):
 - Return fluid temperature reset
 - Space temperature reset (requires accessory thermistor)
 - Outdoor air temperature reset (requires accessory thermistor)
- Chilled fluid flow switch

LOW-AMBIENT OPERATION — If operating temperatures below 0° F (–18 C) are expected, refer to separate installation instructions for low-ambient operation, Motor-master® III control.

HOT GAS BYPASS — Hot gas bypass usually is *not* recommended because it results in application of equipment out of its normal design application range. However, if its use is required, the appropriate hot gas bypass package may be used. For installation details, refer to separate instructions supplied with the accessory package.

MISCELLANEOUS ACCESSORIES — For applications requiring special accessories, the following packages are available: condenser hail guard, gage panel, sound reduction kit, convenience outlet, and security grille package.

PRE-START-UP

IMPORTANT: Before beginning Pre-Start-Up or Start-Up, complete Start-Up Checklist for Flotronic™ Chiller Systems at center of this publication (page CL-1). The Checklist assures proper start-up of a unit, and provides a record of unit condition, application requirements, system information, and operation at initial start-up.

Do not attempt to start the chiller until following checks have been completed.

System Check

1. Check all auxiliary components, such as the chilled fluid circulating pump, air-handling equipment, or other equipment to which the chiller supplies liquid. Consult manufacturer's instructions. If the unit has field-installed accessories, be sure all are properly installed and wired correctly. Refer to unit wiring diagrams.
2. Backseat (open) compressor suction and discharge shut-off valves. Close valves one turn to allow refrigerant pressure to reach the test gages.
3. Open liquid line service valves.
4. Fill the chiller fluid circuit with clean water (with recommended inhibitor added) or other noncorrosive fluid to be cooled. Bleed all air out of high points of system. An air vent is included with the cooler. If outdoor temperatures are expected to be below 32 F (0° C), sufficient inhibited ethylene glycol or other suitable corrosion inhibited anti-freeze should be added to the chiller water circuit to prevent possible freeze-up.
5. Check tightness of all electrical connections.
6. Oil should be visible in the compressor sight glass. See Fig. 25. An acceptable oil level in the compressor is from $\frac{1}{8}$ to $\frac{3}{8}$ of sight glass. Adjust the oil level as required. No oil should be removed unless the crankcase heater has been energized for at least 24 hours. See Oil Charge section on page 64 for Carrier-approved oils.
7. Electrical power source must agree with unit nameplate.
8. *Crankcase heaters must be firmly locked into compressors, and must be on for 24 hours prior to start-up.*
9. Fan motors are 3 phase. Check rotation of fans during the quick test (see Quick Test section below). Fan rotation is clockwise as viewed from top of unit. If fan is not turning clockwise, reverse 2 of the power wires.
10. Check compressor suspension. Mounting rails must be floating freely on the springs.
11. Perform quick test to verify proper settings. See Controls and Troubleshooting literature for more details.

Quick Test (See Fig. 25 and Table 8) — Both main power and control circuit power must be on.

The quick test program utilizes a 2-digit LED (light-emitting diode) display (Fig. 26) on set point board to show status of all input and output signals to microprocessor control. Display action and quick test procedure are described as follows:

The quick test is a 42-step program that provides a means of checking all input and output signals of microprocessor control prior to unit start-up. This check ensures that all control options, thermistors, and status switches are in proper working order.




**Fig. 25 — Compressor Connections
(Lead Compressor Shown)**




Table 8 — Quick Test 88
SECTION A. — Configuration and Switch Check

QUICK TEST STEP NO.	NORMAL DISPLAY	STEP DESCRIPTION	HEADER POSITION OR CONTROL SWITCH
1	00	Type Unit — Air-Cooled Chiller	Configuration Header: 1 and 2
2	2 through 7	No. of Compressors 2 = 040-060 (50 Hz), 040-070 (60 Hz) 3 = 070 (50 Hz), 080, 230B 4 = 090-110, 130 (60 Hz), 245B-315B 5 = 130 (50 Hz), 150, 230A-255A 6 = 170, 190, 270A, 290A, 330A/B, 360A/B, 390B 7 = 210, 315A, 390A, 420A/B	Configuration Header: 3, 4, and 5
3	0 through 2	No. of Unloaders 0 = Switch 6 Off, Switch 7 Off 1 = Switch 6 On, Switch 7 Off 2 = Switch 6 Off, Switch 7 On NOTE: There are no standard unloaders on 190-210 and associated modular units.	DIP Switches 6 and 7
4	0 or 1	0 = Water 1 = Brine*	DIP Switch 8
5	1	1 = EXV	Configuration Header: 6
6	50 or 60	50 = 50 Hz 60 = 60 Hz	Configuration Header: 7
7	0 or 1	0 = External Reset 1 = Return Fluid Reset	DIP Switch 1
8	0 or 1	0 = Reset Disabled 1 = Reset Enabled	DIP Switch 2
9	0 or 1	0 = Pulldown Disabled 1 = Pulldown Enabled	DIP Switch 3
10	0 or 1	0 = Demand Limit Disabled 1 = Demand Limit Enabled	DIP Switch 5
11	0 or 1	0 = Remote On/Off — Switch/Jumper Open 1 = Remote On/Off — Switch/Jumper Closed	TB6-3 and TB6-4
12	0 or 1	0 = Loss-of-Charge Switch A Open 1 = Loss-of-Charge Switch A Closed	Circuit A Loss-of-Charge Switch
13	0 or 1	0 = Loss-of-Charge Switch B Open 1 = Loss-of-Charge Switch B Closed	Circuit B Loss-of-Charge Switch
14	0 or 1	0 = Low Oil Pressure Switch A Open 1 = Low Oil Pressure Switch A Closed	Circuit A Low Oil Pressure Switch
15	0 or 1	0 = Low Oil Pressure Switch B Open 1 = Low Oil Pressure Switch B Closed	Circuit B Low Oil Pressure Switch

Table 8 — Quick Test 88 (cont)
SECTION B. — Thermistor and Potentiometer Checkout

QUICK TEST STEP NO.	NORMAL DISPLAY	STEP DESCRIPTION	THERMISTOR OR POTENTIOMETER
1.6.	1	1 — Thermistor OK 0 — Thermistor Faulty	T1 — Cooler Leaving Fluid Thermistor
1.7.	1	1 — Thermistor OK 0 — Thermistor Faulty	T2 — Cooler Entering Fluid Thermistor
1.8.	1	1 — Thermistor OK 0 — Thermistor Faulty	T3 — Saturated Condensing Thermistor, Circuit A
1.9.	1	1 — Thermistor OK 0 — Thermistor Faulty	T4 — Saturated Condensing Thermistor, Circuit B
2.0.	1	1 — Thermistor OK 0 — Thermistor Faulty	T5 — Cooler Thermistor, Circuit A
2.1.	1	1 — Thermistor OK 0 — Thermistor Faulty	T6 — Cooler Thermistor, Circuit B
2.2.	1	1 — Thermistor OK 0 — Thermistor Faulty	T7 — Compressor Thermistor, Circuit A
2.3.	1	1 — Thermistor OK 0 — Thermistor Faulty	T8 — Compressor Thermistor, Circuit B
2.4.	1	1 — Thermistor OK 0 — Thermistor Faulty	T10 — Accessory Remote Thermistor
2.5.	1	1 — Potentiometer OK 0 — Potentiometer Faulty	P1 — Leaving Fluid Set Point Potentiometer
2.6.	0	No Significance	—
2.7.	1 or 0	1 — Potentiometer OK 0 — Potentiometer Faulty or Option Not Used	P3 — Accessory Reset Limit Potentiometer
2.8.	1 or 0	1 — Potentiometer(s) OK 0 — Potentiometer(s) Faulty or Option Not Used	P4 — Accessory Demand Limit Potentiometer(s)
2.9.	1 or 0	1 — Potentiometer OK 0 — Potentiometer Faulty or Option Not Used	P5 — Accessory Reset Ratio Potentiometer
3.0.	1 or 0	1 — Potentiometer OK 0 — Potentiometer Faulty or Option Not Used	P6 — Accessory Reset Set Point Potentiometer

NOTE: See legend and notes on page 53.

Table 8 — Quick Test 88 (cont)
SECTION C. — Output Relay Check

QUICK TEST STEP NO.	NORMAL DISPLAY	STEP DESCRIPTION	RELAY NO.
3.1	1	Energize First Stage of Condenser Fans 040-050 — OFM3 060-110† — OFM3, OFM4 130-210† — OFM3, OFM4, OFM9, OFM10	K11
3.2	1	Energize Second Stage of Condenser Fans 040-050 — OFM4 060-090† — OFM5, OFM6 100, 110† — OFM5, OFM6, OFM7, OFM8 130-170† — OFM1, OFM2 190-210† — OFM1, OFM2, OFM11, OFM12	K12
3.3	0	No Action	K9
3.4	0	No Action	K10
3.5	0 → 1 → 0 **	Energize Compressor A1 and OFM1 (040-110†) Energize Compressor A1, OFM5, and OFM7 (130-210†)	K1
3.6	0 → 1 → 0 **	Energize Compressor A2 No Action 040-060 (50 Hz), 040-070 (60 Hz)	K2
3.7	0	No Action (040-110, 130 [60 Hz]†)	K3
	0 → 1 → 0 **	Energize Compressor A3 (130 [50 Hz], 150-210†)	
3.8	0	Energize Unloader A1 (040-170†)	K4
	0 → 1 → 0 **	Energize Compressor A4 (210†)	
3.9	0 → 1 → 0 **	Energize Compressor B1, OFM2 (040-110†) Energize Compressor B1, OFM6, and OFM8 (all other unit sizes)	K5
4.0	0 → 1 → 0 **	No Action (040-080†) Energize Compressor B2 (090-210†)	K6
4.1	0	No Action (040-150†)	K7
	0 → 1 → 0 **	Energize Compressor B3 (170-210†)	
4.2	0	Energize Unloader B1 (040-170†) No Action (190-210†)	K8

LEGEND

CPCS — Compressor Protection Control System
CR — Control Relay
DIP — Dual, In-Line Package
EXV — Electronic Expansion Valve
OFM — Outdoor (Condenser) Fan Motor
TB — Terminal Block

*Do not change select switch to brine on units that do not have modifications for brine.
Special factory modifications are required. Contact Carrier for details.
†And associated modular units.

**Compressors will be energized for 10 seconds. 0 indicates open CPCS or CR module contacts (compressor energized). 1 indicates closed CPCS or CR contacts (compressor deenergized).

To initiate the quick test program, first turn unit control switch to the ON position. When **20** appears in display, immediately press display button *once*. Code **88** will appear in display; this indicates that microprocessor in control system is ready to run quick test program.

IMPORTANT: Do not allow unit control circuit to remain energized with **20** showing in display for more than 2 minutes. If display button is not pressed within this time, control will attempt to start unit.

For each step of the 42-step program, display button must be pressed *twice*. On first press, step number is displayed; second press initiates required action, and code as shown in Table 8 is displayed.

NOTE: Step number is a numeral followed by a decimal point (a 2-digit number has a decimal point after *each* numeral). Action code number is one or 2 digits with no decimal point(s).

IMPORTANT: Once quick test is initiated, display button must be pressed at least once every 10 minutes for control to remain in quick test mode. If button is not pressed within this time, control will attempt to start unit.

To recheck any step in quick test, control must be re-cycled by turning unit control circuit switch off for a few seconds, then on again. Restart quick test program as described above and proceed through quick test steps. Press display button *twice* for each step until step to be rechecked is reached.

The quick test program is divided into 3 sections as described below and shown in Table 8. For more detailed information, refer to Controls and Troubleshooting literature.

A. QUICK TEST STEPS 1 - 15: UNIT CONFIGURATION — Microprocessor in unit control system is programmed by 2 switch assemblies located on processor board (Fig. 26). Configuration header is factory set and cannot be changed in the field. The DIP switch assembly contains 8 microswitches that must be set in accordance with various options and accessories selected. As shipped from factory, all DIP switches except those controlling pull-down option (switch no. 3) and compressor unloaders (switch no. 7 on 30GU040-330, and 360B 50 Hz units) are in OFF position. Switch no. 8 is in OFF position for water units, and ON position for brine units. All DIP switches should be checked and set to proper position for options selected during quick test.

The DIP switch assembly, functions, and display codes are shown in Fig. 26 and in Tables 8 and 9. Refer to Controls and Troubleshooting literature for details.

B. QUICK TEST STEPS 16 - 30: THERMISTORS AND SET POINT POTENTIOMETERS — In these steps, microprocessor checks resistance values of all sensors and set point potentiometers to ensure they are functional and set within proper range for unit configuration.

Nominal resistance values for all sensors range from 363,000 to 216 ohms. Normal display code for good sensors and potentiometers is **1**. Display code **0** indicates a faulty potentiometer, thermistor, or wiring. A **8** display can also indicate a particular option is not being used, i.e., demand limit not installed.

Tables 8 and 10 show set point potentiometer functions, locations, and quick test display codes.

C. QUICK TEST STEPS 31 - 42: OUTPUT RELAYS — These quick test steps allow microprocessor to check output signals from relay boards in unit control system. In addition, operation of all condenser fans and compressors is checked at each step.

Normal display code for steps **3.1** through **3.4** is **0** or **1**. In steps **3.5** through **4.2**, when appropriate, each compressor is started and allowed to run for approximately 10 seconds. At start-up **0** appears, followed by **1** in a few seconds. At end of 10-second test, code **0** returns to display indicating that test step has been successfully completed. Code **1** indicated that compressor protection circuit (CPCS) or control relay (CR) was tested.

Fan and compressor operating sequence for quick test steps **3.1** through **4.2** are shown in Table 8 and Fig. 27.

If quick test steps do not operate as described, a defect exists in one or more of the following: relay being tested, electronic control, and/or unit wiring. Refer to Controls and Troubleshooting literature for additional information.

START-UP AND OPERATION

NOTE: Complete Start-Up Checklist at center of publication (page CL-1) prior to starting unit.

Digital Display Action — The electronic control system uses a 2-digit LED display located on display set point board (see Fig. 26) to show operational information and diagnostic codes.

When control ON-OFF switch is turned to ON position, display shows **20** for 2 minutes to indicate control is in initialization mode. The electronic expansion valves (EXV) will be closed as part of initialization sequence.

After a 2-minute period, display turns off and unit is allowed to start. If button is pressed after the **20** has been removed from display, operational status codes or diagnostic information will be shown as long as button is held in. Code numbers on display have following significance:

CODE NUMBER	OPERATIONAL STATUS
0-12	Capacity stage
20-26	Operational information
51-87	Overload information






Table 9 — DIP Switch Functions

DIP SWITCH NO.	SELECTED FUNCTION*
1	Type of Reset
2	Reset
3	Pull Down Limit
4	Not Used
5	Demand Limit
6	1 Unloader
7	2 Unloaders
8	Brine

LEGEND

DIP — Dual In-Line Package

*Refer to Table 8, Quick Test steps 3 through 1.0

FAN ARRANGEMENT	FAN NO.	QUICK TEST DISPLAY NUMBER*	CONTROLLED BY
30GU040-050 	1	3.5.	Compressor No A1
	2	3 9.	Compressor No B1
	3	3 1	First Stage of Condenser Fans
	4	3 2	Second Stage of Condenser Fans
30GU060,070 	1	3.5.	Compressor No A1
	2	3 9	Compressor No B1
	3,4	3 1.	First Stage of Condenser Fans
	5,6	3 2	Second Stage of Condenser Fans
30GU080,090,230B,245B 	1	3.5	Compressor No. A1
	2	3 9	Compressor No B1
	3,4	3 1.	First Stage of Condenser Fans
	5,6	3.2	Second Stage of Condenser Fans
30GU100,110,255B-315B 	1	3.5	Compressor No. A1
	2	3 9	Compressor No. B1
	3,4	3.1.	First Stage of Condenser Fans
	5,6,7,8	3.2	Second Stage of Condenser Fans
30GU130-210 230A-315, 330A/B-420A/B† POWER 	5,7	3 5	Compressor No A1
	6,8	3.9	Compressor No. B1
	3,4,9,10	3 1.	First Stage of Condenser Fans
	1,2,11,12	3 2.	Second Stage of Condenser Fans

*During quick test only.

†Fan numbers 11 and 12 do not apply to standard 130-170 and associated modular units (see Table 1)

**Control Box

Fig. 27 — Condenser Fan Sequence

Table 10 — Potentiometer Locations

POTENTIOMETER	LOCATION
P1 — Leaving Fluid Set Point	Set Point Board (Standard)
P3 — Reset Limit Set Point	Accessory Board (Option)
P4 — Demand Limit Set Point	Accessory Board (Option)
P5 — Reset Ratio Set Point	Accessory Board (Option)
P6 — Reset Temp Set Point	Accessory Board (Option)

Under normal operation, only stage number is displayed. If an operational status code or an overload code is displayed, the display rotates every 2 seconds and displays up to 3 numbers. Overload information will take priority over all other codes. The codes are stored by the microprocessor as long as board is energized.

IMPORTANT: The alarm memory is cleared when control power is removed.

Actual Start-Up — Actual start-up should be done only under supervision of a qualified refrigeration mechanic.

1. Be sure all service valves are open. The unit is shipped from the factory with the suction, discharge, and liquid line service valves closed.
2. Set leaving fluid temperature. No cooling range adjustment is necessary.

3. If accessory reset boards are used, set potentiometers properly. Refer to Controls and Troubleshooting literature for details.

4. Start chilled fluid pump.

5. Turn ON-OFF switch to ON position. The display will read **2 0**. During this time the machine checks all potentiometers and thermistors for valid readings. In approximately 2 minutes, the **2 0** reading is no longer displayed, and the machine is operational.

Allow the unit to operate and confirm that everything is functioning properly. Check the leaving fluid temperature and be sure that it agrees with the set point potentiometer P1. If the temperature setting does not agree, the set point can be compensated by shifting the control point slightly. If temperature reset is in effect, the leaving fluid temperature may not agree with the set point.

Operating Limitations

TEMPERATURES (See Table 11) — If unit is to be used in an area with high solar radiation, mounted position should be such that control box is not exposed to direct solar radiation. Exposure to direct solar radiation could affect the temperature switch controlling cooler heaters.

Table 11 — Temperature Limits

TEMPERATURES	F	C
Maximum Ambient Temp	125	52
Minimum Ambient Temp	0	-18
Maximum Cooler EWT*	95	35
Maximum Cooler LWT	70	21
Minimum Cooler LWT†	40	4.5

LEGEND

EWT — Entering Fluid (Water) Temperature
LWT — Leaving Fluid (Water) Temperature

*For sustained operation, it is recommended that EWT *NOT* exceed 85 F (29.4 C).

†Unit and/or DIP switch requires modification below this temperature

Low-Ambient Operation — If operating temperatures below 0° F (-18° C) are expected, refer to separate installation instructions for low-ambient operation/Motormaster® III control. Contact your Carrier representative for details.

High Cooler LCWT (Leaving Chilled Water [Fluid] Temperature) — During start-up with leaving fluid temperatures above approximately 60 F (16 C), EXV limits suction pressure to approximately 90 psig (620 kPa) to avoid overloading compressor.

Low Cooler LCWT — Application of chillers within 39.9 F to 34 F (4.4 C to 1.1 C) temperature range is possible in some situations with proper field change of control configuration. This requires that DIP switch no. 8 (brine switch) of S1 on the processor board be set to ON position. See Tables 8 and 9.

⚠ WARNING

Do not operate with leaving water temperature below 34 F (1.1 C). Application in the range 34 F to 15 F (1° C to -9.4 C) requires chiller with factory modification for brine duty (only applicable to certain units). Contact your Carrier representative for details.

VOLTAGE


Main Power Supply — Minimum and maximum acceptable supply voltages are listed in Tables 4A and 4B.

Unbalanced 3-Phase Supply Voltage — *Never operate a motor where a phase imbalance between phases is greater than 2%.* To determine percentage of voltage imbalance:

$$\% \text{ Voltage Imbalance} = 100 \times \frac{\text{max voltage deviation from avg voltage}}{\text{average voltage}}$$

The maximum voltage deviation is the largest difference between a voltage measurement across 2 legs and the average across all 3 legs.

EXAMPLE: Supply voltage is 240-3-60.



AB = 243 v
 BC = 236 v
 AC = 238 v

$$\begin{aligned} \text{Average voltage} &= \frac{243 + 236 + 238}{3} \\ &= \frac{717}{3} \\ &= 239 \text{ v} \end{aligned}$$

Determine maximum deviation from average voltage:

$$(AB) 243 - 239 = 4 \text{ v}$$

$$(BC) 239 - 236 = 3 \text{ v}$$

$$(AC) 239 - 238 = 1 \text{ v}$$

Maximum deviation is 4 v.

Determine percentage of voltage imbalance:

$$\begin{aligned} \% \text{ Voltage Imbalance} &= 100 \times \frac{4}{239} \\ &= 1.7\% \end{aligned}$$

This voltage imbalance is satisfactory as it is below the maximum allowable 2%.

IMPORTANT: If the supply voltage phase imbalance is more than 2%, contact your local electric utility company immediately. Do not operate unit until imbalance condition is corrected.

Control Circuit Power — Electronic control includes logic to detect low control circuit voltage. Acceptable voltage range is shown in Table 5.

MINIMUM FLUID LOOP VOLUME — To obtain proper temperature control, loop fluid volume must be at least 3 gal per ton (3.25 L per kW) of chiller nominal capacity for air conditioning and at least 6 gal per ton (6.5 L per kW) for process applications or systems that must operate in low ambients (below 32 F [0° C]). Refer to application information in Product Data literature for details.

FLOW RATE REQUIREMENTS — Standard chillers should be applied with nominal flow rates approximating those listed in Table 12. Higher or lower flow rates are permissible to obtain lower or higher temperature rises. Minimum flow rates *must be exceeded* to assure turbulent flow and proper heat transfer in the cooler.

⚠ WARNING

Operation below minimum flow could subject tubes to frost pinching in tube sheet, resulting in failure of cooler.

Consult application data and job design requirements to determine flow rate requirements for particular installation.

Operation Sequence — During unit off cycle, crankcase heaters are energized. If ambient temperature is below 36 F (2 C), cooler heaters and a microprocessor board heater are also energized.

When control ON-OFF switch is turned to ON position, control first goes through a 2-minute initialization period during which the display continuously shows

20. Ninety (90) seconds after **20** leaves display, control begins to bring on compressors. Rate at which compressors are started depends on leaving chilled fluid temperature and rate of change of leaving fluid temperature.

An automatic lead-lag feature in control system on all units determines by random selection whether circuit A or B starts first.

At first call for cooling, microprocessor starts first compressor, deenergizes crankcase heater, and starts one condenser fan.

Table 12 — Nominal and Minimum Cooler Fluid Flow Rates

30GU UNIT SIZE	NOMINAL FLOW RATE*		MINIMUM FLOW RATE (See Notes)	
	Gpm	L/s	Gpm	L/s
040	60	3.8	36.8	2.38
045	67	4.2	37.7	2.38
050	82	5.2	37.7	2.38
060	96	6.1	47.5	3.00
070	120	7.6	47.5	3.00
080,230B	132	8.3	66.7	4.2
090,245B	144	9.1	66.7	4.2
100,255B,270B	168	10.6	84.1	5.3
110,290B,315B	180	11.4	84.1	5.3
130	216	13.6	110	6.9
150,230A,245A,255A	240	15.1	110	6.9
170,270A,330,360B (50 Hz)	264	16.7	120	7.5
190,290A,360A/B (60 Hz), 360A (50 Hz), 390B	288	18.2	120	7.5
210,315A,390A,420A/B	336	21.2	148	9.3

LEGEND

- ARI — Air Conditioning and Refrigeration Institute (U.S.A.)
 Gpm — Gallons per minute (U.S.A.)
 kPa — Kilopascals
 L/s — Liters per second
 N — Liters per kW
 PD — Pressure Drop
 V — Gallons per ton

*Nominal flow rates required at ARI conditions 44 F (7 C) leaving fluid temperature, 54 F (12 C) entering fluid temperature, 95 F (35 C) ambient. Fouling factor 00025 ft² • hr • F/Btu (000044 m² • kW).

NOTES:

- Minimum flow based on 1.0 fps (0.30 m/s) velocity in cooler without special cooler baffling.
- Minimum Loop Volumes:
 Gallons = V x ARI Cap (tons)
 Liters = N x ARI Cap. (kW)

APPLICATION	V	N
Normal Air Conditioning	3	3.25
Process Type Cooling	6 to 10	6.5 to 10.8
Low Ambient Unit Operation	6 to 10	6.5 to 10.8

The EXV remains closed for 10 seconds to purge cooler and suction line of any liquid refrigerant that may have migrated to these areas during off period. After 10 seconds, EXV starts to open. As more cooling is required, control brings on additional stages of capacity. Loading sequence for compressors is shown in Table 13.

Lag compressor will shut down, and lead compressor will continue to run. After lag compressor shuts down, the EXV

is signaled to close. Lead compressor remains on until EXV is less than 300 steps open, and the saturated suction temperature is less than 25 F (–4 C) as sensed by cooler thermistor T5 or T6, or until one minute has elapsed.

LOAD SHED — If load shed option is being used, control limits maximum capacity to load shed input value. Refer to Controls and Troubleshooting literature for details. If capacity is limited by a load shed signal, display shows **22** when display button is pressed.

TEMPERATURE RESET — If temperature reset is being used, microprocessor adjusts leaving fluid temperature to obtain greater part-load efficiency. Refer to Controls and Troubleshooting literature for details. If leaving fluid temperature is being reset, display shows **21** when the display button is pressed.

HEAD PRESSURE CONTROL — Microprocessor controls EXV to maintain a superheat of 23° F (12.7° C) entering compressor cylinders.

Microprocessor control also cycles condenser fans on and off to maintain an adequate pressure differential across EXVs. Fans are controlled by position of EXV and saturated condensing temperature thermistors. When EXV is fully open and superheat is greater than 40° F (22° C), fan stages are removed; when the valve is approximately half open, fan stages are added. This allows unit to run at very low condensing temperatures at part load. Thus chiller has very high part-load EERs (energy efficiency ratios). Fan sequence is shown in Fig. 27. Refer to Controls and Troubleshooting literature for more head pressure control information.

Logic to cycle microprocessor-controlled fans is based on saturated condensing temperature only. This temperature is sensed by thermistors T3 and T4 (Fig. 28 and 29). The microprocessor turns on an additional stage of fans when either coil thermistor (T3 or T4) is greater than 113 F (45 C) and turns off a fan stage when T3 and T4 are both below 73 F (23 C). Between each change in fan stage, control waits one minute to allow head pressure to stabilize unless either T3 or T4 is greater than 125 F (52 C), in which case all microprocessor-controlled fans turn on immediately.

Condenser fan sequence is shown in Fig. 27.

REMOTE ON-OFF — In applications where controlling the starting and stopping of the chiller from a remote location is desired, such as a remote timeclock, the remote on-off feature is used. See Fig. 22-24 for wiring information. If the chiller is being held off by the remote on-off switch, **2b** appears in the display when the display button is pressed.

NOTE: DO NOT USE FLUID PUMP to cycle chiller on and off except as a safety feature. Cycling of chiller must be accomplished through the remote on-off switch, since the fluid pump must continue to run for 1 minute after initialization of pumpdown.

REMOTE ALARM — See Fig. 22-24 for remote alarm field wiring.

Table 13 — Capacity Control Steps

30GU UNIT SIZE	CONTROL STEPS	LOADING SEQUENCE A		LOADING SEQUENCE B	
		% Displ.	Compressors	% Displ.	Compressors
040 (60 Hz) A1†	1	25	A1*	—	—
	2	50	A1	—	—
	3	75	A1*,B1	—	—
	4	100	A1,B1	—	—
040 (60 Hz) A1†,B1**	1	25	A1*	25	B1*
	2	50	A1	50	B1
	3	75	A1*,B1	75	A1,B1*
	4	100	A1,B1	100	A1,B1
040 (50 Hz) 045 (60 Hz) A1†	1	21	A1*	—	—
	2	42	A1	—	—
	3	99	A1*,B1	—	—
	4	100	A1,B1	—	—
040 (50 Hz) 045 (60 Hz) A1†, B1**	1	21	A1*	38	B1*
	2	42	A1	58	B1
	3	60	A1*,B1*	60	A1*,B1*
	4	79	A1*,B1	81	A1,B1*
	5	100	A1,B1	100	A1,B1
045 (50 Hz) 050 (60 Hz) A1†	1	32	A1*	—	—
	2	48	A1	—	—
	3	84	A1*,B1	—	—
	4	100	A1,B1	—	—
045 (50 Hz) 050 (60 Hz) A1†, B1**	1	32	A1*	35	B1*
	2	48	A1	52	B1
	3	67	A1*, B1*	67	A1*,B1*
	4	83	A1,B1*	83	A1,B1*
	5	84	A1*,B1	84	A1*,B1
	6	100	A1,B1	100	A1,B1
050 (50 Hz) 060 (60 Hz) A1†	1	29	A1*	—	—
	2	43	A1	—	—
	3	86	A1*,B1	—	—
	4	100	A1,B1	—	—
050 (50 Hz) 060 (60 Hz) A1†,B1**	1	29	A1*	38	B1*
	2	43	A1	57	B1
	3	67	A1*,B1*	67	A1*,B1*
	4	86	A1*,B1	81	A1,B1*
	5	100	A1,B1	100	A1,B1
060 (50 Hz) 070 (60 Hz) A1†	1	33	A1*	—	—
	2	50	A1	—	—
	3	83	A1*,B1	—	—
	4	100	A1,B1	—	—
060 (50 Hz) 070 (60 Hz) A1†,B1**	1	33	A1*	33	B1*
	2	50	A1	50	B1
	3	83	A1*,B1	83	A1,B1*
	4	100	A1,B1	100	A1,B1
070 (50 Hz) A1†	1	19	A1*	—	—
	2	29	A1	—	—
	3	48	A1*,A2	—	—
	4	62	A1*,B1	—	—
	5	71	A1,B1	—	—
	6	90	A1*,A2,B1	—	—
	7	100	A1,A2	—	—
070 (50 Hz) A1†,B1**	1	19	A1*	28	B1*
	2	29	A1	43	B1
	3	47	A1*,B1*	47	A1*,B1*
	4	48	A1*,A2	57	A1,B1*
	5	58	A1,A2	71	A1,B1
	6	61	A1*,B1	76	A1*,A2,B1*
	7	71	A1,B1	86	A1,A2,B1*
	8	90	A1*,A2,B1	100	A1,A2,B1
	9	100	A1,A2,B1	—	—

LEGEND

Displ. — Displacement (Approximate)

*Compressor unloaded.

†Compressor unloader, standard

**Compressor unloader, accessory

NOTES:

- The microprocessor has a random number generator that selects loading sequence A or B, which in turn determines the compressor circuit that is energized first. This evens out operating hours on each circuit over an extended period of time
- If unit operation is anticipated with system load below minimum unloaded capacity of chiller:
 - Consider using 2 smaller units in place of the larger unit
 - Increase *fluid loop volume* to ensure adequate run time (see Application Data in Product Data literature)
 - Consider adding accessory hot gas bypass package
- The staging of modular units (30GU230-420) will be random due to variables within the system. The loading sequence of each individual module will be as listed.

Table 13 — Capacity Control Steps (cont)

30GU UNIT SIZE	CONTROL STEPS	LOADING SEQUENCE A		LOADING SEQUENCE B	
		% Displ.	Compressors	% Displ.	Compressors
080,230B (60 Hz) A1†, B1†	1	22	A1*	29	B1*
	2	52	A1*,B1*	52	A1*,B1*
	3	67	A1*, B1	63	A1,B1*
	4	78	A1,B1	78	A1,B1
	5	89	A1*,A2,B1	89	A1*,A2,B1
	6	100	A1,A2,B1	100	A1,A2,B1
080,230B (50 Hz) A1†, B1†	1	16	A1*	25	B1*
	2	42	A1*,B1*	42	A1*,B1*
	3	54	A1*,B1	50	A1,B1*
	4	62	A1,B1	62	A1,B1
	5	92	A1*,A2,B1	92	A1*,A2,B1
	6	100	A1,A2,B1	100	A1,A2,B1
090,245B (60 Hz) A1†, B1†	1	18	A1*	18	B1*
	2	35	A1*,B1*	35	A1*,B1*
	3	44	A1*,B1	44	A1,B1*
	4	53	A1,B1	53	A1,B1
	5	65	A1*,A2,B1	71	A1,B1*,B2
	6	73	A1,A2,B1	80	A1,B1,B2
	7	91	A1*,A2,B1,B2	91	A1,A2,B1*,B2
	8	100	A1,A2,B1,B2	100	A1,A2,B1,B2
090,245B (50 Hz) A1†, B1†	1	14	A1*	14	B1*
	2	29	A1*,B1*	29	A1*,B1*
	3	36	A1*,B1	36	A1,B1*
	4	43	A1,B1	43	A1,B1
	5	68	A1*,A2,B1	60	A1,B1*,B2
	6	75	A1,A2,B1	67	A1,B1,B2
	7	93	A1*,A2,B1,B2	93	A1,A2,B1*,B2
	8	100	A1,A2,B1,B2	100	A1,A2,B1,B2
100,255B,270B (60 Hz) A1†, B1†	1	15	A1*	15	B1*
	2	31	A1*,B1*	31	A1*,B1*
	3	39	A1*,B1	39	A1,B1*
	4	46	A1,B1	46	A1,B1
	5	65	A1*,A2,B1	65	A1,B1*,B2
	6	73	A1,A2,B1	73	A1,B1,B2
	7	92	A1*,A2,B1,B2	92	A1,A2,B1*,B2
	8	100	A1,A2,B1,B2	100	A1,A2,B1,B2
100,255B,270B (50 Hz) A1†, B1†	1	13	A1*	13	B1*
	2	26	A1*,B1*	26	A1*,B1*
	3	33	A1*, B1	33	A1,B1*
	4	40	A1,B1	40	A1,B1
	5	63	A1*,A2,B1	63	A1,B1*,B2
	6	70	A1,A2,B1	70	A1,B1,B2
	7	93	A1*,A2,B1,B2	93	A1,A2,B1*,B2
	8	100	A1,A2,B1,B2	100	A1,A2,B1,B2
110,290B,315B (60 Hz) A1†, B1†	1	14	A1*	14	B1*
	2	29	A1*,B1*	29	A1*,B1*
	3	36	A1*,B1	36	A1,B1*
	4	43	A1,B1	43	A1,B1
	5	68	A1*,A2,B1	60	A1,B1*,B2
	6	75	A1,A2,B1	67	A1,B1,B2
	7	93	A1*,A2,B1,B2	93	A1,A2,B1*,B2
	8	100	A1,A2,B1,B2	100	A1,A2,B1,B2
110,290B,315B (50 Hz) A1†, B1†	1	17	A1*	17	B1*
	2	33	A1*,B1*	33	A1*,B1*
	3	42	A1*,B1	42	A1,B1*
	4	50	A1,B1	50	A1,B1
	5	67	A1*,A2,B1	67	A1,B1*,B2
	6	75	A1,A2,B1	75	A1,B1,B2
	7	92	A1*,A2,B1,B2	92	A1,A2,B1*,B2
	8	100	A1,A2,B1,B2	100	A1,A2,B1,B2

LEGEND

Displ. — Displacement (Approximate)

*Compressor unloaded.

†Compressor unloader, standard

**Compressor unloader, accessory.

NOTES:

- The microprocessor has a random number generator that selects loading sequence A or B, which in turn determines the compressor circuit that is energized first. This evens out operating hours on each circuit over an extended period of time.
- If unit operation is anticipated with system load below minimum unloaded capacity of chiller
 - Consider using 2 smaller units in place of the larger unit.
 - Increase *fluid loop volume* to ensure adequate run time (see Application Data in Product Data literature).
 - Consider adding accessory hot gas bypass package.
- The staging of modular units (30GU230-420) will be random due to variables within the system. The loading sequence of each individual module will be as listed.

Table 13 — Capacity Control Steps (cont)

30GU UNIT SIZE	CONTROL STEPS	LOADING SEQUENCE A		LOADING SEQUENCE B	
		% Displ. (Approx)	Compressors	% Displ. (Approx)	Compressors
130 (60 Hz) A1†, B1†	1	14	A1*	14	B1*
	2	29	A1*,B1*	29	A1*,B1*
	3	36	A1*,B1	36	A1,B1*
	4	43	A1,B1	43	A1,B1
	5	64	A1*,A2,B1	64	A1,B1*,B2
	6	72	A1,A2,B1	72	A1,B1,B2
	7	93	A1*,A2,B1,B2	93	A1,A2,B1*,B2
	8	100	A1,A2,B1,B2	100	A1,A2,B1,B2
130 (50 Hz) A1†, B1†	1	10	A1*	16	B1*
	2	21	A1*,B1*	21	A1*,B1*
	3	29	A1*,B1	32	A1,B1*
	4	34	A1,B1	34	A1,B1
	5	47	A1*,A2,B1	56	A1*,B1,B2
	6	58	A1,A2,B1	64	A1,B1,B2
	7	77	A1*,A2,B1,B2	74	A1,A2,B1*,B2
	8	82	A1,A2,B1,B2	82	A1,A2,B1,B2
	9	95	A1*,A2,A3,B1,B2	92	A1,A2,A3,B1*,B2
	10	100	A1,A2,A3,B1,B2	100	A1,A2,A3,B1,B2
150,230A,245A,255A (60 Hz) A1†, B1†	1	11	A1*	17	B1*
	2	19	A1*,B1*	19	A1*,B1*
	3	28	A1*,B1	33	A1,B1*
	4	33	A1,B1	33	A1,B1
	5	44	A1*,A2,B1	58	A1*,B1,B2
	6	58	A1,A2,B1	67	A1,B1,B2
	7	78	A1*,A2,B1,B2	75	A1,A2,B1*,B2
	8	83	A1,A2,B1,B2	83	A1,A2,B1,B2
	9	94	A1*,A2,A3,B1,B2	92	A1,A2,A3,B1*,B2
	10	100	A1,A2,A3,B1,B2	100	A1,A2,A3,B1,B2
150,230A,245A,255A (50 Hz) A1†, B1†	1	13	A1*	13	B1*
	2	27	A1*,B1*	27	A1*,B1*
	3	33	A1*,B1	33	A1,B1*
	4	40	A1,B1	40	A1,B1
	5	53	A1*,A2,B1	53	A1*,B1,B2
	6	60	A1,A2,B1	60	A1,B1,B2
	7	73	A1*,A2,B1,B2	73	A1,A2,B1*,B2
	8	80	A1,A2,B1,B2	80	A1,A2,B1,B2
	9	93	A1*,A2,A3,B1,B2	93	A1,A2,A3,B1*,B2
	10	100	A1,A2,A3,B1,B2	100	A1,A2,A3,B1,B2
170,270A,330A/B (60 Hz) A1†, B1†	1	11	A1*	11	B1*
	2	22	A1*,B1*	22	A1*,B1*
	3	28	A1*,B1	28	A1,B1*
	4	33	A1,B1	33	A1,B1
	5	44	A1*,A2,B1	44	A1,B1*,B2
	6	50	A1,A2,B1	50	A1,B1,B2
	7	61	A1*,A2,B1,B2	61	A1,A2,B1*,B2
	8	67	A1,A2,B1,B2	67	A1,A2,B1,B2
	9	78	A1*,A2,A3,B1,B2	78	A1,A2,B1*,B2,B3
	10	83	A1,A2,A3,B1,B2	83	A1,A2,B1,B2,B3
	11	94	A1*,A2,A3,B1,B2,B3	94	A1,A2,A3,B1*,B2,B3
	12	100	A1,A2,A3,B1,B2,B3	100	A1,A2,A3,B1,B2,B3
170,270A,330A/B,360B (50 Hz) A1†, B1†	1	10	A1*	10	B1*
	2	24	A1*,B1*	24	A1*,B1*
	3	29	A1*,B1	24	A1,B1*
	4	29	A1,B1	28	A1,B1
	5	43	A1*,A2,B1	43	A1,B1*,B2
	6	43	A1,A2,B1	48	A1,B1,B2
	7	57	A1*,A2,B1,B2	57	A1,A2,B1*,B2
	8	62	A1,A2,B1,B2	62	A1,A2,B1,B2
	9	76	A1*,A2,A3,B1,B2	76	A1,A2,B1*,B2,B3
	10	81	A1,A2,A3,B1,B2	81	A1,A2,B1,B2,B3
	11	95	A1*,A2,A3,B1,B2,B3	95	A1,A2,A3,B1*,B2,B3
	12	100	A1,A2,A3,B1,B2,B3	100	A1,A2,A3,B1,B2,B3

LEGEND

Displ. — Displacement (Approximate)

*Compressor unloaded

†Compressor unloader, standard.

**Compressor unloader, accessory.


NOTES:

- The microprocessor has a random number generator that selects loading sequence A or B, which in turn determines the compressor circuit that is energized first. This evens out operating hours on each circuit over an extended period of time.
- If unit operation is anticipated with system load below minimum unloaded capacity of chiller:
 - Consider using 2 smaller units in place of the larger unit.
 - Increase fluid loop volume to ensure adequate run time (see Application Data in Product Data literature).
 - Consider adding accessory hot gas bypass package
- The staging of modular units (30GU230-420) will be random due to variables within the system. The loading sequence of each individual module will be as listed.

Table 13 — Capacity Control Steps (cont)

30GU UNIT SIZE	CONTROL STEPS	LOADING SEQUENCE A		LOADING SEQUENCE B	
		% Displ. (Approx)	Compressors	% Displ. (Approx)	Compressors
190,290A, 360A/B,390B (60 Hz)	1	14	A1	14	B1
	2	27	A1,B1	27	A1,B1
	3	43	A1,A2,B1	43	A1,B1,B2
	4	59	A1,A2,B1,B2	59	A1,A2,B1,B2
	5	79	A1,A2,A3,B1,B2	79	A1,A2,B1,B2,B3
	6	100	A1,A2,A3,B1,B2,B3	100	A1,A2,A3,B1,B2,B3
190,290A, 360A/B,390B (60 Hz) A1**	1	9	A1*	9	A1*
	2	14	A1	14	A1
	3	23	A1*,B1	23	A1*,B1
	4	27	A1,B1	27	A1,B1
	5	38	A1*,A2,B1	38	A1*,A2,B1
	6	43	A1,A2,B1	43	A1,A2,B1
	7	54	A1*,A2,B1,B2	54	A1*,A2,B1,B2
	8	59	A1,A2,B1,B2	59	A1,A2,B1,B2
	9	75	A1*,A2,A3,B1,B2	75	A1*,A2,A3,B1,B2
	10	79	A1,A2,A3,B1,B2	79	A1,A2,B1,B2
	11	95	A1*,A2,A3,B1,B2,B3	95	A1*,A2,A3,B1,B2,B3
	12	100	A1,A2,A3,B1,B2,B3	100	A1,A2,A3,B1,B2,B3
190,290A, 360A/B,390B (60 Hz) A1** & B1**	1	9	A1*	9	B1*
	2	18	A1*,B1*	18	A1*,B1*
	3	23	A1*,B1	23	A1,B1*
	4	27	A1,B1	27	A1,B1
	5	38	A1*,A2,B1	38	A1,B1*,B2
	6	43	A1,A2,B1	43	A1,B1,B2
	7	54	A1*,A2,B1,B2	54	A1,A2,B1*,B2
	8	59	A1,A2,B1,B2	59	A1,A2,B1,B2
	9	75	A1*,A2,A3,B1,B2	75	A1,A2,B1*,B2,B3
	10	79	A1,A2,A3,B1,B2	79	A1,A2,B1,B2,B3
	11	95	A1*,A2,A3,B1,B2,B3	95	A1,A2,A3,B1*,B2,B3
	12	100	A1,A2,A3,B1,B2,B3	100	A1,A2,A3,B1,B2,B3
190,290A, 360A,390B (50 Hz)	1	17	A1	17	B1
	2	33	A1,B1	33	A1,B1
	3	50	A1,A2,B1	50	A1,B1,B2
	4	67	A1,A2,B1,B2	67	A1,A2,B1,B2
	5	83	A1,A2,A3,B1,B2	83	A1,A2,B1,B2,B3
	6	100	A1,A2,A3,B1,B2,B3	100	A1,A2,A3,B1,B2,B3
190,290A, 360A,390B (50 Hz) A1**	1	11	A1*	11	A1*
	2	17	A1	17	A1
	3	28	A1*,B1	28	A1*,B1
	4	33	A1,B1	33	A1,B1
	5	44	A1*,A2,B1	44	A1*,A2,B1
	6	50	A1,A2,B1	50	A1,A2,B1
	7	61	A1*,A2,B1,B2	61	A1*,A2,B1,B2
	8	67	A1,A2,B1,B2	67	A1,A2,B1,B2
	9	78	A1*,A2,A3,B1,B2	78	A1*,A2,A3,B1,B2
	10	83	A1,A2,A3,B1,B2	83	A1,A2,A3,B1,B2
	11	94	A1*,A2,A3,B1,B2,B3	94	A1*,A2,A3,B1,B2,B3
	12	100	A1,A2,A3,B1,B2,B3	100	A1,A2,A3,B1,B2,B3
190,290A, 360A,390B (50 Hz) A1**, B1**	1	11	A1*	11	B1*
	2	22	A1*,B1*	22	A1*,B1*
	3	28	A1*,B1	28	A1,B1*
	4	33	A1,B1	33	A1,B1
	5	44	A1*,A2,B1	44	A1,B1*,B2
	6	50	A1,A2,B1	50	A1,B1,B2
	7	61	A1*,A2,B1,B2	61	A1,A2,B1*,B2
	8	67	A1,A2,B1,B2	67	A1,A2,B1,B2
	9	78	A1*,A2,A3,B1,B2	78	A1,A2,B1*,B2,B3
	10	83	A1,A2,A3,B1,B2	83	A1,A2,B1,B2,B3
	11	94	A1*,A2,A3,B1,B2,B3	94	A1,A2,A3,B1*,B2,B3
	12	100	A1,A2,A3,B1,B2,B3	100	A1,A2,A3,B1,B2,B3
210,315A, 390A,420A/B (60 Hz)	1	12	A1	14	B1
	2	26	A1,B1	26	A1,B1
	3	37	A1,A2,B1	44	A1,B1,B2
	4	56	A1,A2,B1,B2	56	A1,A2,B1,B2
	5	68	A1,A2,A3,B1,B2	74	A1,A2,B1,B2,B3
	6	86	A1,A2,A3,B1,B2,B3	86	A1,A2,A3,B1,B2,B3
	7	100	A1,A2,A3,A4,B1,B2,B3	100	A1,A2,A3,A4,B1,B2,B3
210,315A, 390A,420A/B (50 Hz)	1	10	A1	16	B1
	2	26	A1,B1	26	A1,B1
	3	37	A1,A2,B1	42	A1,B1,B2
	4	52	A1,A2,B1,B2	52	A1,A2,B1,B2
	5	68	A1,A2,A3,B1,B2	68	A1,A2,B1,B2,B3
	6	84	A1,A2,A3,B1,B2,B3	84	A1,A2,A3,B1,B2,B3
	7	100	A1,A2,A3,A4,B1,B2,B3	100	A1,A2,A3,A4,B1,B2,B3

(See Legend on page 60)



LEGEND

EXV — Electronic Expansion Valve
T — Thermistor

Fig. 28 — Typical Thermistor Locations

SERVICE



ELECTRIC SHOCK HAZARD.

Turn off all power to unit before servicing. The ON-OFF switch on control panel does *not* shut off control power; use field disconnect.

Diagnostics and Troubleshooting — Refer to Controls and Troubleshooting literature.

For field service use, a Ground Fault Interrupter (GFI) convenience outlet is available as a field-installed accessory for all units. The GFI is rated for 15 amps. However, in units with active cooler heaters, only 8 amps are available.

Refrigerant Circuit

LEAK TESTING — Units are shipped with complete operating charge of refrigerant R-134a (see Tables 2A-3B) and should be under sufficient pressure to conduct a leak test. If there is no pressure in the system, use standard refrigeration practices to search for the leak. Repair the leak using good refrigeration practices. After leaks are repaired, system must be evacuated and dehydrated.


DEHYDRATION — Refer to Carrier Standard Service Techniques Manual, Chapter 1, Refrigerants, Sections 6 and 7 for details. *Do not use compressor to evacuate system.*

REFRIGERANT CHARGE (Refer to Tables 2A-3B) — Immediately ahead of filter drier in each circuit is a factory-installed liquid line service valve. Each valve has a 1/4-in. Schrader connection for charging liquid refrigerant.

Charging with Unit Off and Evacuated — Close liquid line service valve before charging. Weigh in charge shown on unit nameplate (also in Tables 2A-3B). Open liquid line service valve; start unit and allow it to run several minutes fully loaded. Check for a clear sight glass. Be sure clear condition is liquid and not vapor.

Charging with Unit Running — If charge is to be added while unit is operating, all condenser fans and compressors must be operating. It may be necessary to block condenser coils at low ambient temperatures to raise condensing pressure to approximately 185 psig (1275 kPa) to turn all condenser fans on. Do not totally block a coil to do this. Partially block all coils in uniform pattern. Charge each circuit until sight glass shows clear liquid, then weigh in amount over a clear sight glass as listed in Tables 2A-3B.

IMPORTANT: When adjusting refrigerant charge, circulate fluid through cooler continuously to prevent freezing and possible damage to the cooler. Do not over-charge and never charge liquid into low-pressure side of system.



*And associated modular units (see Table 1).

Fig. 29 — Thermistor T3 and T4 Locations

Electronic Components

CONTROL COMPONENTS — Unit uses an advanced electronic control system that normally does not require service. For details on controls refer to Controls and Troubleshooting literature.

30GU040-110 AND 230B-315B UNIT CONTROL BOX — Viewed facing compressors, main control box is at left end of unit. All incoming power enters through main box. Control box contains power components and electronic controls.

Outer panels are hinged and latched for easy opening. Remove screws to remove inner panels. Outer panels can be held open for service and inspection by using door retainer on each panel. Remove bottom pin from door retainer assembly, swing retainer out horizontally, engage pin in one of the retainer ears and the hinge assembly.

30GU130-210, 230A-315A, AND 330A/B-420A/B UNIT CONTROL AND MAIN POWER BOXES — The main power box is on the cooler side of the unit, and the control box is

on the compressor side. Outer panels are hinged and latched for easy opening. Remove screws to remove inner panels.

Compressors — If lead compressor on either refrigerant circuit becomes inoperative for any reason, circuit is locked off and *cannot* be operated due to features built in the electronic control system. *Do not attempt to bypass controls to force compressors to run.*

COMPRESSOR REMOVAL — Access to the pump end of the compressor is from the compressor side of the unit. Access to the motor end of the compressor is from the inside of the unit. All compressors can be removed from the compressor side of the unit.

IMPORTANT: All compressor mounting hardware and support brackets removed during servicing must be re-installed prior to start-up.

Following the installation of the new compressor:

Tighten discharge service valve bolts to —

	Compressor(s)
20 - 25 ft-lb (27 - 34 N-m)	06E150
80 - 90 ft-lb (109 - 122 N-m)	06E165,175,199

Tighten suction service valve bolts to —

	Compressor(s)
80 - 90 ft-lb (109 - 122 N-m)	06E150
90 - 120 ft-lb (122 - 163 N-m)	06E165,175,199

Tighten the following fittings to —

120 in.-lb (13.5 N-m)	High Pressure Switch
120 in.-lb (13.5 N-m)	Loss of Charge Switch

OIL CHARGE (Refer to Tables 2A-3B) — All units are factory charged with oil. Acceptable oil level for each compressor is from $\frac{1}{8}$ to $\frac{3}{8}$ of sight glass (see Fig. 25).

When additional oil or a complete charge is required, use only Carrier-approved compressor oil.

Approved polyolester (POE) oils are as follows:

- Mobil Artic EAL 68
- Castrol SW68
- ICI Emkarate RL68H
- Lubrizol 29168 (Texaco HFC Capella 68NA)
- CPI Solest 68

COMPRESSOR	OIL REQUIRED	
	Pts	L
06E150	17	8 0
06E165	19	9 0
06E175	19	9 0
06E199	19	9 0

Polyolester oils are extremely hygroscopic (retain moisture). Do not reuse drained oil and do not use any oil that has been exposed to atmosphere.

Cooler — The cooler is easily accessible from the cooler side of the unit. The refrigerant feed components are accessible from the control box end of the unit.

COOLER REMOVAL — Cooler can be removed from the cooler side of the unit as follows:

⚠ CAUTION

Open and tag all electrical disconnects before any work begins. Note that cooler is heavy and both fluid-side and refrigerant-side may be under pressure.

- To ensure the refrigerant is in the condenser, follow this procedure:
 - Open the circuit breakers and close the discharge valves for the lag compressors (A2-A4, B2, and B3).

⚠ WARNING

Do not close the discharge valve of an operating compressor. Severe damage to the compressor can result.

- After the lag compressors have shut down, close the liquid line service valve for one circuit. Allow the lead compressor to pump down that circuit until it reaches approximately 10 to 15 psig (68.8 to 103.2 kPa).

- As soon as the system reaches that pressure, shut down the lead compressor by opening the compressor circuit breaker, then quickly close the discharge service valve for that compressor.

- Repeat the procedure for the other circuit.

- Close the shutoff valves, if installed, in the cooler fluid lines, and remove the cooler fluid piping. Remove the cooler fluid-side strainer (sizes 130-210, 230A-315A, and 330A/B-420A/B only).
- Open the air vent at the top of the cooler, and open the drain on the bottom of the cooler (near the leaving fluid outlet) to drain the cooler. Both the drain and the air vent are located on the leaving fluid end of cooler. See Fig. 30.
- Disconnect the conduit and cooler heater wires, if equipped. Remove all thermistors from the cooler, being sure to label all thermistors as they are removed. Thermistor T2 is immersed directly in the fluid. Thermistors T1, T5, and T6 are friction-fit well-type thermistors. See Fig. 30.
- Remove the insulation on the refrigerant connection end of the cooler.
- Unbolt the suction flanges from the cooler head. Save the bolts.
- Remove the liquid lines by breaking the silver-soldered joints at the cooler liquid line nozzles.
- On 30GU080-110 and 230B-315B units, remove the two vertical supports under the condenser coil, in front of the cooler. *Provide temporary support as needed.* Save all screws for reinstallation later.
- Remove the screws in the cooler feet. Slide the cooler slightly to the left to clear the refrigerant tubing. Save all screws.


Removing the cooler can be accomplished in one of 2 ways, depending on the jobsite. Either continue sliding the cooler toward the end of the unit opposite the tubing and carefully remove, or pivot the cooler and remove it from the cooler side of the unit.

REPLACING COOLER — To replace the cooler:

- Insert new cooler carefully into place. Reattach the screws into the cooler feet (using saved screws).
On 30GU080-110 and 230B-315B units, reattach the 2 vertical supports under the condenser coil in front of the cooler using screws saved.
 - Replace the liquid lines and solder at the cooler liquid line nozzles.
 - Rebolt the suction flanges onto the cooler head using bolts saved during removal. Use new gaskets for the suction line flanges. Use compressor oil to aid in gasket sealing, and tighten the suction flange bolts to 70 to 90 ft-lb (94 to 122 N-m).
- NOTE:** The suction flange has a 4-bolt pattern. See Carrier specified parts for replacement part number, if necessary.
- Using adhesive, reinstall the cooler insulation on the refrigerant connection end of the cooler.
 - Reinstall the thermistors. Refer to Thermistors section on page 72, and install as follows:
 - Apply pipe sealant to the $\frac{1}{4}$ -in. NPT threads on the replacement coupling for the fluid side, and install it in place of the original.

⚠ CAUTION

Do not use the packing nut to tighten the coupling. Damage to the ferrules will result.



LEGEND

- EXV — Electronic Expansion Valve
T — Thermistor

*And associated modular units (see Table 1)

Fig. 30 — Cooler Thermistor Locations

- b. Reinstall thermistor T1 well, and insert thermistor T1 into well.
- c. Install thermistor T2 (entering fluid temperature) so that it is not touching an internal refrigerant tube, but so that it is close enough to sense a freeze condition. The recommended distance is $\frac{1}{8}$ in. (3.2 mm) from the cooler tube. Tighten the packing nut finger tight, and then tighten $1\frac{1}{4}$ turns more using a back-up wrench.
6. Install the cooler heater and conduit (if equipped), connecting the wires as shown in the unit wiring schematic located on the unit.
7. Close the air vent at the top of the cooler, and close the drain on the bottom of the cooler near the leaving fluid outlet. Both the drain and the air vent are located on the leaving fluid end of the cooler. See Fig. 30.
8. Reconnect the cooler fluid piping, and open the shutoff valves (if installed). Purge the fluid of all air before starting unit.
9. Open the discharge service valves, close the circuit breakers, and open the liquid line service valves for the compressors.

SERVICING COOLER — When cooler heads and partition plates are removed, tube sheets are exposed showing ends of tubes.

⚠ CAUTION

Certain tubes in the 10HB coolers cannot be removed. Eight tubes in the bundle are secured inside the cooler to the baffles and *cannot be removed*. These tubes are marked by a dimple on the tube sheet. See Fig. 31. *If any of these tubes have developed a leak, plug the tube(s) as described under Tube Plugging section following.*

Tube Plugging — A leaky tube can be plugged until retubing can be done. The number of tubes plugged determines how soon cooler *must* be retubed. Tubes plugged in the following locations will affect the performance of the unit: Any tube in the area of thermistor T2, particularly the tube that thermistor T2 is adjacent to, will affect unit reliability and performance. Thermistor T2 is used in the freeze protection algorithm for the controller. If several tubes require plugging, check with your local Carrier representative to find out how number and location can affect unit capacity.

Figure 32 shows an Elliott tube plug and a cross-sectional view of a plug in place.

⚠ CAUTION

Use extreme care when installing plugs to prevent damage to the tube sheet section between the holes.

Retubing (See Table 14) — When retubing is to be done, obtain service of qualified personnel experienced in boiler maintenance and repair. Most standard procedures can be followed when retubing the 10HB coolers. An 8% crush is recommended when rolling replacement tubes into the tube sheet. An 8% crush can be achieved by setting the torque on the gun at 48 to 50 in.-lb (5.4 to 5.6 N-m).

The following Elliott Co. tube rolling tools are required:
B3400 Expander Assembly
B3401 Cage
B3405 Mandrel
B3408 Rolls





Fig. 32 — Elliott Tube Plug

Place one drop of Loctite No. 675 or equivalent on top of tube prior to rolling. This material is intended to “wick” into the area of the tube that is not rolled into the tube sheet, and prevent fluid from accumulating between the tube and the tube sheet.

Tube information:

	in.	mm
• Tube sheet hole diameter	0.631	16.03
• Tube OD	0.625	15.87
• Tube ID after rolling	0.581	14.76
(includes expansion due to clearance)	to 0.588	to 14.94

NOTE: Tubes next to gasket webs must be flush with tube sheet (both ends).

Table 14 — Plugs

COMPONENTS FOR PLUGGING	PART NUMBER
For Tubes	
Brass Pin	853103-500*
Brass Ring	853002-570*
For Holes without Tubes	
Brass Pin	853103-1*
Brass Ring	853002-631*
Loctite	No. 675†
Locquic	“N”†

*Order directly from: Elliott Tube Company, Dayton, Ohio





†Can be obtained locally

Tightening Cooler Head Bolts

Gasket Preparation — When reassembling cooler heads, always use new gaskets. Gaskets are neoprene-based and are brushed with a light film of compressor oil. *Do not soak gasket or gasket deterioration will result.* Use new gaskets within 30 minutes to prevent deterioration. Reassemble cooler nozzle end or plain end cover of the cooler with the gaskets. Torque all cooler bolts to the following specification and sequence:


- 3/8-in. Diameter Perimeter Bolts 150 to 170 ft-lb (201 to 228 N-m)
- 1/2-in. Diameter Flange Bolts 70 to 90 ft-lb (94 to 121 N-m)

1. Install all bolts finger tight.
2. Bolt tightening sequence is outlined in Fig. 33. Follow the numbering sequence so that pressure is evenly applied to gasket.
3. Apply torque in one-third steps until required torque is reached. Load *all* bolts to each one-third step before proceeding to next one-third step.
4. No less than one hour later, retighten all bolts to required torque values.
5. After refrigerant is restored to system, check for refrigerant leaks with soap solution or Halide device.
6. Replace cooler insulation.



*And associated modular units (see Table 1)

Fig. 31 — Typical Tube Sheets, Cover Off (Non-Removable Tubes)



*And associated modular units (see Table 1)

Fig. 33 — Cooler Head Bolt Tightening Sequence (Typical Tube Sheet)

Condenser Coils

COIL CLEANING — Clean coils with a vacuum cleaner, fresh water, compressed air, or a bristle brush (not wire). Units installed in corrosive environments should have coil cleaning as part of a planned maintenance schedule. In this type of application, all accumulations of dirt should be cleaned off the coil.

⚠ CAUTION

Do not use high-pressure water or air — fin damage may result.

Condenser Fans — Each fan is supported by a formed wire mount bolted to fan deck and covered with a wire guard. The exposed end of fan motor shaft is protected from weather by grease. If fan motor must be removed for service or replacement, be sure to regrease fan shaft, and reinstall fan guard. For proper performance, fan should be positioned as in Fig. 34 (standard and low-noise applications). Tighten set-screws to 15 ± 1 ft-lb (20 ± 1.3 N-m).


If the unit is equipped with the high static fan option, the fan must be set from the top of the fan deck to the plastic ring or center of the fan to a distance of $2.13 \text{ in.} \pm 0.13 \text{ in.}$ ($54.6 \pm 3 \text{ mm}$). This is different from standard fans, since there is no area available to measure from the top of the orifice ring to the fan hub itself. See Fig. 35.

IMPORTANT: Check for proper fan rotation (clockwise viewed from above). If necessary, switch any 2 power leads to reverse fan rotation.

Refrigerant Feed Components — Each circuit has all necessary refrigerant controls.

ELECTRONIC EXPANSION VALVE (EXV) — A cutaway view of valve is shown in Fig. 36.


High-pressure liquid refrigerant enters valve through bottom. A series of calibrated slots have been machined in side of orifice assembly. As refrigerant passes through orifice, pressure drops and refrigerant changes to a 2-phase condition (liquid and vapor). To control refrigerant flow for different operating conditions, sleeve moves up and down over orifice and modulates orifice size. Sleeve is moved by a linear stepper motor. Stepper motor moves in increments and is controlled directly by processor board. As stepper motor rotates, motion is transferred into linear movement by lead screw. Through stepper motor and lead screw, 1500 discrete steps of motion are obtained. The large number of steps and long stroke results in very accurate control of refrigerant flow. The valve orifice begins to be exposed at 320 steps. Since there is not a tight seal with the orifice and the sleeve, the minimum position for operation is 120 steps.



DIMENSION	FAN TYPE	
	Standard	Low-Noise (Optional)
A	0.50" (13 mm)	1.50" (38 mm)
B	0.88" (22 mm)	1 1/3" (29 mm)

NOTE Fan rotation is clockwise as viewed from top of unit

Fig. 34 — Condenser Fan Adjustment



NOTE: Dimensions are in millimeters. Dimensions in [] are in inches.

Fig. 35 — Condenser Fan Adjustment, Units with High Static Fan Option

The microprocessor controls the valve. Two thermistor temperature sensors are used to determine superheat. One thermistor is located in cooler and other is located in passage between compressor motor and cylinders. The difference between the 2 temperatures controls superheat. On a normal EXV system, superheat leaving evaporator is normally 3 to 4° F (1.7 to 2.2° C). Motor then adds approximately 20° F (11° C), resulting in approximately 23° F (12.8° C) superheat entering cylinders.

Because EXVs are controlled by the processor board, it is possible to track valve position. By this means, head pressure is controlled and unit is protected against loss of charge and a faulty valve. During initial start-up, EXV is fully closed. After initialization period, valve position is tracked by processor by constantly observing amount of valve movement.

The EXV is also used to limit cooler saturated suction temperature to 55 F (13 C). This makes it possible for the chiller to start at higher cooler fluid temperatures without overloading the compressor. This is commonly referred to as MOP (maximum operating pressure).

If it appears that EXV is not properly controlling operating suction pressure or superheat, there are a number of checks that can be made using quick test and initialization features built into the microprocessor control. See Controls and Troubleshooting literature.

Follow steps below to diagnose and correct EXV problems.

Step 1 — Check Processor EXV Outputs — Check EXV output signals at appropriate terminals on J7 terminal strip as follows:

1. Turn power off.
2. Connect positive test lead of meter to terminal 8 on connector J7 (see Fig. 37).
3. Set meter for approximately 20 vdc.
4. Turn power on, but do not enter quick test mode. For the first 100 seconds, valve motor windings will be alternately energized to close valve in circuit 1.
5. During this time, connect negative test lead to terminals 9, 10, 11, and 12 in succession. Voltage should rise and fall at each pin. If it remains constant at a voltage or at 0 v, remove connector and recheck. If problem is still there, replace processor board. If it is no longer there, check EXV.
6. Turn power off and connect positive lead to terminal 1 on connector J7.
7. Turn power on. After 100 seconds, motor windings in circuit 2 valve will begin to be energized.
8. During this time, connect negative test lead to terminals 2, 3, 4, and 5. Voltage should rise and fall at each pin. If it remains constant at a voltage or at 0 v, remove connector and recheck. If problem is still there, replace processor board. If there is no longer a problem there, check EXV.

Step 2 — Check EXV Wiring — Check wiring to EXVs from J7 terminal strip on processor board (see Fig. 37).

1. Check color coding and wire connections. Make sure wires are connected to correct terminals at J7 and EXV plug connections.
2. Check for continuity and tight connection at all pin terminals.
3. Check plug connections at J7 and at EXVs. Be sure EXV connections are not crossed.

Step 3 — Check Resistance of EXV Motor Windings — Remove plug at J7 terminal strip and check resistance between common lead (red wire, terminal D) and remaining leads A, B, C, and E. Resistance should be 25 ohms $\pm$ 2 ohms.





Fig. 36 — Electronic Expansion Valve (EXV)

PROCESSOR BOARD

J7



EXV — Electronic Expansion Valve

Fig. 37 — Processor Board Connections

Step 4 — Check Thermistors that Control EXV — Check thermistors that control processor output voltage pulses to EXVs. Circuit A thermistors are T5 and T7, and circuit B thermistors are T6 and T8. Refer to Fig. 28 for location.

1. Use quick test steps 2.0. through 2.3. to determine if thermistors are shorted or open.
2. Check thermistor calibration at a known temperature by measuring actual resistance and comparing value measured with values listed in Tables 15 and 16.
3. Make sure that thermistor leads are connected to proper pin terminals at J1 terminal strip on processor board and that thermistor probes are located in proper position in refrigerant circuit (Fig. 28 and 30).

When above checks have been completed, actual operation of EXV can be checked by using procedures outlined in Step 5 — Check Operation of the EXV section below. During quick test steps 3.5. and 3.9., each EXV is opened approximately 500 steps by processor. This quick test feature, along with initialization mode **20**, can be used to verify proper valve operation.

Step 5 — Check Operation of the EXV — Use following procedure to check actual operation of EXVs.

1. Close liquid line service valve for circuit to be checked and run through appropriate quick test step 3.5. or 3.9. to pump down low side of system. Repeat quick test step 3 times to ensure all refrigerant has been pumped from low side and that EXV has been driven fully open (1500 steps open).

NOTE: Do not use control ON-OFF switch to recycle control during this step, and be sure to allow compressors to run full 10 seconds at each step.

2. Turn control circuit switch and compressor circuit breaker(s) to OFF position. Close compressor service valves and remove any remaining refrigerant from low side of system.
3. Remove screws holding top cover of EXV. Carefully remove top cover, using caution to avoid damage to the O-ring seal and motor leads. If EXV plug was disconnected during this process, reconnect it after the cover is removed.

4. Note position of lead screw (see Fig. 36). If valve has responded properly to processor signals in Step 1 of this section, valve should be fully open and lead screw should protrude approximately 1/4 in. (6 mm) to 3/4 in. (19 mm) above top of motor.
5. Recycle control by turning control circuit switch to ON position. This puts control in initialization mode **20**. During first 100 seconds of initialization mode, each valve is driven to fully closed position (zero steps open) by processor. With cover lifted off EXV valve body, observe operation of valve motor and lead screw. The motor should turn in the counterclockwise (CCW) direction and lead screw should move down into motor hub until valve is fully closed. Lead screw movement should be smooth and uniform from fully open to fully closed position.
6. When test has been completed, carefully reassemble EXV. Be careful not to damage motor or O-ring when reassembling valve. Open compressor service valves and close compressor circuit breakers. Open liquid line service valve. Turn control circuit switch to ON position, and allow unit to operate. Verify proper operation of unit.

This process of opening and closing EXV can be repeated by repeating quick test steps 3.5. or 3.9. and recycling control as described in preceding steps. If valve does not operate as described (when properly connected to processor and receiving correct signals), replace valve.

If operating problems persist after reassembly, they may be due to out-of-calibration thermistor(s), or intermittent connections between processor board terminals and EXV plug. Recheck all wiring connections and voltage signals.

Another possible cause of improper refrigerant flow control could be restrictions in liquid line. Check for plugged filter drier(s), stuck liquid line solenoid valve(s), or restricted metering slots in the EXV. Formation of ice or frost on lower body of EXV is one symptom of restricted metering slots. Clean or replace valve if necessary.

NOTE: Frosting of valve is normal during quick test steps 3.5. and 3.9., and at initial start-up. Frost should dissipate after 5- to 10-minute operation of a system that is operating properly. If valve is to be replaced, wrap valve with a wet cloth to prevent excessive heat from damaging internal components. Superheat control built into valve is *not* adjustable.

NOTE: The EXV orifice is a screw-in type that can be removed for inspection and cleaning. Once the top cover has been removed, the EXV motor may be taken out by removing the 2 cap screws securing motor to valve body. Pull motor, lead screw, and the slide assembly up off the orifice assembly. A slot has been cut in top of orifice assembly to facilitate removal using a large screwdriver. Turn orifice assembly counterclockwise to remove.

When cleaning or reinstalling orifice assembly, be careful not to damage orifice assembly seals. The bottom seal acts as a liquid shut-off, replacing a liquid line solenoid valve.

Reassembly of valve is made easier by screwing the slide and lead screw assembly out of the motor. Align hole in top of slide with the guide pin in orifice assembly and gently push slide and lead screw onto orifice assembly about half way. Screw motor onto lead screw and secure EXV motor with cap screws. Be careful not to twist or pull on wires from EXV motor to valve cover pin connections. Check EXV operation in quick test steps outlined on page 49.

Table 15 — Sensor Temperature (°F) vs Resistance/Voltage Drop; Flotronic™ Units

TEMPERATURE (F)	VOLTAGE DROP (V)	RESISTANCE (OHMS)	TEMPERATURE (F)	VOLTAGE DROP (V)	RESISTANCE (OHMS)	TEMPERATURE (F)	VOLTAGE DROP (V)	RESISTANCE (OHMS)
-25	4.684	98,010	63	2.581	7,091	151	0.655	1,007
-24	4.673	94,707	64	2.549	6,911	152	0.644	986
-23	4.662	91,522	65	2.517	6,735	153	0.634	965
-22	4.651	88,449	66	2.486	6,564	154	0.623	945
-21	4.640	85,485	67	2.454	6,399	155	0.613	925
-20	4.628	82,627	68	2.423	6,237	156	0.602	906
-19	4.616	79,871	69	2.391	6,081	157	0.592	887
-18	4.604	77,212	70	2.360	5,929	158	0.582	868
-17	4.591	74,648	71	2.329	5,781	159	0.573	850
-16	4.578	72,175	72	2.299	5,637	160	0.563	832
-15	4.565	69,790	73	2.268	5,497	161	0.554	815
-14	4.551	67,490	74	2.237	5,361	162	0.545	798
-13	4.537	65,272	75	2.207	5,229	163	0.536	782
-12	4.523	63,133	76	2.177	5,101	164	0.527	765
-11	4.509	61,070	77	2.147	4,976	165	0.518	749
-10	4.494	59,081	78	2.117	4,855	166	0.509	734
-9	4.479	57,162	79	2.088	4,737	167	0.501	719
-8	4.463	55,311	80	2.058	4,622	168	0.493	705
-7	4.448	53,526	81	2.029	4,511	169	0.484	690
-6	4.431	51,804	82	2.000	4,403	170	0.476	677
-5	4.415	50,143	83	1.972	4,298	171	0.468	663
-4	4.398	48,541	84	1.943	4,195	172	0.461	650
-3	4.381	46,996	85	1.915	4,096	173	0.453	638
-2	4.363	45,505	86	1.887	4,000	174	0.446	626
-1	4.345	44,066	87	1.859	3,906	175	0.438	614
0	4.327	42,678	88	1.832	3,814	176	0.431	602
1	4.308	41,339	89	1.805	3,726	177	0.424	591
2	4.289	40,047	90	1.778	3,640	178	0.417	581
3	4.270	38,800	91	1.751	3,556	179	0.410	570
4	4.250	37,596	92	1.725	3,474	180	0.403	560
5	4.230	36,435	93	1.699	3,395	181	0.397	551
6	4.209	35,313	94	1.673	3,318	182	0.390	542
7	4.188	34,231	95	1.647	3,243	183	0.384	533
8	4.167	33,185	96	1.622	3,170	184	0.378	524
9	4.145	32,176	97	1.597	3,099	185	0.371	516
10	4.123	31,201	98	1.572	3,031	186	0.365	508
11	4.101	30,260	99	1.548	2,964	187	0.360	501
12	4.078	29,351	100	1.523	2,898	188	0.354	494
13	4.055	28,472	101	1.500	2,835	189	0.348	487
14	4.032	27,624	102	1.476	2,773	190	0.342	480
15	4.008	26,804	103	1.453	2,713	191	0.337	473
16	3.984	26,011	104	1.430	2,655	192	0.332	467
17	3.959	25,245	105	1.407	2,598	193	0.326	461
18	3.934	24,505	106	1.385	2,542	194	0.321	456
19	3.909	23,789	107	1.362	2,488	195	0.316	450
20	3.883	23,096	108	1.341	2,436	196	0.311	444
21	3.858	22,427	109	1.319	2,385	197	0.306	439
22	3.831	21,779	110	1.298	2,335	198	0.301	434
23	3.805	21,153	111	1.277	2,286	199	0.297	429
24	3.778	20,547	112	1.256	2,238	200	0.292	424
25	3.751	19,960	113	1.236	2,192	201	0.288	419
26	3.723	19,392	114	1.216	2,147	202	0.283	415
27	3.696	18,843	115	1.196	2,103	203	0.279	410
28	3.668	18,311	116	1.176	2,060	204	0.274	405
29	3.639	17,796	117	1.157	2,018	205	0.270	401
30	3.611	17,297	118	1.138	1,977	206	0.266	396
31	3.582	16,814	119	1.120	1,937	207	0.262	391
32	3.553	16,346	120	1.101	1,898	208	0.258	386
33	3.523	15,892	121	1.083	1,860	209	0.254	382
34	3.494	15,453	122	1.065	1,822	210	0.250	377
35	3.464	15,027	123	1.048	1,786	211	0.247	372
36	3.434	14,614	124	1.030	1,750	212	0.243	366
37	3.404	14,214	125	1.013	1,715	213	0.239	361
38	3.373	13,826	126	0.997	1,680	214	0.236	356
39	3.343	13,449	127	0.980	1,647	215	0.232	350
40	3.312	13,084	128	0.964	1,614	216	0.229	344
41	3.281	12,730	129	0.948	1,582	217	0.225	338
42	3.250	12,387	130	0.932	1,550	218	0.222	332
43	3.219	12,053	131	0.917	1,519	219	0.219	325
44	3.187	11,730	132	0.902	1,489	220	0.215	318
45	3.156	11,416	133	0.887	1,459	221	0.212	311
46	3.124	11,111	134	0.872	1,430	222	0.209	304
47	3.093	10,816	135	0.857	1,401	223	0.206	297
48	3.061	10,529	136	0.843	1,373	224	0.203	289
49	3.029	10,250	137	0.829	1,345	225	0.200	282
50	2.997	9,979	138	0.815	1,318			
51	2.965	9,717	139	0.802	1,291			
52	2.933	9,461	140	0.788	1,265			
53	2.901	9,213	141	0.775	1,239			
54	2.869	8,973	142	0.762	1,214			
55	2.837	8,739	143	0.750	1,189			
56	2.805	8,511	144	0.737	1,165			
57	2.772	8,291	145	0.725	1,141			
58	2.740	8,076	146	0.713	1,118			
59	2.708	7,868	147	0.701	1,095			
60	2.676	7,665	148	0.689	1,072			
61	2.644	7,468	149	0.678	1,050			
62	2.612	7,277	150	0.666	1,028			

Table 16 — Sensor Temperature (°C) vs Resistance/Voltage Drop; Flotronic™ Units

TEMPERATURE (C)	VOLTAGE DROP (V)	RESISTANCE (OHMS)	TEMPERATURE (C)	VOLTAGE DROP (V)	RESISTANCE (OHMS)	TEMPERATURE (C)	VOLTAGE DROP (V)	RESISTANCE (OHMS)
-32.0	4 690	100 049	16.5	2 622	7334	65.0	0 678	1050
-31.5	4 680	97 006	17.0	2 593	7165	65.5	0 667	1030
-31.0	4 671	94 061	17.5	2 565	7000	66.0	0 657	1011
-30.5	4 661	91 209	18.0	2 536	6840	66.5	0 648	992
-30.0	4 651	88 449	18.5	2 508	6683	67.0	0 638	973
-29.5	4 641	85 777	19.0	2 479	6531	67.5	0 628	955
-29.0	4 630	83 191	19.5	2 451	6382	68.0	0 619	937
-28.5	4 620	80 687	20.0	2 423	6237	68.5	0 609	919
-28.0	4 609	78 264	20.5	2 395	6096	69.0	0 600	902
-27.5	4 597	75 918	21.0	2 367	5959	69.5	0 591	885
-27.0	4 586	73 648	21.5	2 339	5825	70.0	0 582	868
-26.5	4 574	71 451	22.0	2 311	5694	70.5	0 574	852
-26.0	4 562	69 324	22.5	2 283	5566	71.0	0 565	836
-25.5	4 550	67 265	23.0	2 256	5442	71.5	0 557	820
-25.0	4 537	65 272	23.5	2 228	5321	72.0	0 548	805
-24.5	4 525	63 344	24.0	2 201	5203	72.5	0 540	790
-24.0	4 512	61 477	24.5	2 174	5088	73.0	0 532	775
-23.5	4 499	59 670	25.0	2 147	4976	73.5	0 524	761
-23.0	4 485	57 921	25.5	2 120	4867	74.0	0 516	746
-22.5	4 471	56 228	26.0	2 094	4760	74.5	0 508	733
-22.0	4 457	54 589	26.5	2 067	4656	75.0	0 501	719
-21.5	4 443	53 003	27.0	2 041	4555	75.5	0 493	706
-21.0	4 428	51 467	27.5	2 015	4457	76.0	0 486	693
-20.5	4 413	49 980	28.0	1 989	4360	76.5	0 479	681
-20.0	4 398	48 541	28.5	1 963	4267	77.0	0 472	669
-19.5	4 383	47 148	29.0	1 938	4175	77.5	0 465	657
-19.0	4 367	45 799	29.5	1 912	4086	78.0	0 458	645
-18.5	4 351	44 492	30.0	1 887	4000	78.5	0 451	634
-18.0	4 334	43 228	30.5	1 862	3915	79.0	0 444	623
-17.5	4 318	42 003	31.0	1 837	3832	79.5	0 437	613
-17.0	4 301	40 817	31.5	1 813	3752	80.0	0 431	602
-16.5	4 283	39 668	32.0	1 789	3674	80.5	0 425	592
-16.0	4 266	38 556	32.5	1 764	3597	81.0	0 418	583
-15.5	4 248	37 478	33.0	1 741	3523	81.5	0 412	573
-15.0	4 230	36 435	33.5	1 717	3450	82.0	0 406	564
-14.5	4 211	35 424	34.0	1 693	3379	82.5	0 400	556
-14.0	4 193	34 444	34.5	1 670	3310	83.0	0 394	547
-13.5	4 174	33 495	35.0	1 647	3243	83.5	0 388	539
-13.0	4 154	32 576	35.5	1 624	3177	84.0	0 383	531
-12.5	4 135	31 685	36.0	1 602	3113	84.5	0 377	524
-12.0	4 115	30 821	36.5	1 579	3051	85.0	0 371	516
-11.5	4 094	29 984	37.0	1 557	2990	85.5	0 366	509
-11.0	4 074	29 173	37.5	1 536	2931	86.0	0 361	502
-10.5	4 053	28 386	38.0	1 514	2873	86.5	0 355	496
-10.0	4 032	27 624	38.5	1 492	2816	87.0	0 350	489
- 9.5	4 010	26 884	39.0	1 471	2761	87.5	0 345	483
- 9.0	3 989	26 168	39.5	1 450	2707	88.0	0 340	477
- 8.5	3 967	25 472	40.0	1 430	2655	88.5	0 335	472
- 8.0	3 944	24 798	40.5	1 409	2603	89.0	0 331	466
- 7.5	3 922	24 144	41.0	1 389	2553	89.5	0 326	461
- 7.0	3 899	23 509	41.5	1 369	2504	90.0	0 321	456
- 6.5	3 876	22 893	42.0	1 349	2457	90.5	0 317	451
- 6.0	3 852	22 296	42.5	1 330	2410	91.0	0 312	446
- 5.5	3 829	21 716	43.0	1 311	2364	91.5	0 308	441
- 5.0	3 805	21 153	43.5	1 292	2320	92.0	0 303	436
- 4.5	3 781	20 606	44.0	1 273	2276	92.5	0 299	432
- 4.0	3 756	20 076	44.5	1 254	2234	93.0	0 295	427
- 3.5	3 732	19 561	45.0	1 236	2192	93.5	0 291	423
- 3.0	3 707	19 061	45.5	1 218	2152	94.0	0 287	419
- 2.5	3 682	18 575	46.0	1 200	2112	94.5	0 283	415
- 2.0	3 656	18 103	46.5	1 182	2073	95.0	0 279	410
- 1.5	3 631	17 645	47.0	1 165	2035	95.5	0 275	406
- 1.0	3 605	17 199	47.5	1 148	1997	96.0	0 271	402
- 0.5	3 579	16 766	48.0	1 131	1961	96.5	0 267	398
0.0	3 553	16 346	48.5	1 114	1925	97.0	0 264	393
0.5	3 526	15 937	49.0	1 098	1890	97.5	0 260	389
1.0	3 500	15 539	49.5	1 081	1856	98.0	0 257	385
1.5	3 473	15 153	50.0	1 065	1822	98.5	0 253	380
2.0	3 446	14 777	50.5	1 049	1789	99.0	0 250	376
2.5	3 419	14 412	51.0	1 034	1757	99.5	0 246	371
3.0	3 392	14 057	51.5	1 019	1725	100.0	0 243	367
3.5	3 364	13 711	52.0	1 003	1694	100.5	0 240	362
4.0	3 337	13 375	52.5	0 988	1663	101.0	0 236	357
4.5	3 309	13 048	53.0	0 974	1634	101.5	0 233	352
5.0	3 281	12 730	53.5	0 959	1604	102.0	0 230	346
5.5	3 253	12 420	54.0	0 945	1575	102.5	0 227	341
6.0	3 225	12 119	54.5	0 931	1547	103.0	0 224	335
6.5	3 197	11 826	55.0	0 917	1519	103.5	0 221	330
7.0	3 169	11 541	55.5	0 903	1492	104.0	0 218	324
7.5	3 140	11 263	56.0	0 890	1465	104.5	0 215	318
8.0	3 112	10 992	56.5	0 876	1438	105.0	0 212	312
8.5	3 083	10 729	57.0	0 863	1412	105.5	0 209	305
9.0	3 054	10 472	57.5	0 850	1387	106.0	0 206	299
9.5	3 026	10 223	58.0	0 837	1362	106.5	0 204	292
10.0	2 997	9 979	58.5	0 825	1337	107.0	0 201	285
10.5	2 968	9 742	59.0	0 812	1313			
11.0	2 939	9 512	59.5	0 800	1289			
11.5	2 911	9 287	60.0	0 788	1265			
12.0	2 882	9 068	60.5	0 776	1242			
12.5	2 853	8 855	61.0	0 765	1219			
13.0	2 824	8 647	61.5	0 753	1197			
13.5	2 795	8 444	62.0	0 742	1175			
14.0	2 766	8 247	62.5	0 731	1153			
14.5	2 737	8 055	63.0	0 720	1132			
15.0	2 708	7 868	63.5	0 709	1111			
15.5	2 680	7 685	64.0	0 698	1090			
16.0	2 651	7 507	64.5	0 688	1070			

MOISTURE-LIQUID INDICATOR — Clear flow of liquid refrigerant indicates sufficient charge in system. Bubbles in the sight glass indicate undercharged system or presence of noncondensables. Moisture in system, measured in parts per million (ppm), changes color of indicator:

- Green — moisture is below 45 ppm;
- Yellow-green (chartreuse) — 45 to 130 ppm (caution);
- Yellow (wet) — above 130 ppm.

Change filter drier at first sign of moisture in system.

IMPORTANT: Unit must be in operation at least 12 hours before moisture indicator can give an accurate reading. With unit running, indicating element must be in contact with liquid refrigerant to give true reading.

FILTER DRIER — Whenever moisture-liquid indicator shows presence of moisture, replace filter drier(s). There is one filter drier on each circuit. Refer to Carrier Standard Service Techniques Manual, Chapter 1, Refrigerants, for details on servicing filter driers.

LIQUID LINE SOLENOID VALVE — All units have a liquid line solenoid valve to prevent liquid refrigerant migration to low side of system during the off cycle.

LIQUID LINE SERVICE VALVE — This valve is located immediately ahead of filter drier, and has a 1/4-in. Schrader connection for field charging. In combination with compressor discharge service valve, each circuit can be pumped down into the high side for servicing.

Thermistors — Electronic control uses 4 to 9 thermistors to sense temperatures used to control the operation of chiller. See Table 17.

Table 17 — Thermistor Designations

SENSOR	TEMPERATURE
T1	Cooler Leaving Fluid
T2	Cooler Entering Fluid
T3	Saturated Condensing Temperature — Circuit A
T4	Saturated Condensing Temperature — Circuit B
T5	Evaporator Refrigerant Temperature — Circuit A
T6	Evaporator Refrigerant Temperature — Circuit B
T7	Compressor Return Gas Temperature — Circuit A
T8	Compressor Return Gas Temperature — Circuit B
T10	Remote Temperature Sensor (Accessory)

All thermistors are identical in their temperature vs resistance and voltage drop performance. Resistances at various temperatures are listed in Table 15 or 16.

LOCATION — General locations of thermistor sensors are shown in Fig. 28.

Cooler Leaving Fluid Thermistor, T1 — Thermistor T1 is located in the leaving fluid nozzle. The probe is in a well immersed in the fluid. Actual location is shown in Fig. 28 and 30.

Cooler Entering Fluid Thermistor, T2 — Thermistor T2 is located in the cooler shell in first baffle space, in close proximity to tube bundle. Connection is made through 1/4-in. coupling (Fig. 38). Actual location is shown in Fig. 28 and 30.

Saturated Condensing Temperature Thermistors, T3 and T4 — Thermistors T3 and T4 are each clamped to the outside of a return bend on condenser coil. Exact locations for all units are shown in Fig. 28 and 29.

Evaporator Refrigerant Thermistors, T5 and T6 — Thermistors T5 and T6 are located next to refrigerant inlet in cooler

head. Thermistors are well-type thermistors. Typical location is shown in Fig. 28 and 30.

Compressor Return Gas Thermistors, T7 and T8 — Thermistors T7 and T8 are located in lead compressor in each circuit in a suction passage between motor and cylinders above oil pump. They are well-type thermistors. Location is shown in Fig. 28.

Remote Thermistor, T10 — Thermistor T10 is an accessory thermistor that is mounted remotely from unit. It is used for outdoor air or space temperature reset.

To troubleshoot a thermistor, refer to separate Controls and Troubleshooting literature.

TO REPLACE THERMISTOR T2 (Cooler):

▲ CAUTION

Thermistor T2 is installed directly in the fluid circuit. Relieve all pressure or drain fluid before removing.


1. Remove and discard original thermistor and coupling. Do not disassemble new coupling. Install assembly as received.
2. Apply pipe sealant to 1/4-in. NPT threads on replacement coupling, and install in place of original. Do not use the packing nut to tighten coupling. Damage to ferrules will result.
3. Thermistor T2 (entering fluid temperature) should not be touching an internal refrigerant tube, but should be close enough to sense a freeze condition. Recommended distance is 1/8 in. (3.2 mm) from cooler tube. Tighten packing nut finger-tight to position ferrules, then tighten 1 1/4 turns more using a back-up wrench. Ferrules are now attached to the thermistor, which can be withdrawn from coupling for service.

TO REPLACE THERMISTORS T1, T5, T6, T7, AND T8 — Add a small amount of thermal conductive grease to thermistor well. Thermistors are friction-fit thermistors, which must be slipped into receivers located in the cooler leaving fluid nozzle for T1, in the cooler head for T5 or T6, and in the compressor pump end for T7 or T8.


THERMISTORS T3 AND T4 — These thermistors are located on header end of condenser coil. They are clamped on a return bend.

THERMISTOR/TEMPERATURE SENSOR CHECK — A high quality digital volt-ohmmeter is required to perform this check.

1. Connect the digital voltmeter across the appropriate thermistor terminals at the J1 terminal strip on the processor board (see Fig. 26 and Fig. 39). Using the voltage reading obtained, read the sensor temperature from Table 15 or 16. To check thermistor accuracy, measure temperature at probe location with an accurate thermocouple-type temperature measuring instrument. Insulate thermocouple to avoid ambient temperatures from influencing reading. Temperature measured by thermocouple and temperature determined from thermistor voltage reading should be close, $\pm 5^\circ \text{F}$ (3°C) if care was taken in applying thermocouple and taking readings.
2. If a more accurate check is required, unit must be shut down. Remove thermistor and check at a known temperature (freezing point or boiling point of water) using either voltage drop measured across thermistor at the J1 terminals with unit in quick test mode **88** or by determining the resistance with chiller shut down and thermistor disconnected from J1.




FLUID-SIDE THERMISTOR (T1) AND REFRIGERANT THERMISTORS (T5, T6, T7, T8)



FLUID-SIDE THERMISTOR (T2)

NOTE Dimensions in () are in millimeters

Fig. 38 — Thermistors



LEGEND

COMPR — Compressor

Fig. 39 — Thermistor Connections to J1, Processor Board

Safety Devices — Chillers contain many safety devices and protection logic built into electronic control. Following is a brief summary of major safeties. For complete details, refer to Controls and Troubleshooting literature.

COMPRESSOR PROTECTION

Circuit Breaker — One manual-reset, calibrated-trip, magnetic circuit breaker for each compressor protects against over-current. Do not bypass or increase size of a breaker to

correct problems. Determine cause for trouble and correct before resetting breaker. Circuit breaker must-trip amps (MTA) are listed on individual circuit breakers, and on unit label diagrams.

30GU040-110 AND 230B-315B Compressor Protection Board (CPCS) — The CPCS is used to control and protect compressors and crankcase heaters. Board provides following features:

- Compressor contactor control
- Crankcase heater control
- Ground current protection
- Status communication to processor board
- High-pressure protection

One large relay is located on CPCS board that controls crankcase heater and compressor contactor. In addition, relay provides a set of contacts that microprocessor monitors to determine operating status of compressor. If processor board determines that compressor is not operating properly through signal contacts, control locks compressor off.

The CPCS contains logic that can detect if current-to-ground of any winding exceeds 2.5 amps; if so, compressor shuts down.

A high-pressure switch with a trip pressure of 426 ± 7 psig ($2,936 \pm 48$ kPa) is mounted on each compressor; switch setting is shown in Table 18. Switch is wired in series with the CPCS. If switch opens, CPCS relay opens, processor detects it through signal contacts, and compressor locks off.

If any of these switches opens during operation, the compressor stops and the failure is detected by processor when signal contacts open. If lead compressor in either circuit is shut down by high pressure switch, ground current protector, loss of charge switch, or oil pressure switch, all compressors in the circuit are locked off.

30GU130-210, 230A-315A, AND 330A/B-420A/B — A control relay in conjunction with a ground fault module replaces the function of the CPCS. To reset, press the push-button switch on the module.

LOW OIL PRESSURE PROTECTION — Lead compressor in each circuit is equipped with a switch to detect low oil pressure. Switch is connected directly to processor board. Switch is set to open at approximately 5 psig (35 kPa) and to close at 9 psig (62 kPa) maximum. If switch opens when compressor is running, processor board stops all compressors in circuit. During start-up, switch is bypassed for 2 minutes.

CRANKCASE HEATERS — Each compressor has a 180-w crankcase heater to prevent absorption of liquid refrigerant by oil in crankcase when compressor is not running. Heater power source is auxiliary control power, independent of main unit power. This assures compressor protection even when main unit power disconnect switch is off.

IMPORTANT: Never open any switch or disconnect that deenergizes crankcase heaters unless unit is being serviced or is to be shut down for a prolonged period. After a prolonged shutdown or a service job, energize crankcase heaters for 24 hours before starting unit.

COOLER PROTECTION

Freeze Protection — Cooler can be wrapped with heater cables as shown in Fig. 40, which are wired through an ambient temperature switch set at 36 F (2 C). Entire cooler is covered with closed-cell insulation applied over heater cables. Heaters plus insulation protect cooler against low ambient temperature freeze-up to 0° F (-18 C).

IMPORTANT: If unit is installed in an area where ambient temperatures fall below 32 F (0° C), it is recommended that inhibited ethylene glycol or other suitable corrosion-inhibitive antifreeze solution be used in chilled-liquid circuit.

⚠ CAUTION

If coolers are equipped with heaters and the coolers are drained during the non-cooling season, the cooler heaters **MUST** be disconnected by removing fuse no. 1. Without fluid in the cooler, the heater could reach a temperature that damages the cooler insulation.




Fig. 40 — Cooler Heater Cables

Low Fluid Temperature — Microprocessor is programmed to shut chiller down if leaving fluid temperature drops below 35 F (1.7 C). When fluid temperature rises to 6° F (3.3° C) above leaving fluid set point, safety resets and chiller restarts.

Loss of Fluid Flow Protection — Microprocessor contains internal logic that protects cooler against loss of cooler flow. Entering and leaving fluid temperature sensors in cooler detect a no-flow condition. Leaving sensor is located in leaving fluid nozzle and entering sensor is located in first cooler baffle space in close proximity to cooler tubes, as shown in Fig. 30. When there is no cooler flow and the compressors

start, leaving fluid temperature does not change. However, entering fluid temperature drops rapidly as refrigerant enters cooler through EXV. Entering sensor detects this temperature drop and when entering temperature is 5° F (2.8° C) below leaving temperature, unit stops and is locked off.

Loss-of-Charge — A pressure switch connected to high side of each refrigerant circuit protects against total loss-of-charge. Switch settings are listed in Table 18. If switch is open, unit cannot start; if switch opens during operation, unit locks out and cannot restart until switch is closed. Low charge is also monitored by the processor.

A low charge is detected by monitoring EXV position and superheat entering the compressor. If EXV is wide open, superheat is greater than 50 F (28 C) and saturated cooler suction is less than 55 F (13 C), circuit is stopped and locked off.

Relief Devices — Fusible plugs are located in each circuit to protect against damage from excessive pressures.

HIGH-SIDE PROTECTION — One device is located between condenser and filter drier; a second is on filter drier. These are both designed to relieve pressure on a temperature rise to approximately 210 F (99 C).

LOW-SIDE PROTECTION — A device is located on suction line, designed to relieve pressure on a temperature rise to approximately 170 F (77 C).

PRESSURE RELIEF VALVES — Where relief valves are installed, there is one in each circuit. The valves are designed to relieve at 450 psig (3103 kPa). *These valves should not be capped.* If a valve relieves, it should be replaced. If valve is not replaced, it may relieve at a lower pressure, or leak due to trapped dirt from the system which may prevent resealing.

The pressure relief valves are equipped with a 3/8-in. SAE flare for field connection. Some local building codes require that relieved gases be removed. This connection will allow conformance to this requirement.

Other Safeties — There are several other safeties that are provided by microprocessor control. For details refer to Controls and Troubleshooting literature.

Table 18 — Pressure Switch Settings, psig (kPa)

SWITCH	CUTOUT	CUT-IN
High Pressure	280 ± 7 (1931 ± 48)	320 ± 20 (1241 ± 138)
Loss-of-Charge	7 (48.2)	22 (151.6)



