



# Installation Instructions

## CONTENTS

|  | Page |
|--|------|
| <b>SAFETY CONSIDERATIONS</b>   | 1    |
| <b>GENERAL</b>   | 2    |
| <b>Rated Indoor Airflow (cfm)</b>  | 2    |
| <b>INSTALLATION</b>  | 19   |
| <b>Jobsite Survey</b>  | 19   |
| <b>Step 1 — Plan for Unit Location</b>                                     | 19   |
| • ROOF MOUNT   |      |
| <b>Step 2 — Plan for Sequence of Unit Installation</b>                     | 19   |
| • CURB-MOUNTED INSTALLATION  |      |
| • PAD-MOUNTED INSTALLATION   |      |
| • FRAME-MOUNTED INSTALLATION   |      |
| <b>Step 3 — Inspect Unit</b>   | 19   |
| <b>Step 4 — Provide Unit Support</b>                                       | 20   |
| • ROOF CURB MOUNT  |      |
| • SLAB MOUNT (HORIZONTAL UNITS ONLY)                                       |      |
| • ALTERNATE UNIT SUPPORT (IN LIEU OF CURB OR SLAB MOUNT)                   |      |
| <b>Step 5 — Field Fabricate Ductwork</b>                                   | 24   |
| <b>Step 6 — Rig and Place Unit</b>   | 24   |
| • POSITIONING ON CURB  |      |
| <b>Step 7 — Horizontal Duct Connection</b>                                 | 24   |
| <b>Step 8 — VAV Duct Pressure Transducer and Field Tubing Installation</b> | 24   |
| <b>Step 9 — Install Outside Air Hood</b>                                   | 25   |
| <b>Step 10 — Assemble Barometric Hood</b>                                  | 26   |
| • BAROMETRIC HOOD (VERTICAL CONFIGURATION)                                 |      |
| • BAROMETRIC HOOD (HORIZONTAL CONFIGURATION)                               |      |
| <b>Step 11 — Economizer - Horizontal Airflow Units</b>                     | 27   |
| <b>Step 12 — Install Flue Hood and Combustion Air Hood</b>                 | 28   |
| <b>Step 13 — Install Gas Piping</b>  | 28   |
| • GAS SUPPLY LINE  |      |
| • FACTORY-OPTION THRU-BASE CONNECTIONS                                     |      |
| <b>Step 14 — Make Electrical Connections</b>                               | 31   |
| • FIELD POWER SUPPLY   |      |
| • UNITS WITHOUT FACTORY-INSTALLED NON-FUSED DISCONNECT OR HACR             |      |
| • UNITS WITH FACTORY-INSTALLED NON-FUSED DISCONNECT OR HACR                |      |
| • ALL UNITS  |      |
| • CONVENIENCE OUTLETS  |      |
| • HACR   |      |
| • FACTORY-OPTION THRU-BASE CONNECTIONS                                     |      |
| • UNITS WITHOUT THRU-BASE CONNECTIONS                                      |      |
| • UNIT WITHOUT THRU-BASE CONNECTION KIT                                    |      |
| • HEAT ANTICIPATOR SETTINGS  |      |
| • TRANSFORMER CONNECTION FOR 208-V POWER SUPPLY                            |      |
| <b>VAV-RTU Open Controller</b>   | 37   |
| <b>Integrated Staging Control (ISC) Board</b>                              | 38   |
| • SEQUENCE OF OPERATION  |      |
| <b>Variable Air Volume (VAV) with Variable Frequency Drive</b>             | 41   |
| • MULTI-SPEED VFD DISPLAY KIT (FIELD-INSTALLED OPTION)                     |      |
| • CONNECTING THE KEYPAD TO THE VFD   |      |
| • PROGRAM THE VFD FOR INDOOR FAN CONTROL                                   |      |
| <b>Smoke Detectors</b>   | 54   |
| • RETURN AIR SENSOR TUBE INSTALLATION                                      |      |
| • SMOKE DETECTOR TEST MAGNET   |      |
| • ADDITIONAL APPLICATION DATA  |      |
| <b>Step 15 — Install Accessories</b>                                       | 54   |
| <b>Pre-Start and Start-Up</b>  | 54   |
| <b>START-UP CHECKLIST</b>  | CL-1 |

## SAFETY CONSIDERATIONS

Installation and servicing of air-conditioning equipment can be hazardous due to system pressure and electrical components. Only trained and qualified service personnel should install, repair, or service air-conditioning equipment.

Untrained personnel can perform basic maintenance functions of cleaning coils and filters and replacing filters. All other operations should be performed by trained service personnel. When working on air-conditioning equipment, observe precautions in the literature, tags and labels attached to the unit, and other safety precautions that may apply.

Follow all safety codes, including ANSI (American National Standards Institute) Z223.1. Wear safety glasses and work gloves. Use quenching cloth for unbrazing operations. Have fire extinguisher available for all brazing operations.

It is important to recognize safety information. This is the safety-alert symbol  $\Delta$ . When you see this symbol on the unit and in instructions or manuals, be alert to the potential for personal injury.

Understand the signal words DANGER, WARNING, CAUTION, and NOTE. These words are used with the safety-alert symbol. DANGER identifies the most serious hazards which **will** result in severe personal injury or death. WARNING signifies hazards which **could** result in personal injury or death. CAUTION is used to identify unsafe practices, which **may** result in minor personal injury or product and property damage. NOTE is used to highlight suggestions which **will** result in enhanced installation, reliability, or operation.

## ⚠️ WARNING

### FIRE, EXPLOSION HAZARD

Failure to follow this warning could result in death, serious personal injury and/or property damage.


Disconnect gas piping from unit when pressure testing at pressure greater than 0.5 psig (3450 Pa). Pressures greater than 0.5 psig will cause gas valve damage resulting in hazardous condition. If gas valve is subjected to pressure greater than 0.5 psig, it must be replaced before use. When pressure testing field-supplied gas piping at pressures of 0.5 psig or less, a unit connected to such piping must be isolated by closing the manual gas valve(s).

## ⚠️ WARNING

### FIRE HAZARD

Failure to follow this warning could result in severe personal injury and/or property damage.

Inlet pressure tap set screw must be tightened and 1/8-in. NPT pipe plug must be installed to prevent gas leaks.




## ⚠️ WARNING

### FIRE HAZARD

Failure to follow this warning could result in severe personal injury and/or property damage.

Manifold pressure tap set screw must be tightened and 1/8-in. NPT pipe plug must be installed to prevent gas leaks.



## ⚠️ WARNING

### CARBON-MONOXIDE POISONING HAZARD

Failure to follow instructions could result in severe personal injury or death due to carbon-monoxide poisoning, if combustion products infiltrate into the building.

Check that all openings in the outside wall around the vent (and air intake) pipe(s) are sealed to prevent infiltration of combustion products into the building.

Check that furnace vent (and air intake) terminal(s) are not obstructed in any way during all seasons.

## ⚠️ AVERTISSEMENT

### RISQUE D'INTOXICATION AU MONOXYDE DE CARBONE

Si ces directives ne sont pas suivies, cela peut entraîner des blessures graves ou une intoxication au monoxyde de carbone pouvant causer la mort, si des produits de combustion s'infiltrent dans le bâtiment.

Vérifier que toutes les ouvertures pratiquées dans le mur extérieur autour du ou des tuyaux d'évent (et de la prise d'air) sont scellées de manière à empêcher l'infiltration de produits de combustion dans le bâtiment.

Veiller à ce que la ou les sorties de l'évent de l'appareil de chauffage (et la prise d'air) ne soient, en aucune façon, obstruées, quelle que soit la saison.

## ⚠️ DANGER

### ELECTRICAL SHOCK HAZARD

Failure to follow this warning will result in personal injury or death.

Before performing service or maintenance operations on unit, turn off main power switch to unit and install lock(s) and lock-out tag(s). Ensure electrical service to rooftop unit agrees with voltage and amperage listed on the unit rating plate. Unit may have more than one power switch.

## ⚠️ WARNING

### PERSONAL INJURY AND ENVIRONMENTAL HAZARD

Failure to follow this warning could cause personal injury or death.

Relieve pressure and recover all refrigerant before system repair or final unit disposal.

Wear safety glasses and gloves when handling refrigerants. Keep torches and other ignition sources away from refrigerants and oils.

## ⚠️ CAUTION

### PERSONAL INJURY HAZARD

Failure to follow this caution may result in personal injury.

Sheet metal parts may have sharp edges or burrs. Use care and wear appropriate protective clothing, safety glasses and gloves when handling parts and servicing air conditioning equipment.

## GENERAL

See Fig. 1 for model number nomenclature. See Fig. 2-16 for unit dimensions. See Table 2 for operating weights.

### Rated Indoor Airflow (cfm)

Table 1 lists the rated indoor airflow used for the AHRI efficiency rating for the units covered in this document.

**Table 1 — Rated Indoor Airflow**

| UNIT     | FULL LOAD AIRFLOW (CFM) |
|----------|-------------------------|
| 48LC*B14 | 4375                    |
| 48LC*B17 | 4875                    |
| 48LC*B20 | 5690                    |
| 48LC*B24 | 6500                    |
| 48LC*B26 | 7500                    |

|           |   |   |   |   |   |   |   |   |   |    |    |    |    |    |    |    |    |    |
|-----------|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|
| Position: | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 |
| Example:  | 4 | 8 | L | C | D | B | 2 | 4 | A | 1  | A  | 5  | -  | 1  | N  | 0  | A  | 0  |

**Unit Heat Type**  
48 - Gas Heat Packaged Rooftop

**Model Series - WeatherExpert®**  
LC - Ultra High Efficiency

**Heat Options**

D = Low Gas Heat  
E = Medium Gas Heat  
F = High Gas Heat  
S = Low Heat w/ Stainless Steel Exchanger  
R = Medium Heat w/ Stainless Steel Exchanger  
T = High Heat w/ Stainless Steel Exchanger

**Refrigerant System**

B = Three stage cooling capacity control  
with multi-zone VAV operation

**Cooling Tons**

14 - 12.5 ton  
17 - 15 ton  
20 - 17.5 ton  
24 - 20 ton  
26 - 23 ton

**Sensor Options**

A = None  
B = RA Smoke Detector  
C = SA Smoke Detector  
D = RA + SA Smoke Detector  
E = CO<sub>2</sub>  
F = RA Smoke Detector and CO<sub>2</sub>  
G = SA Smoke Detector and CO<sub>2</sub>  
H = RA + SA Smoke Detector and CO<sub>2</sub>

**Indoor Fan Motor Options**

1 = Standard Static / Vertical Supply, Return Air Flow  
2 = Medium Static / Vertical Supply, Return Air Flow  
3 = High Static / Vertical Supply, Return Air Flow  
4 = Ultra High Static / Vertical Supply, Return Air Flow  
5 = Standard Static / Horizontal Supply, Return Air Flow  
6 = Medium Static / Horizontal Supply, Return Air Flow  
7 = High Static / Horizontal Supply, Return Air Flow  
8 = Ultra High Static / Horizontal Supply, Return Air Flow

**Coil Options: Fin/Tube (Condenser – Evaporator – Hail Guard)**

A = Al/Cu – Al/Cu  
B = Precoat Al/Cu – Al/Cu  
C = E-coat Al/Cu – Al/Cu  
D = E-coat Al/Cu – E-coat Al/Cu  
E = Cu/Cu – Al/Cu  
F = Cu/Cu – Cu/Cu  
M = Al/Cu – Al/Cu – Louvered Hail Guard  
N = Precoat Al/Cu – Al/Cu – Louvered Hail Guard  
P = E-coat Al/Cu – Al/Cu – Louvered Hail Guard  
Q = E-coat Al/Cu – E-coat Al/Cu – Louvered Hail Guard  
R = Cu/Cu – Al/Cu – Louvered Hail Guard  
S = Cu/Cu – Cu/Cu – Louvered Hail Guard

NOTE: Not all possible options can be displayed above. Refer to other support material or your local Carrier Expert.

**Packaging**  
0 = Standard  
1 = LTL

**Electrical Options**

A = None  
B = HACR Circuit Breaker  
C = Non-Fused Disconnect

**Service Options**

0 = None  
1 = Unpowered Convenience Outlet  
2 = Powered Convenience Outlet  
3 = Hinged Panels  
4 = Hinged Panels and  
Unpowered Convenience Outlet  
5 = Hinged Panels and  
Powered Convenience Outlet

**Intake / Exhaust Options (required on each unit)**

B = Temperature Low Leak Economizer  
with Barometric Relief  
C = Temperature Low Leak Economizer  
with Centrifugal Power Exhaust - Vertical Only  
E = Enthalpy Low Leak Economizer  
with Barometric Relief  
F = Enthalpy Low Leak Economizer  
with Centrifugal Power Exhaust - Vertical Only  
N = Temperature Ultra Low Leak Economizer  
with Barometric Relief  
P = Temperature Ultra Low Leak Economizer  
with Centrifugal Power Exhaust - Vertical Only  
R = Enthalpy Ultra Low Leak Economizer  
with Barometric Relief  
S = Enthalpy Ultra Low Leak Economizer  
with Centrifugal Power Exhaust - Vertical Only

**Base Unit Controls**

1 = VAV-RTU Open Controller  
(required on each model)

**Design Revision**

- = Factory Design Revision


**Voltage**

1 = 575/3/60  
5 = 208-230/3/60  
6 = 460/3/60


**Fig. 1 — 48LC\*B14-26 Model Number Nomenclature**



THIS DOCUMENT IS THE PROPERTY OF UIC CLIMATE CONTROLS & SECURITY AND IS DELIVERED UPON REQUEST. IT IS NOT TO BE COPIED OR DISCLOSED EXCEPT AS AUTHORIZED IN THE CONTRACT.



**Fig. 3 — 48LC\*B14 Horizontal Airflow**






Fig. 5 — 48LC\*B14 Corner Weights and Clearances





Fig. 6 — 48LC\*B14 Bottom View



**Fig. 7 — 48LC\*B17-20 Vertical Airflow**




Fig. 8 — 48LC\*B17-20 Horizontal Airflow




Fig. 9 — 48LC\*17-20 Back View and Condensate Drain Location







Fig. 10 — 48LC\*B17-20 Corner Weights and Clearances


**Carrier** • Lubbock, Texas  
This document is the property of UIC. The prints, condition  
and rights to them are held by UIC. It is the express condition  
that the contents will not be disclosed or used  
without the written consent of UIC.  
SUBMISSION OF THESE DRAWINGS OR DOCUMENTS  
DOES NOT CONSTITUTE ACCEPTANCE OF CONTRACT.



136-1/4  
[3460]  
INSIDE DIM  
BASE RAILS




DETAIL A  
TYPE 4  
PLCS



RIGGING HOLE LOCATIONS

| IIC CLASSIFICATION | SHEET  | DATE     | SUPERSEDES | 48LC 17.20 SINGLE ZONE ELECTRICAL<br>COOLING WITH GAS HEAT | 50LC500665 | REV |
|--------------------|--------|----------|------------|--|------------|-----|
| IIS FCC/NR         | 5 OF 5 | 01/28/19 | 11/06/12   |  |            | A   |




**Fig. 12 — 48LC\*B24-26 Vertical Airflow**


**Carrier**  
United Technologies

THIS DOCUMENT IS THE PROPERTY OF UIC CLIMATE CONTROLS  
AND SECURE IT AND IS HELD UPON THE EXPRESS CONDITION  
THAT THE CONTENTS WILL NOT BE DISCLOSED OR USED  
WITHOUT WRITTEN CONSENT.

SUBMISSION OF THESE DRAWINGS OR DOCUMENTS  
DOES NOT CONSTITUTE PAR PERFORMANCE OR  
ACCEPTANCE OF CONTRACT.



**Fig. 13 — 48LC\*B24-26 Horizontal Airflow**



**Fig. 14 — 48LC\*B24-26 Back View and Condensate Drain Location**





Fig. 15 — 48LC\*B24-26 Corner Weights and Clearances



**Fig. 16 — 48LC\*B24-26 Bottom View**

**Table 2 — Operating Weights**

| 48LC*B                | UNIT LB (KG) |              |               |               |               |
|-----------------------|--------------|--------------|---------------|---------------|---------------|
|                       | 14           | 17           | 20            | 24            | 26            |
| <b>Base Unit</b>      | 1853 (842.3) | 2095 (952.3) | 2201 (1000.7) | 2347 (1067.0) | 2492 (1132.6) |
| <b>Economizer</b>     | 246 (112)    | 246 (112)    | 246 (112)     | 246 (112)     | 246 (112)     |
| <b>Powered Outlet</b> | 35 (16)      | 35 (16)      | 35 (16)       | 35 (16)       | 35 (16)       |
| <b>Curb</b>           |              |              |               |               |               |
| 14-in./356 mm         | 240 (109)    | 240 (109)    | 255 (116)     | 255 (116)     | 273 (124)     |
| 24-in./610 mm         | 340 (154)    | 340 (154)    | 355 (161)     | 355 (161)     | 355 (161)     |

## INSTALLATION

### Jobsite Survey

Complete the following checks before installation.

1. Consult local building codes and the NEC (National Electrical Code) ANSI/NFPA 70 for special installation requirements.
2. Determine unit location (from project plans) or select unit location.
3. Check for possible overhead obstructions which may interfere with unit lifting or rigging.

### Step 1 — Plan for Unit Location

Select a location for the unit and its support system (curb or other) that provides for the minimum clearances required for safety. This includes the clearance to combustible surfaces, unit performance and service access below, around, and above unit as specified in unit drawings. See Fig. 5, 10, and 15.

NOTE: Consider also the effect of adjacent units.

Be sure that the unit is installed such that snow will not block the combustion air intake or flute outlet.

Unit may be installed directly on wood flooring or on Class A, B, or C roof-covering material when roof curb is used.

Do not install unit in an indoor location. Do not locate air inlets near exhaust vents or other sources of contaminated air. For proper unit operation, adequate combustion and ventilation air must be provided in accordance with Section 5.3 (Air for Combustion and Ventilation) of the National Fuel Gas Code, ANSI Z223.1 (American National Standards Institute) and NFPA (National Fire Protection Association) 54 TIA-54-84-1. In Canada, installation must be in accordance with the CAN1-B149 installation codes for gas burning appliances.

Although unit is weatherproof, avoid locations that permit water from higher level runoff and overhangs to fall onto the unit.

Locate mechanical draft system flue assembly at least 4 ft (1.2 m) from any opening through which combustion products could enter the building, and at least 4 ft (1.2 m) from any adjacent building (or per local code). Locate the flue assembly at least 10 ft (3.05 m) from an adjacent unit's fresh air intake hood if within 3 ft (0.91 m) of same elevation (or per local code). When unit is located adjacent to public walkways, flue assembly must be at least 7 ft (2.1 m) above grade.

Select a unit mounting system that provides adequate height to allow installation of condensate trap per requirements. Refer to Step 11 — Install External Condensate Trap and Line — for required trap dimensions.

### ROOF MOUNT

Check building codes for weight distribution requirements. Unit operating weight is shown in Table 2.

### Step 2 — Plan for Sequence of Unit Installation

The support method used for this unit will dictate different sequences for the steps of unit installation. For example, on curb-mounted units, some accessories must be installed on the unit

before the unit is placed on the curb. Review the following for recommended sequences for installation steps.

#### CURB-MOUNTED INSTALLATION

1. Install curb
2. Install field-fabricated ductwork inside curb
3. Install thru-base service connection fittings (affects curb and unit)
4. Rig and place unit
5. Remove top skid
6. Install outside air hood
7. Install smoke detector tube
8. Install combustion air hood
9. Install flue hood
10. Install gas piping
11. Install condensate line trap and piping
12. Make electrical connections
13. Install other accessories

#### PAD-MOUNTED INSTALLATION

1. Prepare pad and unit supports
2. Rig and place unit
3. Remove duct covers and top skid
4. Install smoke detector return air sensor tube
5. Install field-fabricated ductwork at unit duct openings
6. Install outside air hood
7. Install combustion air hood
8. Install flue hood
9. Install gas piping
10. Install condensate line trap and piping
11. Make electrical connections
12. Install other accessories

#### FRAME-MOUNTED INSTALLATION

Frame-mounted applications generally follow the sequence for a curb installation. Adapt as required to suit specific installation plan.


### Step 3 — Inspect Unit

Inspect unit for transportation damage. File any claim with transportation agency.

Confirm before installation of unit that voltage, amperage and circuit protection requirements listed on unit data plate agree with power supply provided.

On units with hinged panel option, check to be sure all latches are tight and in closed position.

Locate the carton containing the outside air hood parts; see Fig. 17 and 25. Do not remove carton until unit has been rigged and located in final position.



**Fig. 17 — Typical Access Panel and Compressor Locations**

#### Step 4 — Provide Unit Support

##### ROOF CURB MOUNT


See Fig. 19 for unit rigging details. Accessory roof curb details and dimensions are shown in Fig. 20-22. Assemble and install accessory roof curb in accordance with instructions shipped with the curb.

NOTE: The gasketing of the unit to the roof curb is critical for a watertight seal. Install gasket supplied with the roof curb as shown in Fig. 20-22. Improperly applied gasket can also result in air leaks and poor unit performance.

Curb should be level. This is necessary for unit drain to function properly. Unit leveling tolerances are shown in Fig. 18. Refer to Accessory Roof Curb Installation Instructions for additional information as required.

Install insulation, cant strips, roofing felt, and counter flashing as shown. Ductwork must be attached to curb and not to the unit. Thru-the-base power connection must be installed before the unit is set on the roof curb. If field-installed thru-the-roof curb gas connections are desired remove knockout in basepan located in the gas section, see Fig. 17 for location. Gas connections and power

connections to the unit must be field installed after the unit is installed on the roof curb.



**Fig. 18 — Unit Leveling Tolerances**

If electrical and control wiring is to be routed through the basepan, remove the knockouts in the basepan located in the control box access area (see Fig. 17). For basepan knockout locations for vertical airflow units, see Fig. 2, 7, or 12; for horizontal airflow units, see Fig. 3, 8, or 13. Attach the service connections to the basepan.


##### SLAB MOUNT (HORIZONTAL UNITS ONLY)

Provide a level concrete slab that extends a minimum of 6-in. (150 mm) beyond unit cabinet. Install a gravel apron in front of condenser coil air inlet to prevent grass and foliage from obstructing airflow.

NOTE: Horizontal units may be installed on a roof curb if required.

##### ALTERNATE UNIT SUPPORT (IN LIEU OF CURB OR SLAB MOUNT)

A non-combustible sleeper rail can be used in the unit curb support area. If sleeper rails cannot be used, support the long sides of the unit with a minimum of 4 equally spaced 4-in. x 4-in. (102 mm x 102 mm) pads on each side. Locate pads so that they support the rails. Make sure to avoid the fork openings.



| UNIT     | MAX WEIGHT |      | DIMENSIONS |      |      |      |      |      |
|----------|------------|------|------------|------|------|------|------|------|
|          | lb         | kg   | A          |      | B    |      | C    |      |
| 48LC*B14 | 2135       | 970  | 127.8      | 3249 | 59.1 | 1501 | 52.3 | 1328 |
| 48LC*B17 | 2377       | 1080 | 141.5      | 3595 | 65.5 | 1664 | 60.3 | 1532 |
| 48LC*B20 | 2483       | 1129 | 141.5      | 3595 | 65.5 | 1664 | 60.3 | 1532 |
| 48LC*B24 | 2629       | 1195 | 157.8      | 4007 | 72.8 | 1849 | 60.3 | 1532 |
| 48LC*B26 | 2774       | 1261 | 157.8      | 4007 | 72.8 | 1849 | 60.3 | 1532 |

##### NOTES:

1. Dimensions in ( ) are inches.
2. Hook rigging shackles through holes in base rail, as shown in detail "A." Holes in base rails are centered around the unit center of gravity. Use wooden top to prevent rigging straps from damaging unit.

**Fig. 19 — Rigging Details**

| UNIT SIZE | "A"                                 | ROOF CURB<br>ACCESSORY           |
|-----------|-------------------------------------|----------------------------------|
| 14        | 1'-4-5/16" [356.0]<br>2'-0" [610.0] | CRRFCURB045A00<br>CRRFCURB046A00 |






Fig. 20 — 48LC\*B14 Roof Curb Details

| UNIT SIZE | "A"                            | ROOF CURB<br>ACCESSORY           |
|-----------|--------------------------------|----------------------------------|
| 17, 20    | 1'-2" [356.0]<br>2'-0" [610.0] | CRRFCURB047A00<br>CRRFCURB048A00 |




**NOTES:**

- 1 ROOF CURB ACCESSORY IS SHIPPED UNASSEMBLED.
- 2 DIMENSIONS IN [ ] ARE IN MILLIMETERS.
- 3 ROOF CURB GALVANIZED STEEL.
- 4 ATTACH DUCTWORK TO CURB (FLANGES ON DUCT REST ON CURB)

5 SERVICE CLEARANCE 4" ON EACH SIDE


→ DIRECTION OF AIR FLOW






RETURN END

0'-1 1/4" ↓ .28° ↓  
[5.9]

#### MAX CURB LEVELING TOLERANCES




The diagram illustrates a vertical wall corner detail. A vertical wall is shown with a horizontal curb at the top. A gasket, labeled '(SUPPLIED WITH CURB)', is applied to the curb. The distance from the bottom of the curb to the top of the wall is indicated as '0'-7/16" [111]. The wall is covered with 'RIGID INSULATION (FIELD SUPPLIED)'. A 'GASKET' is applied to the curb. A 'NAIL' is shown at the top of the curb. A 'COUNTER FLASHING (FIELD SUPPLIED)' is applied over the curb. A 'ROOFING FELT (FIELD SUPPLIED)' is applied over the counter flashing. A 'CANT STRIP (FIELD SUPPLIED)' is applied over the roofing felt. A 'ROOFING MATERIAL (FIELD SUPPLIED)' is applied over the cant strip.



**Fig. 21 — 48LC\*B17-20 Roof Curb Details**


| UNIT SIZE | "A"                            | ROOF CURB<br>ACCESSORY           |
|-----------|--------------------------------|----------------------------------|
| 24, 26    | 1'-2" [356.0]<br>2'-0" [610.0] | CRRFCURB049A00<br>CRRFCURB050A00 |



NOTES:

- 1 ROOF CURB ACCESSORY IS SHIPPED UNASSEMBLED.
- 2 BOLT HEADS TO BE ON INSIDE OF FLANGE.  
CLEARANCE IS [11] 0-0-7/16" TYP ALL CORNERS.
- 3 DIMENSIONS IN [ ] ARE IN MILLIMETERS.
- 4 ROOF CURB GALVANIZED STEEL.
- 5 ATTACH DUCTWORK TO CURB (FLANGES ON DUCT  
REST ON CURB)
- 6 SERVICE CLEARANCE 4 ft ON EACH SIDE
- 7 GAS SERVICE PLATE IS PART OF A SEPARATELY  
SHIPPED ACCESSORY PACKAGE.
- 8 GAS SERVICE PLATE CAN BE USED WITH EITHER  
ACCESSORY ROOFCURB.

► DIRECTION OF AIR FLOW



MAX CURB LEVELING TOLERANCES







Fig. 22 — 48LC\*B24-26 Roof Curb Details

## Step 5 — Field Fabricate Ductwork

Cabinet return-air static pressure (a negative condition) shall not exceed 0.5 in. wg (87 Pa).

For vertical ducted applications, secure all ducts to roof curb and building structure. Do not connect ductwork to unit.

Fabricate supply ductwork so that the cross sectional dimensions are equal to or greater than the unit supply duct opening dimensions for the first 18-in. (458 mm) of duct length from the unit basepan.

Insulate and weatherproof all external ductwork, joints, and roof openings with counter flashing and mastic in accordance with applicable codes.

Ducts passing through unconditioned spaces must be insulated and covered with a vapor barrier.

If a plenum return is used on a vertical unit, the return should be ducted through the roof deck to comply with applicable fire codes. A minimum clearance is not required around ductwork.

### ⚠ CAUTION

#### PROPERTY DAMAGE HAZARD

Failure to follow this caution may result in damage to roofing materials.

Membrane roofs can be cut by sharp sheet metal edges. Be careful when placing any sheet metal parts on such roof.

## Step 6 — Rig and Place Unit

Keep unit upright and do not drop. Spreader bars are not required if top crating is left on unit. Rollers may be used to move unit across a roof. Level by using unit frame as a reference. See Table 2 (on page 19) and Fig. 19 for additional information.

Lifting holes are provided in base rails as shown in Fig. 19. Refer to rigging instructions on unit.

### ⚠ CAUTION

#### UNIT DAMAGE HAZARD

Failure to follow this caution may result in equipment damage. All panels must be in place when rigging. Unit is not designed for handling by fork truck when packaging is removed.

If using top crate as spreader bar, once unit is set, carefully lower wooden crate off building roof top to ground. Ensure that no people or obstructions are below prior to lowering the crate.

Before setting the unit onto the curb, recheck gasketing on curb.

#### POSITIONING ON CURB

Position unit on roof curb so that the following clearances are maintained: 1/4-in. (6 mm) clearance between the roof curb and the base rail inside the right and left, 1/2-in. (12 mm) clearance between the roof curb and the base rail inside the front and back. This will result in the distance between the roof curb and the base rail inside on the condenser end of the unit being approximately equal to Details A and B in Fig. 20-22.

Do not attempt to slide unit on curb after unit is set. Doing so will result in damage to the roof curb seal.

Although unit is weatherproof, guard against water from higher level runoff and overhangs.

Flue vent discharge must have a minimum horizontal clearance of 48-in. (1220 mm) from electric and gas meters, gas regulators, and gas relief equipment. Minimum distance between unit and other electrically live parts is 48-in. (1220 mm).

Flue gas can deteriorate building materials. Orient unit such that flue gas will not affect building materials. Locate mechanical draft system flue assembly at least 48-in. (1220 mm) from an adjacent building or combustible material.


After unit is in position, remove rigging skids and shipping materials.

## Step 7 — Horizontal Duct Connection

Depending on the unit size, see either Fig. 3 and 4 (size 14), Fig. 8 and 9 (size 20), or Fig. 13 and 14 (sizes 24 and 26) for locations and sizes of the horizontal duct connections. Note that there are two different return air duct connection locations – one for non-VAV units without an economizer (on back side of unit) and a different one for LC\*B VAV units with the integrated economizer (on left end, under the economizer hood). The supply air duct connection is on the back side. See Fig. 23 for top view depicting typical horizontal duct arrangements.

Field-supplied (3/4-in.) flanges should be attached to horizontal duct openings (see Fig. 23) and all ductwork should be secured to the flanges. Insulate and weatherproof all external ductwork, joints, and roof or building openings with counter flashing and mastic in accordance with applicable codes.

NOTE: 48LC size 17 to 26 units are factory assembled as either dedicated horizontal or vertical units. These units cannot be field converted.



|                    | SUPPLY                               | NON-VAV<br>UNIT RETURN                | LC*B-VAV<br>UNIT RETURN               |
|--------------------|--------------------------------------|---------------------------------------|---------------------------------------|
| Location           | Back                                 | Back                                  | Left end                              |
| Height<br>In. (mm) | 15 <sup>7</sup> / <sub>8</sub> (402) | 49 <sup>3</sup> / <sub>8</sub> (1253) | 18 <sup>3</sup> / <sub>8</sub> (467)  |
| Width<br>in. (mm)  | 29 <sup>3</sup> / <sub>4</sub> (756) | 23 <sup>3</sup> / <sub>8</sub> (593)  | 61 <sup>5</sup> / <sub>8</sub> (1564) |


Fig. 23 — Horizontal Duct Opening Dimensions

## Step 8 — VAV Duct Pressure Transducer and Field Tubing Installation

Before a VAV rooftop unit can operate correctly, installation of the factory-supplied duct pressure transducer (DPT) and plastic pneumatic tubing (field supplied) is required. The DPT is mounted in the unit control box for shipping purposes and is shown in Fig. 24. Remove the screw holding the DPT and disconnect quick connects from the transducer terminals. For correct pressure sensing, mount the DPT externally to the main trunk duct approximately two-thirds (2/3) of the way from the unit. Install factory-supplied duct pressure tap (located in the installer's packet) at the DPT location by inserting tap perpendicular to duct airflow with the arrow on pressure tap flange matching airflow direction.

Connect 1/4-in. plastic pneumatic tubing (field supplied) to barbed fitting on pressure tap and connect the other end to "High" fitting of pressure transducer. Leave "Low" pressure connection open to the atmosphere. Connect 20 or 22 AWG insulated wire [35°C (95°F) minimum] to DPT "+" and "-" terminals. Route wiring back to rooftop unit along with the low voltage VAV terminal field control wiring. Connect wire from DPT "+" terminal to quick connect on red wire from VAV-RTU Open Board J4 – Terminal 4 and wire from DPT "-" terminal to quick connect on black wire from VAV RTU-Open Board J4-Terminal 5 with 3/16-in. quick connects. Wire nuts may also be used.


Proper installation of these components is required for accurate input to Analog Input 1 (static\_press) on the VAV-RTU Open Control Board. For more information on this, please refer to the 48/50LC\*B07-26 *Controls, Start-Up, Operation, and Troubleshooting* document.



**Fig. 24 — Duct Pressure Transducer**

### Step 9 — Install Outside Air Hood

The outside air hood for the economizer is shipped in knock-down form and requires field assembly. The panel for the hood top is shipped on the end of the unit (see Fig. 25). The remaining parts for the hood assembly (including side panels, filters and tracks) are shipped in a carton that secured to the rear of the blower assembly. Access the carton location through rear panel (see Fig. 26).




**Fig. 25 — Hood Top – Shipping Position**

To remove the hood parts package:

1. Remove the back blower access panel.
2. Locate and cut the strap, being careful to not damage any wiring.
3. Carefully lift the hood package carton through the back blower access opening.


See Fig. 26 for identification of the various parts of the hood assembly.



**Fig. 26 — Hood Package – Shipping Location**


To assemble the outside air hood (see Fig. 27 for hood component locations):

1. Remove hood top panel from shipping position on unit end.
2. Install filters supports (Item #1) to the upper end panel using the screws provided.
3. Install each deflector (Item #8) on to each filter support (Item #1) using the screws provided.
4. Apply seal strip to mating flanges on side plates of hood (Items #4 and #5).
5. Secure side panels (Items #4 and #5) to upper panel using the screws provided.
6. Apply seal strip to mating flange of the hood (see Fig. 27).
7. Secure hood top (Item #3) to upper panel using the screws provided. (On 44-in. chassis, remove the screws from across top cover of unit. The rear flange of hood top will slide behind unit top over flange.)
8. Secure side retainers (Item #6) to side panels (Items #4 and #5) using the screws provided, screwing from outside of the hood.
9. Secure each central retainer (Item #2) to the hood top (Item #3). Then align central retainers to holes located on filter support (Item #1), so central retainer is perpendicular to hood and each filter support. Secure using screws provided.
10. Apply seal strip to top diverters (Item #7).
11. Secure top diverters (Item #7) to hood top (Item #3).
12. Install outdoor air screens by sliding them into each of the four spaces created by the hood, filter support and central retainers. To do so, first insert the air screens into pocket created at the end of hood (Item #3), then fully put the air screen into place, and then slide them back into pocket created in the filter support (Item #1). Repeat this for each air screen (see Fig. 28). See Fig. 29 for completed hood assembly.




| ITEM # | DESCRIPTION      | QTY |
|--------|------------------|-----|
| 1      | Filter Supports  | 3   |
| 2      | Central Retainer | 3   |
| 3      | Hood Top         | 1   |
| 4      | Left Hood Side   | 1   |
| 5      | Right Hood Side  | 1   |
| 6      | Side Retainer    | 2   |
| 7      | Top Diverters    | 2   |
| 8      | Deflector        | 3   |

**Fig. 27 — Hood Part Identification and Seal Strip Application Areas**




**Fig. 28 — Outdoor Air Screen Installation**



**Fig. 29 — Completed Hood Assembly**

## Step 10 — Assemble Barometric Hood


The barometric hood can be assembled in vertical or horizontal configuration. Figure 30 illustrates the barometric hood parts.



**Fig. 30 — Barometric Hood Parts**


### BAROMETRIC HOOD (VERTICAL CONFIGURATION)

1. Remove the hood top panel from its shipping position on the unit end (see Fig. 31).




**Fig. 31 — Shipping Location, Vertical Units**

2. Remove the side panels located in the hood parts box (see Fig. 32).




**Fig. 32 — Barometric Hood Box Parts Location**

3. Install parts as shown in the following exploded view (Fig. 33) using the seal strip and screws provided in the parts box.



**Fig. 33 — Barometric Hood Exploded View**


Figure 34 illustrates the installed barometric hood parts.



**Fig. 34 — Installed Barometric Hood Side View and Isometric View**

**BAROMETRIC HOOD (HORIZONTAL CONFIGURATION)**  
For horizontal return and field installed economizer, install the economizer as follows:

1. Install the field provided horizontal ductwork onto the unit. Duct height must be at least 19 1/2 inches high, however the duct can be no taller than the top of the relief opening in the bottom panel, or airflow into the outside air hood will be restricted. See Fig. 35.




**Fig. 35 — Relief Damper**

2. Cut a 16 in. x 36 in. opening in the return duct for the relief damper (see Fig. 35).
3. On the field installed economizer (CRECOMZRO\*\*A00), a birdscreen or hardware cloth is shipped attached to the bottom panel used for vertical applications.


NOTE: This panel is not used for horizontal return applications. Remove the screen from the provided panel and install it over the relief opening cut in return duct.

4. Using the blade brackets, install the relief damper onto the side of the return duct (see Fig. 36). The two brackets and relief damper are provided with the economizer.



**Fig. 36 — Installing CRBARDHOD001A00 Over Relief Damper**

5. Using the provided hardware, screw the CRBARDHOD001A00 hood sides and top together (see Fig. 37).




**Fig. 37 — CRBARDHOD001A00 Hood Sides and Top**

Caulk the backside of the mating flanges to ensure a watertight seal. Install the CRBARDHOD001A00 over the relief damper and screw to the return duct, as illustrated in Fig. 36.

### Step 11 — Economizer - Horizontal Airflow Units

The barometric relief damper ships attached to the exterior return opening panel on the unit (see Fig. 38). Remove shipping cover to access the barometric relief damper, rain angle, and parts bag. These items are to be repositioned on the side of the field supplied ductwork. In addition, the barometric relief hood should be used and can be ordered separately (PN: CRBARDHOD001A00) or can be field supplied.




**Fig. 38 — Barometric Relief Damper (Shipping Location)**

### Step 12 — Install Flue Hood and Combustion Air Hood

The flue hood is shipped screwed to the fan deck inside the burner compartment. Remove the burner access panel and then remove the flue hood from its shipping location. Using the screws provided, install flue hood in the location shown in Fig. 39.

The combustion air hood is attached to the back of the burner access panel. Remove the two screws securing the hood to the back of the burner access panel. Using the two screws, re-attach the hood to the front of the burner access panel as shown in Fig. 39.



**Fig. 39 — Flue Hood and Combustion Air Hood Details**

### Step 13 — Install Gas Piping

Installation of the gas piping must be in accordance with local building codes and with applicable national codes. In U.S.A., refer to NFPA 54/ANSI Z223.1 National Fuel Gas Code (NFGC). In Canada, installation must be in accordance with the CAN/CSA B149.1 and CAN/CSA B149.2 installation codes for gas burning appliances. This unit is factory equipped for use with natural gas (NG) fuel at elevations up to 2000 ft (610 m) above sea level. Unit may be field converted for operation at elevations above 2000 ft (610 m) and/or for use with liquefied petroleum (LP) fuel. See accessory kit installation instructions regarding these accessories.

NOTE: Furnace gas input rate on rating plate is for installation up to 2000 ft (610 m) above sea level. The input rating for altitudes above 2000 ft (610 m) must be derated by 4% for each 1000 ft (305 m) above sea level.


### GAS SUPPLY LINE

The gas supply pipe enters the unit adjacent to the burner access panel on the front side of the unit, through the grommeted hole. The gas connection to the unit is made to the  $\frac{3}{4}$ -in. FPT gas inlet port on the unit gas valve.

Table 3 lists typical  $\frac{3}{4}$ -in. NPT (National Pipe Thread) field supplied pipe fittings required for Thru-Base gas supply, starting from the unit gas valve (see Fig. 40).

Pipe gas supply into 90 degree elbow (item 15 in Table 3) through the hole in the unit basepan.

For typical  $\frac{3}{4}$ -in. NPT field supplied fittings required for NON thru-base gas supply starting from the unit gas valve, omit items 14 and 15 from Table 3 and pipe gas supply into TEE. See Fig. 41.




**Fig. 40 — Gas Supply Line Piping with Thru-Base**

**Table 3 — Typical  $\frac{3}{4}$ -in. NPT Field Supplied Piping Parts**

| ITEM | QTY | DESCRIPTION                        |
|------|-----|------------------------------------|
| 1    | 1   | 90 Deg Street Elbow                |
| 2    | 1   | 5 Inch Long Nipple                 |
| 3    | 1   | Ground-Joint Union                 |
| 4    | 1   | 3 Inch Long Nipple                 |
| 5    | 1   | 90 Deg Elbow                       |
| 6    | 1   | 12 Inch Long Nipple                |
| 7    | 1   | 90 Deg Elbow                       |
| 8    | 1   | 3 Inch Long Nipple                 |
| 9    | 1   | TEE                                |
| 10   | 1   | 4 Inch Long Nipple (Sediment Trap) |
| 11   | 1   | Cap                                |
| 12   | 1   | 3 $\frac{1}{2}$ -in. long nipple   |
| 13   | 1   | NIBCO® Ball Valve (PN: GB30)       |
| 14   | 1   | 8 Inch Long Nipple                 |
| 15   | 1   | 90 Deg Elbow                       |

\* NIBCO is a registered trademark of NIBCO INC.



**Fig. 41 — Gas Supply Line Piping**

For natural gas (NG) applications, gas pressure at unit gas connection must not be less than 5 in. wg (1246 Pa) or greater than 13 in. wg (3240 Pa) while the unit is operating (see Table 4). For liquified petroleum (LP) applications, the gas pressure must not be less than 11 in. wg (2740 Pa) or greater than 13 in. wg (3240 Pa) at the unit connection (see Table 5).

Manifold pressure is factory-adjusted for NG fuel use. Adjust as required to obtain best flame characteristics. See Table 6.

Manifold pressure for LP fuel must be adjusted to specified range (see Table 7). Follow instructions in the accessory kit to make initial readjustment.

**Table 4 — Natural Gas Supply Line Pressure Ranges**

| UNIT   | UNIT SIZE          | MIN                     | MAX                      |
|--------|--------------------|-------------------------|--------------------------|
| 48LC*B | 14, 17, 20, 24, 26 | 5.0 in. wg<br>(1246 Pa) | 13.0 in. wg<br>(3240 Pa) |

**Table 5 — Liquid Propane Supply Line Pressure Ranges**

| UNIT   | UNIT SIZE          | MIN                      | MAX                      |
|--------|--------------------|--------------------------|--------------------------|
| 48LC*B | 14, 17, 20, 24, 26 | 11.0 in. wg<br>(2740 Pa) | 13.0 in. wg<br>(3240 Pa) |

**Table 6 — Natural Gas Manifold Pressure Ranges**

| UNIT   | UNIT SIZE          | HIGH FIRE              | LOW FIRE               |
|--------|--------------------|------------------------|------------------------|
| 48LC*B | 14, 17, 20, 24, 26 | 3.0 in. wg<br>(747 Pa) | 2.0 in. wg<br>(498 Pa) |

**Table 7 — Liquid Propane Manifold Pressure Ranges**

| UNIT   | UNIT SIZE          | HIGH FIRE                | LOW FIRE                |
|--------|--------------------|--------------------------|-------------------------|
| 48LC*B | 14, 17, 20, 24, 26 | 11.0 in. wg<br>(2740 Pa) | 7.3 in. wg<br>(1818 Pa) |
| 48LCSB | 14 only            | 9.8 in. wg<br>(2441 Pa)  | 6.5 in. wg<br>(1619 Pa) |


**CAUTION**

**EQUIPMENT DAMAGE**

Failure to follow this caution may result in equipment damage. When connecting the gas line to the unit gas valve, the installer **MUST** use a backup wrench to prevent damage to the valve.

Install a gas supply line that runs to the unit heating section. Refer to the NFPA 54/NFGC or equivalent code for gas pipe sizing data. Do not use a pipe smaller than the size specified. Size the gas supply line to allow for a maximum pressure drop of 0.5 in. wg (124 Pa) between gas regulator source and unit gas valve connection when unit is operating at high-fire flow rate.

The gas supply line can approach the unit in two ways: horizontally from outside the unit (across the roof), or through unit basepan. Observe clearance to gas line components per Fig. 42.



**Fig. 42 — Gas Piping Guide**

**FACTORY-OPTION THRU-BASE CONNECTIONS**

**Electrical Connections**

Knockouts are located in the control box area. Remove the appropriate size knockout for high voltage connection. Use the field supplied connector depending on wiring or conduit being utilized. Remove the 7/8-in. (22mm) knockout and appropriate connector for low voltage wiring. If non-unit powered convenience outlet is being utilized, remove the 7/8-in. (22mm) knockout and utilize appropriate connector for 115 volt line. See "Step 14 — Making Electrical Connections" for details.

**Gas Connections**

Remove the knockout in the base pan and route 3/4-in. gas line up through the opening. Install an elbow and route gas line through opening in panel after first removing plastic bushing. Install a gas shut off followed by a drip leg and ground-joint union. Route gas line into gas section through the grommet (Part #: KA56SL112) at the gas inlet and into the gas valve. See Fig. 40 and Table 3. If a regulator is installed, it must be located 4 feet (1.22 meters) from the flue outlet.

Some municipal codes require that the manual shutoff valve be located upstream of the sediment trap. See Fig. 41 for typical piping arrangements for gas piping that has been routed through the sidewall of the base pan.

When installing the gas supply line, observe local codes pertaining to gas pipe installations. Refer to the NFPA 54/ANSI Z223.1 NFGC latest edition (in Canada, CAN/CSA B149.1). In the absence of local building codes, adhere to the following pertinent recommendations:

1. Avoid low spots in long runs of pipe. Grade all pipe 1/4-in. in every 15 ft (7 mm in every 5 m) to prevent traps. Grade all horizontal runs downward to risers. Use risers to connect to heating section and to meter.

2. Protect all segments of piping system against physical and thermal damage. Support all piping with appropriate straps, hangers, etc. Use a minimum of one hanger every 6 ft (1.8 m). For pipe sizes larger than 1/2-in., follow recommendations of national codes.
3. Apply joint compound (pipe dope) sparingly and only to male threads of joint when making pipe connections. Use only pipe dope that is resistant to action of liquefied petroleum gases as specified by local and/or national codes. If using PTFE (Teflon<sup>1</sup>) tape, ensure the material is Double Density type and is labeled for use on gas lines. Apply tape per manufacturer's instructions.
4. Pressure-test all gas piping in accordance with local and national plumbing and gas codes before connecting piping to unit.

NOTE: Pressure test the gas supply system after the gas supply piping is connected to the gas valve. The supply piping must be disconnected from the gas valve during the testing of the piping systems when test pressure is in excess of 0.5 psig (3450 Pa). Pressure test the gas supply piping system at pressures equal to or less than 0.5 psig (3450 Pa). The unit heating section must be isolated from the gas piping system by closing the external main manual shutoff valve and slightly opening the ground-joint union.


Check for gas leaks at the field-installed and factory-installed gas lines after all piping connections have been completed. Use soap-and-water solution (or method specified by local codes and/or regulations).

### ⚠ WARNING

Failure to follow this warning could result in personal injury, death and/or property damage.

- Connect gas pipe to unit using a backup wrench to avoid damaging gas controls.
- Never purge a gas line into a combustion chamber.
- Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections.
- Use proper length of pipe to avoid stress on gas control manifold.

NOTE: If orifice hole appears damaged or it is suspected to have been redrilled, check orifice hole with a numbered drill bit of correct size. Never redrill an orifice. A burr-free and squarely aligned orifice hole is essential for proper flame characteristics. See Fig. 43.




**Fig. 43 — Orifice Hole**


The unit has one 3/4-in. condensate drain connection on the end of the condensate pan (see Fig. 44). See Fig. 4, 9, and 14 for the location of the condensate drain connection.

The piping for the condensate drain and external trap can be completed after the unit is in place. Hand tighten fittings to the drain pan fitting. Provide adequate support for the drain line. Failure to do so can result in damage to the drain pan. See Fig. 45.

All units must have an external trap for condensate drainage. Install a trap at least 4-in. (102 mm) deep and protect against freeze-up. If drain line is installed downstream from the external trap, pitch the line away from the unit at 1-in. per 10 ft (25 mm in 3 m) of run. Do not use a pipe size smaller than the unit connection (3/4-in.).



**Fig. 44 — Condensate Drain Pan Connection**



NOTE: Trap should be deep enough to offset maximum unit static difference. A 4-in. (102 mm) trap is recommended.

**Fig. 45 — Condensate Drain Piping Details**

1. Teflon is a registered trademark of DuPont.

## Step 14 — Make Electrical Connections

### ⚠ WARNING

Failure to follow this warning could result in personal injury or death.

Do not use gas piping as an electrical ground.

Unit cabinet must have an uninterrupted, unbroken electrical ground to minimize the possibility of personal injury if an electrical fault should occur. This ground may consist of electrical wire connected to unit ground lug in control compartment, or conduit approved for electrical ground when installed in accordance with NEC (National Electrical Code); ANSI/NFPA 70, latest edition (in Canada, Canadian Electrical Code CSA [Canadian Standards Association] C22.1), and local electrical codes.

NOTE: Field-supplied wiring shall conform with the limitations of minimum 63°F (33°C) rise.

### FIELD POWER SUPPLY

If equipped with optional powered convenience outlet: the power source leads to the convenience outlet's transformer primary are not factory connected. Installer must connect these leads according to required operation of the convenience outlet. If an always-energized convenience outlet operation is desired, connect the source leads to the line side of the unit-mounted disconnect. (Check with local codes to ensure this method is acceptable in your area.) If a de-energize via unit disconnect switch operation of the convenience outlet is desired, connect the source leads to the load side of the unit disconnect. On a unit without a unit-mounted disconnect or HACR, connect the source leads to the terminal block with unit field power leads. See Fig. 46.




Fig. 46 — Location of TB1

Field power wires are connected to the unit at line-side pressure lugs on the terminal block (see wiring diagram label for control box component arrangement) or at factory-installed option non-fused disconnect switch or HACR breaker. Use copper conductors only. See Fig. 47.

NOTE: Make field power connections directly to line connection pressure lugs only.

### ⚠ WARNING

#### FIRE HAZARD

Failure to follow this warning could result in personal injury, death, or property damage.

Do not connect aluminum wire between disconnect switch and unit. Use only copper wire.




Fig. 47 — Disconnect Switch and Unit

See Fig. 48 and 49 for unit wiring diagrams.





Fig. 48 — 48LC\*B14-26 VAV-RTU Open Control Wiring Diagram



**Fig. 49 — 48LC\*B14-26 Power Wiring Diagram**

## UNITS WITHOUT FACTORY-INSTALLED NON-FUSED DISCONNECT OR HACR

When installing units, provide a disconnect switch per NEC (National Electrical Code) of adequate size. Disconnect sizing data is provided on the unit informative plate. Locate on unit cabinet or within sight of the unit per national or local codes. Do not cover unit informative plate if mounting the disconnect on the unit cabinet.

## UNITS WITH FACTORY-INSTALLED NON-FUSED DISCONNECT OR HACR


The factory-installed option non-fused disconnect switch (NFD) or HACR is located in the main control box. The manual switch handle and shaft are shipped in the control box and must be mounted on the corner post adjacent to the control box (see Fig. 50 or 51). Note that the tape covering the hole for the shaft in the corner post must be removed prior to handle and shaft installation.

### ***To field install the NFD shaft and handle:***


1. Open the control box panel.
2. Make sure the NFD shipped from the factory is at OFF position (the arrow on the black handle knob or on the silver metal collar is at OFF).
3. Insert the shaft with the cross pin on the top of the shaft in the horizontal position.
4. Measure the tip of the shaft to the outside surface of the corner post to be 0.88-in.
5. Tighten the locking screw to secure the shaft to the NFD.
6. Turn the handle to OFF position with red arrow pointing at OFF.
7. Install the handle on to the corner post vertically with the red arrow pointing up.
8. Secure the handle to the corner post with (2) screws and lock washers supplied.

### ***To field install the HACR shaft and handle:***

1. Open the control box panel.
2. Make sure the HACR shipped from the factory is at OFF position (the white arrow pointing at OFF).
3. Insert the shaft with the cross pin on the top of the shaft in the horizontal position.
4. Measure the tip of the shaft to the outside surface of the corner post to be 0.88-in.
5. Tighten the locking screw to secure the shaft to the HACR.
6. Turn the handle to OFF position with red arrow pointing at OFF.
7. Install the handle on to the corner post vertically with the red arrow pointing up.
8. Secure the handle to the corner post with (2) screws and lock washers supplied.



**Fig. 50 — Handle and Shaft Assembly for NFD**




**Fig. 51 — Handle and Shaft Assembly for HACR**

## ALL UNITS


All field wiring must comply with NEC and all local code requirements.

Size wire based on MCA (Minimum Circuit Amps) on the unit informative plate. See Fig. 52 for power wiring connections to the unit power terminal block and equipment ground. Maximum wire size is 2/0 AWG per pole.

### Units Without Disconnect or HACR Option



### Units With Disconnect or HACR Option



**Fig. 52 — Power Wiring Connections**

Provide a ground-fault and short-circuit over-current protection device (fuse or breaker) per NEC Article 440 (or local codes). Refer to unit informative data plate for MOCP (Maximum Over-current Protection) device size.

**NOTE:** Units ordered with factory-installed HACR do not need additional ground-fault and short circuit over current protection device unless required by local codes.

Voltage to compressor terminals during operation must be within voltage range indicated on unit nameplate. On 3-phase units, voltages between phases must be balanced within 2% and the current within 10%. Use the formula shown below to determine the percent of voltage imbalance.


### CAUTION

#### UNIT DAMAGE HAZARD

Failure to follow this caution may result in equipment damage. Operation on improper line voltage or excessive phase imbalance constitutes abuse and may cause damage to electrical components. Such operation would invalidate any applicable Carrier warranty.

$$\% \text{ Voltage Imbalance} = 100 \times \frac{\text{max voltage deviation from average voltage}}{\text{average voltage}}$$

Example: Supply voltage is 230-3-60



$$\text{Average Voltage} = \frac{(224 + 231 + 226)}{3} = \frac{681}{3} = 227$$

Determine maximum deviation from average voltage.

$$(AB) 227-224 = 3 \text{ v}$$

$$(BC) 231-227 = 4 \text{ v}$$

$$(AC) 227-226 = 1 \text{ v}$$

Maximum deviation is 4 v.

Determine percent of voltage imbalance.

$$\% \text{ Voltage Imbalance} = 100 \times \frac{4}{227} = 1.78\%$$

This amount of phase imbalance is satisfactory as it is below the maximum allowable 2%.

**IMPORTANT:** If the supply voltage phase imbalance is more than 2%, contact your local electric utility company immediately.

## CONVENIENCE OUTLETS


### WARNING

#### ELECTRICAL OPERATION HAZARD

Failure to follow this warning could result in personal injury or death.

Units with convenience outlet circuits may use multiple disconnects. Check convenience outlet for power status before opening unit for service. Locate its disconnect switch, if appropriate, and open it. Lock-out and tag-out this switch, if necessary.

Two types of convenience outlets are offered on 48LC\*B models: non-unit powered and unit-powered. Both types provide a 125-v GFCI (ground-fault circuit-interrupter) duplex receptacle rated at 15-A behind a hinged access cover, located on the corner panel of the unit. See Fig. 53.



**Fig. 53 — Convenience Outlet Location**

#### Installing Weatherproof Cover

A weatherproof while-in-use cover for the factory-installed convenience outlets is now required by UL standards. This cover cannot be factory-mounted due to its depth; it must be installed at unit installation. For shipment, the convenience outlet is covered with a blank cover plate.


The weatherproof cover kit is shipped in the unit's control box. The kit includes the hinged cover, a backing plate and gasket.

DISCONNECT ALL POWER TO UNIT AND CONVENIENCE OUTLET. LOCK-OUT AND TAG-OUT ALL POWER.

Remove the blank cover plate at the convenience outlet; discard the blank cover.

Loosen the two screws at the GFCI duplex outlet, until approximately 1/2-in. (13 mm) under screw heads are exposed. Press the gasket over the screw heads. Slip the backing plate over the screw heads at the keyhole slots and align with the gasket; tighten the two screws until snug (do not over-tighten).

Mount the weatherproof cover to the backing plate as shown in Fig. 54. Remove two slot fillers in the bottom of the cover to permit service tool cords to exit the cover. Check for full closing and latching.



#### **Fig. 54 — Weatherproof Cover Installation**

### *Non-unit powered type*

This type requires the field installation of a general-purpose 125-v 15-A circuit powered from a source elsewhere in the building. Observe national and local codes when selecting wire size, fuse or breaker requirements and disconnect switch size and location. Route 125-v power supply conductors into the bottom of the utility box containing the duplex receptacle.

### *Unit-powered type*

A unit-mounted transformer is factory-installed to stepdown the main power supply voltage to the unit to 115-v at the duplex receptacle. This option also includes a manual switch with fuse, located in a control box and mounted on a bracket behind the convenience outlet; access is through the unit's control box access panel. See Fig. 53.


The primary leads to the convenience outlet transformer are not factory-connected. If local codes permit, the transformer primary leads can be connected at the line-side terminals on the unit-mounted non-fused disconnect switch; this will provide service power to the unit when the unit disconnect switch is open. See Fig. 55.

Test the GFCI receptacle by pressing the TEST button on the face of the receptacle to trip and open the receptacle. Check for proper grounding wires and power line phasing if the GFCI receptacle does not trip as required. Press the RESET button to clear the tripped condition.

### **Using unit-mounted convenience outlets**

Units with unit-mounted convenience outlet circuits will often require that two disconnects be opened to de-energize all power to the unit. Treat all units as electrically energized until the convenience outlet power is also checked and de-energization is confirmed. Observe National Electrical Code Article 210, Branch Circuits, for use of convenience outlets.

Figure 56 shows the Convenience Outlet Utilization label which is located below the convenience outlet.



| UNIT VOLTAGE | CONNECT AS | PRIMARY CONNECTIONS                    | TRANSFORMER TERMINALS |
|--------------|------------|--|-----------------------|
| 208, 230     | 240        | L1: RED + YEL<br>L2: BLU + GRA         | H1 + H3<br>H2 + H4    |
| 460          | 480        | L1: RED<br>Splice BLU + YEL<br>L2: GRA | H1<br>H2 + H3<br>H4   |
| 575          | 600        | L1: RED<br>L2: GRA                     | H1<br>H2              |


**Fig. 55 — Powered Convenience Outlet Wiring**



### Fig. 56 — Convenience Outlet Utilization Notice

HACR

The amp rating of the HACR factory installed option is based on the size, voltage, indoor motor and other electrical options of the unit as shipped from the factory. If field installed accessories are added or changed in the field (i.e., power exhaust), the HACR may no longer be of the proper amp rating and therefore will need to be removed from the unit. See unit nameplate and label on factory installed HACR for the amp rating of the HACR that was shipped with the unit from the factory (see Fig. 57). See unit nameplates for the proper fuse, HACR or maximum over-current protection device required on the unit with field installed accessories.



**Fig. 57 — HACR Caution Label**

#### FACTORY-OPTION THRU-BASE CONNECTIONS

All units are equipped with the ability to bring utilities through the base.

Gas is brought up through an embossed area located in the gas section behind the gas entrance post. Access is gained through the gas access panel. A knock out must be removed to accomplish this.

The electrical entrance is located in the control box area and can be accessed through the control box access panel. An embossed area is provided with three knock outs. High voltage is brought through the multi knock out by removing the appropriate size for the size of the fitting required. A  $7/8$ -in. knock out is provided for low voltage. An additional  $7/8$ -in. knock out is provided for a 115 v line which is used when the unit is equipped with the non-unit powered convenience outlet option.

All required fittings are field supplied. Install fittings when access to both top and bottom of the base pan is available. See electrical and gas connections for routing and connection information.


#### UNITS WITHOUT THRU-BASE CONNECTIONS

1. Install liquid tight conduit between disconnect and control box.
2. Pull correctly rated high voltage wires through the conduit.
3. Install power lines to terminal connections as shown in Fig. 52.

#### UNIT WITHOUT THRU-BASE CONNECTION KIT

Correctly rated low voltage wire can be routed through the rubber grommet located on the corner post adjacent to the control box access panel. Route wire through the grommet and then route the wire behind the corner post utilizing the factory provided wire ties secured to the control box. This will ensure separation of the field low voltage wire and the high voltage circuit. Route the low voltage wire to the Integrated Staging Control (ISC) board. See Fig. 58.

NOTE: If utilizing the through the base connections, route the low voltage wire through the wire ties to the Integrated Staging Control (ISC) board (see Fig. 59).



**Fig. 58 — Field Control Wiring Raceway**

#### HEAT ANTICIPATOR SETTINGS

Set heat anticipator settings at 0.14 amp for the first stage and 0.14 amp for second-stage heating.

#### TRANSFORMER CONNECTION FOR 208-V POWER SUPPLY

All units except 208/230-v units are factory wired for the voltage shown on the nameplate. If the 208/230-v unit is to be connected to a 208-v power supply, the control transformer must be rewired by moving the black wire with the  $1/4$ -in. female spade connector from the 230-v connection and moving it to the 208-v  $1/4$ -in. male terminal on the primary side of the transformer. Refer to unit label diagram for additional information.

#### VAV-RTU Open Controller

For details on VAV-RTU Open option, refer to the *48/50LC\*B 7-26 VAV-RTU Open Controller Controls, Start-up, Operation and Troubleshooting* manual.

## Integrated Staging Control (ISC) Board




Fig. 59 — Integrated Staging Control (ISC) Board

Table 8 — Status Code Descriptions for ISC Board LEDs

| ERROR# | ERROR NAME  | LED INDICATION |       |       |       |       |
|--------|---|----------------|-------|-------|-------|-------|
|        |   | LED01          | LED02 | LED03 | LED04 | LED05 |
| 1      | Check Smoke Detector/PMR/AUX  |                |       | RED   |       |       |
| 2      | Check HPS/LPS/COFS  |                | RED   | RED   |       |       |
| 3      | Call for Y3 with no call for Y1. Check Y1 wiring.   |                |       |       |       | RED   |
| 4      | Call for Y3 with no call for Y1/Y2. Check Y1 wiring.  |                |       |       |       | RED   |
| 5      | Call for Y2 with no call for Y1. Check Y1 wiring.   |                |       | RED   |       |       |
| 6      | Call for W2 with no call for W1. Check W1 wiring.   |                | RED   |       |       |       |
| 7      | Call for heat (W1/W2) and cooling (Y1/Y2/Y3). Check VAV-RTU Open wiring.  | RED            | RED   |       |       |       |
| 8      | Call for heat (W1/W2) with no IFM. Check G wiring.  |                |       | RED   |       |       |
| 9      | Call for cooling (Y1/Y2/Y3) with no G. Check G wiring.  | RED            | RED   |       |       |       |
| 10     | Call for heat (W1/W2) and cooling (Y1/Y2/Y3) with no G. Check VAV-RTU Open and G wiring.                              | RED            | RED   |       |       |       |
| 11     | Check ISC Board and the VAV-RTU Open wiring   | RED            |       |       |       |       |
| 12     | Call for Economizer Y1 Feedback (ECON) from economizer with no call for Y1. Check VAV-RTU Open and economizer wiring. | RED            |       |       |       |       |
| 13     | Check ISC Board and the VAV-RTU Open wiring.  | RED            |       |       |       |       |
| 14     | Check ISC Board and the VAV-RTU Open wiring.  |                |       |       |       | RED   |
| 15     | Check ISC Board and the VAV-RTU Open wiring.  |                |       | RED   |       |       |

NOTES:

1. Green LED Blinking at 1HZ indicates normal operation.
2. Solid red LED indicates an error exists, see above LED configuration.

## SEQUENCE OF OPERATION

### General

The Carrier Integrated Staging Control (ISC) is intended for use with the VAV-RTU Open controller. After initial power to the board, a Green LED will blink with a 1 second duty cycle indicating the unit is running properly. In the event of the ISC board failing, the Green LED will be OFF or continuously ON. When the unit is not running properly, the Green LED will blink along with Red LED lights. The Red LED light configuration will indicate the type of error the board has identified. See Fig. 59 for LED locations and Table 8 for a list of status codes.

The ISC board can be remotely shutdown by removing Jumper 4 and wiring to the Remote Shutdown terminal. The Smoke Control Module can shutdown the unit by removing Jumper 3 and wiring to the Smoke Shutdown terminal. The Smoke Alarm terminal on the ISC Board provides a pass-through connection should a smoke alarm signal be connected. The VAV-RTU Open controller provides the signal which is passed through the ISC board to the Smoke Alarm terminal.

The crankcase heater will run at all times except when the compressors are running. An auxiliary power supply (24Vac) available at TB-4 Terminal is provided to power auxiliary equipment. An optional Phase Monitor Relay can be wired to the PMR terminal by removing Jumper 5. An optional Condensate Flow Switch can be wired to the COFS Terminal by removing Jumper 7.

### Static Pressure Control

The supply fan VFD will be controlled using a PID and an analog input from a duct static pressure transducer. The supply fan will modulate its speed to maintain the desired duct static pressure setpoint.

### Field Test/Commissioning

The control will provide BACnet test points to activate specific test modes that can be used to commission the rooftop and the system. Test modes will be available in the Service Test screen on the Property pages and shall also be available on the local Equipment Touch device for standalone commissioning. Tests include: Fan Test, Low Heat Test, High Heat Test, Cooling Test, Power Exhaust Test, and an Economizer Test. When any test is active, the appropriate Linkage mode will be sent to the system's terminals. This will ensure appropriate system operation and airflow during any test mode.

### Ventilation

In the Ventilation/Fan Mode (G), the indoor fan will run at low speed and the damper will operate at minimum position.

### Supply Air Temperature Control

The control will maintain the desired supply air temperature setpoint whenever cooling is required. A user configurable setpoint will be provided (default 53°F [12°C]). The control will use the appropriate method (economizer cooling, mechanical cooling, or a combination of both) to achieve this setpoint whenever the zone temperature is greater than the current cooling setpoint (occupied or unoccupied). If Supply Air Reset is enabled, the reset algorithm will calculate a proportional reset value between the Occupied Cooling setpoint and 1°F above the Occupied Heating setpoint. The amount of reset (reset ratio and maximum reset limit value) is user configurable.

### Minimum Ventilation

The economizer minimum position will be adjusted as required based on the supply fan speed. Two user configurable minimum economizer positions will be provided. The economizer will be positioned at the "Low Fan Econ Min Pos" when the fan is operating at its slowest speed. When the fan is operating at its maximum speed, the economizer will be positioned at the "Vent Dmpr Pos / DCV Min Pos". For any supply fan speed between these two points, the economizer minimum position will be calculated proportionally.

### Demand Controlled Ventilation (DCV)

Whenever the unit is in an occupied mode and "DCV Control" is set to enable, a unique economizer minimum position will be calculated based on the output of the DCV calculation. Two user configurable values are provided; the "DCV Max Ctrl Setpoint" is the differential CO<sub>2</sub> setpoint that is used as the control point and a "DCV Max Vent Damper Pos" provides the ability to limit the maximum amount of outdoor air being introduced into the unit through the economizer by the DCV control. The economizer will be positioned at the greater of any minimum economizer position. Demand Controlled Ventilation can be used in either a differential mode where both the indoor air and outdoor air CO<sub>2</sub> levels are provided to the control or in a single indoor air mode with only the indoor air CO<sub>2</sub> level. In the latter case, the outdoor air CO<sub>2</sub> level is assumed at 400 ppm.

### Mechanical Cooling Cycle

The control will operate three stages of mechanical cooling in order to maintain the desired supply air temperature whenever economizer cooling operation is unavailable but cooling is required. This condition will be determined if the OA has high enthalpy or at a temperature above the Economizer Lockout temperature. The two compressors will be staged in a binary fashion so that three stages of cooling are provided. Mechanical cooling stages will be added as required to meet the desired SA setpoint. The number of stages will depend on the return air conditions and the system load (airflow through the coil). Stages will be added or dropped as required to maintain the setpoint while also maintaining the minimum on time and minimum off time for compressor operation. Anytime the SA falls below the desired SA setpoint, stages will be dropped until only stage 1 is operating. At that point, should the SA fall below 45°F (7°C), the economizer will modulate to increase the amount of outdoor air in order to maintain this minimum SA temperature. Should the economizer reach the maximum OA position and if the SA is still below the minimum SA temperature, the first cooling stage will be disabled and the economizer will return to the minimum position.

### Integrated Cooling Cycle

If economizer cooling operation is insufficient to maintain the desired SA setpoint, mechanical cooling will be activated to supplement the free economizer cooling. This condition will be determined if the OA has low enthalpy but is at a temperature at least 5°F above the desired SA setpoint and below the Economizer Lockout temperature. Mechanical cooling stages will be added as required to meet the desired SA setpoint. The number of stages will depend on the return air conditions and the system load (airflow through the coil). Stages will be added or dropped as required to maintain the setpoint while also maintaining the minimum on time and minimum off time for compressor operation. Anytime the SA falls below the desired SA setpoint, stages will be dropped until only stage 1 is operating. At that point, should the SA fall below the minimum SA temperature, the economizer will modulate to increase the amount of return air in order to maintain this minimum SA temperature. Should the economizer reach the minimum OA position and if the SA is still below the minimum SA temperature, the first cooling stage will be disabled.

### Economizer Cooling Cycle

The control will provide the ability to utilize outdoor air for maintaining the supply air setpoint should the outdoor air be suitable. The economizer control will utilize an OAT temperature check, a RAT temperature check if RAT is available or a SPT temperature check comparison and optionally, an OA enthalpy check to determine if OA conditions are suitable for economizing. Economizer operation, if available, will begin whenever cooling is required. The economizer will modulate the position of the OA damper to maintain the desired calculated economizer setpoint. The economizer will be controlled to meet CEC Title 24 requirements so that it will remain open 100% during integrated cooling and only partially close if required.

### Low Ambient Cooling Operation Down to 45°F (7°C)

In Low Ambient RTU conditions when the temperature is between 55°F (13°C) and 45°F (7°C), the Low Ambient Switch (LAS) will be active and the outdoor-fans will run to the pre-set factory outdoor-fan speed. When the temperature is greater than 65°F (18°C), the Low Ambient Switch will deactivate and the outdoor-fans will run in the standard cooling mode. If the Outdoor Fan Select Switch (see Fig. 60) is in the up position, the outdoor fans will run in the Fan Cycle Speed Mode (FCS) set to 250 rpm. If the Outdoor Fan Select Switch is in the down position, the outdoor fans will run in the Minimum Fan Speed Mode (MIN) set to 160 rpm regardless of the cooling demand.

At temperatures below 45°F (7°C), unit will utilize economizer for SA temperature control.

48LC Size 14 through 26 Units have a SPST normally open Low Ambient Switch wired across the TS and OF terminal and a jumper placed across the PS terminal (see Fig. 61). When the LAS is active, the switch will close making contact to the OF terminal. This is done for units that require all outdoor fans to run at the same pre-set factory low ambient speed.

Table 9 shows the operation of the outdoor fan for each unit.




Fig. 60 — Outdoor Fan Speed Select Switch




Fig. 61 — Schematic of SPST Low Ambient Switch

Table 9 — Low Ambient Temperature Outdoor Fan Control

| 48LC UNIT | NO. OF FANS ON | NO. OF FANS OFF | SWITCH | OUTDOOR FAN SELECT SWITCH | RPM |
|-----------|----------------|-----------------|--------|---------------------------|-----|
| 14        | 3              | 0               | SPST   | Up                        | 250 |
| 17        | 4              | 0               | SPST   | Up                        | 250 |
| 20        | 4              | 0               | SPST   | Up                        | 250 |
| 24        | 6              | 0               | SPST   | Up                        | 250 |
| 26        | 6              | 0               | SPST   | Up                        | 250 |

### Heating

In the Heating Mode (W1 and G), the ISC board sends power to W on the IGC board. The indoor-fan motor will energize and the outdoor-air dampers will open to their minimum position. The ISC board upon seeing W1 and G ON will turn the indoor fan to high speed.

The IGC board starts its gas ignition process. A check is made to ensure that the rollout switch and limit switch are closed. If the check was successful, the induced draft motor is energized, and when its speed is satisfactory, as proven by the “hall effect” sensor, the ignition activation period begins. The burners will ignite within 5 seconds. If the burners do not light, there is a 22 second delay before another 5 second attempt. This sequence is repeated for 15 minutes or until the burners light. If, after the 15 minutes, the burners still have not lit, heating is locked out. To reset the control, break 24VAC power to the VAV-RTU Open.

When gas ignition occurs, the IGC board will continue to monitor the condition of the rollout switch, the limit switches, the “hall effect” sensor, as well as the flame sensor.

When W1 is turned OFF, the IGC board turns off the gas valve. The IGC board has a delay time before it turns IFO=OFF. At this time, the ISC board sees W1=OFF and IFO=ON. The ISC will keep the indoor fan ON high speed. Once the IGC board delay times out, the ISC board will see W1=OFF and IFO=OFF, which then turns the indoor fan OFF.

If the call for W1 lasted less than 1 minute, the heating cycle will not terminate until 1 minute after W1 became active. The indoor fan motor will continue to operate for an additional 45 seconds then stop. If the overtemperature limit opens after the indoor motor is stopped, but within 10 minutes of W1 becoming inactive, on the next cycle the time will be extended by 15 seconds. The maximum delay is 3 minutes. Once modified, the fan OFF delay will not change back to 45 seconds unless power is reset to the control. A LED indicator is provided on the IGC to monitor operation.

When additional heat is required, W2 closes and initiates power to the second stage of the main gas valve. When the zones are satisfied, the gas valve closes, interrupting the flow of gas to the main burners.

### Morning Warm-up

The control will provide a Morning Warm-up cycle the first time if transition from unoccupied to occupied and if the heating is required and the unit goes into heating immediately. Whenever the unit enters the heating mode, before any heat stage is enabled, the control will provide a Linkage mode to the system that will cause the terminals to maintain sufficient airflow. The Linkage mode of Warm-up (2) will be sent to the terminal system to insure sufficient airflow while in the heating mode but also providing a controlled warm-up cycle to prevent overheating of some zones. As a safety measure, should the heating cycle continue and the SAT approach the “Maximum Heating SAT” limit, the Linkage mode sent will change to Pressurization (6) to insure all terminals open to their maximum airflow. The Linkage mode will remain Pressurization until that heating cycle ends. Once the heating demand is met and the heat cycle is completed or if cooling is required, heating will be locked out until the beginning of the next occupied period.

### Occupied Heating

Optionally, the user may enable occupied heating which will allow heating whenever heating is needed during the occupied period. The cycle will operate exactly the same as Morning Warm-up above, except it will not be limited by the transition into an occupied period.

## Variable Air Volume (VAV) with Variable Frequency Drive

The Variable Air Volume (VAV) system utilizes a Variable Frequency Drive (VFD) to modulate supply fan speed using a PID and an analog input from a duct static pressure sensor. The supply fan will adjust to meet the configured static set point regardless of cooling stage. In heating mode, the latest VAV Open air terminals offer a minimum airflow setting. This shall be configured to maintain the required airflow (CFM) whenever the RTU is in a heating mode per the unit's specification. The Open VAV terminals will recognize the Heating or Warm-up modes as a heat mode and utilize the higher airflow minimum setpoint as configured. The system will further monitor the SAT of the RTU to determine if the SAT is approaching the configured maximum limit. As the limit is approached, the Linkage mode is changed to Linkage Pressurization to ensure all terminals open to their maximum supply airflow. See Fig. 62 and 63.





Fig. 62 — Variable Frequency Drive (VFD)




575V ONLY

Fig. 63 — VFD Location

MULTI-SPEED VFD DISPLAY KIT (FIELD-INSTALLED OPTION)

NOTE: The Remote VFD Keypad is part of the Multi-Speed VFD display kit (PN: CRDISKIT002A00) which is a field-installed option. It is not included with the 48LC\*B14-26 base units.




**Fig. 64 — VFD Keypad**

The VFD keypad as shown in Fig. 64 consists of the following sections.

#### Alpha Numeric Display

The LCD display is back lit with 2 alpha-numeric lines. All data is displayed on the LCD. See Fig. 65.



|   |   |
|---|---|
| 1 | Parameter number and name.  |
| 2 | Parameter value.  |
| 3 | Setup number shows the active setup and the edit setup. If the same set-up acts as both the active and edit set-up, only that setup number is shown (factory setting). When the active and edit setup differ, both numbers are shown in the display (SETUP 12). The flashing number indicates the edit setup. |
| 4 | The symbol in the number 4 position in the figure above indicates motor direction. The arrow point either clockwise or counter-clockwise to show the motor's current direction.   |
| 5 | The position of the triangle indicates the currently selected menu: Status, Quick Menu or Main Menu.  |


**Fig. 65 — Alphanumeric Display**

#### Menu Key

Use the Menu key to select between Status, Quick Menu or Main Menu. The triangle icon at the bottom of the LCD display indicates the currently selected mode. (See number 5 in Fig. 65.)

#### Navigation Keys and Status LEDs

The Navigation keys and Status LEDs are detailed in Fig. 66.




|   |  |
|---|--|
| 1 | Com. LED: Flashes when bus communications is communicating.  |
| 2 | Green LED/On: Control selection is working.  |
| 3 | Yellow LED/Warn.: Indicates a warning.   |
| 4 | Flashing Red LED/Alarm: Indicates an alarm.  |
| 5 | Arrows $\blacktriangle$ $\blacktriangledown$ : Use the Up and Down arrow keys to navigate between parameter groups, parameters and within parameters. Also used for setting local reference. |
| 6 | Back key: Press to move to the previous step or layer in the navigation structure.   |
| 7 | OK key: Press to select the currently displayed parameter and for accepting changes to parameter settings.   |

**Fig. 66 — Navigation Keys and Status LEDs**

#### Operation Keys and LEDs

Figure 67 details the functions of the Operating keys. An illuminated yellow LED above the key indicates the active key.



|   |  |
|---|--|
| 1 | Hand On key: Starts the motor and enables control of the variable frequency drive (VFD) via the VFD Keypad option. NOTE: Please note that terminal 27 Digital Input (5-12 Terminal 27 Digital Input) has coast inverse as default setting. This means that the Hand On key will not start the motor if there is no 24V to terminal 27, so be sure to connect terminal 12 to terminal 27. |
| 2 | Off/Reset key: Stops the motor (off). If in alarm mode, the alarm will be reset.   |
| 3 | Auto On key: The variable frequency drive is controlled either via control terminals or serial communication.  |


**Fig. 67 — Operation Keys and LEDs**

#### CONNECTING THE KEYPAD TO THE VFD


The VFD keypad can be mounted directly to the variable frequency drive, provided you can easily access the front panel of the VFD. If you don't have easy access to the VFD front panel, use the cable included with the kit to connect the keypad to the VFD.

#### Connecting the Keypad Directly to the VFD

1. Place the bottom of the VFD keypad into the variable frequency drive as shown in Fig. 68.
2. Push the top of the VFD keypad into the variable frequency drive as shown in Fig. 69.



**Fig. 68 — Align Bottom of VFD Keypad with Opening in VFD Front Panel**




**Fig. 69 — Secure Keypad in Place**

#### **Using the Cable to Connect the Keypad to the VFD**

The VFD keypad can be connected to the variable frequency drive via the cable included with the Multi-Speed VFD display kit (PN: CRDISKIT002A00). See Fig. 70.

1. Connect the male end of the cable to the front panel of the variable frequency drive. Use 2 of the screws included with the kit to secure the cable to the VFD.
2. Connect the female end of the cable to the back panel of the VFD Remote keypad. Secure the cable to the remote keypad using the 2 remaining screws from the kit.



**Fig. 70 — VFD Remote Keypad Cable**

#### **PROGRAM THE VFD FOR INDOOR FAN CONTROL**

**IMPORTANT:** 48LC\*B14-26 units are programmed at the factory for variable indoor fan speeds. The following procedure is only to be used to recover this function after an event such as a system crash.


**NOTE:** This procedure requires use of the VFD Keypad which is included as part of the field-installed Multi-Speed VFD display kit (PN: CRDISKIT002A00). If the VFD keypad is not already installed, install it. See “Connecting the Keypad to the VFD” for details.

##### ***To program the VFD for variable indoor fan motor speeds:***

1. At Power-Up:

At the first power up the LCD displays the Select Language screen. The default setting is English (see Fig. 71). To change the language, press the OK key and use the **▲** and **▼** keys to scroll to the desired language and then press OK.

**NOTE:** If English is not the desired language, press OK, select the desired language and press OK again.



**Fig. 71 — Keypad with Power Up Screen Displayed**

2. Selecting Regional Settings:

- Press the **Off Reset** key.
- Press the **Menu** key to move the **▼** (triangle icon) so it is positioned over Main Menu. The display shows the following.

|                          |
|--------------------------|
| 0—** Operation / Display |
| 1—** Load and Motor      |

- Press the **OK** key and the display changes to:

|                        |
|------------------------|
| 0—0* Basic Settings    |
| 0—1* Set-up Operations |

NOTE: Press the **Back** key to return to the previous display.

- With the top row highlighted, press **OK**. The display changes to:

|               |
|---------------|
| 0—01 Language |
| [0] English   |

- Press **▼** (Down Arrow key) once; the display changes to:

|                        |
|------------------------|
| 0—03 Regional Settings |
| [0] International      |

- Press **OK**; the [0] is now highlighted.
- Press **▼** (Down Arrow key) once; the display changes to:

|                        |
|------------------------|
| 0—03 Regional Settings |
| [1] North America      |

- Press **OK**

NOTE: If the Alarm 060 appears, follow Step 3 to clear the alarm. Make sure to press **Off Reset** when done. If there is no alarm, continue at Step 4.

3. Clearing Alarm 060: External Interlock:

- Press the **Menu** key twice to position the **▼** (triangle icon) over Main Menu; the display changes to:

|                          |
|--------------------------|
| 0—** Operation / Display |
| 1—** Load and Motor      |

- Press the **▼** (Down Arrow) key until the following display appears:

|                        |
|------------------------|
| 4—** Limits / Warnings |
| 5—** Digital In/Out    |

- Press **OK**. The display changes to:

|                       |
|-----------------------|
| 5—0* Digital I/O Mode |
| 5—1* Digital Inputs   |

- Press **▼** (Down Arrow) once to highlight the bottom row and press **OK**. The display changes to:

|                                |
|--------------------------------|
| 5—10 Terminal 18 Digital In... |
| [8] Start                      |

- Press **▼** (Down Arrow) twice; the following display appears:

|                                |
|--------------------------------|
| 5—12 Terminal 27 Digital In... |
| [7] External Interlock         |

- Press **OK** to highlight the number in the bracket.

- Press **▼** (Down Arrow) until the following display appears:

|                                |
|--------------------------------|
| 5—12 Terminal 27 Digital In... |
| [0] No operation               |

- Press **OK**.

- Press **Off Reset**. The Alarm indicator disappears.

4. Entering Grid Type:

- Press the **Menu** key to move the **▼** (triangle icon) so it is positioned over Main Menu. The display shows the following:

|                        |
|------------------------|
| 0—0* Basic Settings    |
| 0—1* Set-up Operations |

- Press **OK** twice; the display changes to:

|               |
|---------------|
| 0—01 Language |
| [0] English   |

- Press **▼** (Down Arrow) three times to reach the following display:

|                     |
|---------------------|
| 0—06 Grid Type      |
| [102] 200-240V/60Hz |

- Press **OK** to highlight the number in the bracket and then use the **▲** and **▼** (Up and Down Arrow) keys to select the desired voltage and Hertz for the unit.

- Press **OK** to accept the selection and continue.

5. Entering Motor Data:

- Press the **Menu** key to move the **▼** (triangle icon) so it is positioned over Main Menu. The display shows the following:

|                          |
|--------------------------|
| 0—** Operation / Display |
| 1—** Load and Motor      |

- Press **▼** (Down Arrow) once to highlight the bottom row.

- Press **OK**, the display changes to:

|                       |
|-----------------------|
| 1—0* General Settings |
| 1—1* Motor Selection  |

- Press **▼** (Down Arrow) twice to reach the following display:

|                      |
|----------------------|
| 1—1* Motor Selection |
| 1—2* Motor Data      |

- Press **OK**; the following display appears:

|                  |
|------------------|
| 1-20 Motor Power |
| [9] 1.5kW - 2 hp |

NOTE: The number in the bracket may be different from what is shown above.

- f. Press **OK** and then use the **▲** and **▼** (Up and Down Arrow) keys to scroll to the proper motor horsepower. Press **OK** again to set the selected hp.
- g. Press **▼** (Down Arrow) once, the following display appears:

|                            |
|----------------------------|
| 1-22 Motor Voltage<br>230V |
|----------------------------|

- h. Press **OK** to highlight the voltage value. Use the **▲** and **▼** (Up and Down Arrow) keys to select the nameplate voltage. Press **OK** again to set the selected voltage.
- i. Press **▼** (Down Arrow) once to display the following:

|                              |
|------------------------------|
| 1-23 Motor Frequency<br>60Hz |
|------------------------------|

- j. Press **OK** to highlight the Frequency value and then use the **▲** and **▼** (Up and Down Arrow) keys to select the nameplate Hz. Press **OK** again to set the selected Hz.
- k. Press **▼** (Down Arrow) once to display the following:

|                             |
|-----------------------------|
| 1-24 Motor Current<br>6.61A |
|-----------------------------|

- l. Press **OK** to highlight the Current value and then use the **▲** and **▼** (Up and Down Arrow) keys to select the Max Amps value provided. Press **OK** again to set the selected Max Amps.

NOTE: The Max Amps is greater than the nameplate value. Check the VFD Unit Parameters (see Tables 10-14 on pages 48-53) and use the value listed for the given unit in the column labeled "Motor Current Must-Hold Amps".

- m. Press **▼** (Down Arrow) once to display the following

|                                      |
|--------------------------------------|
| 1-25 Motor Nominal Speed<br>1740 rpm |
|--------------------------------------|

- n. Press **OK** to highlight the rpm value and then use the **▲** and **▼** (Up and Down Arrow) keys to select the nameplate rpm. Press **OK** again to set the selected rpm.
- 6. Entering Parameters for 1-71, 1-73, 1-82, and 1-90:
  - a. Press the **Menu** key to move the **▼** (triangle icon) so it is positioned over Main Menu. The display shows the following:

|                          |
|--------------------------|
| 0—** Operation / Display |
|--------------------------|

|                     |
|---------------------|
| 1—** Load and Motor |
|---------------------|

- b. Press **▼** (Down Arrow) once to highlight the bottom row.
- c. Press **OK**, the display changes to:

|                       |
|-----------------------|
| 1—0* General Settings |
|-----------------------|

|                      |
|----------------------|
| 1—1* Motor Selection |
|----------------------|

- d. Press **▼** (Down Arrow) until the following display appears:

|                          |
|--------------------------|
| 1—6* Load Depen. Setting |
|--------------------------|

|                        |
|------------------------|
| 1—7* Start Adjustments |
|------------------------|

- e. Press **OK**, the following display appears:

|                          |
|--------------------------|
| 1-71 Start Delay<br>2.0s |
|--------------------------|

- f. Press **OK** to highlight the number and then use the **▲** and **▼** (Up and Down Arrow) keys to select the number provided in Tables 10-14. Press **OK** again to set the selected value.

- g. Press **▼** (Down Arrow) twice, the following display appears:

|                                  |
|----------------------------------|
| 1-73 Flying Start<br>[1] Enabled |
|----------------------------------|

- h. Press **OK** to highlight the number in the bracket and then use the **▲** and **▼** (Up and Down Arrow) keys to select the number provided in Tables 10-14. Press **OK** again to set the selected value.
- i. Press the **Back** key once, the following display appears:

|                          |
|--------------------------|
| 1—6* Load Depen. Setting |
|--------------------------|

|                        |
|------------------------|
| 1—7* Start Adjustments |
|------------------------|

- j. Press **▼** (Down Arrow) once, the following display appears:

|                        |
|------------------------|
| 1—7* Start Adjustments |
|------------------------|

|                       |
|-----------------------|
| 1—8* Stop Adjustments |
|-----------------------|

- k. Press **OK**, the following display appears:

|                                    |
|------------------------------------|
| 1-80 Function at Stop<br>[0] Coast |
|------------------------------------|

- l. Press **▼** (Down Arrow) once, the following display appears:

|   |
|---|
| 1-82 Min Speed for Functio...<br>1.0 Hz |
|---|

- m. Press **OK** to highlight the number and then use the **▲** and **▼** (Up and Down Arrow) keys to select the number provided in Tables 10-14. Press **OK** again to set the selected value.
- n. Press the **Back** key once, the following display appears:

|                        |
|------------------------|
| 1—7* Start Adjustments |
|------------------------|

|                       |
|-----------------------|
| 1—8* Stop Adjustments |
|-----------------------|

- o. Press **▼** (Down Arrow) once, the following display appears:

|                       |
|-----------------------|
| 1—8* Stop Adjustments |
|-----------------------|

|                        |
|------------------------|
| 1—9* Motor Temperature |
|------------------------|

- p. Press **OK**, the following display appears:

|   |
|---|
| 1-90 Motor Thermal Prote...<br>[4] ETR trip 1 |
|---|

- q. Press **OK** to highlight the number in the bracket then use the **▲** and **▼** (Up and Down Arrow) keys to select the number provided in Tables 10-14. Press **OK** again to set the selected value.

## 7. Setting References:

- a. Press the **Menu** key to move the **▼** (triangle icon) so it is positioned over Main Menu. The display shows the following:

|                          |
|--------------------------|
| 0—** Operation / Display |
|--------------------------|

|                     |
|---------------------|
| 1—** Load and Motor |
|---------------------|

- b. Press **▼** (Down Arrow) three times, the following display appears:

|             |
|-------------|
| 2—** Brakes |
|-------------|

|                        |
|------------------------|
| 3—** Reference / Ramps |
|------------------------|

c. Press **OK**, the following display appears:

|                       |
|-----------------------|
| 3-0* Reference Limits |
| 3-1* References       |

d. Press **OK** again, the following display appears:

|                        |
|------------------------|
| 3-02 Minimum Reference |
| 0.000                  |

NOTE: If the bottom row displays a number other than 0.000, press **OK** and use the **▲** and **▼** (Up and Down Arrow) key to select 0.000.

e. Press **▼** (Down Arrow) once, the following display appears:

|                        |
|------------------------|
| 3-03 Maximum Reference |
| 60.000                 |

NOTE: If the bottom row displays a number other than 60.000, press **OK** and use the **▲** and **▼** (Up and Down Arrow) key to select 60.000.

f. Press the **Back** key until the following display appears:

|                       |
|-----------------------|
| 3-0* Reference Limits |
| 3-1* References       |

g. Press **▼** (Down Arrow) once to move the highlight to the bottom row and then press **OK**. The following display appears:

|                       |
|-----------------------|
| 3-10 Preset Reference |
| [0]0.00%              |

h. Press **OK** once to highlight the number in the bracket. Press **OK** again; the highlight moves to the current percent value. Use the **▲** and **▼** (Up and Down Arrow) keys and the table below to enter the required Preset Reference values.

|           |  |
|-----------|--|
| [0]0.00%  | Stop   |
| [1]LL.LL% | Low Speed (see Tables 10-14, column labeled "Preset References 3-10[1]" for the proper % for each unit)    |
| [2]MM.MM% | Medium Speed (see Tables 10-14, column labeled "Preset References 3-10[2]" for the proper % for each unit) |
| [3]100%   | Override (High Speed)  |
| [4]100%   | High Speed (100% or close to 100% to achieve the required CFM at high speed)                               |
| [5]0.00%  | Stop   |
| [6]0.00%  | Stop   |
| [7]0.00%  | Stop   |

8. Setting the Ramp Time:

a. Press the **Back** key until the following display appears:

|                       |
|-----------------------|
| 3-0* Reference Limits |
| 3-1* References       |

b. Press **▼** (Down Arrow) twice, the following display appears:

|                 |
|-----------------|
| 3-1* References |
| 3-4* Ramp 1     |

c. Press **OK**, the following display appears:

|                          |
|--------------------------|
| 3-41 Ramp 1 Ramp up Time |
| 3.00s                    |

d. Press **OK** again to highlight the bottom row and use the **▲** and **▼** (Up and Down Arrow) keys to select 10.00s. Press **OK** again to set the selected Ramp up Time.

e. Press **▼** (Down Arrow) once, the following display appears:

|                            |
|----------------------------|
| 3-42 Ramp 1 Ramp Down Time |
| 3.00s                      |

f. Press **OK** again to highlight the bottom row and use the **▲** and **▼** (Up and Down Arrow) keys to select 10.00s. Press **OK** again to set the selected Ramp Down Time.

9. Setting Limits:

a. Press the **Back** key until the following display appears:

|                        |
|------------------------|
| 2—** Brakes            |
| 3—** Reference / Ramps |

b. Press **▼** (Down Arrow) once, the following display appears:

|                        |
|------------------------|
| 3—** Reference / Ramps |
| 4—** Limits / Warnings |

c. Press **OK**, the following display appears:

|                     |
|---------------------|
| 4—1* Motor Limits   |
| 4—4* Adj. Warning 2 |

d. Press **OK** again, the following display appears:

|                            |
|----------------------------|
| 4-10 Motor Speed Direction |
| [2] Both Directions        |

e. Press **▼** (Down Arrow) once, the following display appears:

|                              |
|------------------------------|
| 4-12 Motor Speed Low Limi... |
| 0.0Hz                        |

f. Press **▼** (Down Arrow) again, the following display appears:

|                               |
|-------------------------------|
| 4-14 Motor Speed High Limi... |
| 65.0Hz                        |

NOTE: Press **OK** to highlight the Hz value and then use the **▲** and **▼** (Up and Down Arrow) keys to enter the required values.

g. Press **▼** (Down Arrow) once, the following display appears:

|                    |
|--------------------|
| 4-18 Current Limit |
| 110%               |

NOTE: Press **OK** to highlight the % value and then use the **▲** and **▼** (Up and Down Arrow) keys to enter the required value. See Tables 10-14 for proper selection of the value for this parameter, then press **OK** to set the selected value.

h. Press **▼** (Down Arrow) once, the following display appears:

|                           |
|---------------------------|
| 4-19 Max Output Frequency |
| 65.0Hz                    |

NOTE: Press **OK** to highlight the Hz value and then use the **▲** and **▼** (Up and Down Arrow) keys to enter the required values.

10. Setting Digital Inputs:

a. Press the **Back** key until the following display appears:

|                        |
|------------------------|
| 3—** Reference / Ramps |
| 4—** Limits / Warnings |

b. Press **▼** (Down Arrow) once, the following display appears:

|                        |
|------------------------|
| 4—** Limits / Warnings |
| 5—** Digital In/Out    |

c. Press **OK**, the following display appears:

|                       |
|-----------------------|
| 5—0* Digital I/O mode |
| 5—1* Digital Inputs   |

d. Press **▼** (Down Arrow) once to move the highlight to the bottom row and then press **OK**. The following display appears:

|                                |
|--------------------------------|
| 5-10 Terminal 18 Digital In... |
| [8] Start                      |

e. Press **▼** (Down Arrow) again. The following display appears:

|                                |
|--------------------------------|
| 5-11 Terminal 19 Digital In... |
| [16] Preset ref bit 0          |

f. Press **▼** (Down Arrow) again. The following display appears:

|                                |
|--------------------------------|
| 5-12 Terminal 27 Digital In... |
| [17] Preset ref bit 1          |

g. Press **▼** (Down Arrow) again. The following display appears:

|                                |
|--------------------------------|
| 5-13 Terminal 29 Digital In... |
| [18] Preset ref bit 2          |

NOTE: By pressing **OK**, the number in the bracket can be changed until the desired number appears. Press **OK** again to set the selected value.

#### 11. Setting Analog Inputs:

a. Press the **Back** key until the following display appears:

|                        |
|------------------------|
| 4—** Limits / Warnings |
| 5—** Digital In/Out    |

b. Press **▼** (Down Arrow) until the following display appears:

|                     |
|---------------------|
| 5—** Digital In/Out |
| 6—** Analog In/Out  |

c. Press **OK**, the following display appears:

|                      |
|----------------------|
| 6—** Analog In/Out   |
| 6—1* Analog Input 53 |

d. Press **▼** (Down Arrow) once to move the highlight to the bottom row and then press **OK**. The following display appears:

|                              |
|------------------------------|
| 6-10 Terminal 53 Low Voltage |
| 2V                           |

e. Press **▼** (Down Arrow) once to move the highlight to the bottom row and then press **OK**. The following display appears:

|                               |
|-------------------------------|
| 6-11 Terminal 53 High Voltage |
| [10V]                         |

f. Press **▼** (Down Arrow) once to move the highlight to the bottom row and then press **OK**. The following display appears:

|                        |
|------------------------|
| 6-14 Set Min Reference |
| [0 Hz]                 |

g. Press **▼** (Down Arrow) once to move the highlight to the bottom row and then press **OK**. The following display appears:

|                        |
|------------------------|
| 6-15 Set Max Reference |
| [60 Hz]                |

12. Setting Reset Mode and RFI Filter:

a. Press the **Back** key until the following display appears:

|                          |
|--------------------------|
| 0—** Operation / Display |
| 1—** Load and Motor      |

b. Press **▼** (Down Arrow) until the following display appears:

|                         |
|-------------------------|
| 13—** Smart Logic       |
| 14—** Special Functions |

c. Press **OK**, the following display appears:

|                          |
|--------------------------|
| 14—0* Inverter Switching |
| 14—1* Mains On/Off       |

d. Press **▼** (Down Arrow) twice. The following display appears:

|                       |
|-----------------------|
| 14—1* Mains On/Off    |
| 14—2* Reset Functions |

e. Press **OK**, the following display appears:

|                  |
|------------------|
| 14-20 Reset Mode |
| [0] Manual reset |

f. Press **OK** to highlight the number in the bracket.

g. Use the **▲** and **▼** (Up and Down Arrow) keys to change the number to 3 for 3 automatic resets and then press **OK**. The display changes to:

|                         |
|-------------------------|
| 14-20 Reset Mode        |
| [3] Automatic reset x 3 |

h. Press **▼** (Down Arrow) once, the following display appears:

|                              |
|------------------------------|
| 14-21 Automatic Restart T... |
| 10s                          |

i. Press **OK** to highlight the number of seconds and use the **▲** and **▼** (Up and Down Arrow) keys to select 600 seconds. Press **OK** again to set the selected value.

j. Press the **Back** key once, the following display appears:

|                       |
|-----------------------|
| 14—1* Mains On/Off    |
| 14—2* Reset Functions |

k. Press **▼** (Down Arrow) twice, the following display appears:

|                         |
|-------------------------|
| 14—4* Energy Optimising |
| 14—5* Environment       |

l. Press **OK**, the following display appears:

|                  |
|------------------|
| 14-50 RFI Filter |
| [1] On           |

m. Press **OK** to highlight the number in the bracket and use the **▲** and **▼** (Up and Down Arrow) keys to select [0]. Press **OK** again to set the selected value.

13. To complete reprogramming, press the **Auto On** key before disconnecting the VFD Remote Keypad from the variable frequency drive.

**Table 10 — VFD Unit Parameters – 48LC\*B Size 14**

|              |         |           |                 |             | REGIONAL SETTINGS | GRID TYPE | MOTOR POWER | MOTOR VOLTAGE | MOTOR FREQUENCY (Hz) | MOTOR CURRENT (MUST-HOLD AMPS) | MOTOR NOMINAL SPEED (RPM) |
|--------------|---------|-----------|-----------------|-------------|-------------------|-----------|-------------|---------------|----------------------|--------------------------------|---------------------------|
| Motor Option | Voltage | Motor P/N | VFD Carrier P/N | VFD Mfr P/N | 0-03              | 0-06      | 1-20        | 1-22          | 1-23                 | 1-24                           | 1-25                      |
| STD          | 208/230 | HD58FE654 | HK30WA371       | 131L9796    | [1]               | [102]     | [10]        | 230           | 60                   | 9.2                            | 1735                      |
|              | 460     | HD58FE654 | HK30WA377       | 131L9864    | [1]               | [122]     | [10]        | 460           | 60                   | 4.2                            | 1735                      |
|              | 575     | HD58FE577 | HK30WA383       | 131N0227    | [1]               | [132]     | [11]        | 575           | 60                   | 4.9                            | 1710                      |
| MID          | 208/230 | HD60FK658 | HK30WA372       | 131L9797    | [1]               | [102]     | [13]        | 230           | 60                   | 13.6                           | 1745                      |
|              | 460     | HD60FK658 | HK30WA379       | 131L9866    | [1]               | [122]     | [13]        | 460           | 60                   | 6.8                            | 1745                      |
|              | 575     | HD60FE576 | HK30WA387       | 134F0217    | [1]               | [132]     | [13]        | 575           | 60                   | 6.0                            | 1745                      |
| HIGH         | 208/230 | HD60FK657 | HK30WA373       | 131L9798    | [1]               | [102]     | [14]        | 230           | 60                   | 21.2                           | 1760                      |
|              | 460     | HD60FK657 | HK30WA380       | 131L9867    | [1]               | [122]     | [14]        | 460           | 60                   | 9.7                            | 1760                      |
|              | 575     | HD60FL576 | HK30WA384       | 131N0229    | [1]               | [132]     | [14]        | 575           | 60                   | 7.2                            | 1745                      |
| ULTRA        | 208/230 | HD62FK654 | HK30WA374       | 131L9799    | [1]               | [102]     | [15]        | 230           | 60                   | 28.0                           | 1760                      |
|              | 460     | HD62FK654 | HK30WA381       | 131L9868    | [1]               | [122]     | [15]        | 460           | 60                   | 13.7                           | 1760                      |
|              | 575     | HD62FL576 | HK30WA384       | 131N0229    | [1]               | [132]     | [15]        | 575           | 60                   | 8.9                            | 1750                      |

|              |         | START DELAY (sec) | FLYING START | MIN SPEED FOR FUNCTION (Hz) | MOTOR THERMAL PROTECTION | PRESET REFERENCE |          |          |          |          |          |          |          |
|--------------|---------|-------------------|--------------|-----------------------------|--------------------------|------------------|----------|----------|----------|----------|----------|----------|----------|
| Motor Option | Voltage | 1-71              | 1-73         | 1-82                        | 1-90                     | 3-10 [0]         | 3-10 [1] | 3-10 [2] | 3-10 [3] | 3-10 [4] | 3-10 [5] | 3-10 [6] | 3-10 [7] |
| STD          | 208/230 | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 53.43%   | 79.57%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 460     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 53.43%   | 79.57%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 575     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 53.43%   | 79.57%   | 100%     | 100%     | 0%       | 0%       | 0%       |
| MID          | 208/230 | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 53.43%   | 79.57%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 460     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 53.43%   | 79.57%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 575     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 53.43%   | 79.57%   | 100%     | 100%     | 0%       | 0%       | 0%       |
| HIGH         | 208/230 | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 53.43%   | 79.57%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 460     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 53.43%   | 79.57%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 575     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 53.43%   | 79.57%   | 100%     | 100%     | 0%       | 0%       | 0%       |
| ULTRA        | 208/230 | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 53.43%   | 79.57%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 460     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 53.43%   | 79.57%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 575     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 53.43%   | 79.57%   | 100%     | 100%     | 0%       | 0%       | 0%       |

|              |         | RAMP UP TIME (sec) | RAMP DOWN TIME (sec) | CURRENT LIMIT | TERMINAL 18 DIGITAL INPUT | TERMINAL 19 DIGITAL INPUT | TERMINAL 27 DIGITAL INPUT | TERMINAL 29 DIGITAL INPUT |
|--------------|---------|--------------------|----------------------|---------------|---------------------------|---------------------------|---------------------------|---------------------------|
| Motor Option | Voltage | 3-41               | 3-42                 | 4-18          | 5-10                      | 5-11                      | 5-12                      | 5-13                      |
| STD          | 208/230 | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 460     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 575     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
| MID          | 208/230 | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 460     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 575     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
| HIGH         | 208/230 | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 460     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 575     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
| ULTRA        | 208/230 | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 460     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 575     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |

**Table 10 — VFD Unit Parameters – 48LC\*B Size 14 (cont)**

|                 |         | TERMINAL 53<br>LOW VOLTAGE | TERMINAL 53<br>HIGH VOLTAGE | TERMINAL 53<br>LOW REFERENCE | TERMINAL 53<br>HIGH REFERENCE | RESET<br>MODE | AUTO. RESTART<br>TIME (s) | RFI<br>FILTER |
|-----------------|---------|----------------------------|-----------------------------|------------------------------|-------------------------------|---------------|---------------------------|---------------|
| Motor<br>Option | Voltage | 6-10                       | 6-11                        | 6-14                         | 6-15                          | 14-20         | 14-21                     | 14-50         |
| STD             | 208/230 | 2                          | [10]                        | 0                            | [60]                          | [3]           | 600                       | [0]           |
|                 | 460     | 2                          | [10]                        | 0                            | [60]                          | [3]           | 600                       | [0]           |
|                 | 575     | 2                          | [10]                        | 0                            | [60]                          | [3]           | 600                       | [0]           |
| MID             | 208/230 | 2                          | [10]                        | 0                            | [60]                          | [3]           | 600                       | [0]           |
|                 | 460     | 2                          | [10]                        | 0                            | [60]                          | [3]           | 600                       | [0]           |
|                 | 575     | 2                          | [10]                        | 0                            | [60]                          | [3]           | 600                       | [0]           |
| HIGH            | 208/230 | 2                          | [10]                        | 0                            | [60]                          | [3]           | 600                       | [0]           |
|                 | 460     | 2                          | [10]                        | 0                            | [60]                          | [3]           | 600                       | [0]           |
|                 | 575     | 2                          | [10]                        | 0                            | [60]                          | [3]           | 600                       | [0]           |
| ULTRA           | 208/230 | 2                          | [10]                        | 0                            | [60]                          | [3]           | 600                       | [0]           |
|                 | 460     | 2                          | [10]                        | 0                            | [60]                          | [3]           | 600                       | [0]           |
|                 | 575     | 2                          | [10]                        | 0                            | [60]                          | [3]           | 600                       | [0]           |

**Table 11 — VFD Unit Parameters – 48LC\*B Size 17**

|                 |         |              |                    |                | REGIONAL<br>SETTINGS | GRID<br>TYPE | MOTOR<br>POWER | MOTOR<br>VOLTAGE | MOTOR<br>FREQUENCY<br>(Hz) | MOTOR<br>CURRENT<br>(MUST-HOLD<br>AMPS) | MOTOR<br>NOMINAL<br>SPEED (RPM) |
|-----------------|---------|--------------|--------------------|----------------|----------------------|--------------|----------------|------------------|----------------------------|---|---------------------------------|
| Motor<br>Option | Voltage | Motor<br>P/N | VFD<br>Carrier P/N | VFD<br>Mfr P/N | 0-03                 | 0-06         | 1-20           | 1-22             | 1-23                       | 1-24                                    | 1-25                            |
| STD             | 208/230 | HD58FE654    | HK30WA371          | 131L9796       | [1]                  | [102]        | [10]           | 230              | 60                         | 9.2                                     | 1735                            |
|                 | 460     | HD58FE654    | HK30WA377          | 131L9864       | [1]                  | [122]        | [10]           | 460              | 60                         | 4.2                                     | 1735                            |
|                 | 575     | HD58FE577    | HK30WA383          | 131N0227       | [1]                  | [132]        | [11]           | 575              | 60                         | 4.9                                     | 1710                            |
| MID             | 208/230 | HD60FK657    | HK30WA373          | 131L9798       | [1]                  | [102]        | [14]           | 230              | 60                         | 21.2                                    | 1760                            |
|                 | 460     | HD60FK657    | HK30WA380          | 131L9867       | [1]                  | [122]        | [14]           | 460              | 60                         | 9.7                                     | 1760                            |
|                 | 575     | HD60FL576    | HK30WA384          | 131N0229       | [1]                  | [132]        | [14]           | 575              | 60                         | 7.2                                     | 1745                            |
| HIGH            | 208/230 | HD62FK654    | HK30WA374          | 131L9799       | [1]                  | [102]        | [15]           | 230              | 60                         | 28.0                                    | 1760                            |
|                 | 460     | HD62FK654    | HK30WA381          | 131L9868       | [1]                  | [122]        | [15]           | 460              | 60                         | 13.7                                    | 1760                            |
|                 | 575     | HD62FL576    | HK30WA384          | 131N0229       | [1]                  | [132]        | [15]           | 575              | 60                         | 8.9                                     | 1750                            |
| ULTRA           | 208/230 | HD64FK654    | HK30WA375          | 131L9800       | [1]                  | [102]        | [16]           | 230              | 60                         | 37.3                                    | 1755                            |
|                 | 460     | HD64FK654    | HK30WA386          | 131L9869       | [1]                  | [122]        | [16]           | 460              | 60                         | 16.9                                    | 1755                            |
|                 | 575     | HD64FL576    | HK30WA388          | 131N0233       | [1]                  | [132]        | [16]           | 575              | 60                         | 12.6                                    | 1755                            |

|                 |         | START<br>DELAY<br>(sec) | FLYING<br>START | MIN SPEED FOR<br>FUNCTION (Hz) | MOTOR<br>THERMAL<br>PROTECTION | PRESET REFERENCE |          |          |          |          |          |          |          |
|-----------------|---------|-------------------------|-----------------|--------------------------------|--------------------------------|------------------|----------|----------|----------|----------|----------|----------|----------|
| Motor<br>Option | Voltage | 1-71                    | 1-73            | 1-82                           | 1-90                           | 3-10 [0]         | 3-10 [1] | 3-10 [2] | 3-10 [3] | 3-10 [4] | 3-10 [5] | 3-10 [6] | 3-10 [7] |
| STD             | 208/230 | 2.0                     | [1]             | 1.0                            | [4]                            | 0%               | 56.64%   | 82.40%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|                 | 460     | 2.0                     | [1]             | 1.0                            | [4]                            | 0%               | 56.64%   | 82.40%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|                 | 575     | 2.0                     | [1]             | 1.0                            | [4]                            | 0%               | 56.64%   | 82.40%   | 100%     | 100%     | 0%       | 0%       | 0%       |
| MID             | 208/230 | 2.0                     | [1]             | 1.0                            | [4]                            | 0%               | 56.64%   | 82.40%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|                 | 460     | 2.0                     | [1]             | 1.0                            | [4]                            | 0%               | 56.64%   | 82.40%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|                 | 575     | 2.0                     | [1]             | 1.0                            | [4]                            | 0%               | 56.64%   | 82.40%   | 100%     | 100%     | 0%       | 0%       | 0%       |
| HIGH            | 208/230 | 2.0                     | [1]             | 1.0                            | [4]                            | 0%               | 56.64%   | 82.40%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|                 | 460     | 2.0                     | [1]             | 1.0                            | [4]                            | 0%               | 56.64%   | 82.40%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|                 | 575     | 2.0                     | [1]             | 1.0                            | [4]                            | 0%               | 56.64%   | 82.40%   | 100%     | 100%     | 0%       | 0%       | 0%       |
| ULTRA           | 208/230 | 2.0                     | [1]             | 1.0                            | [4]                            | 0%               | 56.64%   | 82.40%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|                 | 460     | 2.0                     | [1]             | 1.0                            | [4]                            | 0%               | 56.64%   | 82.40%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|                 | 575     | 2.0                     | [1]             | 1.0                            | [4]                            | 0%               | 56.64%   | 82.40%   | 100%     | 100%     | 0%       | 0%       | 0%       |

**Table 11 — VFD Unit Parameters – 48LC\*B Size 17 (cont)**

|              |         | RAMP UP TIME (sec) | RAMP DOWN TIME (sec) | CURRENT LIMIT | TERMINAL 18 DIGITAL INPUT | TERMINAL 19 DIGITAL INPUT | TERMINAL 27 DIGITAL INPUT | TERMINAL 29 DIGITAL INPUT |
|--------------|---------|--------------------|----------------------|---------------|---------------------------|---------------------------|---------------------------|---------------------------|
| Motor Option | Voltage | 3-41               | 3-42                 | 4-18          | 5-10                      | 5-11                      | 5-12                      | 5-13                      |
| STD          | 208/230 | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 460     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 575     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
| MID          | 208/230 | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 460     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 575     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
| HIGH         | 208/230 | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 460     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 575     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
| ULTRA        | 208/230 | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 460     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 575     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |

|              |         | TERMINAL 53 LOW VOLTAGE | TERMINAL 53 HIGH VOLTAGE | TERMINAL 53 LOW REFERENCE | TERMINAL 53 HIGH REFERENCE | RESET MODE | AUTO. RESTART TIME (s) | RFI FILTER |
|--------------|---------|-------------------------|--------------------------|---------------------------|----------------------------|------------|------------------------|------------|
| Motor Option | Voltage | 6-10                    | 6-11                     | 6-14                      | 6-15                       | 14-20      | 14-21                  | 14-50      |
| STD          | 208/230 | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 460     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 575     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
| MID          | 208/230 | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 460     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 575     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
| HIGH         | 208/230 | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 460     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 575     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
| ULTRA        | 208/230 | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 460     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 575     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |

**Table 12 — VFD Unit Parameters – 48LC\*B Size 20**

|              |         |           |                 |             | REGIONAL SETTINGS | GRID TYPE | MOTOR POWER | MOTOR VOLTAGE | MOTOR FREQUENCY (Hz) | MOTOR CURRENT (MUST-HOLD AMPS) | MOTOR NOMINAL SPEED (RPM) |
|--------------|---------|-----------|-----------------|-------------|-------------------|-----------|-------------|---------------|----------------------|--------------------------------|---------------------------|
| Motor Option | Voltage | Motor P/N | VFD Carrier P/N | VFD Mfr P/N | 0-03              | 0-06      | 1-20        | 1-22          | 1-23                 | 1-24                           | 1-25                      |
| STD          | 208/230 | HD60FE656 | HK30WA372       | 131L9797    | [1]               | [102]     | [11]        | 230           | 60                   | 11.7                           | 1750                      |
|              | 460     | HD60FE656 | HK30WA378       | 131L9865    | [1]               | [122]     | [11]        | 460           | 60                   | 5.4                            | 1750                      |
|              | 575     | HD58FE577 | HK30WA383       | 131N0227    | [1]               | [132]     | [11]        | 575           | 60                   | 4.9                            | 1710                      |
| MID          | 208/230 | HD60FK657 | HK30WA373       | 131L9798    | [1]               | [102]     | [14]        | 230           | 60                   | 21.2                           | 1760                      |
|              | 460     | HD60FK657 | HK30WA380       | 131L9867    | [1]               | [122]     | [14]        | 460           | 60                   | 9.7                            | 1760                      |
|              | 575     | HD60FL576 | HK30WA384       | 131N0229    | [1]               | [132]     | [14]        | 575           | 60                   | 7.2                            | 1745                      |
| HIGH         | 208/230 | HD62FK654 | HK30WA374       | 131L9799    | [1]               | [102]     | [15]        | 230           | 60                   | 28.0                           | 1760                      |
|              | 460     | HD62FK654 | HK30WA381       | 131L9868    | [1]               | [122]     | [15]        | 460           | 60                   | 13.7                           | 1760                      |
|              | 575     | HD62FL576 | HK30WA384       | 131N0229    | [1]               | [132]     | [15]        | 575           | 60                   | 8.9                            | 1750                      |
| ULTRA        | 208/230 | HD64FK654 | HK30WA375       | 131L9800    | [1]               | [102]     | [16]        | 230           | 60                   | 37.3                           | 1755                      |
|              | 460     | HD64FK654 | HK30WA386       | 131L9869    | [1]               | [122]     | [16]        | 460           | 60                   | 16.9                           | 1755                      |
|              | 575     | HD64FL576 | HK30WA388       | 131N0233    | [1]               | [132]     | [16]        | 575           | 60                   | 12.6                           | 1755                      |

Table 12 — VFD Unit Parameters – 48LC\*B Size 20 (cont)

|              |         | START DELAY (sec) | FLYING START | MIN SPEED FOR FUNCTION (Hz) | MOTOR THERMAL PROTECTION | PRESET REFERENCE |          |          |          |          |          |          |          |
|--------------|---------|-------------------|--------------|-----------------------------|--------------------------|------------------|----------|----------|----------|----------|----------|----------|----------|
| Motor Option | Voltage | 1-71              | 1-73         | 1-82                        | 1-90                     | 3-10 [0]         | 3-10 [1] | 3-10 [2] | 3-10 [3] | 3-10 [4] | 3-10 [5] | 3-10 [6] | 3-10 [7] |
| STD          | 208/230 | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 52.57%   | 61.63%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 460     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 52.57%   | 61.63%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 575     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 52.57%   | 61.63%   | 100%     | 100%     | 0%       | 0%       | 0%       |
| MID          | 208/230 | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 52.57%   | 61.63%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 460     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 52.57%   | 61.63%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 575     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 52.57%   | 61.63%   | 100%     | 100%     | 0%       | 0%       | 0%       |
| HIGH         | 208/230 | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 52.57%   | 61.63%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 460     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 52.57%   | 61.63%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 575     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 52.57%   | 61.63%   | 100%     | 100%     | 0%       | 0%       | 0%       |
| ULTRA        | 208/230 | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 52.57%   | 61.63%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 460     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 52.57%   | 61.63%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 575     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 52.57%   | 61.63%   | 100%     | 100%     | 0%       | 0%       | 0%       |

|              |         | RAMP UP TIME (sec) | RAMP DOWN TIME (sec) | CURRENT LIMIT | TERMINAL 18 DIGITAL INPUT | TERMINAL 19 DIGITAL INPUT | TERMINAL 27 DIGITAL INPUT | TERMINAL 29 DIGITAL INPUT |
|--------------|---------|--------------------|----------------------|---------------|---------------------------|---------------------------|---------------------------|---------------------------|
| Motor Option | Voltage | 3-41               | 3-42                 | 4-18          | 5-10                      | 5-11                      | 5-12                      | 5-13                      |
| STD          | 208/230 | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 460     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 575     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
| MID          | 208/230 | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 460     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 575     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
| HIGH         | 208/230 | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 460     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 575     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
| ULTRA        | 208/230 | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 460     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 575     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |

|              |         | TERMINAL 53 LOW VOLTAGE | TERMINAL 53 HIGH VOLTAGE | TERMINAL 53 LOW REFERENCE | TERMINAL 53 HIGH REFERENCE | RESET MODE | AUTO. RESTART TIME (s) | RFI FILTER |
|--------------|---------|-------------------------|--------------------------|---------------------------|----------------------------|------------|------------------------|------------|
| Motor Option | Voltage | 6-10                    | 6-11                     | 6-14                      | 6-15                       | 14-20      | 14-21                  | 14-50      |
| STD          | 208/230 | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 460     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 575     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
| MID          | 208/230 | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 460     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 575     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
| HIGH         | 208/230 | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 460     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 575     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
| ULTRA        | 208/230 | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 460     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 575     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |

**Table 13 — VFD Unit Parameters – 48LC\*B Size 24**

|              |         |           |                 |             | REGIONAL SETTINGS | GRID TYPE | MOTOR POWER | MOTOR VOLTAGE | MOTOR FREQUENCY (Hz) | MOTOR CURRENT (MUST-HOLD AMPS) | MOTOR NOMINAL SPEED (RPM) |
|--------------|---------|-----------|-----------------|-------------|-------------------|-----------|-------------|---------------|----------------------|--------------------------------|---------------------------|
| Motor Option | Voltage | Motor P/N | VFD Carrier P/N | VFD Mfr P/N | 0-03              | 0-06      | 1-20        | 1-22          | 1-23                 | 1-24                           | 1-25                      |
| STD          | 208/230 | HD60FK657 | HK30WA373       | 131L9798    | [1]               | [102]     | [14]        | 230           | 60                   | 21.2                           | 1760                      |
|              | 460     | HD60FK657 | HK30WA380       | 131L9867    | [1]               | [122]     | [14]        | 460           | 60                   | 9.7                            | 1760                      |
|              | 575     | HD60FL576 | HK30WA384       | 131N0229    | [1]               | [132]     | [14]        | 575           | 60                   | 7.2                            | 1745                      |
| MID          | 208/230 | HD62FK654 | HK30WA374       | 131L9799    | [1]               | [102]     | [15]        | 230           | 60                   | 28.0                           | 1760                      |
|              | 460     | HD62FK654 | HK30WA381       | 131L9868    | [1]               | [122]     | [15]        | 460           | 60                   | 13.7                           | 1760                      |
|              | 575     | HD62FL576 | HK30WA384       | 131N0229    | [1]               | [132]     | [15]        | 575           | 60                   | 8.9                            | 1750                      |
| HIGH         | 208/230 | HD64FK654 | HK30WA375       | 131L9800    | [1]               | [102]     | [16]        | 230           | 60                   | 37.3                           | 1755                      |
|              | 460     | HD64FK654 | HK30WA386       | 131L9869    | [1]               | [122]     | [16]        | 460           | 60                   | 16.9                           | 1755                      |
|              | 575     | HD64FL576 | HK30WA388       | 131N0233    | [1]               | [132]     | [16]        | 575           | 60                   | 12.6                           | 1755                      |

|              |         | START DELAY (sec) | FLYING START | MIN SPEED FOR FUNCTION (Hz) | MOTOR THERMAL PROTECTION | PRESET REFERENCE |          |          |          |          |          |          |          |
|--------------|---------|-------------------|--------------|-----------------------------|--------------------------|------------------|----------|----------|----------|----------|----------|----------|----------|
| Motor Option | Voltage | 1-71              | 1-73         | 1-82                        | 1-90                     | 3-10 [0]         | 3-10 [1] | 3-10 [2] | 3-10 [3] | 3-10 [4] | 3-10 [5] | 3-10 [6] | 3-10 [7] |
| STD          | 208/230 | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 52.33%   | 64.48%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 460     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 52.33%   | 64.48%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 575     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 52.33%   | 64.48%   | 100%     | 100%     | 0%       | 0%       | 0%       |
| MID          | 208/230 | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 52.33%   | 64.48%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 460     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 52.33%   | 64.48%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 575     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 52.33%   | 64.48%   | 100%     | 100%     | 0%       | 0%       | 0%       |
| HIGH         | 208/230 | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 52.33%   | 64.48%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 460     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 52.33%   | 64.48%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 575     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 52.33%   | 64.48%   | 100%     | 100%     | 0%       | 0%       | 0%       |

|              |         | RAMP UP TIME (sec) | RAMP DOWN TIME (sec) | CURRENT LIMIT | TERMINAL 18 DIGITAL INPUT | TERMINAL 19 DIGITAL INPUT | TERMINAL 27 DIGITAL INPUT | TERMINAL 29 DIGITAL INPUT |
|--------------|---------|--------------------|----------------------|---------------|---------------------------|---------------------------|---------------------------|---------------------------|
| Motor Option | Voltage | 3-41               | 3-42                 | 4-18          | 5-10                      | 5-11                      | 5-12                      | 5-13                      |
| STD          | 208/230 | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 460     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 575     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
| MID          | 208/230 | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 460     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 575     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
| HIGH         | 208/230 | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 460     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 575     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |

|              |         | TERMINAL 53 LOW VOLTAGE | TERMINAL 53 HIGH VOLTAGE | TERMINAL 53 LOW REFERENCE | TERMINAL 53 HIGH REFERENCE | RESET MODE | AUTO. RESTART TIME (s) | RFI FILTER |
|--------------|---------|-------------------------|--------------------------|---------------------------|----------------------------|------------|------------------------|------------|
| Motor Option | Voltage | 6-10                    | 6-11                     | 6-14                      | 6-15                       | 14-20      | 14-21                  | 14-50      |
| STD          | 208/230 | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 460     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 575     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
| MID          | 208/230 | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 460     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 575     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
| HIGH         | 208/230 | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 460     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 575     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |

**Table 14 — VFD Unit Parameters – 48LC\*B Size 26**

|              |         |           |                 |             | REGIONAL SETTINGS | GRID TYPE | MOTOR POWER | MOTOR VOLTAGE | MOTOR FREQUENCY (Hz) | MOTOR CURRENT (MUST-HOLD AMPS) | MOTOR NOMINAL SPEED (RPM) |
|--------------|---------|-----------|-----------------|-------------|-------------------|-----------|-------------|---------------|----------------------|--------------------------------|---------------------------|
| Motor Option | Voltage | Motor P/N | VFD Carrier P/N | VFD Mfr P/N | 0-03              | 0-06      | 1-20        | 1-22          | 1-23                 | 1-24                           | 1-25                      |
| STD          | 208/230 | HD60FK657 | HK30WA373       | 131L9798    | [1]               | [102]     | [14]        | 230           | 60                   | 21.2                           | 1760                      |
|              | 460     | HD60FK657 | HK30WA380       | 131L9867    | [1]               | [122]     | [14]        | 460           | 60                   | 9.7                            | 1760                      |
|              | 575     | HD60FL576 | HK30WA384       | 131N0229    | [1]               | [132]     | [14]        | 575           | 60                   | 7.2                            | 1745                      |
| MID          | 208/230 | HD62FK654 | HK30WA374       | 131L9799    | [1]               | [102]     | [15]        | 230           | 60                   | 28.0                           | 1760                      |
|              | 460     | HD62FK654 | HK30WA381       | 131L9868    | [1]               | [122]     | [15]        | 460           | 60                   | 13.7                           | 1760                      |
|              | 575     | HD62FL576 | HK30WA384       | 131N0229    | [1]               | [132]     | [15]        | 575           | 60                   | 8.9                            | 1750                      |
| HIGH         | 208/230 | HD64FK654 | HK30WA375       | 131L9800    | [1]               | [102]     | [16]        | 230           | 60                   | 37.3                           | 1755                      |
|              | 460     | HD64FK654 | HK30WA386       | 131L9869    | [1]               | [122]     | [16]        | 460           | 60                   | 16.9                           | 1755                      |
|              | 575     | HD64FL576 | HK30WA388       | 131N0233    | [1]               | [132]     | [16]        | 575           | 60                   | 12.6                           | 1755                      |

|              |         | START DELAY (sec) | FLYING START | MIN SPEED FOR FUNCTION (Hz) | MOTOR THERMAL PROTECTION | PRESET REFERENCE |          |          |          |          |          |          |          |
|--------------|---------|-------------------|--------------|-----------------------------|--------------------------|------------------|----------|----------|----------|----------|----------|----------|----------|
| Motor Option | Voltage | 1-71              | 1-73         | 1-82                        | 1-90                     | 3-10 [0]         | 3-10 [1] | 3-10 [2] | 3-10 [3] | 3-10 [4] | 3-10 [5] | 3-10 [6] | 3-10 [7] |
| STD          | 208/230 | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 60.00%   | 72.00%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 460     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 60.00%   | 72.00%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 575     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 60.00%   | 72.00%   | 100%     | 100%     | 0%       | 0%       | 0%       |
| MID          | 208/230 | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 60.00%   | 72.00%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 460     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 60.00%   | 72.00%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 575     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 60.00%   | 72.00%   | 100%     | 100%     | 0%       | 0%       | 0%       |
| HIGH         | 208/230 | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 60.00%   | 72.00%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 460     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 60.00%   | 72.00%   | 100%     | 100%     | 0%       | 0%       | 0%       |
|              | 575     | 2.0               | [1]          | 1.0                         | [4]                      | 0%               | 60.00%   | 72.00%   | 100%     | 100%     | 0%       | 0%       | 0%       |

|              |         | RAMP UP TIME (sec) | RAMP DOWN TIME (sec) | CURRENT LIMIT | TERMINAL 18 DIGITAL INPUT | TERMINAL 19 DIGITAL INPUT | TERMINAL 27 DIGITAL INPUT | TERMINAL 29 DIGITAL INPUT |
|--------------|---------|--------------------|----------------------|---------------|---------------------------|---------------------------|---------------------------|---------------------------|
| Motor Option | Voltage | 3-41               | 3-42                 | 4-18          | 5-10                      | 5-11                      | 5-12                      | 5-13                      |
| STD          | 208/230 | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 460     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 575     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
| MID          | 208/230 | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 460     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 575     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
| HIGH         | 208/230 | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 460     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |
|              | 575     | 10.00              | 10.00                | 100%          | [8]                       | [16]                      | [17]                      | [18]                      |

|              |         | TERMINAL 53 LOW VOLTAGE | TERMINAL 53 HIGH VOLTAGE | TERMINAL 53 LOW REFERENCE | TERMINAL 53 HIGH REFERENCE | RESET MODE | AUTO. RESTART TIME (s) | RFI FILTER |
|--------------|---------|-------------------------|--------------------------|---------------------------|----------------------------|------------|------------------------|------------|
| Motor Option | Voltage | 6-10                    | 6-11                     | 6-14                      | 6-15                       | 14-20      | 14-21                  | 14-50      |
| STD          | 208/230 | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 460     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 575     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
| MID          | 208/230 | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 460     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 575     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
| HIGH         | 208/230 | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 460     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |
|              | 575     | 2                       | [10]                     | 0                         | [60]                       | [3]        | 600                    | [0]        |

## Smoke Detectors

Smoke detectors are available as factory-installed options on 48LC\*B14-26 models. Smoke detectors may be specified for supply air only, for return air without or with economizer, or in combination of supply air and return air. The unit is factory-configured for immediate smoke detector shutdown operation; additional wiring or modifications to unit's Integrated Staging Control (ISC) board may be necessary to complete the unit and smoke detector configuration to meet project requirements.

### RETURN AIR SENSOR TUBE INSTALLATION

The return air sampling tube is shipped in the unit's supply fan section, attached to the blower housing (see Fig. 72). Its operating location is in the return air section of the unit (see Fig. 73, unit without economizer, or Fig. 74, unit with economizer), inserted into the return air sensor module housing which protrudes through the back of the control box.




Fig. 72 — Typical Supply Air Smoke Detector Sensor Location




Fig. 73 — Return Air Sampling Tube Location in Unit without Economizer




Fig. 74 — Return Air Sampling Tube Location in Unit with Economizer

#### To install the return air sensor sampling tube:

1. Remove the tube from its shipping location.
2. Open the unit end to access the return air sensor (located on right-hand partition).
3. Orient the tube's sampling holes into the return air flow direction. For vertical application, position the sampling holes on the bottom of the tube, facing into the bottom return duct opening. For horizontal application, position the sampling holes on the side of the tube, facing the unit's end panel.
4. Insert the sampling tube into the return air sensor module until the tube snaps into position.
5. Replace end panel or outside air hood.

### SMOKE DETECTOR TEST MAGNET

Locate the magnet; it is shipped in the control box area.

### ADDITIONAL APPLICATION DATA

Refer to the Application Data sheet, *Factory-Installed Smoke Detectors for Small and Medium Rooftop Units 2 to 25 Tons* for discussions on additional control features of these smoke detectors including multiple unit coordination.

### Step 15 — Install Accessories

Available accessories include:

- Curb
- Thru-base connection kit (must be installed before unit is set on curb)
- Power Exhaust
- Outdoor enthalpy sensor
- Differential enthalpy sensor
- CO<sub>2</sub> sensor
- Louvered hail guard
- Phase monitor control

Refer to separate installation instructions for information on installing these accessories.

### Pre-Start and Start-Up

This completes the mechanical installation of the unit. Refer to the unit's Service and Maintenance manual for detailed Pre-Start and Start-up instructions.

## START-UP CHECKLIST

(Remove and Store in Job File)

**NOTE: To avoid injury to personnel and damage to equipment or property when completing the procedures listed in this start-up checklist, use good judgment, follow safe practices, and adhere to the safety considerations/information as outlined in preceding sections of this Installation Instruction document.**

### I. PRELIMINARY INFORMATION

MODEL NO. \_\_\_\_\_

JOB NAME \_\_\_\_\_

SERIAL NO.. \_\_\_\_\_

ADDRESS \_\_\_\_\_

START-UP DATE \_\_\_\_\_

TECHNICIAN NAME \_\_\_\_\_

ADDITIONAL ACCESSORIES \_\_\_\_\_

### II. PRE-START-UP

Verify that all packaging materials have been removed from unit (Y/N) \_\_\_\_\_

Verify installation of duct pressure transducer (Y/N) \_\_\_\_\_

Verify installation of outdoor air hood (Y/N) \_\_\_\_\_

Verify installation of flue exhaust and inlet hood (Y/N) \_\_\_\_\_

Verify that condensate connection is installed per instructions (Y/N) \_\_\_\_\_

Verify that all electrical connections and terminals are tight (Y/N) \_\_\_\_\_

Verify gas pressure to unit gas valve is within specified range (Y/N) \_\_\_\_\_

Check gas piping for leaks (Y/N) \_\_\_\_\_

Check that indoor-air filters are clean and in place (Y/N) \_\_\_\_\_

Check that outdoor-air inlet screens are in place (Y/N) \_\_\_\_\_

Verify that unit is level (Y/N) \_\_\_\_\_

Check fan wheels and propeller for location in housing/orifice and verify setscrew is tight (Y/N) \_\_\_\_\_

Verify that fan sheaves are aligned and belts are properly tensioned (Y/N) \_\_\_\_\_

Verify that scroll compressors are rotating in the correct direction (Y/N) \_\_\_\_\_

Verify installation of thermostat (Y/N) \_\_\_\_\_

Verify that crankcase heaters have been energized for at least 24 hours (Y/N) \_\_\_\_\_

### III. START-UP

#### ELECTRICAL

Supply Voltage L1-L2 \_\_\_\_\_

L2-L3 \_\_\_\_\_

L3-L1 \_\_\_\_\_

Compressor Amps 1 L1 \_\_\_\_\_

L2 \_\_\_\_\_

L3 \_\_\_\_\_

Compressor Amps 2 L1 \_\_\_\_\_

L2 \_\_\_\_\_

L3 \_\_\_\_\_

Supply Fan Amps L1 \_\_\_\_\_

L2 \_\_\_\_\_

L3 \_\_\_\_\_

#### TEMPERATURES

Outdoor-air Temperature \_\_\_\_\_ °F DB (Dry Bulb)

Return-air Temperature \_\_\_\_\_ °F DB

Cooling Supply Air Temperature \_\_\_\_\_ °F

Gas Heat Supply Air Temperature \_\_\_\_\_ °F

**PRESSURES**

|   |           |              |
|---|-----------|--------------|
| Gas Inlet Pressure                                    | _____     | IN. WG       |
| Gas Manifold Pressure                                 | STAGE 1   | _____ IN. WG |
|   | STAGE 2   | _____ IN. WG |
| Refrigerant Suction                                   | CIRCUIT A | _____ PSIG   |
|   | CIRCUIT B | _____ PSIG   |
| Refrigerant Discharge                                 | CIRCUIT A | _____ PSIG   |
|   | CIRCUIT B | _____ PSIG   |
| Verify Refrigerant Charge using Charging Charts (Y/N) | _____     |              |

**GENERAL**

Economizer minimum vent and changeover settings to job requirements (if equipped) (Y/N) \_\_\_\_\_  
Verify smoke detector unit shutdown by utilizing magnet test (Y/N) \_\_\_\_\_

CUT ALONG DOTTED LINE

CUT ALONG DOTTED LINE