



Operating Guide

CONTENTS

	Page
INTRODUCTION	2
Purpose of the Manual	2
Additional Resources	2
Software Version	2
Approvals and Certifications	2
• COMPLIANCE WITH ADN	
Disposal	2
SAFETY	2
Safety Symbols	2
Qualified Personnel	3
Safety Precautions	3
PRODUCT OVERVIEW	4
Intended Use	4
• FORESEEABLE MISUSE	
Power Ratings, Weight, and Dimensions	4
Interior View of D1h Drive	5
Interior View of D2h Drive	6
View of Control Shelf	7
Extended Options Cabinets	8
Local Control Panel (LCP)	9
LCP Menus	10
• QUICK MENUS	
• Q1 MY PERSONAL MENU	
• Q2 QUICK SETUP	
• Q4 SMART SETUP	
• Q5 CHANGES MADE	
• Q6 LOGGINGS	
• Q7 MOTOR SETUP	
• MAIN MENU MODE	
MECHANICAL INSTALLATION	11
Items Supplied	11
Tools Needed	12
Storage	12
Operating Environment	12
• GASES	
• DUST	
• POTENTIALLY EXPLOSIVE ATMOSPHERES	
Installation and Cooling Requirements	13
Lifting the Drive	13
Mounting the Drive	14
• CREATING CABLE OPENINGS	
• ATTACHING THE DRIVE TO THE PEDESTAL	
• FLOOR MOUNTING THE DRIVE	
• WALL MOUNTING THE DRIVE	
ELECTRICAL INSTALLATION	17
Safety Instructions	17
• OVERCURRENT PROTECTION	
• WIRE TYPE AND RATINGS	
EMC-compliant Installation	17
Wiring Schematic	19
Connecting to Ground	20
• FOR ELECTRICAL SAFETY	
• FOR EMC-COMPLIANT INSTALLATION	
Connecting the Motor	21
Connecting the AC Mains	22
Connecting Regen/Load Share Terminals	23
Terminal Dimensions	25
• D1H TERMINAL DIMENSIONS	
• D2H TERMINAL DIMENSIONS	
• D3H TERMINAL DIMENSIONS	
• D4H TERMINAL DIMENSIONS	
• D5H TERMINAL DIMENSIONS	
• D6H TERMINAL DIMENSIONS	
• D7H TERMINAL DIMENSIONS	
• D8H TERMINAL DIMENSIONS	
Control Wiring	53
• CONTROL CABLE ROUTING	
• CONTROL TERMINAL TYPES	
• WIRING TO CONTROL TERMINALS	
• ENABLING MOTOR OPERATION (TERMINAL 27)	
• CONFIGURING RS485 SERIAL COMMUNICATION	
• WIRING SAFE TORQUE OFF (STO)	
• WIRING THE SPACE HEATER	
• WIRING THE AUXILIARY CONTACTS TO THE DISCONNECT	
• WIRING THE BRAKE RESISTOR TEMPERATURE SWITCH	
• SELECTING VOLTAGE/CURRENT INPUT SIGNAL	
PRE-START CHECKLIST	56
COMMISSIONING	57
Applying Power	57
Programming the Drive	57
• PARAMETER OVERVIEW	
• PARAMETER NAVIGATION	
• ENTERING SYSTEM INFORMATION	
• CONFIGURING AUTOMATIC ENERGY OPTIMIZATION	
• CONFIGURING AUTOMATIC MOTOR ADAPTATION	
Testing Before System Start-up	58
• MOTOR ROTATION	
• ENCODER ROTATION	
System Start-up	58
Parameter Setting	59
• UPLOADING AND DOWNLOADING PARAMETER SETTINGS	
• RESTORING FACTORY DEFAULT SETTINGS	
WIRING CONFIGURATION EXAMPLES	60
Introduction	60
Wiring Configurations for Automatic Motor	

Adaptation (AMA)	60
Wiring Configurations for Analog Speed Reference	60
Wiring Configurations for Start/Stop	61
Wiring Configuration for an External Alarm Reset	62
Wiring Configuration for Speed Reference Using a Manual Potentiometer	62
Wiring Configuration for Speed Up/Speed Down	63
Wiring Configuration for RS485 Network Connection	63
Wiring Configuration for a Motor Thermistor	64
Wiring Configuration for a Cascade Controller	64
Wiring Configuration for Relay Set-up with Smart Logic Control	66
Wiring Configuration for a Fixed Variable Speed Pump	66
Wiring Configuration for Lead Pump Alternation	66
MAINTENANCE, DIAGNOSTICS, AND TROUBLESHOOTING	67
Maintenance and Service	67
Heat Sink Access Panel	67
• REMOVING THE HEAT SINK ACCESS PANEL	
Status Messages	67
Warning and Alarm Types	69
List of Warnings and Alarms	70
Troubleshooting	78
SPECIFICATIONS	80
Electrical Data	80
• ELECTRICAL DATA FOR ENCLOSURES D1H-D4H, 3X200-240 V	
Electrical Data for Enclosures D1h-D8h, 3x380-480 V	82
• ELECTRICAL DATA FOR ENCLOSURES D1H-D8H, 3X525-690 V	
Mains Supply	86
Motor Output and Torque Data	86
Ambient Conditions	86
Cable Specifications	86
Control Input/Output and Control Data	86
Fuses and Circuit Breakers	88
• FUSE SELECTION	
• SHORT-CIRCUIT CURRENT RATING (SCCR)	
Fastener Tightening Torques	89
Enclosure Dimensions	90
• D1H EXTERIOR DIMENSIONS	
• D2H EXTERIOR DIMENSIONS	
• D3H EXTERIOR DIMENSIONS	
• D4H ENCLOSURE DIMENSIONS	
• D5H EXTERIOR DIMENSIONS	
• D6H EXTERIOR DIMENSIONS	
• D7H EXTERIOR DIMENSIONS	
• D8H EXTERIOR DIMENSIONS	
APPENDIX	125
Abbreviations and Conventions	125
International/North American Default Parameter Settings	126
Parameter Menu Structure	127
• SOFTWARE 5.20	

INTRODUCTION

Purpose of the Manual

This operating guide provides information for safe installation and commissioning of the drives.

The operating guide is intended for use by qualified personnel. To use the unit safely and professionally, read and follow this operating guide. Pay particular attention to the safety instructions and general warnings. Always keep the operating guide with the drive.

Additional Resources

Other resources are available to understand advanced drive functions and programming.

- The programming guide provides greater detail on working with parameters and many application examples.
- The design guide provides detailed information about capabilities and functionality to design motor control systems.
- Instructions provide information for operation with optional equipment.

Software Version

Software version is 5.20.

Approvals and Certifications

Fig. 1 — Approvals and Certifications



More approvals and certifications are available. Contact Carrier. Drives of voltage 525-690 V are UL certified for only 525-600 V. The drive complies with UL 61800-5-1 thermal memory retention requirements. For more information, contact Carrier.

NOTICE

OUTPUT FREQUENCY LIMIT

Due to export control regulations, the output frequency of the drive is limited to 590 Hz. For demands exceeding 590 Hz, contact Carrier.

COMPLIANCE WITH ADN

For compliance with the European Agreement concerning International Carriage of Dangerous Goods by Inland Waterways (ADN).

Disposal

Do not dispose of equipment containing electrical components together with domestic waste.

Collect it separately in accordance with local and currently valid legislation.

SAFETY

Safety Symbols

The following symbols are used in this guide:

WARNING

Indicates a potentially hazardous situation that could result in death or serious injury.

CAUTION

Indicates a potentially hazardous situation that could result in minor or moderate injury. It can also be used to alert against unsafe practices.

NOTICE

Indicates important information, including situations that can result in damage to equipment or property.

Qualified Personnel

Correct and reliable transport, storage, installation, operation, and maintenance are required for the troublefree and safe operation of the drive. Only qualified personnel are allowed to install or operate this equipment.

Qualified personnel are defined as trained staff, who are authorized to install, commission, and maintain equipment, systems, and circuits in accordance with pertinent laws and regulations. Also, the personnel must be familiar with the instructions and safety measures described in this manual.

Safety Precautions

⚠ WARNING

HIGH VOLTAGE

Drives contain high voltage when connected to AC mains input, DC supply, load sharing, or permanent motors. Failure to use qualified personnel to install, start up, and maintain the drive can result in death or serious injury.

- Only qualified personnel must install, start up, and maintain the drive.

⚠ WARNING

UNINTENDED START

When the drive is connected to the AC mains, DC supply, or load sharing, the motor can start at any time. Unintended start during programming, service, or repair work can result in death, serious injury, or property damage. The motor can start with an external switch, a fieldbus command, an input reference signal from the LCP or LOP, via remote operation using MCT 10 Set-up Software, or after a cleared fault condition.

To prevent unintended motor start:

- Press [Off/Reset] on the LCP before programming parameters.
- Disconnect the drive from the mains.
- Completely wire and assemble the drive, motor, and any driven equipment before connecting the drive to the AC mains, DC supply, or load sharing.

⚠ WARNING

DISCHARGE TIME

The drive contains DC-link capacitors, which can remain charged even when the drive is not powered. High voltage can be present even when the warning LED indicator lights are off. Failure to wait the specified time after power has been removed before performing service or repair work can result in death or serious injury.

- Stop the motor.
- Disconnect AC mains and remote DC-link power supplies, including battery back-ups, UPS, and DC-link connections to other drives.
- Disconnect or lock PM motor.

- Wait for the capacitors to discharge fully. The minimum waiting time is 20 minutes.
- Before performing any service or repair work, use an appropriate voltage measuring device to make sure that the capacitors are fully discharged.

⚠ WARNING

LEAKAGE CURRENT HAZARD

Leakage currents exceed 3.5 mA. Failure to ground the drive properly can result in death or serious injury.

- Ensure the correct grounding of the equipment by a certified electrical installer.

⚠ WARNING

EQUIPMENT HAZARD

Contact with rotating shafts and electrical equipment can result in death or serious injury.

- Ensure that only trained and qualified personnel install, start up, and maintain the drive.
- Ensure that electrical work conforms to national and local electrical codes.
- Follow the procedures in this guide.

⚠ WARNING

UNINTENDED MOTOR ROTATION WINDMILLING

Unintended rotation of permanent magnet motors creates voltage and can charge the unit, resulting in death, serious injury, or equipment damage.

- Ensure that permanent magnet motors are blocked to prevent unintended rotation.

⚠ WARNING

INTERNAL FAILURE HAZARD

Under certain circumstances, an internal failure can cause a component to explode. Failure to keep the enclosure closed and properly secured can cause death or serious injury.

- Do not operate the drive with the door open or panels off.
- Ensure that the enclosure is properly closed and secured during operation.

⚠ CAUTION

HOT SURFACES

The drive contains metal components that are still hot even after the drive has been powered off. Failure to observe the high temperature symbol (yellow triangle) on the drive can result in serious burns.

- Be aware that internal components, such as busbars, can be extremely hot even after the drive has been powered off.
- Exterior areas marked by the high-temperature symbol (yellow triangle) are hot while the drive is in use and immediately after being powered off.

NOTICE

MAINS SHIELD SAFETY OPTION

A mains shield option is available for enclosures with a protection rating of IP21/IP54 (Type 1/Type 12). The mains shield is a cover installed inside the enclosure to protect against the unintended touch of the power terminals, according to BGV A2, VBG 4.

PRODUCT OVERVIEW

Intended Use

The drive is an electronic motor controller that converts AC mains input into a variable AC waveform output. The frequency and voltage of the output are regulated to control the motor speed or torque. The drive is designed to:

- Regulate motor speed in response to system feedback or to remote commands from external controllers.
- Monitor system and motor status.
- Provide motor overload protection.

Table 1 — Mechanical Dimensions, Enclosure Sizes D1h-D4h

Enclosure size	D1h	D2h	D3h	D4h	D3h	D4h
	110-160 kW (380-480 V) 75-160 kW (525-690 V)	200-315 kW (380-480 V) 200-400 kW (525-690 V)	110-160 kW (380-480 V) 75-160 kW (525-690 V)	200-315 kW (380-480 V) 200-400 kW (525-690 V)	With regeneration or load sharing terminals	
IP	21/54	21/54	20	20	20	20
NEMA	TYPE 1/12	TYPE 1/12	CHASSIS	CHASSIS	CHASSIS	CHASSIS
Shipping dimensions [mm (in.)]	Height 95 (3.7) Width 997 (39.3) Depth 460 (18.1)	587 (23.1) 1170 (46.1) 535 (21.1)	587 (23.1) 1170 (46.1) 460 (18.1)	587 (23.1) 1122 (44.2) 535 (21.1)	587 (23.1) 1004 (39.5) 460 (18.1)	587 (23.1) 1268 (49.9) 535 (21.1)
Drive dimensions [mm (in.)]	Height 901 (35.5) Width 325 (12.8) Depth 378 (14.9)	1060 (41.7) 420 (16.5) 378 (14.9)	909 (35.8) 250 (9.8) 375 (14.7)	1122 (44.2) 350 (13.8) 375 (14.7)	1004 (39.5) 250 (9.8) 375 (14.7)	1268 (49.9) 350 (13.8) 375 (14.8)
Maximum weight [kg (lb)]	98 (216)	164 (362)	98 (216)	164 (362)	108 (238)	179 (395)

Table 2 — Mechanical Dimensions, Enclosure Sizes D5h-D8h

Enclosure size	D5h	D6h	D7h	D8h
	110-160 kW (380-480 V) 75-160 kW (525-690 V)	110-160 kW (380-480 V) 75-160 kW (525-690 V)	200-315 kW (380-480 V) 200-400 kW (525-690 V)	200-315 kW (380-480 V) 200-400 kW (525-690 V)
IP	21/54	21/54	21/54	21/54
NEMA	TYPE 1/12	TYPE 1/12	TYPE 1/12	TYPE 1/12
Shipping dimensions [mm (in.)]	Height 660 (26) Width 1820 (71.7) Depth 510 (20.1)	660 (26) 1820 (71.7) 510 (20.1)	660 (26) 2470 (97.4) 590 (23.2)	660 (26) 2470 (97.4) 590 (23.2)
Drive dimensions [mm (in.)]	Height 1324 (52.1) Width 325 (12.8) Depth 381 (15)	1663 (65.5) 325 (12.8) 381 (15)	1978 (77.9) 420 (16.5) 386 (15.2)	2284 (89.9) 420 (16.5) 406 (16)
Maximum weight [kg (lb)]	116 (256)	129 (284)	200 (441)	225 (496)

The drive is designed for industrial and commercial environments in accordance with local laws and standards. Depending on configuration, the drive can be used in standalone applications or form part of a larger system or installation.

NOTICE

In a residential environment, this product can cause radio interference, in which case supplementary mitigation measures can be required.

FORESEEABLE MISUSE

Do not use the drive in applications which are non-compliant with specified operating conditions and environments. Ensure compliance with the conditions specified in “Specifications” on page 80.


Power Ratings, Weight, and Dimensions

For enclosure sizes and power ratings of the drives, refer to Tables 1 and 2. For more dimensions, “Enclosure Dimensions” on page 90.

Interior View of D1h Drive

Figure 2 shows the D1h components relevant to installation and commissioning. The D1h drive interior is similar to that of the

D3h, D5h, and D6h drives. Drives with the contactor option also contain a contactor terminal block (TB6). For the location of TB6, see “Terminal Dimensions” on page 25.




1	LCP (local control panel)	6	Mounting holes
2	Control terminals	7	Relays 1 and 2
3	Mains input terminals 91 (L1), 92 (L2), 93 (L3)	8	Motor output terminals 96 (U), 97 (V), 98 (W)
4	Ground terminals for IP21/54 (Type 1/12)	9	Cable clamps
5	Lifting ring	10	Ground terminals for IP20 (Chassis)

Fig. 2 — Interior View of D1h Drive (similar to D3h/D5h/D6h)

Interior View of D2h Drive

Figure 3 shows the D2h components relevant to installation and commissioning. The D2h drive interior is similar to that of the D4h, D7h, and D8h drives. Drives with the contactor option also

contain a contactor terminal block (TB6). For the location of TB6, see “Terminal Dimensions” on page 25.




1	Fieldbus top entry kit (optional)	7	Mounting hole
2	LCP (local control panel)	8	Relays 1 and 2
3	Control terminals	9	Terminal block for anti-condensation heater (optional)
4	Mains input terminals 91 (L1), 92 (L2), 93 (L3)	10	Motor output terminals 96 (U), 97 (V), 98 (W)
5	Cable clamps	11	Ground terminals for IP21/54 (Type 1/12)
6	Lifting ring	12	Ground terminals for IP20 (Chassis)

Fig. 3 — Interior View of D2h Drive (Similar to D4h/D7h/D8h)

View of Control Shelf

The control shelf holds the keypad, known as the local control panel or LCP. The control shelf also includes the control terminals, relays, and various connectors. See Fig. 4.



1	Local control panel (LCP)	7	Mounting holes
2	RS485 termination switch	8	LCP connector
3	USB connector	9	Analog switches (A53, A54)
4	RS485 fieldbus connector	10	Analog I/O connector
5	Digital I/O and 24 V supply	11	Relay 1 (01, 02, 03) on power card
6	Lifting rings	12	Relay 2 (04, 05, 06) on power card

Fig. 4 — View of Control Shelf

Extended Options Cabinets

If a drive is ordered with any of the following options, it is supplied with an extended options cabinet to contain the optional components.

- Brake chopper.
- Mains disconnect.
- Contactor.
- Mains disconnect with contactor.
- Circuit breaker.
- Regeneration terminals.
- Load sharing terminals.
- Oversized wiring cabinet.
- Multiwire kit.

Figure 5 shows an example of a drive with an options cabinet. Table 3 lists the variants of the drive that include these options.


Table 3 — Overview of Extended Options

Drive model	Possible options
D5h	Brake, disconnect
D6h	Contactor, contactor with disconnect, circuit breaker
D7h	Brake, disconnect, multiwire kit
D8h	Contactor, contactor with disconnect, circuit breaker, multiwire kit

The D7h and D8h drives include a 200 mm (7.9 in.) pedestal for floor mounting.

There is a safety latch on the front cover of the options cabinet. If the drive includes a mains disconnect or circuit breaker, the safety latch locks the cabinet door while the drive is energized. Before opening the door, open the disconnect or circuit breaker to de-energize the drive, and remove the cover of the options cabinet.

For drives purchased with a disconnect, contactor or circuit breaker, the nameplate label includes a type code for a replacement drive that does not include the options. If the drive is replaced, it can be replaced independently of the options cabinet.



e30bg830.10

Fig. 5 — Drive with Extended Options Cabinet (D7h)

Local Control Panel (LCP)

The local control panel (LCP) is the combined display and keypad on the front of the drive. The term LCP refers to the graphical LCP. A numeric local control panel (NLCP) is available as an option. The NLCP operates in a manner similar to the LCP, but there

are differences. For details on how to use the NLCP, see the product-specific programming guide.

Use the LCP to:

- Control the drive and motor.
- Access drive parameters and program the drive.
- Display operational data, drive status, and warnings.




Fig. 6 — Graphical Local Control Panel (LCP)

A. Display area

Each display readout has a parameter associated with it. See Table 4. The information shown on the LCP can be customized for specific applications. Refer to “Q1 My Personal Menu” on page 10.

Table 4 — LCP Display Area

Callout	Parameter	Default setting
A1.1	Parameter 0-20 Display Line 1.1 Small	Reference [%]
A1.2	Parameter 0-21 Display Line 1.2 Small	Motor current [A]
A1.3	Parameter 0-22 Display Line 1.3 Small	Power [kW]
A2	Parameter 0-23 Display Line 2 Large	Frequency [Hz]
A3	Parameter 0-24 Display Line 3 Large	kWh counter

B. Menu keys

Menu keys are used to access the menu for setting up parameters, toggling through status display modes during normal operation, and viewing fault log data.

Table 5 — LCP Menu Keys

Callout	Key	Function
B1	Status	Shows operational information.
B2	Quick Menu	Allows access to parameters for initial set-up instructions. Also provides detailed application steps. Refer to “Quick Menus” on page 10.
B3	Main Menu	Allows access to all parameters. Refer “Main Menu Mode” on page 11.
B4	Alarm Log	Shows a list of current warnings and the last 10 alarms.

C. Navigation keys

Navigation keys are used for programming functions and moving the display cursor. The navigation keys also provide speed control in local (hand) operation. The display brightness can be adjusted by pressing [Status] and [▲]/[▼] keys.

Table 6 — LCP Navigation Keys

Callout	Key	Function
C1	Back	Reverts to the previous step or list in the menu structure.
C2	Cancel	Cancels the last change or command as long as the display mode has not changed.
C3	Info	Shows a definition of the function being shown.
C4	OK	Accesses parameter groups or enables an option.
C5 ?	▲▼◀▶	Moves between items in the menu.

D. Indicator lights

Indicator lights are used to identify the drive status and to provide a visual notification of warning or fault conditions.

Table 7 — LCP Indicator Lights

Callout	Indicator	Indicator light	Function
D1	On	Green	Activates when the drive receives power from the mains voltage or a 24 V DC external supply.
D2	Warn.	Yellow	Activates when warning conditions are active. Text appears in the display area identifying the problem.
D3	Alarm	Red	Activates during a fault condition. Text appears in the display area identifying the problem.

E. Operation keys and reset

The operation keys are found toward the bottom of the local control panel.

Table 8 — LCP Operation Keys and Reset

Callout	Key	Function
E1	Hand on	Starts the drive in local control. An external stop signal by control input or serial communication overrides the local [Hand On].
E2	Off	Stops the motor but does not remove power to the drive.
E3	Reset	Resets the drive manually after a fault has been cleared.
E4	Auto on	Puts the system in remote operational mode so it can respond to an external start command by control terminals or serial communication.

LCP Menus

QUICK MENUS

The Quick Menus mode provides a list of menus used to configure and operate the drive. Select Quick Menus by pressing the [Quick Menu] key. The resulting readout appears on the LCP display.




Fig. 7 — Quick Menu View

Q1 MY PERSONAL MENU

Use My Personal Menu to determine what is shown in the display area. Refer to “Local Control Panel (LCP)” on page 9. This menu can also show up to 50 pre-programmed parameters. These 50 parameters are manually entered using parameter 0-25 My Personal Menu.

Q2 QUICK SETUP

The parameters found in Q2 Quick Setup contain basic system and motor data that are always necessary for configuring the drive. See “Entering System Information” on page 57 for the set-up procedures.

Q4 SMART SETUP

Q4 Smart Setup guides the user through typical parameter settings used to configure 1 of the following 3 applications:

- Mechanical brake.
- Conveyor.
- Pump/fan.

The [Info] key can be used to display help information for various selections, settings, and messages.

Q5 CHANGES MADE

Select Q5 Changes Made for information about:

- The 10 most recent changes.
- Changes made from default setting.

Q6 LOGGINGS

Use Q6 Loggings for fault finding. To get information about the display line readout, select Loggings. The information is shown as graphs. Only parameters selected in parameter 0-20 Display Line 1.1 Small through parameter 0-24 Display Line 3 Large can be

viewed. It is possible to store up to 120 samples in the memory for later reference.

Table 9 — Logging Parameter Examples

Q6 Loggings	
Parameter 0-20 Display Line 1.1 Small	Reference [%]
Parameter 0-21 Display Line 1.2 Small	Motor current [A]
Parameter 0-22 Display Line 1.3 Small	Power [kW]
Parameter 0-23 Display Line 2 Large	Frequency [Hz]
Parameter 0-24 Display Line 3 Large	kWh Counter

Q7 MOTOR SETUP

The parameters found in Q7 Motor Setup contain basic and advanced motor data that are always necessary for configuring the drive. This option also includes parameters for encoder set-up.

MAIN MENU MODE

The Main Menu mode lists all the parameter groups available to the drive. Select the Main Menu mode by pressing the [Main Menu] key. The resulting readout appears on the LCP display.




Fig. 8 — Main Menu View

All parameters can be changed in the main menu. Option cards added to the unit enable extra parameters associated with the option device.

MECHANICAL INSTALLATION

Items Supplied

Items supplied may vary according to product configuration.

- Make sure the items supplied and the information on the nameplate correspond to the order confirmation. Figures 9 and 10 show sample nameplates for a D-sized drive either with or without an options cabinet.
- Check the packaging and the drive visually for damage caused by inappropriate handling during shipment. File any claim for damage with the carrier. Retain damaged parts for clarification.





Fig. 9 — Example Nameplate for Drive Only (D1h-D4h)



1	Type code
2	Part number and serial number
3	Power rating
4	Input voltage, frequency, and current
5	Output voltage, frequency, and current
6	Discharge time

Fig. 10 — Example Nameplate for Drive with Options Cabinet (D5h-D8h)

NOTICE

LOSS OF WARRANTY

Do not remove the nameplate from the drive. Removing the nameplate can result in loss of warranty.

Tools Needed

Receiving/unloading

- I-beam and hooks rated to lift the weight of the drive. Refer to “Power Ratings, Weight, and Dimensions” on page 4.
- Crane or other lifting aid to place the unit into position.

Installation

- Drill with 10 mm (0.39 in.) or 12 mm (0.47 in.) drill bits.
- Tape measurer.
- Various sizes of Phillips and flat bladed screwdrivers.
- Wrench with relevant metric sockets (7-17 mm/0.28-0.67 in.).
- Wrench extensions.
- Torx drives (T25 and T50).
- Sheet metal punch for conduits or cable glands.
- I-beam and hooks to lift the weight of the drive. Refer to “Power Ratings, Weight, and Dimensions” on page 4.
- Crane or other lifting aid to place the drive onto pedestal and into position.

Storage

Store the drive in a dry location. Keep the equipment sealed in its packaging until installation. Refer to “Ambient Conditions” on page 86 for recommended ambient temperature.

Periodic forming (capacitor charging) is not necessary during storage unless storage exceeds 12 months.

Operating Environment

NOTICE

In environments with airborne liquids, particles, or corrosive gases, ensure that the IP/type rating of the equipment matches the installation environment. Failure to meet requirements for ambient conditions can reduce the lifetime of the drive. Ensure that requirements for humidity, temperature, and altitude are met.

Table 10 — Installation at High Altitudes

Voltage [V]	Altitude restrictions
200-240	At altitudes above 3000 m (9842 ft), contact Carrier regarding PELV.
380-480	At altitudes above 3000 m (9842 ft), contact Carrier regarding PELV.
525-690	At altitudes above 2000 m (6562 ft), contact Carrier regarding PELV.

For detailed ambient conditions specifications, refer to “Ambient Conditions” on page 86.

NOTICE

CONDENSATION

Moisture can condense on the electronic components and cause short circuits. Avoid installation in areas subject to frost. Install an optional space heater when the drive is colder than the ambient air. Operating in standby mode reduces the risk of condensation as long as the power dissipation keeps the circuitry free of moisture.

NOTICE

EXTREME AMBIENT CONDITIONS

Hot or cold temperatures compromise unit performance and longevity.

- Do not operate in environments where the ambient temperature exceeds 55°C (131°F).
- The drive can operate at temperatures down to -10°C (14°F). However, proper operation at rated load is only guaranteed at 0°C (32°F) or higher.
- If temperature exceeds ambient temperature limits, extra air conditioning of the cabinet or installation site is required.

GASES

Aggressive gases, such as hydrogen sulfide, chlorine, or ammonia can damage the electrical and mechanical components. The unit uses conformal-coated circuit boards to reduce the effects of aggressive gases. For conformal coating class specifications and ratings, see “Ambient Conditions” on page 86.

DUST

When installing the drive in dusty environments, pay attention to the following:

Periodic maintenance

When dust accumulates on electronic components, it acts as a layer of insulation. This layer reduces the cooling capacity of the components, and the components become warmer. The hotter environment decreases the life of the electronic components.

Keep the heat sink and fans free from dust buildup. For more service and maintenance information, refer to “Maintenance, Diagnostics, and Troubleshooting” on page 67.

Cooling fans

Fans provide airflow to cool the drive. When fans are exposed to dusty environments, the dust can damage the fan bearings and cause premature fan failure. Also, dust can accumulate on fan blades causing an imbalance which prevents the fans from properly cooling the unit.

POTENTIALLY EXPLOSIVE ATMOSPHERES

WARNING

EXPLOSIVE ATMOSPHERE

Do not install the drive in a potentially explosive atmosphere. Install the unit in a cabinet outside of this area. Failure to follow this guideline increases risk of death or serious injury.

Systems operated in potentially explosive atmospheres must fulfill special conditions. EU Directive 94/9/EC (ATEX 95) classifies the operation of electronic devices in potentially explosive atmospheres.

- Class d specifies that if a spark occurs, it is contained in a protected area.

- Class e prohibits any occurrence of a spark.

Motors with class d protection

Do not require approval. Special wiring and containment are required.

Motors with class e protection

When combined with an ATEX-approved PTC monitoring device like the CAR102 PTC Thermistor Card MCB 112, the installation does not need an individual approval from an apporobated organization.

Motors with class d/e protection

The motor itself has an e ignition protection class, while the motor cabling and connection environment is in compliance with the d classification. To attenuate the high peak voltage, use a sine-wave filter at the drive output.

When using a drive in a potentially explosive atmosphere, use the following:

- Motors with ignition protection class d or e.
- PTC temperature sensor to monitor the motor temperature.
- Short motor cables.
- Sine-wave output filters when shielded motor cables are not used.

NOTICE

MOTOR THERMISTOR SENSOR MONITORING
Drives with the CAR102 PTC Thermistor Card MCB 112 option are PTB-certified for potentially explosive atmospheres.

Installation and Cooling Requirements

NOTICE

MOUNTING PRECAUTIONS

Improper mounting can result in overheating and reduced performance. Observe all installation and cooling requirements.

Installation requirements

- Ensure unit stability by mounting vertically to a solid flat surface.
- Ensure that the strength of the mounting location supports the unit weight. Refer to “Power Ratings, Weight, and Dimensions” on page 4.
- Ensure that the mounting location allows access to open the enclosure door. See “Enclosure Dimensions” on page 90.
- Ensure that there is adequate space around the unit for cooling airflow.
- Place the unit as near to the motor as possible. Keep the motor cables as short as possible. See “Cable Specifications” on page 86.
- Ensure that the location allows for cable entry at the bottom of the unit.

Cooling and airflow requirements

- Ensure that top and bottom clearance for air cooling is provided. Clearance requirement: 225 mm (9 in).
- Consider derating for temperatures starting between 45°C (113°F) and 50°C (122°F) and elevation 1000 m (3300 ft) above sea level. See the product-specific design guide for detailed information.

The drive uses back-channel cooling to circulate the heat sink cooling air. The cooling duct carries approximately 90% of the heat out of the back channel of the drive. Redirect the back-channel air from the panel or room by using:

- Duct cooling. Back-channel cooling kits are available to direct the air away from the panel when an IP20/chassis drive is installed in a Rittal enclosure. Use of a kit reduces the heat in the panel and smaller door fans can be specified on the enclosure.
- Cooling out the back (top and base covers). The back-channel cooling air can be ventilated out of the room so that the heat from the back channel is not dissipated into the control room.

NOTICE

One or more door fans are required on the enclosure to remove heat not contained in the back channel of the drive. The fans also remove any additional losses generated by other components inside the drive.

Ensure that the fans supply adequate airflow over the heat sink. To select the appropriate number of fans, calculate the total required airflow. The flow rate is shown in Table 11.

Table 11 — Airflow

ENCLOSURE SIZE	DOOR FAN/ TOP FAN	POWER SIZE	HEAT SINK FAN
D1H/D3H/D5H/ D6H	102 m ³ /hr (60 CFM)	90-110 kW, 380-480 V	420 m ³ /hr (250 CFM)
		75-132 kW, 525-690 V	420 m ³ /hr (250 CFM)
		132 kW, 380-480 V	840 m ³ /hr (500 CFM)
		All, 200-240 V	840 m ³ /hr (500 CFM)
D2h/D4h/D7h/ D8h	204 m ³ /hr (120 CFM)	160 kW, 380-480 V	420 m ³ /hr (250 CFM)
		160 kW, 525-690 V	420 m ³ /hr (250 CFM)
		All, 200-240 V	840 m ³ /hr (500 CFM)

Lifting the Drive

Always lift the drive using the dedicated eye bolts at the top of the drive. See Fig. 11.

WARNING

HEAVY LOAD

Unbalanced loads can fall or tip over. Failure to take proper lifting precautions increases risk of death, serious injury, or equipment damage.

- Move the unit using a hoist, crane, forklift, or other lifting device with the appropriate weight rating. See “Power Ratings, Weight, and Dimensions” on page 4 for the weight of the drive.
- Failure to locate the center of gravity and correctly position the load can cause unexpected shifting during lifting and transport. For measurements and center of gravity, see “Enclosure Dimensions” on page 90.
- The angle from the top of the drive module to the lifting cables affects the maximum load force on the cable. This angle must be 65° or greater. Refer to Fig. 11. Attach and dimension the lifting cables properly.
- Never walk under suspended loads.
- To guard against injury, wear personal protective equipment such as gloves, safety glasses, and safety shoes.





Fig. 11 — Lifting the Drive

130BE566.11




e30bg284.10

1	Cable entry hole
2	Metal gland plate

Fig. 12 — Cable Openings in Sheet Metal Gland Plate

130BF662.10




1	Plastic tabs
2	Tabs removed for cable access

Fig. 13 — Cable Openings in Plastic Gland Plate

ATTACHING THE DRIVE TO THE PEDESTAL

To install a standard pedestal, use the following steps. To install an optional pedestal kit, refer to the instructions that shipped with the kit. See Fig. 14.

1. Unfasten 4 M5 screws, and remove the pedestal front cover plate.
2. Secure 2 M10 nuts over the threaded studs at the back of the pedestal, securing it to the drive back channel.
3. Fasten 2 M5 screws through the back flange of the pedestal into the pedestal mounting bracket on the drive.
4. Fasten 4 M5 screws through the front flange of the pedestal and into the gland plate mounting holes.



1	Pedestal wall spacer	6	Back flange of pedestal
2	Fastener slots	7	M5 screw (fasten through back flange)
3	Mounting flange at drive top	8	Front flange of pedestal
4	Mounting holes	9	Front cover plate of pedestal
5	M10 nuts (fasten to threaded posts)	10	M5 screw (fasten through front flange)

Fig. 14 — Pedestal Installation in D7h/D8h Drives

FLOOR MOUNTING THE DRIVE

To secure the pedestal to the floor (after attaching the drive to the pedestal), use the following steps.

1. Fasten 4 M10 bolts in the mounting holes at the bottom of the pedestal, securing it to the floor. See Fig. 15.
2. Reposition the pedestal front cover plate, and fasten with 4 M5 screws. See Fig. 14.
3. Slide the pedestal wall spacer behind the mounting flange at the top of the drive. See Fig. 14.
4. Fasten 2-4 M10 bolts in the mounting holes at the top of the drive, securing it to the wall. Use 1 bolt for each mounting hole. The number varies with enclosure size. See Fig. 14.




Fig. 15 — Pedestal-to-floor Mounting Holes

WALL MOUNTING THE DRIVE

To wall mount a drive, use the following steps. Refer to Fig. 16.

1. Fasten 2 M10 bolts in the wall to align with the fastener slots at the bottom of drive.
2. Slide the fastener slots over the M10 bolts.
3. Tip the drive against the wall, and secure the top with 2 M10 bolts in the mounting holes.




Fig. 16 — Drive-to-wall Mounting Holes

ELECTRICAL INSTALLATION

Safety Instructions

See "Safety" on page 2 for general safety instructions.

WARNING

INDUCED VOLTAGE

Induced voltage from output motor cables from different drives that are run together can charge equipment capacitors even with the equipment turned off and locked out. Failure to run output motor cables separately or use shielded cables could result in death or serious injury.

- Run output motor cables separately or use shielded cables.
- Simultaneously lock out all the drives.

WARNING

SHOCK HAZARD

The drive can cause a DC current in the ground conductor and thus result in death or serious injury.

- When a residual current-operated protective device (RCD) is used for protection against electrical shock, only an RCD of Type B is allowed on the supply side.

Failure to follow the recommendation means that the RCD cannot provide the intended protection.

OVERCURRENT PROTECTION

- Additional protective equipment such as short-circuit protection or motor thermal protection between drive and motor is required for applications with multiple motors.
- Input fusing is required to provide short circuit and overcurrent protection. If fuses are not factory-supplied, the installer must provide them. See maximum fuse ratings in "Fuses and Circuit Breakers" on page 88.

WIRE TYPE AND RATINGS

- All wiring must comply with local and national regulations regarding cross-section and ambient temperature requirements.
- Power connection wire recommendation: Minimum 75°C (167°F) rated copper wire.

See "Cable Specifications" on page 86 for recommended wire sizes and types.

CAUTION

PROPERTY DAMAGE

Protection against motor overload is not included in the default setting. To add this function, set parameter 1-90 Motor Thermal Protection to [ETR trip] or [ETR warning]. For the North American market, the ETR function provides class 20 motor overload protection in accordance with NEC. Failure to set parameter 1-90 Motor Thermal Protection to [ETR trip] or [ETR warning] means that motor overload protection is not provided and, if the motor overheats, property damage can occur.

EMC-compliant Installation

To obtain an EMC-compliant installation, follow the instructions provided in:

- "Wiring Schematic" on page 19
- "Connecting to Ground" on page 20
- "Connecting the Motor" on page 21
- "Connecting the AC Mains" on page 22

NOTICE

TWISTED SHIELD ENDS (PIGTAILS)

Twisted shield ends (pigtails) increase the shield impedance at higher frequencies, reducing the shield effect and increasing the leakage current. To avoid twisted shield ends, use integrated shield clamps.

- For use with relays, control cables, a signal interface, field-bus, or brake, connect the shield to the enclosure at both ends. If the ground path has high impedance, is noisy, or is carrying current, break the shield connection on 1 end to avoid ground current loops.
- Convey the currents back to the unit using a metal mounting plate. Ensure good electrical contact from the mounting plate through the mounting screws to the drive chassis.
- Use shielded cables for motor output cables. An alternative is unshielded motor cables within metal conduit.

NOTICE

SHIELDED CABLES

If shielded cables or metal conduits are not used, the unit and the installation do not meet regulatory limits on radio frequency (RF) emission levels.

- Ensure that motor and brake cables are as short as possible to reduce the interference level from the entire system.
- Avoid placing cables with a sensitive signal level alongside motor and brake cables.
- For communication and command/control lines, follow the particular communication protocol standards. Carrier recommends use of shielded cables.
- Ensure that all control terminal connections are PELV.

NOTICE

EMC INTERFERENCE

Use separate shielded cables for motor and control wiring, and separate cables for mains wiring, motor wiring, and control wiring. Failure to isolate power, motor, and control cables can result in unintended behavior or reduced performance. Minimum 200 mm (7.9 in.) clearance between mains, motor, and control cables is required.

NOTICE

INSTALLATION AT HIGH ALTITUDE


There is a risk of overvoltage. Isolation between components and critical parts could be insufficient, and not comply with PELV requirements. Reduce the risk of overvoltage by using external protective devices or galvanic isolation.

For installations above 2000 m (6500 ft) altitude, contact Carrier regarding PELV compliance.

NOTICE

PELV COMPLIANCE


Prevent electric shock by using protective extra low voltage (PELV) electrical supply and complying with local and national PELV regulations.



1	PLC	10	Mains cable (unshielded)
2	Minimum 16 mm ² (6 AWG) equalizing cable	11	Output contactor and similar options
3	Control cables	12	Cable insulation stripped
4	Required minimum separation of 200 mm (7.9 in.) between control cables, motor cables, and mains cables	13	Common ground busbar (Follow local and national requirements for enclosure grounding)
5	Mains supply	14	Brake resistor
6	Bare (unpainted) surface	15	Metal box
7	Star washers	16	Connection to motor
8	Brake cable (shielded)	17	Motor
9	Motor cable (shielded)	18	EMC cable gland

Fig. 17 — Example of Proper EMC Installation

Wiring Schematic



1) TB6 contactor is found only in D6h and D8h drives with a contactor option.

2) Terminal 37 (optional) is used for Safe Torque Off.

Fig. 18 — Basic Wiring Schematic

Connecting to Ground

⚠ WARNING

LEAKAGE CURRENT HAZARD

Leakage currents exceed 3.5 mA. Failure to ground the drive properly can result in death or serious injury.

- Ensure the correct grounding of the equipment by a certified electrical installer.

FOR ELECTRICAL SAFETY

- Ground the drive in accordance with applicable standards and directives.
- Use a dedicated ground wire for input power, motor power, and control wiring.
- Do not ground 1 drive to another in a daisy chain fashion.
- Keep the ground wire connections as short as possible.
- Follow motor manufacturer wiring requirements.

- Minimum cable cross-section: 10 mm² (6 AWG) (or 2 rated ground wires terminated separately).

- Tighten the terminals in accordance with the information provided in “Fastener Tightening Torques” on page 89.

FOR EMC-COMPLIANT INSTALLATION

- Establish electrical contact between the cable shield and the drive enclosure by using metal cable glands or by using the clamps provided on the equipment.
- Reduce burst transient by using high-strand wire.
- Do not use twisted shield ends (pigtails).

NOTICE

POTENTIAL EQUALIZATION

There is a risk of burst transient when the ground potential between the drive and the control system is different. Install equalizing cables between the system components. Recommended cable cross-section: 16 mm² (5 AWG).




Fig. 19 — Ground Terminals (D1h shown)

Connecting the Motor

⚠ WARNING

INDUCED VOLTAGE

Induced voltage from output motor cables that run together can charge equipment capacitors, even with the equipment turned off and locked out. Failure to run output motor cables separately or use shielded cables could result in death or serious injury.

- Comply with local and national electrical codes for cable sizes. For maximum wire sizes, see “Cable Specifications” on page 86.
- Follow motor manufacturer wiring requirements.
- Motor wiring knockouts or access panels are provided at the base of IP21 (NEMA1/12) and higher units.

- Do not wire a starting or pole-changing device (for example Dahlander motor or slip ring asynchronous motor) between the drive and the motor.

Procedure

1. Strip a section of the outer cable insulation.
2. Position the stripped wire under the cable clamp, establishing mechanical fixation and electrical contact between the cable shield and ground.
3. Connect the ground wire to the nearest grounding terminal in accordance with the grounding instructions provided in “Connecting to Ground” on page 20. See Fig. 20.
4. Connect the 3-phase motor wiring to terminals 96 (U), 97 (V), and 98 (W). See Fig. 20.
5. Tighten the terminals in accordance with the information provided in “Fastener Tightening Torques” on page 89.




Fig. 20 — Motor Terminals (D1h shown)

Connecting the AC Mains

- Size the wiring according to the input current of the drive. For maximum wire sizes, see “Electrical Data” on page 80.
- Comply with local and national electrical codes for cable sizes.

Procedure

1. Strip a section of the outer cable insulation.
2. Position the stripped wire under the cable clamp, establishing mechanical fixation and electrical contact between the cable shield and ground.
3. Connect the ground wire to the nearest grounding terminal in accordance with the grounding instructions provided in “Connecting to Ground” on page 20.

4. Connect the 3-phase AC input power wiring to terminals R, S, and T. See Fig. 21.
5. Tighten the terminals in accordance with the information provided in “Fastener Tightening Torques” on page 89.
6. When supplied from an isolated mains source (IT mains or floating delta) or TT/TN-S mains with a grounded leg (grounded delta), ensure that parameter 14-50 RFI Filter is set to [0] Off to avoid damage to the DC link and to reduce ground capacity currents.

NOTICE

OUTPUT CONTACTOR

Carrier does not recommend using an output contactor on 525-690 V drives that are connected to an IT mains network.




Fig. 21 — AC Mains Terminals (D1h shown). For a detailed view of terminals, see “Terminal Dimensions” on page 25.

e30bg267.10


Connecting Regen/Load Share Terminals

The optional regeneration/load share terminals are found at the top of the drive. For drives with IP21/IP54 enclosures, the wiring is routed through a cover surrounding the terminals. Refer to Fig. 21.

- Size the wiring according to the current of the drive. For maximum wire sizes, see “Electrical Data” on page 80.
- Comply with local and national electrical codes for cable sizes.

Procedure

1. Remove 2 plugs (for either top entry or side entry) from the terminal cover.
2. Insert cable fittings into the terminal cover holes.
3. Strip a section of the outer cable insulation.
4. Position the stripped cable through the fittings.
5. Connect the DC (+) cable to the DC (+) terminal, and secure with 1 M10 fastener.
6. Connect the DC (-) cable to the DC (-) terminal, and secure with 1 M10 fastener.
7. Tighten the terminals in accordance with “Fastener Tightening Torques” on page 89.




1	Top openings for regen/load share terminals	7	DC(+) terminal
2	Terminal cover	8	DC(−) terminal
3	Side opening for regen/load share terminals	9	Hole for M10 fastener
4	Top view	10	Close-up view
5	Side view	11	Regen/load share terminals
6	View without cover	12	Front view

Fig. 22 — Regen/Load Share Terminals in Enclosure Size D

Terminal Dimensions





D1H TERMINAL DIMENSIONS



1	Mains terminals	3	Motor terminals
2	Ground terminals	—	—

Fig. 23 — D1h Terminal Dimensions (Front View)

130BF342.10




1 Mains terminals

2 Motor terminals


Fig. 24 — D1h Terminal Dimensions (Side Views)

D2H TERMINAL DIMENSIONS



130BF345.10

Fig. 25 — D2h Terminal Dimensions (Front View)




1 Mains terminals

2 Motor terminals

Fig. 26 — D2h Terminal Dimensions (Side Views)



D3H TERMINAL DIMENSIONS



130BF341.10

Fig. 27 — D3h Terminal Dimensions (Front View)


1	Mains terminals	3	Motor terminals
2	Brake terminals	4	Ground terminals



1 and 6	Bottom brake/regen terminals	3 and 5	Mains terminals
2 and 7	Brake terminals	4	Ground terminals

Fig. 28 — D3h Terminal Dimensions (Side Views)


D4H TERMINAL DIMENSIONS



130BF34710

1	Mains terminals	3	Motor terminals
2	Brake terminals	4	Ground terminals


Fig. 29 — D4h Terminal Dimensions (Front View)



1 and 6	Brake/regen terminals	3 and 5	Mains terminals
2 and 7	Motor terminals	4	Ground terminals


Fig. 30 — D4h Terminal Dimensions (Side Views)

D5H TERMINAL DIMENSIONS




130BE349.10

Fig. 31 — D5h Terminal Dimensions with Disconnect Option (Front View)



1	Mains terminals	3	Motor terminals
2	Brake terminals	—	—


Fig. 32 — D5h Terminal Dimensions with Disconnect Option (Side Views)



130BF351.10

1	Mains terminals	3	Motor terminals
2	Brake terminals	4	Ground terminals


Fig. 33 — D5h Terminal Dimensions with Brake Option (Front View)



1	Brake terminals	3	Motor terminals
2	Mains terminals	—	—


Fig. 34 — D5h Terminal Dimensions with Brake Option (Side Views)

D6H TERMINAL DIMENSIONS




1	Mains terminals	4	Brake terminals
2	Ground terminals	5	Motor terminals
3	TB6 terminal block for contactor	—	—

Fig. 35 — D6h Terminal Dimensions with Contactor Option (Front View)




1	Mains terminals	3	Motor terminals
2	Brake terminals	—	—

Fig. 36 — D6h Terminal Dimensions with Contactor Option (Side Views)




1	Mains terminals	4	Brake terminals
2	Ground terminals	5	Motor terminals
3	TB6 terminal block for contactor	—	—

Fig. 37 — D6h Terminal Dimensions with Contactor and Disconnect Options (Front View)




1	Brake terminals	3	Motor terminals
2	Mains terminals	—	—

Fig. 38 — D6h Terminal Dimensions with Contactor and Disconnect Options (Side Views)



1	Mains terminals	3	Brake terminals
2	Ground terminals	4	Motor terminals


Fig. 39 — D6h Terminal Dimensions with Circuit Breaker Option (Front View)



1	Mains terminals	3	Motor terminals
2	Brake terminals	—	—


Fig. 40 — D6h Terminal Dimensions with Circuit Breaker Option (Side Views)

D7H TERMINAL DIMENSIONS




130BF359.10

Fig. 41 — D7h Terminal Dimensions with Disconnect Option (Front View)




1	Mains terminals	3	Motor terminals
2	Brake terminals	—	—

Fig. 42 — D7h Terminal Dimensions with Disconnect Option (Side Views)



1	Mains terminals	3	Brake terminals
2	Ground terminals	4	Motor terminals


Fig. 43 — D7h Terminal Dimensions with Brake Option (Front View)



1	Brake terminals	3	Motor terminals
2	Mains terminals	—	—


Fig. 44 — D7h Terminal Dimensions with Brake Option (Side Views)

D8H TERMINAL DIMENSIONS




1	Mains terminals	4	TB6 terminal block for contactor
2	Brake terminals	5	Motor terminals
3	Ground terminals	—	—

Fig. 45 — D8h Terminal Dimensions with Contactor Option (Front View)




1	Mains terminals	2	Motor terminals
2	Brake terminals	—	—

Fig. 46 — D8h Terminal Dimensions with Contactor Option (Side Views)



1	Mains terminals	4	TB6 terminal block for contactor
2	Brake terminals	5	Motor terminals
3	Ground terminals	—	—


Fig. 47 — D8h Terminal Dimensions with Contactor and Disconnect Options (Front View)



130BF370.10


1	Mains terminals	3	Motor terminals
2	Brake terminals	—	—

Fig. 48 — D8h Terminal Dimensions with Contactor and Disconnect Options (Side View)



1	Mains terminals	3	Ground terminals
2	Brake terminals	4	Motor terminals

Fig. 49 — D8h Terminal Dimensions with Circuit Breaker Option (Front View)



1	Mains terminals	3	Motor terminals
2	Brake terminals	—	—

Fig. 50 — D8h Terminal Dimensions with Circuit Breaker Option (Side View)

Control Wiring

All terminals to the control cables are inside the drive below the LCP. To access the control terminals, either open the door (D1h/D2h/D5h/D6h/D7h/D8h) or remove the front panel (D3h/D4h).

CONTROL CABLE ROUTING

- Isolate control wiring from high-power components in the drive.
- Tie down all control wires after routing them.
- Connect shields to ensure optimum electrical immunity.
- When the drive is connected to a thermistor, ensure that the thermistor control wiring is shielded and reinforced/double insulated. A 24 V DC supply voltage is recommended.

Fieldbus connection

Connections are made to the relevant options on the control card. For more detail, see the relevant fieldbus instruction. The cable must be tied down and routed along with other control wires inside the unit.

CONTROL TERMINAL TYPES

Figure 51 shows the removable drive connectors. Terminal functions and default settings are summarized in Tables 12-14.





Fig. 51 — Control Terminal Locations



1	Serial communication terminals
2	Digital input/output terminals
3	Analog input/output terminals

Fig. 52 — Terminal Numbers Located on the Connectors

Table 12 — Serial Communication Terminal Descriptions

Terminal	Parameter	Default setting	Description
61	-	-	Integrated RC-filter for cable shield. ONLY for connecting the shield to correct EMC problems.
68 (+)	Parameter group 8-3* FC Port Settings	-	RS485 interface. A switch (BUS TER.) is provided on the control card for bus termination resistance. See Fig. 20.
69 (-)	Parameter group 8-3* FC Port Settings	-	

Table 13 — Digital Input/Output Terminal Descriptions

Digital input/output terminals			
Terminal	Parameter	Default setting	Description
12, 13	-	+24 V DC	24 V DC supply voltage for digital inputs and external transducers. Maximum output current 200 mA for all 24 V loads.
18	Parameter 5-10 Terminal 18 Digital Input	[8] Start	Digital inputs.
19	Parameter 5-11 Terminal 19 Digital Input	[10] Reversing	
32	Parameter 5-14 Terminal 32 Digital Input	[0] No operation	
33	Parameter 5-15 Terminal 33 Digital Input	[0] No operation	
27	Parameter 5-12 Terminal 27 Digital Input	[2] Coast inverse	
29	Parameter 5-13 Terminal 29 Digital Input	[14] JOG	
20	-	-	For digital input or output. Default setting is input.
37	-	STO	Common for digital inputs and 0 V potential for 24 V supply. When not using the optional STO feature, a jumper wire is required between terminal 12 (or 13) and terminal 37. This set-up allows the drive to operate with factory default programming values.

Table 14 — Analog Input/Output Terminal Descriptions

Analog input/output terminals			
Terminal	Parameter	Default setting	Description
39	-	-	Common for analog output.
42	Parameter 6-50 Terminal 42 Output	[0] No operation	Programmable analog output. 0-20 mA or 4-20 mA at a maximum of 500 Ω .
50	-	+10 V DC	10 V DC analog supply voltage for potentiometer or thermistor. 15 mA maximum.
53	Parameter group 6-1* Analog Input 1	Reference	Analog input. For voltage or current. Switches A53 and A54 select mA or V.
54	Parameter group 6-2* Analog Input 2	Feedback	
55	-	-	Common for analog input.

WIRING TO CONTROL TERMINALS

The control terminals are located near the LCP. The control terminal connectors can be unplugged from the drive for convenience when wiring, as shown in Fig. 51.

Either solid or flexible wire can be connected to the control terminals. Use the following procedures to connect or disconnect the control wires.

NOTICE

Minimize interference by keeping control wires as short as possible and separate from high-power cables.

Connecting wire to control terminals

1. Strip 10 mm (0.4 in.) of the outer plastic layer from the end of the wire.
2. Insert the control wire into the terminal.
3. For a solid wire, push the bare wire into the contact. See Fig. 53.
4. For a flexible wire, open the contact by inserting a small screwdriver into the slot between the terminal holes and push the screwdriver inward. See Fig. 54. Then, insert the stripped wire into the contact, and remove the screwdriver.
5. Pull gently on the wire to ensure that the contact is firmly established. Loose control wiring can be the source of equipment faults or reduced performance.




Fig. 53 — Connecting Solid Control Wires




Fig. 54 — Connecting Flexible Control Wires

Disconnecting wires from the control terminals

1. To open the contact, insert a small screwdriver into the slot between the terminal holes and push the screwdriver inward.
2. Pull gently on the wire to free it from the control terminal contact.

See “Cable Specifications” on page 86 for control terminal wiring sizes and “Wiring Configuration Examples” on page 60 for typical control wiring connections.

ENABLING MOTOR OPERATION (TERMINAL 27)

A jumper wire is required between terminal 12 (or 13) and terminal 27 for the drive to operate when using factory default programming values.

- Digital input terminal 27 is designed to receive 24 V DC external interlock command.
- When no interlock device is used, wire a jumper between control terminal 12 (recommended) or 13 to terminal 27. This wire provides an internal 24 V signal on terminal 27.
- When the status line at the bottom of the LCP reads AUTO REMOTE COAST, the unit is ready to operate, but is missing an input signal on terminal 27.
- When factory-installed optional equipment is wired to terminal 27, do not remove that wiring.

NOTICE

The drive cannot operate without a signal on terminal 27, unless terminal 27 is reprogrammed using parameter 5-12 Terminal 27 Digital Input.

CONFIGURING RS485 SERIAL COMMUNICATION


RS485 is a 2-wire bus interface compatible with multi-drop network topology, and it contains the following features:

- Either FC or Modbus RTU communication protocol, which are internal to the drive, can be used.
- Functions can be programmed remotely using the protocol software and RS485 connection or in parameter group 8-** Communications and Options.
- Selecting a specific communication protocol changes various default parameter settings to match the specifications of the protocol, making more protocol-specific parameters available.
- Option cards for the drive are available to provide more communication protocols. See the option card documentation for installation and operation instructions.
- A switch (BUS TER) is provided on the control card for bus termination resistance. See Fig. 56.

For basic serial communication set-up, perform the following steps:

1. Connect RS485 serial communication wiring to terminals (+)68 and (-)69.

- a. Use shielded serial communication cable (recommended).
- b. See “Connecting to Ground” on page 20 for proper grounding.
2. Select the following parameter settings:
 - a. Protocol type in parameter 8-30 Protocol.
 - b. Drive address in parameter 8-31 Address.
 - c. Baud rate in parameter 8-32 Baud Rate.



130BB489.10

Fig. 55 — Serial Communication Wiring Diagram

WIRING SAFE TORQUE OFF (STO)

The Safe Torque Off (STO) function is a component in a safety control system. STO prevents the unit from generating the voltage required to rotate the motor.

To run STO, more wiring for the drive is required. Refer to Safe Torque Off Operating Guide for further information.

WIRING THE SPACE HEATER

The space heater is an option used to prevent condensation from forming inside the enclosure when the unit is turned off. It is designed to be field wired and controlled by an external system.

Specifications

- Nominal voltage: 100-240
- Wire size: 12-24 AWG

WIRING THE AUXILIARY CONTACTS TO THE DISCONNECT

The disconnect is an option that is installed at the factory. The auxiliary contacts, which are signal accessories used with the disconnect, are not installed at the factory to allow more flexibility during installation. The contacts snap into place without the need for tools.

Contacts must be installed in specific locations on the disconnect depending on their functions. Refer to the datasheet included in the accessory bag that comes with the drive.

Specifications

- U_i [V]: 690
- U_{imp} [kV]: 4
- Pollution degree: 3
- I_{th} [A]: 16
- Cable size: 1...2x0.75...2.5 mm²
- Maximum fuse: 16 A/gG
- NEMA: A600, R300, wire size: 18-14 AWG, 1(2)

WIRING THE BRAKE RESISTOR TEMPERATURE SWITCH

The brake resistor terminal block is found on the power card and allows for the connection of an external brake resistor temperature switch. The switch can be configured as normally closed or normally open. If the input changes, a signal trips the drive and shows

alarm 27, Brake chopper fault on the LCP display. At the same time, the drive stops braking and the motor coasts.


1. Locate the brake resistor terminal block (terminals 104-106) on the power card. See Fig. 5.
2. Remove the M3 screws that hold the jumper to the power card.
3. Remove the jumper and wire the brake resistor temperature switch in 1 of the following configurations:
 - a. Normally closed. Connect to terminals 104 and 106.
 - b. Normally open. Connect to terminals 104 and 105.
4. Secure the switch wires with the M3 screws. Torque to 0.5-0.6 Nm (5 in.-lb).

SELECTING VOLTAGE/CURRENT INPUT SIGNAL


The analog input terminals 53 and 54 allow setting of input signal to voltage (0-10 V) or current (0/4-20 mA).

Default parameter setting:

- Terminal 53: Speed reference signal in open loop (see parameter 16-61 Terminal 53 Switch Setting).
- Terminal 54: Feedback signal in closed loop (see parameter 16-63 Terminal 54 Switch Setting).



1. Remove the LCP. See Fig. 56.
2. Remove any optional equipment covering the switches.
3. Set switches A53 and A54 to select the signal type (U = voltage, I = current).



130BF146.10

Fig. 56 — Location of Terminal 53 and 54 Switches

PRE-START CHECKLIST

Before completing installation of the unit, inspect the entire installation as detailed in Table 15. Check and mark the items when completed.

Table 15 — Pre-start Check List

Inspect for	Description	✓
Motor	<ul style="list-style-type: none"> Confirm continuity of the motor by measuring ohm values on U-V (96-97), V-W (97-98), and W-U (98-96). Confirm that the supply voltage matches the voltage of the drive and the motor. 	
Switches	<ul style="list-style-type: none"> Ensure that all switch and disconnect settings are in the proper positions. 	
Auxiliary equipment	<ul style="list-style-type: none"> Look for auxiliary equipment, switches, disconnects, or input fuses/circuit breakers that reside on the input power side of the drive or output side to the motor. Ensure that they are ready for full-speed operation. Check function and installation of any sensors used for feedback to the drive. Remove any power factor correction caps on motor. Adjust any power factor correction caps on the mains side and ensure that they are dampedened. 	
Cable routing	<ul style="list-style-type: none"> Ensure that motor wiring, brake wiring (if equipped), and control wiring are separated or shielded, or in 3 separate metallic conduits for high-frequency interference isolation. 	
Control wiring	<ul style="list-style-type: none"> Check for broken or damaged wires and loose connections. Check that control wiring is isolated from high-power wiring for noise immunity. Check the voltage source of the signals, if necessary. Use shielded cable or twisted pair and ensure that the shield is terminated correctly. 	
Input and output power wiring	<ul style="list-style-type: none"> Check for loose connections. Check that motor and mains are in separate conduit or separated shielded cables. 	
Grounding	<ul style="list-style-type: none"> Check for good ground connections that are tight and free of oxidation. Grounding to conduit, or mounting the back panel to a metal surface, is not a suitable grounding. 	
Fuses and circuit breakers	<ul style="list-style-type: none"> Check for proper fusing or circuit breakers. Check that all fuses are inserted firmly and are in operational condition and that all circuit breakers (if used) are in the open position. 	
Cooling clearance	<ul style="list-style-type: none"> Look for any obstructions in the airflow path. Measure top and bottom clearance of the drive to verify adequate airflow for cooling, see "Installation and Cooling Requirements" on page 13. 	
Ambient conditions	<ul style="list-style-type: none"> Check that requirements for ambient conditions are met. See "Ambient Conditions" on page 86. Inspect that the unit interior is free of dirt, metal chips, moisture, and corrosion. 	
Interior of the drive	<ul style="list-style-type: none"> Verify that all installation tools have been removed from unit interior. For D3h and D4h enclosures, ensure that the unit is mounted on an unpainted, metal surface. 	
Vibration	<ul style="list-style-type: none"> Check that the unit is mounted solidly, or that shock mounts are used, if necessary. Check for an unusual amount of vibration. 	

COMMISSIONING

Applying Power

⚠ WARNING

UNINTENDED START

When the drive is connected to AC mains, DC supply, or load sharing, the motor can start at any time, causing risk of death, serious injury, and equipment, or property damage. The motor can start by activation of an external switch, a fieldbus command, an input reference signal from the LCP or LOP, via remote operation using MCT 10 Set-up software, or after a cleared fault.

To prevent unintended motor start:

- Press [Off] on the LCP before programming parameters.
- Disconnect the drive from mains whenever personal safety considerations make it necessary to avoid unintended motor start.
- Check that the drive, motor, and any driven equipment are in operational readiness.

NOTICE

MISSING SIGNAL

If the status at the bottom of the LCP reads AUTO REMOTE COASTING, or alarm 60, External interlock is shown, it indicates that the unit is ready to operate but is missing an input signal on, for example, terminal 27. See “Enabling Motor Operation (Terminal 27)” on page 54.

Apply power to the drive using the following steps:

1. Confirm that the input voltage is balanced within 3%. If not, correct the input voltage imbalance before proceeding. Repeat this procedure after the voltage correction.
2. Ensure that any optional equipment wiring matches the installation requirements.
3. Ensure that all operator devices are in the OFF position.
4. Close and securely fasten all covers and doors on the drive.
5. Apply power to the unit, but do not start the drive. For units with a disconnect switch, turn the switch to the ON position to apply power to the drive.

Programming the Drive

PARAMETER OVERVIEW

Parameters contain various settings that are used to configure and operate the drive and motor. These parameter settings are programmed into the local control panel (LCP) through the different LCP menus. For more detail on parameters, see the product-specific programming guide.

Parameter settings are assigned a default value at the factory, but can be configured for their unique application. Each parameter has a name and number that remain the same regardless of the programming mode.

In the Main Menu mode, the parameters are divided into groups. The first digit of the parameter number (from the left) indicates the parameter group number. The parameter group is then broken down into sub-groups, if necessary.

For example:

Table 16 — Example of Parameter Group Hierarchy

0-** Operation/Display	Parameter group
0-0* Basic Settings	Parameter sub-group

Table 16 — Example of Parameter Group Hierarchy

Parameter 0-01 Language	Parameter
Parameter 0-02 Motor Speed Unit	Parameter
Parameter 0-03 Regional Settings	Parameter

PARAMETER NAVIGATION

Use the following LCP keys to navigate through the parameters:

- Press [**▲**] [**▼**] to scroll up or down.
- Press [**◀**] [**▶**] to shift a space to the left or right of a decimal point while editing a decimal parameter value.
- Press [OK] to accept the change.
- Press [Cancel] to disregard the change and exit edit mode.
- Press [Back] twice to show the status view.
- Press [Main Menu] once to go back to the main menu.

ENTERING SYSTEM INFORMATION

NOTICE

SOFTWARE DOWNLOAD

For commissioning via PC, install MCT 10 Set-up Software. The software is available for download (basic version) or for ordering (advanced version, code number 130B1000).

The following steps are used to enter basic system information into the drive. Recommended parameter settings are intended for start-up and checkout purposes. Application settings vary.

NOTICE

Although these steps assume that an asynchronous motor is used, a permanent magnet motor can be used. For more information on specific motor types, see the product-specific programming guide.

1. Press [Main Menu] on the LCP.
2. Select 0-** Operation/Display and press [OK].
3. Select 0-0* Basic Settings and press [OK].
4. Select parameter 0-03 Regional Settings and press [OK].
5. Select [0] International or [1] North America as appropriate and press [OK]. (This action changes the default settings for some basic parameters).
6. Press [Quick Menus] on the LCP and then select 02 Quick Setup.
7. Change the following parameters settings listed in Table 17 if necessary. The motor data is found on the motor nameplate.

Table 17 — Quick Set-up Settings

Parameter	Default setting
Parameter 0-01 Language	English
Parameter 1-20 Motor Power [kW]	4.00 kW
Parameter 1-22 Motor Voltage	400 V
Parameter 1-23 Motor Frequency	50 Hz
Parameter 1-24 Motor Current	9.00 A
Parameter 1-25 Motor Nominal Speed	1420 RPM
Parameter 5-12 Terminal 27 Digital Input	Coast inverse
Parameter 3-02 Minimum Reference	0.000 RPM
Parameter 3-03 Maximum Reference	1500.000 RPM
Parameter 3-41 Ramp 1 Ramp Up Time	3.00 s
Parameter 3-42 Ramp 1 Ramp Down Time	3.00 s
Parameter 3-13 Reference Site	Linked to Hand/Auto
Parameter 1-29 Automatic Motor Adaptation (AMA)	Off

NOTICE

MISSING INPUT SIGNAL

When the LCP shows AUTO REMOTE COASTING or alarm 60, External Interlock, the unit is ready to operate but is missing an input signal. See “Enabling Motor Operation (Terminal 27)” on page 54 for details.

CONFIGURING AUTOMATIC ENERGY OPTIMIZATION

Automatic energy optimization (AEO) is a procedure that minimizes voltage to the motor, reducing energy consumption, heat, and noise.

1. Press [Main Menu].
2. Select 1-** Load and Motor and press [OK].
3. Select 1-0* General Settings and press [OK].
4. Select parameter 1-03 Torque Characteristics and press [OK].
5. Select either [2] Auto Energy Optim CT or [3] Auto Energy Optim VT and press [OK].

CONFIGURING AUTOMATIC MOTOR ADAPTATION

Automatic motor adaptation is a procedure that optimizes compatibility between the drive and the motor.

The drive builds a mathematical model of the motor for regulating output motor current. The procedure also tests the input phase balance of electrical power. It compares the motor characteristics with the data entered in parameters 1-20 to 1-25.

NOTICE

If warnings or alarms occur, see “List of Warnings and Alarms” on page 70. Some motors are unable to run the complete version of the test. In that case, or if an output filter is connected to the motor, select [2] Enable reduced AMA.

Run this procedure on a cold motor for best results.

1. Press [Main Menu].
2. Select 1-** Load and Motor and press [OK].
3. Select 1-2* Motor Data and press [OK].
4. Select parameter 1-29 Automatic Motor Adaptation (AMA) and press [OK].
5. Select [1] Enable complete AMA and press [OK].
6. Press [Hand On] and then [OK]. The test runs automatically and indicates when it is complete.

Testing Before System Start-up

WARNING

MOTOR START

Failure to ensure that the motor, system, and any attached equipment are ready for start can result in personal injury or equipment damage.

Before start,

- Ensure that equipment is safe to operate under any condition.
- Ensure that the motor, system, and any attached equipment are ready for start.

NOTICE

If the motor runs in the wrong direction, it can damage equipment. Before running the unit, check the motor rotation by briefly running the motor. The motor runs briefly at either 5 Hz or the minimum frequency set in parameter 4-12 Motor Speed Low Limit [Hz].

1. Press [Hand On].
2. Move the left cursor to the left of the decimal point by using the left arrow key, and enter an RPM that slowly rotates the motor.
3. Press [OK].
4. If the motor rotation is wrong, set parameter 1-06 Clockwise Direction to [1] Inverse.

ENCODER ROTATION

If encoder feedback is used, perform the following steps:

1. Select [0] Open Loop in parameter 1-00 Configuration Mode.
2. Select [1] 24 V encoder in parameter 7-00 Speed PID Feedback Source.
3. Press [Hand On].
4. Press [▶] for positive speed reference
5. (parameter 1-06 Clockwise Direction at [0] Normal).
6. In parameter 16-57 Feedback [RPM], check that the feedback is positive.

For more information on the encoder option, refer to the option manual.

NOTICE

NEGATIVE FEEDBACK

If the feedback is negative, the encoder connection is wrong. Use either parameter 5-71 Term 32/33 Encoder Direction or parameter 17-60 Feedback Direction to inverse the direction, or reverse the encoder cables. Parameter 17-60 Feedback Direction is only available with the CAR102 Encoder Input MCB 102 option.

System Start-up

WARNING

MOTOR START

Failure to ensure that the motor, system, and any attached equipment are ready for start can result in personal injury or equipment damage.

Before start,

- Ensure that equipment is safe to operate under any condition.
- Ensure that the motor, system, and any attached equipment are ready for start.

The procedure in this section requires user-wiring and application programming to be completed. The following procedure is recommended after application set-up is completed.

1. Press [Auto On].
2. Apply an external run command. Examples of external run commands are a switch, key, or programmable logic controller (PLC).
3. Adjust the speed reference throughout the speed range.

4. Ensure that the system is working as intended by checking sound and vibration level of the motor.
5. Remove the external run command.

If warnings or alarms occur, see “List of Warnings and Alarms” on page 70.

Parameter Setting

NOTICE

REGIONAL SETTINGS

Some parameters have different default settings for international or North America. For a list of the different default values, see “International/North American Default Parameter Settings” on page 126.

Establishing the correct programming for applications requires setting several parameter functions. Details for parameters are provided in the programming guide.

Parameter settings are stored internally in the drive, allowing the following advantages:

- Parameter settings can be uploaded into the LCP memory and stored as a back-up.
- Multiple units can be programmed quickly by connecting the LCP to the unit and downloading the stored parameter settings.
- Settings that are stored in the LCP are not changed when restoring factory default settings.
- Changes made to default settings as well as any programming entered into parameters are stored and available for viewing in the quick menu. See “LCP Menus” on page 10.

UPLOADING AND DOWNLOADING PARAMETER SETTINGS

The drive operates using parameters stored on the control card, which is located within the drive. The upload and download functions move the parameters between the control card and the LCP.

1. Press [Off].
2. Go to parameter 0-50 LCP Copy and press [OK].
3. Select 1 of the following:
 - a. To upload data from the control card to the LCP, select [1] All to LCP.
 - b. To download data from the LCP to the control card, select [2] All from LCP.
4. Press [OK]. A progress bar shows the uploading or downloading process.
5. Press [Hand On] or [Auto On].

RESTORING FACTORY DEFAULT SETTINGS

NOTICE

LOSS OF DATA

Loss of programming, motor data, localization, and monitoring records occurs when restoring default settings. To create a back-up, upload data to the LCP before initialization. Refer to “Uploading and Downloading Parameter Settings” on page 59.

Restore the default parameter settings by initializing the unit. Initialization is carried out through parameter 14-22 Operation Mode or manually.

Parameter 14-22 Operation Mode does not reset settings such as the following:

- Running hours.

- Serial communication options.
- Personal menu settings.
- Fault log, alarm log, and other monitoring functions.

Recommended initialization

1. Press [Main Menu] twice to access parameters.
2. Go to parameter 14-22 Operation Mode and press [OK].
3. Scroll to Initialization and press [OK].
4. Remove power to the unit and wait for the display to turn off.
5. Apply power to the unit. Default parameter settings are restored during start-up. Start-up takes slightly longer than normal.
6. After alarm 80, Drive initialized to default value appears, press [Reset].

Manual initialization

Manual initialization resets all factory settings except for the following:

- Parameter 15-00 Operating hours.
- Parameter 15-03 Power Up's.
- Parameter 15-04 Over Temp's.
- Parameter 15-05 Over Volt's.

To perform manual initialization:

1. Remove power to the unit and wait for the display to turn off.
2. Press and hold [Status], [Main Menu], and [OK] simultaneously while applying power to the unit (approximately 5 s or until an audible click sounds and the fan starts). Start-up takes slightly longer than normal.

WIRING CONFIGURATION EXAMPLES

Introduction

The examples in this section are intended as a quick reference for common applications.

- Parameter settings are the regional default values unless otherwise indicated (selected in parameter 0-03 Regional Settings).
- Parameters associated with the terminals and their settings are shown next to the drawings.
- Switch settings for analog terminals A53 or A54 are shown where required.
- For STO, a jumper wire may be required between terminal 12 and terminal 37 when using factory default programming values.

Wiring Configurations for Automatic Motor Adaptation (AMA)

Table 18 — Wiring Configuration for AMA with T27 Connected

Parameters	
Function	Setting
Parameter 1-29 Automatic Motor Adaptation (AMA)	[1] Enable complete AMA
Parameter 5-12 Terminal 27 Digital Input	[2]* Coast inverse

Notes/comments:
Set parameter group 1-2* Motor Data according to motor nameplate.





Table 19 — Wiring Configuration for AMA without T27 Connected

Parameters	
Function	Setting
Parameter 1-29 Automatic Motor Adaptation (AMA)	[1] Enable complete AMA
Parameter 5-12 Terminal 27 Digital Input	[0] No operation

*=Default value

Notes/comments:
Set parameter group 1-2* Motor Data according to motor nameplate.



Wiring Configurations for Analog Speed Reference

Table 20 — Wiring Configuration for Analog Speed Reference (Voltage)

Parameters	
Function	Setting
Parameter 6-10 Terminal 53 Low Voltage	0.07 V*
Parameter 6-11 Terminal 53 High Voltage	10 V*
Parameter 6-14 Terminal 53 Low Ref./Feedb. Value	0 RPM
Parameter 6-15 Terminal 53 High Ref./ Feedb. Value	1500 RPM

*=Default value

Notes/comments:




Table 21 — Wiring Configuration for Analog Speed Reference (Current)

Parameters	
Function	Setting
Parameter 6-12 Terminal 53 Low Current	4 mA*
Parameter 6-13 Terminal 53 High Current	20 mA*
Parameter 6-14 Terminal 53 Low Ref./Feedb. Value	0 RPM
Parameter 6-15 Terminal 53 High Ref./ Feedb. Value	1500 RPM
* =Default value	
Notes/comments:	

Wiring Configurations for Start/Stop

Table 22 — Wiring Configuration for Start/Stop Command with Safe Torque Off

Parameters	
Function	Setting
Parameter 5-10 Terminal 18 Digital Input	[8] Start*
Parameter 5-12 Terminal 27 Digital Input	[0] No operation
Parameter 5-19 Terminal 37 Safe Stop	[1] Safe Torque Off Alarm
* =Default value	
Notes/comments: If parameter 5-12 Terminal 27 Digital Input is set to [0] No operation, a jumper wire to terminal 27 is not needed.	




Fig. 57 — Start/Stop with Safe Torque Off

Table 23 — Wiring Configuration for Pulse Start/Stop

Parameters	
Function	Setting
Parameter 5-10 Terminal 18 Digital Input	[9] Latched Start
Parameter 5-12 Terminal 27 Digital Input	[6] Stop Inverse
* =Default value	
Notes/comments: If parameter 5-12 Terminal 27 Digital Input is set to [0] No operation, a jumper wire to terminal 27 is not needed.	




Fig. 58 — Latched Start/Stop Inverse

Table 24 — Wiring Configuration for Start/Stop with Reversing and 4 Preset Speeds

		Parameters	
		Function	Setting
FC		Parameter 5-10 Terminal 18 Digital Input	[8] Start
+24 V	12	Parameter 5-11 Terminal 19 Digital Input	[10] Reversing*
D IN	18	Parameter 5-12 Terminal 27 Digital Input	[0] No operation
D IN	19	Parameter 5-14 Terminal 32 Digital Input	[16] Preset ref bit 0
D IN	27	Parameter 5-15 Terminal 33 Digital Input	[17] Preset ref bit 1
D IN	29	Parameter 3-10 Preset Reference	
D IN	32	Preset ref. 0	25%
D IN	33	Preset ref. 1	50%
+10 V	50	Preset ref. 2	75%
A IN	53	Preset ref. 3	100%
A IN	54		
COM	55		
A OUT	42		
COM	39		

* = Default value

130BB934.11

Wiring Configuration for an External Alarm Reset

Table 25 — Wiring Configuration for an External Alarm Reset

		Parameters	
		Function	Setting
FC		Parameter 5-11 Terminal 19 Digital Input	[1] Reset
+24 V	12		
+24 V	13		
D IN	18		
D IN	19		
COM	20		
D IN	27		
D IN	29		
D IN	32		
D IN	33		
+10 V	50		
A IN	53		
A IN	54		
COM	55		
A OUT	42		
COM	39		

* = Default value

130BB928.11

Notes/comments:

Wiring Configuration for Speed Reference Using a Manual Potentiometer

Table 26 — Wiring Configuration for Speed Reference (Using a Manual Potentiometer)

		Parameters	
		Function	Setting
FC		Parameter 6-10 Terminal 53 Low Voltage	0.07 V*
+10 V	50	Parameter 6-11 Terminal 53 High Voltage	10 V*
A IN	53	Parameter 6-14 Terminal 53 Low Ref./Feedb. Value	0 RPM
A IN	54	Parameter 6-15 Terminal 53 High Ref./ Feedb. Value	1500 RPM
COM	55		
A OUT	42		
COM	39		

≈ 5kΩ

e30bb683.11

U - I

A53

Notes/comments:

Table 27 — Wiring Configuration for Speed Reference (Using a Manual Potentiometer)

		Parameters	
		Function	Setting
FC		Parameter 6-10 Terminal 53 Low Voltage	0.07 V*
+10 V	500	Parameter 6-11 Terminal 53 High Voltage	10 V*
A IN	530	Parameter 6-14 Terminal 53 Low Ref./Feedb. Value	0 RPM
A IN	540	Parameter 6-15 Terminal 53 High Ref./Feedb. Value	1500 RPM
COM	550	* = Default value	
A OUT	420	Notes/comments:	
COM	390		
U - I			
A53			

Wiring Configuration for Speed Up/Speed Down

Table 28 — Wiring Configuration for Speed Up/Speed Down

		Parameters	
		Function	Setting
FC		Parameter 5-10 Terminal 18 Digital Input	[8] Start*
+24 V	120	Parameter 5-12 Terminal 27 Digital Input	[19] Freeze Reference
+24 V	130	Parameter 5-13 Terminal 29 Digital Input	[21] Speed Up
D IN	180	Parameter 5-14 Terminal 32 Digital Input	[22] Speed Down
D IN	190	* = Default value	
COM	200	Notes/comments:	
D IN	270		
D IN	290		
D IN	320		
D IN	330		
D IN	370		
e30bb683.11			




Fig. 59 — Speed Up/Speed Down

Wiring Configuration for RS485 Network Connection

Table 29 — Wiring Configuration for RS485 Network Connection

		Parameters	
		Function	Setting
FC		Parameter 8-30 Protocol	FC*
+24 V	120	Parameter 8-31 Address	1*
D IN	130	Parameter 8-32 Baud Rate	9600*
COM	180	* = Default value	
D IN	190	Notes/comments:	
D IN	200	Select protocol, address, and baud rate in the parameters.	
D IN	270		
D IN	290		
D IN	320		
D IN	330		
D IN	370		
+10 V	500		
A IN	530		
A IN	540		
COM	550		
A OUT	420		
COM	390		
R1	010		
	020		
	030		
R2	040		
	050		
	060		
RS-485	610		
	680		
	690		
	+		
	-		
130BB685.10			

Wiring Configuration for a Motor Thermistor

NOTICE

Thermistors must use reinforced or double insulation to meet PELV insulation requirements.

Table 30 — Wiring Configuration for a Motor Thermistor

		Parameters		
		Function	Setting	
CAR		Parameter 1-90 Motor Thermal Protection	[2] Thermistor trip	
+24 V	12○	Parameter 1-93 Thermistor Source	[1] analog input 53	
+24 V	13○	*=Default value		
D IN	18○			
D IN	19○			
COM	20○			
D IN	27○			
D IN	29○			
D IN	32○			
D IN	33○			
D IN	37○			
+10 V	50○			
A IN	53○			
A IN	54○			
COM	55○			
A OUT	42○			
COM	39○			
U - I				
A53				
		Notes/comments: If only a warning is wanted, set parameter 1-90 Motor Thermal Protection to [1] Thermistor warning.		
130BB686.12				

Wiring Configuration for a Cascade Controller

Figure 60 shows an example with the built-in basic cascade controller with 1 variable-speed pump (lead) and 2 fixed-speed pumps, a 4-20 mA transmitter, and system safety interlock.




Fig. 60 — Cascade Controller Wiring Diagram

Wiring Configuration for Relay Set-up with Smart Logic Control

Table 31 — Wiring Configuration for a Relay Set-up with Smart Logic Control


		Parameters	
		Function	Setting
FC		Parameter 4-30 Motor Feedback Loss Function	[1] Warning
+24 V	120	Parameter 4-31 Motor Feedback Speed Error	100 RPM
D IN	130	Parameter 4-32 Motor Feedback Loss Timeout	5 s
D IN	180	Parameter 7-00 Speed PID Feedback Source	[2] MCB 102
D IN	190	Parameter 17-11 Resolution (PPR)	1024*
D IN	200	Parameter 13-00 SL Controller Mode	[1] On
D IN	270	Parameter 13-01 Start Event	[19] Warning
D IN	290	Parameter 13-02 Stop Event	[44] Reset key
D IN	320	Parameter 13-10 Comparator Operand	[21] Warning no.
D IN	330	Parameter 13-11 Comparator Operator	[1] . (equal)*
D IN	370	Parameter 13-12 Comparator Value	90
+10 V	500	Parameter 13-51 SL Controller Event	[22] Comparator 0
A IN	530	Parameter 13-52 SL Controller Action	[32] Set digital out A low
A IN	540	Parameter 5-40 Function Relay	[80] SL digital output A
		*=Default value	

Notes/comments:

If the limit in the feedback monitor is exceeded, warning 90, Feedback Mon. is issued. The SLC monitors warning 90, Feedback Mon. and if the warning becomes true, relay 1 is triggered.

External equipment may require service. If the feedback error goes below the limit again within 5 s, the drive continues and the warning disappears. Reset relay 1 by pressing [Reset] on the LCP.


Wiring Configuration for a Fixed Variable Speed Pump



130BA376.10

Fig. 61 — Fixed Variable Speed Pump Wiring Diagram

Wiring Configuration for Lead Pump Alternation



130BA377.13

Fig. 62 — Lead Pump Alternation Wiring Diagram

Every pump must be connected to 2 contactors (K1/K2 and K3/K4) with a mechanical interlock. Thermal relays or other motor overload protection devices must be applied according to local regulation and/or individual demands.

- Relay 1 (R1) and relay 2 (R2) are the built-in relays in the drive.
- When all relays are de-energized, the first built-in relay that is energized cuts in the contactor corresponding to the pump controlled by the relay. For example, relay 1 cuts in contactor K1, which becomes the lead pump.
- K1 blocks for K2 via the mechanical interlock, preventing mains from being connected to the output of the drive (via K1).
- Auxiliary break contact on K1 prevents K3 from cutting in.
- Relay 2 controls contactor K4 for on/off control of the fixed speed pump.
- At alternation, both relays de-energize and now relay 2 is energized as the first relay.

MAINTENANCE, DIAGNOSTICS, AND TROUBLESHOOTING

130BD430.10

This chapter includes:

- Maintenance and service guidelines.
- Status messages.
- Warnings and alarms.
- Basic troubleshooting.

Maintenance and Service

Under normal operating conditions and load profiles, the drive is maintenance-free throughout its designed lifetime.

To prevent breakdown, danger, and damage, examine the drive at regular intervals depending on the operating conditions. Replace worn or damaged parts with original spare parts or standard parts. For service and support, contact Carrier.

WARNING

UNINTENDED START

When the drive is connected to AC mains, DC supply, or load sharing, the motor can start at any time.

Unintended start during programming, service, or repair work can result in death, serious injury, or property damage. The motor can start with an external switch, a fieldbus command, an input reference signal from the LCP or LOP, via remote operation using MCT 10 Set-up Software, or after a cleared fault condition.

To prevent unintended motor start:

- Press [Off/Reset] on the LCP before programming parameters.
- Disconnect the drive from the mains.
- Completely wire and assemble the drive, motor, and any driven equipment before connecting the drive to AC mains, DC supply, or load sharing.

Heat Sink Access Panel

REMOVING THE HEAT SINK ACCESS PANEL

The drive can be ordered with an optional access panel in the back of the unit. This panel provides access to the heat sink and allows the heat sink to be cleaned of any dust buildup.




Fig. 63 — Heat Sink Access Panel

NOTICE


DAMAGE TO HEAT SINK

Using fasteners that are longer than those originally supplied with the heat sink panel can damage the heat sink cooling fins.

1. Remove power from the drive and wait 20 minutes for the capacitors to discharge completely. Refer to "Safety" on page 2.
2. Position the drive so that the back of the drive is accessible.
3. Remove the screws (3 mm [0.12 in.] internal hex) connecting the access panel to the back of the enclosure. There are 5 or 9 screws depending on the size of the drive.
4. Inspect the heat sink for damage or dust buildup.
5. Remove dust and debris with a vacuum.
6. Replace the panel and secure it to the back of the enclosure with the screws previously removed. Tighten the fasteners according to "Fastener Tightening Torques" on page 89.

Status Messages

When the drive is in status mode, status messages automatically appear in the lowest line of the LCP display. Refer to Fig. 64. Status messages are defined in Tables 33- 35.



1	Where the stop/start command originates. Refer to Table 9.1.
2	Where the speed control originates. Refer to Table 9.2.
3	Provides the drive status. Refer to Table 9.3.

Fig. 64 — Status Display

NOTICE

In auto/remote mode, the drive requires external commands to execute functions.

Tables 32-34 define the meaning of the shown status messages.

Table 32 — Operating Mode

Off	The drive does not react to any control signal until [Auto On] or [Hand On] is pressed.
Auto	The start/stop commands are sent via the control terminals and/or the serial communication.
Hand	The navigation keys on the LCP can be used to control the drive. Stop commands, reset, reversing, DC brake, and other signals applied to the control terminals override local control.

Table 33 — Reference Site

Remote	The speed reference is given from: <ul style="list-style-type: none"> External signals. Serial communication. Internal preset references.
Local	The drive uses reference values from the LCP.

Table 34 — Operation Status

AC brake	AC brake was selected in parameter 2-10 Brake Function. The AC brake overmagnetizes the motor to achieve a controlled slow-down.
AMA finish OK	Automatic motor adaptation (AMA) was carried out successfully.
AMA ready	AMA is ready to start. To start, press [Hand On].
AMA running	AMA process is in progress.
Braking	The brake chopper is in operation. The brake resistor absorbs the generative energy.
Braking max.	The brake chopper is in operation. The power limit for the brake resistor defined in parameter 2-12 Brake Power Limit (kW) has been reached.
Coast	<ul style="list-style-type: none"> [2] Coast inverse was selected as a function for a digital input (parameter group 5-1* Digital Inputs). The corresponding terminal is not connected. Coast activated by serial communication.
Ctrl. ramp-down	<ul style="list-style-type: none"> [1] Ctrl. ramp-down was selected in parameter 14-10 Mains Failure. The mains voltage is below the value set in parameter 14-11 Mains Voltage at Mains Fault at mains fault. The drive ramps down the motor using a controlled ramp-down.
Current high	The drive output current is above the limit set in parameter 4-51 Warning Current High.
Current low	The drive output current is below the limit set in parameter 4-52 Warning Speed Low.
DC hold	DC hold is selected in parameter 1-80 Function at Stop and a stop command is active. The motor is held by a DC current set in parameter 2-00 DC Hold Current.
DC stop	<ul style="list-style-type: none"> The motor is held with a DC current (parameter 2-01 DC Brake Current) for a specified time (parameter 2-02 DC Braking Time). DC brake is activated in parameter 2-03 DC Brake Cut In Speed [RPM] and a stop command is active. DC brake (inverse) is selected as a function for a digital input (parameter group 5-1* Digital Inputs). The corresponding terminal is not active. The DC brake is activated via serial communication.
Feedback high	The sum of all active feedbacks is above the feedback limit set in parameter 4-57 Warning Feedback High.
Feedback low	The sum of all active feedbacks is below the feedback limit set in parameter 4-56 Warning Feedback Low.
Freeze output	<ul style="list-style-type: none"> The remote reference, which holds the present speed, is active. [20] Freeze Output was selected as a function for a digital input (parameter group 5-1* Digital Inputs). The corresponding terminal is active. Speed control is only possible via the terminal functions speed up and speed down. Hold ramp is activated via serial communication.
Freeze output request	A freeze output command has been given, but the motor remains stopped until a run permissive signal is received.
Freeze ref.	[19] Freeze Reference was selected as a function for a digital input (parameter group 5-1* Digital Inputs). The corresponding terminal is active. The drive saves the actual reference. Changing the reference is now only possible via terminal functions speed up and speed down.
Jog request	A jog command has been given, but the motor is stopped until a run permissive signal is received via a digital input.
Jogging	<ul style="list-style-type: none"> The motor is running as programmed in parameter 3-19 Jog Speed [RPM]. [14] Jog was selected as function for a digital input (parameter group 5-1* Digital Inputs). The corresponding terminal (for example, terminal 29) is active. The jog function is activated via the serial communication. The jog function was selected as a reaction for a monitoring function (for example, No signal). The monitoring function is active.
Motor check	In parameter 1-80 Function at Stop, [2] Motor Check was selected. A stop command is active. To ensure that a motor is connected to the drive, a permanent test current is applied to the motor.

Table 34 — Operation Status

OVC control	Overvoltage control was activated in parameter 2-17 Over-voltage Control, [2] Enabled. The connected motor is supplying the drive with generative energy. The overvoltage control adjusts the V/Hz ratio to run the motor in controlled mode and to prevent the drive from tripping.
Power unit off	(For drives with a 24 V DC external supply installed only.) Mains supply to the drive is removed, but the control card is supplied by the 24 V DC external supply.
Protection md	Protection mode is active. The unit has detected a critical status (an overcurrent or overvoltage). <ul style="list-style-type: none"> • To avoid tripping, the switching frequency is reduced to 1500 kHz if parameter 14-55 Output Filter is set to [2] Sine-Wave Filter Fixed. Otherwise, the switching frequency is reduced to 1000 Hz. • If possible, protection mode ends after approximately 10 s. • Protection mode can be restricted in parameter 14-26 Trip Delay at Inverter Fault.
QStop	The motor is decelerating using parameter 3-81 Quick Stop Ramp Time. <ul style="list-style-type: none"> • [4] Quick stop inverse was selected as a function for a digital input (parameter group 5-1* Digital Inputs). The corresponding terminal is not active. • The quick stop function was activated via serial communication.
Ramping	The motor is accelerating/decelerating using the active ramp up/down. The reference, a limit value, or a standstill is not yet reached.
Ref. high	The sum of all active references is above the reference limit set in parameter 4-55 Warning Reference High.
Ref. low	The sum of all active references is below the reference limit set in parameter 4-54 Warning Reference Low.
Run on ref.	The drive is running in the reference range. The feedback value matches the setpoint value.
Run request	A start command has been given, but the motor is stopped until a run permissive signal is received via digital input.
Running	The drive is driving the motor.
Sleep mode	The energy saving function is enabled. This function being enabled means that the motor has stopped, but that it restarts automatically when required.
Speed high	The motor speed is above the value set in parameter 4-53 Warning Speed High.
Speed low	The motor speed is below the value set in parameter 4-52 Warning Speed Low.
Standby	In auto-on mode, the drive starts the motor with a start signal from a digital input or serial communication.
Start delay	In parameter 1-71 Start Delay, a delay starting time was set. A start command is activated and the motor starts after the start delay time expires.
Start fwd/rev	[12] Enable Start Forward and [13] Enable Start Reverse were selected as functions for 2 different digital inputs (parameter group 5-1* Digital Inputs). The motor starts in forward or reverse depending on which corresponding terminal is activated.
Stop	The drive has received a stop command from 1 of the following: <ul style="list-style-type: none"> • LCP. • Digital input. • Serial communication.
Trip	An alarm occurred and the motor is stopped. Once the cause of the alarm is cleared, reset the drive using 1 of the following: <ul style="list-style-type: none"> • Pressing [Reset]. • Remotely by control terminals. • Via serial communication. Pressing [Reset] or remotely by control terminals or via serial communication.
Trip lock	An alarm occurred and the motor is stopped. Once the cause of the alarm is cleared, cycle power to the drive. Reset the drive manually by 1 of the following: <ul style="list-style-type: none"> • Pressing [Reset]. • Remotely by control terminals. • Via serial communication

Warning and Alarm Types

The drive software issues warnings and alarms to help diagnose issues. The warning or alarm number appears in the LCP.

Warning

A warning indicates that the drive has encountered an abnormal operating condition that leads to an alarm. A warning stops when the abnormal condition is removed or resolved.

Alarm

An alarm indicates a fault that requires immediate attention. The fault always triggers a trip or trip lock. Reset the drive after an alarm.

Reset the drive in any of 4 ways:

- Press [Reset]/[Off/Reset].
- Digital reset input command.
- Serial communication reset input command.
- Auto reset.

Trip

When tripping, the drive suspends operation to prevent damage to the drive and other equipment. When a trip occurs, the motor coasts to a stop. The drive logic continues to operate and monitor the drive status. After the fault condition is remedied, the drive is ready for a reset.

Trip lock

When trip locking, the drive suspends operation to prevent damage to the drive and other equipment. When a trip lock occurs, the motor coasts to a stop. The drive logic continues to operate and monitor the drive status. The drive starts a trip lock only when serious faults occur that can damage the drive or other equipment. After the faults are fixed, cycle the input power before resetting the drive.

Warning and alarm displays

- A warning is shown in the LCP along with the warning number.
- An alarm flashes along with the alarm number.





Fig. 65 — Alarm Example

In addition to the text and alarm code in the LCP, there are 3 status indicator lights.



130BB467.11

WARNING 5, DC link voltage high

The DC-link voltage (DC) is higher than the high-voltage warning limit. The limit depends on the drive voltage rating. The unit is still active.

WARNING 6, DC link voltage low

The DC-link voltage (DC) is lower than the low-voltage warning limit. The limit depends on the drive voltage rating. The unit is still active.

WARNING/ALARM 7, DC overvoltage

If the DC-link voltage exceeds the limit, the drive trips after a certain time.

Troubleshooting

- Connect a brake resistor.
- Extend the ramp time.
- Change the ramp type.
- Activate the functions in parameter 2-10 Brake Function.
- Increase parameter 14-26 Trip Delay at Inverter Fault.
- If the alarm/warning occurs during a power sag, use kinetic back-up (parameter 14-10 Mains Failure).

WARNING/ALARM 8, DC under voltage

If the DC-link voltage drops below the undervoltage limit, the drive checks for 24 V DC back-up supply. If no 24 V DC back-up supply is connected, the drive trips after a fixed time delay. The time delay varies with unit size.

Troubleshooting

- Check that the supply voltage matches the drive voltage.
- Perform an input voltage test.
- Perform a soft-charge circuit test.

WARNING/ALARM 9, Inverter overload

The drive has run with more than 100% overload for too long and is about to cut out. The counter for electronic thermal inverter protection issues a warning at 98% and trips at 100% with an alarm. The drive cannot be reset until the counter is below 90%.

Troubleshooting

- Compare the output current shown on the LCP with the drive rated current.
- Compare the output current shown on the LCP with the measured motor current.
- Show the thermal drive load on the LCP and monitor the value. When running above the drive continuous current rating, the counter increases.

When running below the drive continuous current rating, the counter decreases.

WARNING/ALARM 10, Motor overload temperature

According to the electronic thermal protection (ETR), the motor is too hot.

Select 1 of these options:

- The drive issues a warning or an alarm when the counter is >90% if parameter 1-90 Motor Thermal Protection is set to warning options.
- The drive trips when the counter reaches 100% if parameter 1-90 Motor Thermal Protection is set to trip options.

The fault occurs when the motor runs with more than 100% overload for too long.

Troubleshooting

- Check for motor overheating.
- Check if the motor is mechanically overloaded.
- Check that the motor current set in parameter 1-24 Motor Current is correct.
- Ensure that the motor data in parameters 1-20 to 1-25 is set correctly.

	Warning indicator light	Alarm indicator light
Warning	On	Off
Alarm	Off	On (flashing)
Trip lock	On	On (flashing)

Fig. 66 — Status Indicator Lights

List of Warnings and Alarms

The following warning and alarm information defines each warning or alarm condition, provides the probable cause for the condition, and details a remedy or troubleshooting procedure.

WARNING 1, 10 Volts low

The control card voltage is less than 10 V from terminal 50. Remove some of the load from terminal 50, as the 10 V supply is overloaded. Maximum 15 mA or minimum 590 Ω.

A short circuit in a connected potentiometer or incorrect wiring of the potentiometer can cause this condition.

Troubleshooting

- Remove the wiring from terminal 50. If the warning clears, the problem is with the wiring. If the warning does not clear, replace the control card.

WARNING/ALARM 2, Live zero error

This warning or alarm only appears if programmed in parameter 6-01 Live Zero Timeout Function. The signal on 1 of the analog inputs is less than 50% of the minimum value programmed for that input. Broken wiring or a faulty device sending the signal can cause this condition.

Troubleshooting

- Check connections on all analog mains terminals.
- Control card terminals 53 and 54 for signals, terminal 55 common.
- CAR102 General Purpose I/O MCB 101 terminals 11 and 12 for signals, terminal 10 common.
- CAR102 Analog I/O Option MCB 109 terminals 1, 3, and 5 for signals, terminals 2, 4, and 6 common.
- Check that the drive programming and switch settings match the analog signal type.
- Perform an input terminal signal test.

WARNING/ALARM 3, No motor

No motor has been connected to the output of the drive. This warning or alarm appears only if programmed in parameter 1-80 Function at Stop.

Troubleshooting

- Check the connection between the drive and the motor.

WARNING/ALARM 4, Mains phase loss

A phase is missing on the supply side, or the mains voltage imbalance is too high. This message also appears for a fault in the input rectifier. Options are programmed in parameter 14-12 Response to Mains Imbalance.

Troubleshooting

- Check the supply voltage and supply currents to the drive.

- If an external fan is in use, check that it is selected in parameter 1-91 Motor External Fan.
- Running AMA in parameter 1-29 Automatic Motor Adaptation (AMA) tunes the drive to the motor more accurately and reduces thermal loading.

WARNING/ALARM 11, Motor thermistor overtemp

Check whether the thermistor is disconnected. Select whether the drive issues a warning or an alarm in parameter 1-90 Motor Thermal Protection.

Troubleshooting

- Check for motor overheating.
- Check if the motor is mechanically overloaded.
- When using terminal 53 or 54, check that the thermistor is connected correctly between either terminal 53 or 54 (analog voltage input) and terminal 50 (+10 V supply). Also check that the terminal switch for 53 or 54 is set for voltage. Check that parameter 1-93 Thermistor Resource selects terminal 53 or 54.
- When using terminal 18, 19, 31, 32, or 33 (digital inputs), check that the thermistor is connected correctly between the digital input terminal used (digital input PNP only) and terminal 50. Select the terminal to use in parameter 1-93 Thermistor Resource.

WARNING/ALARM 12, Torque limit

The torque has exceeded the value in parameter 4-16 Torque Limit Motor Mode or the value in parameter 4-17 Torque Limit Generator Mode.

Parameter 14-25 Trip Delay at Torque Limit can change this warning from a warning-only condition to a warning followed by an alarm.

Troubleshooting

- If the motor torque limit is exceeded during ramp-up, extend the ramp-up time.
- If the generator torque limit is exceeded during ramp-down, extend the ramp-down time.
- If torque limit occurs while running, increase the torque limit. Make sure that the system can operate safely at a higher torque.
- Check the application for excessive current draw on the motor.

WARNING/ALARM 13, Over current

The inverter peak current limit (approximately 200% of the rated current) is exceeded. The warning lasts approximately 1.5 s, then the drive trips and issues an alarm. Shock loading or quick acceleration with high-inertia loads can cause this fault. If the acceleration during ramp-up is quick, the fault can also appear after kinetic back-up. If extended mechanical brake control is selected, a trip can be reset externally.

Troubleshooting

- Remove the power and check if the motor shaft can be turned.
- Check that the motor size matches the drive.
- Check that the motor data is correct in parameters 1-20 to 1-25.

ALARM 14, Earth (ground) fault

There is current from the output phase to ground, either in the cable between the drive and the motor, or in the motor itself. The current transducers detect the ground fault by measuring current going out from the drive and current going into the drive from the motor. Ground fault is issued if the deviation of the 2 currents is too large. The current going out of the drive must be the same as the current going into the drive.

Troubleshooting

- Remove power to the drive and repair the ground fault.

- Check for ground faults in the motor by measuring the resistance to ground of the motor cables and the motor with a megohmmeter.
- Reset any potential individual offset in the 3 current transducers in the drive. Perform the manual initialization or perform a complete AMA.

This method is most relevant after changing the power card.

ALARM 15, Hardware mismatch

A fitted option is not operational with the present control card hardware or software.

Record the value of the following parameters and contact Carrier.

- Parameter 15-40 FC Type.
- Parameter 15-41 Power Section.
- Parameter 15-42 Voltage.
- Parameter 15-43 Software Version.
- Parameter 15-45 Actual Typecode String.
- Parameter 15-49 SW ID Control Card.
- Parameter 15-50 SW ID Power Card.
- Parameter 15-60 Option Mounted.
- Parameter 15-61 Option SW Version (for each option slot).

There is short-circuiting in the motor or motor wiring.

WARNING

HIGH VOLTAGE

Drives contain high voltage when connected to AC mains input, DC supply, or load sharing. Failure to perform installation, start-up, and maintenance by qualified personnel can result in death or serious injury.

ALARM 16, Short circuit

Troubleshooting

- Remove the power to the drive and repair the short circuit.
- Check that the drive contains the correct current scaling card and the correct number of current scaling cards for the system.

WARNING/ALARM 17, Control word timeout

There is no communication to the drive.

The warning is only active when parameter 8-04 Control Word Timeout Function is NOT set to [0] Off. If parameter 8-04 Control Word Timeout Function is set to [5] Stop and trip, a warning appears, and the drive ramps down to a stop and shows an alarm.

Troubleshooting

- Check the connections on the serial communication cable.
- Increase parameter 8-03 Control Word Timeout Time.
- Check the operation of the communication equipment.
- Verify that proper EMC installation was performed.

WARNING/ALARM 20, Temp. input error

The temperature sensor is not connected.

WARNING/ALARM 21, Parameter error

The parameter is out of range. The parameter number is shown in the display.

Troubleshooting

- Set the affected parameter to a valid value.

WARNING/ALARM 22, Hoist mechanical brake

The value of this warning/alarm indicates the cause::

0 = The torque reference was not reached before timeout (parameter 2-27 Torque Ramp Time).

1 = Expected brake feedback was not received before timeout (parameter 2-23 Activate Brake Delay, parameter 2-25 Brake Release Time).

WARNING 23, Internal fan fault

The fan warning function is a protective function that checks if the fan is running/mounted. The fan warning can be disabled in parameter 14-53 Fan Monitor ([0] Disabled).

For drives with DC fans, a feedback sensor is mounted in the fan. If the fan is commanded to run and there is no feedback from the sensor, this alarm appears. For drives with AC fans, the voltage to the fan is monitored.

Troubleshooting

- Check for proper fan operation.
- Cycle power to the drive and check that the fan operates briefly at start-up.
- Check the sensors on the control card.

WARNING 24, External fan fault

The fan warning function is a protective function that checks if the fan is running/mounted. The fan warning can be disabled in parameter 14-53 Fan Monitor ([0] Disabled).

A feedback sensor is mounted in the fan. If the fan is commanded to run and there is no feedback from the sensor, this alarm appears. This alarm also shows if there is a communication error between the power card and the control card.

Check the alarm log for the report value associated with this warning.

If the report value is 1, there is a hardware problem with 1 of the fans. If the report value is 11, there is a communication problem between the power card and the control card.

Fan troubleshooting

- Cycle power to the drive and check that the fan operates briefly at start-up.
- Check for proper fan operation. Use parameter group 43-** Unit Readouts to show the speed of each fan.

Power card troubleshooting

- Check the wiring between the power card and the control card.
- Power card may need to be replaced.
- Control card may need to be replaced.

WARNING 25, Brake resistor short circuit

The brake resistor is monitored during operation. If a short circuit occurs, the brake function is disabled and the warning appears. The drive is still operational, but without the brake function

Troubleshooting

- Remove the power to the drive and replace the brake resistor (refer to parameter 2-15 Brake Check).

WARNING/ALARM 26, Brake resistor power limit

The power transmitted to the brake resistor is calculated as a mean value over the last 120 s of run-time. The calculation is based on the DC-link voltage and the brake resistor value set in parameter 2-16 AC brake Max. Current. The warning is active when the dissipated braking power is higher than 90% of the brake resistor power. If option [2] Trip is selected in parameter 2-13 Brake Power Monitoring, the drive trips when the dissipated braking power reaches 100%.

The brake transistor is monitored during operation, and if a short circuit occurs, the brake function is disabled, and a warning is issued. The drive is still operational, but since the brake transistor has short-circuited, substantial power is transmitted to the brake resistor, even if it is inactive.

⚠ WARNING

OVERHEATING RISK

A surge in power can cause the brake resistor to overheat and possibly catch fire. Failure to remove power to the drive and remove the brake resistor can cause equipment damage.

Troubleshooting

- Remove power to the drive.
- Remove the brake resistor.
- Troubleshoot the short circuit.

WARNING/ALARM 28, Brake check failed

The brake resistor is not connected or not working.

Troubleshooting

- Check parameter 2-15 Brake Check.

ALARM 29, Heat sink temp

The maximum temperature of the heat sink has been exceeded. The temperature fault does not reset until the temperature drops below a defined heat sink temperature. The trip and reset points are different based on the drive power size.

Troubleshooting

Check for the following conditions:

- Ambient temperature too high.
- Motor cable too long.
- Incorrect airflow clearance above and below the drive.
- Blocked airflow around the drive.
- Damaged heat sink fan.
- Dirty heat sink.

For drives in enclosure sizes D and E, this alarm is based on the temperature measured by the heat sink sensor mounted inside the IGBT modules.

Troubleshooting

- Check fan resistance.
- Check soft charge fuses.
- Check IGBT thermal.

ALARM 30, Motor phase U missing

Motor phase U between the drive and the motor is missing.

⚠ WARNING

HIGH VOLTAGE

Drives contain high voltage when connected to AC mains input, DC supply, or load sharing. Failure to perform installation, start-up, and maintenance by qualified personnel can result in death or serious injury.

- Only qualified personnel must perform installation, start-up, and maintenance.
- Before performing any service or repair work, use an appropriate voltage measuring device to make sure that there is no remaining voltage on the drive.

Troubleshooting

- Remove the power from the drive and check motor phase U.

ALARM 31, Motor phase V missing

Motor phase V between the drive and the motor is missing.

⚠ WARNING

HIGH VOLTAGE

Drives contain high voltage when connected to AC mains input, DC supply, or load sharing. Failure to perform installation, start-up, and maintenance by qualified personnel can result in death or serious injury.

- Only qualified personnel must perform installation, start-up, and maintenance.
- Before performing any service or repair work, use an appropriate voltage measuring device to make sure that there is no remaining voltage on the drive.

Troubleshooting

- Remove the power from the drive and check motor phase V.

ALARM 32, Motor phase W missing

Motor phase W between the drive and the motor is missing.

⚠ WARNING

HIGH VOLTAGE

Drives contain high voltage when connected to AC mains input, DC supply, or load sharing. Failure to perform installation, start-up, and maintenance by qualified personnel can result in death or serious injury.

- Only qualified personnel must perform installation, start-up, and maintenance.
- Before performing any service or repair work, use an appropriate voltage measuring device to make sure that there is no remaining voltage on the drive.

Troubleshooting

- Remove the power from the drive and check motor phase W.

ALARM 33, Inrush fault

Too many power-ups have occurred within a short time period.

Troubleshooting

- Let the unit cool to operating temperature.
- Check potential DC-link fault to ground.

WARNING/ALARM 34, Fieldbus communication fault

The fieldbus on the communication option card is not working.

WARNING/ALARM 35, Option fault

An option alarm is received. The alarm is option-specific. The most likely cause is a power-up or a communication fault.

WARNING/ALARM 36, Mains failure

This warning/alarm is only active if the supply voltage to the drive system is lost and parameter 14-10 Mains Failure is not set to option [0] No Function.

- Check the fuses to the drive system and the mains supply to the unit.
- Check that mains voltage conforms to product specifications.
- Check that the following conditions are not present:
 - Alarm 307, Excessive THD(V), alarm 321, Voltage imbalance, warning 417, Mains undervoltage, or warning 418, Mains overvoltage is reported if any of the listed conditions are true:
 - The 3-phase voltage magnitude drops below 25% of the nominal mains voltage.
 - Any single-phase voltage exceeds 10% of the nominal mains voltage.

- Percent of phase or magnitude imbalance exceeds 8%.
- Voltage THD exceeds 10%.

ALARM 37, Phase imbalance

There is a current imbalance between the power units.

ALARM 38, Internal fault

When an internal fault occurs, a code number defined in Table 35 is shown.

Troubleshooting

- Cycle power.
- Check that the option is properly installed.
- Check for loose or missing wiring.

It may be necessary to contact Carrier. Note the code number for further troubleshooting directions.

Table 35 — Internal Fault Codes

Number	Text
0	The serial port cannot be initialized. Contact Carrier.
256-258	The power EEPROM data is defective or too old. Replace the power card.
512-519	Internal fault. Contact Carrier.
783	Parameter value outside of minimum/maximum limits.
1024-1284	Internal fault. Contact Carrier.
1299	The option software in slot A is too old.
1300	The option software in slot B is too old.
1302	The option software in slot C1 is too old.
1315	The option software in slot A is not supported/allowed.
1316	The option software in slot B is not supported/allowed.
1318	The option software in slot C1 is not supported/allowed.
1379-2819	Internal fault. Contact Carrier.
1792	Hardware reset of digital signal processor.
1793	Motor-derived parameters not transferred correctly to the digital signal processor.
1794	Power data not transferred correctly at power-up to the digital signal processor.
1795	The digital signal processor has received too many unknown SPI telegrams. The AC drive also uses this fault code if the MCO does not power up correctly. This situation can occur due to poor EMC protection or improper grounding.
1796	RAM copy error.
2561	Replace the control card.
2820	LCP stack overflow.
2821	Serial port overflow.
2822	USB port overflow.
3072-5122	Parameter value is outside its limits.
5123	Option in slot A: Hardware incompatible with the control board hardware.
5124	Option in slot B: Hardware incompatible with the control board hardware.
5125	Option in slot C0: Hardware incompatible with the control board hardware.
5126	Option in slot C1: Hardware incompatible with the control board hardware.
5376-6231	Internal fault. Contact Carrier.

ALARM 39, Heat sink sensor

No feedback from the heat sink temperature sensor.

The signal from the IGBT thermal sensor is not available on the power card.

Troubleshooting

- Check the ribbon cable between the power card and gat-edrive card.

- Check for a defective power card.
- Check for a defective gatedrive card.

WARNING 40, Overload of digital output terminal 27

Check the load connected to terminal 27 or remove the short-circuit connection. Check parameter 5-00 Digital I/O Mode and parameter 5-01 Terminal 27 Mode.

WARNING 41, Overload of digital output terminal 29

Check the load connected to terminal 29 or remove the short-circuit connection. Also check parameter 5-00 Digital I/O Mode and parameter 5-02 Terminal 29 Mode.

WARNING 42, Overload of digital output on X30/6 or over-load of digital output on X30/7

For terminal X30/6, check the load connected to terminal X30/6 or remove the short-circuit connection. Also check parameter 5-32 Term X30/6 Digi Out (MCB 101) (CAR102 General Purpose I/O MCB 101).

For terminal X30/7, check the load connected to terminal X30/7 or remove the short-circuit connection. Check parameter 5-33 Term X30/7 Digi Out (MCB 101) (CAR102 General Purpose I/O MCB 101).

ALARM 43, Ext. supply

CAR102 Extended Relay Option MCB 113 is mounted without external 24 V DC. Either connect a 24 V DC external supply or specify that no external supply is used via parameter 14-80 Option Supplied by External 24VDC, [0] No. A change in parameter 14-80 Option Supplied by External 24VDC requires a power cycle.

ALARM 45, Earth fault 2

Ground fault.

Troubleshooting

- Check for proper grounding and loose connections.
- Check for proper wire size.
- Check the motor cables for short circuits or leakage currents.

ALARM 46, Power card supply

The supply on the power card is out of range.

There are 4 supplies generated by the switch mode power supply on the power card:

- 48 V.
- 24 V.
- 5 V.
- ± 18 V.

When powered with CAR102 24 V DC Supply MCB 107, only the 24 V and 5 V supplies are monitored. When powered with 3-phase mains voltage, all 4 supplies are monitored.

Troubleshooting

- Check for a defective power card.
- Check for a defective control card.
- Check for a defective option card.
- If a 24 V DC supply is used, verify proper supply power.
- Check D-sized drives for a defective heat sink fan, top fan, or door fan.
- Check E-sized drives for a defective mixing fan.

WARNING 47, 24 V supply low

The supply on the power card is out of range.

There are 4 supplies generated by the switch mode supply (SMPS) on the power card:

- 48 V.
- 24 V.
- 5 V.
- ± 18 V.

Troubleshooting

- Check for a defective power card.

WARNING 48, 1.8 V supply low

The 1.8 V DC supply used on the control card is outside of the allowable limits. The supply is measured on the control card.

Troubleshooting

- Check for a defective control card.
- If an option card is present, check for overvoltage.

WARNING 49, Speed limit

The warning is shown when the speed is outside of the specified range in parameter 4-11 Motor Speed Low Limit [RPM] and parameter 4-13 Motor Speed High Limit [RPM]. When the speed is below the specified limit in parameter 1-86 Trip Speed Low [RPM] (except when starting or stopping), the drive trips.

ALARM 50, AMA calibration failed

Contact Carrier.

ALARM 51, AMA check Unom and Inom

The settings for motor voltage, motor current, and motor power are wrong.

Troubleshooting

- Check the settings in parameters 1-20 to 1-25.

ALARM 52, AMA low Inom

The motor current is too low.

Troubleshooting

- Check the settings in parameter 1-24 Motor Current.

ALARM 53, AMA motor too big

The motor is too large for the AMA to operate.

ALARM 54, AMA motor too small

The motor is too small for the AMA to operate.

ALARM 55, AMA parameter out of range

The AMA cannot run because the parameter values of the motor are outside of the acceptable range.

ALARM 56, AMA interrupted by user

The AMA is manually interrupted.

ALARM 57, AMA internal fault

Try to restart the AMA. Repeated restarts can overheat the motor.

ALARM 58, AMA Internal fault

Contact Carrier.

WARNING 59, Current limit

The current is higher than the value in parameter 4-18 Current Limit. Ensure that the motor data in parameters 1-20 to 1-25 is set correctly. Increase the current limit if necessary. Ensure that the system can operate safely at a higher limit.

WARNING 60, External interlock

A digital input signal indicates a fault condition external to the drive. An external interlock has commanded the drive to trip. Clear the external fault condition. To resume normal operation, apply 24 V DC to the terminal programmed for external interlock, and reset the drive.

WARNING/ALARM 61, Feedback error

An error is detected between calculated speed and speed measurement from feedback device.

Troubleshooting

- Check the settings for warning/alarm/disabling in parameter 4-30 Motor Feedback Loss Function.
- Set the tolerable error in parameter 4-31 Motor Feedback Speed Error.
- Set the tolerable feedback loss time in parameter 4-32 Motor Feedback Loss Timeout.

WARNING 62, Output frequency at maximum limit

If the output frequency reaches the value set in parameter 4-19 Max Output Frequency, the drive issues a warning. The warning ceases when the output drops below the maximum limit. If the drive is unable to limit the frequency, it trips and issues an alarm. The latter may happen in the flux mode if the drive loses control of the motor.

Troubleshooting

- Check the application for possible causes.
- Increase the output frequency limit. Ensure that the system can operate safely at a higher output frequency.

ALARM 63, Mechanical brake low

The actual motor current has not exceeded the release brake current within the start delay time window.

WARNING 64, Voltage Limit

The load and speed combination demands a motor voltage higher than the actual DC-link voltage.

WARNING/ALARM 65, Control card over temperature

The cutout temperature of the control card is 85°C (185°F).

Troubleshooting

- Check that the ambient operating temperature is within the limits.
- Check for clogged filters.
- Check the fan operation.
- Check the control card.

WARNING 66, Heat sink temperature low

The drive is too cold to operate. This warning is based on the temperature sensor in the IGBT module. Increase the ambient temperature of the unit. Also, a trickle amount of current can be supplied to the drive whenever the motor is stopped by setting parameter 2-00 DC Hold/Preheat Current to 5% and parameter 1-80 Function at Stop.

ALARM 67, Option module configuration has changed

One or more options have either been added or removed since the last power-down. Check that the configuration change is intentional and reset the unit.

ALARM 68, Safe Stop activated

Safe Torque Off (STO) has been activated. To resume normal operation, apply 24 V DC to terminal 37, then send a reset signal (via bus, digital I/O, or by pressing [Reset]).

ALARM 69, Power card temperature

The temperature sensor on the power card is either too hot or too cold.

Troubleshooting

- Check that the ambient operating temperature is within limits.
- Check for clogged filters.
- Check fan operation.
- Check the power card.

ALARM 70, Illegal FC configuration

The control card and power card are incompatible. To check compatibility, contact Carrier with the type code from the unit nameplate and the part numbers of the cards.

WARNING/ALARM 71, PTC 1 Safe Stop

Safe Torque Off (STO) has been activated from the CAR102 PTC Thermistor Card MCB 112 because the motor is too warm. Once the motor cools and the digital input from the MCB 112 is deactivated, normal operation can resume when the MCB 112 applies 24 V DC to terminal 37 again. When the motor is ready for normal operation, a reset signal is sent (via serial communication, digital I/O, or by pressing [Reset] on the LCP). If automatic restart is enabled, the motor can start when the fault is cleared.

ALARM 72, Dangerous failure

STO with trip lock. An unexpected combination of STO commands has occurred:

- CAR102 PTC Thermistor Card MCB 112 enables X44/10, but STO is not enabled.
- MCB 112 is the only device using STO (specified through selection [4] PTC 1 alarm or [5] PTC 1 warning in parameter 5-19 Terminal 37 Safe Stop), STO is activated, and X44/10 is not activated.

WARNING 73, Safe Stop auto restart

Safe Torque Off (STO) activated. With automatic restart enabled, the motor can start when the fault is cleared.

ALARM 74, PTC Thermistor

Alarm related to CAR102 PTC Thermistor Card MCB 112. The PTC is not working.

ALARM 75, Illegal profile sel.

Do not write the parameter value while the motor is running. Stop the motor before writing the MCO profile to parameter 8-10 Control Word Profile.

WARNING 76, Power unit setup

The required number of power units does not match the detected number of active power units. When replacing an enclosure size F module, this warning occurs if the power specific data in the module power card does not match the rest of the drive. If the power card connection is lost, the unit also triggers this warning.

Troubleshooting

- Confirm that the spare part and its power card are the correct part number.
- Ensure that the 44-pin cables between the MDCIC and power cards are mounted properly.

WARNING 77, Reduced power mode

This alarm applies to only multi-drive systems. The system is operating in reduced power mode (fewer than the allowed number of drive modules). This warning is generated on power cycle when the system is set to run with fewer drive modules and remains on.

ALARM 78, Tracking error

The difference between setpoint value and actual value exceeds the value in parameter 4-35 Tracking Error.

Troubleshooting

- Disable the function or select an alarm/warning in parameter 4-34 Tracking Error Function.
- Investigate the mechanics around the load and motor. Check feedback connections from motor encoder to drive.
- Select motor feedback function in parameter 4-30 Motor Feedback Loss Function.
- Adjust the tracking error band in parameter 4-35 Tracking Error and parameter 4-37 Tracking Error Ramping.

ALARM 79, Illegal power section configuration

The scaling card has an incorrect part number or is not installed. Also, the MK101 connector on the power card could not be installed.

ALARM 80, Drive initialized to default value

Parameter settings are initialized to default settings after a manual reset. To clear the alarm, reset the unit.

ALARM 81, CSIV corrupt

CSIV file has syntax errors.

ALARM 82, CSIV parameter error

CSIV failed to initialize a parameter.

ALARM 83, Illegal option combination

The mounted options are incompatible.

ALARM 84, No safety option

The safety option was removed without applying a general reset. Reconnect the safety option.

ALARM 88, Option detection

A change in the option layout is detected.

Parameter 14-89 Option Detection is set to [0] Frozen configuration and the option layout has been changed.

- To apply the change, enable option layout changes in parameter 14-89 Option Detection.
- Alternatively, restore the correct option configuration.

WARNING 89, Mechanical brake sliding

The hoist brake monitor detects a motor speed exceeding 10 RPM.

ALARM 90, Feedback monitor

Check the connection to encoder/resolver option and, if necessary, replace CAR102 Encoder Input MCB 102 or CAR102 Resolver Input MCB 103.

ALARM 91, Analog input 54 wrong settings

Set switch S202 in position OFF (voltage input) when a KTY sensor is connected to analog input terminal 54.

ALARM 96, Start delayed

The motor start has been delayed due to short-cycle protection. Parameter 22-76 Interval between Starts is enabled.

Troubleshooting

- Troubleshoot the system and reset the drive after clearing the fault.

WARNING 97, Stop delayed

Stopping the motor has been delayed because the motor has been running for less than the minimum time specified in parameter 22-77 Minimum Run Time.

WARNING 98, Clock fault

Time is not set, or the RTC clock has failed. Reset the clock in parameter 0-70 Date and Time.

ALARM 99, Locked rotor

The rotor is blocked.

WARNING/ALARM 104, Mixing fan fault

The fan is not operating. The fan monitor checks that the fan is spinning at power-up or whenever the mixing fan is turned on. The mixing-fan fault can be configured as a warning or an alarm trip in parameter 14-53 Fan Monitor.

Troubleshooting

- Cycle power to the drive to determine if the warning/alarm returns.

WARNING/ALARM 122, Mot. rotat. unexp.

The drive performs a function that requires the motor to be at standstill, for example DC hold for PM motors.

ALARM 144, Inrush Supply

A supply voltage on the inrush card is out of range. See the bit field result report value for more details.

- Bit 2: Vcc high.
- Bit 3: Vcc low.
- Bit 4: Vdd high.
- Bit 5: Vdd low.

ALARM 145, External SCR disable

The alarm indicates a series DC-link capacitor voltage imbalance.

WARNING/ALARM 146, Mains voltage

Mains voltage is outside valid operating range. The following report values provide more details.

- Voltage too low: 0=R-S, 1=S-T, 2=T-R
- Voltage too high: 3=R-S, 4=S-T, 5=T-R

WARNING/ALARM 147, Mains frequency

Mains frequency is outside valid operating range. Report value provides more details.

- 0: frequency too low.
- 1: frequency too high.

WARNING/ALARM 148, System temp

One or more of the system temperature measurements is too high.

WARNING 163, ATEX ETR cur.lim.warning

The drive has run above the characteristic curve for more than 50 s. The warning is activated at 83% and deactivated at 65% of the allowed thermal overload.

ALARM 164, ATEX ETR cur.lim.alarm

Operating above the characteristic curve for more than 60 s within a period of 600 s activates the alarm, and the drive trips.

WARNING 165, ATEX ETR freq.lim.warning

The drive is running for more than 50 s below the allowed minimum frequency (parameter 1-98 ATEX ETR interpol. points freq.).

ALARM 166, ATEX ETR freq.lim.alarm

The drive has operated for more than 60 s (in a period of 600 s) below the allowed minimum frequency (parameter 1-98 ATEX ETR interpol. points freq.).

WARNING 200, Fire mode

The drive is operating in fire mode. The warning clears when fire mode is removed. Refer to the fire mode data in the alarm log.

WARNING 201, Fire mode was active

The drive has entered fire mode. Cycle power to the unit to remove the warning. Refer to the fire mode data in the alarm log.

WARNING 202, Fire mode limits exceeded

While operating in fire mode, 1 or more alarm conditions that would normally trip the unit have been ignored. Operating in this condition voids unit warranty. Cycle power to the unit to remove the warning. Refer to the fire mode data in the alarm log.

WARNING 203, Missing motor

With a drive operating multi-motors, an underload condition was detected. This condition can indicate a missing motor. Inspect the system for proper operation.

WARNING 204, Locked rotor

With a drive operating multi-motors, an overload condition was detected. This condition can indicate a locked rotor. Inspect the motor for proper operation.

WARNING 219, Compressor interlock

At least 1 compressor is inversely interlocked via a digital input. The interlocked compressors can be viewed in parameter 25-87 Inverse Interlock.

ALARM 243, Brake IGBT

This alarm is only for multi-drive systems. It is equivalent to alarm 27, Brake chopper fault. The report value in the alarm log indicates which drive module generated the alarm. This IGBT fault can be caused by any of the following:

- The DC fuse is blown.
- The brake jumper is not in position.
- The Klixon switch opened due to an overtemperature condition in the brake resistor.

The report value in the alarm log indicates which drive module generated the alarm:

1 = Left drive module.

2 = Second drive module from left.

3 = Third drive module from left (in 4-module module systems).

4 = Fourth drive module from left (in 4-module module systems).

ALARM 245, Heat sink sensor

No feedback from the heat sink temperature sensor. The signal from the IGBT thermal sensor is not available on the power card. This alarm is equivalent to alarm 39, Heat sink sensor. The report value in the alarm log indicates which drive module generated the alarm:

1 = Left drive module.

2 = Second drive module from left.

3 = Third drive module from left (in 4-module module systems).

4 = Fourth drive module from left (in 4-module module systems).

Troubleshooting

Check the following:

- Power card.
- Gatedrive card.
- Ribbon cable between the power card and the gate drive card.

ALARM 246, Power card supply

This alarm is only for multi-drive systems. It is equivalent to alarm 46, Power card supply. The report value in the alarm log indicates which drive module generated the alarm:

1 = Left drive module.

2 = Second drive module from left.

3 = Third drive module from left (in 4-module systems).

4 = Fourth drive module from left (in 4-module systems).

ALARM 247, Power card temperature

This alarm is only for multi-drive systems. It is equivalent to alarm 69, Power card temperature. The report value in the alarm log indicates which drive module generated the alarm:

1 = Left drive module.

2 = Second drive module from left.

3 = Third drive module from left (in 4-module module systems).

4 = Fourth drive module from left (in 4-module module systems).

ALARM 248, Illegal power section configuration

This alarm is only for multi-drive systems. It is equivalent to alarm 79, Illegal power section configuration. The report value in the alarm log indicates which drive module generated the alarm:

1 = Left drive module.

2 = Second drive module from left.

3 = Third drive module from left (in 4-module systems).

4 = Fourth drive module from left (in 4-module systems).

Troubleshooting

Check the following:

- The current scaling cards on the MDCIC.

WARNING 250, New spare part

The power or switch mode supply has been exchanged. Restore the drive type code in the EEPROM. Select the correct type code in parameter 14-23 Typecode Setting according to the label on the drive. Remember to select Save to EEPROM at the end.

WARNING 251, New type code

The power card or other components have been replaced and the type code has been changed.

Troubleshooting

- Reset to remove the warning and to resume normal operation.

Troubleshooting

Table 36 — Troubleshooting

Symptom	Possible cause	Test	Solution
Display dark/No function	Missing input power.	See Table 6.1.	Check the input power source.
	Missing or open fuses.	See Open power fuses in this table for possible causes.	Follow the recommendations provided.
	No power to the LCP.	Check the LCP cable for proper connection or damage.	Replace the faulty LCP or connection cable.
	Shortcut on control voltage (terminal 12 or 50) or at control terminals.	Check the 24 V control voltage supply for terminal 12/13 to 20.39, or 10 V supply for terminals 50.55.	Wire the terminals properly.
	Incompatible LCP (LCP from CAR102 2800 or 5000/6000/8000/FCD or FCM).	—	Use only LCP 101 (P/N 130B1124) or LCP 102 (P/N 130B1107).
	Wrong contrast setting.	—	Press [Status] + [▲]/[▼] to adjust the contrast.
	Display (LCP) is defective.	Test using a different LCP.	Replace the faulty LCP or connection cable.
	Internal voltage supply fault or SMPS is defective.	—	Contact supplier.
Intermittent display	Overloaded supply (SMPS) due to improper control wiring or a fault within the AC drive.	To rule out a problem in the control wiring, disconnect all control wiring by removing the terminal blocks.	If the display stays lit, the problem is in the control wiring. Check the wiring for shorts or incorrect connections. If the display continues to cut out, follow the procedure for Display dark/No function.
Motor not running	Service switch open or missing motor connection.	Check if the motor is connected and the connection is not interrupted by a service switch or other device.	Connect the motor and check the service switch.
	No mains power with 24 V DC option card.	If the display is functioning, but there is no output, check that mains power is applied to the AC drive.	Apply mains power.
	LCP Stop.	Check if [Off] has been pressed.	Press [Auto On] or [Hand On] (depending on operating mode).
	Missing start signal (Standby).	Check parameter 5-10 Terminal 18 Digital Input for correct setting for terminal 18. Use default setting.	Apply a valid start signal.
	Motor coast signal active (Coasting).	Check parameter 5-12 Terminal 27 Digital Input for correct setting for terminal 27 (use default setting).	Apply 24 V on terminal 27 or program this terminal to [0] No operation.
	Wrong reference signal source.	Check reference signal: · Local. · Remote or bus reference? · Preset reference active? · Terminal connection correct? · Scaling of terminals correct? · Reference signal available?	Program correct settings. Check parameter 3-13 Reference Site. Set preset reference active in parameter group 3-1* References. Check for correct wiring. Check scaling of terminals. Check reference signal.
Motor running in wrong direction	Motor rotation limit.	Check that parameter 4-10 Motor Speed Direction is programmed correctly.	Program correct settings.
	Active reversing signal.	Check if a reversing command is programmed for the terminal in parameter group 5-1* Digital inputs.	Deactivate reversing signal.
	Wrong motor phase connection.	—	See "Motor Rotation" on page 58.
Motor is not reaching maximum speed	Frequency limits set wrong.	Check output limits in parameter 4-13 Motor Speed High Limit [RPM], parameter 4-14 Motor Speed High Limit [Hz], and parameter 4-19 Max Output Frequency.	Program correct limits.
	Reference input signal not scaled correctly.	Check reference input signal scaling in parameter group 6-0* Analog I/O mode and parameter group 3-1* References.	Program correct settings.
Motor speed unstable	Possible incorrect parameter settings.	Check the settings of all motor parameters, including all motor compensation settings. For closed-loop operation, check PID settings.	Check settings in parameter group 1-6* Load Depen. Setting. For closed-loop operation, check settings in parameter group 20-0* Feedback.
Motor runs rough	Possible overmagnetization.	Check for incorrect motor settings in all motor parameters.	Check motor settings in parameter groups 1-2* Motor data, 1-3* Adv Motor Data, and 1-5* Load Indep. Setting.
Motor does not brake	Possible incorrect settings in the brake parameters. Rampdown times may be too short.	Check brake parameters. Check ramp time settings.	Check parameter groups 2-0* DC Brake and 3-0* Reference Limits.

Table 36 — Troubleshooting

Symptom	Possible cause	Test	Solution
Open power fuses	Phase-to-phase short.	Motor or panel has a short phase-to-phase. Check motor and panel phases for shorts.	Eliminate any shorts detected.
	Motor overload.	Motor is overloaded for the application.	Perform start-up test and verify that motor current is within specifications. If motor current is exceeding the nameplate full load current, the motor can run only with reduced load. Review the specifications for the application.
	Loose connections.	Perform pre-start-up check for loose connections.	Tighten loose connections.
Mains current imbalance greater than 3%	Problem with mains power (see alarm 4, Mains phase loss description).	Rotate input power leads into the 1 position: A to B, B to C, C to A.	If imbalanced leg follows the wire, it is a power problem. Check the mains supply.
	Problem with the AC drive.	Rotate input power leads into the AC drive 1 position: A to B, B to C, C to A.	If the imbalanced leg stays on same input terminal, it is a problem with the AC drive. Contact supplier.
Motor current imbalance greater than 3%	Problem with motor or motor wiring.	Rotate output motor cables 1 position: U to V, V to W, W to U.	If the imbalanced leg follows the wire, the problem is in the motor or motor wiring. Check motor and motor wiring.
	Problem with AC drive.	Rotate output motor cables 1 position: U to V, V to W, W to U.	If the imbalanced leg stays on same output terminal, it is a problem with the unit. Contact supplier.
AC drive acceleration problems	Motor data are entered incorrectly.	If warnings or alarms occur, see "List of Warnings and Alarms" on page 70. Check that motor data are entered correctly.	Increase the ramp-up time in parameter 3-41 Ramp 1 Ramp Up Time. Increase current limit in parameter 4-18 Current Limit. Increase torque limit in parameter 4-16 Torque Limit Motor Mode.
AC drive deceleration problems	Motor data are entered incorrectly.	If warnings or alarms occur, see "List of Warnings and Alarms" on page 70. Check that motor data are entered correctly.	Increase the ramp-down time in parameter 3-42 Ramp 1 Ramp Down Time. Enable overvoltage control in parameter 2-17 Over-voltage Control.

SPECIFICATIONS

Electrical Data

ELECTRICAL DATA FOR ENCLOSURES D1H-D4H, 3X200-240 V

Table 37 — Electrical Data for Enclosures D1h/D3h, Mains Supply 3x200-240 V AC

HVAC Drive CAR 102	N55K	N75K
Normal overload (Normal overload=110% current during 60 s)	NO	NO
Typical shaft output at 230 V [kW]	55	75
Typical shaft output at 230 V [hp]	75	100
Enclosure size		D1h/D3h
Output current (3-phase)		
Continuous (at 230 V) [A]	190	240
Intermittent (60 s overload) (at 230 V) [A]	209	264
Continuous kVA (at 230 V) [kVA]	76	96
Maximum input current		
Continuous (at 230 V) [A]	183	231
Maximum number and size of cables per phase		
Mains, motor, brake, and load share [mm² (AWG)]	2x95 (2x3/0)	2x95 (2x3/0)
Maximum external mains fuses [A]^a	315	350
Estimated power loss at 230 V [W]^{b,c}	1505	2398
Efficiency^c	0.97	0.97
Output frequency [Hz]	0-590	0-590
Heat sink overtemperature trip [°C (°F)]	110 (230)	110 (230)
Control card overtemperature trip [°C (°F)]	75 (167)	75 (167)

NOTE(S):

- For fuse ratings, see "Fuses and Circuit Breakers" on page 88.
- Typical power loss is at normal conditions and expected to be within ±15% (tolerance relates to variety in voltage and cable conditions). These values are based on a typical motor efficiency (IE3 border line). Lower efficiency motors add to the power loss in the drive. Applies to dimensioning of drive cooling. If the switching frequency is higher than the default setting, the power losses can increase. LCP and typical control card power consumptions are included. For power loss data according to EN 50598-2, contact Carrier. Options and customer load can add up to 30 W to the losses, though usually a fully loaded control card and options for slots A and B each add only 4 W.
- Measured using 5 m (16.4 ft) shielded motor cables at rated load and rated frequency. Efficiency measured at nominal current. For energy efficiency class, see "Ambient Conditions" on page 86. For part load losses, contact Carrier.

Table 38 — Electrical Data for Enclosures D2h/D4h, Mains Supply 3x200-240 V AC

HVAC Drive CAR 102	N90K	N100	N150	N160
Normal overload (Normal overload=110% current during 60 s)	NO	NO	NO	NO
Typical shaft output at 230 V [kW]	90	110	150	160
Typical shaft output at 230 V [hp]	120	150	200	215
Enclosure size	D2h/D4h			
Output current (3-phase)				
Continuous (at 230 V) [A]	302	361	443	535
Intermittent (60 s overload) (at 230 V) [A]	332	397	487	589
Continuous kVA (at 230 V) [kVA]	120	144	176	213
Maximum input current				
Continuous (at 230 V) [A]	291	348	427	516
Maximum number and size of cables per phase				
Mains, motor, brake, and load share [mm² (AWG)]	2x185 (2x350 mcm)	2x185 (2x350 mcm)	2x185 (2x350 mcm)	2x185 (2x350 mcm)
Maximum external mains fuses [A]^a	400	550	630	800
Estimated power loss at 230 V [W]^{b,c}	2623	3284	4117	5209
Efficiency^c	0.97	0.97	0.97	0.97
Output frequency [Hz]	0-590	0-590	0-590	0-590
Heat sink overtemperature trip [°C (°F)]	110 (230)	110 (230)	110 (230)	110 (230)
Control card overtemperature trip [°C (°F)]	80 (176)	80 (176)	80 (176)	80 (176)

NOTE(S):

- a. For fuse ratings, see “Fuses and Circuit Breakers” on page 88.
- b. Typical power loss is at normal conditions and expected to be within $\pm 15\%$ (tolerance relates to variety in voltage and cable conditions). These values are based on a typical motor efficiency (IE/IE3 border line). Lower efficiency motors add to the power loss in the drive. Applies to dimensioning of drive cooling. If the switching frequency is higher than the default setting, the power losses can increase. LCP and typical control card power consumptions are included. For power loss data according to EN 50598-2, contact Carrier. Options and customer load can add up to 30 W to the losses, though usually a fully loaded control card and options for slots A and B each add only 4 W.
- c. Measured using 5 m (16.4 ft) shielded motor cables at rated load and rated frequency. Efficiency measured at nominal current. For energy efficiency class, see “Ambient Conditions” on page 86. For part load losses, contact Carrier.

Electrical Data for Enclosures D1h-D8h, 3x380-480 V

Table 39 — Electrical Data for Enclosures D1h/D3h/D5h/D6h, Mains Supply 3x380-480 V AC

HVAC Drive CAR 102	N110	N132	N160
Normal overload (Normal overload=110% current during 60 s)	NO	NO	NO
Typical shaft output at 400 V [kW]	110	132	160
Typical shaft output at 460 V [kW]	150	200	250
Typical shaft output at 480 V [kW]	132	160	200
Enclosure size	D1h/D3h/D5h/D6h		
Output current (3-phase)			
Continuous (at 400 V) [A]	212	260	315
Intermittent (60 s overload) (at 400 V) [A]	233	286	347
Continuous (at 460/480 V) [A]	190	240	302
Intermittent (60 s overload) (at 460/480 V) [A]	209	264	332
Continuous kVA (at 400 V) [kVA]	147	180	218
Continuous kVA (at 460 V) [kVA]	151	191	241
Continuous kVA (at 480 V) [kVA]	165	208	262
Maximum input current			
Continuous (at 400 V) [A]	204	251	304
Continuous (at 460/480 V) [A]	183	231	291
Maximum number and size of cables per phase			
Mains, motor, brake, and load share [mm² (AWG)]	2x95 (2x3/0)	2x95 (2x3/0)	2x95 (2x3/0)
Maximum external mains fuses [A]^a	315	350	400
Estimated power loss at 400 V [W]^{b,c}	2555	2949	3764
Estimated power loss at 460 V [W]^{b,c}	2257	2719	3628
Efficiency^c	0.98	0.98	0.98
Output frequency [Hz]	0-590	0-590	0-590
Heat sink overtemperature trip [°C (°F)]	110 (230)	110 (230)	110 (230)
Control card overtemperature trip [°C (°F)]	75 (167)	75 (167)	75 (167)

NOTE(S):

- a. For fuse ratings, see "Fuses and Circuit Breakers" on page 88.
- b. Typical power loss is at normal conditions and expected to be within $\pm 15\%$ (tolerance relates to variety in voltage and cable conditions). These values are based on a typical motor efficiency (IE/IE3 border line). Lower efficiency motors add to the power loss in the drive. Applies to dimensioning of drive cooling. If the switching frequency is higher than the default setting, the power losses can increase. LCP and typical control card power consumptions are included. For power loss data according to EN 50598-2, contact Carrier. Options and customer load can add up to 30 W to the losses, though usually a fully loaded control card and options for slots A and B each add only 4 W.
- c. Measured using 5 m (16.4 ft) shielded motor cables at rated load and rated frequency. Efficiency measured at nominal current. For energy efficiency class, see "Ambient Conditions" on page 86. For part load losses, contact Carrier.

Table 40 — Electrical Data for Enclosures D2h/D4h/D7h/D8h, Mains Supply 3x380-480 V AC

HVAC Drive CAR 102	N200	N250	N315
Normal overload (Normal overload=110% current during 60 s)	NO	NO	NO
Typical shaft output at 400 V [kW]	200	250	315
Typical shaft output at 460 V [kW]	300	350	450
Typical shaft output at 480 V [kW]	250	315	355
Enclosure size	D2h/D4h/D7h/D8h		
Output current (3-phase)			
Continuous (at 400 V) [A]	395	480	588
Intermittent (60 s overload) (at 400 V) [A]	435	528	647
Continuous (at 460/480 V) [A]	361	443	535
Intermittent (60 s overload) (at 460/480 V) [A]	397	487	589
Continuous kVA (at 400 V) [kVA]	274	333	407
Continuous kVA (at 460 V) [kVA]	288	353	426
Continuous kVA (at 480 V) [kVA]	313	384	463
Maximum input current			
Continuous (at 400 V) [A]	381	463	567
Continuous (at 460/480 V) [A]	348	427	516
Maximum number and size of cables per phase			
Mains, motor, brake, and load share [mm² (AWG)]	2x185 (2x350 mcm)	2x185 (2x350 mcm)	2x185 (2x350 mcm)
Maximum external mains fuses [A]^a	550	630	800
Estimated power loss at 400 V [W]^{b,c}	4109	5129	6663
Estimated power loss at 460 V [W]^{b,c}	3561	4558	5703
Efficiency^c	0.98	0.98	0.98
Output frequency [Hz]	0-590	0-590	0-590
Heat sink overtemperature trip [°C (°F)]	110 (230)	110 (230)	110 (230)
Control card overtemperature trip [°C (°F)]	80 (176)	80 (176)	80 (176)

NOTE(S):

- a. For fuse ratings, see "Fuses and Circuit Breakers" on page 88.
- b. Typical power loss is at normal conditions and expected to be within $\pm 15\%$ (tolerance relates to variety in voltage and cable conditions). These values are based on a typical motor efficiency (IE/IE3 border line). Lower efficiency motors add to the power loss in the drive. Applies to dimensioning of drive cooling. If the switching frequency is higher than the default setting, the power losses can increase. LCP and typical control card power consumptions are included. For power loss data according to EN 50598-2, contact Carrier. Options and customer load can add up to 30 W to the losses, though usually a fully loaded control card and options for slots A and B each add only 4 W.
- c. Measured using 5 m (16.4 ft) shielded motor cables at rated load and rated frequency. Efficiency measured at nominal current. For energy efficiency class, see "Ambient Conditions" on page 86. For part load losses, contact Carrier.

Table 41 — Electrical Data for Enclosures D1h/D3h/D5h/D6h, Mains Supply 3x525-690 V AC

HVAC Drive CAR 102	N75K	N90K	N110K	N132	N160
Normal overload (Normal overload=110% current during 60 s)	NO	NO	NO	NO	NO
Typical shaft output at 525 V [kW]	55	75	90	110	132
Typical shaft output at 575 V [kW]	75	100	125	150	200
Typical shaft output at 690 V [kW]	75	90	110	132	160
Enclosure size			D1h/D3h/D5h/D6h		
Output current (3-phase)					
Continuous (at 525 V) [A]	90	113	137	162	201
Intermittent (60 s overload) (at 525 V) [A]	99	124	151	178	221
Continuous (at 575/690 V) [A]	86	108	131	155	192
Intermittent (60 s overload) (at 575/690 V) [A]	95	119	144	171 211	
Continuous kVA (at 525 V) [kVA]	82	103	125	147	183
Continuous kVA (at 575 V) [kVA]	86	108	131	154	191
Continuous kVA (at 690 V) [kVA]	103	129	157	185	230
Maximum input current					
Continuous (at 525 V) [A]	87	109	132	156	193
Continuous (at 575/690 V) [A]	83	104	126	149	185
Maximum number and size of cables per phase					
Mains, motor, brake, and load share [mm² (AWG)]	2x95 (2x3/0)	2x95 (2x3/0)	2x95 (2x3/0)	2x95 (2x3/0)	2x95 (2x3/0)
Maximum external mains fuses [A]^a	160	315	315	315	315
Estimated power loss at 575 V [W]^{b,c}	1162	1428	1740	2101	2649
Estimated power loss at 690 V [W]^{b,c}	1204	1477	1798	2167	2740
Efficiency^c	0.98	0.98	0.98	0.98	0.98
Output frequency [Hz]	0-590	0-590	0-590	0-590	0-590
Heat sink overtemperature trip [°C (°F)]	110 (230)	110 (230)	110 (230)	110 (230)	110 (230)
Control card overtemperature trip [°C (°F)]	75 (167)	75 (167)	75 (167)	75 (167)	75 (167)

NOTE(S):

- a. For fuse ratings, see "Fuses and Circuit Breakers" on page 88.
- b. Typical power loss is at normal conditions and expected to be within $\pm 15\%$ (tolerance relates to variety in voltage and cable conditions). These values are based on a typical motor efficiency (IE/IE3 border line). Lower efficiency motors add to the power loss in the drive. Applies to dimensioning of drive cooling. If the switching frequency is higher than the default setting, the power losses can increase. LCP and typical control card power consumptions are included. For power loss data according to EN 50598-2, contact Carrier. Options and customer load can add up to 30 W to the losses, though usually a fully loaded control card and options for slots A and B each add only 4 W.
- c. Measured using 5 m (16.4 ft) shielded motor cables at rated load and rated frequency. Efficiency measured at nominal current. For energy efficiency class, see "Ambient Conditions" on page 86. For part load losses, contact Carrier.

Table 42 — Electrical Data for Enclosures D2h/D4h/D7h/D8h, Mains Supply 3x525-690 V AC

HVAC Drive CAR 102	N200	N250	N315	N400
Normal overload (Normal overload=110% current during 60 s)	NO	NO	NO	NO
Typical shaft output at 525 V [kW]	160	200	250	315
Typical shaft output at 575 V [kW]	250	300	350	400
Typical shaft output at 690 V [kW]	200	250	315	400
Enclosure size			D2h/D4h/D7h/D8h	
Output current (3-phase)				
Continuous (at 525 V) [A]	253	303	360	418
Intermittent (60 s overload) (at 525 V) [A]	278	333	396	460
Continuous (at 575/690 V) [A]	242	290	344	400
Intermittent (60 s overload) (at 575/690 V) [A]	266	219	378	440
Continuous kVA (at 525 V) [kVA]	230	276	327	380
Continuous kVA (at 575 V) [kVA]	241	289	343	398
Continuous kVA (at 690 V) [kVA]	289	347	411	478
Maximum input current				
Continuous (at 525 V) [A]	244	292	347	403
Continuous (at 575/690 V) [A]	233	279	332	385
Maximum number and size of cables per phase				
Mains, motor, brake, and load share [mm² (AWG)]	2x185 (2x350)	2x185 (2x350)	2x185 (2x350)	2x185 (2x350)
Maximum external mains fuses [A]^a	550	550	550	550
Estimated power loss at 575 V [W]^{b,c}	3074	3723	4465	5028
Estimated power loss at 690 V [W]^{b,c}	3175	3851	4614	5155
Efficiency^c	0.98	0.98	0.98	0.98
Output frequency [Hz]	0.590	0.590	0.590	0.590
Heat sink overtemperature trip [°C (°F)]	110 (230)	110 (230)	110 (230)	110 (230)
Control card overtemperature trip [°C (°F)]	80 (176)	80 (176)	80 (176)	80 (176)

NOTE(S):

- a. For fuse ratings, see "Fuses and Circuit Breakers" on page 88.
- b. Typical power loss is at normal conditions and expected to be within $\pm 15\%$ (tolerance relates to variety in voltage and cable conditions). These values are based on a typical motor efficiency (IE/IE3 border line). Lower efficiency motors add to the power loss in the drive. Applies to dimensioning of drive cooling. If the switching frequency is higher than the default setting, the power losses can increase. LCP and typical control card power consumptions are included. For power loss data according to EN 50598-2, contact Carrier. Options and customer load can add up to 30 W to the losses, though usually a fully loaded control card and options for slots A and B each add only 4 W.
- c. Measured using 5 m (16.4 ft) shielded motor cables at rated load and rated frequency. Efficiency measured at nominal current. For energy efficiency class, see "Ambient Conditions" on page 86. For part load losses, contact Carrier.

Mains Supply

Mains supply (L1, L2, L3)

Supply voltage 200.240 V, 380.480 V $\pm 10\%$, 525.690 V $\pm 10\%$

Mains voltage low/mains voltage drop-out (for 380.480 V and 525.690 V only):

During low mains voltage or a mains drop-out, the drive continues until the DC-link voltage drops below the minimum stop level. Typically, the minimum level corresponds to 15% below the lowest rated supply voltage of the drive. Power-up and full torque cannot be expected at mains voltage lower than 10% below the lowest rated supply voltage of the drive.

Supply frequency 50/60 Hz $\pm 5\%$

Maximum imbalance temporary between mains phases 3.0% of rated supply voltage¹⁾

True power factor (λ) ≥ 0.9 nominal at rated load

Displacement power factor ($\cos \phi$) near unity (>0.98)

Switching on input supply L1, L2, L3 (power-ups) Maximum 1 time/2 minute

Environment according to EN60664-1 Overvoltage category III/pollution degree 2

The drive is suitable for use on a circuit capable of delivering up to 100 kA short-circuit current rating (SCCR) at 240/480/600 V.

Motor Output and Torque Data

Motor output (U, V, W)

Output voltage 0-100% of supply voltage

Output frequency 0-590 Hz¹⁾

Output frequency in flux mode 0-300 Hz

Switching on output Unlimited

Ramp times 0.01-3600 s

1) Dependent on voltage and power.

Torque characteristics

Starting torque (constant torque) Maximum 150% for 60 s¹⁾,²⁾

Overload torque (constant torque) Maximum 150% for 60 s¹⁾,²⁾

1) Percentage relates to the nominal current of the drive.

2) Once every 10 minutes.

Ambient Conditions

Environment

D1h/D2h/D5h/D6h/D7h/D8h enclosure IP21/Type 1, IP54/Type 12

D3h/D4h enclosure IP20/Chassis

Vibration test (standard/ruggedized) 0.7 g/1.0 g

Relative humidity 5-95% (IEC 721-3-3; Class 3K3 (non-condensing) during operation)

Aggressive environment (IEC 60068-2-43) H2S test Class Kd

Aggressive gases (IEC 60721-3-3) Class 3C3

Test method according to IEC 60068-2-43 H2S (10 days)

Ambient temperature (at 60 AVM)

- with derating Maximum 55°C (131°F)¹⁾

- with full output power of typical EFF2 motors (up to 90% output current) Maximum 50°C (122°F)¹⁾

- at full continuous FC output current Maximum 45°C (113°F)¹⁾

Minimum ambient temperature during full-scale operation 0°C (32°F)

Minimum ambient temperature at reduced performance -10°C (14°F)

Temperature during storage/transport -25 to +65/70°C (13 to 149/158°F)

Maximum altitude above sea level without derating 1000 m (3281 ft)

Maximum altitude above sea level with derating 3000 m (9842 ft)

1) For more information on derating, see the design guide.

EMC standards, Emission EN 61800-3

EMC standards, Immunity EN 61800-3

Energy efficiency class¹⁾ IE2

1) Determined according to EN 50598-2 at:

• Rated load.

• 90% rated frequency.

• Switching frequency factory setting.

• Switching pattern factory setting.

Cable Specifications

Cable lengths and cross-sections for control cables¹⁾

Maximum motor cable length, shielded/armored 150 m (492 ft)

Maximum motor cable length, unshielded/unarmored 300 m (984 ft)

Maximum cross-section to motor, mains, load sharing, and brake
See "Electrical Data" on page 80.

Maximum cross-section to control terminals, rigid wire 1.5 mm²/16 AWG (2x0.75 mm²)

Maximum cross-section to control terminals, flexible cable 1 mm²/18 AWG

Maximum cross-section to control terminals, cable with enclosed core 0.5 mm²/20 AWG

Minimum cross-section to control terminals. 0.25 mm²/23 AWG

1) For power cables, see electrical data tables in "Electrical Data" on page 80.

Control Input/Output and Control Data

Digital inputs

Programmable digital inputs 4 (6)

Terminal number 18, 19, 271), 291), 32, 33

Logic PNP or NPN

Voltage level 0-24 V DC

Voltage level, logic 0 PNP <5 V DC

Voltage level, logic 1 PNP >10 V DC

Voltage level, logic 0 NPN >19 V DC

Voltage level, logic 1 NPN <14 V DC

Maximum voltage on input 28 V DC

Input resistance, Ri Approximately 4 k Ω

All digital inputs are galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

1) Terminals 27 and 29 can also be programmed as outputs.

Analog inputs

Number of analog inputs 2

Terminal number 53, 54

Modes Voltage or current

Mode select Switches A53 and A54

Voltage mode Switch A53/A54=(U)

Voltage level -10 V to +10 V (scaleable)

Input resistance, Ri Approximately 10 k Ω

Maximum voltage ± 20 V

Current mode Switch A53/A54=(I)

Current level 0/4 to 20 mA (scaleable)

Input resistance, Ri Approximately 200 Ω

Maximum current 30 mA

Resolution for analog inputs 10 bit (+ sign)

Accuracy of analog inputs Maximum error 0.5% of full scale

Bandwidth 100 Hz

The analog inputs are galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.




Fig. 67 — PELV Isolation

Pulse inputs

Programmable pulse inputs 2

Terminal number pulse 29, 33

Maximum frequency at terminal 29, 33 (push-pull driven) 110 kHz

Maximum frequency at terminal 29, 33 (open collector) 5 kHz

Minimum frequency at terminal 29, 33 4 Hz

Voltage level See Digital Inputs in “Control Input/Output and Control Data” on page 86

Maximum voltage on input 28 V DC

Input resistance, R_i Approximately 4 k Ω

Pulse input accuracy (0.1-1 kHz) Maximum error: 0.1% of full scale

Analog output

Number of programmable analog outputs 1

Terminal number 42

Current range at analog output 0/4-20 mA

Maximum resistor load to common at analog output 500 Ω

Accuracy on analog output Maximum error: 0.8% of full scale

Resolution on analog output 8 bit

The analog output is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Control card, RS485 serial communication

Terminal number 68 (P, TX+, RX+), 69 (N, TX-, RX-)

Terminal number 61 Common for terminals 68 and 69

The RS485 serial communication circuit is functionally separated from other central circuits and galvanically isolated from the supply voltage (PELV).

Digital output

Programmable digital/pulse outputs 2

Terminal number 27, 291)

Voltage level at digital/frequency output 0-24 V

Maximum output current (sink or source) 40 mA

Maximum load at frequency output 1 k Ω

Maximum capacitive load at frequency output 10 nF

Minimum output frequency at frequency output 0 Hz

Maximum output frequency at frequency output 32 kHz

Accuracy of frequency output Maximum error: 0.1% of full scale

Resolution of frequency outputs 12 bit

1) Terminals 27 and 29 can also be programmed as inputs.

The digital output is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Control card, 24 V DC output

Terminal number 12, 13

Maximum load 200 mA

The 24 V DC supply is galvanically isolated from the supply voltage (PELV), but has the same potential as the analog and digital inputs and outputs.

Relay outputs

Programmable relay outputs 2

Maximum cross-section to relay terminals 2.5 mm² (12 AWG)

Minimum cross-section to relay terminals 0.2 mm² (30 AWG)

Length of stripped wire 8 mm (0.3 in.)

Relay 01 terminal number 1-3 (break), 1-2 (make)

Maximum terminal load (AC-1)1) on 1-2 (NO) (Resistive load)2), 3) 400 V AC, 2 A

Maximum terminal load (AC-15)1) on 1-2 (NO) (Inductive load @ cos ϕ 0.4) 240 V AC, 0.2 A

Maximum terminal load (DC-1)1) on 1-2 (NO) (Resistive load) 80 V DC, 2 A

Maximum terminal load (DC-13)1) on 1-2 (NO) (Inductive load) 24 V DC, 0.1 A

Maximum terminal load (AC-1)1) on 1-3 (NC) (Resistive load) 240 V AC, 2 A

Maximum terminal load (AC-15)1) on 1-3 (NC) (Inductive load @ cos ϕ 0.4) 240 V AC, 0.2 A

Maximum terminal load (DC-1)1) on 1-3 (NC) (Resistive load) 50 V DC, 2 A

Maximum terminal load (DC-13)1) on 1-3 (NC) (Inductive load) 24 V DC, 0.1 A

Minimum terminal load on 1-3 (NC), 1-2 (NO) 24 V DC 10 mA, 24 V AC 2 mA

Environment according to EN 60664-1 Overvoltage category III/ pollution degree 2

Relay 02 terminal number 4.6 (break), 4.5 (make)

Maximum terminal load (AC-1)1) on 4.5 (NO) (Resistive load)2), 3) 400 V AC, 2 A

Maximum terminal load (AC-15)1) on 4.5 (NO) (Inductive load @ cos ϕ 0.4) 240 V AC, 0.2 A

Maximum terminal load (DC-1)1) on 4.5 (NO) (Resistive load) 80 V DC, 2 A

Maximum terminal load (DC-13)1) on 4.5 (NO) (Inductive load) 24 V DC, 0.1 A

Maximum terminal load (AC-1)1) on 4.6 (NC) (Resistive load) 240 V AC, 2 A

Maximum terminal load (AC-15)1) on 4.6 (NC) (Inductive load @ cos ϕ 0.4) 240 V AC, 0.2 A

Maximum terminal load (DC-1)1) on 4.6 (NC) (Resistive load) 50 V DC, 2 A

Maximum terminal load (DC-13)1) on 4.6 (NC) (Inductive load) 24 V DC, 0.1 A

Minimum terminal load on 4.6 (NC), 4.5 (NO) 24 V DC 10 mA, 24 V AC 2 mA

Environment according to EN 60664-1 Overvoltage category III/ pollution degree 2

The relay contacts are galvanically isolated from the rest of the circuit by reinforced isolation (PELV).

1) IEC 60947 part 4 and 5.

2) Overvoltage Category II.

3) UL applications 300 V AC 2 A.

Control card, +10 V DC output
 Terminal number 50
 Output voltage $10.5 \text{ V} \pm 0.5 \text{ V}$
 Maximum load 25 mA
 The 10 V DC supply is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.
 Control characteristics
 Resolution of output frequency at $0.1000 \text{ Hz} \pm 0.003 \text{ Hz}$
 System response time (terminals 18, 19, 27, 29, 32, 33) $\leq 2 \text{ m/s}$
 Speed control range (open loop) 1:100 of synchronous speed
 Speed accuracy (open loop) 30.4000 RPM: Maximum error of $\pm 8 \text{ RPM}$
 All control characteristics are based on a 4-pole asynchronous motor.
 Control card performance
 Scan interval 5 M/S
 Control card, USB serial communication
 USB standard 1.1 (full speed)
 USB plug USB type B device plug

NOTICE

Connection to PC is carried out via a standard host/device USB cable.

The USB connection is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals. The USB connection is not galvanically isolated from ground. Use only isolated laptop/PC as connection to the USB connector on the drive or an isolated USB cable/converter.

Fuses and Circuit Breakers

FUSE SELECTION

Installing fuses on the supply side ensures that potential damage is contained inside the drive enclosure if a component breakdown (first fault) occurs inside the drive. Use the recommended fuses to ensure compliance with EN 50178, refer to Tables 43-45.

NOTICE

Use of fuses on the supply side is mandatory for IEC 60364 (CE) and NEC 2009 (UL) compliant installations.

D1h-D8h recommended fuses

Table 43 — D1h-D8h Power/Semiconductor Fuse Options, 200-240 V

Model	Bussmann part number
N55K	170M2620
N75K	170M2621
N90K	170M4015
N110	170M4015
N150	170M4016
N160	170M4018

Table 44 — D1h-D8h Power/Semiconductor Fuse Options, 380-480 V

Model	Bussmann part number
N90K	170M2619
N110	170M2620
N132	170M2621
N160	170M4015

Table 44 — D1h-D8h Power/Semiconductor Fuse Options, 380-480 V

Model	Bussmann part number
N200	170M4016
N250	170M4018

Table 45 — D1h-D8h Power/Semiconductor Fuse Options, 525-690 V

Model	Bussmann part number
N55K	170M2616
N75K	170M2619
N90K	170M2619
N110	170M2619
N132	170M2619
N160	170M4015
N200	170M4015
N250	170M4015
N315	170M4015

Type aR fuses are recommended for drives in enclosure sizes D3h-D4h. See Table 46.

Table 46 — D3h-D4h Power/Semiconductor Fuse Sizes

Model	200-240 V	380-480 V	525-690 V
N45K	ar-350	—	—
N55K	ar-400	—	ar-160
N75K	ar-500	—	ar-315
N90K	ar-500	ar-315	ar-315
N110	ar-630	ar-350	ar-315
N132	—	ar-400	ar-315
N150	ar-800	—	—
N160	—	ar-500	ar-550
N200	—	ar-630	ar-550
N250	—	ar-800	ar-550
N315	—	—	ar-550

Table 47 — D1h-D8h Space Heater Fuse Recommendation

Bussmann	Rating
LPJ-21/2SP	2.5 A, 600 V

For UL compliance, use the Bussmann 170M series fuses for units supplied without a disconnect, contactor, or circuit breaker option. If a disconnect, contactor, or circuit breaker option is supplied with the drive, see Tables 49-52 for SCCR ratings and UL fuse criteria.

SHORT-CIRCUIT CURRENT RATING (SCCR)

The short-circuit current rating (SCCR) represents the maximum level of short-circuit current that the drive can safely withstand. If the drive is not supplied with a mains disconnect, contactor, or circuit breaker, the SCCR of the drive is 100000 A at all voltages (200-690 V).

If the drive is supplied with a mains disconnect only, the SCCR of the drive is 100000 amps at all voltages (200-600 V). See Table 49. If the drive is supplied with a contactor only, refer to Table 50 for the SCCR. If the drive contains both a contactor and disconnect, see Table 51.

If the drive is supplied with a circuit breaker only, the SCCR depends on the voltage. Refer to Table 52.

Table 48 — D5h and D7h Drives Supplied with a Disconnect Only

Enclosure size	≤600 V IEC/UL
D5h	100000 A ^a
D7h	100000 A ^b

NOTE(S):

- a. With an upstream branch protection Class J fuse with maximum rating of 600 A.
- b. With an upstream branch protection Class J fuse with maximum rating of 800 A.

Table 49 — D6h and D8h Drives Supplied with a Contactor Only

Enclosure size	415 V IEC^a	480 V UL^b	600 V UL^a	690 V IEC^b
D6h	100000 A	100000 A	100000 A	100000 A
D8h (excluding N315 380-480 V model)	100000 A	100000 A	100000 A	100000 A
D8h (N315 380-480 V model only)	100000 A	Contact Carrier	Not applicable	Not applicable

NOTE(S):

- a. With gL/gG fuses: 425 A maximum fuse size for D6h, and 630 A maximum fuse size for D8h.
- b. With external upstream Class J fuses: 450 A maximum fuse size for D6h, and 600 A maximum fuse size for D8h.

Table 50 — D6h and D8h Drives Supplied with a Disconnect and Contactor

Enclosure size	415 V IEC^a	480 V UL^b	600 V UL^b
D6h	100000 A	100000 A	100000 A
D8h (excluding N315 380-480 V model)	100000 A	100000 A	100000 A
D8h (N315 380-480 V model only)	100000 A	Contact Carrier	Not applicable

NOTE(S):

- a. With gL/gG fuses: 425A maximum fuse size for D6h, and 630A maximum fuse size for D8h.
- b. With external upstream Class J fuses: 450 A maximum fuse size for D6h, and 600 A maximum fuse size for D8h.

Table 51 — D6h and D8h Supplied with a Circuit Breaker

Enclosure	415 V	480 V	600 V	690 V
D6h	120000 A	100000 A	65000 A	70000 A
D8h	100000 A	100000 A	42000 A	30000 A

Fastener Tightening Torques

Apply the correct torque when tightening fasteners in the locations that are listed in Table 52. Too low or too high torque when fastening an electrical connection results in a bad electrical connection. To ensure correct torque, use a torque wrench.

Table 52 — Fastener Torque Ratings

Table 52 — Fastener Torque Ratings

Location	Bolt size	Torque [Nm (in-lb)]
Heat sink access panel	M5	3.9 (35)
Serial communication cover	M5	2.3 (20)

Enclosure Dimensions

D1H EXTERIOR DIMENSIONS





Fig. 68 — Front View of D1h

130BE982.10



130BF797.10

Fig. 69 — Side View of D1h




Fig. 70 — Back View of D1h





Fig. 71 — Door Clearance for D1h



1	Mains side	2	Motor side
---	------------	---	------------

Fig. 72 — Gland Plate Dimensions for D1h

130BF669.10

130BF607.10

D2H EXTERIOR DIMENSIONS





Fig. 73 — Front View of D2h

130BF321.10



130BF799.10

Fig. 74 — Side View of D2h






Fig. 75 — Back View of D2h



130BF670.10

Fig. 76 — Door Clearance for D2h



130BF608.10

Fig. 77 — Gland Plate Dimensions for D2h

1	Mains side	2	Motor side
----------	------------	----------	------------

D3H EXTERIOR DIMENSIONS





Fig. 78 — Front View of D3h



130BF801.10

Fig. 79 — Side View of D3h






Fig. 80 — Back View of D3h

D4H ENCLOSURE DIMENSIONS



130BF323.10

Fig. 81 — Front View of D4h



130BF803.10

Fig. 82 — Side View of D4h




Fig. 83 — Back View of D4h

D5H EXTERIOR DIMENSIONS





Fig. 84 — Front View of D5h

130BF324.10



130BF805.10

Fig. 85 — Side View of D5h




Fig. 86 — Back View of D5h




Fig. 87 — Heat Sink Access Dimensions for D5h




Fig. 88 — Door Clearance for D5h






Fig. 89 — Gland Plate Dimensions for D5h

D6H EXTERIOR DIMENSIONS




130BF325.10

Fig. 90 — Front View of D6h




130BF807.10


Fig. 91 — Side View of D6h



A



B



130BF808.10

Fig. 92 — Back View of D6h




Fig. 93 — Heat Sink Access Dimensions for D6h





Fig. 94 — Door Clearance for D6h

130BF669.10



1 Mains side

2 Motor side

Fig. 95 — Gland Plate Dimensions for D6h

130BF609.10

D7H EXTERIOR DIMENSIONS





Fig. 96 — Front View of D7h



130BF809.10

Fig. 97 — Side View of D7h




Fig. 98 — Back View of D7h




Fig. 99 — Heat Sink Access Dimensions for D7h






Fig. 100 — Wall Mount Dimensions for D7h



130BF670.10

Fig. 101 — Door Clearance for D7h



130BF610.10

Fig. 102 — Gland Plate Dimensions for D7h

1 Mains side

2 Motor side

D8H EXTERIOR DIMENSIONS





Fig. 103 — Front View of D8h

1308F327.10



130BF811.10

Fig. 104 — Side View of D8h




Fig. 105 — Back View of D8h






Fig. 106 — Heat Sink Access Dimensions for D8h



130BF670.10

Fig. 107 — Door Clearance for D8h



130BF610.10

Fig. 108 — Gland Plate Dimensions for D8h

1 Mains side

2 Motor side

APPENDIX

Abbreviations and Conventions

Table 53 — Abbreviations, Acronyms, and Symbols

°C	— Degrees Celsius
°F	— Degrees Fahrenheit
Ù	— Ohm
AC	— Alternating current
AEO	— Automatic energy optimization
ACP	— Application control processor
AMA	— Automatic motor adaptation
AWG	— American wire gauge
CPU	— Central processing unit
CSIV	— Customer-specific initialization values
CT	— Current transformer
DC	— Direct current
DVM	— Digital voltmeter
EEPROM	— Electrically erasable programmable read-only memory
EMC	— Electromagnetic compatibility
EMI	— Electromagnetic interference
ESD	— Electrostatic discharge
ETR	— Electronic thermal relay
fM,N	— Nominal motor frequency
HF	— High frequency
HVAC	— Heating, ventilation, and air conditioning
Hz	— Hertz
ILIM	— Current limit
IINV	— Rated inverter output current
IM,N	— Nominal motor current
I,MAX	— Maximum output current
I,N	— Rated output current supplied by the drive
IEC	— International electrotechnical commission
IGBT	— Insulated-gate bipolar transistor
I/O	— Input/output
IP	— Ingress protection
kHz	— Kilohertz
kW	— Kilowatt
Ld	— Motor d-axis inductance
Lq	— Motor q-axis inductance
LC	— Inductor-capacitor
LCP	— Local control panel
LED	— Light-emitting diode
LOP	— Local operation pad
mA	— Milliamp
MCB	— Miniature circuit breakers
MCO	— Motion control option
MCP	— Motor control processor
MCT	— Motion control tool
MDCIC	— Multi-drive control interface card
mV	— Millivolts
NEMA	— National Electrical Manufacturers Association
NTC	— Negative temperature coefficient
PM,N	— Nominal motor power
PCB	— Printed circuit board
PE	— Protective earth
PELV	— Protective extra low voltage
PID	— Proportional integral derivative
PLC	— Programmable logic controller
P/N	— Part number
PROM	— Programmable read-only memory
PS	— Power section
PTC	— Positive temperature coefficient
PWM	— Pulse width modulation
Rs	— Stator resistance

Table 53 — Abbreviations, Acronyms, and Symbols

RAM	— Random-access memory
RCD	— Residual current device
Regen	— Regeneration terminals
RFI	— Radio frequency interference
RMS	— Root means square (cyclically alternating electric current)
RPM	— Revolutions per minute
SCR	— Silicon controlled rectifier
SMPS	— Switch mode power supply
S/N	— Serial number
STO	— Safe Torque Off
TLIM	— Torque limit
UM,N	— Nominal motor voltage
V	— Volt
VVC	— Voltage vector control
Xh	— Motor main reactance

Conventions

- Numbered lists indicate procedures.
- Bullet lists indicate other information and description of illustrations.
- Italicized text indicates:
 - Cross reference
 - Link
 - Footnote
 - Parameter name
 - Parameter group name
 - Parameter option
- All dimensions are in mm (inch).

International/North American Default Parameter Settings

Setting parameter 0-03 Regional Settings to [0] International or [1] North America changes the default settings for some parameters. Table 54 lists those parameters that are affected.

Table 54 — International/North American Default Parameter Settings

Parameter	International default parameter value	North American default parameter value
Parameter 0-03 Regional Settings	International	North America
Parameter 0-71 Date Format	DD-MM-YYYY	MM/DD/YYYY
Parameter 0-72 Time Format	24 h	12 h
Parameter 1-20 Motor Power [kW]	1)	a
Parameter 1-21 Motor Power [HP]	2)	b
Parameter 1-22 Motor Voltage	230 V/400 V/575 V	208 V/460 V/575 V
Parameter 1-23 Motor Frequency	50 Hz	60 Hz
Parameter 3-03 Maximum Reference	50 Hz	60 Hz
Parameter 3-04 Reference Function	Sum	External/Preset
Parameter 4-13 Motor Speed High Limit [RPM] ^c	1500 RPM	1800 RPM
Parameter 4-14 Motor Speed High Limit [Hz] ^d	50 Hz	60 Hz
Parameter 4-19 Max Output Frequency	100 Hz	120 Hz
Parameter 4-53 Warning Speed High	1500 RPM	1800 RPM
Parameter 5-12 Terminal 27 Digital Input	Coast inverse	External interlock
Parameter 5-40 Function Relay	Alarm	No alarm
Parameter 6-15 Terminal 53 High Ref./Feedb. Value	50	60
Parameter 6-50 Terminal 42 Output	Speed 0-HighLim	Speed 4-20 mA
Parameter 14-20 Reset Mode	Manual reset	Infinite auto reset
Parameter 22-85 Speed at Design Point [RPM] ^c	1500 RPM	1800 RPM
Parameter 22-86 Speed at Design Point [Hz]	50 Hz	60 Hz
Parameter 24-04 Fire Mode Max Reference	50 Hz	60 Hz

NOTE(S):

a. Parameter 1-20 Motor Power [kW] is only visible when parameter 0-03 Regional Settings is set to [0] International.

b. Parameter 1-21 Motor Power [HP] is only visible when parameter 0-03 Regional Settings is set to [1] North America.

c. This parameter is only visible when parameter 0-02 Motor Speed Unit is set to [0] RPM.

d. This parameter is only visible when parameter 0-02 Motor Speed Unit is set to [1] Hz.

Parameter Menu Structure

SOFTWARE 5.20	0-81	Working Days
0-** Operation / Display	0-82	Additional Working Days
0-0* Basic Settings	0-83	Additional Non-Working Days
0-01 Language	0-84	Time for Fieldbus
0-02 Motor Speed Unit	0-85	Summer Time Start for Fieldbus
0-03 Regional Settings	0-86	Summer Time End for Fieldbus
0-04 Operating State at Power-up	0-89	Date and Time Readout
0-05 Local Mode Unit	0-9*	Varia
0-1* Set-up Operations	0-95	Warning LED blinking
0-10 Active Set-up	1-**	Load and Motor
0-11 Programming Set-up	1-0*	General Settings
0-12 This Set-up Linked to	1-00	Configuration Mode
0-13 Readout: Linked Set-ups	1-03	Torque Characteristics
0-14 Readout: Prog. Set-ups / Channel	1-06	Clockwise Direction
0-15 Readout: actual setup	1-1*	Motor Selection
0-2* LCP Display	1-10	Motor Construction
0-20 Display Line 1.1 Small	1-1*	VVC+ PM/SYN RM
0-21 Display Line 1.2 Small	1-14	Damping Gain
0-22 Display Line 1.3 Small	1-15	Low Speed Filter Time Const.
0-23 Display Line 2 Large	1-16	High Speed Filter Time Const.
0-24 Display Line 3 Large	1-17	Voltage filter time const.
0-25 My Personal Menu	1-2*	Motor Data
0-3* LCP Custom Readout	1-20	Motor Power [kW]
0-30 Custom Readout Unit	1-21	Motor Power [HP]
0-31 Custom Readout Min Value	1-22	Motor Voltage
0-32 Custom Readout Max Value	1-23	Motor Frequency
0-37 Display Text 1	1-24	Motor Current
0-38 Display Text 2	1-25	Motor Nominal Speed
0-39 Display Text 3	1-26	Motor Cont. Rated Torque
0-4* LCP Keypad	1-28	Motor Rotation Check
0-40 [Hand on] Key on LCP	1-29	Automatic Motor Adaptation (AMA)
0-41 [Off] Key on LCP	1-3*	Adv. Motor Data
0-42 [Auto on] Key on LCP	1-30	Stator Resistance (Rs)
0-43 [Reset] Key on LCP	1-31	Rotor Resistance (Rr)
0-44 [Off/Reset] Key on LCP	1-35	Main Reactance (Xh)
0-45 [Drive Bypass] Key on LCP	1-36	Iron Loss Resistance (Rfe)
0-5* Copy/Save	1-37	d-axis Inductance (Ld)
0-50 LCP Copy	1-38	q-axis Inductance (Lq)
0-51 Set-up Copy	1-39	Motor Poles
0-6* Password	1-40	Back EMF at 1000 RPM
0-60 Main Menu Password	1-44	d-axis Inductance Sat. (LdSat)
0-61 Access to Main Menu w/o Password	1-45	q-axis Inductance Sat. (LqSat)
0-65 Personal Menu Password	1-46	Position Detection Gain
0-66 Access to Personal Menu w/o Password	1-47	Torque Calibration
0-67 Bus Access Password	1-48	Inductance Sat. Point
0-7* Clock Settings	1-49	q-Axis Inductance Saturation Point
0-70 Date and Time	1-5*	Load Indep. Setting
0-71 Date Format	1-50	Motor Magnetisation at Zero Speed
0-72 Time Format	1-51	Min Speed Normal Magnetising [RPM]
0-73 Time Zone Offset	1-52	Min Speed Normal Magnetising [Hz]
0-74 DST/Summertime	1-58	Flying Start Test Pulses Current
0-76 DST/Summertime Start	1-59	Flying Start Test Pulses Frequency
0-77 DST/Summertime End	1-6*	Load Depen. Setting
0-79 Clock Fault	1-60	Low Speed Load Compensation
	1-61	High Speed Load Compensation

1-62	Slip Compensation	3-13	Reference Site
1-63	Slip Compensation Time Constant	3-14	Preset Relative Reference
1-64	Resonance Dampening	3-15	Reference 1 Source
1-65	Resonance Dampening Time Constant	3-16	Reference 2 Source
1-66	Min. Current at Low Speed	3-17	Reference 3 Source
1-7*	Start Adjustments	3-19	Jog Speed [RPM]
1-70	Start Mode	3-4*	Ramp 1
1-71	Start Delay	3-41	Ramp 1 Ramp Up Time
1-72	Start Function	3-42	Ramp 1 Ramp Down Time
1-73	Flying Start	3-5*	Ramp 2
1-77	Compressor Start Max Speed [RPM]	3-51	Ramp 2 Ramp Up Time
1-78	Compressor Start Max Speed [Hz]	3-52	Ramp 2 Ramp Down Time
1-79	Compressor Start Max Time to Trip	3-8*	Other Ramps
1-8*	Stop Adjustments	3-80	Jog Ramp Time
1-80	Function at Stop	3-81	Quick Stop Ramp Time
1-81	Min Speed for Function at Stop [RPM]	3-82	Starting Ramp Up Time
1-82	Min Speed for Function at Stop [Hz]	3-9*	Digital Pot.Meter
1-86	Trip Speed Low [RPM]	3-90	Step Size
1-87	Trip Speed Low [Hz]	3-91	Ramp Time
1-9*	Motor Temperature	3-92	Power Restore
1-90	Motor Thermal Protection	3-93	Maximum Limit
1-91	Motor External Fan	3-94	Minimum Limit
1-93	Thermistor Source	3-95	Ramp Delay
1-94	ATEX ETR curlim. speed reduction	4-**	Limits / Warnings
1-95	Thermistor Sensor Type	4-1*	Motor Limits
1-96	Thermistor Sensor Source	4-10	Motor Speed Direction
1-97	Thermistor Threshold level	4-11	Motor Speed Low Limit [RPM]
1-98	ATEX ETR interpol. points freq.	4-12	Motor Speed Low Limit [Hz]
1-99	ATEX ETR interpol points current	4-13	Motor Speed High Limit [RPM]
2-**	Brakes	4-14	Motor Speed High Limit [Hz]
2-0*	DC-Brake	4-16	Torque Limit Motor Mode
2-00	DC Hold/Preheat Current	4-17	Torque Limit Generator Mode
2-01	DC Brake Current	4-18	Current Limit
2-02	DC Braking Time	4-19	Max Output Frequency
2-03	DC Brake Cut In Speed [RPM]	4-5*	Adj. Warnings
2-04	DC Brake Cut In Speed [Hz]	4-50	Warning Current Low
2-06	Parking Current	4-51	Warning Current High
2-07	Parking Time	4-52	Warning Speed Low
2-1*	Brake Energy Funct.	4-53	Warning Speed High
2-10	Brake Function	4-54	Warning Reference Low
2-11	Brake Resistor (ohm)	4-55	Warning Reference High
2-12	Brake Power Limit (kW)	4-56	Warning Feedback Low
2-13	Brake Power Monitoring	4-57	Warning Feedback High
2-15	Brake Check	4-58	Missing Motor Phase Function
2-16	AC brake Max. Current	4-59	Motor Check At Start
2-17	Over-voltage Control	4-6*	Speed Bypass
2-19	Over-voltage Gain	4-60	Bypass Speed From [RPM]
3-**	Reference / Ramps	4-61	Bypass Speed From [Hz]
3-0*	Reference Limits	4-62	Bypass Speed To [RPM]
3-02	Minimum Reference	4-63	Bypass Speed To [Hz]
3-03	Maximum Reference	4-64	Semi-Auto Bypass Set-up
3-04	Reference Function	5-**	Digital In/Out
3-1*	References	5-0*	Digital I/O mode
3-10	Preset Reference	5-00	Digital I/O Mode
3-11	Jog Speed [Hz]	5-01	Terminal 27 Mode

5-02	Terminal 29 Mode	5-98	Pulse Out #X30/6 Timeout Preset
5-1*	Digital Inputs	6-**	Analog In/Out
5-10	Terminal 18 Digital Input	6-0*	Analog I/O Mode
5-11	Terminal 19 Digital Input	6-00	Live Zero Timeout Time
5-12	Terminal 27 Digital Input	6-01	Live Zero Timeout Function
5-13	Terminal 29 Digital Input	6-02	Fire Mode Live Zero Timeout Function
5-14	Terminal 32 Digital Input	6-1*	Analog Input 53
5-15	Terminal 33 Digital Input	6-10	Terminal 53 Low Voltage
5-16	Terminal X30/2 Digital Input	6-11	Terminal 53 High Voltage
5-17	Terminal X30/3 Digital Input	6-12	Terminal 53 Low Current
5-18	Terminal X30/4 Digital Input	6-13	Terminal 53 High Current
5-19	Terminal 37 Safe Stop	6-14	Terminal 53 Low Ref./Feedb. Value
5-20	Terminal X46/1 Digital Input	6-15	Terminal 53 High Ref./Feedb. Value
5-21	Terminal X46/3 Digital Input	6-16	Terminal 53 Filter Time Constant
5-22	Terminal X46/5 Digital Input	6-17	Terminal 53 Live Zero
5-23	Terminal X46/7 Digital Input	6-2*	Analog Input 54
5-24	Terminal X46/9 Digital Input	6-20	Terminal 54 Low Voltage
5-25	Terminal X46/11 Digital Input	6-21	Terminal 54 High Voltage
5-26	Terminal X46/13 Digital Input	6-22	Terminal 54 Low Current
5-3*	Digital Outputs	6-23	Terminal 54 High Current
5-30	Terminal 27 Digital Output	6-24	Terminal 54 Low Ref./Feedb. Value
5-31	Terminal 29 Digital Output	6-25	Terminal 54 High Ref./Feedb. Value
5-32	Term X30/6 Digi Out (MCB 101)	6-26	Terminal 54 Filter Time Constant
5-33	Term X30/7 Digi Out (MCB 101)	6-27	Terminal 54 Live Zero
5-4*	Relays	6-3*	Analog Input X30/11
5-40	Function Relay	6-30	Terminal X30/11 Low Voltage
5-41	On Delay, Relay	6-31	Terminal X30/11 High Voltage
5-42	Off Delay, Relay	6-34	Term. X30/11 Low Ref./Feedb. Value
5-5*	Pulse Input	6-35	Term. X30/11 High Ref./Feedb. Value
5-50	Term. 29 Low Frequency	6-36	Term. X30/11 Filter Time Constant
5-51	Term. 29 High Frequency	6-37	Term. X30/11 Live Zero
5-52	Term. 29 Low Ref./Feedb. Value	6-4*	Analog Input X30/12
5-53	Term. 29 High Ref./Feedb. Value	6-40	Terminal X30/12 Low Voltage
5-54	Pulse Filter Time Constant #29	6-41	Terminal X30/12 High Voltage
5-55	Term. 33 Low Frequency	6-44	Term. X30/12 Low Ref./Feedb. Value
5-56	Term. 33 High Frequency	6-45	Term. X30/12 High Ref./Feedb. Value
5-57	Term. 33 Low Ref./Feedb. Value	6-46	Term. X30/12 Filter Time Constant
5-58	Term. 33 High Ref./Feedb. Value	6-47	Term. X30/12 Live Zero
5-59	Pulse Filter Time Constant #33	6-5*	Analog Output 42
5-6*	Pulse Output	6-50	Terminal 42 Output
5-60	Terminal 27 Pulse Output Variable	6-51	Terminal 42 Output Min Scale
5-62	Pulse Output Max Freq #27	6-52	Terminal 42 Output Max Scale
5-63	Terminal 29 Pulse Output Variable	6-53	Terminal 42 Output Bus Control
5-65	Pulse Output Max Freq #29	6-54	Terminal 42 Output Timeout Preset
5-66	Terminal X30/6 Pulse Output Variable	6-55	Analog Output Filter
5-68	Pulse Output Max Freq #X30/6	6-6*	Analog Output X30/8
5-8*	I/O Options	6-60	Terminal X30/8 Output
5-80	AHF Cap Reconnect Delay	6-61	Terminal X30/8 Min. Scale
5-9*	Bus Controlled	6-62	Terminal X30/8 Max. Scale
5-90	Digital & Relay Bus Control	6-63	Terminal X30/8 Output Bus Control
5-93	Pulse Out #27 Bus Control	6-64	Terminal X30/8 Output Timeout Preset
5-94	Pulse Out #27 Timeout Preset	6-7*	Analog Output X45/1
5-95	Pulse Out #29 Bus Control	6-70	Terminal X45/1 Output
5-96	Pulse Out #29 Timeout Preset	6-71	Terminal X45/1 Min. Scale
5-97	Pulse Out #X30/6 Bus Control	6-72	Terminal X45/1 Max. Scale

6-73	Terminal X45/1 Bus Control	8-85	Slave Timeout Errors
6-74	Terminal X45/1 Output Timeout Preset	8-89	Diagnostics Count
6-8*	Analog Output X45/3	8-9*	Bus Jog / Feedback
6-80	Terminal X45/3 Output	8-90	Bus Jog 1 Speed
6-81	Terminal X45/3 Min. Scale	8-91	Bus Jog 2 Speed
6-82	Terminal X45/3 Max. Scale	8-94	Bus Feedback 1
6-83	Terminal X45/3 Bus Control	8-95	Bus Feedback 2
6-84	Terminal X45/3 Output Timeout Preset	8-96	Bus Feedback 3
8-**	Comm. and Options	9-**	PROFIdrive
8-0*	General Settings	9-00	Setpoint
8-01	Control Site	9-07	Actual Value
8-02	Control Source	9-15	PCD Write Configuration
8-03	Control Timeout Time	9-16	PCD Read Configuration
8-04	Control Timeout Function	9-18	Node Address
8-05	End-of-Timeout Function	9-22	Telegram Selection
8-06	Reset Control Timeout	9-23	Parameters for Signals
8-07	Diagnosis Trigger	9-27	Parameter Edit
8-08	Readout Filtering	9-28	Process Control
8-09	Communication Charset	9-44	Fault Message Counter
8-1*	Control Settings	9-45	Fault Code
8-10	Control Profile	9-47	Fault Number
8-13	Configurable Status Word STW	9-52	Fault Situation Counter
8-3*	FC Port Settings	9-53	Profibus Warning Word
8-30	Protocol	9-63	Actual Baud Rate
8-31	Address	9-64	Device Identification
8-32	Baud Rate	9-65	Profile Number
8-33	Parity / Stop Bits	9-67	Control Word 1
8-34	Estimated cycle time	9-68	Status Word 1
8-35	Minimum Response Delay	9-70	Programming Set-up
8-36	Maximum Response Delay	9-71	Profibus Save Data Values
8-37	Maximum Inter-Char Delay	9-72	ProfibusDriveReset
8-39	Protocol Firmware version	9-75	DO Identification
8-4*	FC MC protocol set	9-80	Defined Parameters (1)
8-40	Telegram Selection	9-81	Defined Parameters (2)
8-42	PCD Write Configuration	9-82	Defined Parameters (3)
8-43	PCD Read Configuration	9-83	Defined Parameters (4)
8-5*	Digital/Bus	9-84	Defined Parameters (5)
8-50	Coasting Select	9-85	Defined Parameters (6)
8-52	DC Brake Select	9-90	Changed Parameters (1)
8-53	Start Select	9-91	Changed Parameters (2)
8-54	Reversing Select	9-92	Changed Parameters (3)
8-55	Set-up Select	9-93	Changed Parameters (4)
8-56	Preset Reference Select	9-94	Changed Parameters (5)
8-7*	BACnet	9-99	Profibus Revision Counter
8-70	BACnet Device Instance	10-**	CAN Fieldbus
8-72	MS/TP Max Masters	10-0*	Common Settings
8-73	MS/TP Max Info Frames	10-00	CAN Protocol
8-74	"I-Am" Service	10-01	Baud Rate Select
8-75	Initialisation Password	10-02	MAC ID
8-8*	FC Port Diagnostics	10-05	Readout Transmit Error Counter
8-80	Bus Message Count	10-06	Readout Receive Error Counter
8-81	Bus Error Count	10-07	Readout Bus Off Counter
8-82	Slave Messages Rcvd	10-1*	DeviceNet
8-83	Slave Error Count	10-10	Process Data Type Selection
8-84	Slave Messages Sent	10-11	Process Data Config Write

10-12	Process Data Config Read	12-31	Net Reference
10-13	Warning Parameter	12-32	Net Control
10-14	Net Reference	12-33	CIP Revision
10-15	Net Control	12-34	CIP Product Code
10-2*	COS Filters	12-35	EDS Parameter
10-20	COS Filter 1	12-37	COS Inhibit Timer
10-21	COS Filter 2	12-38	COS Filter
10-22	COS Filter 3	12-4*	Modbus TCP
10-23	COS Filter 4	12-40	Status Parameter
10-3*	Parameter Access	12-41	Slave Message Count
10-30	Array Index	12-42	Slave Exception Message Count
10-31	Store Data Values	12-7*	BACnet
10-32	Devicenet Revision	12-70	BACnet Status
10-33	Store Always	12-71	BACnet Datalink
10-34	DeviceNet Product Code	12-72	BACnet UDP Port
10-39	Devicenet F Parameters	12-75	BBMD IP Address
11-**	LonWorks	12-76	BBMD Port
11-0*	LonWorks ID	12-77	BBMD Reg. Interval
11-00	Neuron ID	12-78	Device ID Conflict Detection
11-1*	LON Functions	12-79	Message Counter
11-10	Drive Profile	12-8*	Other Ethernet Services
11-15	LON Warning Word	12-80	FTP Server
11-17	XIF Revision	12-81	HTTP Server
11-18	LonWorks Revision	12-82	SMTP Service
11-2*	LON Param. Access	12-83	SNMP Agent
11-21	Store Data Values	12-84	Address Conflict Detection
12-**	Ethernet	12-85	ACD Last Conflict
12-0*	IP Settings	12-89	Transparent Socket Channel Port
12-00	IP Address Assignment	12-9*	Advanced Ethernet Services
12-01	IP Address	12-90	Cable Diagnostic
12-02	Subnet Mask	12-91	Auto Cross Over
12-03	Default Gateway	12-92	IGMP Snooping
12-04	DHCP Server	12-93	Cable Error Length
12-05	Lease Expires	12-94	Broadcast Storm Protection
12-06	Name Servers	12-95	Broadcast Storm Filter
12-07	Domain Name	12-96	Port Config
12-08	Host Name	12-97	QoS Priority
12-09	Physical Address	12-98	Interface Counters
12-1*	Ethernet Link Parameters	12-99	Media Counters
12-10	Link Status	13-**	Smart Logic
12-11	Link Duration	13-0*	SLC Settings
12-12	Auto Negotiation	13-00	SL Controller Mode
12-13	Link Speed	13-01	Start Event
12-14	Link Duplex	13-02	Stop Event
12-18	Supervisor MAC	13-03	Reset SLC
12-19	Supervisor IP Addr.	13-1*	Comparators
12-2*	Process Data	13-10	Comparator Operand
12-20	Control Instance	13-11	Comparator Operator
12-21	Process Data Config Write	13-12	Comparator Value
12-22	Process Data Config Read	13-1*	RS Flip Flops
12-27	Primary Master	13-15	RS-FF Operand S
12-28	Store Data Values	13-16	RS-FF Operand R
12-29	Store Always	13-2*	Timers
12-3*	EtherNet/IP	13-20	SL Controller Timer
12-30	Warning Parameter	13-4*	Logic Rules

13-40	Logic Rule Boolean 1	14-60	Function at Over Temperature
13-41	Logic Rule Operator 1	14-61	Function at Inverter Overload
13-42	Logic Rule Boolean 2	14-62	Inv. Overload Derate Current
13-43	Logic Rule Operator 2	14-8*	Options
13-44	Logic Rule Boolean 3	14-80	Option Supplied by External 24VDC
13-5*	States	14-88	Option Data Storage
13-51	SL Controller Event	14-89	Option Detection
13-52	SL Controller Action	14-9*	Fault Settings
13-9*	User Defined Alerts	14-90	Fault Level
13-90	Alert Trigger	15-**	Drive Information
13-91	Alert Action	15-0*	Operating Data
13-92	Alert Text	15-00	Operating hours
13-9*	User Defined Readouts	15-01	Running Hours
13-97	Alert Alarm Word	15-02	kWh Counter
13-98	Alert Warning Word	15-03	Power Up's
13-99	Alert Status Word	15-04	Over Temp's
14-**	Special Functions	15-05	Over Volt's
14-0*	Inverter Switching	15-06	Reset kWh Counter
14-00	Switching Pattern	15-07	Reset Running Hours Counter
14-01	Switching Frequency	15-08	Number of Starts
14-03	Overmodulation	15-1*	Data Log Settings
14-04	Acoustic Noise Reduction	15-10	Logging Source
14-1*	Mains Failure	15-11	Logging Interval
14-10	Mains Failure	15-12	Trigger Event
14-11	Mains Fault Voltage Level	15-13	Logging Mode
14-12	Response to Mains Imbalance	15-14	Samples Before Trigger
14-16	Kin. Back-up Gain	15-2*	Historic Log
14-2*	Reset Functions	15-20	Historic Log: Event
14-20	Reset Mode	15-21	Historic Log: Value
14-21	Automatic Restart Time	15-22	Historic Log: Time
14-22	Operation Mode	15-23	Historic log: Date and Time
14-23	Typecode Setting	15-3*	Alarm Log
14-25	Trip Delay at Torque Limit	15-30	Alarm Log: Error Code
14-26	Trip Delay at Inverter Fault	15-31	Alarm Log: Value
14-28	Production Settings	15-32	Alarm Log: Time
14-29	Service Code	15-33	Alarm Log: Date and Time
14-3*	Current Limit Ctrl.	15-4*	Drive Identification
14-30	Current Lim Ctrl, Proportional Gain	15-40	FC Type
14-31	Current Lim Ctrl, Integration Time	15-41	Power Section
14-32	Current Lim Ctrl, Filter Time	15-42	Voltage
14-4*	Energy Optimising	15-43	Software Version
14-40	VT Level	15-44	Ordered Typecode String
14-41	AEO Minimum Magnetisation	15-45	Actual Typecode String
14-42	Minimum AEO Frequency	15-46	Frequency Converter Ordering No
14-43	Motor CospHi	15-47	Power Card Ordering No
14-5*	Environment	15-48	LCP Id No
14-50	RFI Filter	15-49	SW ID Control Card
14-51	DC-Link Compensation	15-50	SW ID Power Card
14-52	Fan Control	15-51	Frequency Converter Serial Number
14-53	Fan Monitor	15-53	Power Card Serial Number
14-55	Output Filter	15-54	Config File Name
14-56	Capacitance Output Filter	15-55	Vendor URL
14-57	Inductance Output Filter	15-56	Vendor Name
14-59	Actual Number of Inverter Units	15-58	Smart Setup Filename
14-6*	Auto Derate	15-59	Filename

15-6*	Option Ident	16-37	Inv. Max. Current
15-60	Option Mounted	16-38	SL Controller State
15-61	Option SW Version	16-39	Control Card Temp.
15-62	Option Ordering No	16-40	Logging Buffer Full
15-63	Option Serial No	16-41	Performance Measurements
15-64	Application Version	16-42	Service Log Counter
15-70	Option in Slot A	16-43	Timed Actions Status
15-71	Slot A Option SW Version	16-45	Motor Phase U Current
15-72	Option in Slot B	16-46	Motor Phase V Current
15-73	Slot B Option SW Version	16-47	Motor Phase W Current
15-74	Option in Slot C0/E0	16-49	Current Fault Source
15-75	Slot C0/E0 Option SW Version	16-5*	Ref. & Feedb.
15-76	Option in Slot C1/E1	16-50	External Reference
15-77	Slot C1/E1 Option SW Version	16-52	Feedback[Unit]
15-8*	Operating Data II	16-53	Digi Pot Reference
15-80	Fan Running Hours	16-54	Feedback 1 [Unit]
15-81	Preset Fan Running Hours	16-55	Feedback 2 [Unit]
15-9*	Parameter Info	16-56	Feedback 3 [Unit]
15-92	Defined Parameters	16-58	PID Output [%]
15-93	Modified Parameters	16-59	Adjusted Setpoint
15-98	Drive Identification	16-6*	Inputs & Outputs
15-99	Parameter Metadata	16-60	Digital Input
16-**	Data Readouts	16-61	Terminal 53 Switch Setting
16-0*	General Status	16-62	Analog Input 53
16-00	Control Word	16-63	Terminal 54 Switch Setting
16-01	Reference [Unit]	16-64	Analog Input 54
16-02	Reference [%]	16-65	Analog Output 42 [mA]
16-03	Status Word	16-66	Digital Output [bin]
16-05	Main Actual Value [%]	16-67	Pulse Input #29 [Hz]
16-09	Custom Readout	16-68	Pulse Input #33 [Hz]
16-1*	Motor Status	16-69	Pulse Output #27 [Hz]
16-10	Power [kW]	16-70	Pulse Output #29 [Hz]
16-11	Power [hp]	16-71	Relay Output [bin]
16-12	Motor Voltage	16-72	Counter A
16-13	Frequency	16-73	Counter B
16-14	Motor current	16-75	Analog In X30/11
16-15	Frequency [%]	16-76	Analog In X30/12
16-16	Torque [Nm]	16-77	Analog Out X30/8 [mA]
16-17	Speed [RPM]	16-78	Analog Out X45/1 [mA]
16-18	Motor Thermal	16-79	Analog Out X45/3 [mA]
16-19	Thermistor Sensor Temperature	16-8*	Fieldbus & FC Port
16-20	Motor Angle	16-80	Fieldbus CTW 1
16-22	Torque [%]	16-82	Fieldbus REF 1
16-23	Motor Shaft Power [kW]	16-84	Comm. Option STW
16-24	Calibrated Stator Resistance	16-85	FC Port CTW 1
16-26	Power Filtered [kW]	16-86	FC Port REF 1
16-27	Power Filtered [hp]	16-9*	Diagnosis Readouts
16-3*	Drive Status	16-90	Alarm Word
16-30	DC Link Voltage	16-91	Alarm Word 2
16-31	System Temp.	16-92	Warning Word
16-32	Brake Energy /s	16-93	Warning Word 2
16-33	Brake Energy Average	16-94	Ext. Status Word
16-34	Heatsink Temp.	16-95	Ext. Status Word 2
16-35	Inverter Thermal	16-96	Maintenance Word
16-36	Inv. Nom. Current	18-**	Info & Readouts

18-0*	Maintenance Log	20-22	Setpoint 2
18-00	Maintenance Log: Item	20-23	Setpoint 3
18-01	Maintenance Log: Action	20-3*	Feedb. Adv. Conv.
18-02	Maintenance Log: Time	20-30	Refrigerant
18-03	Maintenance Log: Date and Time	20-31	User Defined Refrigerant A1
18-1*	Fire Mode Log	20-32	User Defined Refrigerant A2
18-10	FireMode Log:Event	20-33	User Defined Refrigerant A3
18-11	Fire Mode Log: Time	20-34	Duct 1 Area [m2]
18-12	Fire Mode Log: Date and Time	20-35	Duct 1 Area [in2]
18-3*	Inputs & Outputs	20-36	Duct 2 Area [m2]
18-30	Analog Input X42/1	20-37	Duct 2 Area [in2]
18-31	Analog Input X42/3	20-38	Air Density Factor [%]
18-32	Analog Input X42/5	20-6*	Sensorless
18-33	Analog Out X42/7 [V]	20-60	Sensorless Unit
18-34	Analog Out X42/9 [V]	20-69	Sensorless Information
18-35	Analog Out X42/11 [V]	20-7*	PID Autotuning
18-36	Analog Input X48/2 [mA]	20-70	Closed Loop Type
18-37	Temp. Input X48/4	20-71	PID Performance
18-38	Temp. Input X48/7	20-72	PID Output Change
18-39	Temp. Input X48/10	20-73	Minimum Feedback Level
18-4*	PGIO Data Readouts	20-74	Maximum Feedback Level
18-40	Analog Input X49/1	20-79	PID Autotuning
18-41	Analog Input X49/3	20-8*	PID Basic Settings
18-42	Analog Input X49/5	20-81	PID Normal/ Inverse Control
18-43	Analog Out X49/7	20-82	PID Start Speed [RPM]
18-44	Analog Out X49/9	20-83	PID Start Speed [Hz]
18-45	Analog Out X49/11	20-84	On Reference Bandwidth
18-46	X49 Digital Output [bin]	20-9*	PID Controller
18-5*	Ref. & Feedb.	20-91	PID Anti Windup
18-50	Sensorless Readout [unit]	20-93	PID Proportional Gain
18-57	Air Pressure to Flow Air Flow	20-94	PID Integral Time
18-6*	Inputs & Outputs 2	20-95	PID Differentiation Time
18-60	Digital Input 2	20-96	PID Diff. Gain Limit
18-7*	Rectifier Status	21-**	Ext. Closed Loop
18-70	Mains Voltage	21-0*	Ext. CL Autotuning
18-71	Mains Frequency	21-00	Closed Loop Type
18-72	Mains Imbalance	21-01	PID Performance
18-75	Rectifier DC Volt.	21-02	PID Output Change
20-**	Drive Closed Loop	21-03	Minimum Feedback Level
20-0*	Feedback	21-04	Maximum Feedback Level
20-00	Feedback 1 Source	21-09	PID Autotuning
20-01	Feedback 1 Conversion	21-1*	Ext. CL 1 Ref./Fb.
20-02	Feedback 1 Source Unit	21-10	Ext. 1 Ref./Feedback Unit
20-03	Feedback 2 Source	21-11	Ext. 1 Minimum Reference
20-04	Feedback 2 Conversion	21-12	Ext. 1 Maximum Reference
20-05	Feedback 2 Source Unit	21-13	Ext. 1 Reference Source
20-06	Feedback 3 Source	21-14	Ext. 1 Feedback Source
20-07	Feedback 3 Conversion	21-15	Ext. 1 Setpoint
20-08	Feedback 3 Source Unit	21-17	Ext. 1 Reference [Unit]
20-12	Reference/Feedback Unit	21-18	Ext. 1 Feedback [Unit]
20-13	Minimum Reference/Feedb.	21-19	Ext. 1 Output [%]
20-14	Maximum Reference/Feedb.	21-2*	Ext. CL 1 PID
20-2*	Feedback/Setpoint	21-20	Ext. 1 Normal/Inverse Control
20-20	Feedback Function	21-21	Ext. 1 Proportional Gain
20-21	Setpoint 1	21-22	Ext. 1 Integral Time

21-23	Ext. 1 Differentiation Time	22-30	No-Flow Power
21-24	Ext. 1 Dif. Gain Limit	22-31	Power Correction Factor
21-26	Ext. 1 On Reference Bandwidth	22-32	Low Speed [RPM]
21-3*	Ext. CL 2 Ref./Fb.	22-33	Low Speed [Hz]
21-30	Ext. 2 Ref./Feedback Unit	22-34	Low Speed Power [kW]
21-31	Ext. 2 Minimum Reference	22-35	Low Speed Power [HP]
21-32	Ext. 2 Maximum Reference	22-36	High Speed [RPM]
21-33	Ext. 2 Reference Source	22-37	High Speed [Hz]
21-34	Ext. 2 Feedback Source	22-38	High Speed Power [kW]
21-35	Ext. 2 Setpoint	22-39	High Speed Power [HP]
21-37	Ext. 2 Reference [Unit]	22-4*	Sleep Mode
21-38	Ext. 2 Feedback [Unit]	22-40	Minimum Run Time
21-39	Ext. 2 Output [%]	22-41	Minimum Sleep Time
21-4*	Ext. CL 2 PID	22-42	Wake-up Speed [RPM]
21-40	Ext. 2 Normal/Inverse Control	22-43	Wake-up Speed [Hz]
21-41	Ext. 2 Proportional Gain	22-44	Wake-up Ref./FB Difference
21-42	Ext. 2 Integral Time	22-45	Setpoint Boost
21-43	Ext. 2 Differentiation Time	22-46	Maximum Boost Time
21-44	Ext. 2 Dif. Gain Limit	22-47*	End of Curve
21-46	Ext. 2 On Reference Bandwidth	22-50	End of Curve Function
21-5*	Ext. CL 3 Ref./Fb.	22-51	End of Curve Delay
21-50	Ext. 3 Ref./Feedback Unit	22-52	End of Curve Tolerance
21-51	Ext. 3 Minimum Reference	22-6*	Broken Belt Detection
21-52	Ext. 3 Maximum Reference	22-60	Broken Belt Function
21-53	Ext. 3 Reference Source	22-61	Broken Belt Torque
21-54	Ext. 3 Feedback Source	22-62	Broken Belt Delay
21-55	Ext. 3 Setpoint	22-7*	Short Cycle Protection
21-57	Ext. 3 Reference [Unit]	22-75	Short Cycle Protection
21-58	Ext. 3 Feedback [Unit]	22-76	Interval between Starts
21-59	Ext. 3 Output [%]	22-77	Minimum Run Time
21-6*	Ext. CL 3 PID	22-78	Minimum Run Time Override
21-60	Ext. 3 Normal/Inverse Control	22-79	Minimum Run Time Override Value
21-61	Ext. 3 Proportional Gain	22-8*	Flow Compensation
21-62	Ext. 3 Integral Time	22-80	Flow Compensation
21-63	Ext. 3 Differentiation Time	22-81	Square-linear Curve Approximation
21-64	Ext. 3 Dif. Gain Limit	22-82	Work Point Calculation
21-66	Ext. 3 On Reference Bandwidth	22-83	Speed at No-Flow [RPM]
22-**	Appl. Functions	22-84	Speed at No-Flow [Hz]
22-0*	Miscellaneous	22-85	Speed at Design Point [RPM]
22-00	External Interlock Delay	22-86	Speed at Design Point [Hz]
22-01	Power Filter Time	22-87	Pressure at No-Flow Speed
22-1*	Air Pres. to Flow	22-88	Pressure at Rated Speed
22-10	Air Pressure to Flow Signal source	22-89	Flow at Design Point
22-11	Air Pressure to Flow Fan k-factor	22-90	Flow at Rated Speed
22-12	Air Pressure to Flow Air density	23-**	Time-based Functions
22-13	Air Pressure to Flow Fan flow unit	23-0*	Timed Actions
22-2*	No-Flow Detection	23-00	ON Time
22-20	Low Power Auto Set-up	23-01	ON Action
22-21	Low Power Detection	23-02	OFF Time
22-22	Low Speed Detection	23-03	OFF Action
22-23	No-Flow Function	23-04	Occurrence
22-24	No-Flow Delay	23-0*	Timed Actions Settings
22-26	Dry Pump Function	23-08	Timed Actions Mode
22-27	Dry Pump Delay	23-09	Timed Actions Reactivation
22-3*	No-Flow Power Tuning	23-1*	Maintenance

23-10	Maintenance Item	25-**	Cascade Controller
23-11	Maintenance Action	25-0*	System Settings
23-12	Maintenance Time Base	25-00	Cascade Controller
23-13	Maintenance Time Interval	25-02	Motor Start
23-14	Maintenance Date and Time	25-04	Pump Cycling
23-1*	Maintenance Reset	25-05	Fixed Lead Pump
23-15	Reset Maintenance Word	25-06	Number of Pumps
23-16	Maintenance Text	25-2*	Bandwidth Settings
23-5*	Energy Log	25-20	Staging Bandwidth
23-50	Energy Log Resolution	25-21	Override Bandwidth
23-51	Period Start	25-22	Fixed Speed Bandwidth
23-53	Energy Log	25-23	SBW Staging Delay
23-54	Reset Energy Log	25-24	SBW Destaging Delay
23-6*	Trending	25-25	OBW Time
23-60	Trend Variable	25-26	Destage At No-Flow
23-61	Continuous Bin Data	25-27	Stage Function
23-62	Timed Bin Data	25-28	Stage Function Time
23-63	Timed Period Start	25-29	Destage Function
23-64	Timed Period Stop	25-30	Destage Function Time
23-65	Minimum Bin Value	25-4*	Destaging Settings
23-66	Reset Continuous Bin Data	25-40	Ramp Down Delay
23-67	Reset Timed Bin Data	25-41	Ramp Up Delay
23-8*	Payback Counter	25-42	Staging Threshold
23-80	Power Reference Factor	25-43	Destaging Threshold
23-81	Energy Cost	25-44	Staging Speed [RPM]
23-82	Investment	25-45	Staging Speed [Hz]
23-83	Energy Savings	25-46	Destaging Speed [RPM]
23-84	Cost Savings	25-47	Destaging Speed [Hz]
23-85	CO2 Conversion Factor	25-5*	Alternation Settings
23-86	CO2 Reduction	25-50	Lead Pump Alternation
24-**	Appl. Functions 2	25-51	Alternation Event
24-0*	Fire Mode	25-52	Alternation Time Interval
24-00	Fire Mode Function	25-53	Alternation Timer Value
24-01	Fire Mode Configuration	25-54	Alternation Predefined Time
24-02	Fire Mode Unit	25-55	Alternate if Load < 50%
24-03	Fire Mode Min Reference	25-56	Staging Mode at Alternation
24-04	Fire Mode Max Reference	25-58	Run Next Pump Delay
24-05	Fire Mode Preset Reference	25-59	Run on Mains Delay
24-06	Fire Mode Reference Source	25-8*	Status
24-07	Fire Mode Feedback Source	25-80	Cascade Status
24-09	Fire Mode Alarm Handling	25-81	Pump Status
24-1*	Drive Bypass	25-82	Lead Pump
24-10	Drive Bypass Function	25-83	Relay Status
24-11	Drive Bypass Delay Time	25-84	Pump ON Time
24-9*	Multi-Motor Funct.	25-85	Relay ON Time
24-90	Missing Motor Function	25-86	Reset Relay Counters
24-91	Missing Motor Coefficient 1	25-9*	Service
24-92	Missing Motor Coefficient 2	25-90	Pump Interlock
24-93	Missing Motor Coefficient 3	25-91	Manual Alternation
24-94	Missing Motor Coefficient 4	26-**	Analog I/O Option
24-95	Locked Rotor Function	26-0*	Analog I/O Mode
24-96	Locked Rotor Coefficient 1	26-00	Terminal X42/1 Mode
24-97	Locked Rotor Coefficient 2	26-01	Terminal X42/3 Mode
24-98	Locked Rotor Coefficient 3	26-02	Terminal X42/5 Mode
24-99	Locked Rotor Coefficient 4	26-1*	Analog Input X42/1

26-10	Terminal X42/1 Low Voltage	31-01	Bypass Start Time Delay
26-11	Terminal X42/1 High Voltage	31-02	Bypass Trip Time Delay
26-14	Term. X42/1 Low Ref./Feedb. Value	31-03	Test Mode Activation
26-15	Term. X42/1 High Ref./Feedb. Value	31-10	Bypass Status Word
26-16	Term. X42/1 Filter Time Constant	31-11	Bypass Running Hours
26-17	Term. X42/1 Live Zero	31-19	Remote Bypass Activation
26-2*	Analog Input X42/3	31-**	Pressure Sensor Option
26-20	Terminal X42/3 Low Voltage	31-2*	Configuration
26-21	Terminal X42/3 High Voltage	31-20	Pressure/Speed Curve
26-24	Term. X42/3 Low Ref./Feedb. Value	31-21	Below level threshold
26-25	Term. X42/3 High Ref./Feedb. Value	31-22	Above level threshold
26-26	Term. X42/3 Filter Time Constant	31-23	On Delay Time
26-27	Term. X42/3 Live Zero	31-24	Reset Delay Time
26-3*	Analog Input X42/5	31-25	Pressure filter time constant
26-30	Terminal X42/5 Low Voltage	31-26	Readouts
26-31	Terminal X42/5 High Voltage	31-27	Pressure Sensor 1
26-34	Term. X42/5 Low Ref./Feedb. Value	31-28	Pressure Sensor 2
26-35	Term. X42/5 High Ref./Feedb. Value	31-29	Pressure Sensor 3
26-36	Term. X42/5 Filter Time Constant	31-30	Pressure Sensor 4
26-37	Term. X42/5 Live Zero	31-31	Press Sens Cmp State
26-4*	Analog Out X42/7	32-**	Press Sens toggle
26-40	Terminal X42/7 Output	32-9*	MCO Basic Settings
26-41	Terminal X42/7 Min. Scale	32-90	Development
26-42	Terminal X42/7 Max. Scale	34-**	Debug Source
26-43	Terminal X42/7 Bus Control	34-0*	MCO Data Readouts
26-44	Terminal X42/7 Timeout Preset	34-01	PCD Write Par.
26-5*	Analog Out X42/9	34-02	PCD 1 Write to MCO
26-50	Terminal X42/9 Output	34-03	PCD 2 Write to MCO
26-51	Terminal X42/9 Min. Scale	34-04	PCD 3 Write to MCO
26-52	Terminal X42/9 Max. Scale	34-05	PCD 4 Write to MCO
26-53	Terminal X42/9 Bus Control	34-06	PCD 5 Write to MCO
26-54	Terminal X42/9 Timeout Preset	34-07	PCD 6 Write to MCO
26-6*	Analog Out X42/11	34-08	PCD 7 Write to MCO
26-60	Terminal X42/11 Output	34-09	PCD 8 Write to MCO
26-61	Terminal X42/11 Min. Scale	34-10	PCD 9 Write to MCO
26-62	Terminal X42/11 Max. Scale	34-2*	PCD 10 Write to MCO
26-63	Terminal X42/11 Bus Control	34-21	PCD Read Par.
26-64	Terminal X42/11 Timeout Preset	34-22	PCD 1 Read from MCO
30-**	Special Features	34-23	PCD 2 Read from MCO
30-2*	Adv. Start Adjust	34-24	PCD 3 Read from MCO
30-22	Locked Rotor Detection	34-25	PCD 4 Read from MCO
30-23	Locked Rotor Detection Time [s]	34-26	PCD 5 Read from MCO
30-5*	Unit Configuration	34-27	PCD 6 Read from MCO
30-50	Heat Sink Fan Mode	34-28	PCD 7 Read from MCO
30-9*	Wifi LCP	34-29	PCD 8 Read from MCO
30-90	SSID	34-30	PCD 9 Read from MCO
30-91	Channel	35-**	PCD 10 Read from MCO
30-92	Password	35-0*	Sensor Input Option
30-93	Security type	35-00	Temp. Input Mode
30-94	IP address	35-01	Term. X48/4 Temperature Unit
30-95	Submask	35-02	Term. X48/4 Input Type
30-96	Port	35-03	Term. X48/7 Temperature Unit
30-97	Wifi Timeout Action	35-04	Term. X48/7 Input Type
31-**	Bypass Option	35-05	Term. X48/10 Temperature Unit
31-00	Bypass Mode		Term. X48/10 Input Type

35-06	Temperature Sensor Alarm Function	36-35	Term. X49/5 High Ref./Feedb. Value
35-1*	Temp. Input X48/4	36-36	Term. X49/5 Filter Time Constant
35-14	Term. X48/4 Filter Time Constant	36-37	Term. X49/5 Live Zero
35-15	Term. X48/4 Temp. Monitor	36-4*	Output X49/7
35-16	Term. X48/4 Low Temp. Limit	36-40	Terminal X49/7 Analogue Output
35-17	Term. X48/4 High Temp. Limit	36-41	Terminal X49/7 Digital Output
35-2*	Temp. Input X48/7	36-42	Terminal X49/7 Min. Scale
35-24	Term. X48/7 Filter Time Constant	36-43	Terminal X49/7 Max. Scale
35-25	Term. X48/7 Temp. Monitor	36-44	Terminal X49/7 Bus Control
35-26	Term. X48/7 Low Temp. Limit	36-45	Terminal X49/7 Timeout Preset
35-27	Term. X48/7 High Temp. Limit	36-5*	Output X49/9
35-3*	Temp. Input X48/10	36-50	Terminal X49/9 Analogue Output
35-34	Term. X48/10 Filter Time Constant	36-51	Terminal X49/9 Digital Output
35-35	Term. X48/10 Temp. Monitor	36-52	Terminal X49/9 Min. Scale
35-36	Term. X48/10 Low Temp. Limit	36-53	Terminal X49/9 Max. Scale
35-37	Term. X48/10 High Temp. Limit	36-54	Terminal X49/9 Bus Control
35-4*	Analog Input X48/2	36-55	Terminal X49/9 Timeout Preset
35-42	Term. X48/2 Low Current	36-6*	Output X49/11
35-43	Term. X48/2 High Current	36-60	Terminal X49/11 Analogue Output
35-44	Term. X48/2 Low Ref./Feedb. Value	36-61	Terminal X49/11 Digital Output
35-45	Term. X48/2 High Ref./Feedb. Value	36-62	Terminal X49/11 Min. Scale
35-46	Term. X48/2 Filter Time Constant	36-63	Terminal X49/11 Max. Scale
35-47	Term. X48/2 Live Zero	36-64	Terminal X49/11 Bus Control
36-**	Programmable I/O Option	36-65	Terminal X49/11 Timeout Preset
36-0*	I/O Mode	40-**	Special Settings
36-00	Terminal X49/1 Mode	40-4*	Extend. Alarm Log
36-01	Terminal X49/3 Mode	40-40	Alarm Log: Ext. Reference
36-02	Terminal X49/5 Mode	40-41	Alarm Log: Frequency
36-03	Terminal X49/7 Mode	40-42	Alarm Log: Current
36-04	Terminal X49/9 Mode	40-43	Alarm Log: Voltage
36-05	Terminal X49/11 Mode	40-44	Alarm Log: DC Link Voltage
36-1*	Analog Input X49/1	40-45	Alarm Log: Control Word
36-10	Terminal X49/1 Low Voltage	40-46	Alarm Log: Status Word
36-11	Terminal X49/1 Low Current	43-**	Unit Readouts
36-12	Terminal X49/1 High Voltage	43-0*	Component Status
36-13	Terminal X49/1 High Current	43-00	Component Temp.
36-14	Term. X49/1 Low Ref./Feedb. Value	43-01	Auxiliary Temp.
36-15	Term. X49/1 High Ref./Feedb. Value	43-02	Component SW ID
36-16	Term. X49/1 Filter Time Constant	43-1*	Power Card Status
36-17	Term. X49/1 Live Zero	43-10	HS Temp. ph.U
36-2*	Analog Input X49/3	43-11	HS Temp. ph.V
36-20	Terminal X49/3 Low Voltage	43-12	HS Temp. ph.W
36-21	Terminal X49/3 Low Current	43-13	PC Fan A Speed
36-22	Terminal X49/3 High Voltage	43-14	PC Fan B Speed
36-23	Terminal X49/3 High Current	43-15	PC Fan C Speed
36-24	Term. X49/3 Low Ref./Feedb. Value	43-2*	Fan Pow.Card Status
36-25	Term. X49/3 High Ref./Feedb. Value	43-20	FPC Fan A Speed
36-26	Term. X49/3 Filter Time Constant	43-21	FPC Fan B Speed
36-27	Term. X49/3 Live Zero	43-22	FPC Fan C Speed
36-3*	Analog Input X49/5	43-23	FPC Fan D Speed
36-30	Terminal X49/5 Low Voltage	43-24	FPC Fan E Speed
36-31	Terminal X49/5 Low Current	43-25	FPC Fan F Speed
36-32	Terminal X49/5 High Voltage	99-*	Devel support
36-33	Terminal X49/5 High Current	99-0*	DSP Debug
36-34	Term. X49/5 Low Ref./Feedb. Value	99-00	DAC 1 selection

99-01	DAC 2 selection
99-02	DAC 3 selection
99-03	DAC 4 selection
99-04	DAC 1 scale
99-05	DAC 2 scale
99-06	DAC 3 scale
99-07	DAC 4 scale
99-08	Test param 1
99-09	Test param 2
99-10	DAC Option Slot
99-1*	Hardware Control
99-11	RFI 2
99-12	Fan
99-1*	Software Readouts
99-13	Idle time
99-14	Paramdb requests in queue
99-15	Secondary Timer at Inverter Fault
99-16	No of Current Sensors
99-20	Fan Ctrl deltaT
99-21	Fan Ctrl Tmean
99-22	Fan Ctrl NTC Cmd
99-23	Fan Ctrl i-term
99-24	Rectifier Current
99-2*	Platform Readouts
99-29	Platform Version
99-4*	Software Control
99-40	StartupWizardState
99-5*	PC Debug
99-50	PC Debug Selection
99-51	PC Debug Argument
99-52	PC Debug 0
99-53	PC Debug 1
99-54	PC Debug 2
99-55	PC Debug Array
99-6*	Fan Power Card Dev
99-60	FPC Debug Selection
99-61	FPC Debug 0
99-62	FPC Debug 1
99-63	FPC Debug 2
99-64	FPC Debug 3
99-65	FPC Debug 4
99-66	FPC Backdoor
99-9*	Internal Values
99-90	Options present
99-91	Motor Power Internal
99-92	Motor Voltage Internal
99-93	Motor Frequency Internal
99-94	Imbalance derate [%]
99-95	Temperature derate [%]
99-96	Overload derate [%]

