

Installation Instructions

50TC*D/E units for installation in the United States contain use of Carrier's Staged Air Volume (SAV™) 2-speed indoor fan control system. This complies with the U.S. Department of Energy (DOE) efficiency standard of 2018. 50TC*D/E units for installation outside the United States may or may not contain Carrier's Staged Air Volume (SAV) 2-speed indoor fan control system as they are not required to comply with the U.S. Department of Energy (DOE) 2018 mandatory efficiency standard.

50TC*M units for installation inside or outside the United States do not contain use of Carrier's Staged Air Volume (SAV) 2-speed indoor fan motor control system as they comply with the U.S. Department of Energy (DOE) 2018 mandatory efficiency standard without their use.

For specific details on operation of the Carrier SAV 2-speed indoor fan system, refer to the Variable Frequency Drive (VFD) Factory-Installed Option 2-Speed Motor Control Installation, Setup, and Troubleshooting manual.

CONTENTS

| | |
|--|------|
| SAFETY CONSIDERATIONS | 1 |
| GENERAL | 2 |
| Rated Indoor Airflow (cfm) | 2 |
| Pre-Installation | 2 |
| INSTALLATION. | 15 |
| Jobsite Survey | 15 |
| Step 1 — Plan for Unit Location | 15 |
| • ROOF MOUNT | |
| Step 2 — Plan for Sequence of Unit Installation | 15 |
| • CURB-MOUNTED INSTALLATION | |
| • PAD-MOUNTED INSTALLATION | |
| • FRAME-MOUNTED INSTALLATION | |
| Step 3 — Inspect Unit | 16 |
| Step 4 — Provide Unit Support | 16 |
| • ROOF CURB MOUNT | |
| • SLAB MOUNT (HORIZONTAL UNITS ONLY) | |
| • ALTERNATE UNIT SUPPORT (IN LIEU OF CURB OR SLAB MOUNT) | |
| Step 5 — Field Fabricate Ductwork | 20 |
| • FOR UNITS WITH ACCESSORY ELECTRIC HEATERS | |
| Step 6 — Rig and Place Unit | 20 |
| • POSITIONING ON CURB (50TC 07-14) | |
| • POSITIONING ON CURB (50TC 16) | |
| Step 7 — Convert to Horizontal and Connect Ductwork (when required) | 21 |
| • 50TC 07-14 UNITS | |
| • 50TC 16 UNITS | |
| Step 8 — Install Outside Air Hood | 22 |
| • 50TC 07-14 OUTSIDE AIR HOOD | |
| • 50TC 16 OUTSIDE AIR HOOD | |
| Step 9 — Install External Condensate Trap and Line | 25 |
| Step 10 — Make Electrical Connections | 38 |
| • 50TC 07-14 UNIT ELECTRICAL CONNECTIONS | |
| • FIELD WIRING FOR 50TC 07-14 UNITS | |
| • CONVENIENCE OUTLETS FOR 50TC 07-14 UNITS | |
| • 50TC 16 UNIT ELECTRICAL CONNECTIONS | |
| • FIELD WIRING FOR 50TC 16 UNITS | |
| • CONVENIENCE OUTLETS FOR 50TC16 UNITS | |
| Electric Heaters | 48 |
| • 50TC 07-14 UNIT ELECTRIC HEATERS | |
| • 50TC 16 UNIT ELECTRIC HEATERS | |
| Humidi-MiZer® System Control Connections | 51 |
| • HUMIDI-MIZER — SPACE RH CONTROLLER | |
| • 50TC 07-14 UNIT HUMIDI-MIZER | |
| • 50TC 16 UNIT HUMIDI-MIZER | |
| EconoMi\$er® X (Factory-Installed Option) | 55 |
| • PRODUCT DESCRIPTION | |
| • SYSTEM COMPONENTS | |
| • SPECIFICATIONS | |
| • INPUTS | |
| • OUTPUTS | |
| • ENVIRONMENTAL | |
| • ECONOMIZER MODULE WIRING DETAILS | |
| • S-BUS SENSOR WIRING | |
| • CO2 SENSOR WIRING | |
| • INTERFACE OVERVIEW | |
| • USER INTERFACE | |
| • KEYPAD | |
| • MENU STRUCTURE | |
| • SETUP AND CONFIGURATION | |
| • TIME-OUT AND SCREEN SAVER | |
| • ENTHALPY SETTINGS | |
| • TWO-SPEED FAN OPERATION | |
| • CHECKOUT | |
| • TROUBLESHOOTING | |
| PremierLink™ Controller (Factory Option) | 68 |
| RTU Open Controller (Factory-Installed Option) | 68 |
| Smoke Detectors | 80 |
| • ADDITIONAL APPLICATION DATA | |
| Step 11 — Adjust Factory-Installed Options | 81 |
| • SMOKE DETECTORS | |
| • ECONOMI\$ER IV OCCUPANCY SWITCH | |
| Step 12 — Install Accessories | 81 |
| Step 13 — Check Belt Tension | 81 |
| • BELT FORCE — DEFLECTION METHOD | |
| • BELT TENSION METHOD | |
| Pre-Start and Start-Up | 82 |
| Troubleshooting the UltraTech™ Compressor | 82 |
| • MODULATION CONTROL INPUT SPECIFICATIONS | |
| START-UP CHECKLIST | CL-1 |

SAFETY CONSIDERATIONS

Installation and servicing of air-conditioning equipment can be hazardous due to system pressure and electrical components. Only trained and qualified service personnel should install, repair, or service air-conditioning equipment.

Untrained personnel can perform basic maintenance functions of cleaning coils and filters and replacing filters. All other operations should be performed by trained service personnel.

When working on air-conditioning equipment, observe precautions in the literature, tags and labels attached to the unit, and other safety precautions that may apply.

Follow all safety codes, including ANSI (American National Standards Institute) Z223.1. Wear safety glasses and work gloves. Use quenching cloth for unbrazing operations. Have fire extinguisher available for all brazing operations.

It is important to recognize safety information. This is the safety-alert symbol . When you see this symbol on the unit and in instructions or manuals, be alert to the potential for personal injury.

Understand the signal words DANGER, WARNING, CAUTION, and NOTE. These words are used with the safety-alert symbol. DANGER identifies the most serious hazards which **will** result in severe personal injury or death. WARNING signifies hazards which **could** result in personal injury or death. CAUTION is used to identify unsafe practices, which **may** result in minor personal injury or product and property damage. NOTE is used to highlight suggestions which **will** result in enhanced installation, reliability, or operation.

WARNING

FIRE, EXPLOSION HAZARD

Failure to follow this warning could result in death, serious personal injury and/or property damage.

Disconnect gas piping from unit when pressure testing at pressure greater than 0.5 psig (3450 Pa). Pressures greater than 0.5 psig will cause gas valve damage resulting in hazardous condition. If gas valve is subjected to pressure greater than 0.5 psig, it must be replaced before use. When pressure testing field-supplied gas piping at pressures of 0.5 psig or less, a unit connected to such piping must be isolated by closing the manual gas valve(s).

WARNING

ELECTRICAL SHOCK HAZARD

Failure to follow this warning could cause personal injury or death.

Before performing service or maintenance operations on unit, turn off main power switch to unit and install lock(s) and lockout tag(s). Ensure electrical service to rooftop unit agrees with voltage and amperage listed on the unit rating plate. Unit may have more than one power switch.

WARNING

UNIT OPERATION AND SAFETY HAZARD

Failure to follow this warning could cause personal injury, death and/or equipment damage.

Puron® (R-410A) refrigerant systems operate at higher pressures than standard R-22 systems. Do not use R-22 service equipment or components on Puron refrigerant equipment.

WARNING

PERSONAL INJURY AND ENVIRONMENTAL HAZARD

Failure to follow this warning could cause personal injury or death.

Relieve pressure and recover all refrigerant before system repair or final unit disposal.

Wear safety glasses and gloves when handling refrigerants. Keep torches and other ignition sources away from refrigerants and oils.

CAUTION

CUT HAZARD

Failure to follow this caution may result in personal injury. Sheet metal parts may have sharp edges or burrs. Use care and wear appropriate protective clothing, safety glasses and gloves when handling parts and servicing air conditioning equipment.

GENERAL

See Fig. 1 for unit options. See Fig. 2-6 for details on size 07 units and Fig. 7-10 for size 08-16 units.

Rated Indoor Airflow (cfm)

The table below lists the rated indoor airflow used for the AHRI efficiency rating for the units covered in this document.

Table 1 — Rated Indoor Airflow (cfm)

| MODEL NUMBER | FULL LOAD AIRFLOW (CFM) |
|--------------|-------------------------|
| 50TC*A/B07 | 2200 |
| 50TC*M08 | 2400 |
| 50TC*D/E08 | 2250 |
| 50TC*M09 | 3000 |
| 50TC*D/E09 | 3400 |
| 50TC*M12 | 3400 |
| 50TC*D/E12 | 3000 |
| 50TC*D/E14 | 3600 |
| 50TC*D/E16 | 5250 |

Pre-Installation

Complete the following checks before installation.

1. Consult local building codes and the NEC (National Electrical Code) ANSI/NFPA 70 for special installation requirements.
2. Determine unit location (from project plans) or select unit location.
3. Check for possible overhead obstructions which may interfere with unit lifting or rigging.

| | | | | | | | | | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|
| Position: | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 |
| Example: | 5 | 0 | T | C | - | A | 0 | 7 | A | 1 | A | 5 | - | 0 | A | 0 | A | 0 |

Unit Heat Type

50 - Electric Heat Packaged Rooftop

Model Series - WeatherMaker®

TC - Standard Efficiency

Heat Size

- = No heat

Refrig. Systems Options

A = Standard One Stage Cooling Models
 B = Standard One Stage Cooling with
 Humidi-MiZer® System (07 models only)
 D = Two-Stage cooling (models 08-16 only)
 E = Two Stage cooling (models 08-16) with Al/Cu
 Condenser Coils and Humidi-MiZer®
 M = Single Circuit, two stage cooling models
 (08, 09, 12 models only) (Humidi-MiZer® not available)

Cooling Tons

| | |
|---------------|----------------|
| 07 = 6 tons | 12 = 10 tons |
| 08 = 7.5 tons | 14 = 12.5 tons |
| 09 = 8.5 tons | 16 = 15 tons |

Sensor Options

A = None
 B = RA Smoke Detector
 C = SA Smoke Detector
 D = RA + SA Smoke Detector
 E = CO₂ Sensor
 F = RA Smoke Detector and CO₂ Sensor
 G = SA Smoke Detector and CO₂ Sensor
 H = RA + SA Smoke Detector and CO₂ Sensor
 J = Condensate Overflow Switch
 K = Condensate Overflow Switch and RA Smoke Detectors
 L = Condensate Overflow Switch and RA and SA Smoke Detectors

Indoor Fan Options

1 = Standard Static Option
 2 = Medium Static Option
 3 = High Static Option
 C = High Static Option with High Efficiency Motor (size 16 only)

Coil Options – RTPF (Outdoor – Indoor – Hail Guard)

A = Al/Cu – Al/Cu
 B = Precoat Al/Cu – Al/Cu
 C = E-coat Al/Cu – Al/Cu
 D = E-coat Al/Cu – E-coat Al/Cu
 E = Cu/Cu – Al/Cu
 F = Cu/Cu – Cu/Cu
 M = Al/Cu – Al/Cu – Louvered Hail Guard
 N = Precoat Al/Cu – Al/Cu – Louvered Hail Guard
 P = E-coat Al/Cu – Al/Cu – Louvered Hail Guard
 Q = E-coat Al/Cu – E-coat Al/Cu – Louvered Hail Guard
 R = Cu/Cu – Al/Cu – Louvered Hail Guard
 S = Cu/Cu – Cu/Cu – Louvered Hail Guard

Coil Options – Novation (Outdoor – Indoor – Hail Guard)

G = Al/Al – Al/Cu
 H = Al/Al – Cu/Cu
 J = Al/Al – E-coat Al/Cu
 K = E-coat Al/Al – Al/Cu
 L = E-coat Al/Al – E-coat Al/Cu
 T = Al/Al – Al/Cu – Louvered Hail Guard
 U = Al/Al – Cu/Cu – Louvered Hail Guard
 V = Al/Al – E-coat Al/Cu – Louvered Hail Guard
 W = E-coat Al/Al – Al/Cu – Louvered Hail Guard
 X = E-coat Al/Al – E-coat Al/Cu – Louvered Hail Guard

Packaging & Seismic Compliance

0 = Standard
 1 = LTL

Electrical Options

A = None
 C = Non-Fused Disconnect
 D = Thru-The-Base Connections
 F = Non-Fused Disconnect and
 Thru-The-Base Connections
 G = 2-Speed Indoor Fan (VFD) Controller
 J = 2 Speed Fan Controller (VFD) and
 Non-Fused Disconnect
 K = 2 Speed Fan Controller (VFD) and
 Thru-The-Base Connections
 M = 2 Speed Fan Controller (VFD)
 with Non-Fused Disconnect and
 Thru-The-Base Connections

Service Options

0 = None
 1 = Unpowered Convenience Outlet
 2 = Powered Convenience Outlet
 3 = Hinged Panels
 4 = Hinged Panels and
 Unpowered Convenience Outlet
 5 = Hinged Panels and
 Powered Convenience Outlet

Intake / Exhaust Options

A = None
 B = Temperature Economizer w/ Barometric Relief
 F = Enthalpy Economizer w/ Barometric Relief
 K = 2-Position Damper
 U = Temperature Ultra Low Leak Economizer
 w/ Barometric Relief
 W = Enthalpy Ultra Low Leak Economizer
 w/ Barometric Relief

Base Unit Controls

0 = Electro-mechanical Controls can be used with W7212
 EconoMi\$er® IV (Non-Fault Detection and Diagnostic)
 1 = PremierLink™ Controller
 2 = RTU Open Multi-Protocol Controller
 6 = Electro-mechanical w/ 2-Speed Fan and W7220
 Economizer Controller Controls. Can be used with
 W7220 EconoMi\$er X (w/ Fault Detection & Diagnostic)

Design Revision

- = Factory Design Revision

Voltage

1 = 575/3/60
 5 = 208-230/3/60
 6 = 460/3/60

NOTE: Not all possible options are displayed, see the current
 50TC 07-16 Price Pages for more details.

Fig. 1 — 50TC 07-16 Model Number Nomenclature (Example)

NOTES:
1. DIMENSIONS ARE IN INCHES, DIMENSIONS
IN [] ARE IN MILLIMETERS.

THIS DOCUMENT IS THE PROPERTY OF UIC CLIMATE CONTROLS AND SECURITY AND IS DELIVERED UPON THE EXPRESS CONDITION THAT THE CONTENTS WILL NOT BE DISCLOSED OR USED WITHOUT WRITTEN CONSENT.








Carrier
Global Technologies

DRAWING REPRESENTS PRODUCT BUILT ON AND AFTER 04/15/2019
(STARTING WITH SERIAL NUMBER 1619...) SEE DETAIL "E" SHT 5

3.  DIRECTION OF AIR FLOW

4. -  ALL VIEW DRAWN USING 3RD ANGLE

| UNIT | J | K |
|----------|------------------|-----------------|
| 50TC-A07 | 41 3/8 [1051] | 14 7/8 [377] |



| CONNECTION SIZES | |
|------------------|---|
| A | 1 3/8" [35] DIA FIELD POWER SUPPLY HOLE |
| B | 2" [51] DIA POWER SUPPLY KNOCKOUT |
| C | 1 3/4" [44] DIA GAUGE ACCESS PLUG |
| D | 7/8" [22] DIA FIELD CONTROL WIRING HOLE |
| E | 3/4" [19] DIA FIELD DRAIN |
| F | 1 1/2" [41] DIA POWER SUPPLY KNOCK-OUT |
| G | 2 1/2" [64] DIA POWER SUPPLY KNOCK-OUT |

| THRU-THE-BASE CHART THESE HOLES REQUIRED FOR USE C.R.B. IN PIRRODAD | | | | | |
|---|---|-----------------------------|-------------|-----------------------------|---|
| | W | THREADED CONDUIT SIZE | WIRE USE | REC'D. HOLE SIZES (MAX.) | |
| | W | 1/2" | 115V | 7/8" (22.2) | |
| | X | 1 1/2" | 24V | 7 1/8" (22.2) | |
| | Y | 3 1/4" | POWER | 1 1/8" (28.6) | |
| | | | | | FOR "H-HU" THE BASE-PIRRODAD FACTORY OPTION, FITTINGS FOR ONLY X & Y ARE PROVIDED (008000) PROVIDES 3 1/4" P/T THRU CURB FLANGE & FITTING. |

11 of 11

Fig. 2 — Dimensional Drawing for Units Built on and After 4/15/19 (Size 07)

PROPERTY OF UIC CLIMATE CONTROLS
SUBMISSION OF THESE DRAWINGS OR DOCUMENTS
DOES NOT CONSTITUTE PART PERFORMANCE OR
ACCEPTANCE OF CONTRACT.
N.Y.

DRAWING REPRESENTS PRODUCT BUILT ON AND PRIOR TO 04/14/2019
SHEET 5 OF 5

NOTES:

1. DIMENSIONS ARE IN INCHES, DIMENSIONS
IN [] ARE IN MILLIMETERS.

| CONNECTION SIZES | |
|------------------|--|
| A | 1 3/8" [35] DIA FIELD POWER SUPPLY HOLE |
| B | 2" [51] DIA POWER SUPPLY KNOCKOUT |
| C | 1 3/4" [44] DIA GAUGE ACCESS PLUG |
| D | 7 1/8" [184] DIA FIELD CONTROL WIRING HOLE |
| E | 3 1/4" [84] DIA NP CONDENSATE DRAIN |
| F | 2 1/2" [64] DIA POWER SUPPLY KNOCK-OUT |

| THRU THE BASE CHART CHART NO. 1001-A0101 | | | | | |
|---|-------------------|----------|-----------------|---------------------------------------|------------------------------------|
| | CONDUT. SIZE | WIRE USE | RED. HOLE SIZES | ACC. | 1/2" (22.2) |
| W | 1/2" | | | | |
| X | 1/2" (1001-A0101) | 24V | 7/8" (22.2) | | |
| Y | 3/4" (1001-A0101) | POWER | 1 1/8" (28.4) | | |
| | | | | FOR "THRU THE BASE" FACTORY OPTION. | |
| | | | | FITTINGS FOR ONLY X & Y ARE PROVIDED. | |
| | | | | | SELECT EITHER 3/4" OR 1 1/8" |
| | | | | | FOR POWER, DEPENDING ON LINE, SITE |

This technical cross-sectional diagram illustrates the internal structure of an air handling unit. The diagram is oriented vertically, showing the flow of air from the bottom to the top. Key components and dimensions include:

- Dimensions:**
 - Width: 32 1/4 [818]
 - Height: 33 3/8 [848]
 - Depth: 16 [406]
 - Horizontal distance from Economizer Hood to Return Air: 25 5/8 [652]
 - Horizontal distance from Return Air to Supply Air: 10 7/8 [277]
 - Horizontal distance from Supply Air to Air Horizontal: 29 3/8 [771]
 - Horizontal distance from Air Horizontal to Air Horizontal: 2X 3 1/8 [19]
 - Vertical distance from Economizer Hood to Return Air: 16 [406]
 - Vertical distance from Return Air to Supply Air: 17 3/4 [455]
 - Vertical distance from Supply Air to Air Horizontal: 26 1/2 [673]
 - Vertical distance from Air Horizontal to Air Horizontal: 18 1/4 [461]
 - Vertical distance from Economizer Hood to Air Horizontal: 33 3/8 [848]
 - Vertical distance from Return Air to Air Horizontal: 29 3/8 [771]
 - Vertical distance from Supply Air to Air Horizontal: 26 1/2 [673]
 - Vertical distance from Air Horizontal to Air Horizontal: 18 1/4 [461]
 - Vertical distance from Economizer Hood to Air Horizontal: 33 3/8 [848]
 - Vertical distance from Return Air to Air Horizontal: 29 3/8 [771]
 - Vertical distance from Supply Air to Air Horizontal: 26 1/2 [673]
 - Vertical distance from Air Horizontal to Air Horizontal: 18 1/4 [461]
- Components:**
 - ECONOMIZER HOOD (OPTIONAL)
 - RETURN AIR
 - CONDENSATE DRAIN DRAINING IN BASE PAN
 - SEE THRU THE BASE CHART
 - SEE DETAIL B
 - SHEET 5

This technical drawing illustrates a condenser coil assembly. The drawing shows a rectangular frame containing a large coil of copper tubing. Several dimensions are indicated: a width of 46 3/4 inches [1188 mm] for the entire assembly, a height of 33 3/4 inches [855 mm] for the coil, and a depth of 6 5/8 inches [168 mm] for the front panel. A dimension 'K' is shown for the side clearance. Labels include 'CONDENSER AIR' pointing to the left side, 'CONDENSER COIL' pointing to the top of the coil, 'OPTIONAL FACTORY INSTALLED CONDUIT/PIPE OUL' pointing to the right side, and 'FIELD INSTALLED ELECTRICAL DISCONNECT LOCATION A,B,G.' pointing to the top center. A dimension of 19 1/2 inches [494 mm] is shown for the top edge of the coil. A small dimension of 0 is shown near the top center. A dimension of 3 3/4 inches [95 mm] is shown at the bottom right. A large arrow at the bottom points upwards, and a large arrow on the left points to the left. The word 'LEFT' is written vertically on the right side.

INDOOR BLOWER
ACCESS

OPTIONAL
FACTORY
INSTALLED
DISCONNECT

CONTROL BOX
ACCESS PANEL

HANDLE

HANDLE

74-3/8

ITC CLASSIFICATION SHEET DATE SUPERFIDES 50TC 07 SINGLE ZONE ELECTRICAL ARTM000004 REV

Fig. 3 — Dimensional Drawing for Units Built Prior to 4/15/19 (Size 07)




Fig. 4 — Corner Weights and Clearances (Size 07)

THIS DOCUMENT IS THE PROPERTY OF UIC CLIMATE CONTROLS. SUBMISSION OF THESE DRAWINGS OR DOCUMENTS DOES NOT CONSTITUTE PART PERFORMANCE OR ACCEPTANCE OF CONTRACT.
SECURITY AND IS DELIVERED UPON THE EXPRESS CONDITION THAT IT NOT BE DISCLOSED OR USED
WITHOUT WRITTEN CONSENT.






Fig. 5 — Base Rail Details (Size 07)



| THRU-THE-BASE CHART CRBMPN900TA01 | | | |
|--------------------------------------|--------------------------|---|----------------------------|
| | THREADED CONDUIT SIZE | WIRE USE | REO'D HOLE SIZES (MAX.) |
| W | 1/2" | ACC | 7/8" [22.2] |
| X | 1 1/2" | 2AV | 7/8" [22.2] |
| Y * | 3 1/4" (001A01) | POWER 1 1/8" [28.4] | |
| | | FOR "THRU-THE-BASEPAN" FACTORY OPTION, FITTINGS FOR ONLY X & Y ARE PROVIDED. | |
| | | SELECT EITHER 3 1/4" OR 1 1/2" | |
| | | FOR POWER, DEPENDING ON WIRE SIZE | |

| THRU-THE-BASE CHART CRBMPN900A00 | | | |
|-------------------------------------|--------------------------|---|----------------------------|
| | THREADED CONDUIT SIZE | WIRE USE | REO'D HOLE SIZES (MAX.) |
| W | 1/2" | ACC | 7/8" [22.2] |
| X | 1 1/2" | 2AV | 7/8" [22.2] |
| Y | 3 1/4" | POWER 1 1/8" [28.6] | |
| | | FOR "THRU-THE-BASEPAN" FACTORY OPTION, FITTINGS FOR ONLY X & Y ARE PROVIDED. | |
| | | (008A00) PROVIDES 3 1/4" FPT THRU CURB FLANGE & FITTING. | |



THIS VIEW REPRESENTS PRODUCT BUILT ON AND PRIOR TO 04/14/2019

THIS VIEW REPRESENTS PRODUCT BUILT ON AND AFTER 04/15/2019

| | | | | | | |
|--------------------|--------|----------|------------|---|------------|----------|
| ITC CLASSIFICATION | SHEET | DATE | SUPERSEDES | 50TC07 SINGLE ZONE ELECTRICAL COOLING WITH ELECTRIC HEAT | 48TM500934 | REV G |
| U.S. ECCN: NSR | 5 OF 5 | 12/27/18 | 03/02/15 | | | |

Fig. 6 — Thru-the-Base Charts (Size 07)




Fig. 7 — Unit Dimensional Drawing (Size 08, 09, 12)




Fig. 7 —Unit Dimensional Drawing (Size 08, 09, 12) (cont)




Fig. 8 — Unit Dimensional Drawing (Size 14)






Fig. 8 —Unit Dimensional Drawing (Size 14) (cont)

STANDARD UNIT WEIGHT IS WITHOUT ELECTRIC HEAT & WITHOUT PACKAGING.
FOR OPTIONS & ACCESSORIES, REFER TO THE PRODUCT DATA CATALOG.



FRONT






Fig. 9 — Unit Dimensional Drawing — Size 16 Unit (cont)

| DATE | SUPERCEDES | 50TC 16 SINGLE ZONE ELECTRICAL COOLING WITH ELECTRIC HEAT | 50TM012/8 | REV |
|----------|------------|--|-----------|-----|
| 05/21/12 | - | | | B |

HORIZONTAL ECONOMIZER



| LOCATION | DIMENSION | CONDITION |
|----------|---|---|
| A | 48-in. (1219 mm) 18-in. (457 mm) 18-in. (457 mm) 12-in. (305 mm) | Unit disconnect is mounted on panel No disconnect, convenience outlet option Recommended service clearance Minimum clearance |
| B | 42-in. (1067 mm) 36-in. (914 mm) Special | Surface behind servicer is grounded (e.g., metal, masonry wall) Surface behind servicer is electrically non-conductive (e.g., wood, fiberglass) Check sources of flue products within 10 ft (3 m) of unit fresh air intake hood |
| C | 36-in. (914 mm) 18-in. (457 mm) | Side condensate drain is used Minimum clearance |
| D | 48 in. (1219 mm) 42-in. (1067 mm) 36-in. (914 mm) Special | No flue discharge accessory installed, surface is combustible material Surface behind servicer is grounded (e.g., metal, masonry wall, another unit) Surface behind servicer is electrically non-conductive (e.g., wood, fiberglass) Check for adjustable units or building fresh air intakes within 10 ft (3 m) of this units flue outlet |

NOTE: Unit not designed to have overhead obstruction. Contact Application Engineering for guidance on any application planning overhead obstruction or for vertical clearances.

Fig. 10 — Service Clearance Dimensions (applies to all 08-16 units, size 14 unit shown)

INSTALLATION

Jobsite Survey

Complete the following checks before installation.

1. Consult local building codes and the NEC (National Electrical Code) ANSI/NFPA 70 for special installation requirements.
2. Determine unit location (from project plans) or select unit location.
3. Check for possible overhead obstructions which may interfere with unit lifting or rigging.

Step 1 — Plan for Unit Location

Select a location for the unit and its support system (curb or other) that provides for the minimum clearances required for safety. This includes the clearance to combustible surfaces, unit performance and service access below, around and above unit as specified in unit drawings. See Fig. 10.

NOTE: Consider also the effect of adjacent units.

Unit may be installed directly on wood flooring or on Class A, B, or C roof-covering material when roof curb is used.

Do not install unit in an indoor location. Do not locate air inlets near exhaust vents or other sources of contaminated air.

Although unit is weatherproof, avoid locations that permit water from higher level runoff and overhangs to fall onto the unit.

Select a unit mounting system that provides adequate height to allow for removal and disposal of frost and ice that will form during

the heating-defrost mode as well as allow installation of condensate trap per requirements. Refer to Step 9 "Install External Condensate Trap and Line" on page 25 for required trap dimensions.

ROOF MOUNT

Check building codes for weight distribution requirements. Unit operating weight is shown in Table 2.

Step 2 — Plan for Sequence of Unit Installation

The support method used for this unit will dictate different sequences for the steps of unit installation. For example, on curb-mounted units, some accessories must be installed on the unit before the unit is placed on the curb. Review the following for recommended sequences for installation steps.

CURB-MOUNTED INSTALLATION

1. Install curb
2. Install field-fabricated ductwork inside curb
3. Install accessory thru-base service connection package (affects curb and unit) (refer to accessory installation instructions for details)
4. Prepare bottom condensate drain connection to suit planned condensate line routing (refer to "Step 9 — Install External Condensate Trap and Line" on page 25 for details)
5. Rig and place unit
6. Install outdoor air hood
7. Install condensate line trap and piping
8. Make electrical connections
9. Install other accessories.

PAD-MOUNTED INSTALLATION

1. Prepare pad and unit supports
2. Check and tighten the bottom condensate drain connection plug
3. Rig and place unit
4. Convert unit to side-duct connection arrangement
5. Install field-fabricated ductwork at unit duct openings
6. Install outdoor air hood
7. Install condensate line trap and piping
8. Make electrical connections
9. Install other accessories

FRAME-MOUNTED INSTALLATION

Frame-mounted applications generally follow the sequence for a curb installation. Adapt as required to suit specific installation plan.

Step 3 — Inspect Unit

Inspect unit for transportation damage. File any claim with transportation agency.

Confirm before installation of unit that voltage, amperage and circuit protection requirements listed on unit data plate agree with power supply provided.

On units with hinged panel option, check to be sure all latches are snug and in closed position.

Locate the carton containing the outside air hood parts; see Fig. 27. Do not remove carton until unit has been rigged and locate in final position.


Step 4 — Provide Unit Support

ROOF CURB MOUNT

Accessory roof curb details and dimensions are shown in Fig. 12-14. Assemble and install accessory roof curb in accordance with instructions shipped with the curb.

NOTE: The gasketing of the unit to the roof curb is critical for a watertight seal. Install gasket supplied with the roof curb as shown in Fig. 12-14. Improperly applied gasket can also result in air leaks and poor unit performance.

Curb should be level. This is necessary for unit drain to function properly. Unit leveling tolerances are shown in Fig. 11. Refer to Accessory Roof Curb Installation Instructions for additional information as required.



MAXIMUM ALLOWABLE DIFFERENCE IN. (MM)

| A-B | B-C | A-C |
|----------|----------|----------|
| 0.5 (13) | 1.0 (25) | 1.0 (25) |

Fig. 11 — Unit Leveling Tolerances

Install insulation, cant strips, roofing felt, and counter flashing as shown. *Ductwork must be attached to curb and not to the unit. The accessory thru-the-base power and gas connection package must be installed before the unit is set on the roof curb.*

If electric and control wiring is to be routed through the basepan, attach the accessory thru-the-base service connections to the basepan in accordance with the accessory installation instructions.

SLAB MOUNT (HORIZONTAL UNITS ONLY)

Provide a level concrete slab that extends a minimum of 6-in. (150 mm) beyond unit cabinet. Install a gravel apron in front of condenser coil air inlet to prevent grass and foliage from obstructing airflow.

NOTE: Horizontal units may be installed on a roof curb if required.

ALTERNATE UNIT SUPPORT (IN LIEU OF CURB OR SLAB MOUNT)

A non-combustible sleeper rail can be used in the unit curb support area. If sleeper rails cannot be used, support the long sides of the unit with a minimum of 3 equally spaced 4-in. x 4-in. (102 mm x 102 mm) pads on each side.

Table 2 — Operating Weights (50TC 07-16)

| 50TC | UNITS LB (KG) | | | | | |
|------------------------------|---------------|-----------|-----------|-----------|------------|------------|
| | 07 | 08 | 09 | 12 | 14 | 16 |
| 50TC-A/B | 607 (275) | | | | | |
| 50TC_M/RTPF | | 777 (353) | 805 (365) | 850 (386) | N/A | N/A |
| 50TC_D/RTPF | | 730 (331) | 855 (388) | 865 (393) | 1075 (489) | 1305 (593) |
| 50TC_D/MCHX | | 805 (366) | N/A | 820 (372) | 1030 (467) | N/A |
| Economizer | | | | | | |
| Vertical | 50 (23) | 75 (34) | 75 (34) | 75 (34) | 75 (34) | 100 (45) |
| Horizontal | 80 (36) | 122 (55) | 122 (55) | 122 (55) | 122 (55) | 115 (52) |
| Powered Outlet | 35 (16) | 35 (16) | 35 (16) | 35 (16) | 35 (16) | 32 (15) |
| Humidi-Mizer® System* | 41 (15) | 80 (36) | 80 (36) | 80 (36) | 85 (39) | 62 (28) |
| Curb | | | | | | |
| 14 in. (356 mm) | 110 (50) | 143 (65) | 143 (65) | 143 (65) | 143 (65) | 180 (82) |
| 24 in. (610 mm) | 145 (66) | 245 (111) | 245 (111) | 245 (111) | 245 (111) | 235 (107) |

* Humidi-Mizer system is not available on 50TC*M models.




Fig. 12 — Roof Curb Details - Size 07 Units

| CONNECTOR PKG ACC. | GAS CONNECTION TYPE | GAS FITTING | POWER WIRING FITTING | CONTROL WIRING FITTING | ACCESSORY CONVENIENCE OUTLET WIRING CONNECTOR |
|--------------------|---------------------|-------------|----------------------|------------------------|---|
| CRBTMPW020A01 | THRU THE CURB | | 3/4" [19] NPT | 1 1/4" [31.7] NPT | 1/2" [12.7] NPT |
| CRBTMPW040A01 | THRU THE BOTTOM | | | | 1/2" [12.7] NPT |

ROCCURB ACCESSORY IS SHIPPED DISASSEMBLED. INSULATED PANELS 2.5 x 4.117 INCH POLYURETHANE FOAM, 44.5 [1-3/4] # DENSITY. DIMENSIONS 11 LARE IN MILLIMETERS. ROCCURB, 18 GAGE STEEL. ATTACH DUCTWORK TO CURB, (FLANGES OF DUCT REST ON CURB). SERVICE CLEARANCE 4 FEET ON EACH SIDE. DIRECTION OF AIR FLOW.





Fig. 13 — Roof Curb Details - Size 08-14 Units




Fig. 14 — Roof Curb Details - Size 16 Unit

Step 5 — Field Fabricate Ductwork

Cabinet return-air static pressure (a negative condition) shall not exceed 0.35 in. wg (87 Pa) with economizer or 0.45 in. wg (112 Pa) without economizer.

For vertical ducted applications, secure all ducts to roof curb and building structure. *Do not connect ductwork to unit.*

Fabricate supply ductwork so that the cross sectional dimensions are equal to or greater than the unit supply duct opening dimensions for the first 18-in. (458 mm) of duct length from the unit basepan.

Insulate and weatherproof all external ductwork, joints, and roof openings with counter flashing and mastic in accordance with applicable codes.

Ducts passing through unconditioned spaces must be insulated and covered with a vapor barrier.

If a plenum return is used on a vertical unit, the return should be ducted through the roof deck to comply with applicable fire codes.

⚠ CAUTION

PROPERTY DAMAGE HAZARD

Failure to follow this caution may result in damage to roofing materials.

Membrane roofs can be cut by sharp sheet metal edges. Be careful when placing any sheet metal parts on such roof.

FOR UNITS WITH ACCESSORY ELECTRIC HEATERS

All installations require a minimum clearance to combustible surfaces of 1-in. (25 mm) from duct for first 12-in. (305 mm) away from unit.

Outlet grilles must not lie directly below unit discharge.

NOTE: A 90 degree elbow must be provided in the ductwork to comply with UL (Underwriters Laboratories) code for use with electric heat.

⚠ WARNING

PERSONAL INJURY HAZARD


Failure to follow this warning could cause personal injury.

For vertical supply and return units, tools or parts could drop into ductwork and cause an injury. Install a 90 degree turn in the return ductwork between the unit and the conditioned space. If a 90 degree elbow cannot be installed, then a grille of sufficient strength and density should be installed to prevent objects from falling into the conditioned space. Due to electric heater, supply duct will require 90 degree elbow.

Step 6 — Rig and Place Unit

Keep unit upright and do not drop. Spreader bars are required for 08-14 size units; size 16 units do not require spreader bars. Rollers may be used to move unit across a roof. Level by using unit frame as a reference. See Table 2 and Fig. 15 for additional information.

Lifting holes are provided in base rails as shown in Fig. 15. Refer to rigging instructions on unit.



| UNIT | MAX WEIGHT | | DIMENSIONS | | | | | |
|------------|------------|-----|------------|------|------|------|------|------|
| | lb | kg | A | | B | | C | |
| | | | in. | mm | in. | mm | in. | mm |
| 50TC-A07 | 1040 | 473 | 74.5 | 1890 | 38.0 | 965 | 41.5 | 1055 |
| 50TC-M08 | 1255 | 569 | 88.0 | 2235 | 40.0 | 1015 | 41.5 | 1055 |
| 50TC-M09 | 1305 | 592 | 88.0 | 2235 | 39.5 | 1005 | 49.5 | 1255 |
| 50TC-M12 | 1400 | 635 | 88.0 | 2235 | 41.0 | 1040 | 49.5 | 1255 |
| 50TC-D/E08 | 1410 | 641 | 88.0 | 2235 | 41.0 | 1040 | 41.5 | 1055 |
| 50TC-D/E09 | 1525 | 693 | 88.0 | 2235 | 40.5 | 1030 | 49.5 | 1255 |
| 50TC-D/E12 | 1565 | 711 | 88.0 | 2235 | 40.0 | 1015 | 49.5 | 1255 |
| 50TC-D/E14 | 1720 | 782 | 88.0 | 2235 | 28.5 | 725 | 53.0 | 1345 |
| 50TC-D/E16 | 2010 | 912 | 116.0 | 2945 | 57.5 | 1461 | 59.5 | 1510 |

NOTES:

1. SPREADER BARS REQUIRED FOR SIZES 07-14 — Top damage will occur if spreader bars are not used.
2. Dimensions in () are in millimeters.
3. Hook rigging shackles through holes in base rail, as shown in detail "A." Holes in base rails are centered around the unit center of gravity.

Fig. 15 — Rigging Details

Before setting the unit onto the curb, recheck gasketing on curb.

Rigging materials under unit (cardboard or wood to prevent base pan damage) must be removed PRIOR to placing the unit on the roof curb.

When using the standard side drain connection, ensure the red plug in the alternate bottom connection is tight. Do this before setting the unit in place. The red drain pan can be tightened with a 1/2-in. square socket drive extension. For further details see "Step 9 — Install External Condensate Trap and Line" on page 25.

CAUTION

UNIT DAMAGE HAZARD

Failure to follow this caution may result in equipment damage.

All panels must be in place when rigging. Unit is not designed for handling by fork truck when packaging is removed.

If using top crate as spreader bar, once unit is set, carefully lower wooden crate off building roof top to ground. Ensure that no people or obstructions are below prior to lowering the crate.

POSITIONING ON CURB (50TC 07-14)

Position unit on roof curb so that the following clearances are maintained: 1/4-in. (6.4 mm) clearance between the roof curb and the base rail inside the front and back, 0.0-in. clearance between the roof curb and the base rail inside on the duct end of the unit. This will result in the distance between the roof curb and the base rail inside on the condenser end of the unit being approximately 1/4-in. (6.4 mm).

Although unit is weatherproof, guard against water from higher level runoff and overhangs. After unit is in position, remove rigging skids and shipping materials.

POSITIONING ON CURB (50TC 16)

For full perimeter curbs CRRFCURB074A00 and 075A00, the clearance between the roof curb and the front and rear base rails should be 1/4-in. (6.4 mm). The clearance between the curb and the end base rails should be 1/2-in. (13 mm). For retrofit applications with curbs CRRFCURB003A01 and 4A01, the unit should be positioned as shown in Fig. 16. Maintain the 15 1/2-in. (394 mm) and 8 5/8-in. (220 mm) clearances and allow the 22 5/16-in. (567 mm) dimension to float if necessary.




Fig. 16 — Retrofit Installation Dimensions (Size 16)

If the alternative condensate drain location through the bottom of the unit is used in conjunction with a retrofit curb, the hole in the curb must be moved 12.5-in. (320 mm) towards the duct end of the unit. (See Fig. 17.)

Although unit is weatherproof, guard against water from higher level runoff and overhangs.




Fig. 17 — Alternative Condensate Drain Hole Positions (Size 16)

IMPORTANT: If the unit has the factory-installed Thru-the-Base option, make sure to complete installation of the option before placing the unit on the roof curb.

See the following section:

- Factory-Option Thru-Base Connections

NOTE: If electrical connections is not going to occur at this time, tape or otherwise cover the fittings so that moisture does not get into the building or conduit in the interim.

Remove all shipping materials and top skid. Remove extra center post from the condenser end of the unit so that the condenser end of the unit matches Fig. 58-60. Recycle or dispose of all shipping materials.

Step 7 — Convert to Horizontal and Connect Ductwork (when required)

50TC 07-14 UNITS

Unit is shipped in the vertical duct configuration. Unit without factory-installed economizer or return-air smoke detector option may be field-converted to horizontal ducted configuration. To convert to horizontal configuration, remove screws from side duct opening covers (see Fig. 18) and remove covers. Use the screws to install the covers on vertical duct openings with the insulation-side down. The panels must be inserted into the notches on the basepan to properly seal. The notches are covered by the tape used to secure the insulation to the basepan and are not easily seen. See Fig. 19 for position of the notches in the basepan. Seals around duct openings must be tight. Secure with screws as shown in Fig. 20. Cover seams with foil duct tape.




Fig. 18 — Horizontal Conversion Panels (Sizes 07-14)




Fig. 19 — Location of Notches (Sizes 07-14)




Fig. 20 — Horizontal Duct Panels in Place (Sizes 07-14)

50TC 16 UNITS

Unit is shipped in the vertical duct configuration. Unit without factory-installed economizer or return-air smoke detector option may be field-converted to horizontal ducted configuration using accessory CRDUCTCV002A00. To convert to horizontal configuration, remove screws from side duct opening covers and remove covers. Discard the supply duct cover. Install accessory CRDUCTCV002A00 to cover the vertical supply duct opening. Use the return duct cover removed from the end panel to cover the vertical return duct opening.

ALL UNITS

Field-supplied flanges should be attached to horizontal duct openings and all ductwork should be secured to the flanges. Insulate and weatherproof all external ductwork, joints, and roof or building openings with counter flashing and mastic in accordance with applicable codes.

Do not cover or obscure visibility to the unit's informative data plate when insulating horizontal ductwork.

Step 8 — Install Outside Air Hood

50TC 07-14 OUTSIDE AIR HOOD

Economizer and Two Position Damper Hood Package Removal and Setup — Factory Option (Size 07-14)

1. The hood is shipped in knock-down form and must be field-assembled. The indoor coil access panel is used as the hood top while the hood sides, divider and filter are packaged together, attached to a metal support tray using plastic stretch wrap, and shipped in the return air compartment behind the indoor coil access panel. The hood assembly's metal tray is attached to the basepan and also attached to the damper using two plastic tie-wraps.
2. To gain access to the hood, remove the filter access panel. (See Fig. 21.)
3. Locate the (2) screws holding the metal tray to the basepan and remove. Locate and cut the (2) plastic tie-wraps securing the assembly to the damper. (See Fig. 22.) Be careful to not damage any wiring or cut tie-wraps securing any wiring.
4. Carefully lift the hood assembly (with metal tray) through the filter access opening and assemble per the steps outlined in *Economizer Hood and Two-Position Damper Hood*.

FILTER ACCESS PANEL




Fig. 21 — Typical Access Panel Locations (Sizes 07-14)




Fig. 22 — Economizer and Two-Position Damper Hood Parts Location (Sizes 07-14)

Economizer Hood and Two-Position Damper Hood Installation (Size 07-14)

NOTE: If the power exhaust accessory is to be installed on the unit, the hood shipped with the unit will not be used and must be discarded. Save the aluminum filter for use in the power exhaust hood assembly.

1. The indoor coil access panel will be used as the top of the hood. Remove the screws along the sides and bottom of the indoor coil access panel. See Fig. 23.
2. Swing out indoor coil access panel and insert the hood sides under the panel (hood top). Use the screws provided to attach the hood sides to the hood top. Use screws provided to attach the hood sides to the unit. See Fig. 24.
3. Remove the shipping tape holding the economizer barometric relief damper in place (economizer only).
4. Insert the hood divider between the hood sides. See Fig. 24 and 25. Secure hood divider with 2 screws on each hood side. The hood divider is also used as the bottom filter rack for the aluminum filter.
5. Open the filter clips which are located underneath the hood top. Insert the aluminum filter into the bottom filter rack (hood divider). Push the filter into position past the open filter clips. Close the filter clips to lock the filter into place. See Fig. 25.
6. Caulk the ends of the joint between the unit top panel and the hood top.
7. Replace the filter access panel.




Fig. 23 — Indoor Coil Access Panel Relocation (Sizes 07-14)




Fig. 24 — Economizer Hood Construction (Sizes 07-14)




Fig. 25 — Economizer Filter Installation (Sizes 07-14)

50TC 16 OUTSIDE AIR HOOD

Economizer Hood Removal and Setup – Factory Option (Size 16)

1. The hood is shipped in knock-down form and located in the return air compartment. It is attached to the economizer using two plastic tie-wraps.
2. To gain access to the hood, remove the filter access panel. (See Fig. 26.)
3. Locate and cut the (2) plastic tie-wraps, being careful to not damage any wiring. (See Fig. 27.)
4. Carefully lift the hood assembly through the filter access opening and assemble per the steps outlined in Economizer Hood and Two-Position Damper Hood (Size 16) section on page 24.




Fig. 26 — Typical Access Panel Locations (Size 16)




Fig. 27 — Economizer Hood Package Location (Size 16)

Two Position Damper Hood Removal and Setup – Factory Option (Size 16)

1. The hood is shipped in knock-down form and assembled to a metal support tray using plastic stretch wrap. Located in the return-air compartment, the assembly's metal tray is attached to the basepan and also attached to the damper using two plastic tie-wraps.
2. To gain access to the hood, remove the filter access panel. (See Fig. 26.)

3. Locate the (2) screws holding the metal tray to the basepan and remove. In order to remove the screws, it may be necessary to remove the panel underneath the two-position damper. Remove the two screws. Locate and cut the (2) plastic tie-wraps securing the assembly to the damper. (See Fig. 28.) Be careful to not damage any wiring or cut tie-wraps securing any wiring.
4. Carefully lift the hood assembly (with metal tray) through the filter access opening and assemble per the steps outlined in Economizer Hood and Two-Position Damper Hood (Size 16) on page 24.
5. If removed, reattach the panel under the damper.




Fig. 28 — Two-Position Damper Hood Package Location (Size 16)

Economizer Hood and Two-Position Damper Hood Installation (Size 16)

NOTE: If the power exhaust accessory is to be installed on the unit, the hood shipped with the unit will not be used and must be discarded. Save the aluminum filter for use in the power exhaust hood assembly.

1. The indoor coil access panel will be used as the top of the hood. If the panel is still attached to the unit, remove the screws along the sides and bottom of the panel. See Fig. 29.
2. Swing out indoor coil access panel and insert the hood sides under the panel (hood top). Be careful not to lift the panel too far as it might fall out. Use the screws provided to attach the hood sides to the hood top. Use screws provided to attach the hood sides to the unit. See Fig. 30.
3. Remove the shipping tape holding the economizer barometric relief damper in place.
4. Insert the hood divider between the hood sides. See Fig. 30 and 31. Secure hood divider with 3 screws on each hood side. The hood divider is also used as the bottom filter rack for the aluminum filter.
5. Attach the post that separates the filters with the screws provided.
6. Open the filter clips which are located underneath the hood top. Insert the aluminum filters into the bottom filter rack (hood divider). Push the filter into position past the open filter clips. Close the filter clips to lock the filters into place. See Fig. 31.
7. Install the two rain deflectors on the edge of the hood top as shown in Fig. 29.
8. Caulk the ends of the joint between the unit top panel and the hood top as shown in Fig. 29.

9. Replace the filter access panel.




Fig. 29 — Indoor Coil Access Panel Relocation (Size 16)




Fig. 30 — Economizer Hood Construction (Size 16)




Fig. 31 — Economizer Filter Installation (Size 16)

Step 9 — Install External Condensate Trap and Line

The unit has one $3/4$ -in. condensate drain connection on the end of the condensate pan and an alternate connection on the bottom. See Fig. 32. Unit airflow configuration does not determine which drain connection to use. Either drain connection can be used with vertical or horizontal applications.

When using the 50TC*16 standard side drain connection, ensure the red plug in the alternate bottom connection is tight. Do this before setting the unit in place. The red drain pan can be tightened with a $1/2$ in. square socket drive extension.

To use the alternate bottom drain connection, remove the red drain plug from the bottom connection (use a $1/2$ -in. square socket drive extension) and install it in the side drain connection.





Fig. 32 — Condensate Drain Pan (Side View)

The piping for the condensate drain and external trap can be completed after the unit is in place. See Fig. 33.



NOTE: Trap should be deep enough to offset maximum unit static difference. A 4-in. (102 mm) trap is recommended.

Fig. 33 — Condensate Drain Piping Details

All units must have an external trap for condensate drainage. Install a trap at least 4-in. (102 mm) deep and protect against freeze-up. If drain line is installed downstream from the external trap, pitch the line away from the unit at 1-in. per 10 ft (25 mm in 3 m) of run. Do not use a pipe size smaller than the unit connection ($3/4$ -in.).

See Fig. 34-45 for wiring diagrams.




Fig. 34 — 50TC 07 Control Wiring Diagram




Fig. 35 — 50TC 07 Power Wiring Diagram




Fig. 36 — 50TC-M08-12 Control Wiring Diagram




Fig. 37 — 50TC-D/E Wiring Diagram (08-14 Size Units)




Fig. 38 — Single-Stage Cooling (without VFD) Power Wiring Diagram (Sizes 08-12)




Fig. 39 — 2-Stage Cooling (with VFD) Power Wiring Diagram (Sizes 08-12)




Fig. 40 — 2-Stage Cooling (with VFD) Power Wiring Diagram (Size 14)

15T STD TIER PAC CONTROL 208/230V, 460V, 575V
3 OEM DIAI COMPRESSOR




Fig. 41 — 50TC 16 Wiring Diagram




Fig. 42 — 2-Stage Cooling (with VFD) Power Wiring Diagram (Size 16)




Fig. 43 — 50TC 07 Units Wiring Diagram with Humidi-MiZer® System Option




Fig. 44 — 50TC 08-14 Units Wiring Diagram with Humidi-MiZer® System Option




Fig. 45 — 50TC 16 Wiring Diagram with Humidi-MiZer® System Option

Step 10 — Make Electrical Connections

50TC 07-14 UNIT ELECTRICAL CONNECTIONS

NOTE: See page 42 for 50TC 16 unit electrical connections.

⚠ WARNING

ELECTRIC SHOCK HAZARD

Failure to follow this warning could result in personal injury or death.

Unit cabinet must have an uninterrupted, unbroken electrical ground to minimize the possibility of personal injury if an electrical fault should occur. This ground may consist of electrical wire connected to unit ground lug in control compartment, or conduit approved for electrical ground when installed in accordance with NEC; ANSI/NFPA 70, latest edition (in Canada, Canadian Electrical Code CSA [Canadian Standards Association] C22.1), and local electrical codes.

NOTE: Check all factory and field electrical connections for tightness. Field-supplied wiring shall conform with the limitations of minimum 63°F (33°C) rise.

Field Power Supply

If equipped with optional powered convenience outlet: the power source leads to the convenience outlet's transformer primary are not factory connected. Installer must connect these leads according to required operation of the convenience outlet. If an always-energized convenience outlet operation is desired, connect the source leads to the line side of the unit-mounted disconnect. (Check with local codes to ensure this method is acceptable in your area.) If a de-energize via unit disconnect switch operation of the convenience outlet is desired, connect the source leads to the load side of the unit disconnect. On a unit without a unit-mounted disconnect, connect the source leads to compressor contactor C and indoor fan contactor IFC pressure lugs with unit field power leads.

Refer to Fig. 52 for power transformer connections and the discussion on connecting the convenience outlet.

Field power wires are connected to the unit at line-side pressure lugs on compressor contactor C and indoor fan contactor IFC (see wiring diagram label for control box component arrangement) or at factory-installed option non-fused disconnect switch. Max wire size is #4 AWG (copper only). (See Fig. 49.)

NOTE: TEST LEADS - Unit may be equipped with short leads (pigtails) on the field line connection points on contactor C or optional disconnect switch. These leads are for factory run-test purposes only; remove and discard before connecting field power wires to unit connection points. Make field power connections directly to line connection pressure lugs only.

⚠ WARNING

FIRE HAZARD

Failure to follow this warning could result in personal injury, death, or property damage.

Do not connect aluminum wire between disconnect switch and unit. Use only copper wire.




Fig. 46 — Disconnect Switch and Unit (Sizes 07-14)

Units with Factory-Installed Non-Fused Disconnect

The factory-installed optional non-fused disconnect (NFD) switch is located in a weatherproof enclosure located under the main control box (see Fig. 47). The manual switch handle and shaft are shipped in the disconnect enclosure. Assemble the shaft and handle to the switch at this point. Discard the factory test leads (see Fig. 49).

Connect field power supply conductors to LINE side terminals when the switch enclosure cover is removed to attach the handle.

Field-Install the NFD Shaft and Handle

1. Remove the control box access panel. The NFD enclosure is located below the control box (see Fig. 47).
2. Remove (3) cap head screws that secure the NFD enclosure front cover — (2) on the face of the cover and (1) on the left side cover. See Fig. 48.
3. Remove the front cover of the NFD enclosure.
4. Make sure the NFD shipped from the factory is at OFF position (the arrow on the black handle knob is at OFF).
5. Insert the shaft with the cross pin on the top of the shaft in the horizontal position. See Fig. 48.
6. Measure from the tip of the shaft to the top surface of the black pointer; the measurement should be 3.75 to 3.88-in. (95 to 99 mm).
7. Tighten the locking screw to secure the shaft to the NFD.
8. Turn the handle to the OFF position with red arrow pointing at OFF.
9. Install the handle on to the painted cover horizontally with the red arrow pointing to the left.
10. Secure the handle to the painted cover with (2) screws and lock washers supplied.
11. Engaging the shaft into the handle socket, re-install (3) hex screws on the NFD enclosure.
12. Re-install the unit front panel.




Fig. 47 — NFD Enclosure (Sizes 07-14)

See Fig. 46.





Fig. 48 — NFD Handle and Shaft Assembly (Sizes 07-14)

When installing units, provide a disconnect switch per NEC (National Electrical Code) of adequate size. Disconnect sizing data is provided on the unit informative plate. Locate disconnect sizing data on unit cabinet or within sight of the unit per national or local codes. Do not cover unit informative plate if mounting the disconnect on the unit cabinet.

FIELD WIRING FOR 50TC 07-14 UNITS

All field wiring must comply with NEC and all local codes. Size wire based on MCA (Minimum Circuit Amps) on the unit informative plate. See Fig. 49 and the unit label diagram for power wiring connections to the unit power terminal blocks and equipment ground. Maximum wire size is #4 ga AWG per pole.

Units Without Disconnect Option



Units With Disconnect Option




Fig. 49 — Power Wiring Connections (Sizes 07-14)

Provide a ground-fault and short-circuit over-current protection device (fuse or breaker) per NEC Article 440 (or local codes). Refer to unit informative data plate for MOCP (Maximum Over-current Protection) device size.

All field wiring must comply with the NEC and local requirements.


All units except 208/230-v units are factory wired for the voltage shown on the nameplate. *If the 208/230-v unit is to be connected to a 208-v power supply, the control transformer must be rewired by moving the black wire with the 1/4-in. female spade connector from the 230-v connection and moving it to the 200-v 1/4-in. male terminal on the primary side of the transformer.* Refer to unit label diagram for additional information.

Voltage to compressor terminals during operation must be within voltage range indicated on unit nameplate. On 3-phase units, voltages between phases must be balanced within 2% and the current within 10%. Use the following formula to determine the percent of voltage imbalance. Operation on improper line voltage or excessive phase imbalance constitutes abuse and may cause damage to electrical components. Such operation would invalidate any applicable Carrier warranty.

% Voltage Imbalance:

$$= 100 \times \frac{\text{max voltage deviation from average voltage}}{\text{average voltage}}$$

Example: Supply voltage is 230-3-60



$$\text{Average Voltage} = \frac{(224 + 231 + 226)}{3} = \frac{681}{3} = 227$$

Determine maximum deviation from average voltage.

(AB) 227-224 = 3 v

(BC) 231-227 = 4 v

(AC) 227-226 = 1 v

Maximum deviation is 4 v.

Determine percent of voltage imbalance.

$$\% \text{ Voltage Imbalance} = 100 \times \frac{4}{227} = 1.78\%$$

This amount of phase imbalance is satisfactory as it is below the maximum allowable 2%.

IMPORTANT: If the supply voltage phase imbalance is more than 2%, contact your local electric utility company immediately.

NOTE: Check all factory and field electrical connections for tightness.

CONVENIENCE OUTLETS FOR 50TC 07-14 UNITS

WARNING

ELECTRICAL OPERATION HAZARD

Failure to follow this warning could result in personal injury or death.

Units with convenience outlet circuits may use multiple disconnects. Check convenience outlet for power status before opening unit for service. Locate its disconnect switch, if appropriate, and open it. Lock-out and tag-out this switch, if necessary.

Two types of convenience outlets are offered on 50TC models: non-powered and unit-powered. Both types provide a 125-v GFCI (ground-fault circuit-interrupter) duplex receptacle rated at 15-A behind a hinged waterproof access cover, located on the end panel of the unit. See Fig. 50.




Fig. 50 — Convenience Outlet Location (Sizes 07-14)

Installing Weatherproof Cover

A weatherproof while-in-use cover for the factory-installed convenience outlets is now required by UL standards. This cover cannot be factory-mounted due to its depth; it must be installed at unit installation. For shipment, the convenience outlet is covered with a blank cover plate.

The weatherproof cover kit is shipped in the unit's control box. The kit includes the hinged cover, a backing plate and gasket.

DISCONNECT ALL POWER TO UNIT AND CONVENIENCE OUTLET. LOCK-OUT AND TAG-OUT ALL POWER.

Remove the blank cover plate at the convenience outlet; discard the blank cover.

Loosen the two screws at the GFCI duplex outlet, until approximately 1/2-in. (13 mm) under screw heads are exposed. Press the gasket over the screw heads. Slip the backing plate over the screw heads at the keyhole slots and align with the gasket; tighten the two screws until snug (do not over-tighten).

Mount the weatherproof cover to the backing plate as shown in Fig. 51. Remove two slot fillers in the bottom of the cover to permit service tool cords to exit the cover. Check for full closing and latching.




Fig. 51 — Weatherproof Cover Installation (Sizes 07-14)


Non-powered type

This type requires the field installation of a general-purpose 125-v 15-A circuit powered from a source elsewhere in the building. Observe national and local codes when selecting wire size, fuse or breaker requirements, and disconnect switch size and location. Route 125-v power supply conductors into the bottom of the utility box containing the duplex receptacle.

Unit-powered type

A unit-mounted transformer is factory-installed to stepdown the main power supply voltage to the unit to 115-v at the duplex receptacle. This option also includes a manual switch with fuse, located in a utility box and mounted on a bracket behind the convenience outlet; access is through the unit's control box access panel. See Fig. 50.

The primary leads to the convenience outlet transformer are not factory-connected. Selection of primary power source is a customer option. If local codes permit, the transformer primary leads can be connected at the line-side terminals on the unit-mounted non-fused disconnect or HACR breaker switch; this will provide service power to the unit when the unit disconnect switch or HACR switch is open. Other connection methods will result in the convenience outlet circuit being de-energized when the unit disconnect or HACR switch is open. See Fig. 52.



| UNIT VOLTAGE | CONNECT AS | PRIMARY CONNECTIONS | TRANSFORMER TERMINALS |
|--------------|------------|--|-----------------------|
| 208,230 | 240 | L1: RED +YEL L2: BLU +GRA | H1 + H3 H2 + H4 |
| 460 | 480 | L1: RED Splice BLU + YEL L2: GRA | H1 H2 + H3 H4 |
| 575 | 600 | L1: RED L2: GRA | H1 H2 |

Fig. 52 — Powered Convenience Outlet Wiring (Sizes 07-14)

Test the GFCI receptacle by pressing the TEST button on the face of the receptacle to trip and open the receptacle. Check for proper grounding wires and power line phasing if the GFCI receptacle does not trip as required. Press the RESET button to clear the tripped condition.

Fuse on power type

The factory fuse is a Bussman¹ "Fusetron" T-15, non-renewable screw-in (Edison base) type plug fuse.

1. Bussman and Fusetron are trademarks of Cooper Technologies Company.

NOTICE

Convenience Outlet Utilization

Maximum Continuous use: 15 Amps for receptacle outlets, and 8 Amps for factory supplied transformers

50HJ542739 C

Fig. 53 — Convenience Outlet Utilization Notice Label (Sizes 07-14)

Using unit-mounted convenience outlets

Units with unit-mounted convenience outlet circuits will often require that two disconnects be opened to de-energize all power to the unit. Treat all units as electrically energized until the convenience outlet power is also checked and de-energization is confirmed. Observe National Electrical Code Article 210, Branch Circuits, for use of convenience outlets.

Factory Option Thru-Base Connections

This service connection kit consists of a $1\frac{1}{2}$ -in. electrical bulkhead connector and a $1\frac{1}{4}$ -in. electrical bulkhead connector, all factory-installed in the embossed (raised) section of the unit basepan in the condenser section. The $1\frac{1}{2}$ -in. bulkhead connector enables the low-voltage control wires to pass through the basepan. The $1\frac{1}{4}$ -in. electrical bulkhead connector allows the high-voltage power wires to pass through the basepan. See Fig. 54 and 55.




Fig. 54 — Thru-Base Connection Fittings (Size 08-14 units and 07 units built prior to 4/15/2019)




Fig. 55 — Thru-Base Connection Fittings (Size 07 units built on or after 4/15/2019)

Check tightness of connector lock nuts before connecting electrical conduits.

Field-supplied and field-installed liquid-tight conduit connectors and conduit may be attached to the connectors on the basepan. Pull correctly-rated high voltage and low voltage through appropriate conduits. Connect the power conduit to the internal disconnect (if unit is so equipped) or to the external disconnect (through unit side panel). A hole must be field-cut in the main control box bottom on the left side so the 24-v control connections can be made. Connect the control power conduit to the unit control box at this hole.

Units Without Thru-Base Connections

1. Install power wiring conduit through side panel openings. Install conduit between disconnect and control box.
2. Install power lines to terminal connections as shown in Fig. 49.

Field Control Wiring


The 50TC unit requires an external temperature control device. This device can be a thermostat (field-supplied) or a Premier-Link™ controller (available as factory-installed option or as field-installed accessory, for use on a Carrier Comfort Network® or as a stand alone control) or the RTU Open Controller for Building Management Systems using non-CCN protocols (RTU Open is available as a factory-installed option only).

Thermostat

Install a Carrier-approved accessory thermostat according to installation instructions included with the accessory. For complete economizer function and 2-stage compressor operation, select a two-stage cooling thermostat. If a 2-stage cooling thermostat is not available, use a single stage cooling thermostat instead, but note that this will limit cooling to just 1 stage. Locate the thermostat accessory on a solid wall in the conditioned space to sense average temperature in accordance with the thermostat installation instructions.

If the thermostat contains a logic circuit requiring 24-v power, use a thermostat cable or equivalent single leads of different colors with minimum of seven leads. If the thermostat does not require a 24-v source (no "C" connection required), use a thermostat cable or equivalent with minimum of six leads. See Fig. 56. Check the thermostat installation instructions for additional features which might require additional conductors in the cable.

For wire runs up to 50 ft. (15 m), use no. 18 AWG (American Wire Gage) insulated wire [35°C (95°F) minimum]. For 50 to 75 ft. (15 to 23 m), use no. 16 AWG insulated wire [35°C (95°F) minimum]. For over 75 ft. (23 m), use no. 14 AWG insulated wire [35°C (95°F) minimum]. All wire sizes larger than no. 18 AWG cannot be directly connected to the thermostat and will require a junction box and splice at the thermostat.



Note 1: Typical multi-function marking. Follow manufacturer's configuration instructions to select Y2.

Note 2: W2 connection not required on units with single-stage heating.
- - - Field Wiring

Fig. 56 — Typical Low-Voltage Control Connections (Sizes 07-14)

Unit without Thru-Base Connection Kit

Pass the thermostat control wires through the hole provided in the corner post; then feed the wires through the raceway built into the corner post to the control box. Pull the wires over to the terminal strip on the upper-left corner of the Controls Connection Board. See Fig. 57.




Fig. 57 — Field Control Wiring Raceway (Sizes 07-14)

NOTE: If thru-the-bottom connections accessory is used, refer to the accessory installation instructions for information on routing power and control wiring.

Heat Anticipator Settings

Set heat anticipator settings at 0.14 amp for the first stage and 0.14 amp for second-stage heating, when available.

WARNING

ELECTRIC SHOCK HAZARD

Failure to follow this warning could result in personal injury or death.

Unit cabinet must have an uninterrupted, unbroken electrical ground to minimize the possibility of personal injury if an electrical fault should occur. This ground may consist of electrical wire connected to unit ground lug in control compartment, or conduit approved for electrical ground when installed in accordance with NEC; ANSI/NFPA 70, latest edition (in Canada, Canadian Electrical Code CSA [Canadian Standards Association] C22.1), and local electrical codes.

NOTE: Check all factory and field electrical connections for tightness. Field-supplied wiring shall conform with the limitations of minimum 63°F (33°C) rise.

Field Power Supply

For those units without through-the-curb power, conduit must be used to route the main power from the condenser end, via the power entry in the corner post of the unit (see Fig. 58-60) to either the factory option disconnect or the bottom of the control box. A 1-in. conduit is provided wrapped around compressor. A second conduit is provided with factory-installed powered convenience outlet. For those units that require a conduit larger than 1-in., the conduit must be field-supplied. Figures 58-60 show the wire routings.

If the field disconnect is larger than 100-A, it must be attached to the unit using accessory CRDISBKT001A00 — disconnect switch bracket (see Fig. 61). Follow the instructions provided with this accessory. For smaller field disconnects, be sure to use 1/2-in. screws to mount the disconnect directly to the end panel (see Fig. 62). In either case, set the disconnect vertical location on the unit so that a 90 degree fitting can be used to connect the conduit to the disconnect.




Fig. 58 — Conduit into Factory Option Disconnect (Size 16)




Fig. 59 — Conduit into Control Box (Size 16)




Fig. 60 — Conduit into Single Point Box (Size 16)




Fig. 61 — Mounting Position for Field Disconnects (over 100A) (Size 16)





Fig. 62 — Mounting Position for Field Disconnects (up to 100A) (Size 16)

Field power wires are connected to the unit at line-side pressure lugs at the main terminal block (TB1) or at factory-installed option non-fused disconnect switch. Max wire size is #2 AWG (copper only). See Fig. 63.

Units Without Disconnect Option

TB1



Units With Disconnect Option




Fig. 63 — Power Wiring Connections (Size 16)

NOTE: TEST LEADS - Unit may be equipped with short leads (pigtails) on the field line connection points off the optional disconnect switch. These leads are for factory run-test purposes only; remove and discard before connecting field power wires to unit connection points. Make field power connections directly to line connection pressure lugs only.

⚠️ WARNING

FIRE HAZARD

Failure to follow this warning could result in personal injury, death, or property damage.

Do not connect aluminum wire between disconnect switch and unit. Use only copper wire.




Fig. 64 — Disconnect Switch and Unit (Size 16)

FIELD WIRING FOR 50TC 16 UNITS

All field wiring must comply with the NEC and local requirements.

All units except 208/230-v units are factory wired for the voltage shown on the nameplate. If the 208/230-v unit is to be connected to a 208-v power supply, the control transformer must be rewired by moving the black wire with the 1/4-in. female spade connector from the 230-v connection and moving it to the 200-v 1/4-in. male terminal on the primary side of the transformer. Refer to unit label diagram for additional information.

Size wire based on MCA (Minimum Circuit Amps) on the unit informative plate. See Fig. 63 and the unit label diagram for power wiring connections to the unit power terminal blocks and equipment ground. Maximum wire size is 2/0 AWG per pole.

Provide a ground-fault and short-circuit over-current protection device (fuse or breaker) per NEC Article 440 (or local codes). Refer to unit informative data plate for MOCP (Maximum Over-current Protection) device size.

Voltage to compressor terminals during operation must be within voltage range indicated on unit nameplate. On 3-phase units, voltages between phases must be balanced within 2% and the current within 10%. Use the following formula to determine the percent of voltage imbalance.

% Voltage Imbalance:

$$= 100 \times \frac{\text{max voltage deviation from average voltage}}{\text{average voltage}}$$

Example: Supply voltage is 230-3-60



AB = 224 v
BC = 231 v
AC = 226 v

$$\text{Average Voltage} = \frac{(224 + 231 + 226)}{3} = \frac{681}{3} = 227$$

Determine maximum deviation from average voltage.

(AB) 227-224 = 3 v

(BC) 231-227 = 4 v

(AC) 227-226 = 1 v

Maximum deviation is 4 v.

Determine percent of voltage imbalance.

$$\% \text{ Voltage Imbalance} = 100 \times \frac{4}{227} = 1.78\%$$

This amount of phase imbalance is satisfactory as it is below the maximum allowable 2%.

IMPORTANT: If the supply voltage phase imbalance is more than 2%, contact your local electric utility company immediately.

NOTE: Check all factory and field electrical connections for tightness.

⚠️ CAUTION

UNIT DAMAGE HAZARD

Failure to follow this caution may result in equipment damage.

Operation on improper line voltage or excessive phase imbalance constitutes abuse and may cause damage to electrical components. Such operation would invalidate any applicable Carrier warranty.

Units Without Factory-Installed Disconnect

When installing units, provide a disconnect switch of adequate size per NEC (National Electrical Code). Disconnect sizing data is provided on the unit informative plate. Locate disconnect sizing data on unit cabinet or within sight of the unit per national or local codes. Do not cover unit informative plate if mounting the disconnect on the unit cabinet.

Units with Factory-Installed Disconnect

The factory-installed option disconnect switch is located in a weatherproof enclosure located under the main control box (see Fig. 65). The manual switch handle is accessible through an opening in the access panel. Discard the factory test leads (see Fig. 63 on page 43). The factory disconnect is an 80A disconnect.

Field-Install the NFD Shaft and Handle

1. Remove the Control Box access panel. The NFD enclosure is located below the Control Box (see Fig. 65).
2. Remove (3) cap head screws that secure the NFD enclosure front cover — (2) on the face of the cover and (1) on the left side cover. See Fig. 66.
3. Remove the front cover of the NFD enclosure.
4. Make sure the NFD shipped from the factory is at OFF position (the arrow on the black handle knob is at OFF).
5. Insert the shaft with the cross pin on the top of the shaft in the horizontal position. See Fig. 66.
6. Measure from the tip of the shaft to the top surface of the black pointer; the measurement should be 3.75 to 3.88 in. (95 to 99 mm).
7. Tighten the locking screw to secure the shaft to the NFD.
8. Turn the handle to the OFF position with red arrow pointing at OFF.
9. Install the handle on to the painted cover horizontally with the red arrow pointing to the left.
10. Secure the handle to the painted cover with (2) screws and lock washers supplied.
11. Engaging the shaft into the handle socket, re-install (3) hex screws on the NFD enclosure.

Re-install the unit front panel.




Fig. 65 — Location of Non-Fused Disconnect Enclosure (Size 16)




Fig. 66 — Handle and Shaft Assembly for NFD (Size 16)

CONVENIENCE OUTLETS FOR 50TC16 UNITS

WARNING

ELECTRICAL OPERATION HAZARD

Failure to follow this warning could result in personal injury or death.

Units with convenience outlet circuits may use multiple disconnects. Check convenience outlet for power status before opening unit for service. Locate its disconnect switch, if appropriate, and open it. Lock-out and tag-out this switch, if necessary.

Two types of convenience outlets are offered on the 50TC-D16: non-powered and unit-powered. Both types provide a 125-v GFCI (ground-fault circuit-interrupter) duplex receptacle rated at 15-A

behind a hinged waterproof access cover, located on the panel beneath the control box. See Fig. 67 and 68.




Fig. 67 — Convenience Outlet Location (Size 16)

Non-powered type

This type requires the field installation of a general-purpose 125-v 15-A circuit powered from a source elsewhere in the building. Observe national and local codes when selecting wire size and conduit requirements, fuse or breaker requirements and disconnect switch size and location. Route 125-v power supply conductors into the bottom of the utility box containing the duplex receptacle.

Unit-powered type

A unit-mounted transformer is factory-installed to stepdown the main power supply voltage to the unit to 115-v at the duplex receptacle. This option also includes a manual switch with fuse, located in a utility box and mounted on a bracket behind the convenience outlet; access is through the panel beneath the control box. See Fig. 67.

The primary leads to the convenience outlet transformer are not factory-connected. Selection of primary power source is a customer option. If local codes permit, the transformer primary leads can be connected at the line-side terminals on the unit-mounted non-fused disconnect switch; this will provide service power to the unit when the unit disconnect switch is open. Other connection methods will result in the convenience outlet circuit being de-energized when the unit disconnect switch is open. See Fig. 69. On a unit without a unit-mounted disconnect, connect the source leads to the main terminal block (TB1).

If the convenience outlet transformer is connected to the line side of a field disconnect, the conduit provided with the unit must be used to protect the wires as they are routed from the transformer to the field disconnect. The end of the conduit with the straight connector attaches to the field disconnect. The other end does not need to connect to the transformer; however, the conduit must be routed so that all wiring is either in the conduit or behind the access panel.

If the convenience outlet transformer is connected to the line side of the factory disconnect option, route the wires through the web bushing located on the bottom of the disconnect box. For the load side wiring to the factory option disconnect, route the wires through the hole on the right side of the disconnect. Be sure to create a drip loop at least 6-in. long.

Test the GFCI receptacle by pressing the TEST button on the face of the receptacle to trip and open the receptacle. Check for proper grounding wires and power line phasing if the GFCI receptacle does not trip as required. Press the RESET button to clear the tripped condition.





Fig. 68 — Convenience Outlet Utilization Notice (Size 16)



| UNIT VOLTAGE | CONNECT AS | PRIMARY CONNECTIONS | TRANSFORMER TERMINALS |
|--------------|------------|--|-----------------------|
| 208,230 | 240 | L1: RED +YEL L2: BLU + GRA | H1 + H3 H2 + H4 |
| 460 | 480 | L1: RED Splice BLU + YEL L2: GRA | H1 H2 + H3 H4 |
| 575 | 600 | L1: RED L2: GRA | H1 H2 |

Fig. 69 — Powered Convenience Outlet Wiring (Size 16)

Fuse on power type

The factory fuse is a Bussman "Fusetron" T-15, non-renewable screw-in (Edison base) type plug fuse. See Fig. 68 for maximum continuous use amp limitations.

⚠ WARNING

ELECTRICAL OPERATION HAZARD

Failure to follow this warning could result in personal injury or death.

Using unit-mounted convenience outlets: Units with unit-mounted convenience outlet circuits will often require that two disconnects be opened to de-energize all power to the unit. Treat all units as electrically energized until the convenience outlet power is also checked and de-energization is confirmed. Observe National Electrical Code Article 210, Branch Circuits, for use of convenience outlets.

Installing Weatherproof Cover

A weatherproof while-in-use cover for the factory-installed convenience outlets is now required by UL standards. This cover cannot be factory-mounted due to its depth; it must be

installed at unit installation. For shipment, the convenience outlet is covered with a blank cover plate.

The weatherproof cover kit is shipped in the unit's control box. The kit includes the hinged cover, a backing plate and gasket. DISCONNECT ALL POWER TO UNIT AND CONVENIENCE OUTLET. LOCK-OUT AND TAG-OUT ALL POWER.

Remove the blank cover plate at the convenience outlet; discard the blank cover.

Loosen the two screws at the GFCI duplex outlet, until approximately 1/2-in. (13 mm) under screw heads are exposed. Press the gasket over the screw heads. Slip the backing plate over the screw heads at the keyhole slots and align with the gasket; tighten the two screws until snug (do not over-tighten).

Mount the weatherproof cover to the backing plate as shown in Fig. 70. Remove two slot fillers in the bottom of the cover to permit service tool cords to exit the cover. Check for full closing and latching.




Fig. 70 — Weatherproof Cover Installation (Size 16)

Factory Option Thru-Base Connections

This service connection kit consists of a 1/2-in. electrical bulkhead connector and a 1 1/2-in. electrical bulkhead connector, connected to an "L" bracket covering the embossed (raised) section of the unit basepan in the condenser section. See Fig. 71. The 1/2-in. bulkhead connector enables the low-voltage control wires to pass through the basepan. The 1 1/2-in. electrical bulkhead connector allows the high-voltage power wires to pass through the basepan.

1. Remove the "L" bracket assembly from the unit.
2. Remove connector plate assembly from the "L" bracket and discard the "L" bracket, but retain the washer head screws and the gasket (located between the "L" bracket and the connector plate assembly).

NOTE: Take care not to damage the gasket, as it is reused in the following step.

3. Place the gasket over the embossed area in the basepan, aligning the holes in the gasket to the holes in the basepan. See Fig. 72.
4. Install the connector plate assembly to the basepan using 8 of the washer head screws.

NOTE: If electrical connections are not going to occur at this time, tape or otherwise cover the fittings so that moisture does not get into the building or conduit in the interim.

Check tightness of connector lock nuts before connecting electrical conduits.

Field-supplied and field-installed liquid-tight conduit connectors and conduit may be attached to the connectors on the

basepan. Pull correctly rated high voltage and low voltage through appropriate conduits. Connect the power conduit to the internal disconnect (if unit is so equipped) or to the external disconnect (through unit side panel). Remove one of the two knockouts located on the bottom left side of the unit control box. Use this hole for the control conduit.




Fig. 71 — Thru-the Base Option, Shipping Position (Size 16)




Fig. 72 — Installing Thru-the Base Option (Size 16)

Units Without Thru-base Connections

1. Install power wiring conduit through side panel openings. Install conduit between disconnect and control box.
2. Install power lines to terminal connections as shown in Fig. 63.

Field Control Wiring

The 50TC-16D unit requires an external temperature control device. This device can be a thermostat (field-supplied) or a PremierLink™ controller (available as factory-installed option or as field-installed accessory, for use on a Carrier Comfort Network® or as a stand alone control) or the RTU Open Controller for Building Management Systems using non-CCN protocols (RTU Open controller is available as a factory-installed option only).

Thermostat


Select a Carrier-approved accessory thermostat. When electric heat is installed in the 50TC unit, the thermostat must be capable of energizing the G terminal (to energize the Indoor Fan Contactor) whenever there is a space call for heat (energizing the W1 terminal). The accessory thermostats listed on the unit price pages can provide this signal but they are not configured to enable this signal as shipped.

Install the accessory thermostat according to installation instructions included with the accessory.

Locate the thermostat accessory on a solid wall in the conditioned space to sense average temperature in accordance with the thermostat installation instructions.

If the thermostat contains a logic circuit requiring 24-v power, use a thermostat cable or equivalent single leads of different colors with minimum of seven leads. If the thermostat does not require a 24-v source (no "C" connection required), use a thermostat cable or equivalent with minimum of six leads. Check the thermostat installation instructions for additional features which might require additional conductors in the cable.

For wire runs up to 50 ft (15 m), use no. 18 AWG (American Wire Gage) insulated wire (35°C minimum). For 50 to 75 ft (15 to 23 m), use no. 16 AWG insulated wire (35°C minimum). For over 75 ft (23 m), use no. 14 AWG insulated wire (35°C minimum). All wire sizes larger than no. 18 AWG cannot be directly connected to the thermostat and will require a junction box and splice at the thermostat.



Note 1: Typical multi-function marking. Follow manufacturer's configuration instructions to select Y2. Do not configure for O output.

Note 2: W2 connection not required on units without electric heating.

----- Field Wiring

Fig. 73 — Typical Low-Voltage Control Connections (Size 16)

Unit without Thru-Base Connection Kit

Pass the thermostat control wires through the bushing on the unit end panel. Route the wire through the snap-in wire tie and up to the web bushing near the control box. Route the wire through the bushing and into the bottom left side of the control box after removing one of the two knockouts in the corner of the box. Using a connector at the control box to protect the wire as it passes into the control box. Pull the wires over to the terminal strip at the upper left corner of the Central Terminal Board (CTB). Use the connector at the control box and the wire tie to take up any slack in the thermostat wire to ensure that it will not be damaged by contact with the condenser coil. See Fig. 74.

NOTE: If thru-the-bottom connections accessory is used, refer to the accessory installation instructions for information on routing power and control wiring.




Fig. 74 — Thermostat Wire Routing (Size 16)

Heat Anticriminator Settings

Set heat anticipator settings at 0.14 amp for the first stage and 0.14 amp for second-stage heating, when available.

Electric Heaters

50TC 07-14 UNIT ELECTRIC HEATERS

NOTE: See page 49 for 50TC 16 electric heaters.

50TC*07-14 units may be equipped with field-installed accessory electric heaters. The heaters are modular in design, with heater frames holding open coil resistance wires strung through ceramic insulators, line-break limit switches and a control contactor. One or two heater modules may be used in a unit.

Heater modules are installed in the compartment below the indoor (supply) fan outlet. Access is through the indoor access panel. Heater modules slide into the compartment on tracks along the bottom of the heater opening. See Fig. 75-77.

Not all available heater modules may be used in every unit. Use only those heater modules that are UL listed for use in a specific size unit. Refer to the label on the unit cabinet for the list of approved heaters.




Fig. 75 — Typical Access Panel Location (Sizes 07-14)




Fig. 76 — Typical Component Location (Sizes 07-14)




Fig. 77 — Typical Module Installation (Sizes 07-14)

Single Point Boxes and Supplementary Fuses

When the unit MOCP device value exceeds 60-A, unit-mounted supplementary fuses are required for each heater circuit. These fuses are included in accessory single point boxes, with power distribution and fuse blocks. The single point box will be installed directly under the unit control box, just to the left of the partition separating the indoor section (with electric heaters) from the outdoor section. The single point box has a hinged access cover. See Fig. 78. The single point box also includes a set of power taps and pigtailed to complete the wiring between the single point box and the unit's main control box terminals. Refer to the accessory heater and single point box installation instructions for details on tap connections.

All fuses on 50TC units are 60-A. (Note that all heaters are qualified for use with a 60-A fuse, regardless of actual heater ampacity, so only 60-A fuses are necessary.)

Single Point Boxes without Fuses

Unit heater applications not requiring supplemental fuses require a special single point box without any fuses. The accessory single point boxes contain a set of power taps and pigtailed to complete the wiring between the single point box and the unit's main control box terminals. Refer to accessory heater and single point box installation instructions for details on tap connections.




Fig. 78 — Typical Single Point Installation (Sizes 07-14)

Low-Voltage Control Connections

Pull the low-voltage control leads from the heater module(s) - VIO and BRN (two of each if two modules are installed; identify for Module #1) - to the 4-pole terminal board TB4 located on the heater bulkhead to the left of Heater #1. Connect the VIO lead from Heater #1 to terminal TB4-1. For 2-stage heating, connect the VIO lead from Heater #2 to terminal TB4-2. For 1-stage heating with 2 heater modules connect the VIO lead from both Heater #1 and #2 to terminal TB4-1. Connect both BRN leads to terminal TB4-3. See Fig. 79.




Fig. 79 — Accessory Electric Heater Control Connections (Sizes 07-14)

For CRHEATER128B00-129B00 only

Connect the ORN lead from Heater Relay 1 (HR1) to terminal TB4-1. For 2-stage heating, connect the VIO lead from Heater Relay 3 (HR3) to terminal TB4-2. For 1-stage heating with CRHEATER128B00 or CRHEATER129B00, connect the ORN lead from HR1 and the VIO lead from HR3 to terminal TB4-1. Connect the BRN lead from HR1 to TB4-3. See Fig. 80.




Fig. 80 — Accessory Electric Heater Control Connections for CRHEATER128B00-129B00 Only (Sizes 07-14)

50TC 16 UNIT ELECTRIC HEATERS

50TC-D16 units may be equipped with field-installed accessory electric heaters. The heaters are modular in design. One or two heater modules may be used in a unit.

Heater modules are installed in the compartment below the indoor (supply) fan outlet. Access is through the indoor access panel (see Fig. 82). Heater modules slide into the compartment on tracks along the bottom of the heater opening. See Fig. 81.

CAUTION

UNIT DAMAGE HAZARD

Failure to follow this caution may result in equipment damage.

Not all available heater modules and single point boxes may be used in every unit. Use only those heater modules that are UL listed for use in a specific size unit. Refer to the label on the unit cabinet for the list of approved heaters and single point boxes.

Single Point Boxes

When heaters are installed, power wiring to both heaters and the rest of the unit is connected via the single point box accessory, which will be installed directly under the unit control box, just to the left of the partition separating the indoor section (with electric heaters) from the outdoor section. The single point box has a hinged access cover. See Fig. 83. The single point box also includes tap conductors to complete the wiring between the single point box and the unit's main control box terminals. Refer to the accessory heater and single point box installation instructions for details on tap connections.




Fig. 81 — Typical Component Location (Size 16)




Fig. 82 — Typical Access Panel Location (Size 16)




Fig. 83 — Typical Single Point Installation (Size 16)

Heater and Supplementary Fuses

When the unit MOCP device value exceeds 60-A, unit-mounted supplementary fuses are required for each heater circuit. These fuses are included in accessory single point boxes, with power distribution and fuse blocks.

All fuses on 50TC-*16 units are 60-A. (Note that all heaters are qualified for use with a 60-A fuse, regardless of actual heater ampacity, so only 60-A fuses are necessary.)

Heater Low-Voltage Control Connections

One or two heaters can be installed in the unit. Use the wiring procedure listed below for each heater as determined by the number of stages in the heater.

Single Stage Heaters

Single-stage heaters will have an orange and a brown control wire. Connect these to the orange and brown wires located on TB4.

Two Stage Heaters

Two-stage heaters will have orange, purple, red and brown wires. The orange and the purple ones are the control wires and the red and brown wires feed the safety circuit. Connect both the orange and the purple wires to the orange wire locations of TB4. Connect the red and brown wires to red and brown wires on TB4. If more than one heater is installed, repeat the wiring procedure for the second heater. The 3 locations across the top of TB4 do allow a switch to be installed in series with some of the heaters in order to add additional heater control.




Fig. 84 — Accessory Electric Heater Control Connections (Size 16)

Humidi-MiZer® System Control Connections

HUMIDI-MIZER — SPACE RH CONTROLLER

NOTE: The Humidi-MiZer system is a factory installed option. The Humidi-MiZer dehumidification system requires a field-supplied and installed space relative humidity control device. This device may be a separate humidistat control (contact closes on rise in space RH above control set point) or a combination thermostat-humidistat control device such as Carrier's Edge® Pro Thermidistat with isolated contact set for dehumidification control (see Fig. 86). The humidistat is normally used in applications where a temperature control is already provided (units with PremierLink™ control).

50TC 07-14 UNIT HUMIDI-MIZER

To connect the Carrier humidistat (HL38MG029):

1. Route the humidistat 2-conductor cable (field-supplied) through the hole provided in the unit corner post.
2. Feed wires through the raceway built into the corner post (see Fig. 57) to the 24-v barrier located on the left side of the control box. The raceway provides the UL-required clearance between high-voltage and low-voltage wiring.
3. Use wire nuts to connect humidistat cable to two PINK leads in the low-voltage wiring as shown in Fig. 87 and 88.

To connect the Thermidistat device (33CS2PPRH-01):

1. Route the Thermidistat multi-conductor thermostat cable (field-supplied) through the hole provided in the unit corner post.
2. Feed wires through the raceway built into the corner post (see Fig. 57) to the 24-v barrier located on the left side of

the control box. The raceway provides the UL-required clearance between high-voltage and low-voltage wiring.

3. The Thermidistat has dry contacts at terminals D1 and D2 for dehumidification operation (see Fig. 90). The dry contacts must be wired between CTB terminal R and the PINK lead to the LTLO switch with field-supplied wire nuts. Refer to the installation instructions included with the Carrier Edge Pro Thermidistat device for more information.

50TC 16 UNIT HUMIDI-MIZER

To connect the Carrier humidistat (HL38MG029):

1. Route the humidistat 2-conductor cable (field-supplied) through the bushing the unit's louvered end panel (see Fig. 74).
2. Route the cable through the snap-in wire tie and up to the web bushing near the control box.
3. Feed the cable through the bushing and into the bottom left side of the control box after removing one of the two knockouts in the corner of the box. Use a connector to protect the cable as it enters the control box.
4. Use the connector and the wire tie to reduce any slack in the humidistat cable to ensure that it will not be damaged by contact with the condenser coil (see Fig. 74).
5. Use wire nuts to connect humidistat cable to two PINK leads in the low-voltage wiring as shown in Fig. 89.

To connect the Thermidistat device (33CS2PPRH-01):

1. Route the Thermidistat multi-conductor thermostat cable (field-supplied) through the bushing the unit's louvered end panel (see Fig. 74).
2. Route the cable through the snap-in wire tie and up to the web bushing near the control box.
3. Feed the cable through the bushing and into the bottom left side of the control box after removing one of the two knockouts in the corner of the box. Use a connector to protect the cable as it enters the control box.
4. Use the connector and the wire tie to reduce any slack in the thermostat cable to ensure that it will not be damaged by contact with the condenser coil (see Fig. 74).
5. The Thermidistat has dry contacts at terminals D1 and D2 for dehumidification operation (see Fig. 90). The dry contacts must be wired between CTB terminal R and the PINK lead to the LTLO switch with field-supplied wire nuts. Refer to the installation instructions included with the Carrier Edge Thermidistat device literature for more information.




Fig. 85 — Accessory Field-Installed Humidistat



Fig. 86 — Edge® Pro Thermidistat




Fig. 87 — Typical Humidi-MiZer® Adaptive Dehumidification System Humidistat Wiring (50TC 07 Unit Shown)




Fig. 88 — Typical Humidi-MiZer® Adaptive Dehumidification System Humidistat Wiring (50TC 08-14 Units Shown)





Fig. 89 — Typical Humidi-MiZer® Adaptive Dehumidification System Humidistat Wiring (50TC 16 Units Shown)



*Connection not required.

Fig. 90 — Typical Rooftop Unit with Humidi-MiZer® Adaptive Dehumidification System with Edge® Pro Thermostat Device

EconoMi\$er® X (Factory-Installed Option)

PRODUCT DESCRIPTION

The EconoMi\$er X system is an expandable economizer control system, which includes a W7220 economizer module (controller) with an LCD and keypad (see Fig. 91). The W7220 can be configured with optional sensors.



Fig. 91 — W7220 Economizer Module

The W7220 economizer module can be used as a stand-alone economizer module wired directly to a commercial set-back space thermostat and sensors to provide outside air dry-bulb economizer control.

The W7220 economizer module can be connected to optional sensors for single or differential enthalpy control. The W7220 economizer module provides power and communications for the sensors.

The W7220 economizer module automatically detects sensors by polling to determine which sensors are present. If a sensor loses communications after it has been detected, the W7220 economizer controller indicates a device fail error on its LCD.

SYSTEM COMPONENTS

The EconoMi\$er X system includes an economizer module, 20k mixed air sensor, damper actuator, and either a 20k outdoor air temperature sensor or S-Bus enthalpy sensors.

Economizer Module

The module is the core of the EconoMi\$er X system. The module is mounted in the unit's control box, and includes the user interface for the system. The W7220 economizer module provides the basic inputs and outputs to provide simple economizer control. When used with the optional sensors, the economizer module provides more advanced economizer functionality.

S-Bus Enthalpy Control Sensors

The sensor is a combination temperature and humidity sensor which is powered by and communicates on the S-Bus. Up to three sensors may be configured with the W7220 economizer module.

CO₂ Sensor (optional)

The sensor can be added for Demand Controlled Ventilation (DCV).

SPECIFICATIONS

W7220 Economizer Module

The module is designed for use with 2 to 10 vdc or bus communicating actuator. The module includes terminals for CO₂ sensor, Mixed Air sensor, and an Outdoor Dry Bulb sensor. Enthalpy and other options are available with bus sensors.

User Interface

Provides status for normal operation, setup parameters, check-out tests, and alarm and error conditions with a 2-line 16 character LCD display and four button keypad.

Electrical

Rated Voltage — 20 to 30 vac RMS, 50/60 Hz

Transformer — 100 va maximum system input

Nominal Power Consumption (at 24 vac, 60 Hz) — 11.5 VA without sensors or actuators

Relay Digital Output Rating at 30 vac (maximum power from Class 2 input only) — 1.5A run:
 3.5A inrush at 0.45PF (200,000 cycles) or
 7.5A inrush at 0.45PF (100,000 cycles)
 External Sensors Power Output — 21 vdc \pm 5% at 48mA

IMPORTANT: All inputs and outputs must be Class 2 wiring.

INPUTS

Sensors

NOTE: A Mixed Air (MA) analog sensor is required on all W7220 units; either an Outdoor Air (OA) sensor for dry bulb change over or an OA bus sensor for outdoor enthalpy change over is required in addition to the MA sensor. An additional Return Air (RA) bus sensor can be added to the system for differential enthalpy or dry bulb changeover. For differential dry bulb changeover a 20k ohm sensor is required in the OA and a bus sensor in the RA. DIP switch on RA bus sensor must be set in the RA position.

Dry Bulb Temperature (optional) and Mixed Air (required). 20k NTC

2-wire (18 to 22 AWG);

Temperature range -40°F to 150°F (-40°C to 65°C)

Temperature accuracy $-0^{\circ}\text{F}/+2^{\circ}\text{F}$

Temperature and Humidity, C7400S1000 (optional)

S-Bus; 2-wire (18 to 22 AWG)

Temperature: range -40°F to 150°F (-40°C to 65°C)

Temperature accuracy $-0^{\circ}\text{F}/+2^{\circ}\text{F}$

Humidity: range 0 to 100% RH with 5% accuracy.

NOTE: Up to three (3) S-Bus sensors may be connected to the W7220 economizer module. For outdoor air (OA), return air (RA) and discharge (supply) air (DA).

4 Binary Inputs

1-wire 24 vac + common GND (see page 46 for wiring details).

24 vac power supply

20 to 30 vac 50/60Hz; 100 VA Class 2 transformer.

OUTPUTS

Actuator Signal:

2-10 vdc; minimum actuator impedance is 2k ohm; bus two-wire output for bus communicating actuators.

Exhaust fan, Y1, Y2 and AUX1 O:

All Relay Outputs (at 30 vac):

Running: 1.5A maximum

Inrush: 7.5A maximum

ENVIRONMENTAL

Operating Temperature:

-40°F to 150°F (-40°C to 65°C).

Exception of display operation down to -4°F (-20°C) with full recovery at -4°F (-20°C) from exposure to -40°F (-40°C)

Storage Temperature:

-40°F to 150°F (-40°C to 65°C)

Shipping Temperature:

-40°F to 150°F (-40°C to 65°C)

Relative Humidity:

5% to 95% RH non-condensing

ECONOMIZER MODULE WIRING DETAILS

Use Fig. 92 and Tables 3 and 4 to locate the wiring terminals for the Economizer module.

NOTE: The four terminal blocks are removable. You can slide out each terminal block, wire it, and then slide it back into place.




Fig. 92 — W7220 Wiring Terminals

Table 3 — Economizer Module - Left Hand Terminal Blocks

| LABEL | TYPE | DESCRIPTION |
|--------------------------------|-------------------|--|
| Top Left Terminal Block | | |
| MAT MAT | 20k NTC and COM | Mixed Air Temperature Sensor (Polarity Insensitive Connection) |
| OAT OAT | 20k NTC and COM | Outdoor Air Temperature Sensor (Polarity Insensitive Connection) |
| S-BUS S-BUS | S-BUS (Sylk* Bus) | Enthalpy Control Sensor (Polarity Insensitive Connection) |

| Bottom Left Terminal Block | | |
|-----------------------------------|----------|--|
| IAQ 2-10 | 2-10 vdc | Air Quality Sensor Input (e.g. CO ₂ sensor) |
| IAQ COM | COM | Air Quality Sensor Common |
| IAQ 24V | 24 vac | Air Quality Sensor 24 vac Source |
| ACT 2-10 | 2-10 vdc | Damper Actuator Output (2-10 vdc) |
| ACT COM | COM | Damper Actuator Output Common |
| ACT 24v | 24 vac | Damper Actuator 24 vac Source |

*Sylk is a trademark of Honeywell International, Inc.

Table 4 — Economizer Module - Right Hand Terminal Blocks

| LABEL | TYPE | DESCRIPTION |
|-------------------------------------|------------|--|
| Top Right Terminal Blocks | | |
| AUX2 I | 24 vac IN | The first terminal is not used. |
| OCC | 24 vac IN | Shut Down (SD) or HEAT (W) Conventional only and Heat Pump Changeover (O-B) in Heat Pump mode. |
| E-GND | E-GND | Occupied/Unoccupied Input |
| EXH1 | 24 vac OUT | Exhaust Fan 1 Output |
| AUX1 O | 24 vac OUT | Programmable: Exhaust fan 2 output or ERV or System alarm output |
| Bottom Right Terminal Blocks | | |
| Y2-I | 24 vac IN | Y2 in - Cooling Stage 2 Input from space thermostat |
| Y2-O | 24 vac OUT | Y2 out - Cooling Stage 2 Output to stage 2 mechanical cooling |
| Y1-I | 24 vac IN | Y1 in - Cooling Stage 2 Input from space thermostat |
| Y1-O | 24 vac OUT | Y1 out - Cooling Stage 2 Output to stage 2 mechanical cooling |
| C | COM | 24 vac Common |
| R | 24 vac | 24 vac Power (hot) |

S-BUS SENSOR WIRING

The labels on the sensors and controller are color coded for ease of installation. Orange labeled sensors can only be wired to orange terminals on the controller. Brown labeled sensors can only be wired to S-bus (brown) terminals. Use Fig. 93 and Table 5 to locate the wiring terminals for each S-Bus sensor.

Use Fig. 93 and Table 5 to locate the wiring terminals for each enthalpy control sensor.




Fig. 93 — S-Bus Sensor DIP Switches

Table 5 — HH57AC081 Sensor Wiring Terminations

| TERMINAL | | TYPE | DESCRIPTION |
|----------|-------|-------|--|
| NUMBER | LABEL | | |
| 1 | S-BUS | S-BUS | S-BUS Communications (Enthalpy Control Sensor Bus) |
| 2 | S-BUS | S-BUS | S-BUS Communications (Enthalpy Control Sensor Bus) |

Use Fig. 93 and Table 6 to set the DIP switches for the desired use of the sensor.

Table 6 — HH57AC081 Sensor DIP Switch

| USE | DIP SWITCH POSITIONS FOR SWITCHES 1, 2, AND 3 | | |
|-----|---|-----|-----|
| | 1 | 2 | 3 |
| DA | OFF | ON | OFF |
| RA | ON | OFF | OFF |
| OA | OFF | OFF | OFF |

NOTE: When a S-Bus sensor is connected to an existing network, it will take 60 minutes for the network to recognize and auto-configure itself to use the new sensor.

During the 60 minute setup period, no alarms for sensor failures (except SAT) will be issued and no economizing function will be available.

CO₂ SENSOR WIRING

When using a CO₂ sensor, the black and brown common wires are internally connected and only one is connected to "IAQ COM" on the W7220. Use the power from the W7220 to power the CO₂ sensor OR make sure the ground for the power supplies are common. See Fig. 94 for CO₂ sensor wiring.




Fig. 94 — CO₂ Sensor Wiring

INTERFACE OVERVIEW

This section describes how to use the Economizer's user interface for:

- Keypad and menu navigation
- Settings and parameter changes
- Menu structure and selection

USER INTERFACE

The user interface consists of a 2-line LCD display and a 4-button keypad on the front of the economizer controller.

KEYPAD

The four navigation buttons (see Fig. 95) are used to scroll through the menus and menu items, select menu items, and to change parameter and configuration settings.

To use the keypad when working with menus:

- Press the ▲ (Up arrow) button to move to the previous menu.
- Press the ▼ (Down arrow) button to move to the next menu.
- Press the (Enter) button to display the first item in the currently displayed menu.




Fig. 95 — W7220 Controller Navigation Buttons

Press the \uparrow (Menu Up/Exit) button to exit a menu's item and return to the list of menus. To use the keypad when working with Set points, System and Advanced Settings, Checkout tests and Alarms:

1. Navigate to the desired menu.
2. Press the \leftarrow (Enter) button to display the first item in the currently displayed menu.
3. Use the ▲ and ▼ buttons to scroll to the desired parameter.
4. Press the \leftarrow (Enter) button to display the value of the currently displayed item.
5. Press the ▲ button to increase (change) the displayed parameter value.
6. Press the ▼ button to decrease (change) the displayed parameter value.

NOTE: When values are displayed, pressing and holding the ▲ or ▼ button causes the display to automatically increment.

7. Press the \leftarrow (Enter) button to accept the displayed value and store it in nonvolatile RAM.
8. "CHANGE STORED" displays.

9. Press the \leftarrow (Enter) button to return to the current menu parameter.

10. Press the \uparrow (Menu Up/Exit) button to return to the previous menu.

MENU STRUCTURE

Table 7 illustrates the complete hierarchy of menus and parameters for the EconoMi\$er® X system.

The Menus in display order are:

- STATUS
- SETPOINTS
- SYSTEM SETUP
- ADVANCED SETUP
- CHECKOUT
- ALARMS

Table 7 illustrates the complete hierarchy. Your menu parameters may be different depending on your configuration. For example, if you do not have a DCV (CO₂) sensor, then none of the DCV parameters appear and only MIN POS will display. If you have a CO₂ sensor, the DCV MIN and DCV MAX will appear AND if you have 2 speed fan DCV MIN (high and low speed) and DCV MAX (high and low speed will appear).

NOTE: Some parameters in the menus use the letters MA or MAT, indicating a mixed air temperature sensor location before the cooling coil. This unit application has the control sensor located after the cooling coil, in the fan section, where it is designated as (Cooling) Supply Air Temperature or SAT sensor.

SETUP AND CONFIGURATION

Before being placed into service, the W7220 Economizer module must be setup and configured for the installed system.

IMPORTANT: During setup, the economizer module is live at all times.

The setup process uses a hierarchical menu structure that is easy to use. Press the ▲ and ▼ arrow buttons to move forward and backward through the menus and press the button to select and confirm setup item changes.

TIME-OUT AND SCREEN SAVER

When no buttons have been pressed for 10 minutes, the LCD displays a screen saver, which cycles through the Status items. Each Status items displays in turn and cycles to the next item after 5 seconds.

Table 7 — Menu Structure

| MENU | PARAMETER | PARAMETER DEFAULT VALUE | PARAMETER RANGE AND INCREMENT | NOTES |
|--------|-------------|-------------------------------|-------------------------------------|--|
| STATUS | ECONO AVAIL | NO | YES/NO | FIRST STAGE COOLING DEMAND (Y1-IN) YES = economizing available; the system can use outside air for free cooling when required |
| | ECONOMIZING | NO | YES/NO | FIRST STAGE COOLING RELAY OUTPUT YES = outside air being used for 1 stage cooling |
| | OCCUPIED | NO | YES/NO | OCCUPIED YES = OCC signal received from space thermostat or unitary controller YES = 24 vac on terminal OCC NO = 0 vac on terminal OCC |
| | HEAT PUMP | N/A | COOL HEAT | HEAT PUMP MODE Displays COOL or HEAT when system is set to heat pump (Non-conventional) |
| | COOL Y1—IN | OFF | ON/OFF | FIRST STAGE COOLING DEMAND (Y1-IN) Y1-I signal from space thermostat or unitary controller for cooling stage 1. ON = 24 vac on terminal Y1-I OFF = 0 vac on terminal Y1-I |
| | COOL Y1—OUT | OFF | ON/OFF | FIRST STAGE COOLING RELAY OUTPUT Cool stage 1 Relay Output to stage 1 mechanical cooling (Y1-OUT terminal) |
| | COOL Y2—IN | OFF | ON/OFF | SECOND STAGE COOLING DEMAND (Y2-IN) Y2-I signal from space thermostat or unitary controller for second stage cooling. ON = 24 vac on terminal Y2-I OFF = 0 vac on terminal Y2-I |
| | COOL Y2—OUT | OFF | ON/OFF | SECOND STAGE COOLING RELAY OUTPUT Cool Stage 2 Relay Output to mechanical cooling (Y2-OUT terminal) |
| | MA TEMP | ___.F | 0°F to 140°F | SUPPLY AIR TEMPERATURE, Cooling Mode Displays value of measured mixed air from MAT sensor. Displays ___.F if not connected, short or out-of-range. |
| | DA TEMP | ___.F | 0°F to 140°F | DISCHARGE AIR TEMPERATURE, after Heating section Displays when Discharge Air sensor is connected and displays measured discharge temperature. Displays ___.F if sensor sends invalid value, if not connected, short or out-of-range. |
| | OA TEMP | ___.F | -40°F to 140°F | OUTSIDE AIR TEMP Displays measured value of outdoor air temperature. Displays ___.F if sensor sends invalid value, short or out-of-range. |
| | OA HUM | __ % | 0 to 100% | OUTSIDE AIR RELATIVE HUMIDITY Displays measured value of outdoor humidity from OA sensor. Displays __ % if not connected short, or out-of-range. |
| | RA TEMP | ___.F | 0°F to 140°F | RETURN AIR TEMPERATURE Displays measured value of return air temperature from RAT sensor. Displays ___.F if sensor sends invalid value, if not connected, short or out-of-range |
| | RA HUM | __ % | 0 to 100% | RETURN AIR RELATIVE HUMIDITY Displays measured value of return air humidity from RA sensor. Displays __ % if sensor sends invalid value, if not connected, short or out-of-range |
| | IN CO2 | ___ ppm | 0 TO 2000 ppm | SPACE/RETURN AIR CO ₂ Displays value of measured CO ₂ from CO ₂ sensor. Invalid if not connected, short or out-of-range |
| | DCV STATUS | N/A | ON/OFF | DEMAND CONTROLLED VENTILATION STATUS Displays ON if above setpoint and OFF if below setpoint, and ONLY if a CO ₂ sensor is connected. |
| | DAMPER OUT | 2.0v | 2.0 TO 10.0v | Displays voltage output to the damper actuator. |
| | ACT POS | N/A | 0 to 100% | Displays actual position of outdoor air damper actuator |
| | ACT COUNT | N/A | 1 to 65535 | Displays number of times actuator has cycled. 1 cycles equals 180 deg. of actuator movement in any direction. |
| | ACTUATOR | N/A | OK/Alarm (on Alarm menu) | Displays ERROR if voltage or torque is below actuator range. |
| | EXH1 OUT | OFF | ON/OFF | EXHAUST STAGE 1 RELAY OUTPUT Output of EXH1 terminal: ON = relay closed OFF = relay open |

Table 7 — Menu Structure (cont)

| MENU | PARAMETER | PARAMETER DEFAULT VALUE | PARAMETER RANGE AND INCREMENT | NOTES |
|------------------|--|-------------------------------|--|--|
| STATUS (cont) | EXH2 OUT | OFF | ON/OFF | EXHAUST STAGE 2 RELAY OUTPUT Output of AUX terminal; displays only if AUX = EXH2 |
| | ERV | OFF | ON/OFF | ENERGY RECOVERY VENTILATOR Output of AUX terminal; displays only if AUX = ERV |
| | MECH COOL ON or HEAT STAGES ON | 0 | 0, 1, or 2 | Displays stage of mechanical cooling that is active. Displays the stage of heat pump heating that is active. |
| | FAN SPEED | N/A | LOW or HIGH | SUPPLY FAN SPEED Displays speed setting of fan on a 2-speed fan unit. |
| | W (HEAT ON) | N/A | ON/OFF | HEAT DEMAND STATUS Displays status of heat demand on a 2-speed fan unit. |
| SETPOINTS | MAT SET | 53F | 38°F to 65°F; increment by 1 | SUPPLY AIR SETPOINT Setpoint determines where the economizer will modulate the OA damper to maintain the mixed air temperature. |
| | LOW T LOCK | 32F | -45°F to 80°F; increment by 1 | COMPRESSOR LOW TEMPERATURE LOCKOUT Setpoint determines outdoor temperature when the mechanical cooling cannot be turned on. Commonly referred to as the Compressor lockout. |
| | DRYBLB SET | 63F | 48°F to 80°F; increment by 1 | OA DRY BULB TEMPERATURE CHANGEOVER SETPOINT Setpoint determines where the economizer will assume outdoor air temperature is good for free cooling; e.g.; at 63°F unit will economize at 62°F and below and not economize at 64°F and above. There is a 2°F deadband. |
| | ENTH CURVE | ES3 | ES1, ES2, ES3, ES4, or ES5 | ENTHALPY CHANGEOVER CURVE Enthalpy boundary “curves” for economizing using single enthalpy. |
| | DCV SET | 1100ppm | 500 to 2000ppm; increment by 100 | DEMAND CONTROLLED VENTILATION Displays only if CO ₂ sensor is connected. Setpoint for Demand Control Ventilation of space. Above the setpoint, the OA dampers will modulate open to bring in additional OA to maintain a space ppm level below the setpoint. |
| | MIN POS | 2.8 V | 2 to 10 vdc | VENTILATION MINIMUM POSITION Displays ONLY if a CO ₂ sensor is NOT connected. |
| | VENTMAX With 2-speed fan units VENTMAX L (low speed fan) and VENTMAX H (high speed fan) settings are required | 2.8 V | 2 to 10 vdc | DCV MAXIMUM DAMPER POSITION Displays only if a CO ₂ sensor is connected. Used for Vbz (ventilation max cfm) setpoint. Displays 2 to 10 V if <3 sensors (RA, OA, and MA). In AUTO mode dampers controlled by CFM. |
| | | | 100 to 9990 cfm; increment by 10 | If OA, MA, RA, and CO ₂ sensors are connected and DCV CAL ENABLE is set to AUTO mode, the OA dampers are controlled by CFM and displays from 100 to 9990 CFM. |
| | | | 2 to 10 Vdc | With 2-speed fan units VENT L (low speed fan) and MIN POS H (high speed fan) settings are required. Default for VENTMAX L is 3.2V and VENTMAX H is 2.8V |
| | VENTMIN With 2-speed fan units VENTMIN L (low speed fan) and VENTMIN H (high speed fan) set | 2.25 V | 2 to 10 Vdc or 100 to 9990 cfm increment by 10 | DCV MINIMUM DAMPER POSITION Displays only if a CO ₂ sensor is connected. Used for Ba (ventilation min cfm) setpoint. Displays 2 to 10 V if <3 sensors (RA, OA, and MA). Va is only set if DCV is used. This is the ventilation for less than maximum occupancy of the space. In AUTO mode dampers controlled by CFM. |
| | | | 100 to 9990 cfm; increment by 10 | If OA, MA, RA, and CO ₂ sensors are connected and DCV CAL ENABLE is set to AUTO mode, the OA dampers are controlled by CFM and displays from 100 to 9990 CFM. |
| | | | 2 to 10 Vdc | With 2-speed fan units VENTMIN L (low speed fan) and MIN POS H (high speed fan) settings are required. Default for VENTMIN L is 3.2V and VENTMIN H is 2.8V |
| | ERV OAT SP | 32°F | 0 to 50 F; increment by 1 | ENERGY RECOVERY VENTILATOR UNIT OUTDOOR AIR TEMPERATURE SETPOINT Only when AUX1 O = ERV |
| | EXH1 SET With 2-speed fan units Exh1 L (low speed fan) and Exh1 H (high speed fan) settings are required | 50% | 0 to 100%; increment by 1 | EXHAUST FAN STAGE 1 SETPOINT Setpoint for OA damper position when exhaust fan 1 is powered by the economizer. With 2-speed fan units Exh1 L (low speed fan) and Exh1 H (high speed fan) settings are required. Default for Exh1 L is 65% and Exh1 H is 50% |
| | EXH2 SET With 2-speed fan units Exh2 L (low speed fan) and Exh2 H (high speed fan) settings are required | 75% | 0 to 100%; increment by 1 | EXHAUST FAN STAGE 2 SETPOINT Setpoint for OA damper position when exhaust fan 2 is powered by the economizer. Only used when AUX1 O is set to EHX2. With 2-speed fan units Exh2 L (low speed fan) and Exh2 H (high speed fan) settings are required. Default for Exh2 L is 80% and Exh2 H is 75% |

Table 7 — Menu Structure (cont)

| MENU | PARAMETER | PARAMETER DEFAULT VALUE | PARAMETER RANGE AND INCREMENT | NOTES |
|-------------------|-----------------|-------------------------------|---|--|
| SYSTEM SETUP | INSTALL | 01/01/10 | N/A | Display order = MM/DD/YY Setting order = DD, MM, then YY. |
| | UNITS DEG | F | °F or °C | Sets economizer controller in degrees Fahrenheit or Celsius |
| | EQUIPMENT | CONV | Conventional or HP | CONV = conventional; HP O/B = Enable Heat Pump mode. Use AUX2 I for Heat Pump input from thermostat or controller. See Menu Note 7 |
| | AUX2 IN | W | SD/W or HP(O)/HP(B) | In CONV mode: SD + Enables configuration of shutdown (default); W = Informs controller that system is in heating mode. NOTE: If using 2-speed fan mode, you must program CONV mode for W. Shutdown is not available in 2-speed fan mode. See Menu Note 7. In HP O/B mode: HP(O) = energize heat pump on Cool (default); HP(B) = energize heat pump on heat. |
| | FAN SPEED | 2 speed | 1 speed/2 speed | Sets the economizer controller for operation of 1 speed or 2 speed supply fan. NOTE: 2-speed fan option also needs Heat (W1) programmed in AUX 2 In. See Menu Note 7. |
| | FAN CFM | 5000cfm | 100 to 15000 cfm; increment by 100 | UNIT DESIGN AIRFLOW (CFM) Enter only if using DCVAL ENA = AUTO The value is found on the nameplate label for the specific unit. |
| | AUX1 OUT | NONE | NONE ERV EXH2 SYS | Select OUTPUT for AUX1 O relay • NONE = not configured (output is not used) • ERV = Energy Recovery Ventilator • EXH2 = second damper position relay closure for second exhaust fan • SYS = use output as an alarm signal |
| | OCC | INPUT | INPUT or ALWAYS | OCCUPIED MODE BY EXTERNAL SIGNAL When using a setback thermostat with occupancy out (24 vac), the 24 vac is input "INPUT" to the OCC terminal. If no occupancy output from the thermostat then change program to "ALWAYS" OR add a jumper from terminal R to OCC terminal. |
| | FACTORY DEFAULT | NO | NO or YES | Resets all set points to factory defaults when set to YES. LCD will briefly flash YES and change to NO but all parameters will change to the factory default values. NOTE: RECHECK AUX2 IN and FANTYPE for required 2-speed values. |
| ADVANCED SETUP | MA LO SET | 45 F | 35°F to 55°F; Incremented by 10 | SUPPLY AIR TEMPERATURE LOW LIMIT Temperature to achieve Freeze Protection (close damper and alarm if temperature falls below setup value). |
| | FREEZE POS | CLO | CLO or MIN | FREEZE PROTECTION DAMPER POSITION Damper position when freeze protection is active (closed or MIN POS). |
| | CO2 ZERO | 0ppm | 0 to 500 ppm; Increment by 10 | CO ₂ ppm level to match CO ₂ sensor start level. |
| | CO2 SPAN | 2000ppm | 1000 to 3000 ppm; Increment by 10 | CO ₂ ppm span to match CO ₂ sensor. |
| | STG3 DLY | 2.0h | 0 min, 5 min, 15 min, then 15 min intervals. Up to 4 hrs or OFF | COOLING STAGE 3 DELAY Delay after stage 2 cool has been active. Turns on second stage of cooling when economizer is first stage and mechanical cooling is second stage. Allows three stages of cooling, 1 economizer and 2 mechanical. OFF = no Stage 3 cooling |
| | SD DMPR POS | CLO | CLO or OPN | Indicates shutdown signal from space thermostat or unitary controller. When controller receives 24 vac input on the SD terminal in conventional mode, the OA damper will open if programmed for OPN and OA damper will close if programmed for CLO. All other controls, e.g., fans, etc. will shut off. |
| | DA LO ALM | 45 F (7 C) | 35°F to 65°F (2°C to 18°C); Incremented by 5° | Used for alarm for when the DA air temperature is too low. Set lower range of alarm, below this temperature the alarm will show on the display. |
| | DA HI ALM | 80 F (27 C) | 70°F to 180°F (21°C to 82°C); Incremented by 5° | Used for alarm for when the DA air temperature is too high. Set upper range of alarm, above this temperature the alarm will show on the display. |
| | DCVCAL ENA | MAN | MAN (manual) AUTO | Turns on the DCV automatic control of the dampers. Resets ventilation based on the RA, OA, and MA sensor conditions. Requires all 3 RA, OA, and MA sensors. |
| | MATT CAL | 0.0 F | ±2.5°F | SUPPLY AIR TEMPERATURE CALIBRATION Allows for the operator to adjust for an out of calibration temperature sensor. |

Table 7 — Menu Structure (cont)

| MENU | PARAMETER | PARAMETER DEFAULT VALUE | PARAMETER RANGE AND INCREMENT | NOTES |
|--------------------------|--|-------------------------------|--|---|
| ADVANCED SETUP (cont) | OAST CAL | 0.0 F | ±2.5°F | OUTSIDE AIR TEMPERATURE CALIBRATION Allows for the operator to adjust for an out of calibration temperature sensor. |
| | OA H CAL | 0% RH | ±10% RH | OUTSIDE AIR HUMIDITY CALIBRATION Allows for operator to adjust for an out of calibration humidity sensor. |
| | RAT CAL | 0.0 F | ±2.5°F | RETURN AIR TEMPERATURE CALIBRATION Allows for the operator to adjust for an out of calibration temperature sensor. |
| | RA H CAL | 0% RH | ±10% RH | RETURN AIR HUMIDITY CALIBRATION Allows for operator to adjust for an out of calibration humidity sensor. |
| | DAT CAL | 0.0 F | ±2.5°F | DISCHARGE AIR TEMPERATURE CALIBRATION Allows for the operator to adjust for an out of calibration temperature sensor. |
| | 2SP FAN DELAY | 5 Minutes | 0 to 20 minutes in 1 minute increments | TIME DELAY ON SECOND STAGE ECONOMIZING When in economizing mode, this is the delay for the high speed fan to try to satisfy the call for second stage cooling before the first stage mechanical cooling is enabled. |
| CHECKOUT | DAMPER MINIMUM POSITION | N/A | N/A | The checkout for the damper minimum position is based on the system. See Table 8. |
| | DAMPER OPEN | N/A | N/A | Position damper to the full open position. Exhaust fan contacts enable during the DAMPER OPEN test. Make sure you pause in the mode to allow exhaust contacts to energize due to the delay in the system. |
| | DAMPER CLOSE | N/A | N/A | Positions damper to the fully closed position |
| | CONNECT Y1-O | N/A | N/A | Closes the Y1-O relay (Y1-O) |
| | CONNECT Y2-O | N/A | N/A | Closes the Y2-O relay (Y2-O) |
| | CONNECT AUX1-O | N/A | N/A | Energizes the AUX output. If Aux setting is: <ul style="list-style-type: none"> • NONE — no action taken • ERV — 24 vac out. Turns on or signals an ERV that the conditions are not good for economizing but are for ERV operation. • SYS — 24 vac out. Issues a system alarm |
| | CONNECT EXH1 | N/A | N/A | Closes the power exhaust fan 2 relay (EXH1) |
| ALARMS | Alarms display only when they are active. The menu title "ALARMS(#)" includes the number of active alarms in parenthesis (). When using SYLK bus sensors, "SYLK" will appear on the screen, and when using 20k OA temperature sensors, "SENS T" will appear on the screen | | | |
| | MAT SENS ERR | N/A | N/A | SUPPLY AIR TEMPERATURE SENSOR ERROR Mixed air sensor has failed or become disconnected - check wiring then replace sensor if the alarm continues. |
| | CO2 SENS ERR | N/A | N/A | CO ₂ SENSOR ERROR CO ₂ sensor has failed, gone out of range or become disconnected - check wiring then replace sensor if the alarm continues. |
| | OA SYLK T ERR | N/A | N/A | OUTSIDE AIR S-BUS SENSOR ERROR |
| | OA SYLK H ERR | N/A | N/A | Outdoor air enthalpy sensor has failed or become disconnected - check wiring then replace sensor if the alarm continues. |
| | RA SYLK T ERR | N/A | N/A | RETURN AIR S-BUS SENSOR ERROR |
| | RA SYLK H ERR | N/A | N/A | Return air enthalpy sensor has failed or become disconnected - check wiring then replace sensor if the alarm continues. |
| | DA SYLK T ERR | N/A | N/A | DISCHARGE AIR S-BUS SENSOR ERROR |
| | DA SYLK H ERR | N/A | N/A | Discharge air sensor has failed or become disconnected - check wiring then replace sensor if the alarm continues. |
| | OA SENS T ERR | N/A | N/A | OUTSIDE AIR TEMPERATURE SENSOR ERROR Outdoor air temperature sensor has failed or become disconnected - check wiring then replace if the alarm continues. |
| | ACT ERROR | N/A | N/A | ACTUATOR ERROR Actuator has failed or become disconnected - check for stall, over voltage, under voltage and actuator count. Replace actuator if damper is movable and supply voltage is between 21.6 V and 26.4 V. Check actuator count on STATUS menu. |
| | FREEZE ALARM | N/A | N/A | Check if outdoor temperature is below the LOW Temp Lockout on setpoint menu. Check if Mixed air temperature on STATUS menu is below the Lo Setpoint on Advanced menu. When conditions are back in normal range then the alarm will go away. |
| | SHUTDOWN ACTIVE | N/A | N/A | AUX2 IN is programmed for SHUTDOWN and 24 V has been applied to AUX2 IN terminal. |

Table 7 — Menu Structure (cont)

| MENU | PARAMETER | PARAMETER DEFAULT VALUE | PARAMETER RANGE AND INCREMENT | NOTES |
|------------------|-----------------|-------------------------------|-------------------------------------|---|
| ALARMS (cont) | DMP CAL RUNNING | N/A | N/A | DAMPER CALIBRATION ROUTINE RUNNING If DCV Auto enable has been programmed, when the W7220 is completing a calibration on the dampers, this alarm will display. Wait until the calibration is completed and the alarm will go away. Must have OA, MA and RA sensors for DCV calibration; set up in the Advanced setup menu. |
| | DA SENS ALM | N/A | N/A | DISCHARGE AIR TEMPERATURE SENSOR ALARM Discharge air temperature is out of the range set in the ADVANCED SETUP Menu. Check the temperature of the discharge air. |
| | SYS ALARM | N/A | N/A | When AUX1-O is set to SYS and there is any alarm (e.g., failed sensors, etc.), the AUX1-O terminal has 24 vac out. |
| | ACT UNDER V | N/A | N/A | ACTUATOR VOLTAGE LOW Voltage received by actuator is above expected range. |
| | ACT OVER V | N/A | N/A | ACTUATOR VOLTAGE HIGH Voltage received by actuator is below expected range. |
| | ACT STALLED | N/A | N/A | ACTUATOR STALLED Actuator stopped before achieving commanded position. |

LEGEND

CLO — Compressor Lockout
ERV — Energy Recovery Ventilator
LCD — Liquid Crystal Display
MA — Mixed Air
MAT — Mixed Air Temperature
N/A — Not Applicable
OA — Outdoor Air
OAT — Outdoor Air Temperature
OCC — Occupied
RA — Return Air
RAT — Return Air Temperature
RTU — Rooftop Unit
SYS — System

NOTES:

1. Table 7 illustrates the complete hierarchy. Your menu parameters may be different depending on your configuration. For example if you do not have a DCV (CO₂) sensor, then none of the DCV parameters appear.
2. When values are displayed, pressing and holding the ▲ or ▼ button causes the display to automatically increment.
3. ERV Operation: When in cooling mode AND the conditions are NOT OK for economizing - the ERV terminal will be energized. In the Heating mode, the ERV terminal will be energized when the OA is below the ERV OAT set point in the set point menu.

4. STATUS —> OCCUPIED — The factory-standard Occupancy signal originates with a thermostat or other controller call for indoor fan operation at CTB terminal G. This signal passes through the Central Terminal Board's OCCUPIED jumper JMP1 to the ECONO connector and to the W7220's OCC input terminal. An external timeclock or relay is required to implement an Occupancy schedule on the economizer damper position.
5. STATUS —> MA TEMP, SETPOINTS —> MAT SET — The W7220 menu parameters and labels include designations MA, MAT and Mixed Air for the economizer cooling control sensor. On these rooftop units, the economizer control sensor is located downstream of the evaporator/indoor coil in the supply fan section where this sensor is designated as Supply Air Temperature (SAT) sensor.
6. SETPOINTS —> DRYBLB SET — This point is not displayed if a Return Air (differential) temperature sensor or an Outdoor Air enthalpy sensor is connected.
7. SYSTEM SETUP parameters must be configured as noted for 2-Speed unit operation:
 EQUIPMENT = CONV
 AUX2 IN = W
 FAN SPEED = 2SPEED

For damper minimum position settings and checkout menu readings, see Table 8. For dry bulb operation with a 1 speed indoor fan, with or without DCV, see Tables 9 and 10. For enthalpy operation with a 1 speed indoor fan, with or without DCV, see Tables 11 and 12. For dry bulb operation with a 2 speed indoor fan, with or without DCV, see Tables 13 and 14. For enthalpy operation with a 2 speed indoor fan, with or without DCV, see Tables 15 and 16.

Table 8 — Damper Minimum Position Settings and Readings on Checkout Menu

| DEMAND CONTROLLED VENTILATION (CO ₂ SENSOR) | FAN SPEED | SETPOINTS | CHECKOUT |
|--|-----------|------------|----------|
| NO | 1 | MIN POS | VMAX-HS |
| | | N/A | N/A |
| | 2 | MIN POS H | VMAX-HS |
| | | MIN POS L | VMAX-LS |
| YES | 1 | VENT MIN | VMAX-HS |
| | | VENT MAX | VMAX-HS |
| | 2 | VENT MIN H | VMAX-HS |
| | | VENT MAX H | VMAX-LS |
| | | VENT MIN L | N/A |
| | | VENT MAX L | N/A |

Table 9 — Dry Bulb Operation without DCV (CO₂ Sensor) — 1 Speed Fan

| DEMAND CONTROLLED VENTILATION (DCV) | OUTSIDE AIR GOOD TO ECONOMIZE | Y1-I | Y2-I | FAN SPEED | Y1-O | Y2-O | OCCUPIED | UNOCCUPIED |
|-------------------------------------|-------------------------------|------|------|-----------|--------|---------|----------------------|---------------------|
| NONE | NO | OFF | OFF | HIGH | 0v/Off | 0v/Off | MIN POS | Closed |
| | | ON | OFF | HIGH | 24v/On | 0v/Off | MIN POS | Closed |
| | | ON | ON | HIGH | 24v/On | 24v/On | MIN POS | Closed |
| | YES | OFF | OFF | HIGH | 0v/Off | 0v/Off | MIN POS | Closed |
| | | ON | OFF | HIGH | 0v/Off | 0v/Off | MIN POS to Full Open | Closed to Full-Open |
| | | ON | ON | HIGH | 24v/On | 0v/Off* | MIN POS to Full Open | Closed to Full-Open |

*With stage 3 delay (STG3 DLY) in Advanced setup menu can turn on second stage of mechanical cooling Y2-O after the delay if the call for Y1-I and Y2-I have not been satisfied.

Table 10 — Dry Bulb Operation with DCV (CO₂ Sensor) — 1 Speed Fan

| DEMAND CONTROLLED VENTILATION (DCV) | OUTSIDE AIR GOOD TO ECONOMIZE | Y1-I | Y2-I | FAN SPEED | Y1-O | Y2-O | OCCUPIED | UNOCCUPIED |
|-------------------------------------|-------------------------------|------|------|-----------|--------|---------|----------------------|---------------------|
| Below CO ₂ Set | No | OFF | OFF | HIGH | 0v/Off | 0v/Off | VENTMIN | Closed |
| | | ON | OFF | HIGH | 24v/On | 0v/Off | VENTMIN | Closed |
| | | ON | ON | HIGH | 24v/On | 24v/On | VENTMIN | Closed |
| | Yes | OFF | OFF | HIGH | 0v/Off | 0v/Off | VENTMIN | Closed |
| | | ON | OFF | HIGH | 0v/Off | 0v/Off | VENTMIN to Full-Open | Closed to Full-Open |
| | | ON | ON | HIGH | 24v/On | 0v/Off | VENTMIN to Full-Open | Closed to Full-Open |
| Above CO ₂ Set | No | OFF | OFF | HIGH | 0v/Off | 0v/Off | VENTMIN to VENTMAX | Closed |
| | | ON | OFF | HIGH | 24v/On | 0v/Off | VENTMIN to VENTMAX | Closed |
| | | ON | ON | HIGH | 24v/On | 24v/On | VENTMIN to VENTMAX | Closed |
| | Yes | OFF | OFF | HIGH | 0v/Off | 0v/Off | VENTMIN to VENTMAX | Closed |
| | | ON | OFF | HIGH | 0v/Off | 0v/Off | VENTMIN to Full-Open | Closed to Full-Open |
| | | ON | ON | HIGH | 24v/On | 0v/Off* | VENTMIN to Full-Open | Closed to Full-Open |

*With stage 3 delay (STG3 DLY) in Advanced setup menu can turn on second stage of mechanical cooling Y2-O after the delay if the call for Y1-I and Y2-I have not been satisfied.

Table 11 — Enthalpy Operation without DCV (CO₂ Sensor) — 1 Speed Fan

| DEMAND CONTROLLED VENTILATION (DCV) | OUTSIDE AIR GOOD TO ECONOMIZE | Y1-I | Y2-I | FAN SPEED | Y1-O | Y2-O | OCCUPIED | UNOCCUPIED |
|-------------------------------------|-------------------------------|------|------|-----------|--------|---------|----------------------|---------------------|
| NONE | NO | OFF | OFF | HIGH | 0v/Off | 0v/Off | MIN POS | Closed |
| | | ON | OFF | HIGH | 24v/On | 0v/Off | MIN POS | Closed |
| | | ON | ON | HIGH | 24v/On | 24v/On | MIN POS | Closed |
| | YES | OFF | OFF | HIGH | 0v/Off | 0v/Off | MIN POS | Closed |
| | | ON | OFF | HIGH | 0v/Off | 0v/Off | MIN POS to Full Open | Closed to Full-Open |
| | | ON | ON | HIGH | 24v/On | 0v/Off* | MIN POS to Full Open | Closed to Full-Open |

*With stage 3 delay (STG3 DLY) in Advanced setup menu can turn on second stage of mechanical cooling Y2-O after the delay if the call for Y1-I and Y2-I have not been satisfied.

Table 12 — Enthalpy Operation with DCV (CO₂ Sensor) — 1 Speed Fan

| DEMAND CONTROLLED VENTILATION (DCV) | OUTSIDE AIR GOOD TO ECONOMIZE | Y1-I | Y2-I | FAN SPEED | Y1-O | Y2-O | OCCUPIED | UNOCCUPIED |
|-------------------------------------|-------------------------------|------|------|-----------|--------|---------|----------------------|---------------------|
| Below CO ₂ Set | No | OFF | OFF | HIGH | 0v/Off | 0v/Off | VENTMIN | Closed |
| | | ON | OFF | HIGH | 24v/On | 0v/Off | VENTMIN | Closed |
| | | ON | ON | HIGH | 24v/On | 24v/On | VENTMIN | Closed |
| | Yes | OFF | OFF | HIGH | 0v/Off | 0v/Off | VENTMIN | Closed |
| | | ON | OFF | HIGH | 0v/Off | 0v/Off | VENTMIN to Full-Open | Closed to Full-Open |
| | | ON | ON | HIGH | 24v/On | 0v/Off | VENTMIN to Full-Open | Closed to Full-Open |
| Above CO ₂ Set | No | OFF | OFF | HIGH | 0v/Off | 0v/Off | VENTMIN to VENTMAX | Closed |
| | | ON | OFF | HIGH | 24v/On | 0v/Off | VENTMIN to VENTMAX | Closed |
| | | ON | ON | HIGH | 24v/On | 24v/On | VENTMIN to VENTMAX | Closed |
| | Yes | OFF | OFF | HIGH | 0v/Off | 0v/Off | VENTMIN to VENTMAX | Closed |
| | | ON | OFF | HIGH | 0v/Off | 0v/Off | VENTMIN to Full-Open | Closed to Full-Open |
| | | ON | ON | HIGH | 24v/On | 0v/Off* | VENTMIN to Full-Open | Closed to Full-Open |

*With stage 3 delay (STG3 DLY) in Advanced setup menu can turn on second stage of mechanical cooling Y2-O after the delay if the call for Y1-I and Y2-I have not been satisfied.

Table 13 — Dry Bulb Operation without DCV (CO₂ Sensor) — 2 Speed Fan

| DEMAND CONTROLLED VENTILATION (DCV) | OUTSIDE AIR GOOD TO ECONOMIZE | Y1-I | Y2-I | FAN SPEED | Y1-O | Y2-O | OCCUPIED | UNOCCUPIED |
|-------------------------------------|-------------------------------|------|------|-----------|--------|---------|----------------------|---------------------|
| NONE | NO | OFF | OFF | LOW | 0v/Off | 0v/Off | MIN POS | Closed |
| | | ON | OFF | LOW | 24v/On | 0v/Off | MIN POS | Closed |
| | | ON | ON | HIGH | 24v/On | 24v/On | MIN POS | Closed |
| | YES | OFF | OFF | LOW | 0v/Off | 0v/Off | MIN POS | Closed |
| | | ON | OFF | LOW | 0v/Off | 0v/Off | MIN POS to Full Open | Closed to Full-Open |
| | | ON | ON | HIGH | 24v/On | 0v/Off* | MIN POS to Full Open | Closed to Full-Open |

*With stage 3 delay (STG3 DLY) in Advanced setup menu can turn on second stage of mechanical cooling Y2-O after the delay if the call for Y1-I and Y2-I have not been satisfied.

Table 14 — Dry Bulb Operation with DCV (CO₂ Sensor) — 2 Speed Fan

| DEMAND CONTROLLED VENTILATION (DCV) | OUTSIDE AIR GOOD TO ECONOMIZE | Y1-I | Y2-I | FAN SPEED | Y1-O | Y2-O | OCCUPIED | UNOCCUPIED |
|-------------------------------------|-------------------------------|------|------|-----------|--------|---------|----------------------|---------------------|
| Below CO ₂ Set | No | OFF | OFF | LOW | 0v/Off | 0v/Off | VENTMIN | Closed |
| | | ON | OFF | LOW | 24v/On | 0v/Off | VENTMIN | Closed |
| | | ON | ON | HIGH | 24v/On | 24v/On | VENTMIN | Closed |
| | Yes | OFF | OFF | LOW | 0v/Off | 0v/Off | VENTMIN | Closed |
| | | ON | OFF | LOW | 0v/Off | 0v/Off | VENTMIN to Full-Open | Closed to Full-Open |
| | | ON | ON | HIGH | 24v/On | 0v/Off | VENTMIN to Full-Open | Closed to Full-Open |
| Above CO ₂ Set | No | OFF | OFF | LOW | 0v/Off | 0v/Off | VENTMIN to VENTMAX | Closed |
| | | ON | OFF | LOW | 24v/On | 0v/Off | VENTMIN to VENTMAX | Closed |
| | | ON | ON | HIGH | 24v/On | 24v/On | VENTMIN to VENTMAX | Closed |
| | Yes | OFF | OFF | LOW | 0v/Off | 0v/Off | VENTMIN to VENTMAX | Closed |
| | | ON | OFF | LOW | 0v/Off | 0v/Off | VENTMIN to Full-Open | Closed to Full-Open |
| | | ON | ON | HIGH | 24v/On | 0v/Off* | VENTMIN to Full-Open | Closed to Full-Open |

*With stage 3 delay (STG3 DLY) in Advanced setup menu can turn on second stage of mechanical cooling Y2-O after the delay if the call for Y1-I and Y2-I have not been satisfied.

Table 15 — Enthalpy Operation without DCV (CO₂ Sensor) — 2 Speed Fan

| DEMAND CONTROLLED VENTILATION (DCV) | OUTSIDE AIR GOOD TO ECONOMIZE | Y1-I | Y2-I | FAN SPEED | Y1-O | Y2-O | OCCUPIED | UNOCCUPIED |
|-------------------------------------|-------------------------------|------|------|-----------|--------|---------|----------------------|---------------------|
| NO CO ₂ SENSOR | NO | OFF | OFF | LOW | 0v/Off | 0v/Off | MIN POS | Closed |
| | | ON | OFF | LOW | 24v/On | 0v/Off | MIN POS | Closed |
| | | ON | ON | HIGH | 24v/On | 24v/On | MIN POS | Closed |
| | YES | OFF | OFF | LOW | 0v/Off | 0v/Off | MIN POS | Closed |
| | | ON | OFF | LOW | 0v/Off | 0v/Off | MIN POS to Full Open | Closed to Full-Open |
| | | ON | ON | HIGH | 24v/On | 0v/Off* | MIN POS to Full Open | Closed to Full-Open |

*With stage 3 delay (STG3 DLY) in Advanced setup menu can turn on second stage of mechanical cooling Y2-O after the delay if the call for Y1-I and Y2-I have not been satisfied.

Table 16 — Enthalpy Operation with DCV (CO₂ Sensor) — 2 Speed Fan

| DEMAND CONTROLLED VENTILATION (DCV) | OUTSIDE AIR GOOD TO ECONOMIZE | Y1-I | Y2-I | FAN SPEED | Y1-O | Y2-O | OCCUPIED | UNOCCUPIED |
|-------------------------------------|-------------------------------|------|------|-----------|--------|---------|----------------------|---------------------|
| Below CO ₂ Set | No | OFF | OFF | LOW | 0v/Off | 0v/Off | VENTMIN | Closed |
| | | ON | OFF | LOW | 24v/On | 0v/Off | VENTMIN | Closed |
| | | ON | ON | HIGH | 24v/On | 24v/On | VENTMIN | Closed |
| | Yes | OFF | OFF | LOW | 0v/Off | 0v/Off | VENTMIN | Closed |
| | | ON | OFF | LOW | 0v/Off | 0v/Off | VENTMIN to Full-Open | Closed to Full-Open |
| | | ON | ON | HIGH | 24v/On | 0v/Off | VENTMIN to Full-Open | Closed to Full-Open |
| Above CO ₂ Set | No | OFF | OFF | LOW | 0v/Off | 0v/Off | VENTMIN to VENTMAX | Closed |
| | | ON | OFF | LOW | 24v/On | 0v/Off | VENTMIN to VENTMAX | Closed |
| | | ON | ON | HIGH | 24v/On | 24v/On | VENTMIN to VENTMAX | Closed |
| | Yes | OFF | OFF | LOW | 0v/Off | 0v/Off | VENTMIN to VENTMAX | Closed |
| | | ON | OFF | LOW | 0v/Off | 0v/Off | VENTMIN to Full-Open | Closed to Full-Open |
| | | ON | ON | HIGH | 24v/On | 0v/Off* | VENTMIN to Full-Open | Closed to Full-Open |

*With stage 3 delay (STG3 DLY) in Advanced setup menu can turn on second stage of mechanical cooling Y2-O after the delay if the call for Y1-I and Y2-I have not been satisfied.




Fig. 96 — Single Enthalpy Curve Boundaries

Table 17 — Single Enthalpy and Dual Enthalpy High Limit Curves

| ENTHALPY CURVE | TEMP. DRY BULB (F) | TEMP. DEWPOINT (F) | ENTHALPY (btu/lb/da) | POINT P1 | | POINT P2 | |
|----------------|--------------------|--------------------|----------------------|-----------|----------------|-----------|----------------|
| | | | | TEMP. (F) | HUMIDITY (%RH) | TEMP. (F) | HUMIDITY (%RH) |
| ES1 | 80 | 60 | 28.0 | 80 | 36.8 | 66.3 | 80.1 |
| ES2 | 75 | 57 | 26.0 | 75 | 39.6 | 63.3 | 80.0 |
| ES3 | 70 | 54 | 24.0 | 70 | 42.3 | 59.7 | 81.4 |
| ES4 | 65 | 51 | 22.0 | 65 | 44.8 | 55.7 | 84.2 |
| ES5 | 60 | 48 | 20.0 | 60 | 46.9 | 51.3 | 88.5 |
| HL | 86 | 66 | 32.4 | 86 | 38.9 | 72.4 | 80.3 |

ENTHALPY SETTINGS

When the OA temperature, enthalpy and dew point are below the respective set points, the Outdoor Air can be used for economizing. Fig. 96 shows the new single enthalpy boundaries in the W7220. There are 5 boundaries (set points ES1 through ES5), which are defined by dry bulb temperature, enthalpy and dew point.

Refer to Table 17 for ENTH CURVE set point values.

The W7220 calculates the enthalpy and dew point using the OA temperature and humidity input from the OA enthalpy sensor. When the OA temperature, OA humidity and OA dew point are all below the selected boundary, the economizer sets the economizing mode to YES, economizing is available.

When all of the OA conditions are above the selected boundary, the conditions are not good to economize and the mode is set to NO.

Figure 96 shows the 5 current boundaries. There is also a high limit boundary for differential enthalpy. The high limit boundary is ES1 when there are no stages of mechanical cooling energized and HL (high limit) when a compressor stage is energized.

Table 17 provides the values for each boundary limit.

TWO-SPEED FAN OPERATION

The W7220 controller has the capability to work with a system using a 2-speed supply fan. The W7220 does not control the supply directly but uses the following input status to determine the speed of the supply fan and controls the OA damper to the required position, see Table 18.

Table 18 — Fan Speed

| STATE | FAN SPEED |
|-------|-----------|
| OCC | Low |
| Y1 | Low |
| Y2 | High |
| W | High |

The W (heating mode) is not controlled by the W7220 but it requires the status to know where to position the OA damper for minimum position for the fan speed.

The 2 speed fan delay is available when the system is programmed for 2 speed fan (in the System Setup menu item). The 2 speed fan delay is defaulted to 5 minutes and can be changed in the Advanced Setup menu item. When the unit has a call for Y1 In and in the free cooling mode and there is a call for Y2 In, the 2-speed fan delay starts and the OA damper will modulate 100% open, the supply fan should be set to high speed by the unit controller.

After the delay, one of two actions will happen:

- The Y2 In call will be satisfied with the damper 100% open and fan on high speed and the call will turn off
OR
- If the call for additional cooling in the space has not been satisfied, then the first stage of mechanical cooling will be enabled through Y1 Out or Y2 Out.

CHECKOUT

Inspect all wiring connections at the economizer module's terminals, and verify compliance with the installation wiring diagrams.

For checkout, review the Status of each configured parameter and perform the Checkout tests.

NOTE: For information about menu navigation and use of the keypad, see Interface Overview on page 57.

WARNING

ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury, property damage, or death.

Before performing service or maintenance operations on unit, always turn off main power switch to unit and install lock(s) and lockout tag(s). Unit may have more than one power switch. Ensure electrical service to rooftop unit agrees with voltage and amperage listed on the unit rating plate.

If any wiring changes are required, first be sure to remove power from the economizer module before starting work. Pay particular attention to verifying the power connection (24 vac).

Power Up

After the W7220 module is mounted and wired, apply power.

Initial Menu Display

On initial start up, Honeywell displays on the first line and economizer W7220 on the second line. After a brief pause, the revision of the software appears on the first line and the second line will be blank.

Power Loss (Outage or Brownout)

All set points and advanced settings are restored after any power loss or interruption.

NOTE: All settings are stored in non-volatile flash memory.

Status

Use the Status menu (see Table 7) to check the parameter values for the various devices and sensors configured.

NOTE: For information about menu navigation and use of the keypad, see Interface Overview on page 57.

Checkout Tests

Use the Checkout menu (on page 62) to test the damper operation and any configured outputs. Only items that are configured are shown in the Checkout menu.

NOTE: For information about menu navigation and use of the keypad, see Interface Overview on page 57.

To perform a Checkout test:

1. Scroll to the desired test in the Checkout menu using the ▲ and ▼ buttons.
2. Press the ← button to select the item.
3. RUN? appears.
4. Press the ← button to start the test.

5. The unit pauses and then displays IN PROGRESS.
6. When the test is complete, DONE appears.
7. When all desired parameters have been tested, press the  (Menu Up) button to end the test.

The Checkout tests can all be performed at the time of installation or at any time during the operation of the system as a test that the system is operable.

TROUBLESHOOTING

Alarms

The economizer module provides alarm messages that display on the 2-line LCD.

NOTE: Upon power up, the module waits 60 minutes before checking for alarms. This allows time for all the configured devices (e.g. sensors, actuator) to become operational. The exception is the SAT sensor which will alarm immediately.

If one or more alarms are present and there has been no keypad activity for at least 5 minutes, the Alarms menu displays and cycles through the active alarms.

You can also navigate to the Alarms menu at any time.

Clearing Alarms

Once the alarm has been identified and the cause has been removed (e.g. replaced faulty sensor) the alarm can be cleared from the display.

To clear an alarm, perform the following:

1. Navigate to the desired alarm.
2. Press the  (Enter) button.
3. ERASE? displays.

4. Press the  (Enter) button.
5. ALARM ERASED displays.
6. Press the  (Menu up/Exit) button to complete the action and return to the previous menu.

NOTE: If the alarm still exists after clearing it, it is redisplayed within 5 seconds.

CAUTION

EQUIPMENT DAMAGE HAZARD

Failure to follow this caution may result in equipment damage.

Be sure to allow enough time for compressor start-up and shutdown between checkout tests so that you do not short-cycle the compressors.

PremierLink™ Controller (Factory Option)

For details on operating 50TC**07-16 units equipped with the factory-installed PremierLink controller option, refer to the PREMIERLINK Retrofit Rooftop Controller Version 3.x Installation, Start-up and Configuration Instructions.

See Fig. 97-100 for wiring diagrams.

RTU Open Controller (Factory-Installed Option)

For details on operating 50TC**07-16 units equipped with the factory-installed RTU Open Controller option, refer to the *Factory-Installed Option RTU Open Multi-Protocol Controller Controls, Start-Up, Operation, and Troubleshooting* manual.

See Fig. 101-107 for wiring diagrams.




Fig. 97 — Typical PremierLink™ Control Wiring Diagram, Size 07 Shown




Fig. 98 — 50TC*M08-12 PremierLink™ Control Wiring Diagram




Fig. 99 — Typical PremierLink™ Control Wiring Diagram, Dual Compressor Sizes 08-12 shown




Fig. 100 — Typical PremierLink™ Control Wiring Diagram with Humidi-MiZer® System Option




Fig. 101 — Typical RTU Open Controller Wiring Diagram - 50TC 07 Units




Fig. 102 — 50TC-M08-12, RTU Open Controller Wiring Diagram




Fig. 103 — Typical RTU Open Controller Wiring Diagram — 50TC-D/E08-14 Units

15T STD TIER PAC CONTROL 208 / 230V , 460V , 575V
3 OEM DUAL COMPRESSOR




Fig. 104 — RTU Open Controller Wiring Diagram — 50TC 16 Unit




Fig. 105 — Typical RTU Open Controller Wiring Diagram with Humidi-MiZer® System Option - 50TC 07 Units





Fig. 106 — Typical RTU Open Controller Wiring Diagram with Humidi-MiZer® System Option — 50TC 08-14 Units



15T STD TIER PAC CONTROL W/DEHUMIDIFICATION
208/230V, 460V, 575V 3 OFM DUAL COMPRESSOR

[50TM501305 1]

Smoke Detectors

Smoke detectors are available as factory-installed options on 50TC models. Smoke detectors may be specified for supply-air only, for return-air without or with economizer, or in combination of supply-air and return-air. All components necessary for operation are factory-provided and mounted. The unit is factory-configured for immediate smoke detector shutdown operation; additional wiring or modifications to unit terminal board may be necessary to complete the unit and smoke detector configuration to meet project requirements.

Units equipped with factory-optional return-air smoke detectors require a relocation of the sensor module at unit installation. See Fig. 108 for the as-shipped location.

Completing Installation of Return Air Smoke Sensor:

1. Unscrew the two screws holding the Return Air Smoke Detector assembly. See Fig. 109, Step 1.
2. Save the screws.
3. Turn the assembly 90 degrees and then rotate end to end. Make sure that the elbow fitting is pointing down. See Fig. 109, Step 2.
4. Screw the sensor and detector plate into its operating position using screws from Step 1. See Fig. 109, Step 3.
5. Connect the flexible tube on the sampling inlet to the sampling tube on the basepan.

ADDITIONAL APPLICATION DATA

Refer to the Application Data sheet, *Factory-Installed Smoke Detectors for Small and Medium Rooftop Units 2 to 25 Tons* for discussions on additional control features of these smoke detectors, including multiple unit coordination.




Fig. 108 — Return Air Smoke Detector; Shipping Position




Fig. 109 — Completing Installation of Return Air Smoke Sensor




Fig. 110 — EconoMi\$er® IV Wiring

Step 11 — Adjust Factory-Installed Options

SMOKE DETECTORS

Smoke detector(s) will be connected at the Controls Connections Board, at terminals marked "Smoke Shutdown." Cut jumper JMP 3 when ready to energize unit.

ECONOMI\$ER IV OCCUPANCY SWITCH

Refer to Fig. 110 for general EconoMi\$er IV wiring. External occupancy control is managed through a connection on the Controls Connections Board.

If external occupancy control is desired, connect a time clock or remotely controlled switch (closed for Occupied, open for Unoccupied sequence) at terminals marked OCCUPANCY. Cut jumper JMP 2 to complete the installation.

Step 12 — Install Accessories

Available accessories include:

- Roof Curb
- Thru-base connection kit (must be installed before unit is set on curb)
- Manual outside air damper
- Two-position motorized outside air damper
- EconoMi\$er IV (with control and integrated barometric relief)
- EconoMi\$er2 (without control/for external signal and integrated barometric relief)
- Power exhaust
- Differential dry-bulb sensor (EconoMi\$er IV)
- Outdoor enthalpy sensor
- Differential enthalpy sensor
- Electric heaters

- Single point kits
- Low Ambient Controls
- Thermostat / Sensors
- CO₂ sensor
- DDC interface (PremierLink controller)
- Louvered hail guard
- Phase monitor control

Refer to separate installation instructions for information on installing these accessories.

Step 13 — Check Belt Tension

Measure the belt span length as shown in Fig. 111. Calculate the required deflection by multiplying the belt span length by $1/64$. For example, if the belt span length is 32 inches:


$$32 \times \frac{1}{64} = \frac{1}{2}\text{-in. deflection.}$$

BELT FORCE — DEFLECTION METHOD

Check the belt tension with a spring-force belt force deflection gage (available from drive belt manufacturer).

1. Place a straightedge along the belt between the two pulleys. Measure the distance between the motor shaft and the blower shaft.
2. Set the tension gage to the desired tension (see Table 1 in Fig. 111). Place the large O-ring at that point.
3. Press the tension checker downward on the belt until the large O-ring is at the bottom of the straightedge.
4. Adjust the belt tension as needed.

Adjust belt tension by loosening the motor mounting plate front bolts and rear bolt (see Fig. 112) and slide the plate towards the fan (to reduce tension) or away from the fan (to increase tension). Ensure the blower shaft and motor shaft are parallel to each other (pulleys aligned). Tighten all bolts securely when finished.



TORQUE ALL SHEAVE SET SCREWS TO 110-130 IN LBS.

| BELT CROSS SECTION | SMALLEST SHEAVE DIAMETER | BELT DEFLECTION FORCE (LBS) | | | |
|--------------------|--------------------------|-----------------------------|-----|---------------|------|
| | | UNNOTCHED BELTS | | NOTCHED BELTS | |
| | | USED | NEW | USED | NEW |
| A, AX | 3.0-3.6 | 3.7 | 5.5 | 4.1 | 6.1 |
| | 3.8-4.8 | 4.5 | 6.8 | 5.0 | 7.4 |
| | 5.0-7.0 | 5.4 | 8.0 | 5.7 | 8.4 |
| B, BX | 3.4-4.2 | — | — | 4.9 | 7.2 |
| | 4.4-5.6 | 5.3 | 7.9 | 7.1 | 10.5 |
| | 5.8-8.6 | 6.3 | 9.4 | 8.5 | 12.6 |

Table 1

| BELT CONDITION | TENSION FORCE IN BELT (LBS) |
|----------------|-----------------------------|
| New | 100 |
| Used | 80 |

Table 2

Fig. 111 — V-Belt Force Label

BELT TENSION METHOD

Requires belt tension gage that measures tension in belt in units of lbs force.




Fig. 112 — Belt Drive Motor Mounting

Pre-Start and Start-Up

This completes the mechanical installation of the unit. Refer to the unit's Service Manual for detailed Pre-Start and Start-Up instructions. Download the latest versions from HVAC Partners (www.hvacpartners.com).

Troubleshooting the UltraTech™ Compressor

The UltraTech¹ compressor's molded plug should be used at all times. The maximum power is 5A.

MODULATION CONTROL INPUT SPECIFICATIONS

The compressor will modulate from part load to full load when the voltage supplied to the molded plug is 18 to 28vdc or 18 to 28 vac rectified to vdc. The compressor will modulate from full load to part load when the current in the circuit drops below 0.9 MA. See Table 19 and Fig. 113 for details.

1. UltraTech™ is a trademark of Emerson Climate Technologies, Inc.

Table 19 — Troubleshooting UltraTech Compressor

| STAGE | CAPACITY | METERING | LIQUID LINE SOLENOID | COMPRESSOR UNLOADER | FOR ULTRATECH COMPRESSOR TROUBLESHOOTING (COMPRESSOR CURRENT) | FOR LIQUID LINE SOLENOID VALVE TROUBLESHOOTING (TOP EVAPORATOR COIL TEMPERATURE) |
|-------|------------------|-----------|-----------------------|---------------------|---|--|
| Y1 | Part Load (66%) | TXV | Closed (De-energized) | De-energized | Approx. 80% or less | Top section of the evaporator coil will not be cold (U-bend tubes) |
| Y1+Y2 | Full Load (100%) | TXV+Fixed | Open (Energized) | Energized | 100% | Top section of the evaporator coil will be cold (U-bend tubes) |

| Stage | Capacity (%) | Metering | Solenoid | SHR |
|---------|------------------|-------------|-----------------------|-----|
| Y | Part Load (67%) | TXV | Closed (De-energized) | .74 |
| Y1 & Y2 | Full Load (100%) | TXV & Fixed | Open (Energized) | .74 |

Face Split Evaporator coil
1/3 rd

TXV
Non-adjustable balanced port




Fig. 113 — UltraTech Scroll Compressor

START-UP CHECKLIST FOR 50TC 07-16 ONLY

(Remove and use for job file)

NOTE: To avoid injury to personnel and damage to equipment or property when completing the procedures listed in this start-up checklist, use good judgment, follow safe practices, and adhere to the safety considerations/information as outlined in preceding sections of this Installation Instructions document.

I. PRELIMINARY INFORMATION

MODEL NO _____

JOB NAME _____

SERIAL NO _____

ADDRESS _____

START-UP DATE _____

TECHNICIAN NAME _____

ADDITIONAL ACCESSORIES _____

II. PRE-START-UP

Verify that all packaging materials have been removed from unit (Y/N) _____

Verify installation of outdoor air hood (Y/N) _____

Verify that condensate connection is installed per instructions (Y/N) _____

Verify that all electrical connections and terminals are tight (Y/N) _____

Check that indoor-air filters are clean and in place (Y/N) _____

Check that outdoor-air inlet screens are in place (Y/N) _____

Verify that unit is level (Y/N) _____

Check fan wheels and propeller for location in housing/orifice and verify setscrew is tight (Y/N) _____

Verify that fan sheaves are aligned and belts are properly tensioned (Y/N) _____

Verify that scroll compressors are rotating in the correct direction (Y/N) _____

Verify installation of thermostat (Y/N) _____

III. START-UP

ELECTRICAL

| | | | |
|-------------------|-------------|-------------|-------------|
| Supply Voltage | L1-L2 _____ | L2-L3 _____ | L3-L1 _____ |
| Compressor Amps 1 | L1 _____ | L2 _____ | L3 _____ |
| Compressor Amps 2 | L1 _____ | L2 _____ | L3 _____ |
| Supply Fan Amps | L1 _____ | L2 _____ | L3 _____ |

TEMPERATURES

| | | |
|--------------------------------|----------|------------------------|
| Outdoor-air Temperature | _____ °F | DB (Dry Bulb) |
| Return-air Temperature | _____ °F | _____ °F WB (Wet Bulb) |
| Cooling Supply Air Temperature | _____ °F | |

PRESSESSES

| | | |
|-----------------------|-----------------|------|
| Refrigerant Suction | CIRCUIT A _____ | PSIG |
| | CIRCUIT B _____ | PSIG |
| Refrigerant Discharge | CIRCUIT A _____ | PSIG |
| | CIRCUIT B _____ | PSIG |

Verify Refrigerant Charge using Charging Charts (Y/N) _____

GENERAL

Economizer minimum vent and changeover settings to job requirements (if equipped) (Y/N) _____

Verify smoke detector unit shutdown by utilizing magnet test (Y/N) _____

IV. HUMIDI-MIZER® START-UP

NOTE: Units equipped with either SystemVu™ or RTU Open controls have Service Test menus or modes that can assist with the Humidi-Mizer System Start-Up function and provide the means to make the observations listed for this start-up.

STEPS

1. Check CTB for jumper 5, 6, 7 (Jumper 5, 6, 7 must be cut and open) (Y/N) _____
2. Open humidistat contacts (Y/N) _____
3. Start unit In cooling (Close Y1) (Y/N) _____

OBSERVE AND RECORD

| | | |
|---|-------|------|
| A. Suction pressure | _____ | PSIG |
| B. Discharge pressure | _____ | PSIG |
| C. Entering air temperature | _____ | ° F |
| D. Liquid line temperature at outlet or reheat coil | _____ | ° F |
| E. Confirm correct rotation for compressor (Y/N) | _____ | |
| F. Check for correct ramp-up of outdoor fan motor as condenser coil warms (Y/N) | _____ | |
| 4. Check unit charge per charging chart (Y/N) | _____ | |

(Jumper 32L Motormaster® temperature sensor during this check. Remove jumper when complete.)

5. Switch unit to high-latent mode (sub-cooler) by closing humidistat with Y1 closed (Y/N) _____

OBSERVE

- A. Reduction in suction pressure (5 to 7 psi expected) (Y/N) _____
- B. Discharge pressure unchanged (Y/N) _____
- C. Liquid temperature drops to 50°F to 55°F range (Y/N) _____
- D. LSV solenoid energized (valve closes) (Y/N) _____
6. Switch unit to dehumid (reheat) by opening Y1 (Y/N) _____

OBSERVE

- A. Suction pressure increases to normal cooling level
- B. Discharge pressure decreases (35 to 50 psi) (Limited by Motormaster control)
- C. Liquid temperature returns to normal cooling level
- D. LSV solenoid energized (valve closes)
- E. DSV solenoid energized, valve opens
7. With unit in dehumid mode close W1 compressor and outdoor fan stop; LSV and DSV solenoids de-energized (Y/N) _____
8. Open W1 restore unit to dehumid mode (Y/N) _____
9. Open humidistat input compressor and outdoor fan stop; LSV and DSV solenoids de-energized (Y/N) _____
10. Restore set-points for thermostat and humidistat (Y/N) _____

REPEAT PROCESS FOR 2 COMPRESSOR SYSTEMS.

CUT ALONG DOTTED LINE

CUT ALONG DOTTED LINE