

# Installation, Start-Up and Service Instructions


## CONTENTS

SAFETY CONSIDERATIONS .....	2	SERVICE .....	32 - 41
INSTALLATION GUIDELINES .....	2	Refrigeration System .....	32
Replacement/Retrofit — R-22 to Puron .....	2	Compressor Oil .....	32
INSTALLATION .....	10 - 21	Servicing Systems on Roofs with Synthetic Materials .....	32
Jobsite Survey .....	10	Liquid Line Filter Drier .....	33
Step 1 - Plan for Unit Location .....	10	Filed Refrigerant Access Ports .....	33
Step 2 - Complete Pre-Installation Checks .....	10	Factory High-Flow Access Ports .....	33
Step 3 - Prepare Unit Mounting Support .....	10	Comfort Alert Diagnostic Module .....	34
Step 4 - Rig and Mount the Unit .....	10	Compressor Protection .....	36
Step 5 - Complete Refrigerant Piping Connections ...	11	Crankcase Heater .....	36
Step 6 - Install Accessories .....	18	Low-Pressure Switch .....	36
Step 7 - Complete Electrical Connections .....	18	High-Pressure Switch .....	36
PRE-START-UP .....	22	Outdoor Fans .....	36
System Check .....	22	Lubrication .....	36
Turn On Crankcase Heater .....	22	Coil Type Identification .....	39
Preliminary Charge .....	22	NOVATION™ Coil Cleaning and Maintenance .....	39
START-UP .....	22 - 30	Repairing NOVATION Condenser Tube Leaks .....	39
Preliminary Checks .....	22	Replacing NOVATION Condenser Coil .....	39
Start Unit .....	23	Routine Cleaning of Round-Tube Plate Fin (RTPF) Coils .....	40
OPERATING SEQUENCE .....	31	Fastener Torque Values .....	41
Indoor (Supply) Fan .....	31	TROUBLESHOOTING .....	41 - 42
Cooling, Unit Without Economizer .....	31	APPENDIX A	
Cooling, Unit With Economizer .....	31	Air Conditioner & Heat Pump with Puron® —	
Heating .....	31	Quick Reference Guide .....	43
ROUTINE SYSTEM MAINTENANCE .....	32	APPENDIX B	
Quarterly Inspection (and 30 days after initial start) ...	32	Wiring Diagram List .....	43
Seasonal Maintenance .....	32	APPENDIX C	
		Low Ambient Option — Factory Installed .....	44
		START-UP CHECKLIST .....	51 - 52

## SAFETY CONSIDERATIONS

Improper installation, adjustment, alteration, service, maintenance, or use can cause explosion, fire, electrical shock or other conditions which may cause personal injury or property damage. Consult a qualified installer, service agency, or your distributor or branch for information or assistance. The qualified installer or agency must use factory-authorized kits or accessories when modifying this product. Refer to the individual instructions package

Follow all safety codes. Wear safety glasses and work gloves. Use quenching cloths for brazing operations and have a fire extinguisher available. Read these instructions thoroughly and follow all warnings or cautions attached to the unit. Consult local building codes for special requirements. In absence of local codes, it is recommended that the USA standard ANSI/NFPA 70, National Electrical Code (NEC), be followed.

It is important to recognize safety information. This is the safety-alert symbol . When you see this symbol on the unit and in instructions or manuals, be alert to the potential for personal injury.

Understand the signal words DANGER, WARNING, CAUTION, and NOTE. These words are used with the safety-alert symbol. DANGER identifies the most serious hazards which **will** result in severe personal injury or death. WARNING signifies hazards which **could** result in personal injury or death. CAUTION is used to identify unsafe practices, which **may** result in minor personal injury or product and property damage. NOTE is used to highlight suggestions which **will** result in enhanced installation, reliability, or operation.

### WARNING

#### ELECTRICAL SHOCK HAZARD

Failure to follow this warning could cause in personal injury or death.

Before performing service or maintenance operations on unit, always turn off main power switch to unit and install lockout tag. Unit may have more than one power switch.

### WARNING

#### UNIT OPERATION AND SAFETY HAZARD

Failure to follow this warning could cause in personal injury, death and/or equipment damage.

Puron<sup>®</sup> (R-410A) refrigerant systems operate at higher pressures than standard R-22 systems. Do not use R-22 service equipment or components on Puron refrigerant equipment.

### WARNING

#### PERSONAL INJURY AND ENVIRONMENTAL HAZARD

Failure to follow this warning could cause in personal injury or death.

Relieve pressure and recover all refrigerant before system repair or final unit disposal.

Wear safety glasses and gloves when handling refrigerants. Keep torches and other ignition sources away from refrigerants and oils.

### CAUTION

#### CUT HAZARD

Failure to follow this caution may result in personal injury.

Sheet metal parts may have sharp edges or burrs. Use care and wear appropriate protective clothing, safety glasses and gloves when handling parts and servicing 38AU units.

## INSTALLATION GUIDELINE

### Replacement/Retrofit — R-22 to Puron<sup>®</sup>

Replacement/retrofit installations require change-out of outdoor unit, metering device, and filter driers. Change-out of indoor coil (evaporator) and interconnecting tubing is recommended.

**Existing evaporator coil** – If the existing evaporator coil may be re-used, check with the coil manufacturer to verify the coil construction is suitable for operation with the higher pressures of Puron<sup>®</sup> (R-410A). Also determine if the existing TXV valve is compatible with R-410A, replace if necessary. The minimum factory test pressure rating must be 1725 kPa (250 psig). Existing coil will need to be purged with Nitrogen to remove as much mineral oil as possible to eliminate cross contamination of oils.

**Acid test** – If the existing system is being replaced because of a compressor electrical failure, assume acid is in system. If system is being replaced for any other reason, use an approved acid test kit to determine acid level. If even low levels of acid are detected, install a 100 percent activated alumina suction-line filter drier in addition to the replacement liquid-line filter drier. Remove the suction line filter drier as soon as possible, with a maximum of 72 hr of operation. Recommendation: Install a ball valve in the liquid line at the filter drier location when installing a suction filter in the suction line.

**Existing refrigeration piping** – Reuse of existing refrigerant piping involves three issues: quality (strength) of existing tubing, cleanliness and tube size. Inspect all tube segments and joints for signs of damage, corrosion or poor brazing. Flush the interconnecting piping system with dry Nitrogen to eliminate as much trace of mineral oil as possible.

Same tube sizes are capable of handling higher flowrates (expressed as tons of cooling capacity) with Puron refrigerant compared to R-22 at constant pressure drops. For example, a 1/2-inch OD liquid line is rated at 33% higher tons with Puron® than with R-22 (at 5°F pressure drop). A 1 1/8-inch OD suction line is rated at 53% higher tons with Puron than with R-22 (at 2°F pressure drop). Refrigeration lines selected for R-22 use are typically oversized for Puron applications. Carefully check the existing suction line size against the table for maximum size (see Table 7); replace vertical riser segments if necessary. Check existing liquid line size against sizing data in Table 5 or 6; replace with smaller lines when feasible.

#### Installation –

1. Remove the existing evaporator coil or fan coil and install the replacement coil when appropriate.
2. Drain oil from low points and traps in suction line tubing (and hot gas bypass tubing if appropriate) and evaporator if they were not replaced. Removing oil from evaporator coil may require purging of the tubing with dry nitrogen.
3. Unless indoor unit is equipped with a Puron® approved metering device, change the metering device to a thermal expansion valve (TXV) designed for Puron® (R-410A).
4. Remove the existing outdoor unit. Install the new outdoor unit according to these installation instructions.

5. Install a new field-supplied liquid-line filter drier at the indoor coil just upstream of the TXV or fix orifice metering device.
6. If a suction line filter drier is also to be installed, install suction line drier downstream of suction line service valve at condensing unit.

## ⚠ CAUTION

### UNIT DAMAGE HAZARD

Failure to follow this caution may result in equipment damage or improper operation.


Never install suction-line filter drier in the liquid-line of a Puron® system.

7. If required, install a 100% activated alumina suction line filter drier at the outdoor unit.
8. Evacuate and charge the system according to the instructions in this installation manual.
9. Operate the system for 10 hr. Monitor the pressure drop across the suction line filter drier. If pressure drop exceeds 21kPa (3 psig), replace suction-line and liquid-line filter driers. Be sure to purge system with dry nitrogen and evacuate when replacing filter driers. Continue to monitor the pressure drop across suction-line filter drier. Repeat filter changes is necessary. Never leave suction-line filter drier in system longer than 72 hr (actual time).






NOTES:

1. MINIMUM CLEARANCE (LOCAL CODES OR JURISDICTION MAY PREVAIL):
  - A. BOTTOM TO COMBUSTIBLE SURFACES: 0 INCHES.
  - B. OUTDOOR COIL, FOR PROPER AIR FLOW: 36 INCHES ONE SIDE, 12 INCHES THE OTHER, THE SIDE GETTING THE GREATER CLEARANCE IS OPTIONAL.
  - C. OVERHEAD: 60 INCHES, TO ASSURE PROPER OUTDOOR FAN OPERATION.
  - D. BETWEEN UNITS: CONTROL BOX SIDE, 42 INCHES PER NEC.
  - E. BETWEEN UNIT AND UNGROUNDED SURFACES: CONTROL BOX SIDE, 36 INCHES PER NEC.
  - F. BETWEEN UNIT AND BLOCK OR CONCRETE WALLS AND OTHER GROUNDED SURFACES: CONTROL BOX SIDE, 42 INCHES PER NEC.
2. WITH EXCEPTION OF THE CLEARANCE FOR THE OUTDOOR COIL AS STATED IN NOTE 1B, A REMOVABLE FENCE OR BARRICADE REQUIRES NO CLEARANCE.
3. UNITS MAY BE INSTALLED ON COMBUSTIBLE FLOORS MADE FROM WOOD OR CLASS A, B OR C ROOF COVERING MATERIAL.

CG CENTER OF GRAVITY  
 DIRECTION OF AIR FLOW  
 DIMENSIONS IN [ ] ARE IN MILLIMETERS.



SERVICE VALVE CONNECTIONS		
UNIT	SUCTION	LIQUID
38AUZ07	1-1/8 [28.6]	3/8 [9.5]
38AUZ08	1-1/8 [28.6]	1/2 [12.7]
38AUD12	1-1/8 [28.6]	3/8 [9.5]
38AUD14	1-3/8 [34.9]	1/2 [12.7]



C101015

UNIT	STD. UNIT WT.		CORNER A		CORNER B		CORNER C		CORNER D		CENTER OF GRAVITY			UNIT HEIGHT
	kg.	lbs.	kg.	lbs.	kg.	lbs.	kg.	lbs.	kg.	lbs.	X	Y	Z	H
38AUZ*07 (MCHX)	149	328	58	128	31	68	28	62	32	70	533.2 mm 21 in	482.6 mm 19 in	330.2 mm 13 in	1076.0 mm 42 3/8 in
38AUZ*08 (MCHX)	160	353	63	138	33	72	29	65	35	78	482.6 mm 19 in	584.2 mm 23 in	330.2 mm 13 in	1076.0 mm 42 3/8 in
38AUD*12 (MCHX)	226	499	88	193	50	111	38	72	56	123	508.0 mm 20 in	584.2 mm 23 in	381.0 mm 15 in	1279.2 mm 50 3/8 in
38AUD*14 (MCHX)	229	505	86	190	40	88	34	76	68	151	508.0 mm 20 in	609.6 mm 24 in	381.0 mm 15 in	1279.2 mm 50 3/8 in
38AUZ*07 (RTPF)	176	389	64	141	44	96	28	62	41	91	457.2 mm 18 in	609.6 mm 24 in	533.4 mm 21 in	1076.0 mm 42 3/8 in
38AUZ*08 (RTPF)	177	391	64	142	44	96	28	62	41	91	457.2 mm 18 in	609.6 mm 24 in	533.4 mm 21 in	1076.0 mm 42 3/8 in
38AUD*12 (RTPF)	234	516	84	185	53	117	38	83	59	131	482.6 mm 19 in	584.2 mm 23 in	609.6 mm 24 in	1279.2 mm 50 3/8 in

LEGEND: MCXH = Novation™ coil  
 RTPF = Round Tube/Plate Fin coil

Fig. 1 - 38AU Unit Dimensions

**Table 1A — Physical Data — 38AUZ\*07-08 Units — 50 Hz SI**

UNIT SIZE 38AU	Z*07	Z*08
<b>NOMINAL CAPACITY (kW)</b>	18	22
<b>OPERATING WEIGHTS (kg)</b>		
<b>NOVATION™ Coil (Al Tube)</b>	149	160
<b>Round Tube/Plate Fin Coil (Cu/Al)</b>	176	176
<b>REFRIGERANT TYPE‡</b>	R-410A	
<b>NOVATION Operating Charge, Typical (kg)†</b>	3.8	4.6
<b>NOVATION Shipping Charge (kg)</b>	2.0	2.2
<b>RTPF Operating Charge, Typical (kg)†</b>	6.4	7.7
<b>RTPF Shipping Charge (kg)</b>	5.0	5.9
<b>COMPRESSOR</b>		
<b>Qty...Type</b>	1...Scroll	1...Scroll
<b>Oil Charge (L)</b>	1.7	1.8
<b>CONDENSER FANS</b>		
<b>Qty...r/s</b>	2...15.3	
<b>Motor kW</b>	0.43	0.40
<b>Diameter (mm)</b>	560	
<b>Nominal Airflow (L/s)</b>	1950	3000
<b>RTPF CONDENSER COIL</b>		
<b>Material (Tube/Fin)</b>	Cu / Al	
<b>Coil Type</b>	3/8-in RTPF	
<b>Rows/Fins per Meter (Fins/m)</b>	2 / 670	
<b>Face Area (sq m total)</b>	1.6	1.6
<b>NOVATION CONDENSER COIL</b>		
<b>Material (Tube/Fin)</b>	Al / Al	
<b>Coil Type</b>	Novation	
<b>Rows/Fins per Meter (Fins/m)</b>	1 / 670	
<b>Face Area (sq m total)</b>	1.6	1.9
<b>CONTROLS</b>		
<b>Pressurestat Settings (kPa)</b>		
<b>High Cutout</b>	4347 ± 70	
<b>Cut-in</b>	3482 ± 138	
<b>Low Cutout</b>	372 ± 21	
<b>Cut-in</b>	807 ± 34	
<b>PIPING CONNECTIONS (in. ODS)</b>		
<b>Qty...Suction</b>	1...1 <sup>1</sup> / <sub>8</sub>	1...1 <sup>1</sup> / <sub>8</sub>
<b>Qty...Liquid</b>	1...3/8	1...1/2

**LEGEND**

**RTPF** — Round Tube/Plate Fin

**ODS** — Outside Diameter Sweat (socket)

‡ Unit is factory-supplied with partial charge only.

† Typical operating charge with 7.6 m (25 ft) of interconnecting piping.

Table 1B — Physical Data — 38AUZ\*07-08 Units — 50 Hz English

UNIT SIZE 38AU	Z*07	Z*08
NOMINAL CAPACITY (tons)	6	7.5
OPERATING WEIGHTS (lb)		
NOVATION™ Coil (Al Tube)	328	353
Round Tube/Plate Fin Coil (Cu/Al)	389	389
REFRIGERANT TYPE‡	R-410A	
NOVATION Operating Charge, Typical (lb)†	8.4	10.2
NOVATION Shipping Charge (lb)	4.4	4.9
RTPF Operating Charge, Typical (lb)†	14.0	17.0
RTPF Shipping Charge (lb)	11.0	13.0
COMPRESSOR		
Qty...Type	1...Scroll	1...Scroll
Oil Charge (oz)	56	60
CONDENSER FANS		
Qty...Rpm	2...920	
Motor Watts	430	400
Diameter	22	
Nominal Airflow (Cfm Total)	4150	6300
RTPF CONDENSER COIL		
Material (Tube/Fin)	Cu / Al	
Coil Type	3/8-in RTPF	
Rows/Fins per inch (FPI)	2/ 17	
Face Area (sq ft total)	17.5	17.5
NOVATION CONDENSER COIL		
Material (Tube/Fin)	Al / Al	
Coil Type	Novation	
Rows/Fins per inch (FPI)	1 / 17	
Face Area (sq ft total)	17.5	20.5
CONTROLS		
Pressurestat Settings (psig)		
High Cutout	630 ± 10	
Cut-in	505 ± 20	
Low Cutout	54 ± 3	
Cut-in	117 ± 5	
PIPING CONNECTIONS (in. ODS)		
Qty...Suction	1...1 1/8	1...1 1/8
Qty...Liquid	1...3/8	1...1/2

LEGEND

RTPF — Round Tube/Plate Fin

ODS — Outside Diameter Sweat (socket)

‡ Unit is factory-supplied with partial charge only.

† Typical operating charge with 25 ft (7.6 m) of interconnecting piping.

Table 2A — Physical Data — 38AUD\*12-14 Units — 50 Hz SI

UNIT SIZE 38AU	D*12	D*14
NOMINAL CAPACITY (kW)	28	34
OPERATING WEIGHTS (kg)		
NOVATION™ Coil (Al Tube)	226	229
Round Tube/Plate Fin Coil (Cu/Al)	234	—
REFRIGERANT TYPE‡	R-410A	
NOVATION Operating Charge A/B, Typical (kg)†	3.4 / 3.3	4.8 / 4.9
NOVATION Shipping Charge A/B (kg)	1.3 / 1.3	1.5 / 1.5
RTPF Operating Charge A/B, Typical (kg)†	5.0 / 5.0	—
RTPF Shipping Charge A/B (kg)	3.6 / 3.6	—
COMPRESSOR		
Qty...Type	2...Scroll	2...Scroll
Oil Charge A/B (L)	1.2	1.7
CONDENSER FANS		
Qty...r/s	2...15.3	
Motor kW	0.40	
Diameter (mm)	560	
Nominal Airflow (l/s Total)	3000	2450
RTPF CONDENSER COIL		
Material (Tube/Fin)	Cu / Al	—
Coil Type	<sup>3</sup> / <sub>8</sub> -in RTPF	—
Rows/Fins per Meter (Fins/m)	2 / 670	—
Face Area (sq m total)	2.3	—
NOVATION CONDENSER COIL		
Material (Tube/Fin)	Al / Al	
Coil Type	Novation	
Rows/Fins per Meter (Fins/m)	1 / 670	
Face Area (sq m total)	2.3	3.0
CONTROLS		
Pressurestat Settings (kPa)		
High Cutout	4347 ± 70	
Cut-in	3482 ± 138	
Low Cutout	372 ± 21	
Cut-in	807 ± 34	
PIPING CONNECTIONS (in. ODS)		
Qty...Suction A/B	1...1 <sup>1</sup> / <sub>8</sub> / 1...1 <sup>1</sup> / <sub>8</sub>	1...1 <sup>3</sup> / <sub>8</sub> / 1...1 <sup>3</sup> / <sub>8</sub>
Qty...Liquid A/B	1... <sup>3</sup> / <sub>8</sub> / 1... <sup>3</sup> / <sub>8</sub>	1... <sup>1</sup> / <sub>2</sub> / 1... <sup>1</sup> / <sub>2</sub>

LEGEND

RTPF — Round Tube/Plate Fin

ODS — Outside Diameter Sweat (socket)

‡ Unit is factory-supplied with partial charge only.

† Typical operating charge with 7.6 m (25 ft) of interconnecting piping.

Table 2B — Physical Data — 38AUD\*12-14 Units — 50 Hz English

UNIT SIZE 38AU	D*12	D*14
NOMINAL CAPACITY (tons)	10	12.5
OPERATING WEIGHTS (lb)		
NOVATION™ Coil (Al Tube)	499	505
Round Tube/Plate Fin Coil (Cu/Al)	516	—
REFRIGERANT TYPE‡	R-410A	
NOVATION Operating Charge A/B, Typical (lb)†	7.4 / 7.3	10.8 / 10.9
NOVATION Shipping Charge A/B (lb)	3.0 / 3.0	3.5 / 3.5
RTPF Operating Charge A/B, Typical (lb)†	11.0 / 11.0	—
RTPF Shipping Charge A/B (lb)	8.0 / 8.0	—
COMPRESSOR		
Qty...Type	2...Scroll	2...Scroll
Oil Charge A/B (oz)	42	60
CONDENSER FANS		
Qty...Rpm	2...920	
Motor Watts	400	
Diameter	22	
Nominal Airflow (Cfm Total)	6300	5200
RTPF CONDENSER COIL		
Material (Tube/Fin)	Cu / Al	—
Coil Type	<sup>3</sup> / <sub>8</sub> -in RTPF	—
Rows/Fins per inch (FPI)	2 / 17	—
Face Area (sq ft total)	25.1	—
NOVATION CONDENSER COIL		
Material (Tube/Fin)	Al / Al	
Coil Type	Novation	
Rows/Fins per inch (FPI)	1 / 17	
Face Area (sq ft total)	25.0	31.8
CONTROLS		
Pressurestat Settings (psig)		
High Cutout	630 ± 10	
Cut-in	505 ± 20	
Low Cutout	54 ± 3	
Cut-in	117 ± 5	
PIPING CONNECTIONS (in. ODS)		
Qty...Suction A/B	1...1 <sup>1</sup> / <sub>8</sub> / 1...1 <sup>1</sup> / <sub>8</sub>	1...1 <sup>3</sup> / <sub>8</sub> / 1...1 <sup>3</sup> / <sub>8</sub>
Qty...Liquid A/B	1... <sup>3</sup> / <sub>8</sub> / 1... <sup>3</sup> / <sub>8</sub>	1... <sup>1</sup> / <sub>2</sub> / ...1 <sup>1</sup> / <sub>2</sub>

LEGEND

RTPF — Round Tube/Plate Fin

ODS — Outside Diameter Sweat (socket)

‡ Unit is factory-supplied with partial charge only.

† Typical operating charge with 25 ft (7.6 m) of interconnecting piping.



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
3	8	A	U	D	A	1	4	A	0	G	9	A	0	A	0	A	0

#### Model Type

38AU = Carrier Condensing Unit  
Puron® R-410A Refrigerant

#### Type of Coil

Z = Single Circuit, A/C Scroll Compressor  
D = Dual Circuit, A/C Scroll Compressor

#### Refrigerant Options

A = None  
B = Low Ambient

#### Nominal Capacity

07 = 18 kW (6 Tons)  
08 = 22 kW (7.5 Tons)  
12 = 28 kW (10 Tons)  
14 = 34 kW (12.5 Tons)

#### Not Used

A = Not Used

#### Not Used

0 = Not Used

#### Packaging

0 = Standard  
1 = LTL

#### Electrical Options

A = None  
C = Non-Fused Disconnect

#### Service Options

0 = None

#### Not Used

A = Place Holder

#### Base Unit Controls

0 = Electro-Mechanical Controls

#### Design Revision

A = Initial Rev (Discrete Model Number)

#### Voltage

9 = 400/3/60

#### Coil Options

NOVATION™

G = Al/Al

K = E-Coat Al/Al

T = Al/Al with Hail Guard

W = E-Coat Al/Al with Hail Guard

RTPF

A = Cu/Al

B = Precoat (Cu/Al)

C = E-Coat (Cu/Al)

M = Cu/Al with Hail Guard

N = Precoat (Cu/Al) with Hail Guard

P = E-Coat (Cu/Al) with Hail Guard

38AU

**Fig. 2 - Model Number Nomenclature**

C101016

POSITION NUMBER	1	2	3	4	5	6	7	8	9	10
TYPICAL	0	5	1	0	G	1	2	3	4	5

#### POSITION

1-2

3-4

5

6-10

#### DESIGNATES

Week of manufacture (fiscal calendar)

Year of manufacture ("10" = 2010)

Manufacturing location (G = ETP, Texas, USA)

Sequential number

**Fig. 3 - Serial Number Nomenclature**

C10068

## Matching 38AU Model To Evaporator Coil

The Model 38AUZ is a single-circuit unit design, requiring one set of refrigeration piping. This model can be connected to an evaporator coil with one circuit or with two circuits (by manifolding the evaporator connections into a single piping system).

The Model 38AUD is a dual-circuit unit design that requires two sets of refrigeration piping between the outdoor unit and the evaporator coil (or coils). This model can only be connected to an evaporator coil that has two refrigeration circuits (or to two separate evaporator coils). The Model 38AUD CANNOT be connected to a single-circuit evaporator coil. The Model 38AUD CANNOT be field-converted to a single-circuit design.

**Table 3 – Evaporator Coil Connections**

Evaporator Coil has	Connect to Model	Notes
Single Circuit	38AUZ ONLY	
Two Circuits	38AUZ Or 38AUD	Manifold evaporator circuits into single piping system  Use two separate piping systems

Before unpacking this new 38AU model, compare the evaporator coil design to the 38AU model.

# INSTALLATION

## Jobsite Survey

Complete the following checks before installation.


1. Consult local building codes or the U.S.A. National Electrical Code (Ref: ANSI/NFPA 70, [American National Standards Institute/National Fire Protection Association], latest revision) for special installation requirements
2. Determine unit location (from project plans) or select unit location.
3. Check for possible overhead obstructions which may interfere with unit lifting or rigging.

## Step 1 — Plan for Unit Location

Select a location for the unit and its support system (pad, rails or other) that provides for the minimum clearances required for safety. This includes the clearance to combustible surfaces, unit performance and service access below, around and above unit as specified in unit drawings. See Fig.4.

**NOTE:** Local codes may require different clearances than specified in Fig. 4. It is the responsibility of installers to be knowledgeable in local codes and to modify the recommended clearances to satisfy local codes.

**NOTE:** Consider also the effect of adjacent units on airflow performance and control box safety clearance.



C110201

**Fig. 4 - Service Clearance Dimensional Drawing**

Do not install the outdoor unit in an area where fresh air supply to the outdoor coil may be restricted or when recirculation from the condenser fan discharge is possible. Do not locate the unit in a well or next to high walls.

Evaluate the path and required line length for interconnecting refrigeration piping, including suction riser requirements (outdoor unit above indoor unit), liquid line lift (outdoor unit below indoor unit) and hot gas bypass line. Relocate sections to minimize the length of interconnecting tubing.

**DO NOT BURY REFRIGERATION LINES.**

Although unit is weatherproof, avoid locations that permit water from higher level runoff and overhangs to fall onto the unit.

## Step 2 — Complete Pre-Installation Checks

**Check Unit Electrical Characteristics:** Confirm before installation of unit that voltage, amperage and circuit protection requirements listed on unit data plate agree with power supply provided.

**Un-crate Unit:** Remove unit packaging except for the top skid assembly, which should be left in place until after the unit is rigged into its final location.

**Inspect Shipment:** File a claim with shipping company if the shipment is damaged or incomplete.

### Consider System Requirements:

- Consult local building codes or the U.S.A. National Electrical Code (Ref: ANSI/NFPA 70, [American National Standards Institute/National Fire Protection Association], latest revision) for special installation requirements.
- Allow sufficient space for airflow clearance, wiring, refrigerant piping, and servicing unit. See Fig. 1 for unit dimensions and weight distribution data.
- Locate the unit so that the outdoor coil (condenser) airflow is unrestricted on all sides and above.
- The unit may be mounted on a level pad directly on the base channels or mounted on raised pads at support points. See Tables 1A through 2B for unit operating weights. See Fig. 1 for weight distribution based on recommended support points.

**NOTE:** If vibration isolators are required for a particular installation, use the data in Fig. 1 to make the proper selection.

## Step 3 — Prepare Unit Mounting Support

### Slab Mount —

Provide a level concrete slab that extends a minimum of 150 mm (6 in.) beyond unit cabinet. Install a gravel apron in front of condenser coil air inlet to prevent grass and foliage from obstructing airflow.

## Step 4 — Rig and Mount the Unit

### ⚠ CAUTION

#### UNIT DAMAGE HAZARD

Failure to follow this caution may result in equipment damage.

All panels must be in place when rigging. Unit is not designed for handling by fork truck.

**Rigging:** These units are designed for overhead rigging. Refer to the rigging label for preferred rigging method. Spreader bars are not required if top crating is left on the unit. All panels must be in place when rigging. As further protection for coil faces, plywood sheets may be placed against the sides of the unit, behind cables. Run cables to a central suspension point so that the angle from the

horizontal is not less than 45 degrees. Raise and set the unit down carefully.

If it is necessary to roll the unit into position, mount the unit on longitudinal rails, using a minimum of 3 rollers. Apply force to the rails, not the unit. If the unit is to be skidded into position, place it on a large pad and drag it by the pad. Do not apply any force to the unit.

Raise from above to lift the unit from the rails or pad when unit is in its final position.

After the unit is in position, remove all shipping materials and top crating.

## Step 5 — Complete Refrigerant Piping Connections

**IMPORTANT:** Do not bury refrigerant piping underground.

**IMPORTANT:** A refrigerant receiver is not provided with the unit. Do not install a receiver.

### Provide Safety Relief —

If local codes dictate an additional safety relief device, purchase locally and install locally. Installation will require the recovery of the factory shipping charge before the factory tubing can be cut and the supplemental relief device is installed.

Model 38AUD has two separate refrigeration systems. If required, each circuit will require a field-supplied/installed supplemental relief device.

### Check 38AU Model with Evaporator Coil Connections —

Confirm before installation of unit that the evaporator coil connections are consistent with this 38AU model. See Table 3 on page 9.

### Determine Refrigerant Line Sizes —

Select the recommended line sizes for 38AUZ and 38AUD unit from the appropriate tables.

Determine the linear length of interconnecting piping required between the outdoor unit and indoor unit (evaporator). Consider and identify also the arrangement of the tubing path (quantity and type of elbows in both lines), liquid line solenoid size, filter drier and any other refrigeration specialties located in the liquid line. Refer to the indoor unit installation instructions for additional details on refrigeration specialties devices.

Determine equivalent line length adjustments for path and components and add to linear line lengths. See Table 4, Equivalent Lengths for Common Fittings, for usual fitting types. Also identify adjustments for refrigeration specialties. Refer to Part 3 of the Carrier System Design Manual for additional data and information on equivalent lengths.

**Table 4 – Equivalent Lengths for Common Fittings (EN units)**

mm Ref	Nominal Tube OD (in)	Elbows				
		90° Std	90° Lrad	90° Street	45° Std	45° Street
9.5	<sup>3</sup> / <sub>8</sub>	0.40	0.24	0.67	0.18	0.30
12.7	<sup>1</sup> / <sub>2</sub>	0.43	0.27	0.70	0.21	0.34
15.9	<sup>5</sup> / <sub>8</sub>	0.49	0.30	0.76	0.24	0.40
19.1	<sup>3</sup> / <sub>4</sub>	0.55	0.37	0.88	0.27	0.46
22.2	<sup>7</sup> / <sub>8</sub>	0.61	0.43	0.98	0.27	0.49
28.6	<sup>1</sup> / <sub>8</sub>	0.79	0.52	1.25	0.40	0.64
34.9	<sup>1</sup> / <sub>8</sub>	1.01	0.70	1.71	0.52	0.91
41.3	<sup>1</sup> / <sub>8</sub>	1.22	0.79	1.92	0.64	1.04
54.0	<sup>2</sup> / <sub>8</sub>	1.52	1.01	2.50	0.79	1.37

mm Ref	Nominal Tube OD (in)	Tees			
		Branch Flow	Straight-Thru		
			No Reduct	Reduce 25%	Reduce 50%
9.5	<sup>3</sup> / <sub>8</sub>	0.79	0.24	0.34	0.40
12.7	<sup>1</sup> / <sub>2</sub>	0.82	0.27	0.37	0.43
15.9	<sup>5</sup> / <sub>8</sub>	0.91	0.30	0.43	0.49
19.1	<sup>3</sup> / <sub>4</sub>	1.07	0.37	0.52	0.55
22.2	<sup>7</sup> / <sub>8</sub>	1.22	0.43	0.58	0.61
28.6	<sup>1</sup> / <sub>8</sub>	1.52	0.52	0.70	0.79
34.9	<sup>1</sup> / <sub>8</sub>	2.13	0.70	0.94	1.01
41.3	<sup>1</sup> / <sub>8</sub>	2.44	0.79	1.13	1.22
54.0	<sup>2</sup> / <sub>8</sub>	3.05	1.01	1.43	1.52

**NOTE:** Equivalent line lengths will vary based on tube diameter. Calculate equivalent line length for each pipe by adding equivalent length adjustments to linear lengths for each pipe.

Enter the appropriate table to select the recommended line sizes.

Model:	Line Sizes Table	Quantity of Line Sets
38AUZ	5	1
38AUD	6	2

### Liquid Lift —

A liquid lift condition exists when the outdoor unit is located below the indoor (evaporator) unit and liquid flows vertically up in a portion of the liquid line. The vertical column of liquid reduces the available state point subcooling at the evaporator coil's thermal expansion valve. This effect reduces the length of liquid lift (feet of elevation) that a liquid line size can accommodate. Longer linear tube lengths will also reduce the amount of liquid lift possible.

Check Tables 5 (38AUZ) and 6 (38AUD) for maximum liquid lift capabilities for line sizes. Reselect the liquid line tube size if necessary. If maximum available tube size cannot provide the required lift distance on this installation, relocate the outdoor unit to reduce the equivalent line length or the lift requirement.

**Table 5 – 38AUZ 07-08 50Hz Piping Recommendations (Single-Circuit Unit)**

R-410A		Equivalent Length											
		meter	0-12		12-23		23-34		34-46		46-57		
		feet	0-38		38-75		75-113		113-150		150-188		
Model	Linear Length												
	meter		0-7.5		7.5-15		15-23		23-30		30-38		
	feet		0-25		25-50		50-75		75-100		100-125		
38AUZ*07	Liquid Line	3/8	3/8 1/2		3/8 1/2		3/8 1/2		3/8 1/2		3/8 1/2		
	Max Lift												
	SI (m)												
	Novation	7.5	15		16 23		9 29		10 34				
	RTPF	7.5	15		19 23		12 30		11 38				
	EN (ft)												
	Novation	25	50		53 75		34 97		33 112				
	RTPF	25	50		63 75		42 100		38 125				
	Suction Line	7/8 7/8	7/8		7/8		7/8		7/8		1-1/8		
	Charge												
	SI (kg)												
	Novation	3.8	4.4		4.9 5.9		5.4 6.8		6.1 7.9				
	RTPF	6.4	7.0		7.4 8.5		7.9 9.3		8.7 10.4				
	EN (lbs)												
	Novation	8.4	9.8		10.8 13.1		11.8 14.9		13.5 17.4				
	RTPF	14.0	15.4		16.4 18.7		17.4 20.5		19.1 23.0				
38AUZ*08	Liquid Line	1/2	1/2 5/8		1/2 5/8		1/2 5/8		1/2 5/8		1/2 5/8		
	Max Lift												
	SI (m)												
	Novation	7.5	9 11		7 10		DNU 10		10 16				
	RTPF	7.5	15 NR		23 NR		27 30		18 38				
	EN (ft)												
	Novation	25	30 38		24 36		DNU 35		33 53				
	RTPF	25	50 NR		75 NR		89 100		62 125				
	Suction Line	7/8	7/8		1-1/8		1-1/8		1-1/8				
	Charge												
	SI (kg)												
	Novation	5.5	6.3 7.2		7.4 8.6		DNU 9.9		9.1 11.2				
	RTPF	8.6	9.4 NR		10.4 NR		11.3 13.0		12.2 14.3				
	EN (lbs)												
	Novation	12.2	13.9 15.8		16.2 19.0		DNU 21.9		20.0 24.8				
	RTPF	19.0	20.7 NR		23.0 NR		24.9 28.7		26.8 31.6				
Legend:													
Equivalent Length		Equivalent tubing length, including effects of refrigeration specialties devices											
Linear Length		Linear tubing length, feet											
Liquid Line		Tubing size, inches OD.											
Max Lift		Maximum liquid lift (indoor unit ABOVE outdoor unit only), at maximum permitted liquid line pressure drop • Linear Length Less than 30 m (100 ft): Minimum 1.1°C (2.0°F) subcooling entering TXV • Linear Length Greater than 30 m (100 ft): Minimum 0.3°C (0.5°F) subcooling entering TXV											
Suction Line		Tube size, inches OD											
Charge		Charge Quantity, lbs. Calculated for both liquid line sizes (where applicable), but only with larger suction line size (where applicable)											
DNU		Do Not Use (pressure drop exceeds available subcooling in this model)											
NR		Not Recommended (use smaller liquid tube size)											
SI		Metric units of measure											
EN		English units of measure (I-P)											
NOTE:		For applications with equivalent length greater than 57 m (188 ft) and/or linear length greater than 38 m (125 ft), contact your local Carrier representative.											

**Table 6 – 38AUD 12-14 50Hz Piping Recommendations (Two-Circuit Unit)**

<b>NOTE:</b> 38AUD requires TWO sets of refrigeration piping						
<b>R-410A</b>	Equivalent Length					
	meter	0–12	12–23	23–34	34–46	46–57
	feet	0–38	38–75	75–113	113–150	150–188
<b>Model</b>	Linear Length					
	meter	0–7.5	7.5–15	15–23	23–30	30–38
	feet	0–25	25–50	50–75	75–100	100–125
<b>38AUD*12</b>	Liquid Line	$\frac{3}{8}$	$\frac{3}{8}$	$\frac{3}{8}$ $\frac{1}{2}$	$\frac{3}{8}$ $\frac{1}{2}$	$\frac{3}{8}$ $\frac{1}{2}$
	Max Lift					
	SI (m)					
	Novation	7.5	15	15 23	10 24	13 29
	RTPF	7.5	15	15 23	10 27	11 32
	EN (ft)					
	Novation	25	50	50 75	36 79	44 96
	RTPF	25	50	50 75	36 89	39 106
	Suction Line	$\frac{7}{8}$	$\frac{7}{8}$	$\frac{7}{8}$	$\frac{7}{8}$	1– $\frac{1}{8}$
	Charge					
	SI (kg)					
	Novation	3.3	3.8	4.2 5.3	4.7 6.1	5.1 6.9
	RTPF	4.9	5.4	5.8 6.9	6.3 7.7	6.8 8.6
	EN (lbs)					
	Novation	7.3	8.3	9.3 11.6	10.3 13.4	11.3 15.2
	RTPF	10.9	11.9	12.9 15.2	13.9 17.0	14.9 18.8
<b>38AUD*14</b>	Liquid Line	$\frac{3}{8}$	$\frac{1}{2}$ $\frac{5}{8}$	$\frac{1}{2}$ $\frac{5}{8}$	$\frac{1}{2}$ $\frac{5}{8}$	$\frac{1}{2}$ $\frac{5}{8}$
	Max Lift					
	SI (m)					
	Novation	7.5	13 15	12 14	11 14	17 20
	EN (ft)					
	Novation	25	45 50	42 49	39 48	56 68
	Suction Line	$\frac{7}{8}$	$\frac{7}{8}$	$\frac{7}{8}$	1– $\frac{1}{8}$	1– $\frac{1}{8}$
	Charge					
	SI (kg)					
	Novation	4.6	5.8 6.6	6.6 7.8	7.6 10.7	9.4 12.0
	EN (lbs)					
	Novation	10.1	12.7 14.6	14.5 17.3	16.8 23.5	20.7 26.4
<b>Legend:</b>						
Equivalent Length	Equivalent tubing length, including effects of refrigeration specialties devices					
Linear Length	Linear tubing length, feet					
Liquid Line	Tubing size, inches OD.					
Max Lift	Maximum liquid lift (indoor unit ABOVE outdoor unit only), at maximum permitted liquid line pressure drop • Linear Length Less than 30 m (100 ft): Minimum 1.1° C (2.0° F) subcooling entering TXV • Linear Length Greater than 30 m (100 ft): Minimum 0.3° C (0.5° F) subcooling entering TXV					
Suction Line	Tube size, inches OD					
Charge	Charge Quantity, lbs. Calculated for both liquid line sizes (where applicable), but only with larger suction line size (where applicable)					
DNU	Do Not Use (pressure drop exceeds available subcooling in this model)					
NR	Not Recommended (use smaller liquid tube size)					
SI	Metric units of measure					
EN	English units of measure (I–P)					
<b>NOTE:</b>	For applications with equivalent length greater than 57 m (188 ft) and/or linear length greater than 38 m (125 ft), contact your local Carrier representative.					

Suction Riser —

A suction riser condition exists when the outdoor unit is located above the indoor (evaporator) unit and suction vapor must flow vertically up to return to the compressor. Oil return is a concern when the suction tube size is too large to produce the minimum refrigerant velocity to ensure oil return at minimum load conditions.

Check Table 7 for maximum suction tube size for 38AU units at minimum load conditions. Consider suction speed riser (reduced tube size for vertical segment only) or double suction riser arrangement if the proposed suction tube size does not provide necessary minimum flowrates for this riser.

Table 7 – 38AU Maximum Suction Pipe Size

Model:	Unit Size	Maximum Tube Size
38AUZ	07	1 <sup>3</sup> / <sub>8</sub>
	08	1 <sup>5</sup> / <sub>8</sub>
38AUD	12	1 <sup>3</sup> / <sub>8</sub>
	14	1 <sup>3</sup> / <sub>8</sub>

Vertical Separation (outdoor unit above indoor unit) –

Vertical elevation difference of 60 m (200 ft) is permitted when the outdoor unit (38AUZ or 38AUD) is located above the indoor unit.

Insulate Suction Lines —

Apply closed-cell tubular insulation to all suction lines between evaporator coil connection and 38AU unit's suction service valve.

Hot Gas Bypass —

Hot gas bypass, if used, should be introduced before the evaporator. (A bypass route that also bypasses the evaporator circuit may lead to oil trapping in the evaporator circuit during low load conditions and then to oil slugging as evaporator load increases.) Model 38AU units do not include a hot gas stub connection; a tee must be field-supplied and installed in the compressor discharge line. Run a 1/2-in OD line between outdoor unit and evaporator coil inlet. Install an Auxiliary Side Connector at the evaporator between TXV and distributor (follow instructions for the side connector part). Insulate the hot gas line.

**38AUD:** Generally only one hot gas bypass system will be applied on a two-circuit unit. Connect the hot gas bypass system to Circuit 1 (first-on/last-off, connected to the evaporator coil's bottom circuit).


38AUD Piping Connections —

The 38AUD's two circuits are designated Circuit 1 and Circuit 2. Circuit 1 is controlled by the thermostat's Y1 (or TC1) contact and will be the first circuit on and last circuit off. Circuit 2 is controlled by the thermostat's Y2

(or TC2) contact and this circuit is always the "lag" circuit.

See Fig. 5 for location of Circuit 1 and Circuit 2 service valves and field piping connections. Circuit 1 is on the right-hand side of the service valve compartment; Circuit 2 is on the left.

When a single piece evaporator coil with two separate circuits is connected to a 38AUD, the lower coil circuit should be connected to the 38AUD's Circuit 1 so that the evaporator's lower coil segment is first-on/last-off (to avoid re-evaporation of condensate on dry lower coil segments).



C10912

Fig. 5 - 38AUD Service Valve Locations


Plan the Circuit 1 and Circuit 2 tubing segments carefully, mark each segment and check constantly as piping systems are assembled to avoid piping errors.

38AUD unit cannot be field-piped as a single-circuit/tandem system.

**Connecting 40RU to 38AUD:** The 40RU fan coil in sizes 12, 14 and 16 is a face-split coil design that also has its circuits designated as 1 and 2. See Fig. 6. Note that the lower coil segment changes as the arrangement of the 40RU changes. In a vertical arrangement, the 40RU's lower coil segment is segment 2; this segment should be connected to the 38AUD's Circuit 1. In a horizontal arrangement, the 40RU's lower segment is now segment 1; this segment should be connected to the 38AUD's Circuit 1.

Note that refrigerant suction piping should be insulated.

40RU Arrangement	Cooling Stage	40RU Coil Segment	Connect to 38AUD
Vertical	Y1	2	Circuit 1 Circuit 2
	Y2	1	
Horizontal	Y1	1	Circuit 1 Circuit 2
	Y2	2	



C10071

**Fig. 6 - Typical Evaporator Coil Connections (40RU)****Install Filter Drier(s) and Moisture Indicator(s) —**

Every unit **MUST** have a filter drier in the liquid line. 38AUD models require two filter driers (one in each liquid line). Locate the filter drier(s) at the indoor unit, close to the evaporator coil's thermal expansion valve (TXV) inlets.

38AU units include one (38AUZ) or two (38AUD) Puron-duty filter drier(s), shipped in cartons attached to the unit basepan. Remove the filter drier(s) and prepare to install in the liquid line(s) at the evaporator coil. Do not remove connection fitting plugs until ready to connect and braze the filter drier into the liquid line position.

**Table 8 – Puron-duty Filter Drier(s)**

Model-Size	Qty	Liquid Line OD	Desiccant Volume	Part Number Ref
38AUZ*07	1	3/8-in	8 cu. in.	KH43LG091
38AUZ*08	1	1/2-in	16 cu. in.	KH43LG085
38AUD*12	2	3/8-in	8 cu. in.	KH43LG091
38AUD*14	2	1/2-in	16 cu. in.	KH43LG085

**Table 9 – Refrigerant Specialties Part Numbers**

LIQUID LINE SIZE (in.)	LIQUID LINE SOLENOID VALVE (LLSV)	LLSV COIL	SIGHT GLASS	FILTER DRIER
3/8	EF680033	EF680037	KM680008	provided with unit see Table 8
1/2	EF680035	EF680037	KM680004	



38AUD units require TWO sets of parts.

Installation of liquid line moisture indicating sightglass in each circuit is recommended. Locate the sightglass(es) between the outlet of the filter drier and the TXV inlet.

Refer to Table 9 for recommendations on refrigeration specialties.

In some applications, depending on space and convenience requirements, it may be desirable to install 2 filter driers and sight glasses in a single circuit application. One filter drier and sight glass may be installed at A locations (see Fig. 7) or 2 filter driers and sight glasses may be installed at B locations (see Figs. 7 and 8).


Select the filter drier for maximum unit capacity and minimum pressure drop. Complete the refrigerant piping from the indoor unit to the outdoor unit before opening the liquid and suction lines at the outdoor unit.

Single Circuit Coil Piping Configuration  
For single compressor condensing unitsDual Circuit Coil Piping Configuration  
For single compressor condensing units

C10202

**Fig. 7 - Location of Sight Glass(es) and Filter Driers  
Typical 38AUZ Systems**





C10072

**Fig. 8 - Location of Sight Glasses and Filter Driers  
Typical 38AUD Systems**

### Install Liquid Line Solenoid Valve —

It is recommended that a solenoid valve be placed in the main liquid line (see Figs. 7 & 8) between the condensing unit and the evaporator coil. Locate the solenoid valve at the outlet end of the liquid line, near the evaporator coil connections, with flow direction arrow pointed at the evaporator coil. Refer to Table 9. (A liquid line solenoid valve is required when the liquid line length exceeds 23 m [75 ft].) This valve prevents refrigerant migration (which causes oil dilution) to the compressor during the off cycle, at low outdoor ambient temperatures.

**Solenoid drop control wiring:** control the power to the liquid line solenoid through a Solenoid Valve Relay (SVR) in all units. Use part number HN61PC005 (field-supplied, installed). 38AUZ unit requires one SVR; 38AUD unit requires two relays.

38AUD units also require a separate control power transformer for the liquid solenoid valve loads. Use transformer part number HT01BD602, according to unit power supply.

Mount the SVR (and transformer TRAN3 when used) in unit control box. Connect per wiring schematic label on unit or per Fig. 24 (38AUZ) or Fig. 25 (38AUD).

**Capacity Control Liquid Line Solenoid Valve:** Evaporator capacity staging control via direct thermostat control of a liquid solenoid valve on the evaporator's second stage circuit is not possible with 38AU models. If this installation is a retrofit for a unit that included automatic pressure-operated unloading, check the existing thermostat and liquid solenoid valve wiring for possible direct thermostat control of a solenoid valve; re-wire per Figs. 12 or 13 and 24 or 25.

### Selecting an Accumulator —


Because all 38AU models use scroll compressors, an accumulator is not required. If an accumulator is to be added, check the accumulator manufacturer's literature

carefully for indication of its suitability for use with R-410A; look for minimum working pressure of 1380 kPa (200 psig). Select the accumulator first on the basis of its cataloged minimum capacity (tons) to ensure oil return from the accumulator, then on tube size or holding capacity.

### Make Piping Connections —

Piping connections at the 38AU unit are ball valves with stub tube extensions. Do not open the unit service valves until all interconnecting tube brazing has been completed.

The stub tube connections include 1/4-in SAE service fittings with Schrader valve cores (see Fig. 9). Before making any brazed connections to the unit service valves, remove both Schrader valve caps and cores and save for re-installation. Connect a source for nitrogen to one of these service fittings during tube brazing to prevent the formation of copper oxides inside the tubes at brazed joints.



C10203

**Fig. 9 - Typical Piping Connection Assembly**

When connecting the field tubing to the 38AU service valves, wrap the valves in wet rags to prevent overheating.

Pressure-test all joints from outdoor unit connections over to the evaporator coil, using nitrogen as pressure and with soap-and-bubbles.

When pressure-testing is completed, remove the nitrogen source at the outdoor unit service valves and re-install the two Schrader valve cores. Torque the cores to 23-34 N-cm (2-3 in-lbs).

### Evacuation/Dehydration —

Evacuate and dehydrate the connected refrigeration system(s) (excluding the 38AU unit) to 500 microns using a two-stage vacuum pump attached to the service ports outside the 38AU service valves, following description in GTAC II, Module 4, System Dehydration.

## ⚠ WARNING

### UNIT OPERATION AND SAFETY HAZARD

Failure to follow this warning could cause personal injury, death and/or equipment damage.

Puron® (R-410A) refrigerant systems operate at higher pressure than standard R-22 systems. Do not use R-22 service equipment or components on Puron refrigerant equipment.



This unit is designed for use with Puron (R-410A) refrigerant. Do not use any other refrigerant in this system.

Puron (R-410A) refrigerant is provided in pink (rose) colored cylinders. These cylinders are available with and without dip tubes; cylinders with dip tubes will have a label indicating this feature. For a cylinder with a dip tube, place the cylinder in the upright position (access valve at the top) when removing liquid refrigerant for charging. For a cylinder without a dip tube, invert the cylinder (access valve on the bottom) when removing liquid refrigerant.

Because Puron (R-410A) refrigerant is a blend, it is strongly recommended that refrigerant always be removed from the cylinder as a liquid. Admit liquid refrigerant into the system in the discharge line. If adding refrigerant into the suction line, use a commercial metering/expansion device at the gauge manifold; remove liquid from the cylinder, pass it through the metering device at the gauge set and then pass it into the suction line as a vapor. Do not remove Puron (R-410A) refrigerant from the cylinder as a vapor.

### **Preliminary Charge —**

Before starting the unit, charge R-410A liquid refrigerant into the high side of each 38AU circuit through the liquid service valve(s). The amount of refrigerant added must be at least 80% of the operating charge listed in Tables 5 or 6 for LINEAR line length LESS the factory charge quantity (if factory shipping charge has not been removed). See example below.

Allow high and low side pressures to equalize. If pressures do not equalize readily, charge R-410A vapor (using special service manifold with expansion device) into the suction line service port for the low side of system to assure charge in the evaporator. Refer to GTAC II, Module 5, Charging, Recover, Recycling, and Reclamation for liquid charging procedures.

Example (using Tables 5 and 6):

Unit 38AUZA08 with Novation coil

Linear line length 25 m

Estimated equivalent line length 37 m (add 50% to linear length)

Liquid lift 8 m (indoor unit above outdoor unit)

See Table 5, 38AUZ models, for line sizes and system operating charge. Enter table in Equivalent Length column for 34-46 m.

Liquid line size: Note that a DNU code (Do Not Use) applies to 1/2-in. OD tube with Novation coil option for unit 38AUZ\*08. Check liquid lift capability of 5/8-in OD tube against project requirements. Table 5 indicates 5/8-in tube allows 10 m lift which exceeds job requirements. (Note: If maximum liquid lift value is not greater than project requirements, STOP. Select a new location for the outdoor unit that reduces lift and/or length requirements or select a unit model with RTPF coil option.)

Suction line size: Select 1-1/8-in. OD tube for this line length.

Note Operating Charge quantity: 9.9 kg.

### **Start-up Charge Calculation**

Target start-up charge quantity is 80% of Operating Charge quantity:

Start-up Charge =  $0.80 \times 9.9 = 7.9$  kg (use for recharge situation)

Deduct Shipping Charge if still available (new unit installation):

Shipping Charge (from Table 1A): 2.2 kg

Field-Add for Start-up:  $7.9 - 2.2 = 5.7$  kg (use for new unit installation)

### **EN Units:**

38AUZA08 with Novation coil

Linear length 82 ft

Equivalent length 123 ft

Liquid lift 25 ft

Select liquid line as 5/8-in OD, suction line as 1-1/8-in OD.

Note Operating Charge quantity: 21.9 lbs

### **Start-up Charge Calculation**

Target start-up charge quantity is 80% of Operating Charge quantity:

Start-up Charge =  $0.80 \times 21.9 = 17.5$  lbs (use for recharge situation)

Deduct Shipping Charge if still available (new unit installation):

Shipping Charge (from Table 2A): 4.6 lbs

Field-Add for Start-up:  $17.5 - 4.6 = 12.9$  lbs (use for new unit installation)

## Step 6 — Install Accessories

Accessories requiring modifications to unit wiring should be completed now. These accessories may include Winter Start controls and Low Ambient controls. Refer to the instructions shipped with the accessory.

## Step 7 — Complete Electrical Connections

### ⚠ WARNING

#### ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death.

Do not use gas piping as an electrical ground. Unit cabinet must have an uninterrupted, unbroken electrical ground to minimize the possibility of personal injury if an electrical fault should occur. This ground may consist of electrical wire connected to unit ground lug in control compartment, or conduit approved for electrical ground when installed in accordance with local electrical codes or in absence of local codes, it is recommended that the U.S.A. standard ANSI/NFPA 70, National Electrical Code (NEC), be followed.

**NOTE:** Check all factory and field electrical connections for tightness. Field-supplied wiring shall conform with the limitations of 33°C (63°F) rise.

#### Field Power Supply —

Field power wires are connected to the unit at line-side pressure lugs on compressor contactor C and TB1 (see wiring diagram label for control box component arrangement) or at factory-installed option non-fused disconnect switch. Max wire size is #4 AWG (copper only).


**NOTE:** TEST LEADS - Unit may be equipped with short leads (pigtailed) on the field line connection points on contactor C or optional disconnect switch. These leads are for factory run-test purposes only; remove and discard before connecting field power wires to unit connection points. Make field power connections directly to line connection pressure lugs only.

### ⚠ WARNING

#### FIRE HAZARD

Failure to follow this warning could cause in personal injury, death and/or equipment damage.

Do not connect aluminum wire between disconnect switch and condensing unit. Use only copper wire. (See Fig. 10.)



A93033

Fig. 10 - Disconnect Switch and Unit

#### Units Without Factory-Installed Disconnect —

When installing units, provide a disconnect switch of adequate size per local or national wiring code. Disconnect sizing data is provided on the unit informative plate. Locate on unit cabinet or within sight of the unit per national or local codes. Do not cover unit informative plate if mounting the disconnect on the unit cabinet.

#### Units with Factory-Installed Disconnect —

The factory-installed option disconnect switch is located in a weatherproof enclosure located under the main control box. The manual switch handle is accessible through an opening in the access panel.

#### All Units —

All field wiring must comply with all local codes. Size wire based on MCA (Minimum Circuit Amps) on the unit informative plate. See Fig. 11 for power wiring connections to the unit load terminals and equipment ground.


Provide a ground-fault and short-circuit over-current protection device (fuse or breaker) per local code (or in absence of local code, it is recommended that U.S.A. standard, NEC Article 440, be followed). Refer to unit informative data plate for MOCP (Maximum Over-current Protection) device size.

All field wiring must comply with the appropriate national electrical codes and local requirements.


Affix the crankcase heater warning sticker to the unit disconnect switch.

Voltage to compressor terminals during operation must be within voltage range indicated on unit nameplate. See Tables 11 and 12. On 3-phase units, voltages between phases must be balanced within 2% and the current within 10%. Use the formula shown in the legend for Tables 11 and 12 Note 3 (see page 21) to determine the percent of voltage imbalance. Operation on improper line voltage or excessive phase imbalance constitutes abuse and may cause damage to electrical components. Such operation would invalidate any applicable Carrier warranty.

### Units Without Disconnect Option



### Units With Disconnect Option



**Fig. 11 - Power Wiring Connections**

C10074

**Table 10 – American/European Wire Conversions**


AMERICAN		EUROPEAN
Industry Standard Size	American Conversion Size (mm <sup>2</sup> )	Industry Standard Size (mm <sup>2</sup> )
20 AWG	0.52	0.5
18 AWG	0.82	1.0
16 AWG	1.30	1.5
14 AWG	2.08	2.5
12 AWG	3.30	4.0
10 AWG	5.25	6.0
8 AWG	6.36	10.0
6 AWG	13.29	16.0
4 AWG	21.14	25.0
3 AWG	26.65	—
2 AWG	33.61	35.0
1 AWG	42.39	50.0
1/0 AWG	53.49	—
2/0 AWG	67.42	70.0
3/0 AWG	85.00	95.0
4/0 AWG	107.9	120.0

### Field Control Wiring —

38AU unit control voltage is 24 v. See Fig. 24 (38AUZ) and Fig. 25 (38AUD) for typical field control connections and the unit's label diagram for field-supplied wiring details. Route control wires to the 38AU unit through the opening in unit's end panel to the connections terminal board in the unit's control box.

Remainder of the system controls connection will vary according to the specific construction details of the indoor section (air handler or packaged fan coil). Fig. 12 (38AUZ) and Fig. 13 (38AUD) depict typical connections to a Carrier 40RU fan coil unit. Plan for field connections carefully and install control wiring correctly per the project plan. Additional components and supplemental transformer accessory may be required.


The 38AU unit requires an external temperature control device. This device can be a thermostat (field-supplied) or a PremierLink controller (available as a field-installed accessory, for use on a Carrier Comfort Network or as a stand alone control).



Note 1: Connect only if thermostat requires 24-vac power source.  
Note 2: Connect W1 and W2 if supplemental heaters are installed  
--- Field Wiring

C10985

**Fig. 12 - Typical Remote Thermostat Connections — 38AUZ**



Note 1: Typical multi-function marking. Follow manufacturer's configuration instructions to select Y2.  
Note 2: Connect only if thermostat requires 24-vac power source.  
Note 3: Connect W1 and W2 if supplemental heaters are installed  
--- Field Wiring

C10078

**Fig. 13 - Typical Remote Thermostat Connections — 38AUD**

38AU

### Thermostat —

Install a Carrier-approved accessory thermostat according to installation instructions included with the accessory. Locate the thermostat accessory on a solid wall in the conditioned space to sense average temperature in accordance with the thermostat installation instructions.

**38AUZ Unit -** 38AUZ unit is a single-stage cooling unit. If no economizer function is required, select a single-stage cooling thermostat. If an integrated economizer function is required, select a two-stage cooling thermostat.

The 38AUD is a dual-circuit, two-stage cooling unit. Select a two—stage cooling thermostat.

Select a thermostat cable or equivalent single leads of different colors with minimum of four leads for 38AUZ or five leads for 38AUD unit. Check the thermostat installation instructions for additional features which might require additional conductors in the cable.

For wire runs up to 15 m (50 ft.), use no. 18 AWG (American Wire Gage) insulated wire (35°C minimum). For 15 to 23 m (50 to 75 ft.), use no. 16 AWG insulated wire (35°C minimum). For over 23 m (75 ft.), use no. 14 AWG insulated wire (35°C minimum). All wire sizes larger than no. 18 AWG cannot be directly connected to the thermostat and will require a junction box and splice at the thermostat.


**PremierLink (accessory installation) –** Refer to Form 33CS-58SI for details on connecting the PremierLink controller and its various sensors.

### Control Circuit Wiring —

Control voltage is 24 v. See Fig. 24 and Fig. 25 and the unit's label diagram for field-supplied wiring details. Route control wires through the opening in unit's end panel to the connection in the unit's control box.

### Control Transformer Wiring —

On multi voltage units, check the transformer primary wiring connections. See Fig. 14 or refer to the unit's label diagram.



**Fig. 14 - Control Transformer Wiring**

C10079

**Table 11 – Electrical Data — 38AUZ\*07-14 50 Hz Units**

UNIT	V-Ph-Hz	VOLTAGE RANGE <sup>‡</sup>		COMPRESSOR 1		OFM		POWER SUPPLY		DISCONNECT SIZE	
		MIN	MAX	RLA	LRA	QTY	FLA	MCA	Fuse	FLA	LRA
<b>38AUZ*07</b>	400-3-50	360	440	9.7	64	2	.07	13.5	20	13	68
<b>38AUZ*08</b>	400-3-50	360	440	12.2	100	2	.07	16.7	25	16	104

**NOTE:** See “Legend and Notes for Tables 11 & 12”

**Table 12 – Electrical Data — 38AUD\*12-14 50 Hz Units**

UNIT	V-Ph-Hz	VOLTAGE RANGE <sup>‡</sup>		COMPRESSOR 1		COMPRESSOR 2		OFM (ea)		POWER SUPPLY		DISCONNECT SIZE	
		MIN	MAX	RLA	LRA	RLA	LRA	QTY	FLA	MCA	Fuse	FLA	LRA
<b>38AUD*12</b>	400-3-50	360	440	7.8	52	7.8	52	2	0.7	19.0	25	20	108
<b>38AUD*14</b>	400-3-50	360	440	10.6	74	10.6	74	2	0.7	25.3	30	26	152

**NOTE:** See “Legend and Notes for Tables 11 & 12”

**Legend and Notes for Tables 11 and 12**

**LEGEND:**

- FLA – Full Load Amps
- LRA – Locked Rotor Amps
- MCA – Minimum Circuit Amps Protection
- NEC – National Electrical Code
- RLA – Rated Load Amps



<sup>‡</sup> Units are suitable for use on electrical systems where voltage supplied to the unit terminals is not below or above the listed limits.

**NOTES:**

1. The MCA and Fuse values are calculated in accordance with The NEC, Article 440.
2. Motor RLA and LRA values are established in accordance with Underwriters' Laboratories (UL). Standard 1995.
3. **Unbalanced 3-Phase Supply Voltage**  
Never operate a motor where a phase imbalance in supply voltage is greater than 2%. Use the following formula to determine the percentage of voltage imbalance.

Example: Supply voltage is 400-3-50

$$\% \text{ Voltage Imbalance} = 100 \times \frac{\text{max voltage deviation from average voltage}}{\text{average voltage}}$$



AB = 394 v  
BC = 401 v  
AC = 396 v

$$\text{Average Voltage} = \frac{(394 + 401 + 396)}{3} = \frac{1191}{3} = 397$$

Determine maximum deviation from average voltage.

(AB) 397 – 394 = 3 v

(BC) 401 – 397 = 4 v

(AC) 397 – 396 = 1 v

Maximum deviation is 4 v.

Determine percent of voltage imbalance.

$$\begin{aligned} \% \text{ Voltage Imbalance} &= 100 \times \frac{4}{397} \\ &= 1.00\% \end{aligned}$$

This amount of phase imbalance is satisfactory as it is below the maximum allowable 2%.

**IMPORTANT:** If the supply voltage phase imbalance is more than 2%, contact your local electric utility company immediately.

## PRE-START-UP

**IMPORTANT:** Before beginning Pre-Start-Up or Start-Up, review Start-Up Checklist at the back of this book. The Checklist assures proper start-up of a unit and provides a record of unit condition, application requirements, system information, and operation at initial start-up.

### ⚠ CAUTION

#### UNIT DAMAGE HAZARD

Failure to follow this caution may result in equipment damage.

Do not attempt to start the condensing unit, even momentarily, until the following steps have been completed. Compressor damage may result.

### System Check

1. The electrical power source must agree with the unit's nameplate rating.
2. Check all air handler(s) and other equipment auxiliary components. Consult the manufacturer's instructions regarding any other equipment connected to the condensing unit. If the unit has field-installed accessories, be sure all are properly installed and correctly wired. If used, the airflow switch must be properly installed.
3. Check tightness of all electrical connections.
4. Be sure liquid line and low side of the system are properly leak checked and dehydrated.
5. Be sure the unit is properly charged. See "Preliminary Charge", below.
6. Open the liquid line and suction line service valves.
7. The crankcase heater must be firmly attached to the compressor crankcase. Be sure the crankcase is warm (heater must be on for 24 hours before starting compressor).

### Turn On Crankcase Heater —

*Turn on the crankcase heater for 24 hours before starting the unit to be sure all the refrigerant is out of the oil. To energize the crankcase heater, proceed as follows:*

1. Set the space thermostat set point above the space temperature so there is no demand for cooling.
2. Close the field disconnect.

### Preliminary Charge —

Before starting the unit, charge liquid refrigerant into the high side of the system through the liquid service valve. The amount of refrigerant added must be at least 80% of the operating charge listed in the Physical Data table (Tables 1A through 2B, pages 5 through 8). Allow high and low side pressures to equalize before starting compressor. If pressures do not equalize readily, charge vapor on low side of system to assure charge in the evaporator. Refer to GTAC II, Module 5, Charging, Recover, Recycling, and Reclamation for liquid charging procedures.

### ⚠ CAUTION

#### UNIT DAMAGE HAZARD

Failure to follow this caution may result in equipment damage.

Prior to starting compressor, a preliminary charge of refrigerant must be added to avoid possible compressor damage.

## START-UP

**38AU Units:** The compressor crankcase heater must be on for 24 hours before start-up. After the heater has been on for 24 hours, the unit can be started. If no time elapsed since the preliminary charge step was completed, it is unnecessary to wait the 24-hour period.

### Preliminary Checks

1. Check that electric power supply agrees with unit nameplate data.
2. Verify that the compressor crankcase heater is securely in place.
3. Check that the compressor crankcase heater has been on at least 24 hours.
4. Recheck for leaks using the procedure outlined in the Pre-Start-Up section, Leak Test and Dehydration. If any leaks are detected, repair as required. Evacuate and dehydrate as described in the Leak Test and Dehydration section.
5. Ensure that the preliminary charge has been added as described in the Pre-Start-Up section, Preliminary Charge.
6. All internal wiring connections must be tight, and all barriers and covers must be in place.

**NOTE:** The 38AU units are factory charged with the required amount of oil. If recharging is required, use Emkarate RL 32-3MAF for the 38AU units.

### Compressor Rotation —

On 3-phase units with scroll compressors, it is important to be certain that the compressor is rotating in the proper direction. 38AU units are equipped with a Comfort Alert Diagnostic Module (CADM). Alert Code 7 indicates reverse power phasing.

### To correct phase order:

1. Turn off power to the unit, tag disconnect.
2. Reverse any two of the unit power leads.
3. Reapply power to the compressor, verify correct pressures.

### To verify the compressor is rotating in the proper direction:

1. Connect service gages to the suction and liquid pressure fittings.
2. Energize the compressor.
3. The suction pressure should drop and the liquid pressure should rise, as is normal on any start-up.

### Compressor Overload —

This overload interrupts power to the compressor when either the current or internal motor winding temperature becomes excessive, and automatically resets when the internal temperature drops to a safe level. This overload may require up to 60 minutes (or longer) to reset. If the internal overload is suspected of being open, disconnect the electrical power to the unit and check the circuit through the overload with an ohmmeter or continuity tester.


### Advanced Scroll Temperature Protection (ASTP) —

A label located above the terminal box identifies Copeland Scroll compressor models that contain this technology. See Fig. 15. Advanced Scroll Temperature Protection (ASTP) is a form of internal discharge temperature protection, that unloads the scroll compressor when the internal temperature reaches approximately 149°C (300°F). At this temperature, an internal bi-metal disk valve opens and causes the scroll elements to separate, which stops compression. Suction and discharge pressures balance while the motor continues to run. The longer the compressor runs unloaded, the longer it must cool before the bi-metal disk resets. See Fig. 16.



C10080

Fig. 15 - Advanced Scroll Temperature Protection Label



\*Times are approximate.

NOTE: Various factors, including high humidity, high ambient temperature, and the presence of a sound blanket will increase cool-down times.

C10081

Fig. 16 - Recommended Minimum Cool-Down Time After Compressor is Stopped

To manually reset ASTP, the compressor should be stopped and allowed to cool. If the compressor is not stopped, the motor will run until the motor protector trips, which occurs up to 90 minutes later. Advanced Scroll Temperature Protection will reset automatically before the motor protector resets, which may take up to 2 hours.

### Start Unit

Set the space thermostat to a set point above space temperature so that there is no demand for cooling. Close the 38AU disconnect switch. Only the crankcase heater will be energized.

Reset the space thermostat below ambient so that a call for cooling is ensured.

**⚠ CAUTION**

**UNIT DAMAGE HAZARD**

Failure to follow this caution may result in equipment damage.

Never charge liquid into the low-pressure side of system. Do not overcharge. During charging or removal of refrigerant, be sure indoor-fan system is operating. Ensure both outdoor fan motors are running; bypass any Motormaster function.

38AU

### Adjust Refrigerant Charge —


Refer to Cooling Charging Charts, Fig. 17 through Fig. 23. For applications with line lengths greater than 125 ft (38 m), contact Carrier representative. Vary refrigerant until the conditions of the chart are met. Note that the charging charts are different from the type normally used. The charts are based on charging the units to the correct subcooling for the various operating conditions. Accurate pressure gage and temperature sensing device are required. Connect the pressure gage to the service port on the liquid line service valve. Mount the temperature sensing device on the liquid line close to the liquid line service valve, and insulate it so that outdoor ambient temperature does not affect the reading. Indoor airflow must be within the unit's normal operating range. Operate the unit for a minimum of 15 minutes. Ensure that pressure and temperature readings have stabilized. Plot the liquid pressure and temperature on chart and add or reduce the charge to meet the curve. Adjust the charge to conform with the charging chart, using the liquid pressure and temperature to read the chart.

#### Using plotted operating point:

If plotted operating condition is -	Adjust charge by -
BELOW the curve	REDUCE charge
ABOVE the curve	ADD charge


### Final Checks —

Ensure that all safety controls are operating, control panel covers are on, and the service panels are in place.



C101050

**Fig. 17 - 38AUZ\*07 Charging Chart (Novation)**



C101051

**Fig. 18 - 38AUZ\*08 Charging Chart (Novation)**







Fig. 19 - 38AUD\*12 Charging Chart (Novation)


## 12.5 TON CHARGING CHART PURON ALL CONDENSER FANS OPERATING

12.5 TONNE TABLEAU DE CHARGE PURON  
TOUTES LES SOUFFLERIES DE CONDENSATION EN FONCTIONNEMENT  
(CIRCUIT 1)



## 12.5 TON CHARGING CHART PURON ALL CONDENSER FANS OPERATING


12.5 TONNE TABLEAU DE CHARGE PURON  
TOUTES LES SOUFFLERIES DE CONDENSATION EN FONCTIONNEMENT  
(CIRCUIT 2)



38AU500809


A

Fig. 20 - 38AUD\*14 Charging Chart (Novation)





**Fig. 21 - 38AUZ\*07 Charging Chart (RTPF)**

C101054



**Fig. 22 - 38AUZ\*08 Charging Chart (RTPF)**

C101055





38AU501103

-

Fig. 23 - 38AUD\*12 Charging Chart (RTPF)

SCHEMATIC  
6-7.5T 400V-50HZ SNGL



- FIELD CONTROL WIRING**
- △ FIELD SPICE
  - (X) MARKED WIRE
  - (X) TERMINAL (MARKED)
  - TERMINAL (UNMARKED)
  - [X] TERMINAL BLOCK
  - SPICE
  - FACTORY WIRING
  - - FIELD CONTROL WIRING
  - - - FIELD POWER WIRING
  - - - - ACCESSORY OR OPTIONAL WIRING
  - TO INDICATE COMMON POTENTIAL ONLY, NOT TO REPRESENT WIRING

**LEGEND**


- C CONTACTOR, COMPRESSOR
- CAP CAPACITOR
- CADM COMFORT ALERT - DIAGNOSTICS MODULE
- CH CRANKCASE HEATER
- COMP COMPRESSOR MOTOR
- FU FUSE
- GR GROUND
- HPS HIGH PRESSURE SWITCH
- LLSV LIQUID LINE SOLENOID VALVE
- LPS LOW PRESSURE SWITCH
- OFM OUTDOOR FAN MOTOR
- OFR OUTDOOR FAN RELAY
- QT QUADRUPLE TERMINAL
- SVR SOLENOID VALVE RELAY
- TB TERMINAL BLOCK
- TDR TIME DELAY RELAY
- TRAN TRANSFORMER

**NOTES:**

1. IF ANY OF THE ORIGINAL WIRE FURNISHED MUST BE REPLACED, IT MUST BE REPLACED WITH TYPE 90 C WIRE OR ITS EQUIVALENT.
2. USE COPPER CONDUCTORS ONLY.
3. COMPRESSORS AND FAN MOTORS ARE THERMALLY PROTECTED. THREE PHASE MOTORS ARE PROTECTED AGAINST PRIMARY SINGLE PHASING CONDITIONS.
4. TRANSFORMER IS WIRED FOR 400V UNIT.
5. ON UNITS WITH SPEED CONTROL, REMOVE OFM1 AND OFM2 BLK WIRES FROM COMPRESSOR CONTACTOR TERMINAL 21 AND CONNECT TO BLK WIRES FROM SPEED CONTROL.

38AU

**Fig. 24 - Typical 38AUZ Wiring Diagram**



## FIELD CONTROL

- WIRING
- △ FIELD SPLICE
- (Y) MARKED WIRE
- (X) TERMINAL (MARKED)
- TERMINAL (UNMARKED)
- [X] TERMINAL BLOCK
- SPLICE
- FACTORY WIRING
- - FIELD CONTROL WIRING
- FIELD POWER WIRING
- ACCESSORY OR OPTIONAL WIRING
- TO INDICATE COMMON  
POTENTIAL ONLY, NOT  
TO REPRESENT WIRING

LEGEND

C	CONTACTOR, COMPRESSOR
CAP	CAPACITOR
CADM	COMFORT ALERT - DIAGNOSTICS MODULE
CH	CRANKCASE HEATER
COMP	COMPRESSOR MOTOR
EQUIP	EQUIPMENT
FU	FUSE
GR	GROUND
HPS	HIGH PRESSURE SWITCH
LLSV	LIQUID LINE SOLENOID VALVE
LPS	LOW PRESSURE SWITCH
OFM	OUTDOOR FAN MOTOR
OFR	OUTDOOR FAN RELAY
QT	QUADRUPEL TERMINAL
SVR	SOLENOID VALVE RELAY
TB	TERMINAL BLOCK
TDR	TIME DELAY RELAY
TRAN	TRANSFORMER

NOTES:

1. IF ANY OF THE ORIGINAL WIRE FURNISHED MUST BE REPLACED, IT MUST BE REPLACED WITH #12 90 C WIRE OR ITS EQUIVALENT.
2. USE COPPER CONDUCTORS ONLY.
3. COMPRESSORS AND FAN MOTORS ARE THERMALLY PROTECTED. THREE PHASE MOTORS ARE PROTECTED AGAINST PRIMARY SINGLE PHASING CONDITIONS.
4. TRANSFORMER IS WIRED FOR 400V UNIT.
5. ON UNITS WITH SPEED CONTROL, REMOVE OFM1 AND OFM2 BLK WIRES FROM OFR AND CONNECT TO BLK WIRES FROM SPEED CONTROL.

### Fig. 25 - Typical 38AUD Wiring Diagram

# OPERATING SEQUENCE

## Base Unit Controls

### Indoor (Supply) Fan —

The indoor fan contactor (IFC) is remotely located at the fan coil or fan section. If the thermostat fan operation is selected as Continuous, the IFC is energized and the indoor (supply) fan motor runs continuously. If the thermostat fan operation is selected as Automatic, the IFC will be energized on a call for Cooling; indoor (supply) fan motor runs. When thermostat call for Cooling is satisfied, the IFC is de-energized and indoor (supply) fan motor stops.

### Cooling, Unit Without Economizer —

#### 38AUZ (Single Circuit)

On a thermostat call for Cooling, IFC will be energized and indoor (supply) fan motor runs. Thermostat output Y1 is energized; terminal Y1 at 38AUZ unit receives 24-v. 24-v received at CADM1 terminal Y. If anti-recycle time delay period has not expired, CADM1 relay will remain open, de-energizing Solenoid Valve Relay (SVR) and preventing compressor start. When safety pressure switches are closed and CADM1 time delay expires, CADM1 relay closes, SVR and compressor contactor C are energized; liquid line solenoid valve LLSV opens, all outdoor fan motors start and Compressor starts.

As space cooling load is satisfied, thermostat output Y1 is de-energized, removing 24-v at 38AUZ terminal Y1. On Y1 opening, Compressor stops, all outdoor fan motors stop and SVR relay is de-energized. Liquid line solenoid valve is de-energized and valve closes. CADM1 begins its three-minute anti-recycle time delay.

#### 38AUD (Two Circuit)

On a thermostat call for Cooling, IFC will be energized and indoor (supply) fan motor runs. Thermostat output Y1 is energized; terminal Y1 at 38AUD unit receives 24-v. 24-v received at CADM1 terminal Y. If anti-recycle time delay period has not expired, CADM1 relay will remain open, de-energizing Solenoid Valve Relay 1 (SVR1) and preventing compressor start. When safety pressure switches are closed and CADM1 time delay expires, CADM1 relay closes, SVR1 and compressor contactor C1 are energized; liquid line solenoid valve LLSV1 opens, all outdoor fan motors start and Circuit 1 compressor starts.

On a thermostat calling for Stage 2 Cooling, thermostat output Y2 is energized; terminal Y2 at 38AUD unit receives 24-v. 24-v received at CADM2 terminal Y. If anti-recycle time delay period has not expired, CADM2 relay will remain open, de-energizing Solenoid Valve Relay 2 (SVR2) and preventing compressor start. When safety pressure switches are closed and CADM2 time delay expires, CADM2 relay closes, SVR2 and compressor contactor C2 are energized; liquid line solenoid valve LLSV2 opens and Circuit 2 compressor starts.

As space cooling load is satisfied, thermostat outputs Y2 and Y1 are de-energized, removing 24-v at 38AUD terminals Y2 and Y1. Circuit 2 compressor stops on Y2 opening; SVR2 is de-energized and LLSV2 closes. CADM2 begins its three-minute anti-recycle time delay. On Y1 opening, Circuit 1 compressor stops, all outdoor fan motors stop and SVR1 relay is de-energized. Liquid line solenoid valve LLSV1 is de-energized and valve closes. CADM1 begins its three-minute anti-recycle time delay.

### All Units

If either the Low Pressure Switch or High Pressure Switch opens while thermostat output Y1 or Y2 remain energized, the compressor contactor is de-energized, the compressor stops and liquid line solenoid is de-energized (valve closes). CADM initiates a TRIP event (cooling demand sensed at CADM terminal Y but no current is measured at T1, T2, T3 motor sensors); CADM relay opens and RED LED is illuminated. TRIP condition maintains lockout of compressor operation until CADM is manually reset. Reset CADM by cycling unit main power.

Complete system shutdown may be caused by loss of main power, open compressor internal overload, open low-pressure or high-pressure switch, or a fault detected by the CADM logic. Compressor operation without cooling may indicate the compressor's ASTP feature is active; disconnect unit power and allow compressor to cool. See Service section for further details.

### Cooling, Unit With Economizer —

Refer to fan coil unit installation instructions and economizer accessory installation instructions for operating sequences when system is equipped with accessory economizer.

### Heating —

Refer to fan coil unit installation instructions and accessory heating device installation instructions for operating sequences in heating mode.

## ROUTINE SYSTEM MAINTENANCE

These items should be part of a routine maintenance program, to be checked every month or two, until a specific schedule for each can be identified for this installation:

### Quarterly Inspection (and 30 days after initial start) —

#### Indoor section

- Condenser coil cleanliness checked.
- Return air filter replacement
- Outdoor hood inlet filters cleaned
- Belt tension checked
- Belt condition checked
- Pulley alignment checked
- Fan shaft bearing locking collar tightness checked
- Condensate drain checked

#### Seasonal Maintenance —

These items should be checked at the beginning of each season (or more often if local conditions and usage patterns dictate):

#### Air Conditioning

- Condenser fan motor mounting bolts tightness
- Compressor mounting bolts
- Condenser fan blade positioning
- Control box cleanliness and wiring condition
- Wire terminal tightness
- Refrigerant charge level
- Evaporator coil cleaning
- Evaporator blower motor amperage

#### Heating

- Power wire connections
- Fuses ready
- Manual-reset limit switch is closed

#### Economizer or Outside Air Damper

- Inlet filters condition
- Check damper travel (economizer)
- Check gear and dampers for debris and dirt

## SERVICE

### Refrigeration System

#### ⚠ CAUTION

##### EQUIPMENT DAMAGE HAZARD

Failure to follow this caution may result in damage to equipment.

This system uses Puron<sup>®</sup> refrigerant which has higher pressures than R-22 and other refrigerants. No other refrigerant may be used in this system. Gage set, hoses, and recovery system must be designed to handle Puron. If you are unsure consult the equipment manufacturer.

### Compressor Oil —

#### ⚠ CAUTION

##### EQUIPMENT DAMAGE HAZARD

Failure to follow this caution may result in damage to equipment.

The compressor in a Puron system uses a polyolester (POE) oil. This oil is extremely hygroscopic, meaning it absorbs water readily. POE oils can absorb 15 times as much water as other oils designed for HCFC and CFC refrigerants. Take all necessary precautions to avoid exposure of the oil to the atmosphere.

### Servicing Systems on Roofs With Synthetic Materials —

POE (polyolester) compressor lubricants are known to cause long term damage to some synthetic roofing materials. Exposure, even if immediately cleaned up, may cause embrittlement (leading to cracking) to occur in one year or more. When performing any service which may risk exposure of compressor oil to the roof, take appropriate precautions to protect roofing. Procedures which risk oil leakage include but are not limited to compressor replacement, repairing refrigerants leaks, replacing refrigerant components such as filter drier, pressure switch, metering device, coil, accumulator, or reversing valve.

#### Synthetic Roof Precautionary Procedure:

1. Cover extended roof working area with an impermeable polyethylene (plastic) drop cloth or tarp. Cover an approximate 3.3 x 3.3 m (10 x 10 ft) area.
2. Cover area in front of the unit service panel with a terry cloth shop towel to absorb lubricant spills and prevent run-offs, and protect drop cloth from tears caused by tools or components.
3. Place terry cloth shop towel inside unit immediately under component(s) to be serviced and prevent lubricant run-offs through the louvered openings in the base pan.
4. Perform required service.
5. Remove and dispose of any oil contaminated material per local codes.



### Liquid Line Filter Drier —

The factory-provided filter drier is specifically designed to operate with Puron<sup>®</sup>. Replace the filter drier with factory-authorized components only with a filter drier with desiccant made from 100% molecular sieve grade XH-11. Filter drier must be replaced whenever the refrigerant system is opened.

When removing a filter drier, use a tubing cutter to cut the drier from the system. **Do not unsweat a filter drier** from the system. Heat from unsweating will release moisture and contaminants from drier into system.

### Field Refrigerant Access Ports —

Field service access to refrigerant pressures is through the access ports located at the service valves (see Figs 29 and 31). These ports are  $\frac{1}{4}$ -in SAE Flare couplings with Schrader check valves and service caps. Use these ports to admit nitrogen to the field tubing during brazing, to evacuate the tubing and evaporator coil, to admit initial refrigerant charge into the low-side of the system and when checking and adjusting the system refrigerant charge. When service activities are completed, ensure the service caps are in place and secure; check for leaks. If the Schrader check valve must be removed and re-installed, tighten to 2-3 in-lbs (23-34 N-cm).

### Factory High-Flow Access Ports —

There are two additional access ports in the system - on the suction tube between the compressor and the suction service valve and on the liquid tube near the liquid service valve (see Figs 30 and 32). These are brass fittings with black plastic caps. The hose connection fittings are standard  $\frac{1}{4}$ -in SAE Male Flare couplings.

The brass fittings are two-piece High Flow valves, with a receptacle base brazed to the tubing and an integral spring-closed check valve core screwed into the base. (See Fig. 26) This check valve is permanently assembled into this core body and cannot be serviced separately; replace the entire core body if necessary. Service tools are available from RCD that allow the replacement of the check valve core without having to recover the entire system refrigerant charge. Apply compressor refrigerant oil to the check valve core's bottom o-ring. Install the fitting body with 96  $\pm$  10 in-lbs (1085  $\pm$  23 N-cm) of torque; do not overtighten.




Fig. 26 - CoreMax Access Port Assembly

C08453

## Comfort Alert Diagnostic Module

The Comfort Alert Diagnostic Module (CADM) monitors and analyzes data from the Copeland Scroll® three-phase compressor and the thermostat demand. The CADM also provides a 3-minute anti-recycle time delay to compressor cycling. Each compressor has a separate CADM module.

The CADM detects causes for electrical and system related failures without any sensors. Flashing LEDs communicate the Alert codes to guide service technicians in accurately and quickly troubleshooting the system and determining root cause for the failure.

Inputs to the CADM include 24-vac power, thermostat Y1 or Y2, compressor contactor coil (common side) and compressor power leads (from the compressor contactor).

Input	Terminal	Voltage
Control Power	R	24-V
Control Common	C	24-V
Cooling	Y	24-V
Contactor Coil	P	24-V
Line A	T1	Line
Line B	T2	Line
Line C	T3	Line

Control of the compressor contactor coil is through a normally-closed (power on the module) contact between terminals P and C.

Communications of status and alert conditions is through three LEDs located on the top edge of the module housing (see Fig. 27): POWER (green), ALERT (yellow), and TRIP (red).

The POWER LED indicates the presence of control power to the CADM.

The ALERT LED indicates an abnormal condition exists in the system through a flash code. The ALERT LED will blink a number of times consecutively, pause and the repeat the process. The number of blinks, defined in Table 13, correlates to a particular abnormal condition; troubleshooting tips are provided for each Alert code. Reset of the ALERT may be automatic or manual. If the fault condition causing the Alert is self-corrected, the Alert code will be removed and the CADM will automatically reset and allow the system to restart normally. Manual reset requires that main power to the 38AU unit be recycled after the cause for the Alert condition has been detected and corrected.




Fig. 27 - CADM Housing/LED Locations

C10086

The TRIP LED indicates either a time-delay period is currently active (RED LED is blinking) or the module has locked out the compressor (RED LED is on steady). A lockout condition will occur when the CADM detects a thermostat demand at input Y but there is no power at the compressor line terminals T1 or T2 or T3. This lockout can occur due to a safety switch (LPS or HPS) opening and de-energizing the compressor contactor, the compressor-motor internal overload opens, or other internal power interruption has occurred. Reset of the TRIP LED requires that unit main power be recycled after the loss of power to the compressor condition has been detected and corrected.

Simultaneous Blinking of YELLOW and RED LEDs indicates control power input to the CADM is low. Check control circuit transformer and wiring.

Troubleshooting the CADM Wiring – Flashing LEDs also indicate wiring problems to the CADM. See Table 14 for discussion of additional LED flash codes and troubleshooting instructions.

**Table 13 – LED Status Codes**

Status LED	Status LED Description	Status LED Troubleshooting Information
Green "POWER"	Module has power	Supply voltage is present at module terminals
Red "TRIP" LED On Solid	Thermostat demand signal Y is present, but the compressor is not running.	<ol style="list-style-type: none"> <li>1. Compressor protector is open</li> <li>2. Condensing unit power disconnect is open</li> <li>3. Compressor circuit breaker or fuse(s) is open</li> <li>4. Broken supply wires or connector is not making contact</li> <li>5. Compressor power wires not routed through Comfort Alert</li> <li>6. Compressor contactor has failed open</li> </ol>
Red "TRIP" LED Flashing	The anti-short cycle timer (3 minutes) in module is preventing compressor restart.  Module locks out compressor when compressor damaging ALERT code appears. Lockout ALERT codes are noted in the Status LED Description. During a compressor lock out, 24VAC power must be removed from module to manually reset.	
Yellow "ALERT" LED On Solid	A short circuit or over current condition exists on PROT terminal.	<ol style="list-style-type: none"> <li>1. Compressor contactor coil shorted</li> <li>2. Electrical load too high for PROT circuit (maximum 1 Amp)</li> <li>3. 24 V AC wired directly to PROT terminal</li> </ol>
Yellow "ALERT" Flash Code 2	System Pressure Trip Discharge pressure out of limits or compressor overload (if no high pressure switch in system) LOCKOUT	<ol style="list-style-type: none"> <li>1. High head pressure</li> <li>2. Condenser coil poor air circulation (dirty, blocked, damaged)</li> <li>3. Condenser fan is not running</li> <li>4. If low pressure switch is open: Refer to Code 3 for troubleshooting</li> </ol>
Yellow "ALERT" Flash Code 3	Short Cycling Compressor is running only briefly (four consecutive cycles of less than three minutes each) LOCKOUT	<ol style="list-style-type: none"> <li>1. If low pressure switch is open:                             <ol style="list-style-type: none"> <li>a. Low refrigerant charge</li> <li>b. Evaporator blower is not running</li> <li>c. Evaporator coil is frozen</li> <li>d. Faulty metering device</li> <li>e. Condenser coil is dirty</li> <li>f. Liquid line restriction (filter drier blocked if present)</li> </ol> </li> <li>2. If high pressure switch is open, go to Flash Code 2 information</li> <li>3. Intermittent thermostat demand signal</li> <li>4. System or control board defective</li> </ol>
Yellow "ALERT" Flash Code 4	Locked Rotor LOCKOUT	<ol style="list-style-type: none"> <li>1. Low line voltage to compressor</li> <li>2. Excessive liquid refrigerant in compressor</li> <li>3. Compressor bearings are seized</li> </ol>
Yellow "ALERT" Flash Code 5	Open Circuit	<ol style="list-style-type: none"> <li>1. Condensing unit power disconnect is open</li> <li>2. Compressor circuit breaker or fuses are open</li> <li>3. Compressor contactor has failed open</li> <li>4. High pressure switch is open and requires manual reset</li> <li>5. Broken supply wires or connector is not making contact</li> <li>6. Unusually long compressor protector reset time due to extreme ambient temperature</li> <li>7. Compressor windings are damaged</li> </ol>
Yellow "ALERT" Flash Code 6	Missing Phase LOCKOUT	<ol style="list-style-type: none"> <li>1. Compressor fuse is open on one phase</li> <li>2. Broken wire or connector on one phase</li> <li>3. Compressor motor winding is damaged</li> <li>4. Utility supply has dropped one phase</li> </ol>
Yellow "ALERT" Flash Code 7	Reverse Phase LOCKOUT	<ol style="list-style-type: none"> <li>1. Compressor running backward due to supply phase reversal</li> </ol>
Yellow "ALERT" Flash Code 8	Welded Contactor Compressor always runs	<ol style="list-style-type: none"> <li>1. Compressor contactor has failed closed</li> <li>2. Thermostat demand signal not connected to module</li> </ol>
Yellow "ALERT" Flash Code 9	Low Voltage Control circuit < 18VAC	<ol style="list-style-type: none"> <li>1. Control circuit transformer is overloaded</li> <li>2. Low line voltage to compressor</li> </ol>

**Table 14 – CADM Troubleshooting**

Miswired Module Indication	Recommended Troubleshooting Action
Green LED is not on, module does not power up	Determine if both R and C module terminals are connected. Verify voltage is present at module's R and C terminals. <b>NOTE:</b> The CADM requires a constant nominal 24VAC power supply. The wiring to the module's R and C terminals must be directly from the control transformer. The module cannot receive its power from another device that will interrupt the 24VAC power supply. See the 38AU Wiring Diagram(s) (Fig. 24 and Fig. 25).
Green LED Intermittent, module powers up only when compressor runs	Determine if R and Y terminals are wired in reverse. Verify module's R and C terminals have a constant source. See "NOTE" above for details on R and C wiring.
TRIP LED is on but system and compressor check OK	Verify Y terminal is wired properly per the 38AU wiring diagram (see Fig. 24 and Fig. 25). Verify voltage at contactor coil falls below 0.5VAC when off. Verify 24VAC is present across Y and C when thermostat demand signal is present. If not, R and C are reverse wired.
TRIP LED and ALERT LED flashing together	Verify R and C terminals are supplied with 19-28VAC.
ALERT Flash Code 3 (Compressor Short Cycling) displayed incorrectly	Verify Y terminal is connected to 24VAC at contactor coil. Verify voltage at contactor coil falls below 0.5VAC when off.
ALERT Flash Code 5 or 6 (Open Circuit, Missing Phase) displayed incorrectly	Check that compressor T1 and T3 wires are through module's current sensing holes. Verify Y terminal is connected to 24VAC at contactor coil. Verify voltage at contactor coil falls below 0.5VAC when off.
Alert Flash Code * (Welded Contactor) displayed incorrectly	Determine if module's Y terminal is connected. Verify Y terminal is connected to 24VAC at contactor coil. Verify 24VAC is present across Y and C when thermostat demand signal is present. If not, R and C are reverse wired. Verify voltage at contactor coil falls below 0.5VAC when off.

## Compressor Protection

### Compressor Overtemperature Protection (IP) —

A thermostat installed on the compressor motor winding reacts to excessively high winding temperatures and shuts off the compressor.

### Crankcase Heater —

The heater minimizes absorption of liquid refrigerant by oil in the crankcase during brief or extended shutdown periods. The heater is wired to cycle with the compressor; the heater is off when compressor is running, and on when compressor is off.

The crankcase heater will operate as long as the power circuit is energized. The main disconnect must be on to energize the crankcase heater.

**IMPORTANT:** Never open any switch or disconnect that energizes the crankcase heater unless unit is being serviced or is to be shut down for a prolonged period. After a prolonged shutdown on a service job, energize the crankcase heater for 24 hours before starting the compressor.

### Advanced Scroll Temperature Protection (ASTP) —

See "Advanced Scroll Temperature Protection (ASTP)" on page 23.

### Low-Pressure Switch —

The 38AU low-pressure switch is stem-mounted on the suction line. Switches are all fixed, non-adjustable type.


### High-Pressure Switch —

The high-pressure switch is stem mounted on the discharge line. The switch is a fixed, non-adjustable type.

### Outdoor Fans —

Each fan is supported by a formed-wire mount bolted to the fan deck and covered with a wire guard. Fan motors have permanently lubricated bearings.

1. Shut off unit power supply. Install lockout tag.
2. Remove outdoor fan assembly (grille, motor, and fan).
3. Loosen fan hub setscrews.
4. Adjust fan height as shown in Fig. 28.
5. Tighten setscrews to 949 N-cm (84 in-lbs).
6. Replace outdoor fan assembly.




C10103

**Fig. 28 - Outdoor Fan Blade Position**

### Lubrication —


**Fan Motors:** The fan motors have sealed bearings. No provisions are made for lubrication.

**Compressor:** The compressor has its own oil supply. Loss of oil due to a leak in the system should be the only reason for adding oil after the system has been in operation.



**Fig. 29 - Typical Exterior, Single-Circuit Unit (38AUZ\*08 shown)**

C10927



**Fig. 30 - Typical Interior, Single-Circuit Unit (38AUZ\*08 shown)**

C10928




Fig. 31 - Typical Exterior, Two-Circuit Unit (38AUD\*14 shown)

C10929




Fig. 32 - Typical Interior, Two-Circuit Unit (38AUD\*14 shown)

C10930




## Coil Type Identification

38AU units are available with different coil types. Cleaning methods differ for each type so identifying the coil type is important. Unit model number and appearance can identify the coil type.

### NOVATION™ Type —

The new NOVATION Heat Exchanger Technology is an all-aluminum construction with louvered serpentine fins over single-depth crosstubes. The horizontal crosstubes have large diameter aluminum headers on each end. Various optional coatings are also available.

38AU units use two-row segmented coils.



C07273

**Fig. 33 - NOVATION Heat Exchanger Coil**

**Model number designation:** See Fig. 2 for general unit model number format. Position 11 indicates the coil type and coating. Position 11 values of G, K, T and W indicate NOVATION coil type is on this unit.

### Round-Tube Plate-Fin (RTPF) Type —

This construction uses a series of small diameter copper hairpin tubes running horizontally with vertical plate fins. The plate fins may be aluminum (standard) or copper (optional). Various optional coatings are also available. 38AU units use two-row segmented coils.


**Model number designation:** See Fig. 2 for general unit model number format. Position 11 indicates the coil type and coating. Position 11 values of A, B, C, M, N and P indicate RTPF coil type is on this unit.

### NOVATION Coil Cleaning and Maintenance —

To clean the NOVATION condenser coil, chemicals are NOT to be used; only water is approved as the cleaning solution. Only clean potable water is authorized for cleaning NOVATION condensers.

Clean the coil as follows:

1. Turn off unit power.
2. Remove screws holding rear corner posts and top cover in place. Pivot top cover up 305 to 457 mm (12 to 18 in.) and support with a rigid support. See Fig. 34.



C10216

**Fig. 34 - Pivot and Support Top Cover**

3. Carefully remove any foreign objects or debris attached to the coil face or trapped within the mounting frame and brackets.
4. Using a high pressure water sprayer, purge any soap or industrial cleaners from hose and/or dilution tank prior to wetting the coil. Clean condenser face by spraying the coil core steadily and uniformly from top to bottom, directing the spray straight into or toward the coil face. Do not exceed 6205 kPa (900 psig) or a 45 degree angle; nozzle must be at least 30 cm (12 in.) from the coil face. Reduce pressure and use caution to prevent damage to air centers (fins). Do not fracture the braze between air centers and refrigerant tubes. Allow water to drain from the coil core and check for refrigerant leaks prior to start up.
5. Replace top cover and rear corner posts.

## ⚠ CAUTION

### EQUIPMENT DAMAGE HAZARD

Failure to follow this caution may result in equipment damage.

Chemical cleaning should NOT be used on the aluminum microchannel (NOVATION) condenser. Damage to the coil may occur. Only approved cleaning is recommended.

### Repairing NOVATION Condenser Tube Leaks —

RCD offers service repair kit Part Number 50TJ660007 for repairing tube leaks in the NOVATION coil crosstubes. This kit includes approved braze materials (aluminum fluxcore braze rods), a heat shield, a stainless steel brush, replacement fin segments, adhesive for replacing fin segments, and instructions specific to the NOVATION aluminum coil. See EPIC for instruction sheet 99TA526379.

The repair procedure requires the use of MAPP gas and torch (must be supplied by servicer) instead of conventional oxyacetylene fuel and torch. While the flame temperature for MAPP is lower than that of oxyacetylene (and thus provides more flexibility when working on aluminum), the flame temperature is still higher than the melting temperature of aluminum, so user caution is required. Follow instructions carefully. Use the heat shield.

### Replacing NOVATION™ Condenser Coil —

The service replacement coil is preformed and is equipped with transition joints with copper stub tubes. When brazing the connection joints to the unit tubing, use a wet cloth around the aluminum tube at the transition joint. Avoid applying torch flame directly onto the aluminum tubing.

### Routine Cleaning of Round-Tube Plate Fin (RTPF) Coils —

Periodic cleaning with Totaline® environmentally sound coil cleaner is essential to extend the life of RTPF coils. This cleaner is available from Carrier Replacement parts division as part number P902-0301 for a 3.8 liter (1 gallon) container, and part number P902-0305 for a 19 liter (5 gallon) container. It is recommended that all RTPF coils be cleaned with the Totaline environmentally sound coil cleaner as described below.

**NOTE:** Do NOT use Totaline® environmentally sound coil cleaner, or any other coil cleaner on NOVATION coils. See “NOVATION Coil Cleaning and Maintenance” for instructions on cleaning NOVATION coils.

Coil cleaning should be part of the unit's regularly scheduled maintenance procedures to ensure long life of the coil. Failure to clean the coils may result in reduced durability in the environment.

Avoid the use of:

- coil brighteners
- acid cleaning prior to painting
- high pressure washers
- poor quality water for cleaning

Totaline environmentally sound coil cleaner is non-flammable, hypoallergenic, non-bacterial, and a USDA accepted biodegradable agent that will not harm the coil or surrounding components such as electrical wiring, painted metal surfaces, or insulation. Use of non-recommended coil cleaners is strongly discouraged since coil and unit durability could be affected.

### Totaline Environmentally Sound Coil Cleaner Application Equipment —

- 9<sup>1</sup>/<sub>2</sub> liter (2<sup>1</sup>/<sub>2</sub> gallon) garden sprayer
- water rinse with low velocity spray nozzle

## ⚠ CAUTION

### UNIT DAMAGE HAZARD

Failure to follow this caution may result in corrosion and damage to the unit.

Harsh chemicals, household bleach or acid or basic cleaners should not be used to clean outdoor or indoor coils or any kind. These cleaners can be very difficult to rinse out of the coil and can accelerate corrosion at the fin/tube interface where dissimilar materials are in contact. If there is dirt below the surface of the coil use the Totaline environmentally sound coil cleaner as described above.

## ⚠ CAUTION

### UNIT RELIABILITY HAZARD

Failure to follow this caution may result in reduced unit performance.

High velocity water from a pressure washer, garden hose, or compressed air should never be used to clean a coil. The force of the water or air jet will bend the fin edges and increase airside pressure drop.

### Totaline Environmentally Sound Coil Cleaner Application Instructions:

**NOTE:** Proper eye protection such as safety glasses is recommended during mixing and application.

1. Turn off unit power.
2. Remove screws holding rear corner post and top cover in place. Pivot top cover up 305 to 457 mm (12 to 18 inches) and support with a rigid support. See Fig. 34.
3. Remove all surface loaded fibers and dirt with a vacuum cleaner. If a vacuum cleaner is not available, a soft non-metallic bristle brush may be used. In either case, the tool should be applied in the direction of the fins. Coil surfaces can be easily damaged (fin edges can be easily bent over and damage to the coating of a protected coil) if the tool is applied across the fins.

**NOTE:** Use of a water stream, such as a garden hose, against surface loaded coil will drive the fibers and dirt into the coil, making cleaning efforts more difficult. Surface loaded fibers must be completely removed prior to using low velocity clean water rinse.

4. Using a low velocity garden hose thoroughly wet finned surfaces with clean water. Be careful not to bend the fins.
5. Mix Totaline environmentally sound coil cleaner in a 9<sup>1</sup>/<sub>2</sub> liter (2<sup>1</sup>/<sub>2</sub> gallon) garden sprayer according to the instructions included with the cleaner. The optimum solution temperature is 38°C (100°F).

**NOTE:** Do NOT USE water in excess of 54°C (130°F), as the enzymatic activity will be destroyed.

6. Thoroughly apply Totaline® environmentally sound coil cleaner solution to all coil surfaces including the finned area, tube sheets and coil headers.



## FASTENER TORQUE VALUES

Table 15 – Torque Values

Compressor mounting bolts	734–847 N–cm (65–75 in–lbs)
Condenser fan motor mounting bolts	226 ±23 N–cm (20 ±2 in–lbs)
Condenser fan hub setscrew	949 ±136 N–cm (84 ±2 in–lbs)
High-flow service port	1085 ±23 N–cm (96 ±10 in–lbs)
Schrader-type service check valve	23–34 N–cm (2–3 in–lbs)
Compressor oil sightglass thread	23–34 N–cm (330 ±31 in–lbs)
Compressor to Compressor rail torque	1356–1898 N–cm (120–168 in–lbs)
Compressor rail to base pan torque	791 ±57 N–cm (70 ±5 in–lbs)

7. Hold garden sprayer nozzle close to finned areas and apply cleaner with a vertical, up-and-down motion. Avoid spraying in horizontal pattern to minimize potential for fin damage.
8. Ensure cleaner thoroughly penetrates deep into finned areas.
9. Interior and exterior finned areas must be thoroughly cleaned.
10. Finned surfaces should remain wet with cleaning solution for 10 minutes.
11. Ensure surfaces are not allowed to dry before rinsing. Reapply cleaner as needed to ensure 10-minute saturation is achieved.
12. Thoroughly rinse all surfaces with low velocity clean water using downward rinsing motion of water spray nozzle. Protect fins from damage from the spray nozzle.
13. Replace top cover and rear corner posts.

## TROUBLESHOOTING

PROBLEM	SOLUTION
<b>COMPRESSOR DOES NOT RUN</b> <u>Contactors Open</u> <ol style="list-style-type: none"> <li>1. Power off.</li> <li>2. Fuses blown in field power circuit.</li> <li>3. No control power.</li> <li>4. Thermostat circuit open.</li> <li>5. Safety device lockout circuit active.</li> <li>6. Low-pressure switch open.</li> <li>7. High-pressure switch open.</li> <li>8. Compressor overtemperature switch open.</li> <li>9. Loose electrical connections.</li> <li>10. Compressor stuck.</li> </ol> <u>Contactors Closed</u> <ol style="list-style-type: none"> <li>1. Compressor leads loose.</li> <li>2. Motor windings open.</li> <li>3. Single phasing.</li> </ol>	<ol style="list-style-type: none"> <li>1. Restore power.</li> <li>2. After finding cause and correcting, replace with correct size fuse.</li> <li>3. Check control transformer primary connections and circuit breaker.</li> <li>4. Check thermostat setting.</li> <li>5. Reset lockout circuit.</li> <li>6. Check for refrigerant undercharge, obstruction of indoor airflow. Make sure liquid line solenoid valve(s) is open.</li> <li>7. Check for refrigerant overcharge, obstruction of outdoor airflow, air in system. Be sure outdoor fans are operating correctly.</li> <li>8. Check for open condition. Allow for reset. Replace compressor if necessary.</li> <li>9. Tighten all connections.</li> <li>10. See compressor service literature.</li> </ol> <ol style="list-style-type: none"> <li>1. Check connections.</li> <li>2. See compressor service literature.</li> <li>3. Check for blown fuse. Check for loose connection at compressor terminal.</li> </ol>
<b>COMPRESSOR STOPS ON HIGH-PRESSURE SWITCH</b> <u>Outdoor Fan On</u> <ol style="list-style-type: none"> <li>1. High-pressure switch faulty.</li> <li>2. Reversed fan rotation.</li> <li>3. Airflow restricted.</li> <li>4. Air recirculating.</li> <li>5. Noncondensables in system.</li> <li>6. Refrigerant overcharge.</li> <li>7. Line voltage incorrect.</li> <li>8. Refrigerant system restrictions.</li> </ol> <u>Outdoor Fan Off</u> <ol style="list-style-type: none"> <li>1. Fan slips on shaft.</li> <li>2. Motor not running.</li> <li>3. Motor bearings stuck.</li> <li>4. Motor overload open.</li> <li>5. Motor burned out.</li> </ol>	<ol style="list-style-type: none"> <li>1. Replace switch.</li> <li>2. Confirm rotation, correct if necessary.</li> <li>3. Remove obstruction.</li> <li>4. Clear airflow area.</li> <li>5. Recover refrigerant and recharge as required.</li> <li>6. Recover refrigerant as required.</li> <li>7. Consult power company.</li> <li>8. Check or replace filter drier, expansion valve, etc.</li> </ol> <ol style="list-style-type: none"> <li>1. Tighten fan hub setscrews.</li> <li>2. Check power and capacitor.</li> <li>3. Replace bearings.</li> <li>4. Check overload rating. Check for fan blade obstruction.</li> <li>5. Replace motor.</li> </ol>

## TROUBLESHOOTING (cont)

PROBLEM	SOLUTION
<b>COMPRESSOR CYCLES ON LOW-PRESSURE SWITCH</b> <u>Indoor-Air Fan Running</u> <ol style="list-style-type: none"> <li>1. Liquid line solenoid valve(s) fails to open.</li> <li>2. Filter drier plugged.</li> <li>3. Expansion valve power head defective.</li> <li>4. Low refrigerant charge.</li> </ol> <u>Airflow Restricted</u> <ol style="list-style-type: none"> <li>1. Coil iced up.</li> <li>2. Coil dirty.</li> <li>3. Air filters dirty.</li> <li>4. Dampers closed.</li> </ol> <u>Indoor-Air Fan Stopped</u> <ol style="list-style-type: none"> <li>1. Electrical connections loose.</li> <li>2. Fan relay defective.</li> <li>3. Motor overload open.</li> <li>4. Motor defective.</li> <li>5. Fan belt broken or slipping.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check liquid line solenoid valve(s) for proper operation. Replace if necessary.</li> <li>2. Replace filter drier.</li> <li>3. Replace power head.</li> <li>4. Add charge. Check low-pressure switch setting.</li> </ol> <ol style="list-style-type: none"> <li>1. Check refrigerant charge.</li> <li>2. Clean coil fins.</li> <li>3. Clean or replace filters.</li> <li>4. Check damper operation and position.</li> </ol> <ol style="list-style-type: none"> <li>1. Tighten all connections.</li> <li>2. Replace relay.</li> <li>3. Power supply.</li> <li>4. Replace motor.</li> <li>5. Replace or tighten belt.</li> </ol>
<b>COMPRESSOR RUNNING BUT COOLING INSUFFICIENT</b> <u>Suction Pressure Low</u> <ol style="list-style-type: none"> <li>1. Refrigerant charge low.</li> <li>2. Head pressure low.</li> <li>3. Air filters dirty.</li> <li>4. Expansion valve power head defective.</li> <li>5. Indoor coil partially iced.</li> <li>6. Indoor airflow restricted.</li> </ol> <u>Suction Pressure High</u> <ol style="list-style-type: none"> <li>1. Heat load excessive.</li> </ol>	<ol style="list-style-type: none"> <li>1. Add refrigerant.</li> <li>2. Check refrigerant charge. Check outdoor-air fan thermostat settings.</li> <li>3. Clean or replace filters.</li> <li>4. Replace power head.</li> <li>5. Check low-pressure setting.</li> <li>6. Remove obstruction.</li> </ol> <ol style="list-style-type: none"> <li>1. Check for open doors or windows in vicinity of fan coil.</li> </ol>
<b>UNIT OPERATES TOO LONG OR CONTINUOUSLY</b> <ol style="list-style-type: none"> <li>1. Low refrigerant charge.</li> <li>2. Control contacts fused.</li> <li>3. Air in system.</li> <li>4. Partially plugged expansion valve or filter drier.</li> </ol>	<ol style="list-style-type: none"> <li>1. Add refrigerant.</li> <li>2. Replace control.</li> <li>3. Purge and evacuate system.</li> <li>4. Clean or replace.</li> </ol>
<b>SYSTEM IS NOISY</b> <ol style="list-style-type: none"> <li>1. Piping vibration.</li> <li>2. Compressor noisy.</li> </ol>	<ol style="list-style-type: none"> <li>1. Support piping as required.</li> <li>2. Replace compressor if bearings are worn.</li> </ol>
<b>COMPRESSOR LOSES OIL</b> <ol style="list-style-type: none"> <li>1. Leak in system.</li> <li>2. Crankcase heaters not energized during shutdown.</li> <li>3. Improper interconnecting piping design.</li> </ol>	<ol style="list-style-type: none"> <li>1. Repair leak.</li> <li>2. Check wiring and relays. Check heater and replace if defective.</li> <li>3. Check piping for oil return. Replace if necessary.</li> </ol>
<b>FROSTED SUCTION LINE</b> Expansion valve admitting excess refrigerant.	Adjust expansion valve.
<b>HOT LIQUID LINE</b> <ol style="list-style-type: none"> <li>1. Shortage of refrigerant due to leak.</li> <li>2. Expansion valve opens too wide.</li> </ol>	<ol style="list-style-type: none"> <li>1. Repair leak and recharge.</li> <li>2. Adjust expansion valve.</li> </ol>
<b>FROSTED LIQUID LINE</b> <ol style="list-style-type: none"> <li>1. Restricted filter drier.</li> <li>2. Liquid line solenoid valve partially closed.</li> </ol>	<ol style="list-style-type: none"> <li>1. Remove restriction or replace.</li> <li>2. Replace valve.</li> </ol>

## APPENDIX A

### Air Conditioner & Heat Pump with PURON® — Quick Reference Guide

- Puron® (R-410A) refrigerant operates at 50 percent to 70 percent higher pressures than R-22. Be sure that servicing equipment and replacement components are designed to operate with Puron®.
- Puron® refrigerant cylinders are rose colored.
- Recovery cylinder service pressure rating must be 2758 kPa (400 psig), DOT 4BA400 or DOT BW400.
- Puron® systems should be charged with liquid refrigerant. Use a commercial type metering device in the manifold hose when charging into suction line with compressor operating.
- Manifold sets should be 4826 kPa (700 psig) high side and 1241 kPa (180 psig) low side with 3290 kPa (550 psig) low-side retard.
- Use hoses with 4826 kPa (700 psig) service pressure rating.
- Leak detectors should be designed to detect HFC refrigerant.
- Puron®, as with other HFCs, is only compatible with POE oils.
- Vacuum pumps will not remove moisture from oil.
- Use only factory specified liquid-line filter driers with rated working pressures greater than 4137kPa (600 psig).
- Do not install a suction-line filter drier in liquid-line.
- POE oils absorb moisture rapidly. Do not expose oil to atmosphere.
- POE oils may cause damage to certain plastics and roofing materials.
- Wrap all filter driers and service valves with wet cloth when brazing.
- A factory approved, liquid-line filter drier is required on every unit.
- Do not use an R-22 TXV.
- If indoor unit is equipped with a TXV, it must be changed to a Puron® TXV.
- Never open system to atmosphere while it is under a vacuum.
- When system must be opened for service, recover refrigerant, break vacuum with dry nitrogen before opening system.
- Always replace filter drier after opening system for service.
- Do not vent Puron® into the atmosphere.
- Do not use capillary tube coils.
- Observe all **warnings**, **cautions**, and **bold** text.
- All Puron® heat pumps must have indoor TXV.
- Do not leave Puron® suction line driers in place for more than 72 hours.

## APPENDIX B

### Wiring Diagram List

38AU Size	Electrical Characteristics	Diagram Number
Z*07	400–3–50	38AU500495
Z*08	400–3–50	38AU500495
D*12	400–3–50	38AU500496
D*14	400–3–50	38AU500496

## APPENDIX C

### Low Ambient Option — Factory Installed

Units with the factory installed low ambient option are equipped with a Motormaster® solid-state head pressure control which regulates fan speed. A temperature sensor, mounted on circuit 1 of the outdoor coil (see Figs. 35 through 38) controls the speed of approved outdoor fan motors in order to maintain a constant head pressure in the outdoor coil. The control maintains the appropriate head pressure at low ambient temperatures down to -28°C (-20°F).

Wind baffles are required to prevent wind cross currents from causing abnormally low condensing temperatures.

Use 20-gauge sheet metal to fabricate wind baffles (see Fig. 39 and Table 16).

#### Operation —

Fan on/off control in cooling-only units (38AUZ, 38AUD) is provided by an outdoor fan relay (OFR).

In cooling mode, fan motor speed of outdoor motors OFM1 and OFM3 is regulated by the speed control temperature sensor on outdoor coil 1 for a minimum coil condensing temperature of approximately 38°C (100°F) at higher outdoor ambient temperature and 27°C (80°F) at lower ambient. Additionally, outdoor fan motor OFM2 and OFM4 are turned on/off by the low ambient temperature switch, LAS, operating the low ambient relay (LAR). The LAS control temperatures are open open 5.5°C +/- 2.8°C, close 13.9°C +/- 2.8°C (42°F +/- 5°F, close 57°F +/- 5°F).

To override the speed control for full fan speed operation during service or maintenance, either:


- remove sensor and place in hot water >49°C (>120°F), or
- rewire to bypass control by connecting speed control input and output power wires.

### Troubleshooting —

OBSERVATION	POSSIBLE REMEDY
Fans won't start	All fans: Check power & wiring Check outdoor fan relay (OFR) OFM1, OFM3 only: Check speed control sensor location Check speed sensor resistance OFM2, OFM4 only: Check low ambient switch (LAS) Check low ambient relay (LAR)
Cooling – Center outdoor fans (OFM2, OFM4) off below approximately 16°C (60°F) outdoor ambient.	Normal operation
Cooling – Center outdoor fans (OFM2, OFM4) not on above approximately 16°C (60°F) outdoor ambient	Check low ambient switch (LAS) Check low ambient relay (LAR)
Cooling – Slow fan speed for outer fans (OFM1, OFM3) at start or during low outdoor ambient	Normal operation
Cooling – Slow fan speed for outer fans (OFM1, OFM3) above 85°F (29°F) outdoor ambient (should be full speed)	Check speed control sensor location Check speed control sensor resistance Check fan motor capacitor
Cooling – motor current into speed control is greater than motor name-plate FLA	Normal operation Up to 30% higher A at partial speed at low ambient


### Speed Control Sensor Resistance —

TEMPERATURE		RESISTANCE
°C +/- 1°C	°F +/- 2°F°	Ohms, nominal
-30	-22	88350
-20	-4	48485
-10	14	27650
0	32	16325
10	50	9950
20	68	6245
25	77	5000
30	86	4028
40	104	2663
50	122	1801
60	140	1244
70	158	876



**Fig. 35 - 38AUZ Motormaster Sensor Location**  
(All Sizes - Novation)


C10931



**Fig. 36 - 38AUD\*12-14 Motormaster Sensor Location**  
(Novation)

C10932


MOTOR MASTER SENSOR  
MUST BE POSITIONED  
ON FEEDER TUBE  
(THIRD FROM BOTTOM)  
BETWEEN HEADER TUBE  
AND TUBE SHEET



C10986

**Fig. 37 - 38AUZ\*07-08 Motormaster Sensor Location  
(RTPF)**

MOTOR MASTER SENSOR  
MUST BE POSITIONED  
ON FEEDER TUBE  
(FOURTH FROM TOP  
ON TOP HEADER)  
BETWEEN HEADER TUBE  
AND TUBE SHEET



C109XX

**Fig. 38 - 38AUZ\*12 Motormaster Sensor Location  
(RTPF)**




Fig. 39 - Wind Baffles

**Table 16 – Wind Baffle Dimension**

DIMENSIONS – MM											
UNIT	BAFFLE	A	B	C	D	E	F	G	H	J	K
38AUZ 07 (MCHX)	LEFT SIDE	826	845	864	895	151	457	865	–	–	–
	BACK	1029	1048	1067	895	113	457	827	–	–	–
38AUZ 08 (MCHX)	LEFT SIDE	1130	1149	1168	895	151	457	865	–	–	–
	BACK	1029	1048	1067	895	113	457	827	–	–	–
38AUD 12 (MCHX)	LEFT SIDE	1130	1149	1168	1095	212	539	737	1015	–	–
	BACK	1029	1048	1067	1095	180	507	737	983	–	–
38AUD 14 (MCHX)	LEFT SIDE	1130	1149	1168	1095	212	539	737	1015	–	–
	BACK	1016	1035	1054	1095	180	507	737	983	–	–
	RIGHT SIDE	616	635	654	1095	174	501	737	977	–	–
38AUZ 07 (RTPF)	LEFT SIDE	718.7	737.8	756.8	895.4	32.9	236.1	439.3	642.5	845.7	–
	BACK	1023.0	1042.1	1061.1	895.4	105.8	283.6	461.4	639.2	817.0	–
38AUZ 08 (RTPF)	LEFT SIDE	718.7	737.8	756.8	895.4	32.9	236.1	439.3	642.5	845.7	–
	BACK	1023.0	1042.1	1061.1	895.4	105.8	283.6	461.4	639.2	817.0	–
38AUZ 12 38AUD 12 (RTPF)	LEFT SIDE	1022.7	1041.8	1060.8	1095.4	32.9	236.1	439.3	642.5	845.7	1048.9
	BACK	1023.0	1042.1	1061.1	895.4	105.8	283.6	461.4	639.2	817.0	994.8
DIMENSIONS – INCHES											
UNIT	BAFFLE	A	B	C	D	E	F	G	H	J	K
38AUZ 07 (MCHX)	LEFT SIDE	32 1/2	33 1/4	34	35 1/4	6	18	34 1/8	–	–	–
	BACK	40 1/2	41 1/4	42	35 1/4	4 1/2	18	32 5/8	–	–	–
38AUZ 08 (MCHX)	LEFT SIDE	44 1/2	45 1/4	46	35 1/4	6	18	34 1/8	–	–	–
	BACK	40 1/2	41 1/4	42	35 1/4	4 1/2	18	32 5/8	–	–	–
38AUD 12 (MCHX)	LEFT SIDE	44 1/2	45 1/4	46	43 1/8	8 3/8	21 1/4	29	40	–	–
	BACK	40 1/2	41 1/4	42	43 1/8	7 1/8	20	29	38 3/4	–	–
38AUD 14 (MCHX)	LEFT SIDE	44 1/2	45 1/4	46	43 1/8	8 3/8	21 1/4	29	40	–	–
	BACK	40	40 3/4	41 1/2	43 1/8	7 1/8	20	29	38 3/4	–	–
	RIGHT SIDE	24 1/2	25	25 3/4	43 1/8	6 7/8	19 3/4	29	38 1/2	–	–
38AUZ 07 (RTPF)	LEFT SIDE	28 1/4	29	29 3/4	35 1/4	1 1/4	9 1/4	17 1/4	25 1/4	33 1/4	–
	BACK	40 1/4	41	41 3/4	35 1/4	4 1/8	11 1/8	18 1/8	25 1/8	32 1/8	–
38AUZ 08 (RTPF)	LEFT SIDE	28 1/4	29	29 3/4	35 1/4	1 1/4	9 1/4	17 1/4	25 1/4	33 1/4	–
	BACK	40 1/4	41	41 3/4	35 1/4	4 1/8	11 1/8	18 1/8	25 1/8	32 1/8	–
38AUZ 12 38AUD 12 (RTPF)	LEFT SIDE	40 1/4	41	41 3/4	43 1/8	1 1/4	9 1/4	17 1/4	25 1/4	33 1/4	41 1/4
	BACK	40 1/4	41	41 3/4	35 1/4	4 1/8	11 1/8	18 1/8	25 1/8	32 1/8	39 1/8

MCHX: NOVATION coil model







# START-UP CHECKLIST

## I. PRELIMINARY INFORMATION

OUTDOOR: MODEL NO. \_\_\_\_\_ SERIAL NO. \_\_\_\_\_  
INDOOR: AIRHANDLER MANUFACTURER \_\_\_\_\_  
MODEL NO. \_\_\_\_\_ SERIAL NO. \_\_\_\_\_  
ADDITIONAL ACCESSORIES \_\_\_\_\_

## II. PRE-START-UP

### OUTDOOR UNIT

IS THERE ANY SHIPPING DAMAGE? (Y/N) \_\_\_\_\_

IF SO, WHERE: \_\_\_\_\_

WILL THIS DAMAGE PREVENT UNIT START-UP? (Y/N) \_\_\_\_\_

CHECK POWER SUPPLY. DOES IT AGREE WITH UNIT? (Y/N) \_\_\_\_\_

HAS THE GROUND WIRE BEEN CONNECTED? (Y/N) \_\_\_\_\_

HAS THE CIRCUIT PROTECTION BEEN SIZED AND INSTALLED PROPERLY? (Y/N) \_\_\_\_\_

ARE THE POWER WIRES TO THE UNIT SIZED AND INSTALLED PROPERLY? (Y/N) \_\_\_\_\_

### CONTROLS

ARE THERMOSTAT AND INDOOR FAN CONTROL WIRING CONNECTIONS MADE AND CHECKED?  
(Y/N) \_\_\_\_\_

ARE ALL WIRING TERMINALS (including main power supply) TIGHT? (Y/N) \_\_\_\_\_

HAS CRANKCASE HEATER BEEN ENERGIZED FOR 24 HOURS? (Y/N) \_\_\_\_\_

### INDOOR UNIT

HAS WATER BEEN PLACED IN DRAIN PAN TO CONFIRM PROPER DRAINAGE? (Y/N) \_\_\_\_\_

ARE PROPER AIR FILTERS IN PLACE? (Y/N) \_\_\_\_\_

HAVE FAN AND MOTOR PULLEYS BEEN CHECKED FOR PROPER ALIGNMENT? (Y/N) \_\_\_\_\_

DO THE FAN BELTS HAVE PROPER TENSION? (Y/N) \_\_\_\_\_

HAS CORRECT FAN ROTATION BEEN CONFIRMED? (Y/N) \_\_\_\_\_

### PIPING

ARE LIQUID LINE SOLENOID VALVES LOCATED AT THE INDOOR COILS AS REQUIRED? (Y/N) \_\_\_\_\_

HAVE LEAK CHECKS BEEN MADE AT COMPRESSOR, OUTDOOR AND INDOOR COILS,  
TXVs (Thermostatic Expansion Valves), SOLENOID VALVES, FILTER DRIERS, AND FUSIBLE PLUGS  
WITH A LEAK DETECTOR? (Y/N) \_\_\_\_\_

LOCATE, REPAIR, AND REPORT ANY LEAKS. \_\_\_\_\_

HAVE LIQUID LINE SERVICE VALVES BEEN OPENED? (Y/N) \_\_\_\_\_

HAVE SUCTION LINE SERVICE VALVES BEEN OPENED? (Y/N) \_\_\_\_\_

## 38AU

[illegible]