

**48/50TC04–30, 50TCQ04–24
48/50HC04–28, 50HCQ04–12
48/50LC04–06
Factory Installed Option
RTU Open**



Controls, Start–Up, Operation and Troubleshooting

TABLE OF CONTENTS

SAFETY CONSIDERATIONS	2	Power Exhaust Test	14
GENERAL	2	Economizer Test	14
SENSOR/ACCESSORY INSTALLATION	2	Analog Output 2 Test	14
Sensors and Accessories	4	Configuration	14
User Interfaces	4	Setpoint	14
Install Analog Sensors	4	Unit	14
Supply Air Sensor (SAT)	4	Inputs	15
Outdoor Air Sensor (OAT)	4	Service	16
Space Temperature Sensor (SPT)	4	Clockset	17
CO ₂ Sensor(s) (IAQ and OAQ)	6	USERPW	17
Relative Humidity Sensors	8	OPERATION	17
Installing Discrete Inputs	8	Occupancy	17
Compressor Safety	8	Indoor (Supply) Fan	17
Humidistat	8	Cooling	17
Single Enthalpy (Outdoor Enthalpy)	8	Supply Fan	18
Differential Enthalpy	8	Economizer	18
Fire Shutdown	9	Power Exhaust	19
Filter Status	9	Pre-Occupancy Purge	19
Fan Status	9	Heating	19
Remote Occupancy	9	Indoor Air Quality	19
Communication Wiring-Protocols	10	Dehumidification	19
General	10	Demand Limit	20
i-Vu [®] Open	10	Unoccupied Free Cooling	20
BACnet [®] MS/TP	10	Optimal Start	20
Modbus	11	Fire Shutdown	20
Johnson N2	11	Compressor Safety	20
LonWorks	11	Fan Status	20
Local Access	12	Filter Status	20
START-UP	13	Door Switch	20
Additional Installation/Inspection	13	Linkage	21
Humidi-MiZer [™] Control Wiring	13	TROUBLESHOOTING	21
Power Exhaust Relay Power	13	General	21
Service Test	13	Thermistor Troubleshooting	21
Fan Test	13	Software Version	22
High Speed Fan Test	13	Communication LED's	23
Compressor 1 and Compressor 2 Test	13	Alarms	25
Heat 1 and Heat 2 Test	13	Third Party Networking	27
Reversing Valve Test	13	APPENDIX A - USER INTERFACE MENUS	28
Dehumidification Test	14	APPENDIX B - THIRD PARTY POINTS LIST	37
		RTU OPEN START-UP SHEET	41

SAFETY CONSIDERATIONS

Installation and servicing of air-conditioning equipment can be hazardous due to system pressure and electrical components. Only trained and qualified service personnel should install, repair, or service air-conditioning equipment. Untrained personnel can perform the basic maintenance functions of replacing filters. Trained service personnel should perform all other operations.

When working on air-conditioning equipment, observe precautions in the literature, tags and labels attached to the unit, and other safety precautions that may apply. Follow all safety codes. Wear safety glasses and work gloves.

Follow all safety codes. Wear safety glasses and work gloves. Have fire extinguisher available. Read these instructions thoroughly and follow all warnings or cautions attached to the unit. Consult local building codes and National Electrical Code (NEC) for special requirements.

Recognize safety information. This is the safety-alert symbol . When you see this symbol on the unit and in instructions or manuals, be alert to the potential for personal injury.

Understand the signal words DANGER, WARNING, and CAUTION. These words are used with the safety-alert symbol. DANGER identifies the most serious hazards which **will** result in severe personal injury or death. WARNING signifies a hazard which **could** result in personal injury or death. CAUTION is used to identify unsafe practices which **may** result in minor personal injury or product and property damage. NOTE is used to highlight suggestions which **will** result in enhanced installation, reliability, or operation.

WARNING

ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death.

Disconnect all power to the unit before performing maintenance or service. Unit may automatically start if power is disconnected.

GENERAL

The RTU Open controller is an integrated component of the Carrier rooftop unit. Its internal application programming provides optimum performance and energy efficiency. RTU Open enables the unit to run in 100% stand-alone control mode, Carrier's i-Vu® Open network, or a Third Party Building Automation System (BAS). On-board DIP switches allow you to select your protocol (and baud rate) of choice among the four most popular protocols in use today: BACnet®, Modbus, Johnson N2 and LonWorks. (See Fig. 1.)

NOTE: Lon Works requires addition of LON option card.

Carrier's diagnostic display tools such as Field Assistant, BACview⁶ Handheld or Virtual BACview can be used with the RTU Open controller. Access is available via a 5-pin J12 access port.

SENSOR/ACCESSORY INSTALLATION

There are a variety of sensors and accessories available for the RTU Open. Some of these can be factory or field installed, while others are only field installable. The RTU Open controller may also require connection to a building network system or building zoning system. All field control wiring that connects to the RTU Open must be routed through the raceway built into the corner post of the unit or secured to the unit control box with electrical conduit. The unit raceway provides the UL required clearance between high and low-voltage wiring. Pass the control wires through the hole provided in the corner post, then feed the wires thorough the raceway to the RTU Open. Connect the wires to the removable Phoenix connectors and then reconnect the connectors to the board. See Fig. 1 and Table 1 for board connections and Fig. 2 for Typical Factory RTU Open wiring.

IMPORTANT: Refer to the specific sensor or accessory instructions for its proper installation and for rooftop unit installation refer to base unit installation instructions and the unit's wiring diagrams.

WARNING

ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury, death and/or equipment damage.

Disconnect electrical power and use lock-out tags before wiring the RTU Open controller.

Table 1 – RTU Open Inputs and Outputs

POINT NAME	BACnet OBJECT NAME	TYPE OF I/O	CONNECTION PIN NUMBER(S)
DEDICATED INPUTS			
Space Temp / Zone Temp	zone_temp	AI (10K Thermistor)	J20–1 & 2
Supply Air Temperature	sa_temp	AI (10K Thermistor)	J2–1 & 2
Outdoor Air Temperature	oa_temp	AI (10K Thermistor)	J2–3 & 4
Space Temperature Offset Pot	stpt_adj_offset	AI (100K Potentiometer)	J20–3 & 4
Safety Chain Feedback	safety_status	DI (24 VAC)	J1–9
Compressor Safety Status	comp_status	DI (24 VAC)	J1–2
Fire Shutdown Status	firedown_status	DI (24 VAC)	J1–10
Enthalpy Status	enthalpy_status	DI (24 VAC)	J2–6 & 7
Humidistat Input Status	humstat_status	DI (24 VAC)	J5–7 & 8
Zone Temperature	n/a	n/a	J13–1, 2, 3, 4
CONFIGURABLE INPUTS			
Indoor Air CO2	iaq	AI (4–20 ma)	J4–2 & 3 or J4–5 & 6
Outdoor Air CO2	oaq	AI (4–20 ma)	
Space Relative Humidity	space_rh	AI (4–20 ma)	
Supply Fan Status*	sfan_status	DI (24 VAC)	J5–1 or J5–3 or J5–5
Filter Status*	filter_status	DI (24 VAC)	
Door Contact Input*	door_contact_status	DI (24 VAC)	
Occupancy Contact*	occ_contact_status	DI (24 VAC)	
OUTPUTS			
Economizer Output	econ_output	AO (4–20ma)	J2–5
Supply Fan Relay State	sfan	DO Relay (24VAC , 1A)	J1–4
Compressor 1 Relay State	comp_1	DO Relay (24VAC , 1A)	J1–8
Compressor 2 Relay State	comp_2	DO Relay (24VAC , 1A)	J1–7
Heat Stage 1 Relay State	heat_1	DO Relay (24VAC , 1A)	J1–6
Heat Stage 2 Relay State	heat_2	DO Relay (24VAC , 1A)	J1–5
Power Exhaust Relay State	pexh	DO Relay (24VAC , 1A)	J11–1 & 3
Humidimizer Relay State	dehum	DO Relay (24VAC , 1A)	J11–7, 8

* These inputs (if installed) take the place of the default input on the specific channel
Parallel pins J5–1 = J2–6, J5–3 = J1–10, J5–5 = J1–2 are used for field installation.
Refer to the input configuration and accessory sections for more detail.

Sensors and Accessories

The RTU Open controller is configurable with the following field-supplied sensors:

NOTE: Supply air temperature sensor (33ZCSENSAT) is factory-installed.

- Space temperature sensor (SPS, SPPL, SPP, SPPF, 33ZCT55SPT, 33ZCT56SPT, or 33ZCT59SPT)
- Indoor air quality sensor (33ZCSPTCO2-01, 33ZCSPTCO2LCD-01, 33ZCT55CO2, 33ZCT56CO2) required for demand control ventilation.
- Outdoor air quality sensor (33ZCSPTCO2-01, 33ZCSPTCO2LCD-01)
- CO₂ aspirator box (C33ZCCASPCO2) required for CO₂ return duct/outside air applications
- Outdoor air enthalpy switch (33CSENTHSW)
- Return air enthalpy sensor (33CSENSEN) required for differential enthalpy control
- Space relative humidity sensor (33ZCSENSRH-02)
- Duct relative humidity (33ZCSENDRH-02)
- Humidistat (--HL--38MG-029)
- Smoke Detectors (CRSMKSEN002A00, CRSMKKIT002A00)
- Fan and/or Filter Status (CRSTATUS001A00, CRSTATUS005A00)

User Interfaces

- BACview⁶ Handheld (BV6H)

- Virtual BACview (USB-L or USB-TKIT required)
- Field Assistant (USB-TKIT required)

Install Analog Sensors

Supply Air Sensor (SAT)

The factory supplies the discharge (supply) air sensor with the unit and is pre-wired. On 04-16 size units, the SAT is secured to the unit's supply duct opening. This sensor must be relocated into the supply duct during unit installation. On 17-30 size units, the SAT is mounted through the side of the heat chamber below the fan deck, and does NOT require relocation.

Outdoor Air Sensor (OAT)

The OAT is supplied with the economizer option or accessory. It is wired through the 12-pin plug (PL6) in the return air section of the unit and is mounted on the economizer assembly.

Space Temperature Sensor (SPT)

There are 2 types of SPT sensors available from Carrier, resistive input non-communicating (T55, T56, and T59) and Rnet communicating (SPS, SPPL, SPP, and SPPF) sensors. Each type has a variety of options consisting of: timed override button, set point adjustment, a LCD screen, and communication tie in. Space temperature can be also be written to from a building network or zoning system. However, it is still recommended that return air duct sensor be installed to allow stand-alone operation for back-up. Refer to the configuration section for details on controller configurations associated with space sensors.

YAC CONTROL 208/230V, 460V, 575V
7.5-10TON YAC (2)COMPR T1
7.5-8.5TON YAC (2)COMPR T2





Fig. 2 - Typical Factory Option Wiring

Resistive Non-Communicating Sensor Wiring

For sensor with setpoint adjustment up to 500 ft (152m), use three-conductor shielded cable 20 gauge wire to connect the sensor to the controller. For non set point adjustment (slidebar) or return air duct sensor, an unshielded, 18 or 20 gauge, two-conductor, twisted pair cable may be used. Below is the list of the connections of the SPT to the RTU Open, refer to Fig. 3 and 4 for typical connections at the sensor.


- J20-1 = temperature sensor input (SEN)
- J20-2 = sensor common
- J20-3 = Setpoint adjustment input (SET)

NOTE: See Fig. 5 for space temperature sensor averaging. T55/56 Override button will no longer function when sensors are averaged. Only Sensor 1 T56 STO input can be used.



C07131

Fig. 3 - Space Temperature Sensor Typical Wiring (33ZCT56SPT)



NOTE: Must use a separate isolated transformer.

C10291

Fig. 4 - Space Temperature Sensor Typical Wiring (33ZCT59SPT)

Rnet Communicating Sensor Wiring

The Rnet bus allows local communication with the RTU Open, including communicating sensors. The Rnet bus can hold up to 6 devices in the following combinations wired in daisy-chain or hybrid configuration:

- 1-4 SPS sensor(s)
- 1 SPPL, SPP, or SPPF sensor
- 1-4 SPS sensor(s), and 1 SPPL, SPP, or SPPF sensor
- Any of the above combinations, plus up to 2 BACview⁶s

NOTE: Additional SPS sensors and BACview⁶ must be addressed. Use the jumpers on the SPS sensor's circuit board and refer to the BACview⁶'s installation instructions for addressing.

For Rnet wiring up to 500ft (152m), use 18 AWG 4 conductor unshielded plenum rated cable. The RTU Open's J13-RNET connection has a 4 pin Phoenix connector wired as described below, Fig. 6 shows sensor Rnet wiring.

- RNET - 1 = Signal ground (GND)
- RNET - 2 = Signal (Rnet+)
- RNET - 3 = Signal (Rnet-)
- RNET - 4 = Power (+12v)

CO₂ Sensor(s) (IAQ and OAQ)

The indoor air quality (IAQ) and outdoor air quality (OAQ) sensors monitor carbon dioxide (CO₂) levels. This information is used to monitor the quality of air in terms of parts per million (PPM). The same sensor is used for inside, outside, and duct monitoring, except an aspirator box is required for outside and duct mounting. The CO₂ sensor is preset for a range of 0 to 2000 ppm and a linear mA output of 4 to 20. The rooftop unit may have a factory installed CO₂ sensor on the side of the economizer assembly in the return air section of the unit and is pre-wired and pre-configured at the factory. For field installed sensors, a field supplied transformer must be used to power the sensor. Refer to the instructions supplied with the CO₂ sensor for electrical requirements and terminal locations. RTU Open configurations must be changed after adding a CO₂ sensor. See below and Fig. 7 for typical CO₂ sensor wiring.

- J4-2 or J4-5 = 4-20mA signal input
- J4-3 or J4-6 = signal common

NOTE: The factory used J4-2&3 for CO₂ (IAQ) sensor inputs.

Combination Temperature and CO₂ Sensor

If using a combination temperature and CO₂ sensor (33ZCT55CO2 or 33ZCT56CO2), refer to the installation instructions provided with the sensor.






Fig. 5 - Space Temperature Averaging

C07133



C10820

Fig. 6 - Typical Rnet Communication Sensor Wiring



C12748

Fig. 7 - Indoor/Outdoor Air Quality (CO₂) Sensor (33ZCSPTCO2-01 or 33ZCSPTCO2LCD-01) Typical Wiring Diagram

Relative Humidity Sensors (Space or Duct Mounted)

The accessory space humidity sensor or duct humidity sensor is used to measure the relative humidity of the air within the space or return air duct. The RH reading is used to control the Humidi-MiZer™ option of the rooftop unit. For wiring distances up to 500 ft (152m), use a 3-conductor, 18 or 20 AWG shielded cable. The shield must be removed from the sensor end of the cable and grounded at the unit end. The current loop power for the sensor is provided by the RTU Open controller as 24vdc. Refer to the instructions supplied with the RH sensor for electrical requirements and terminal locations. RTU Open configurations must be changed after adding a RH sensor. See below and Fig. 8 and 9 for typical RH sensor wiring.

- J4-1 or J4-4 = 24vdc loop power
- J4-2 or J4-5 = 4-20mA signal input


NOTE: The factory default for dehumidification control is a normally open humidistat.

Installing Discrete Inputs

Compressor Safety

The compressor safety input provides the RTU Open with feedback to when the compressor is not running and should be. This feedback is usually provided by a Compressor Lock-Out (CLO) device. Compressor safety is a dedicated input on the configurable input 3 and tells the RTU Open when the compressor is locked out. The normal condition for compressor safety is good operation. A normally open compressor safety is the factory default for all units. Follow specific accessory instructions if installing a CLO device. The CLO should wire into the unit's central terminal Board (CTB).

NOTE: Input 3 can also be wired into J-5.



C07201

Fig. 8 - Space Relative Humidity Sensor Typical Wiring

Humidistat

The accessory humidistat provides the RTU Open insight to the relative humidity in the space. The humidistat reads the RH level in the space and compares it to its setpoint to operate a dry contact. The humidistat is a dedicated input on the configurable input 9 and tells the RTU Open when the RH level is HIGH or LOW. The normal condition for humidity is LOW. A normally open humidistat is the factory default control for the Humidi-MiZer™ option. To wire in the field:

- J5-8 = 24 VAC source for dry contact
- J5-7 = Signal input

Single Enthalpy (Outdoor Enthalpy)

The outdoor enthalpy switch/receiver (33CSENTHSW) senses temperature and humidity of the air surrounding the device and calculates the enthalpy when used without an enthalpy sensor. The relay is energized when enthalpy is high (above 28 BTU/lb OR dry bulb temperature is above 75°F) and de-energized when enthalpy is low (below 27 BTU/lb AND dry bulb temperature is below 74.5°F). The enthalpy input is dedicated to input 8 and tells the RTU Open when the outside air enthalpy is HIGH or LOW. The normal condition for the enthalpy input is HIGH. Enthalpy is configured on input 8 in the factory when it is added as an option.

NOTE: The enthalpy calculation is done using an average altitude of 1000 ft above sea level.

For field installation, refer to the enthalpy accessory instructions. For wiring see below and Fig. 10. The RTU Open board provides 24vac on one of the two loose grey wires in the return air section of the rooftop near the 12-pin economizer plug. To determine the correct grey, measure the voltage on the wires with power applied to the unit. If 24-vac is sensed, then that is the grey wire that is connected to the RTU Open board at J2-7. The other is the signal for input 8, connect it to the LOW Enthalpy terminal on the enthalpy switch/receiver. Tie into the 12-pin economizer plug on pin 4 or the black wire connected to the actuator for the enthalpy's GND connection. Power can also be provided direct from the unit transformer and J5 terminal on the RTU Open.

- J2-7 or J5-2 = 24 VAC for enthalpy switch power
- J2-6 or J5-1 = input signal

Differential Enthalpy

Differential enthalpy control requires both an enthalpy switch/receiver (33CSENTHSW) and an enthalpy sensor (33CSENTSEN). The enthalpy sensor must be installed in the field as the factory can only provide single enthalpy. The enthalpy sensor must be mounted in the return airstream and calculates the enthalpy of the indoor air. The relay is energized when the enthalpy detected by the return air enthalpy sensor is less than the enthalpy at the enthalpy switch/receiver. The relay is de-energized when the enthalpy detected by the return air enthalpy sensor is greater than the enthalpy at the enthalpy switch/receiver (differential enthalpy control).




Fig. 9 - Duct Relative Humidity Sensor Typical Wiring

C12756

To wire return air enthalpy sensor:

Connect the 4-20 mA In terminal on the enthalpy switch/receiver to the 4-20 mA Out terminal on the return air enthalpy sensor. Connect the 24-36 VDC Out terminal on the enthalpy switch/receiver to the 24-36 VDC In terminal on the return air enthalpy sensor. (See Fig 10.)

Fire Shutdown

The fire shutdown input is provided for unit shutdown in response to a fire alarm or smoke detector. The fire shutdown input is dedicated to input 5 and tells the RTU Open when to shutdown due to smoke detection or fire alarm system. The normal condition for fire shutdown is there is no fire alarm. The unit may have factory installed smoke detector(s); refer to the base unit installation instructions for details on any adjustments required during unit installation. Fire shutdown is always factory configured for a normally open smoke detector.

For field installation of a smoke detector see instructions for that specific accessory. See below and the troubleshooting section for wiring at the unit's Central Terminal Board (CTB).

- CTB - UNIT SHUTDOWN - 24v OUT = 24 VAC source
- CTB - UNIT SHUTDOWN - Smoke Alarm = Signal input to RTU Open

NOTE: Input 5 can also be wired into J5-3.

Filter Status

The filter status accessory is a field-installed accessory. This accessory detects plugged filters. When installing this accessory, the unit must have a free input (input 3, 5, 8, or 9). One of the dedicated functions (Humidistat, Fire shutdown, Enthalpy, or Compressor safety) must not be in use to configure Filter Status. Refer to the configuration section for details on configuring inputs for specific functions and state. Refer to Fig. 1 for wire terminations at J5.

Fan Status

The fan status accessory is a field-installed accessory. This accessory detects when the indoor fan is moving air. When installing this accessory, the unit must have a free input (input 3, 5, 8, or 9). One of the dedicated functions (Humidistat, Fire shutdown, Enthalpy, or Compressor safety) must not be in use to configure Fan Status. Refer to the configuration section for details on configuring inputs for specific functions and state. Refer to Fig. 1 for wire terminations at J5.

Remote Occupancy

The remote occupancy accessory is a field-installed accessory. This accessory provides an input to change the units occupancy status. When installing this accessory, the unit must have a free input (input 3, 5, 8, or 9). One of the dedicated functions (Humidistat, Fire shutdown, Enthalpy, or Compressor safety) must not be in use to configure remote occupancy. Refer to the configuration section for details on configuring inputs for specific functions and state. Refer to Fig. 1 for wire terminations at J5.




Fig. 10 - Enthalpy Switch and Sensor Wiring

C10821

Communication Wiring-Protocols

General

Protocols are the communication languages spoken by control devices. The main purpose of a protocol is to communicate information in the most efficient method possible. Different protocols exist to provide different kinds of information for different applications. In the BAS application, many different protocols are used, depending on manufacturer. Protocols do not change the function of a controller; just make the front end user different.

The RTU Open can be set to communicate on four different protocols: BACnet, Modbus, N2, and LonWorks. Switch 3 (SW3) on the board is used to set protocol and baud rate. Switches 1 and 2 (SW1 and SW2) are used to set the board's network address. See Fig. 11 and 12 for protocol switch settings and address switches. The 3rd party connection to the RTU Open is through plug J19. See Fig. 13 for wiring. Refer to the *RTU Open v2 Integration Guide* for more detailed information on protocols, 3rd party wiring, and networking.

NOTE: Power must be cycled after changing the SW1-3 switch settings.

i-Vu® Open

i-Vu Open is a Carrier front-end and Building Automation System (BAS). It is a web based network system that uses a native BACnet over MS/TP communication protocol. The speed of the network can range from 9600 to 76,800 baud. Open devices communicate with a proprietary language called Linkage on i-Vu Open. Linkage is established automatically and allows the flow of specific data across Open devices. Refer to i-Vu Open literature for more information on i-Vu.

BACnet® MS/TP

BACnet Master Slave/Token Passing (MS/TP) is used for communicating BACnet over a sub-network of BACnet-only controllers. This is the default Carrier communications protocol. Each RTU Open module acts as an MS/TP Master. The speed of an MS/TP network can range from 9600 to 76.8K baud. Physical Addresses can be set from 01 to 99.

SW3 Protocol Selection

PROTOCOL	DS8	DS7	DS6	DS5	DS4	DS3	DS2	DS1
BACnet MS/TP (Master)	Unused	OFF	OFF	OFF	ON	OFF	Select Baud	Select Baud
Modbus (Slave)	Unused	OFF	OFF	ON	ON	OFF	Select Baud	Select Baud
N2 (Slave)	Unused	OFF	OFF	OFF	ON	ON	OFF	OFF
LonWorks	Unused	ON	ON	OFF	ON	OFF	OFF	ON

NOTE:

DS = Dip Switch

BACnet MS/TP SW3 example shown

Baud Rate Selections

BAUD RATE	DS2	DS1
9600	OFF	OFF
19,200	ON	OFF
38,400	OFF	ON
76,800	ON	ON




Fig. 11 - RTU Open SW3 Dip Switch Settings

C07166




Fig. 12 - RTU Open Address Switches

C10815




Fig. 13 - Network Wiring

C10816

Modbus

The RTU Open module can speak the Modicon Modbus RTU Protocol as described in the Modicon Modbus Protocol Reference Guide, PI--MBUS--300 Rev. J. The speed of a Modbus network can range from 9600 to 76.8K baud. Physical Addresses can be set from 01 to 99.

Johnson N2

N2 is not a standard protocol, but one that was created by Johnson Controls, Inc. that has been made open and available to the public. The speed of N2 network is limited to only 9600 baud. Physical Addresses can be set from 01 to 99.

LonWorks

LonWorks is an open protocol that requires the use of Echelon's Neuron microprocessor to encode and decode the LonWorks packets. In order to reduce the cost of adding that hardware on every module, a separate LonWorks Option Card (LON-OC) was designed to connect to the RTU Open.

This accessory card is needed for LonWorks and has to be ordered and connected using the ribbon cable to plug J15. The RTU Open's baud rate must be set to 38.4k to communicate with the LON-OC. The address switches (SW1 & SW2) are not used with LonWorks.




Fig. 14 - LON-OC and LON Network Wiring

C12750

Local Access

BACview⁶ Handheld


The BACview⁶ is a keypad/display interface used to connect to the RTU Open to access the control information, read sensor values, and test the RTU. (See Fig. 15.) This is an accessory interface that does not come with the RTU Open controller. You connect the BACview⁶ to the RTU Open's J12 local access port or one of the communicating space sensor's access port. There are 2 password protected levels in the display (User and Admin). The user password is defaulted to 0000, but can be changed. The Admin password is 1111 and cannot be changed. There is a 10 minute auto logout if a screen is left idle. See Appendix A for navigation and screen content.

Virtual BACview

Virtual BACview is a freeware computer program that functions as the BACview⁶ Handheld. The USB Link interface (USB-L) is required to connect a computer to the RTU Open board. The link cable connects a USB port to the J12 local access port. This program functions and operates identical to the handheld.

Field Assistant

Field Assistant is a computer program included with the purchase of the USB Link Tech Kit (USB-TKIT). This is a field Tech Tool to set-up, service, or download the RTU Open controller. The link cable connects a USB port to the J12 local access port. The menu structure is similar to the BACview, but accessed and functions the same as i-Vu.

Fig. 15 - BACview⁶ Handheld Connections

C12749

START-UP

IMPORTANT: Follow the base unit's start-up sequence documented in its specific instructions. Use the base unit's start-up check list when performing the start-up. At the end of this manual there is an additional RTU Open Start-up Sheet to be completed and included with the base unit check list.

Besides the base unit start-up, there are a few steps to take to properly start-up the controls. RTU Open's Service Test function should be used to assist in the base unit start-up and also allows verification of output operation. Controller configuration is also part of start-up. This is especially important when field accessories have been added to the unit. The factory pre-configures options installed at the factory. There may also be additional installation steps or inspection required during the start-up process.

Additional Installation/Inspection

Inspect the field installed accessories for proper installation, making note of which ones do or do not require configuration changes. Inspect the RTU Open's Alarms for initial insight to any potential issues. See troubleshooting section for alarms. Inspect the SAT sensor for relocation as intended during installation. Inspect special wiring as directed below.

Humidi-MiZer™ Control Wiring

In units equipped with the optional Humidi-MiZer option there are 2 loose wires (one pink and one pink/black) in the control box used to control the dehumidification function of the unit. These wires are meant to be tied to a space humidistat or thermidistat on an electromechanical unit. On RTU Open equipped units these wires must be connected to J11-7 & 8 to allow the Open board to operate the dehumidification function of the unit. Disconnect the J11 Phoenix style connector from the board and use the plug screws to secure the pink/black wire in pin 7 and the pink wire in pin 8, reconnect the plug to the board at J11.

Power Exhaust Relay Power

The relay used by the RTU Open board to control power exhaust is a dry contact which means it does not have 24vac. This 24vac must be connected to the relay to allow it operate the power exhaust relay in the PE accessory. A 24vac source should be provided to the J11-2 pin on the RTU Open. This can be provided by the unit's transformer from various sources. The "R" terminal on the unit's central terminal board (CTB) is a logical source.

Service Test

The Service Test function can be used to verify proper operation of compressors, heating stages, indoor fan, power exhaust fans, economizer, and dehumidification. Use of Service Test is recommended at initial system start up and during troubleshooting. See Appendix A for Service Test Mode table.

Service Test mode has the following changes from normal operation:

- Outdoor air temperature limits for cooling circuits, economizer, and heating are ignored.
- Normal compressor time guards and other staging delays are ignored.
- The status of Alarms (except Fire and Safety chain) is ignored, but all alerts and alarms are still broadcasted on the network.

Service Test can be turned ON/OFF at the unit display or from the network. Once turned ON, other entries may be made with the display or through the network. To turn Service Test on, change the value of Test Mode to ON, to turn Service Test off, change the value of Test Mode to OFF.

NOTE: Service Test mode is password protected when accessing from the display. Depending on the unit model, factory-installed options, and field-installed accessories, some of the Service Test functions may not apply.

Fan Test

This point allows the board's fan output to be manually turned On (Enable) and Off (Disable). Other test points that require the fan for operation will automatically turn the fan on and this point will still show "Disable." Fan test can operate simultaneously with other Service Test Points.

High Speed Fan Test

Use the High Speed Fan Test to activate and deactivate the Supply Fan (BO-1) output.

NOTE: This output is only applicable if Fan Control is set to Two Speed and Unit Type is not equal to HP O/B Ctrl.

Compressor 1 and Compressor 2 Test

The compressor test points are used to change output status for the individual compressors. Compressor starts are not staggered. The fan and heating service test outputs are reset to "Disable" for the compressor service tests. The Indoor fan and outdoor fans are controlled normally to maintain proper unit operation. All normal cooling alarms and alerts are functional.

NOTE: Compressor 1 is always operated with Compressor 2 due to outdoor fan control on Compressor 1. Always test Compressor 1 first, and leave it on to test Compressor 2.

Heat 1 and Heat 2 Test

The heat test points are used to change output status for the individual heat stages, gas or electric. The fans and cooling service test outputs are reset to "Disable" for the heat service tests. Indoor and outdoor fans are controlled normally to maintain proper unit operation. All normal heating alarms and alerts are functional.

Reversing Valve Test

This test point activates the DO7 relay at J11. These rooftop units do not use reversing valve control for heat pumps, therefore this test is not used.

Dehumidification Test

For units with the factory Reheat option, the dehumidification relay is used to change the output status to operate the circuits in different Reheat modes. Dehumidification relay on by itself puts all circuits running in Hot Gas Reheat dehumidification mode; dehumidification relay on and the cooling test (compressor test relays) on puts unit and or individual circuits in subcooling dehumidification mode. The fans and heating service test outputs are reset to “Disable” for the dehumidification service test. Indoor and outdoor fans are controlled normally to maintain proper unit operation. All normal cooling/dehum alarms and alerts are functional.

Power Exhaust Test

This point allows the board's power exhaust (PE) output to be manually turned On (Enable) and Off (Disable). Power Exhaust test can operate simultaneously with other Service Test Points.

Economizer Test

This point allows the board's economizer output to be manually controlled from 0 to 100 % Open. Economizer test can operate simultaneously with other Service Test Points.

Analog Output 2 Test

This test point activates the AO2 0-10vdc analog output at J22. These rooftops do not use this output, therefore this test is not used.

NOTE: Service Test Mode does not timeout. Be sure to turn off test mode or cycle power to the RTU to return to normal operation.

Configuration

The RTU Open controller's configuration points effect the unit's inputs and operation. Review and understand the meaning and purpose of each configuration point before changing it from the factory default value. Use the RTU Open Start-up Sheet during configuration; fill in changed values if changed from factory default. There are three main configurations menus: SETPOINT, UNIT, and SERVICE. Each configuration point is described below under its according menu. See Appendix A for BACview menu structure.

Setpoint

Occupied Heating Setpoint - The heating setpoint the controller maintains during the occupied period.

Range = 40-90°F Default = 70°F

Occupied Cooling Setpoint - The cooling setpoint the controller maintains during the occupied period.

Range = 55-99°F Default = 76°F

Unoccupied Heating Setpoint - The heating setpoint the controller maintains during the unoccupied period.

Range = 40-90°F Default = 55°F

Unoccupied Cooling Setpoint - The cooling setpoint the controller maintains during the unoccupied period.

Range = 45-99°F Default = 90°F

Effective Heating Setpoint - The current setpoint value heating operation will control to.

Range = 0-120°F

Effective Cooling Setpoint - The current setpoint value cooling operation will control to.

Range = 0-120°F

Optimal Start - The earliest time prior to occupancy, at which the Optimal Start function may begin to adjust the effective setpoints. Setting this to 0 will disable optimal start.

Range = 0-4 hours Default = 4 hours

Occ Relative Humidity Setpoint - The space RH setpoint the controller maintains during the occupied period.

Range = 0 to the Unocc RH setpoint

Default 60%

Unocc Relative Humidity Setpoint - The space RH setpoint the controller will maintain during the unoccupied period.

Range = 30-100% Default = 95%

DCV Max Ctrl Setpoint - The difference between indoor and outdoor CO₂ level which results in maximum ventilation damper position.

Range = 0-9999ppm Default = 650ppm

Power Exhaust Setpoint - When the economizer damper position opens above this point the power exhaust operation will begin. When the damper position falls below this point and 5% lower the power exhaust will shutdown.

Range = 20-90% Default = 50%

NOTE: This point is only used when Continuous Occupied Exhaust = NO

Unit

Fan Mode - Sets the operation of the indoor fan when not in cooling or heating mode. Refer to fan operation for details on each operation.

Range = Auto, Continuous, or Always On

Default = Continuous

Power Fail Restart Delay - Sets how long the controller delays normal operation after the power is restored. Typically used to prevent excessive demand when recovering from a power failure

Range = 0-30 sec Default = 5 sec

Fan Off Delay - Time delay in which the fan will continue run after being commanded off.

Range = 10-300sec Default = 90sec

Minimum Cooling SAT - The supply air temperature must remain above this value to allow cooling with the economizer and/or compressors. There is 5°F plus and minus deadband to this point. If the SAT falls below this value during cooling a compressor stage will be removed and/or the economizer will return to minimum position.

Range = 45-75°F Default = 50°F

Maximum Heating SAT - The supply air temperature must remain below this value to allow heating. There is 5°F plus and minus deadband to this point. If the SAT falls below this value during heating the heat stages will begin to decrease until the SAT has dropped below this value.

Range = 85-150°F Default = 120°F

Vent Dmpr Pos / DCV Min Pos - Minimum damper position for ventilation during the occupied period

Range = 0-100% open Default = 20% open

DCV Max Vent Damper Pos – This is the greatest position the economizer can open to while trying to control the indoor air quality levels

Range = 0-75% open Default = 50% open

S Fan Service Alarm Timer – The timer set for the Supply Fan Runtime Alarm. After the number of hours set on this point is exceeded the corresponding alarm will be generated, and must be manually cleared in the maintenance menu after the maintenance has been completed. The timer will then begin counting its runtime again for the next due maintenance.

Range = 0 to 9999 hr Default = 600 hr

NOTE: If set to 0 hr this setpoint is disabled and its alarm will never be generated.

Comp 1 Service Alarm Timer – The timer set for the Compressor 1 Runtime Alarm. After the number of hours set on this point is exceeded the corresponding alarm will be generated, and must be manually cleared in the maintenance menu after the maintenance has been completed. The timer will then begin counting its runtime again for the next due maintenance.

Range = 0 to 9999 hr Default = 0 hr

NOTE: Default = 0 hours, if set = 0 hr this point is disabled and its alarm will never be generated.

Comp 2 Service Alarm Timer – The timer set for the Compressor 2 Runtime Alarm. After the number of hours set on this point is exceeded the corresponding alarm will be generated, and must be manually cleared in the maintenance menu after the maintenance has been completed. The timer will then begin counting its runtime again for the next due maintenance.

Range = 0 to 9999 hr Default = 0 hr

NOTE: Default = 0 hours, if set = 0 hr this point is disabled and its alarm will never be generated.

Filter Service Alarm Timer – The timer set for the Dirty Filter Alarm. After the number of hours set on this point is exceeded the corresponding alarm will be generated, and must be manually cleared in the maintenance menu after the maintenance has been completed. The timer will then begin counting its runtime again for the next due maintenance.

Range = 0 to 9999 hr Default = 600 hr

NOTE: Default = 600 hours, if set = 0 hr this point is disabled and its alarm will never be generated.

Pushbutton Override – Set to enable or disable the pushbutton override function of the locally installed space sensor.

Range = Disable/Enable Default = Enable

Setpoint Adjustment – Set to enable or disable the setpoint adjustment function of the locally installed space sensor.

Range = Disable/Enable Default = Enable

Setpoint Adjustment Range – Sets the slider range of a space sensor (with built in function). The slider is used to offset the control setpoint.

Range = 0 to 5°F Default = 5°F

Cooling Lockout Temperature – This defines the minimum outdoor air temperature that cooling mode can be enabled and run. If the OAT falls below this number during cooling the compressors will be de-energized.

Range = 0-80°F Default = 45°F

Economizer High OAT Lockout Temp – If the outdoor air temperature rises above this value, economizer cooling will be disabled and dampers will return and stay at minimum position.

Range = 55-80°F Default = 75°F

HP Rev Cycle Lockout Temp – If the outdoor air temperature falls below this value, the compressors will not be allowed to run for heating. Unit Type must be set to Heat pump for this to be active.

Range = -20-30°F Default = -3°F

Heating Lockout Temperature – This defines the maximum outdoor air temperature that heating mode can be enabled and run. If the OAT rises above this number during heating the heat stages will be de-energized.

Range = n/a Default = 65°F

Pre-Occupancy Purge – Enables or disables the use of a purge cycle immediately prior to the start of a scheduled occupied period.

Range = Enable/Disable Default = Disable

Purge Time – The maximum amount of time used for a pre-occupancy purge.

Range = 0 to 240 minutes Default = 60 minutes

Unocc Free Cool Enable – Set to enable or disable the economizer for night time free cooling (NTFC) operation.

Range = Disable/Enable Default = Disable

Setpoint Separation – Sets the minimum separation gap in which setpoints can be set.

Range = 2-10°F Default = 5°F

Occupancy Source – Tells the controller which method of occupancy control to use in determining occupancy of the rooftop. Refer to Occupancy in the operation section for detail on each specific operation function.

Range = Always Occupied, BACnet Schedule, BAS On/Off, or Remote Occ Input

Default = Always occupied

Inputs

Input 1 Function – This input is an analog input and can be configured to be one of four different inputs: No Sensor, IAQ Sensor, OAQ Sensor, or Space RH Sensor. Input 1 is wired to pin J4-4,5,6.

Default = No Sensor

Input 2 Function – This input is an analog input and can be configured to be one of four different inputs: No Sensor, IAQ Sensor, OAQ Sensor, or Space RH Sensor. Input 2 is wired to pin J4-1,2,3.

Software Default = No Sensor

Factory Default = IAQ Sensor with factory installed CO₂ sensor

Input 3 – This input is a discrete input and can be configured to be one of six different functions: No Function, Compressor Safety, Fan Status, Filter Status, Remote Occupancy, or Door Contact. This input can also be configured to be either a Normally Open (N/O) or a Normally Closed (N/C) switch. Input 3 is factory wired to pin J1-2. Field accessories can be wired to its parallel pin J5-5.

Factory Default = Compressor Safety and N/O

Input 5 - This input is a discrete input and can be configured to be one of six different functions: No Function, Fire Shutdown, Fan Status, Filter Status, Remote Occupancy, or Door Contact. This input can also be configured to be either a Normally Open (N/O) or a Normally Closed (N/C) switch. Input 5 is factory wired to pin J1-10. Field accessories can be wired to its parallel pin J5-3.

Software Default = Fire Shutdown and N/C

Factory Default = Fire Shutdown and N/O

Input 8 - This input is a discrete input and can be configured to be one of six different functions: No Function, Enthalpy Switch, Fan Status, Filter Status, Remote Occupancy, or Door Contact. This input can also be configured to be either a Normally Open (N/O) or a Normally Closed (N/C) switch. Input 8 is factory wired to pin J2-6. Field accessories can be wired to its parallel pin J5-1.

Software Default = Enthalpy Switch and N/O

Factory Default = No Function and N/O without factory installed enthalpy sensor

Input 9 - This input is a discrete input and can be configured to be one of six different functions: No Function, Humidistat, Fan Status, Filter Status, Remote Occupancy, or Door Contact. This input can also be configured to be either a Normally Open (N/O) or a Normally Closed (N/C) switch. Input 9 is factory and field wired to pin J5-7.

Factory Default = Humidistat and N/O

Space Sensor Type - This tells the controller what type of space sensor is installed to run the unit. The three types that can be used are: a standard 10k Type II thermistor (T55), sensor with a setpoint offset slider bar (T56), or a communicating sensor (SPT Sensor).

Range = T55, T56 (Use for T59), or SPT Sensor
Default = T55

T5x Override Duration - Sets the override time duration the unit will change from unoccupied to occupied when the override button is pushed on the space sensor.

Range = 0-24 hours Default = 1 hour

Service

Unit Type - This tells the control what type of unit it is controlling. Heat/Cool refers to gas and electric heat units. HP O/B Ctrl refers to a heat pump unit which requires reversing valve control. HP Y1/W1 Ctrl refers to a heat pump unit whose reversing valve is built in to the cooling or heating call.

Factory Default = Heat/Cool for non-heat pump units, or HP Y1/W1 Ctrl for heat pump units.

Compressor Stages - This refers to the number of mechanical cooling stages available on a specific unit. Set this point to "One Stage" if there is one compressor in the specific unit, set to "Two Stage" if there are two compressors in the unit, and set to "None" if economizer cooling ONLY is desired.

Factory Default = "One Stage" for 1 compressor units, or "Two Stages" for 2 compressor units

Economizer Exists - This tells the controller if there is an economizer installed on the unit.

Factory Default = NO if no economizer, or YES if there is an economizer installed

Reversing Valve Output - Sets the heat pump's (HP O/B Ctrl type) reversing valve function. O output type refers to a valve that is energized for cooling, and B output type refers to a valve that is energized for heating. 50TCQ and 50HCQ heat pumps do not require O/B signals.

Default = O output type

Fan Control - The type of fan control used on the unit.

Range = Single Speed, Two Speed, or Variable Speed

Default = Single Speed

Heat Type - Tells the controller which type of heat the unit is capable of. Electric is any unit without gas and a Gas unit is one which requires gas input for heating. 50TCQ and 50HCQ heat pumps should be configured for Electric.

Factory Default = Electric for cooling only units and heat pumps, or Gas for gas units.

Number of Heat Stages - Tells the controller how many heat stages outputs are available for use. See configuration in Appendix A for details on specific unit configuration.

Factory Default = 1 for single heat stage units, 2 for dual stage units, or 0 for cooling only units.

RH Controls - Enables dehumidification control if an RH sensor is available and the unit has the Humidi-MiZer dehumidification option installed.

Range = Disable/Enable

Default = Disable

(Enabled with Humidi-MiZer option)

Continuous Occupied Exhaust - This point tells the controller when to run the power exhaust if equipped on the unit.

If set to YES, the power exhaust will be on all the time when in occupied mode and will be off when in unoccupied mode. If set to NO the power exhaust will be controlled by the Power Exhaust Setpoint.

Default = NO

DCV Control - Enables demand controlled ventilation (DVC) if valid CO₂ sensor value is available and the unit has an economizer installed.

Range = Disable/Enable Default = Disable

Indoor CO₂ Sensor Value @ Min mA - Sets the indoor CO₂ value when the board reads 4 mA at input 1 or 2.

Range = 0 to 9999 ppm Default = 0 ppm

Indoor CO₂ Sensor Value @ Max mA - Sets the indoor CO₂ value when the board reads 20 mA at input 1 or 2.

Range = 0 to 9999 ppm Default = 2000 ppm

Outdoor CO₂ Sensor Value @ Min mA - Sets the outdoor CO₂ value when the board reads 4 mA at input 1 or 2.

Range = 0 to 9999 ppm Default = 0 ppm

Outdoor CO₂ Sensor Value @ Max mA - Sets the outdoor CO₂ value when the board reads 20 mA at input 1 or 2.

Range = 0 to 9999 ppm Default = 2000 ppm

NOTE: The indoor and outdoor min and max mA setting are used to set the linear curve of mA vs. PPM.

Clockset

This submenu screen allows you to set the date and time manually. The Daylight Savings Time (DST) can also be changed here. The date and time is automatically set whenever software is downloaded. The clock is a 24 hour clock and not am/pm. The time should be verified (and maybe changed) according to unit location and time zone.

Factory Default = Eastern Standard Time

USERPW

This submenu screen allows you to change the user password to a four number password of choice. The User password change screen is only accessible with the Administrator Password (1111). The ADMIN password will always override the user password.

Factory Default = 0000

Range = 0000-9999

OPERATION

The RTU Open will control the compressors, economizer and heating outputs based on its space temperature input and setpoints. It can also be controlled by a building control system or zoning system. An optional CO₂ IAQ sensor mounted in the space can influence the economizer minimum position. The RTU Open has a hardware clock that can allow scheduling for stand-alone operation. The RTU Open's default is to control to occupied setpoints all the time, until a type of occupancy control is set. The following sections describe the operation for the functions of the RTU Open.

Occupancy

Occupancy is the fundamental overall control of equipment. The unit can be in one of two states: Occupied or Unoccupied. These are usually referred to as periods because they represent periods of any given day. Before RTU Open can operate specific functions of the equipment it is installed on, occupancy must be determined. There are four different ways RTU Open can determine occupancy. These are described below and selected by the configuration point Occupancy Source.

Always Occupied (Default)

The unit will not determine occupancy and continuously run in the occupied state or period. RTU Open ships from the factory with this setting to allow immediate operation.

BACnet Schedule

When Occupancy Source is set to BACnet Schedule, RTU Open will use a schedule to change occupancy based upon a day of week and a time period. Local time and date should be set in the RTU Open for this function to operate properly. This function applies if setting a local schedule in the RTU Open or if applying the unit to an i-Vu Open network or an Open zoning system. An Open network schedule can override a local schedule within the unit. A space sensor push button override is only available when running a local or Open schedule. The push button will override an unoccupied period to occupied for the specified time duration.

BAS On/Off

When Occupancy Source is set to BAS On/Off, RTU Open follows occupancy based on an On/Off command to the BAS ON/OFF software point. An on command sets the occupancy to occupied, and an off command sets it to unoccupied. The Building Automation System can be speaking BACnet, Modbus, N2, or LON and is writing to the BAS On/Off point in the open protocol point map.

Remote Occ Input

When Occupancy Source is set to Remote Occ Input, RTU Open follows occupancy based on the remote occupancy switch input. Inputs 3, 5, 8, and 9 on plug J5 can be hard-wired to command the unit's occupancy. The Occupancy Contact point show the status as on or off, on is occupied and off is unoccupied.

Indoor (Supply) Fan

The indoor fan can be configured to operate in three different manors. The configuration point Fan Mode determines how the fan will run. The fan will always be disabled if a fire shutdown or safety chain alarm is active. A valid space temperature and supply air temperature must be available for the fan to operate. There is a unit start delay in effect when the unit is transitioning from unoccupied to occupied. The following describes specific fan operation based on the Fan Mode configuration value.

Auto

When Fan Mode is set to Auto, RTU Open will cycle the fan on and off based on the demand for heating, cooling, and dehumidification. There is a configurable fan off delay that is upheld before shutting the fan off after conditioning has ended.

Continuous

When Fan Mode is set to Continuous, RTU Open will cycle the fan based on occupancy. The fan will run the whole occupied period and operate in the auto mode during the unoccupied period.

Always On

When Fan Mode is set to Always On, RTU Open will run the fan all the time regardless of occupancy or demand.

The RTU Open has an optional Supply Fan Status input to provide proof of airflow. If this is enabled, the point will look for a contact change whenever the Supply Fan Relay is on. If it is not enabled then it will always be the same state as the Supply Fan Relay. The cooling, economizer, heating, dehumidification, CO₂ and power exhaust routines will use this input point for fan status.

Cooling

The compressor outputs are controlled by the Cooling Control PID Loop and Cooling Stages Capacity algorithm. They will be used to calculate the desired number of stages needed to satisfy the space by comparing the Space Temperature (SPT) to the Occupied Cool Setpoint plus the T56 slider offset when occupied and the Unoccupied Cool Setpoint (UCSP) plus the T56 slider offset, if unoccupied. The economizer, if available, will be used for cooling in addition to the compressors. The following conditions must be true in order for this algorithm to run:

- Indoor Fan has been ON for at least 30 seconds.

- Heat mode is not active and the time guard between modes equals zero.
- If occupied and the SPT > (occupied cool setpoint plus the T56 slider offset).
- Space Temperature and supply air temperature values are available.
- If it is unoccupied and the SPT > (unoccupied cool setpoint plus the T56 slider offset). The indoor fan will be turned on by the staging algorithm.
- If economizer is available and active and economizer open > 85% and SAT > (SAT low limit + 5°F) and SPT > effective set point + 0.5°F.

OR

Economizer is available, but not active

OR

Economizer is not available

- OAT > DX Lockout temperature

If all of the above conditions are met, the controller uses a PID logic loop to energize or de-energize compressors to satisfy the cooling demand.

There is a fixed 3-minute minimum on time and a 5-minute off time for each compressor output and a 3-minute minimum time delay between staging up or down.

Any time the compressors are running the RTU Open will stage down the compressors if the SAT becomes less than the cooling low supply air setpoint. After a compressor is staged off, it may be started again after a normal time-guard period and the supply air temperature has increased above the low supply air setpoint.

Supply Fan

The RTU Open supply fan may be configured for 1 of 3 Fan Control modes:

- **Single** - The fan operates at one speed only and provides on/off operation
- **Two Speed** - The fan operates at 1 of 2 speeds depending on the mode of operation and load conditions. During fan only, dehumidification, or single stage cooling, the fan operates at low speed. During heating, second stage cooling, or if maximum economizer operation is required, the fan operates at high speed.
- **Variable Speed** - The fan operates at a variable speed to meet the load conditions and SAT safety requirements to provide maximum energy savings by minimizing fan horsepower consumption. Fan speed is NOT controlled by static pressure.

The RTU Open supply fan may be configured for 1 of 3 Fan Modes:

- **Auto** - The fan cycles on/off in conjunction with heating or cooling.
- **Continuous** - The fan runs continuously during occupancy and intermittently during unoccupied periods with heating and cooling.

- **Always On** - The fan runs continuously regardless of occupancy or calls for heating and cooling.

Occupancy can be determined by Linkage, BACnet schedules, BAS schedules, or in response to a remote occupancy switch.

A Fan Off Delay allows the supply fan to continue operating after heating or cooling stops.

If the following alarms are active, the fan turns off immediately, regardless of the occupancy state or demand:

- Fire Shutdown
- Safety chain
- SAT alarm
- SPT alarms

The RTU Open does not include smoke-control functions such as a smoke-purge, zone-pressurization, or smoke-ventilation. Each of these modes require a field-designed circuit to operate the following by local fine codes:

- RTU supply fan
- RTU economizer
- RTU power exhaust

The RTU Open may be configured to accept a Supply Fan Status input to provide proof the supply fan is operating. When enabled, a loss or lack of fan status will stop heating and cooling operation.

A supply Fan Alarm Service Timer function is available to track the number of supply fan run hours and generate an alarm when the accumulated runtime exceeds the set threshold.

Economizer

The Economizer dampers are used to provide free cooling and Indoor Air Quality, if optional CO₂ sensor is installed, when the outside conditions are suitable.

The following conditions must be true for economizer operation:

- Indoor Fan has been on for at least 30 seconds.
- Enthalpy is Low if the Enthalpy input is enabled.
- SAT reading is available.
- OAT reading is available.
- SPT reading is available.
- OAT ≤ High OAT economizer lockout configuration (default = 75).
- OAT ≤ SPT

If the RTU Open is configured for VFD or 2-speed fan, and the fan is on high speed or is configured for single-speed fan, and any of the preceding conditions are not true, the economizer will be set to the Vent Dmpr Pos/DCV Min Pos setpoint. If it is configured for VFD or 2-speed fan, and the fan is on low speed, and any of the preceding conditions are not true, the economizer will be set to the Low Fan Econ Min Pos.

If any of the mentioned conditions are not true, the economizer will be set to its configured minimum position. The minimum damper position can be overridden by the IAQ routine described later in this section.

If the above conditions are true, the Economizer control will calculate a damper position starting with a minimum

vent position and based on current space temperature and a setpoint that is halfway between the effective cool and heat setpoints. If the SAT drops below the cooling low supply air setpoint (+ 5°F), the economizer will ramp down to minimum position.

Power Exhaust

RTU Open may enable and disable an exhaust fan based on either the controller's occupancy or its economizer damper position. If configured for continuous occupied operation, it will be energized whenever the controller is in the occupied mode and disabled when in the unoccupied mode. If configured for damper position control, it will be energized whenever the economizer exceeds the power exhaust setpoint and disabled when the economizer drops below the setpoint by a fixed hysteresis of 10%. If the Fan Control is set to Two Speed or Variable Speed, the Power Exhaust Setpoint is automatically adjusted based on the fan's air delivery. The Calculated PE Setpoint used for control is displayed in the Maintenance section.

Pre-Occupancy Purge

Pre-Occupancy Purge allow the rooftop equipment with an economizer damper to utilize outdoor air to purge the space of contaminants just prior to the beginning of the of the occupied period.

The following conditions must be true for pre-occupancy purge to operate:

- Pre-Occupancy Purge set to Enable
- Economizer Exists set to Yes
- A local time schedule is configured
- The local time schedule is currently unoccupied and the remaining time is less than the configured Purge Time

When the RTU Open schedule is unoccupied and the remaining unoccupied time is less than the purge time, the supply fan starts. The economizer damper opens to the configured Economizer Purge Min Pos. The RTU Open continues to operate in this mode until the occupied start time is reached. The Pre-Occ Purge state is displayed in the Maintenance section.

Heating

The heat outputs are controlled by the Heating Control PID Loop and Heating Stages Capacity algorithm. They will be used to calculate the desired number of stages needed to satisfy the space by comparing the SPT to the Occupied Heat Setpoint the T56 slider offset when occupied and the Unoccupied Heat Setpoint plus the T56 slider offset if unoccupied. The following conditions must be true in order for this algorithm to run:

- Indoor Fan has been ON for at least 30 seconds.
- Cool mode is not active and the time guard between modes equals zero.
- If occupied and $SPT < (\text{occupied heat setpoint plus T56 slider offset})$
- SPT and supply air temperature values are available
- If it is unoccupied and the $SPT < (\text{unoccupied heat setpoint plus T56 slider offset})$. The indoor fan will be turned on by the staging algorithm.
- $OAT < \text{High OAT lockout temperature}$.

If all of the above conditions are met, the controller uses a PID logic loop to energize or de-energize heat outputs to satisfy the heat demand. If the SAT begins to exceed the high supply air setpoint, a ramping function will cause the Heat Stages Capacity algorithm to decrease the number of stages until the SAT has dropped below the setpoint. There is a fixed one minute minimum on time and a one minute off time for each heat output. Heat staging has a 2 minute stage up and 30 second stage down delay.

Heat pump operation is the same as above except for what is explained below. There is a fixed 3 minute on and 5 minute off time for the first heat stage output, and a one minute on and one minute off time for the second heat stage output. There is a 10 minute minimum stage up delay if the heat demand is $\leq 3^\circ\text{F}$, and a 2 minute minimum stage up delay if heat demand is $> 3^\circ\text{F}$. The stage down delay is still 30 seconds. If the Compressor Safety Alarm is active, the second heat stage will come on with the first stage with no delay.

Indoor Air Quality

If the optional indoor air quality sensor is installed, the RTU Open will maintain indoor air quality within the space at the user configured differential set point. The set point is the difference between the indoor air quality and an optional outdoor air quality sensor. If the outdoor air quality is not present then a fixed value of 400ppm is used. The following conditions must be true in order for this algorithm to run:

- The mode is occupied.
- Indoor Fan has been ON for at least 30 seconds.
- Indoor Air Quality sensor has a valid reading.

As air quality within the space changes, the minimum position of the economizer damper will be changed thus allowing more or less outdoor air into the space depending on the relationship of the indoor air quality to the differential setpoint. If all the above conditions are true, the IAQ algorithm will run and calculates an IAQ minimum position value using a PID loop. The IAQ minimum damper position is then compared against the user configured economizer minimum position and the greatest value becomes the final minimum damper position of the economizer output.

If the calculated IAQ minimum position is greater than the DCV Max Vent Damper Pos configuration, then it will be clamped to the configured value.

Dehumidification

The RTU Open will provide occupied and unoccupied dehumidification only on units that are equipped with the Humidi-MiZer™ option from the factory. This function requires a space relative humidity sensor or a humidistat for control. The space relative humidity sensor can be installed and configured as one of the two analog input channels (inputs 1 or 2 on J4), or a humidistat can be installed and configured as switch input 9 on J5. When using a relative humidity sensor to control dehumidification, occupied or unoccupied dehumidification setpoints are used accordingly. When using a humidistat, setpoints are not used and the dehumidification call comes when the humidistat indicates high humidity.

When the indoor relative humidity becomes greater than the dehumidification setpoint (or switches from low to high), a dehumidification demand will be acknowledged. Compressor state is monitored and time guards are honored. If a compressor was just turned off prior to the dehum call the dehumidification output will be delayed the 5 minute minimum off time of the compressor. When ok to dehumidify, the dehumidification output (J11-7, 8) will be energized. This will bring on the supply fan (at high fan speed if Fan Control is set to “Two Speed”), all compressors, and the dehumidification relay placing the unit in Hot Gas Reheat dehumidification mode. If dehumidification is called for during cooling or cooling is called for during dehumidification, the unit will run in Subcooling dehumidification mode. Individual unit circuits can be in different dehumidification modes based on the demand. Refer to the base units operation for additional information.

NOTE: There is a fixed 5% hysteresis that the indoor relative humidity must drop below the active setpoint to end the dehumidification mode and de-energize the dehumidification output. The output will also de-energize if the fan relay is de-energized.

Demand Limit

If the RTU Open receives a level 1 (one degree offset), 2 (two degree offset), or a 3 (4 degree offset) to the BACnet demand limit variable, the controller will outwardly expand the heating and cooling setpoints by the configured demand limit setpoint value and remain in effect until the BACnet demand limit variable receives a 0 value.

Unoccupied Free Cooling

When the unit is equipped with an economizer, the control can run a night time free cooling (NTFC) mode called Unocc Free Cooling. In this mode the damper is utilized to bring in outdoor air for free cooling during unoccupied periods. The following conditions must be true for unoccupied free cooling to operate:

- Unocc Free Cool Enable set to Enable
- The system is unoccupied
- The outside air temperature is below the Economizer High OAT Lockout Temp
- The outside air temperature is less than the space temperature
- Enthalpy (if enabled) is Low

When the RTU Open schedule is unoccupied and the space temperature rises at least 1 degree above the Occupied Cooling Setpoint, the supply fan starts. The economizer damper opens as necessary to cool the space. The RTU Open continues to operate in this mode until the space is satisfied or the outside air conditions are no longer suitable for free cooling.

Optimal Start

The RTU Open may utilize Optimal Start, which adjusts the effective setpoints to achieve the occupied setpoints by the time scheduled occupancy begins. The Optimal Start recovery period may begin as early as 4 hours prior to occupancy. The algorithm works by moving the unoccupied setpoints toward the occupied setpoints. The

rate at which the setpoints move is based on the outside air temperature, design temperatures, and capacities. The following conditions must be true for unoccupied free cooling to operate:

- Under SETPOINT, Optimal Start Value must be set greater than zero and less than or equal to four (0 disables Optimal Start.)
- The system is unoccupied
- The RTU Open has a valid outside air temperature
- The RTU Open is running occupancy based on a schedule, where next time occupied is known.

Fire Shutdown

Fire Shutdown may be configured on Binary Input 5. A typical application involves a smoke detector or fire shutdown contact, which, when active, immediately shuts down equipment operation.

Compressor Safety

Compressor Safety may be configured on Binary Input 3. A compressor safety tripped indicator circuit is available on most Carrier rooftop equipment. A Compressor Safety Alarm indicates that the equipment requires attention. Cooling, heating, and supply fan outputs are not interrupted except where the RTU Open is configured for Heat Pump operation. When configured for Heat Pump, and in the heating mode, a compressor safety fault will cause the available stages of electric heating to be enabled in place of mechanical heating. Normal operation resumes when the compressor safety circuit is de-energized.

Fan Status

Fan Status may be configured on any unused binary input channel. A typical application would be an airflow switch, current sensing relay, or other device that provides a supply fan running verification. Enabling this function displays the supply fan's status on the equipment graphic. If the controller loses fan status during operation, heating and cooling are disabled, the economizer damper (if available) is closed, and an alarm for loss of status is indicated. If the fan status is on when the controller is commanding the fan off, the unit remains in the off state. An alarm is generated indicating that the fan is running when it should be off.

Filter Status

Filter status may be configured on any unused binary input channel. A typical application is a differential pressure switch that senses the pressure drop across a filter bank. When the pressure across the filter bank exceeds the setpoint of the differential pressure switch, the Filter status is displayed as Dirty on the controller graphic. An alarm indicates a dirty filter.

Door Switch

A Door Contact may be configured on any unused binary input. A typical application is an occupancy sensor mounted within the space served by a single zone rooftop. Door Contact disables mechanical cooling and electric or gas heating, when active. Economizer cooling, if available, continues to operate.

Linkage

The RTU Open may serve as an air source to an Open Variable Volume and Temperature (VVT) system. When the RTU Open is part of a VVT system and the controllers are wired together to form a network, the controllers may use a method of communication known as Linkage™. Linkage is a method by which an air source and its subordinate zone terminals exchange data to form a coordinated HVAC system. The system's air source controller, zone controllers, and bypass controller are linked so that their data exchange can be managed by one zone controller configured as the VVT Master. The VVT Master gathers the following information from the slave zone controllers:

- occupancy status
- setpoints
- zone temperature
- relative humidity
- CO₂ level
- damper position
- optimal start data

The VVT Master performs mathematical calculations and algorithms on the data and then sends the composite information to the air source. The VVT Master receives information from the air source such as mode, supply air temperature, and outside air temperature, and passes that information to all linked controllers.

Linkage Air Source Modes

In a linked system, the air source determines its operating mode and qualifies that mode based on its own Supply Air Temperature (SAT). The following modes can be sent by the air source depending on its configuration:

- Off – Air source fan is off
- Fan Only – Air source fan is on and providing ventilation (neutral SAT) without heating or cooling
- Economizer Cooling – Air source fan is on and providing cooling, using economizer only
- Cooling – Air source fan is on and cooling is provided by economizer and mechanical cooling
- Heating – Air source fan is on and heating is provided (gas or electric)
- Dehumidification – Air source fan is on and Humidi-MiZer is active
- Test – The RTU Open Service Test mode is active
- Shutdown – Air source fan is off due to Safety Chain, Fire Shutdown, or invalid SAT sensor
- Unocc Free Cooling – Air source fan is on, with the economizer providing cooling while unoccupied

TROUBLESHOOTING

General

The RTU Open controller acts as an intelligent imbedded thermostat to the rooftop unit, but can be monitored and controlled from i-Vu Open (Linkage) or a 3rd party network. This causes the system as a whole to be troubleshot from three points of view. The three parts to the system are the rooftop unit, the Open controller, and the network

connected. Determining which part needs to be troubleshot is the first step.

The Open controller can be used to troubleshoot the rooftop unit and/or itself with service test, communicating LED's, and built in alarms. Disconnecting the RTU Open from the network may also help troubleshooting the controller and rooftop unit. Third Party Network troubleshooting may also be required. For base unit troubleshooting, refer to specific base unit Service Maintenance manual.

There is an on-board battery that is used for RAM and clock back-up. It is a 3-volt lithium battery (CR2032). The average life is 7 years with a minimum of 10,000 hours of back-up. When the RTU Open board is powered up, the battery is not being used. If power is lost, the battery backs up the time clock. Battery replacement should be done with the board powered up.

Thermistor Troubleshooting

RTU Open uses thermistors to sense temperatures for control operation of the unit. Resistances at various temperatures are listed in Table 2. Thermistor pin connections are shown in Table 1. Thermistors are used for supply air temperature (SAT), outdoor air temperature (OAT), and space temperature (SPT) and all must be a 10 kilo-ohm type II sensor.

Table 2 – Thermistor Resistance vs Temperature Values for Space Temperature Sensor, Supply Air Temperature Sensor, and Outdoor Air Temperature Sensor

TEMP (C)	TEMP (F)	RESISTANCE (Ohms)
-40	-40	335,651
-35	-31	242,195
-30	-22	176,683
-25	-13	130,243
-20	-4	96,974
-15	5	72,895
-10	14	55,298
-5	23	42,315
0	32	32,651
5	41	25,395
10	50	19,903
15	59	15,714
20	68	12,494
25	77	10,000
30	86	8,056
35	95	6,530
40	104	5,325
45	113	4,367
50	122	3,601
55	131	2,985
60	140	2,487
65	149	2,082
70	158	1,752

To check accuracy, use a high quality digital volt-ohmmeter. Connect the meter to the thermistor leads to obtain a resistance value. Use Table 2 to convert that resistance to a temperature. Next step is to measure temperature at probe location with an accurate thermocouple-type temperature-measuring instrument. Temperature measured by thermocouple and temperature determined from thermistor voltage reading should be

close, within 5°F if care was taken in applying thermocouple and taking readings. If a sensor must be corrected, use the RTU Open's calibration function to offset the temperature reading.

Software Version

During Start-up and throughout the life of the equipment, it may be necessary to obtain the RTU Open's software version. To do this a Modstat must be run on the controller. This can be done from the BACview user

interface by holding the function (FN) key and pressing the period (.) key. An example of the beginning lines of a Modstat is shown in Fig. 16. The application software version shows the current running software of the board. In this case the rtu_open-20100409 refers to RTU Open software version 20100409. This 8 digit number refers to a date (YYYYMMDD). The first 4 digits are the year (2010) and the month and day (0409), so this version is April 9th 2010.

```
07/30/2010  18:12:12          CM: 0

Device Instance: 1610100

Application Software Version: PRG:rtu_open-20100409

1 PRGs loaded.  1 PRGs running.

Module status:
Firmware sections validated in flash memory
=====
Boot16-H_IAR      - v2.09:016   Aug 13 2009
RTU-OPEN DRIVER  - v3.04:101   Mar  8 2010
```

Fig. 16 - Example Modstat

C10825

Communication LED's

The LED's indicate if the controller is speaking to the devices on the network. The LED's should reflect communication traffic based on the baud rate set. The higher the baud rate the more solid the LED's will appear.

Table 3 – LED's

The LED's on the RTU Open show the status of certain functions

If this LED is on...	Status is...
Power	The RTU Open has power
Rx	The RTU Open is receiving data from the network segment
Tx	The RTU Open is transmitting data over the network segment
DO#	The digital output is active

The **Run** and **Error** LED's indicate control module and network status

If Run LED shows...	And Error LED shows...	Status is...
2 flashes per second	Off	Normal
2 flashes per second	2 flashes, alternating with Run LED	Five minute auto-restart delay after system error
2 flashes per second	3 flashes, then off	Control module has just been formatted
2 flashes per second	4 flashes, then pause	Two or more devices on this network have the same ARC156 network address
2 flashes per second	On	Exec halted after frequent system errors or control programs halted
5 flashes per second	On	Exec start-up aborted, Boot is running
5 flashes per second	Off	Firmware transfer in progress, Boot is running
7 flashes per second	7 flashes per second, alternating with Run LED	Ten second recovery period after brownout
14 flashes per second	14 flashes per second, alternating with Run LED	Brownout
On	On	Failure. Try the following solutions: – Turn the RTU Open off, then on. – Format the RTU Open. – Download memory to the RTU Open. – Replace the RTU Open.

Table 4 – RTU Open Alarms

POINT NAME	BACnet Object NAME	ACTION TAKEN BY CONTROL	RESET METHOD	PROBABLE CAUSE
Safety Chain	safety_alarm	Immediate Shutdown	Automatic	Over load Indoor Fan or Electric Heater overheat
Fire Shutdown	fire_alarm	Immediate Shutdown	Automatic	Smoke detected by smoke detector or configuration incorrect
Supply Fan Failure	sfan_fail_alarm	Immediately disable Operation	Automatic	Tripped Circuit Breaker, Broken belt, Bad indoor fan motor, Configuration incorrect, Bad fan status switch.
Supply Fan in Hand	sfan_hand_alarm	Ramp down Operations	Automatic	Bad Fan Status Switch, Configuration incorrect.
Compressor Safety	comp_alarm	Alert Generated	Automatic	Compressor would not start
Space Temp Sensor	spt_fail	Ramp down Operations	Automatic	Faulty, shorted, or open thermistor caused by wiring error or loose connection.
Supply Air Temp Sensor	sat_alarm	Economizer Disabled	Automatic	Faulty, shorted, or open thermistor caused by wiring error or loose connection.
Outdoor Air Temp Sensor Alarm	oat_alarm	Economizer and Low ambient DX cooling lockout disabled.	Automatic	Faulty, shorted, or open thermistor caused by wiring error or loose connection.
Space Relative Humidity Sensor	sprh_alarm	Dehumidification disabled	Automatic	Sensor reading is out of range. Bad sensor, bad wiring, or sensor configured incorrectly.
IAQ Sensor	iaq_alarm	No IAQ Operation	Automatic	Sensor reading is out of range. Bad sensor, bad wiring, or sensor configured incorrectly.
OAQ Sensor	oaq_alarm	Set OAQ to 400	Automatic	Sensor reading is out of range. Bad sensor, bad wiring, or sensor configured incorrectly.
Space Temperature	spt_alm_status	Alert Generated	Automatic	Space value is less then the low allowed value or Space value is greater then the high allowed value
Alarming Temperature	spt_alm_temp	Shows temperature that caused alarm	N/A	N/A
Alarm Limit Exceeded	spt_alm_lmt	Shows the limit that was exceeded	N/A	N/A
High Supply Air Temperature	sat_hi_alarm	Alert Generated	Automatic	SAT is greater then the configuration for more then 5 minutes
Low Supply Air Temperature	sat_lo_alarm	Alert Generated	Automatic	SAT is less then the configuration for more then 5 minutes
Setpoint Slider	slidepot_alarm	Set Offset to zero	Automatic	STO sensor is open for more then 5 seconds
Switch Configuration	di_cfg_alarm	Disable only wrong switch functions	Configure correctly	More then one discrete input is configured to provide the same function.
Analog Input Configuration	ai_cfg_alarm	Disable 4 selectable analog inputs	Configure correctly	More then one analog input is configured to provide the same function.
High Space Relative Humidity	sprh_hi_alarm	Alert Generated	Automatic	IRH is greater then the configuration for more then 15 minutes
Low Space Relative Humidity	sprh_lo_alarm	Alert Generated	Automatic	IRH is less then the configuration for more then 5 minutes
High CO2	co2_alarm	Alert Generated	Automatic	CO2 reading is above the configuration for 1 minute
Supply Fan Runtime	sfan_rntm_alarm	Alert Generated	zero the timer	Supply fan run time exceeded user defined limit
Compressor 1 Runtime	comp1_rntm_alarm	Alert Generated	zero the timer	Compressor run time limit is exceeded
Compressor 2 Runtime	comp2_rntm_alarm	Alert Generated	zero the timer	Compressor run time limit is exceeded
Filter	filter_alarm	Alert Generated	Automatic / reset timer	Dirty Filter, supply fan run time exceeded, filter switch configuration wrong.
Airside Linkage Alarm	air_linkage_fail	Alert Generated	Automatic	Linkage communication failed

Alarms

Alarms are provided to indicate a possible problem with the controller or unit. Alarms can be checked through a network and/or the local access device. All alarms are listed in Table 4 with name, object name, action taken by control, reset method, and possible cause. Some alarms can occur based on specific configurations.

Safety Chain Alarm

This alarm occurs immediately if the supply-fan internal overload trips or if an electric-heat limit switch trips. The Unit Status will be Shutdown and the System Mode will be Disable. All unit operations stop immediately and will not restart until the alarm automatically clears. There are no configurations for this alarm; it is all based on internal wiring. This alarm will not occur if Fire Shutdown Alarm is active. Normal operation resumes when the safety chain circuit is complete.

Fire/Smoke Shutdown Alarm

This alarm occurs immediately when the smoke detector senses smoke. The Unit Status will be Shutdown and the System Mode will be Disable. All unit operations stop immediately and will not restart until the alarm automatically clears. If there is not a smoke detector installed or the smoke detector did not trip, check input configurations. NOTE: The default function for input 5 is a normally open Fire Shutdown input.

Supply Fan Failure

This alarm occurs when the indoor fan is being command on and the fan status switch feedback is showing the fan off. This will end current operating mode and disable unit operation. This alarm requires a fan status switch to be configured on one of the inputs.

Supply Fan in Hand

This alarm occurs when the indoor fan is being commanded off and the fan status switch feedback is showing the fan is on. This will prevent any operating mode and disable unit operation. This alarm requires a fan status switch to be configured on one of the inputs.

Compressor Safety

This alarm indicates the base unit's compressor safety circuit is energized. Cooling, heating, and supply fan outputs are not interrupted except when the RTU Open is configured for Heat Pump. Normal operation resumes when the compressor safety circuit is de-energized. If the Heat Pump is in the heating mode, it will automatically replace the compressor stage(s) with the equivalent number of auxiliary heat stages, as available.

For Heat Pump's with O/B, when configured for two stages of aux heat and two compressors, Compressor 1 is replaced by Aux Heat Stage 1 and Compressor 2 is replaced by Aux Heat Stage 2. The compressor output stays on when the safety alarm is present. For cooling, the alarm indicates the compressors are down.

Space Temp Sensor

This alarm occurs if the space sensor wired to the RTU Open is disconnected or shorted for more than 10 seconds. When this occurs the Unit Status will be Shutdown and the System Mode will be Run. Sensor, sensor connections, wiring, board connection, and configurations should be checked for faults or errors. Alarm will reset automatically when cause is fixed.

Supply Air Temp Sensor

This alarm occurs immediately when the supply air temperature sensor wired to the RTU Open is disconnected or shorted. When this occurs the Unit Status will be Shutdown and the System Mode will be Run. Sensor, sensor connections, wiring, board connection, and configurations should be checked for faults or errors. Alarm will reset automatically when cause is fixed.

Outdoor Air Temp Sensor Alarm

This alarm indicates a shorted or open circuit in the OAT input. Cooling, heating, and supply fan operation continues. OAT lockouts will not operate while the sensor is in alarm. Economizer cooling and optimal start functions are disabled. Normal operation resumes when the controller detects a valid sensor.

Space Relative Humidity Sensor

This alarm indicates the mA input at the associated channel falls below 3.5 mA or rises above 21 mA. Cooling, heating, and supply fan operation continues, however, the controller's Humidi-MiZer™ binary output is disabled until the fault condition is corrected.

IAQ Sensor

This alarm indicates the mA input at the associated channel falls below 3.5 mA or rises above 21 mA. Cooling, heating, and supply fan operation continues. However, the controller's IAQ control function is disabled until the fault condition is corrected.

OAQ Sensor

This alarm indicates the mA input at the associated channel falls below 3.5 mA or rises above 21 mA. Cooling, heating, and supply fan operation continues. However, the controller's IAQ control function uses 400ppm as the fixed outdoor air CO2 level until the fault condition is corrected.

Space Temperature

When Occupied, a Low Space Temperature alarm is generated if the space temperature falls below the lower limit or a High Space Temperature alarm is generated if the space temperature rises above the upper limit.

When Unoccupied, an unoccupied low space temperature alarm is generated when the space temperature falls below the alarm configuration Unoccupied Low SPT Alarm Limit or an unoccupied high space temperature alarm is generated when the space temperature rises above the alarm configuration Unoccupied High SPT Alarm Limit.

The following values are related to the Space Temperature alarm:

Alarming Temperature – This variable displays the value of the space temperature that is in alarm and is only visible when the space temperature is in an alarm state.

Alarm Limit Exceeded – This variable displays the value of the alarm setpoint that is exceeded by the alarming space temperature and is only visible when the space temperature is in an alarm state.

High Supply Air Temperature

This alarm indicates the supply air temperature exceeds the alarm configuration High SAT Alarm Limit for 5 minutes. This alarm is inhibited until the RTU has been running for 30 minutes to allow for system stabilization after startup.

Low Supply Air Temperature

This alarm indicates the supply air temperature falls below the alarm configuration Low SAT Alarm Limit for 5 minutes. This alarm is inhibited until the RTU has been running for 30 minutes to allow for system stabilization after startup.

Setpoint Slider

This alarm indicates an open circuit is detected at the setpoint adjustment input. This can only occur if the Space Sensor Type is set to T56. Note that only an open circuit results in an alarm. A short across this input offsets the setpoints negatively by the amount configured by configuration Setpoint Adjustment Range.

Switch Configuration

This occurs if more than one binary input (inputs 3, 5, 8, and 9) is configured for the same function. When this happens the two inputs (or more) configured wrong will be disabled as an inputs. This alarm will automatically be cleared when configuration is corrected.

An example of this would be: Input 3 = Compressor Safety, input 5 = Fan Status, input 8 = Fan Status, and input 9 = Humidistat; the alarm would be active, unit would run, compressor safety and humidistat would function normally, and Fan Status (inputs 5 & 8) will be interpreted as “No Function.”

Analog Input Configuration

This occurs if more than one analog input (inputs 1 & 2) is configured for the same sensor. When this happens the two inputs will be disabled as inputs. This alarm will automatically be cleared when configuration is corrected.

An example of this would be: Input 1 = IAQ Sensor, input 2 = IAQ Sensor; the alarm would be active, unit would run, but the IAQ Sensor (inputs 1 & 2) will be interpreted as “No Function.”

High Space Relative Humidity

This alarm indicates the space humidity exceeds the alarm configuration High Space Humidity Alarm Limit for 10 minutes. This alarm is inhibited until the RTU runs for 15 minutes to allow for system stabilization after startup.

Low Space Relative Humidity

This alarm indicates the space humidity falls below the alarm configuration Low Space Humidity Alarm Limit for 5 minutes. This alarm is inhibited until the RTU runs for 5 minutes to allow for system stabilization after startup.

High CO₂

This alarm indicates the space CO₂ level exceeds the alarm configuration Occupied High CO₂ Alarm Limit for 1-minute. This alarm will be inhibited until the RTU has been running for 2-minutes to allow for system stabilization after startup.

Supply Fan Runtime

This alarm indicates the accumulated runtime exceeds the unit configuration Supply Fan Service Alarm Timer value (when not set to 0). This alarm is most commonly used to indicate an equipment maintenance interval is due. The supply fan runtime accumulator may be reset by setting the maintenance point Reset Supply Fan Runtime Alarm to Clear, and then back to Run – acknowledging each selection by clicking the OK button when it appears. Setting unit configuration Supply Fan Service Timer value to 0 disables the supply fan runtime alarm function.

Compressor 1 Runtime

This alarm indicates the accumulated runtime exceeds the unit configuration Compressor 1 Service Alarm Timer value (when not set to 0). This alarm is most commonly used to indicate an equipment maintenance interval is due. The Compressor 1 Runtime accumulator may be reset by setting the maintenance point Reset Comp 1 Runtime Alarm to Clear, and then back to Run – acknowledging each selection by clicking the OK button when it appears. Setting unit configuration Compressor 1 Service Timer value to 0 disables the Compressor 1 Runtime alarm function.

Compressor 2 Runtime

This alarm indicates the accumulated runtime exceeds the unit configuration Compressor 2 Service Alarm Timer value (when not set to 0). This alarm is most commonly used to indicate an equipment maintenance interval is due. The Compressor 2 runtime accumulator may be reset by setting the maintenance point Reset Comp 2 Runtime Alarm to Clear, and then back to Run – acknowledging each selection by clicking the OK button when it appears. Setting unit configuration Compressor 2 Service Timer value to 0 disables the Compressor 2 runtime alarm function. Note that this function is unavailable if the service configuration Compressor Stages value is not set to Two Stages.

Filter

This alarm indicates the accumulated runtime exceeds the unit configuration Filter Service Alarm Timer value (when not set to 0). This alarm is most commonly used to indicate a filter replacement is due. Reset the filter service runtime accumulator by setting the maintenance point Reset Filter Runtime Alarm to On, back to Off, and clicking the OK button after each setting. Setting unit configuration Filter Service Alarm Timer value to 0 disables the filter service alarm function.

Airside Linkage Alarm

This alarm indicates that RTU Open was connected to a zoned system called Linkage™ and it lost communications with its linkage master or if it receives invalid data.

Third Party Networking

Third party communication and networking troubleshooting should be done by or with assistance from the front end 3rd party technician. A Module Status Report (Modstat) can be run from the BACview⁶ or Virtual BACview (see Table 5 to perform). This lists information about the board status and networking state. For basic troubleshooting, see Table 6. Refer to the *RTU Open v2 Integration Guide* for additional information.

Table 5 – Manufacture Date

When troubleshooting, you may need to know a control module's manufacture date.


Obtain the manufacture date from a...	Notes
Module status report (modstat)	To obtain a modstat with BACview ⁶ : 1. Press Function (FN) key and hold. 2. Then press period (.) 3. Release both buttons. The report shows the date under Main board hardware .
Sticker on the control board "Serial No: ORTYMxxxxN" (Bar Coded & Typed Number)	The serial numbers are unique and contain embedded information: "ORT" – These first three digits are unique to RTU Open and are used as an identifier. "YM" – These two digits identify the last digit of the year and month (in hex, A=10/Oct) of manufacture. "74" would represent a date of manufacture of "April 2007". "xxxx" – These four digits represent the sequential number of units produced for a given product for the mentioned manufacturing time period. "N" – This final digit represents the decade and toggles between "N" and "M" every ten years.

48-50HCTQ-2T

Table 6 – Basic Protocol Troubleshooting


Problem	Possible cause	Corrective action
No communication with 3rd party vendor	Incorrect settings on SW1, SW2 and SW3	Verify and correct switch settings. Cycle power to RTU Open after changing switch settings.
	RS485 Port has no voltage output (check with RTU Open disconnected from RS485 communication bus): - Bacnet @ 9600/19.2K – .01 to .045vdc - Bacnet @ 38.4K – .06 to .09vdc - Bacnet @ 76.8K – .1vdc - Modbus @ 9600 – 76.8K – .124vdc - N2 @ 9600 – .124vdc	Verify RTU Open has correct power supply.
		Possible bad driver on board.
		Check RS485 bus for external voltage before reconnecting to the bus.
	Verify devices are daisy chained and repeaters and bias terminators are correctly installed.	Check 3rd party vendor RS485 communication wiring guidelines and troubleshooting procedures.

APPENDIX A - USER INTERFACE MENUS
Field Assistant Navigation



BACview Navigation

NOTE: The Tables in Appendix A describe parameters of each of the menu levels shown below.



Modstat screen only reached by (FN + .)

APPENDIX A - USER INTERFACE MENUS (CON'T)

System Settings Menu

BACview Menu	POINT NAME	BACnet Object	RANGE	DEFAULT	Field Assistant Menu
STANDBY	RTU Open System Mode run_status 1 = Off 2 = Fan Only 3 = Economizer 4 = Cooling 5 = Heating 6 = Dehumidification 7 = Test 8 = Shutdown 9 = Unocc Free Cooling (NTFC) 10 = Fire Shutdown 11 = IAQ Override 12 = Pre – OCC Purge Space Temperature space_temp xxx ° F Press any key to activate				
LOGIN/LOGOUT	Admin or User Password		****	User: 0000 Admin: 1111	
HOME	Select function below				
HOME> SYSTEM SETTINGS>	SYSTEM SETTINGS				
BACnet	BACnet Device Instance:		xxxxxxx	1610100	
	Base BACnet Device ID:		xxxxxxx	1610100	
	Autogenerate Device ID?		Y/N	Y	
Keypad	Keypad Configuration				
	Inactivity Timeout:		1 – 255 minutes	10	
	BACnet Write Priority:		0 – 16	0	
UserPw	View/Set User				
	Password:		****	0000	
NETWORK	NETWORK				
	Max Masters	this_device/64	1 – 127	127	
	Max Info Frames	this_device/63	1 – 999	10	
	APDU Timeout (ms)	this_device/11	1 – 10000	3000	
	APDU Retries	this_device/73	1 – 10	3	
	MS/TP Baud Rate	this_device/4161(1)	9600 – 76800	76800	
ClockSet	Set Current Time/Date (24 hr clock)				
	Time (hh:mm:ss):				
	Date (dd – mmm – yy):				
DST	DST				
	Start Time:				
	Amount:				
	Entry #				
	Beg (mm – dd – yy)				
	End (mm – dd – yy)				
TimeMstr	BACnet Time Master				
	Time Sync Mode		No Broadcast Local Broadcast Global Broadcast	No Broadcast	
	Time Sync Interval		1 – 9999 minutes	5	

48-50HCTQ-2T

APPENDIX A - USER INTERFACE MENUS (CON'T)

Status Menus

BACview Menu	POINT NAME	BACnet Object	RANGE	DEFAULT	Field Assistant Menu		
STATUS							
HOME>STATUS	Equipment Status	mode_status	1= Disabled 2= Test 3= Run		Properties>Equipment>Status		
	System Mode	run_status	1= Off 2= Fan Only 3= Economizer 4= Cooling 5= Heating 6= Dehumidification 7= Test 8= Shutdown 9= Unocc Free Cooling (NTFC) 10= Fire Shutdown 11= IAQ Override 12= Pre- occ Purge				
	Supply Fan Status	sfan_status	Off/Running				
	Fan Speed	fan_run	1= Off 2= Low 3= Med 4= High 5= On				
	Supply Fan VFD	vfd_output	0- 100%				
	Space Temperature - Prime Variable	space_temp	xxx ° F				
	Supply Air Temperature	sa_temp	xxx ° F				
	Outdoor Air Temperature	oa_temp	xxx ° F				
	Space Relative Humidity	space_rh	0- 100 %				
	Indoor Air CO2	iaq	0- 5000 ppm				
	Outdoor Air CO2	oaq	0- 5000 ppm				
	Economizer Output	econ_output	0- 100 %open				
	Shutdown	shutdown	Inactive/Active				
	LINKAGE						
	HOME>STATUS>LINKAGE	AIRSIDE LINKAGE				Properties>Equipment>Linkage	
Linkage Collector		link_collector					
Airside Linkage Status		a_link_status	Not Active/Active				
Air Source Mode		link_ahu_mode	1= Off 2= Warmup 3= Heating 4= Cooling 5= Freecool 6= Pressure 7= EVAC 8= Vent				
Air Source Supply Air Temp		link_sat	xxx ° F				
Air Source Outdoor Air Temp		link_ahu_oat	xxx ° F				
If "Airside Linkage Status" is "Active," the following are shown as applicable:							
Number of Providers		link_collector/4602	xx				
Occupancy Status		link_occ	Unoccupied/Occupied				
Space Temperature		link_spt	xxx ° F				
Occupied Cooling Setpoint		link_occ_cl_stpt	55- 80 ° F				
Occupied Heating Setpoint		link_occ_ht_stpt	55- 80 ° F				
Unoccupied Cooling Setpoint		link_unocc_cl_stpt	75- 130 ° F				
Unoccupied Heating Setpoint		link_unocc_ht_stpt	55- 85 ° F				
Indoor Air CO2 (ppm)		link_iaq	xxxx ppm				
Space Relative Humidity		link_sprh	xxx %				
Linkage Max Damper Position		link_max_dmpr	0- 100%				
Linkage Optimal Start		a_link_opt_start	Inactive/Active				
					(BACview only)		

APPENDIX A - USER INTERFACE MENUS (CON'T)

Configuration Menus

BACview Menu	POINT NAME	BACnet Object	RANGE	DEFAULT	Field Assistant Menu
UNIT CONFIGURATION					
HOME>CONFIG> UNIT	UNIT CONFIGURATION				Properties>Equipment> Configuration> Unit Configuration
	Fan Mode	fan_mode	1=Auto 2=Continuous 3=Always On	Continuous	
	Power Fail Restart Delay	start_delay	0-30 sec	5	
	Fan Off Delay	fan_delay_off	0-180 sec	90	
	Minimum Cooling SAT	sat_cl_min	45-75 °F	50	
	Maximum Heating SAT	sat_ht_max	85-150° F	120	
	Vent Dmpr Pos / DCV Min Pos	econ_min	0-100 %Open	20	
	Economizer Purge Min Pos	econ_purge_min	0-100 %Open	40	
	Low Fan Econ Min Pos	econ_min_2	0-100 %Open	33	
	DCV Max Vent Damper Pos	iaq_dpr_max	0-75 %Open	50	
	Supply Fan Service Alarm Timer	sfan_service_hrs	0-9999 hr	600	
	Comp 1 Service Alarm Timer	comp1_service_hrs	0-9999 hr	0	
	Comp 2 Service Alarm Timer	comp2_service_hrs	0-9999 hr	0	
	Filter Service Alarm Timer	filter_service_hrs	0-9999 hr	600	
	Pushbutton Override	pb_enable	Disable/Enable	Enable	
	Setpoint Adjustment	stpt_adj_enable	Disable/Enable	Enable	
	Setpoint Adjustment Range	stpt_adj_range	+/- 0-5 °F	5	
	Cooling Lockout Temperature	oat_cl_lockout	0-80° F	45	
	Economizer High OAT Lockout Temp	oat_ec_lockout	55-80° F	75	
	HP Rev Cycle Lockout Temp	hp_rev_cycle_lockout	-20-30° F	-3	
	Heating Lockout Temperature	oat_ht_lockout	35-150° F	65	
	Pre Occupancy Purge	preocc_purge	Disable/Enable	Disable	
	Purge Time	purge_time	60 min	0-240 min	
	Unocc Free Cool	ntfc_ena	Disable/Enable	Disable	
	Min Setpoint Separation	min_stpt_sep	2-10 °F	5	
	Occupancy Source	occ_source	1=Always occupied 2=BACnet Schedule 3=BAS On/Off 4=Remote Occ Input	Always Occupied	

APPENDIX A - USER INTERFACE MENUS (CON'T)

Configuration Menus (con't)

BACview Menu	POINT NAME	BACnet Object	RANGE	DEFAULT	Field Assistant Menu
HOME>CONFIG> UNIT>INPUT	INPUT CONFIGURATION				Properties>Equipment> Configuration> Unit Configuration
	Input 1 Function	ai1_function	1=No Sensor 2=IAO Sensor 3=OAQ Sensor 4=Space RH Sensor	No Sensor	
	Input 2 Function	ai2_function	1=No Sensor 2=IAO Sensor 3=OAQ Sensor 4=Space RH Sensor	1 (No FIOP) 2 (FIOP)	
	Input 3 Function	di3_function	1=No Function 2=Compressor Safety 3=Fan Status 4=Filter Status 5=Remote Occupancy 6=Door Contact	Compressor Safety	
	Input 3 Switch Configuration	di3_type	N/O N/C	N/O	
	Input 5 Function	di5_function	1=No Function 2=Fire Shutdown 3=Fan Status 4=Filter Status 5=Remote Occupancy 6=Door Contact	Fire Shutdown	
	Input 5 Switch Configuration	di5_type	N/O N/C	N/C	
	Input 8 Function	di8_function	1=No Function 2=Enthalpy Switch 3=Fan Status 4=Filter Status 5=Remote Occupancy 6=Door Contact	1 (No FIOP) 2 (FIOP)	
	Input 8 Switch Configuration	di8_type	N/O N/C	N/O	
	Input 9 Function	di9_function	1=No Function 2=Humidistat 3=Fan Status 4=Filter Status 5=Remote Occupancy 6=Door Contact	Humidistat	
	Input 9 Switch Configuration	di9_type	N/O N/C	N/O	
	Space sensor type	spt_type	1=T55 2=T56 (use for T59) 3=SPT Sensor 4=None	T55	
	T5x Override Duration	ovr_dur	0-24 hours	1	
HOME>CONFIG> UNIT>CALIBRATE	SENSOR CALIBRATION				Properties>Equipment> Configuration> Unit Configuration
	Space Temperature	lcl_space_temp			
	Space Temp Calibration	spt_offset	-9.9-10° F	0	
	Space RH	lcl_space_rh	0-100%		
	Space AQ	lcl_space_aq	0-5000ppm		
	Supply Air Temperature	lcl_sa_temp	-56-245° F		
	Supply Air Temp Calibration	sat_offset	-9.9-10° F	0	
	Outdoor Air Temperature	lcl_oa_temp	-56-245° F		
	Outdoor Air Temp Calibration	oat_offset	-9.9-10° F	0	

APPENDIX A - USER INTERFACE MENUS (CON'T)

Configuration Menus (con't)

BACview Menu	POINT NAME	BACnet Object	RANGE	DEFAULT	Field Assistant Menu
SETPOINT					
HOME>CONFIG>SETPOINT	Occupied Heating Setpoint	occupied_heat_setpoint	40–90 °F	70	Properties>Equipment>Configuration>Setpoints
	Occupied Cooling Setpoint	occupied_cool_setpoint	55–99 °F	76	
	Unoccupied Heating Setpoint	unoccupied_heat_setpoint	40–90 °F	55	
	Unoccupied Cooling Setpoint	unoccupied_cool_setpoint	45–99 °F	90	
	Effective Heat Setpoint	effective_heat_setpoint	0–120 °F		
	Effective Cool Setpoint	effective_cool_setpoint	0–120 °F		
	Optimal Start (hrs)	optm_start	0–4 hr	4	
	Optimal Start Type	start_type	1=None 2=Learning Adaptive 3=Temp Compensated	Temperature Compensated	
	Heat Start K factor (min/deg)	h_kfactor	0–99	15	
	Cool Start K factor (min/deg)	c_kfactor	0–99	15	
	DCV Max Ctrl Setpoint	iaq_stpt_max	0–9999 ppm	650	
	Power Exhaust Setpoint	pexh_stpt	20–90 %Open	50	
	Occ Relative Humidity Setpoint	occ_dehum_stpt	0–unocc setpoint %rh	60	
	Unocc Relative Humidity Setpoint	unocc_dehum_stpt	30–100 %rh	95	
HOME>CONFIG>Sched	Schedule				(BACview only)
	Weekly schedule		MON–SUN	none	
	Exceptions			none	
ALARM CONFIGURATION					
HOME>CONFIG>ALARMS	SPACE TEMPERATURE ALARM				Properties>Equipment>Configuration>Alarm Configuration
	Occupied Alarm Hysteresis	occ_spt_alm_hyst	0–20° F	5	
	Alarm Delay (min/deg)	spt_alm_delay	0–60 minutes	10	
	Unoccupied Low SPT Alarm Limit	uno_spt_alm_lo_lmt	35–90 °F	45	
	Unoccupied High SPT Alarm Limit	uno_spt_alm_hi_lmt	45–100 °F	95	
	SUPPLY AIR TEMPERATURE ALARM				
	Low SAT Alarm Limit	sat_lo_alm_lim	15–90 °F	38	
	High SAT Alarm Limit	sat_hi_alm_lim	90–175 °F	160	
	SPACE HUMIDITY ALARM				
	Occupied High RH Alarm Limit (%RH)	sprh_hi_alm_lim	0–100%rh	70%rh	
	Alarm Delay (min/%RH)	sprh_delay	0–30 min	5 min	
	Unoccupied High RH Alarm Limit (%RH)	unocc_sprh_lmt	0–100%rh	100%rh	
	Low RH Alarm Limit (%RH)	sprh_lo_alm_lim	0–100%rh	30%rh	
	IAQ / VENTILATION ALARM				
	Occ High CO2 Alarm Limit (ppm)	iaq_occ_hi_lmt	0–9999 ppm	1200	

APPENDIX A - USER INTERFACE MENUS (CON'T)

Alarm Menus

BACview Menu	POINT NAME	BACnet Object	RANGE	DEFAULT	Field Assistant Menu
ALARMS					
HOME>ALARM	CURRENT ALARMS				Properties>Equipment>Alarms
	Safety Chain	safety_alarm	Normal/Alarm		
	Fire/Smoke Shutdown	fire_alarm	Normal/Alarm		
	Supply Fan Failure	sfan_fail_alarm	Normal/Alarm		
	Supply Fan in Hand	sfan_hand_alarm	Normal/Alarm		
	Compressor Safety	comp_alarm	Normal/Alarm		
	SPT Sensor	spt_sensor_fail	Normal/Alarm		
	Space Temp Sensor	spt_fail	Normal/Alarm		
	Supply Air Temperature	sat_fail	Normal/Alarm		
	Supply Air Temp Sensor	loc_sat_sensor_fail	Normal/Alarm		
	Local OAT Sensor	loc_oat_sensor_fail	Normal/Alarm		
	Indoor Air Quality	iaq_alarm	Normal/Alarm		
	Outdoor Air Temp Sensor	oat_alarm	Normal/Alarm		
	Space Relative Humidity	sprh_hi_alarm	Normal/Alarm		
	Space Relative Humidity Sensor	sprh_sensor_fail	Normal/Alarm		
	Indoor Air Quality Sensor	iaq_sensor_alarm	Normal/Alarm		
	Outdoor Air Quality Sensor	oaq_fail	Normal/Alarm		
	Space Temperature	spt_alarm_status	Normal/Alarm		
	Alarming Temperature	spt_alarm_temp	xxx ° F		
	Alarm Limit Exceeded	spt_alarm_lmt	xxx ° F		
	Setpoint Slider	slidepot_alarm	Normal/Alarm		
	Switch Configuration	di_cfg_alarm	Normal/Alarm		
	Analog Input Configuration	ai_cfg_alarm	Normal/Alarm		
	Supply Fan Runtime	sfan_rntm_alarm	Normal/Alarm		
	Compressor 1 Runtime	comp1_rntm_alarm	Normal/Alarm		
	Compressor 2 Runtime	comp2_rntm_alarm	Normal/Alarm		
	Filter	filter_alarm	Clean/Dirty		
	Airside Linkage Alarm	air_linkage_fail	Normal/Alarm		
HOME>ALARM>Alarm	Module Event History (100 most recent)				(BACview only)
	Active Alarms	Buffer			
	Active Faults	Buffer			
	Returned – To – Normal (RTN)	Buffer			
	Manually Cleared (CLR)	Buffer			

48-50HCTQ-2T

APPENDIX A - USER INTERFACE MENUS (CON'T)

Service Menu

BACview Menu	POINT NAME	BACnet Object	RANGE	DEFAULT	Field Assistant Menu
SERVICE					
HOME>CONFIG>SERVICE	SERVICE CONFIGURATION				Properties>Equipment>Configuration>Service Configuration
	Unit Type	unit_type	1 = Heat/Cool 2 = HP O/B Ctrl 3 = HP Y1/W1 Ctrl	Heat/Cool (TC, HC, and LC models) HP Y1/W1 Ctrl (TCQ and HCQ models)	
	Compressor Stages	comp_stages	One stage/ Two Stage	One Stage (sizes 04–07, and A08–A12) Two Stages (sizes 08–30)	
	Face Split Coil	face_split	Yes/No	Yes	
	Economizer Exists	econ_exist	No/Yes	No (No FIOP) Yes (FIOP)	
	Fan Control	fan_type	1 = Single Speed 2 = Two Speed 3 = Variable Speed	Single Speed (04–07, and A08–12) Two Speed (units with SAV™ option)	
	VFD Input	vfd_in_type	0–10Vdc/2–10Vdc	2–10Vdc	
	Max VFD Output	max_vfd_spd	33–100%	1	
	Min VFD Output	min_vfd_spd	33–100%	0.4	
	Dehum Min VFD Output	dehum_min_vfd	50–100%	0.6	
	Reversing Valve Type	rev_vlv_type	O output type/B output type	O output type	
	Heat Type	heat_type	Electric/Gas	Gas (48 Series Units) Electric (50 Series Units)	
	Number of Heat Stages	heat_stages	1 / 2 / 0 (no heat)	0 (50 series cooling only units) 1 (All TCQ and HCQ units, Low Nox units, single phase gas units, TC04–09 low and TC05–07 med heat 3 phase gas units) 2 (TC04 and 08–09 med, TC05–09 high heat 3 phase gas units, HC04–09 3 phase gas units, All LC gas units and All 12–30 gas units)	
	Continuous Occupied Exhaust	occ_exh	No/Yes	No	
	RH Control	rh_enable	Disable/Enable	Disable Enable (units with Humidi–MiZer option)	
	DCV Control	dcv_enable	Disable/Enable	Disable	
	Indoor CO2 Sensor Value @ Min mA	iaq_ref_lo_ppm	0–9999ppm	0	
	Indoor CO2 Sensor Value @ Max mA	iaq_ref_hi_ppm	0–9999ppm	2000	
	Outdoor CO2 Sensor Value @ Min mA	oaq_ref_lo_ppm	0–9999ppm	0	
	Outdoor CO2 Sensor Value @ Max mA	oaq_ref_hi_ppm	0–9999ppm	2000	
(Field Assistant Only)	System Space Temperature	system_spt			
	System Space RH	system_rh			
	System Space AQ	system_iaq			
	System Outdoor AQ	system_oaq			
	System Cool Demand Level	cool_demand_level	0–3	0	
	System Heat Demand Level	heat_demand_level	0–3	0	
	System Outdoor Air Temperature	system_oat			
HOME>CONFIG>SERVICE>TEST	SERVICE TEST				
	Service Test	test_enable	Disable/Enable	Disable	
	Fan Test	fan_test	Disable/Enable	Disable	
	High Speed Fan Test	hi_spd_test	Disable/Enable	Disable	
	Compressor 1 Test	comp1_test	Disable/Enable	Disable	
	Compressor 2 Test	comp2_test	Disable/Enable	Disable	
	Heat 1 Test	heat1_test	Disable/Enable	Disable	
	Heat 2 Test	heat2_test	Disable/Enable	Disable	
	Reversing Valve Test	rev_vlv_test	Disable/Enable	Disable	
	Dehumidification Test	dehum_test	Disable/Enable	Disable	
	Power Exhaust Test	pexh_test	Disable/Enable	Disable	
	Economizer Test	econ_test	0–100 %Open	0	
	VFD Speed Test	vfd_spd_test	0–100%	0	

APPENDIX A - USER INTERFACE MENUS (CON'T)

Maintenance Menu

BACview Menu	POINT NAME	BACnet Object	RANGE	DEFAULT	Field Assistant Menu
MAINTENANCE					
HOME>MAINT	UNIT MAINTENANCE				Properties>Equipment>Maintenance
	Occupancy Status	occ_status	Occupied/Unoccupied		
	Temp Compensated Start –Or–	tcs_status	Inactive/Active		
	Learning Adaptive Start	aos_status			
	Pre Occupancy Purge	purge	Inactive/Active		
	Space Temp Sensor	spt_status	1=Sensor Failure 2=SPT Sensor 3=T55/T56 4=Network 5=Airside Linkage 6=Locked Value		
	Setpoint Adjustment	stpt_adj	x ° F		
	Relative Humidity Source	rh_source	1=N/A 2=Local 3=Network 4=Linkage 5=Locked Value 6=Linkage&Local		
	IAQ Source	iaq_source	1=N/A 2=Local 3=Network 4=Linkage 5=Locked Value 6=Linkage&Local		
	OAQ Source	oaq_source	1=N/A 2=Local 3=Network 4=Linkage 5=Locked Value 6=Linkage&Local		
	Outdoor Air Temperature Source	oat_status	1=N/A 2=Local 3=Network 4=Linkage 5=Locked Value		
	Safety Chain Feedback	safety_status	Off/Run Enabled		
	Fire Shutdown Status	firedown_status	Run Enabled/Shutdown		
	Compressor Safety Status	comp_status	Normal/Trouble		
	Calculated Min Econ Pos	cal_min_econ_pos	0–100%		
	Calculated Min PE Pos	cal_pe_stpt	0–100%		
	Active Compressor Stages	comp_run	0–2		
	Active Heat Stages	heat_run	0–2		
	Enthalpy Status	enthalpy_status	High/Low		
	Humidistat Input Status	humstat_status	High/Low		
	Filter Status	filter_status	Clean/Dirty		
	Door Contact Status	door_contact_status	Off/On		
	Reset Supply Fan Runtime Alarm	sfan_rmtm_clr	Run/Clear	Run	
	Reset Comp 1 Runtime Alarm	comp1_rmtm_clr	Run/Clear	Run	
	Reset Comp 2 Runtime Alarm	comp2_rmtm_clr	Run/Clear	Run	
	Reset Filter Runtime Alarm	filter_rmtm_clr	Off/On	Off	
OCCUPANCY MAINTENANCE					
	BAS On / Off	keypad_ovrde	1=Inactive 2=Occupied 3=Unoccupied	Inactive	
	Schedules	schedule	Unoccupied/Occupied		
	Pushbutton Override	pb_status	Off/Active		
	Occupancy Contact	occ_contact_status	Off/On		
	Override Time Remaining	ovrde_time	0–240 min		
RUNTIME MAINTENANCE					
	Supply Fan Runtime	sfan_rmtm	xxxx hr		
	Compressor 1 Runtime	comp1_rmtm	xxxx hr		
	Compressor 2 Runtime	comp2_rmtm	xxxx hr		
	Filter Runtime	filter_rmtm	xxxx hr		

48–50HCTQ–2T

APPENDIX B - THIRD PARTY POINTS LIST

(in alphabetical order)

Point Name	Read/Write	BACnet		Modbus		N2		Lonworks	
		BACnet Point Name	Object ID	Register Type	Register #	Network Point Type	Network Point Address	SNVT Type	SNVT Name
Active Compressor Stages	R	comp_run	AV:2020	float value	40031	ADF	10	SNVT_count_inc (9)	nvoCompStages
Active Heat Stages	R	heat_run	AV:2003	float value	40033	ADF	11	SNVT_count_inc (9)	nvoHeatStages
Air Source Mode	R	link_ahu_mode	MSV:2005						
Air Source Outdoor Air Temp	R	link_ahu_oat	AV:2609						
Air Source Supply Air Temp	R	link_sat	AV:2608						
Airside Linkage	R	air_linkage_fail	BV:7030						
BAS On / Off	R/W	keypad_ovrde	MSV:1001	unsigned int	40133	ADI	1	SNVT_count_inc (9)	nviBASOnOff
Compressor 1 Relay State	R	comp_1	BV:2005						
Compressor 1 Runtime	R	comp1_rmtm	AV:2017						
Compressor 1 Runtime	R	comp1_rmtm_alarm	BV:7014						
Compressor 1 Service Alarm Timer	R/W	comp1_service_hrs	AV:83006						
Compressor 1 Test	R/W	comp1_test	BV:81005						
Compressor 2 Relay State	R	comp_2	BV:2004						
Compressor 2 Runtime	R	comp2_rmtm	AV:2018						
Compressor 2 Runtime	R	comp2_rmtm_alarm	BV:7015						
Compressor 2 Service Alarm Timer	R/W	comp2_service_hrs	AV:83007						
Compressor 2 Test	R/W	comp2_test	BV:81004						
Compressor Safety Status	R	comp_status	BV:1008						
Compressor Status	R	comp_alarm	BV:7013	discrete in	10030	BI	30	SNVT_switch (95)	nvoCompSafety
Continuous Occupied Exhaust	R/W	occ_exh	BV:9002						
Cooling Lockout Temperature	R/W	oat_cl_lockout	AV:9002	float value	40043	ADF	16	SNVT_temp_p (105)	nviCoolLckTemp
DCV Max Ctrl Setpoint	R/W	iaq_stpt_max	AV:3013	float value	40045	ADF	17	SNVT_ppm (29)	nviDCVMaxPPM
DCV Max Vent Damper Pos	R/W	iaq_dpr_max	AV:9011	float value	40047	ADF	18	SNVT_lev_percent (81)	nviDCVMaxPos
Dehumidification	R	dehum	BV:2006	discrete in	10009	BI	9	SNVT_switch (95)	nvoDehumRelay
Dehumidification Test	R/W	dehum_test	BV:81006						
Door Contact Status	R	door_contact_status	BV:1010						
Economizer Exists	R/W	econ_exist	BV:99001						
Economizer High OAT Lockout Temp	R/W	oat_ec_lockout	AV:9008						
Economizer Output	R	econ_output	AV:2022	float value	40051	ADF	20	SNVT_lev_percent (81)	nvoEconOutput
Economizer Purge Min Pos	R/W	econ_purge_min	AV:9029	float value	40075	ADF	5	SNVT_lev_percent (81)	nviEconPurgeMin
Economizer Test	R/W	econ_test	AV:81001	float value	40053	ADF	21	SNVT_temp_p (105)	
Effective Cool Setpoint	R	eff_cl_stpt	AV:3005	float value	40055	ADF	22	SNVT_temp_p (105)	nvoEffCoolSP
Effective Heat Setpoint	R	eff_ht_stpt	AV:3006	float value	40057	ADF	23	SNVT_temp_p (105)	nvoEffHeatSP
Enthalpy (BACnet)	R/W	oae	BV:1901	discrete out	6	BO	6	SNVT_switch (95)	nviSysEnthalpy
Enthalpy Status	R	enthalpy_status	BV:1002						
Equipment Status	R	mode_status	MSV:2001						
Factory Test	R/W	fac_test_enable	BV:91000						
Factory Test Analog 1 Control	R/W	ao1_fac_test	AV:91001						
Factory Test Analog 2 Control	R/W	ao2_fac_test	AV:91002						
Factory Test Relay 1 Control	R/W	relay1_fac_test	BV:91001						
Factory Test Relay 2 Control	R/W	relay2_fac_test	BV:91002						
Factory Test Relay 3 Control	R/W	relay3_fac_test	BV:91003						
Factory Test Relay 4 Control	R/W	relay4_fac_test	BV:91004						
Factory Test Relay 5 Control	R/W	relay5_fac_test	BV:91005						
Factory Test Relay 6 Control	R/W	relay6_fac_test	BV:91006						
Factory Test Relay 7 Control	R/W	relay7_fac_test	BV:91007						
Factory Test Relay 8 Control	R/W	relay8_fac_test	BV:91008						
Fan Mode	R/W	fan_mode	MSV:9032						
Fan Off Delay	R/W	fan_delay_off	AV:9024						
Filter	R	filter_alarm	BV:7017	discrete in	10031	BI	31	SNVT_switch (95)	nvoFilter
Filter Runtime	R	filter_rmtm	AV:2015						
Filter Service Alarm Timer	R/W	filter_service_hrs	AV:2019	float value	40067	ADF	28	SNVT_time_hour (124)	nviFilterAlmTime
Filter Status	R	filter_status	BV:1004						
Fire / Smoke Shutdown	R	fire_alarm	BV:7007	discrete in	10032	BI	32	SNVT_switch (95)	nvoFireShutdown
Fire Shutdown Status	R	firedown_status	BV:1005						
Heat 1Test	R/W	heat1_test	BV:81003						
Heat 2Test	R/W	heat2_test	BV:81002						
Heat Stage 1 Relay State	R	heat_1	BV:2003						
Heat Stage 2 Relay State	R	heat_2	BV:2002						
Heating Lockout Temperature	R/W	oat_ht_lockout	AV:9003	float value	40069	ADF	29	SNVT_temp_p (105)	nviHeatLckTemp

APPENDIX B - THIRD PARTY POINTS LIST (CON'T)

(in alphabetical order)

Point Name	Read/Write	BACnet		Modbus		N2		Lonworks	
		BACnet Point Name	Object ID	Register Type	Register #	Network Point Type	Network Point Address	SNVT Type	SNVT Name
High Space Temperature	R	spt_hi_alarm	BV:7011	discrete in	10035	BI	35	SNVT_switch (95)	nvoHiSpaceTemp
High Speed Fan Test	R/W	hi_spd_test	BV:81010						
HP Rev Cycle Lockout Temp	R/W	hp_rev_cycle_lockout	AV:9004	float value	40071	ADF	30	SNVT_temp_p (105)	nviHPRevCLckTemp
Humidistat Input Status	R	humstat_status	BV:1006						
Indoor Air Quality	R	iaq_alarm	BV:7005	discrete in	10033	BI	33	SNVT_switch (95)	nvoIAQAlm
Indoor Air Quality CO2 (ppm)	R	iaq	AV:1009	float value	40073	ADF	31	SNVT_ppm (29)	nvoIAQ
Indoor Air Quality Sensor	R	iaq_sensor_fail	BV:7039	discrete in	10037	BI	37	SNVT_switch (95)	nvoIAQSensor
Input 1 Function	R/W	ai1_function	MSV:81001						
Input 2 Function	R/W	ai2_function	MSV:81002						
Input 3 Function	R/W	di3_function	MSV:81003						
Input 3 Switch Configuration	R/W	di3_type	MSV:81013						
Input 5 Function	R/W	di5_function	MSV:81005						
Input 5 Switch Configuration	R/W	di5_type	MSV:81015						
Input 8 Function	R/W	di8_function	MSV:81008						
Input 8 Switch Configuration	R/W	di8_type	MSV:81018						
Input 9 Function	R/W	di9_function	MSV:81009						
Input 9 Switch Configuration	R/W	di9_type	MSV:81019						
input_1	R	ai_1	AI:1001						
input_10	R	ai_10	AI:1010						
input_11	R	ai_11	AI:1011						
input_2	R	ai_2	AI:1002						
input_3	R	di_3	BI:1003						
input_4	R	di_4	BI:1004						
input_5	R	di_5	BI:1005						
input_6	R	ai_6	AI:1006						
input_7	R	ai_7	AI:1007						
input_8	R	di_8	BI:1008						
input_9	R	di_9	BI:1009						
Linkage Max Damper Position	R	link_max_dmpr	AV:2611						
Low Fan Econ Min Pos	R/W	econ_min_2	AV:9030	float value	40089	ADF	32	SNVT_lev_percent (81)	nviLowFanEconMin
Low Space Temperature	R	spt_lo_alarm	BV:7012	discrete in	10039	BI	39	SNVT_switch (95)	nvoLoSpaceTemp
Maximum Heating SAT	R/W	sat_ht_max	AV:83004						
Minimum Cooling SAT	R/W	sat_cl_min	AV:83003						
Number Of Heat Stages	R/W	heat_stages	MSV:91004						
Occ Relative Humidity Setpoint	R/W	occ_dehum_stpt	AV:3011	float value	40083	ADF	36	SNVT_lev_percent (81)	nviOccRHSP
Occupancy Contact	R	occ_contact_status	BV:1007						
Occupancy Source	R/W	occ_source	MSV:1002						
Occupancy Status	R	occ_status	BV:2008	discrete in	10018	BI	18	SNVT_switch (95)	nvoOccStatus
Optimal Start	R/W	optm_start	AV:9026	float value	40147	ADF	61	SNVT_time_hour (124)	nviOptimalStart
Optimal Start Type	R/W	start_type	MSV:2009	unsigned int	40154	ADI	20	SNVT_count_inc (9)	nviOptimalStType
Outdoor Air Quality CO2 (ppm)	R	oaq	AV:1012	float value	40085	ADF	37	SNVT_ppm (29)	nvoOAQ
Outdoor Air Quality Sensor	R	oaq_fail	BV:7006	discrete in	10041	BI	41	SNVT_switch (95)	nvoOAQSensor
Outdoor Air Temp Sensor	R	oat_fail	BV:7029	discrete in	10027	BI	27		
Outdoor Air Temperature	R	oa_temp	AV:1003	float value	40087	ADF	38	SNVT_temp_p (105)	nvoOAT
Override Time Remaining	R	ovrde_time	AV:2016	float value	40093	ADF	41	SNVT_time_min (123)	nvoOvrTimeRemain
Password Protected Output Variable	R/W	ppo	AV:90000						
Power Exhaust Relay State	R	pexh	BV:2010						
Power Exhaust Setpoint	R/W	pexh_stpt	AV:3010	float value	40097	ADF	43	SNVT_lev_percent (81)	nviPwrExhSP
Power Exhaust Test	R/W	pexh_test	BV:81008						
Power Fail Restart Delay	R/W	start_delay	AV:9007	float value	40127	ADF	58	SNVT_time_sec (107)	nviUnitStartDly
Reset Comp 1 Runtime Alarm	R/W	comp1_rntm_clr	BV:7514						
Reset Comp 2 Runtime Alarm	R/W	comp2_rntm_clr	BV:7515						
Reset Filter Alarm	R/W	filter_rntm_clr	BV:7517	discrete out	22	BO	22	SNVT_switch (95)	nviResetFiltAlm
Reset Supply Fan Runtime Alarm	R/W	sfan_rntm_clr	BV:7510						
Safety Chain	R	safety_alarm	BV:7024	discrete in	10043	BI	43	SNVT_switch (95)	nvoSafetyChain
Safety Chain Feedback	R	safety_status	BV:1009						
Schedule	R/W	schedule	BV:8000						
Service Test	R/W	test_enable	BV:81000						

48-50HCTQ-2T

APPENDIX B - THIRD PARTY POINTS LIST (CON'T)

(in alphabetical order)

Point Name	Read/Write	BACnet		Modbus		N2		Lonworks	
		BACnet Point Name	Object ID	Register Type	Register #	Network Point Type	Network Point Address	SNVT Type	SNVT Name
Setpoint / Cooling Occupied Setpoint	R/W	occ_cl_stpt	AV:3001	float value	40009	ADF	4	SNVT_temp_p (105)	nviOccCoolSP
Setpoint / Cooling Unoccupied Setpoint	R/W	unocc_cl_stpt	AV:3003	float value	40015	ADF	7	SNVT_temp_p (105)	nviUnoccCoolSP
Setpoint / Heating Occupied Setpoint	R/W	occ_ht_stpt	AV:3002	float value	40019	ADF	9	SNVT_temp_p (105)	nviOccHeatSP
Setpoint / Heating Unoccupied Setpoint	R/W	unocc_ht_stpt	AV:3004	float value	40017	ADF	8	SNVT_temp_p (105)	nviUnoccHeatSP
Setpoint Adjustment	R	stpt_adj	AV:1006	float value	40099	ADF	44	SNVT_temp_p (105)	nvoSPAdjust
Setpoint Adjustment	R/W	stpt_adj_enable	BV:1013	discrete out	26	BO	26	SNVT_switch (95)	nviSPAdjEnable
Setpoint Adjustment Range	R/W	stpt_adj_range	AV:9015	float value	40101	ADF	45	SNVT_temp_p (105)	nviSPAdjRange
Setpoint Slider	R	slidepot_alarm	BV:7002						
Shutdown	R/W	shutdown	BV:9001						
slidepot voltage reading	R	slidepot_volts	AI:1012						
Space Relative Humidity	R	space_rh	AV:1011	float value	40103	ADF	46	SNVT_lev_percent (81)	nvoSpaceRH
Space Relative Humidity	R	sprh_hi_alarm	BV:7018	discrete in	10034	BI	34	SNVT_switch (95)	nvoHisSPRHAlm
Space Relative Humidity Sensor	R	sprh_sensor_fail	BV:7022	discrete in	10045	BI	45	SNVT_switch (95)	nvoSpaceRHSensor
Space sensor type	R/W	spt_type	MSV:9001						
Space Temp / Override Time Remaining	R/W	override_time_remaining	AV:1						
Space Temp / Zone Temp	R	zone_temp	AI:1						
Space Temp Sensor	R	spt_fail	BV:7001	discrete in	10046	BI	46	SNVT_switch (95)	nvoSPTempSensor
Space Temp Source	R	spt_status	MSV:2003						
Space Temperature – Prime Variable	R	space_temp	AV:2007	float value	40107	ADF	48	SNVT_temp_p (105)	nvoSpaceTemp
Space Temperature Offset Pot	R	stpt_adj_offset	AV:91006						
SPT Sensor	R	spt_sensor_fail	BV:7032	discrete in	10038	BI	38		
Supply Air Temperature	R	sa_temp	AV:1008	float value	40109	ADF	49	SNVT_temp_p (105)	nvoSAT
Supply Air Temperature	R	sat_alarm	BV:7004	discrete in	10047	BI	47	SNVT_switch (95)	nvoSATSensor
Supply Fan Failure	R	sfan_fail_alarm	BV:7008						
Supply Fan in Hand	R	sfan_hand_alarm	BV:7009						
Supply Fan Relay State	R	sfan	BV:2001	discrete in	10023	BI	23	SNVT_switch (95)	nvoSFRelay
Supply Fan Runtime	R	sfan_rntm	AV:2014						
Supply Fan Runtime	R	sfan_rntm_alarm	BV:7010	discrete in	10050	BI	50		
Supply Fan Service Alarm Timer	R/W	sfan_service_hrs	AV:83005						
Supply Fan Status	R	sfan_status	BV:1003	discrete in	10024	BI	24	SNVT_switch (95)	nvoFanStatus
Supply Fan VFD	R	vfd_output	AV:2027						
System Cooling Demand Level	R	cool_demand_level	AV:9006						
System Heating Demand Level	R	heat_demand_level	AV:9036						
System is shut down	R	shutdown_status	BV:2011						
System Mode	R	run_status	MSV:2002	unsigned int	30001	ADI	13	SNVT_count_inc (9)	nvoOperatingMode
System OAT Master	R	mstr_oa_temp	AV:80001						
System Outdoor Air Temperature	R/W	system_oat	AV:1901	float value	40119	ADF	54	SNVT_temp_p (105)	nviSysOAT
System Space AQ	R/W	system_iaq	AV:1903	float value	40149	ADF	39	SNVT_ppm (29)	nviSysSpaceAQ
System Space RH	R/W	system_rh	AV:1904	float value	40151	ADF	40	SNVT_lev_percent (81)	nviSysSpaceRH
System Space Temperature	R/W	system_spt	AV:1902	float value	40123	ADF	56	SNVT_temp_p (105)	nviSysSpaceTemp
T5x Override Duration	R/W	ovr_dur	AV:9023						
Unocc Free Cool	R/W	ntfc_ena	BV:80001						
Unocc Relative Humidity Setpoint	R/W	unocc_dehum_stpt	AV:3012	float value	40129	ADF	59	SNVT_lev_percent (81)	nviUnoccRHSP
Vent Dmpr Pos / DCV Min Pos	R/W	econ_min	AV:9005	float value	40131	ADF	60	SNVT_lev_percent (81)	nviDCVMinPos
VFD Speed Test	R/W	vfd_spd_test	AV:81002						

RTU OPEN START-UP SHEET

RTU Model Number: _____
 RTU Serial Number: _____
 RTU Open Software Version: _____

Date: _____
 Performed by: _____
 Company: _____

Protocol and Baud Rate: _____

Network Address: _____

CONFIGURATION POINTS

BACview Menu	POINT NAME	BACnet Object	RANGE	DEFAULT	ENTRY
SETPOINT					
HOME> CONFIG> SETPOINT	Occupied Heating Setpoint	occupied_heat_setpoint	40–90 °F	70	
	Occupied Cooling Setpoint	occupied_cool_setpoint	55–99 °F	76	
	Unoccupied Heating Setpoint	unoccupied_heat_setpoint	40–90 °F	55	
	Unoccupied Cooling Setpoint	unoccupied_cool_setpoint	45–99 °F	90	
	Effective Heat Setpoint	effective_heat_setpoint	0–120 °F		
	Effective Cool Setpoint	effective_cool_setpoint	0–120 °F		
	Optimal Start (hrs)	optm_start	0–4 hr	4	
	Optimal Start Type	start_type	1=None 2=Learning Adaptive 3=Temp Compensated	Temperature Compensated	
	Heat Start K factor (min/deg)	h_kfactor	0–99	15	
	Cool Start K factor (min/deg)	c_kfactor	0–99	15	
	DCV Max Ctrl Setpoint	iaq_stpt_max	0–9999 ppm	650	
	Power Exhaust Setpoint	pexh_stpt	20–90 %Open	50	
	Occ Relative Humidity Setpoint	occ_dehum_stpt	0–unocc setpoint %rh	60	
	Unocc Relative Humidity Setpoint	unocc_dehum_stpt	30–100 %rh	95	
Schedule					
HOME> CONFIG> Sched	Weekly schedule		MON–SUN	none	
	Exceptions			none	
ALARM CONFIGURATION					
HOME> CONFIG> ALARMS	SPACE TEMPERATURE ALARM				
	Occupied Alarm Hysteresis	occ_spt_alm_hyst	0–20° F	5	
	Alarm Delay (min/deg)	spt_alm_delay	0–60 minutes	10	
	Unoccupied Low SPT Alarm Limit	uno_spt_alm_lo_lmt	35–90 °F	45	
	Unoccupied High SPT Alarm Limit	uno_spt_alm_hi_lmt	45–100 °F	95	
	SUPPLY AIR TEMPERATURE ALARM				
	Low SAT Alarm Limit	sat_lo_alm_lim	15–90 °F	38	
	High SAT Alarm Limit	sat_hi_alm_lim	90–175 °F	160	
	SPACE HUMIDITY ALARM				
	Occupied High RH Alarm Limit (%RH)	sprh_hi_alm_lim	0–100%rh	70%rh	
	Alarm Delay (min/%RH)	sprh_delay	0–30 min	5 min	
	Unoccupied High RH Alarm Limit (%RH)	unocc_sprh_lmt	0–100%rh	100%rh	
	Low RH Alarm Limit (%RH)	sprh_lo_alm_lim	0–100%rh	30%rh	
	IAQ / VENTILATION ALARM				
	Occ High CO2 Alarm Limit (ppm)	iaq_occ_hi_lmt	0–9999 ppm	1200	

48–50HCTQ–2T

CONFIGURATION POINTS (CON'T)

BACview Menu	POINT NAME	BACnet Object	RANGE	DEFAULT	ENTRY
UNIT CONFIGURATION					
HOME>CONFIG> UNIT	UNIT CONFIGURATION				
	Fan Mode	fan_mode	1=Auto 2=Continuous 3=Always On	Continuous	
	Power Fail Restart Delay	start_delay	0-30 sec	5	
	Fan Off Delay	fan_delay_off	0-180 sec	90	
	Minimum Cooling SAT	sat_cl_min	45-75 °F	50	
	Maximum Heating SAT	sat_ht_max	85-150° F	120	
	Vent Dmpr Pos / DCV Min Pos	econ_min	0-100 %Open	20	
	Economizer Purge Min Pos	econ_purge_min	0-100 %Open	40	
	Low Fan Econ Min Pos	econ_min_2	0-100 %Open	33	
	DCV Max Vent Damper Pos	iaq_dpr_max	0-75 %Open	50	
	Supply Fan Service Alarm Timer	sfan_service_hrs	0-9999 hr	600	
	Comp 1 Service Alarm Timer	comp1_service_hrs	0-9999 hr	0	
	Comp 2 Service Alarm Timer	comp2_service_hrs	0-9999 hr	0	
	Filter Service Alarm Timer	filter_service_hrs	0-9999 hr	600	
	Pushbutton Override	pb_enable	Disable/Enable	Enable	
	Setpoint Adjustment	stpt_adj_enable	Disable/Enable	Enable	
	Setpoint Adjustment Range	stpt_adj_range	+/- 0-5 °F	5	
	Cooling Lockout Temperature	oat_cl_lockout	0-80° F	45	
	Economizer High OAT Lockout Temp	oat_ec_lockout	55-80° F	75	
	HP Rev Cycle Lockout Temp	hp_rev_cycle_lockout	-20-30° F	-3	
	Heating Lockout Temperature	oat_ht_lockout	35-150° F	65	
	Pre Occupancy Purge	preocc_purge	Disable/Enable	Disable	
	Purge Time	purge_time	60 min	0-240 min	
	Unocc Free Cool	ntfc_ena	Disable/Enable	Disable	
	Min Setpoint Separation	min_stpt_sep	2-10 °F	5	
	Occupancy Source	occ_source	1=Always occupied 2=BACnet Schedule 3=BAS On/Off 4=Remote Occ Input	Always Occupied	

48-50HCTQ-2T

CONFIGURATION POINTS (CON'T)

BACview Menu	POINT NAME	BACnet Object	RANGE	DEFAULT	ENTRY
HOME>CONFIG> UNIT>INPUT	INPUT CONFIGURATION				
	Input 1 Function	ai1_function	1=No Sensor 2=IAO Sensor 3=OAQ Sensor 4=Space RH Sensor	No Sensor	
	Input 2 Function	ai2_function	1=No Sensor 2=IAO Sensor 3=OAQ Sensor 4=Space RH Sensor	1 (No FIOP) 2 (FIOP)	
	Input 3 Function	di3_function	1=No Function 2=Compressor Safety 3=Fan Status 4=Filter Status 5=Remote Occupancy 6=Door Contact	Compressor Safety	
	Input 3 Switch Configuration	di3_type	N/O N/C	N/O	
	Input 5 Function	di5_function	1=No Function 2=Fire Shutdown 3=Fan Status 4=Filter Status 5=Remote Occupancy 6=Door Contact	Fire Shutdown	
	Input 5 Switch Configuration	di5_type	N/O N/C	N/C	
	Input 8 Function	di8_function	1=No Function 2=Enthalpy Switch 3=Fan Status 4=Filter Status 5=Remote Occupancy 6=Door Contact	1 (No FIOP) 2 (FIOP)	
	Input 8 Switch Configuration	di8_type	N/O N/C	N/O	
	Input 9 Function	di9_function	1=No Function 2=Humidistat 3=Fan Status 4=Filter Status 5=Remote Occupancy 6=Door Contact	Humidistat	
	Input 9 Switch Configuration	di9_type	N/O N/C	N/O	
	Space sensor type	spt_type	1=T55 2=T56 (use for T59) 3=SPT Sensor 4=None	T55	
	T5x Override Duration	ovr_dur	0-24 hours	1	
HOME>CONFIG> UNIT>CALIBRATE	SENSOR CALIBRATION				
	Space Temperature	lcl_space_temp			
	Space Temp Calibration	spt_offset	-9.9-10° F	0	
	Space RH	lcl_space_rh	0-100%		
	Space AQ	lcl_space_aq	0-5000ppm		
	Supply Air Temperature	lcl_sa_temp	-56-245° F		
	Supply Air Temp Calibration	sat_offset	-9.9-10° F	0	
	Outdoor Air Temperature	lcl_oa_temp	-56-245° F		
	Outdoor Air Temp Calibration	oat_offset	-9.9-10° F	0	

CONFIGURATION POINTS (CON'T)

BACview Menu	POINT NAME	BACnet Object	RANGE	DEFAULT	ENTRY
SERVICE					
HOME>CONFIG>SERVICE	SERVICE CONFIGURATION				
	Unit Type	unit_type	1=Heat/Cool 2=HP O/B Ctrl 3=HP Y1/W1 Ctrl	Heat/Cool (TC, HC, and LC models) HP Y1/W1 Ctrl (TCQ and HCQ models)	
	Compressor Stages	comp_stages	One stage/ Two Stage	One Stage (sizes 04–07, and A08–A12) Two Stages (sizes 08–30)	
	Face Split Coil	face_split	Yes/No	Yes	
	Economizer Exists	econ_exist	No/Yes	No (No FIOP) Yes (FIOP)	
	Fan Control	fan_type	1=Single Speed 2=Two Speed 3=Variable Speed	Single Speed (04–07, and A08–12) Two Speed (units with SAV™ option)	
	VFD Input	vfd_in_type	0–10Vdc/2–10Vdc	2–10Vdc	
	Max VFD Output	max_vfd_spd	33–100%	1	
	Min VFD Output	min_vfd_spd	33–100%	0.4	
	Dehum Min VFD Output	dehum_min_vfd	50–100%	0.6	
	Reversing Valve Type	rev_vlv_type	O output type/B output type	O output type	
	Heat Type	heat_type	Electric/Gas	Gas (48 Series Units) Electric (50 Series Units)	
	Number of Heat Stages	heat_stages	1 / 2 / 0 (no heat)	0 (50 series cooling only units) 1 (All TCQ and HCQ units, Low Nox units, single phase gas units, TC04–09 low and TC05–07 med heat 3 phase gas units) 2 (TC04 and 08–09 med, TC05–09 high heat 3 phase gas units, HC04–09 3 phase gas units, All LC gas units and All 12–30 gas units)	
	Continuous Occupied Exhaust	occ_exh	No/Yes	No	
	RH Control	rh_enable	Disable/Enable	Disable Enable (units with Humidi–MiZer option)	
	DCV Control	dcv_enable	Disable/Enable	Disable	
	Indoor CO2 Sensor Value @ Min mA	iaq_ref_lo_ppm	0–9999ppm	0	
	Indoor CO2 Sensor Value @ Max mA	iaq_ref_hi_ppm	0–9999ppm	2000	
	Outdoor CO2 Sensor Value @ Min mA	oaq_ref_lo_ppm	0–9999ppm	0	
	Outdoor CO2 Sensor Value @ Max mA	oaq_ref_hi_ppm	0–9999ppm	2000	
(Field Assistant Only)	System Space Temperature	system_spt			
	System Space RH	system_rh			
	System Space AQ	system_iaq			
	System Outdoor AQ	system_oaq			
	System Cool Demand Level	cool_demand_level	0–3	0	
	System Heat Demand Level	heat_demand_level	0–3	0	
	System Outdoor Air Temperature	system_oat			
SERVICE TEST					
HOME>CONFIG>SERVICE>TEST	Service Test	test_enable	Disable/Enable	Disable	
	Fan Test	fan_test	Disable/Enable	Disable	
	High Speed Fan Test	hi_spd_test	Disable/Enable	Disable	
	Compressor 1 Test	comp1_test	Disable/Enable	Disable	
	Compressor 2 Test	comp2_test	Disable/Enable	Disable	
	Heat 1 Test	heat1_test	Disable/Enable	Disable	
	Heat 2 Test	heat2_test	Disable/Enable	Disable	
	Reversing Valve Test	rev_vlv_test	Disable/Enable	Disable	
	Dehumidification Test	dehum_test	Disable/Enable	Disable	
	Power Exhaust Test	pexh_test	Disable/Enable	Disable	
	Economizer Test	econ_test	0–100 %Open	0	
	VFD Speed Test	vfd_spd_test	0–100%	0	