

Service and Maintenance Instructions For Sizes 070-155, Series 101

NOTE: Read the entire instruction manual before performing any service or maintenance.

Index	Page
SAFETY CONSIDERATIONS	1
ELECTROSTATIC DISCHARGE (ESD) PRECAUTIONS	
PROCEDURE	2
CARE AND MAINTENANCE.....	2-10
Air Filter Arrangement.....	2-3
Blower Motor and Wheel.....	3
Cleaning Heat Exchanger.....	3-4
Electrical Controls and Wiring.....	5
Troubleshooting	5-10
Unit Wiring Diagram.....	7
Troubleshooting Guide	8-9
Service Label	10

SAFETY CONSIDERATIONS


Installing and servicing heating equipment can be hazardous due to gas and electrical components. Only trained and qualified personnel should install, repair, or service heating equipment.

Untrained personnel can perform basic maintenance functions such as cleaning and replacing air filters. All other operations must be performed by trained service personnel. When working on heating equipment, observe precautions in the literature, on tags, and on labels attached to or shipped with the unit and other safety precautions that may apply.

Follow all safety codes. In the United States, follow all safety codes including the National Fuel Gas Code (NFPA) NFPA 54-1996/ANSI Z223.1-1996. In Canada, refer to the current edition of the National Standard of Canada CAN/CGA-B149.1- and .2-M95 Natural Gas and Propane Installation Codes (NSC-NGPIC). Wear safety glasses and work gloves. Have fire extinguisher available during start-up and adjustment procedures and service calls.

Recognize safety information. This is the safety-alert symbol . When you see this symbol on the furnace and in instructions or manuals, be alert to the potential for personal injury.

Understand the signal words DANGER, WARNING, and CAUTION. These words are used with the safety-alert symbol. DANGER identifies the most serious hazards which **will** result in severe personal injury or death. WARNING signifies a hazard which **could** result in personal injury or death. CAUTION is used to identify unsafe practices which **would** result in minor personal injury or product and property damage. NOTE is used to highlight suggestions which **will** result in enhanced installation, reliability, or operation.



A94085

Fig. 1—Model 58YAV Upflow Furnace

WARNING

The ability to properly perform maintenance on this equipment requires certain expertise, mechanical skills, tools, and equipment. If you do not possess these, do not attempt to perform any maintenance on this equipment other than those procedures recommended in the User's Manual. FAILURE TO FOLLOW THIS WARNING COULD RESULT IN POSSIBLE DAMAGE TO THIS EQUIPMENT, SERIOUS PERSONAL INJURY, OR DEATH.

⚠ CAUTION

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation.

ELECTROSTATIC DISCHARGE (ESD) PRECAUTIONS PROCEDURE

⚠ CAUTION

Electrostatic discharge can affect electronic components. Take precautions during furnace installation and servicing to protect the furnace electronic control. Precautions will prevent electrostatic discharges from personnel and hand tools which are held during the procedure. These precautions will help to avoid exposing the control to electrostatic discharge by putting the furnace, the control, and the person at the same electrostatic potential.

1. Disconnect all power to the furnace. **DO NOT TOUCH THE CONTROL OR ANY WIRE CONNECTED TO THE CONTROL PRIOR TO DISCHARGING YOUR BODY'S ELECTROSTATIC CHARGE TO GROUND.**
2. Firmly touch a clean, unpainted, metal surface of the furnace chassis which is close to the control. Tools held in a person's hand during grounding will be satisfactorily discharged.
3. After touching the chassis you may proceed to service the control or connecting wires as long as you do nothing that recharges your body with static electricity (for example; **DO NOT** move or shuffle your feet, **DO NOT** touch ungrounded objects, etc.).
4. If you touch ungrounded objects (recharge your body with static electricity), firmly touch furnace again before touching control or wires.
5. Use this procedure for installed and uninstalled (ungrounded) furnaces.
6. Before removing a new control from its container, discharge your body's electrostatic charge to ground to protect the control from damage. If the control is to be installed in a furnace, follow items 1 through 5 before bringing the control or yourself into contact with the furnace. Put all used AND new controls into containers before touching ungrounded objects.
7. An ESD service kit (available from commercial sources) may also be used to prevent ESD damage.

CARE AND MAINTENANCE

For continuing high performance and to minimize possible equipment failure, it is essential that periodic maintenance be performed on this equipment. Consult your local dealer as to the proper frequency of maintenance and the availability of a maintenance contract.

⚠ WARNING

Never store anything on, near, or in contact with the furnace, such as:

1. Spray or aerosol cans, rags, brooms, dust mops, vacuum cleaners, or other cleaning tools.
2. Soap powders, bleaches, waxes or other cleaning compounds, plastic or plastic containers, gasoline, kerosene, cigarette lighter fluid, dry cleaning fluids, or other volatile fluids.
3. Paint thinners and other painting compounds, paper bags, or other paper products.

A failure to follow this warning could result in corrosion of the heat exchanger, fire, personal injury, or death.

⚠ WARNING

Turn off the gas and electrical supplies to the unit before performing any maintenance or service. Follow the operating instructions on label attached to furnace. A failure to follow this warning could result in personal injury.

The minimum maintenance that should be performed on this equipment is as follows:

1. Check and clean air filter each month or more frequently if required. Replace if torn.
2. Check blower motor and wheel for cleanliness each heating and cooling season. Clean as necessary.
3. Check electrical connections for tightness and controls for proper operation each heating season. Service as necessary.

⚠ CAUTION

As with any mechanical equipment, personal injury can result from sharp metal edges, etc., therefore, be careful when removing parts.

AIR FILTER ARRANGEMENT

The air filter arrangement may vary depending on the application. Refer to Table 1 for filter size information.

Table 1—Filter Size Information (In.)

FURNACE CASING WIDTH	FILTER QUANTITY AND SIZE		FILTER TYPE
	Side Return	Bottom Return	
14-3/16	(1) 16 X 25 X 1*	(1) 14 X 25 X 1	Cleanable
17-1/2	(1) 16 X 25 X 1*	(1) 16 X 25 X 1	Cleanable
21	(1) 16 X 25 X 1	(1) 20 X 25 X 1*	Cleanable
24-1/2	(2) 16 X 25 X 1*	(1) 24 X 25 X 1	Cleanable

* Factory-provided with the furnace. Filters may be field modified as required by cutting and folding the frame as indicated on the filter.


⚠ WARNING

Never operate unit without a filter or with filter access door removed. A failure to follow this warning could result in fire, personal injury, or death.

Each furnace requires 1 or 2 filters which are installed in the blower compartment. (See Fig. 2.) To remove filters for cleaning or replacement, proceed as follows:

1. Disconnect electrical power before removing access doors.
2. Remove blower and control access doors.
3. Release filter retainer from clip at front of furnace casing. (See Fig. 2.) For side return, clips may be used on either or both sides of the furnace.
4. Slide filter(s) out.

5. Furnaces are equipped with permanent, washable filters. Clean filters with tap water. Spray water through filter in opposite direction of airflow.
6. Rinse and let dry. Oiling or coating of filter is NOT recommended or required.
7. Reinstall filter(s).
8. Replace blower and control access doors.
9. Restore electrical power to furnace.



A92063

Fig. 2—Model 58YAV Upflow Furnace

BLOWER MOTOR AND WHEEL

For long life, economy, and high efficiency, clean accumulated dirt and grease from the blower wheel and motor annually.

The following steps should be performed by a qualified service technician.

Some motors have prelubricated sealed bearings and require no lubrication. These motors can be identified by the absence of oil ports on each end of the motor. For those motors with oil ports, lubricate motor every 5 years if motor is used on intermittent operation (thermostat FAN selection in AUTO mode), or every 2 years if motor is in continuous operation (thermostat FAN selection in ON mode).

NOTE: Remember to disconnect the electrical supply before removing access doors.

Clean and lubricate as follows:

1. Remove blower and control access doors.
2. Remove screws holding control support to blower deck, and hold control assembly out of way.
3. Disconnect blower motor electrical leads from control. (See Fig. 2.) Note location of wires for reassembly.
4. Remove screws holding blower assembly to blower deck and slide blower assembly out of furnace.
5. Loosen screw in strap holding motor capacitor to blower housing and slide capacitor out from under strap.
6. Mark blower wheel, motor, and motor support in relation to blower housing before disassembly to ensure proper reassembly.
7. Loosen setscrew holding blower wheel on motor shaft. Disconnect ground wire attached to blower housing.
8. Remove bolts holding motor mount to blower housing and slide motor and mount out of housing. Do not loosen motor mount belly-band bolt unless motor is to be replaced.
9. Lubricate motor (when oil ports are provided).
 - a. Remove dust caps or plugs from oil ports located at each end of motor.
 - b. Use a good grade of SAE 20 nondetergent motor oil and put 1 teaspoon, 5 cc, 3/16 oz, or 16 to 25 drops in each oil port. Do NOT over-oil.
 - c. Allow time for total quantity of oil to be absorbed by each bearing.
 - d. Wipe excess oil from motor housing.
 - e. Replace dust caps or plugs on oil ports.
10. Remove blower wheel from housing.
 - a. Mark cutoff plate location to ensure proper reassembly.
 - b. Remove screws holding cutoff plate and remove cutoff plate from housing.
 - c. Lift blower wheel from housing through opening.
11. Clean blower wheel and motor using a vacuum cleaner with soft brush attachment. Do not remove or disturb balance weights (clips) on blower wheel blades. The blower wheel should not be dropped or bent as balance will be affected.
12. Reinstall blower wheel by reversing items 10 a through c. Be sure wheel is positioned for proper rotation.
13. Reassemble motor and blower by reversing items 5 through 8. Be sure ground wire is connected as before.
14. Reinstall and secure blower assembly in furnace.
15. Reinstall control assembly. Connect blower electrical leads to control. Please note that the common wire connection is 3/16-in. terminal and all other wire connections are 1/4-in. terminals for assembly. DO NOT FORCE.
16. Replace blower and control access doors.
17. Turn on electrical power and check for speed changes between heating and cooling.

⚠ CAUTION

Be sure the motor is properly positioned in the blower housing. The motor oil ports must be within 45° of top of the motor after the blower assembly has been reinstalled in the furnace.

CLEANING HEAT EXCHANGER

The following steps should be performed by a qualified service technician.

NOTE: Deposits of soot and carbon indicate the existence of a problem which needs to be corrected. Take action to correct the problem.

If it becomes necessary to clean the heat exchanger because of carbon deposits, soot, etc., proceed as follows:

1. Turn off gas and electrical power to furnace.
2. Remove control and blower access doors.
3. Remove vent pipe from relief box.
4. Remove 2 screws that secure relief box. (See Fig. 2.)
5. After labeling wires, disconnect from the following components:
 - a. Draft safeguard switch
 - b. Inducer motor
 - c. Pressure switch


- d. Limit overtemperature switch(es)
 - e. Gas valve
 - f. Hot surface ignitor
 - g. Flame-sensing electrode
 - h. Two wiring connectors leading to control
6. Remove 8 screws that secure flue collector box to center panel. Be careful not to damage sealant.
 7. Remove complete inducer and collector box assembly from furnace, exposing flue openings.
 8. Clean cells using field-provided small wire brush, steel spring cable, reversible electric drill, and vacuum cleaner.

a. Assemble wire brush and steel spring cable.

- (1.) Use 48 in. of 1/4-in. diameter high-grade steel spring cable (commonly known as drain clean-out or Roto-Rooter cable).
- (2.) Use 1/4-in. diameter wire brush (commonly known as 25-caliber rifle cleaning brush).

NOTE: The materials needed in items (1.) and (2.) can usually be purchased at local hardware stores.

- (3.) Remove metal screw fitting from wire brush to allow insertion into cable.
 - (4.) Insert twisted wire end of brush into end of steel spring cable, and crimp tight with crimping tool or strike with ball-peen hammer. **TIGHTNESS** is very important.
- b. Clean each heat exchanger cell.
- (1.) Attach variable-speed, reversible drill to end of steel spring cable (end opposite brush).
 - (2.) Insert brush end of cable into upper opening of cell and slowly rotate with drill. **DO NOT** force cable. Gradually insert at least 36 in. of cable into 2 upper passes of cell. (See Fig. 3.)



A91252


Fig. 3—Cleaning Heat Exchanger Cell

- (3.) Work cable in and out of cell 3 or 4 times to obtain sufficient cleaning. **DO NOT** pull cable with great force. Reverse drill and gradually work cable out.
- (4.) Remove burner assembly and cell inlet plates.

⚠ CAUTION

Be very careful when removing the burner assembly to avoid breaking the ignitor. See Fig. 9 for the correct ignitor location.

- (5.) Replace screws in center panel and cells before cleaning.
- (6.) Insert brush end of cable in lower opening of cell, and proceed to clean 2 lower passes of cell in same manner as 2 upper passes.



A93347

Fig. 4—Position of Ignitor to Burner

- (7.) Repeat foregoing procedures until each cell in furnace has been cleaned.
 - (8.) Remove residue from each cell using vacuum cleaner.
 - (9.) Clean burner assembly using vacuum cleaner with soft brush attachment.
 - (10.) Reinstall cell inlet plates and burner assembly. Care must be exercised to center the burners in the cell openings.
9. After cleaning flue openings, check sealant on flue collector box to ensure that it has not been damaged. If new sealant is needed, contact your dealer or distributor.
 10. Clean and replace flue collector assembly, making sure all 8 screws are secure.
 11. Reinstall screws to secure relief box.
 12. Reconnect wires to the following components.
 - a. Draft safeguard switch
 - b. Inducer motor
 - c. Pressure switch
 - d. Limit overtemperature switch(es)
 - e. Gas valve
 - f. Hot surface ignitor
 - g. Flame-sensing electrode
 - h. Two wiring connectors leading to control
 13. Reconnect vent pipe to relief box.
 14. Replace blower access door only.
 15. Turn on electrical power and gas.
 16. Set thermostat and check furnace for proper operation.

⚠ WARNING

Never use a match or other open flame to check for gas leaks. Use a soap-and-water solution. A failure to follow this warning could result in fire, personal injury, or death.

17. Check for gas leaks.

18. Replace control access door.

ELECTRICAL CONTROLS AND WIRING

⚠ CAUTION

There may be more than 1 electrical supply to the unit. Check accessories and cooling unit for additional electrical supplies.

The electrical ground and polarity for 115-v wiring must be maintained properly. Refer to Fig. 5 for field wiring information and to Fig. 7 for unit wiring information.

NOTE: If the polarity is not correct, the STATUS LED on the control will flash rapidly and prevent the furnace from operating. The control system also requires an earth ground for proper operation of the control and flame-sensing electrode.

The 24-v circuit contains an automotive-type, 3-amp fuse located on the control (See Fig. 6.) Any direct shorts of the 24-v wiring during installation, service, or maintenance will cause this fuse to blow. If fuse replacement is required, use ONLY a fuse of identical size.

With power to the unit disconnected, check all electrical connections for tightness. Tighten all screws on electrical connections. If any smoky or burned connections are found, disassemble the connection, clean all parts, strip wire, and reassemble properly and securely.

Reconnect electrical power to the unit and observe unit through 1 complete operating cycle. Electrical controls are difficult to check without proper instrumentation; if there are any discrepancies in the operating cycle, contact your dealer and request service.

For an explanation of status codes, refer to service label located on blower access door or Fig 8, and the troubleshooting guide.

The control center stores 1 status code (the last status code to occur) for a period of 48 hr or until the 115- or 24-v power is interrupted.

NOTE: Removing blower access door will open blower access door switch and terminate 115-v power to control, and status code will be erased. Look into blower access door sight glass for current LED status BEFORE removing the blower access door.

1. To retrieve status code, proceed with the following:

NOTE: NO thermostat signal shall be present at control center, and all blower off time delay must be completed.

- Leave 115-v power to furnace turned on.
- Look into blower access door sight glass for current LED status.

NOTE: Leave blower access panel installed to maintain power to control to view current LED status.

- Remove control access door.
- BRIEFLY remove either wire from the main limit switch until LED goes out, then reconnect it.

NOTE: If wire to main limit is disconnected longer than 4 sec, main blower starts, and retrieval request is ignored.

- When above items have been completed, the following will occur:
 - LED flashes a status code 4 times. Record this status code for further troubleshooting.
 - Inducer motor starts and continues to run the entire component test.
 - Hot surface ignitor is energized for 15 sec, then de-energized.
 - Main blower operates at heating speed for 10 sec, then turns off.
 - Main blower operates at cooling speed for 10 sec, then turns off.
 - Inducer motor stops.

Items a through e above will assist in furnace troubleshooting since all components are functionally operated except the gas valve. This procedure is also referred to as "Component Test."

- Operate furnace through 1 heat cycle to test for proper operation and check LED status.
- If furnace is operating properly and LED indicates proper operation, replace control access door.
- Component Test can also be initiated by performing the following:
 - Remove control access door.
 - Remove blower access door.
 - Manually close blower access door switch.

⚠ WARNING

Blower access door switch opens 115-v power to control. No component operation can occur. Caution must be taken when manually closing this switch for service purposes. Failure to follow this warning could result in personal injury or death.

- BRIEFLY short (jumper) TEST, 1/4-in. quick-connect terminal on control center (adjacent to LED status light), and Com 24-v terminal on furnace control thermostat terminal block. (See Fig 6.)

NOTE: If TEST to Com 24-v terminals are jumpered longer than 2 sec, LED will flash rapidly, and retrieval request will be ignored.


- Component Test will function as described in item 2 above.
- Check LED status.
- If LED status indicates proper operation, release blower access door switch, replace blower access door, and replace control access door.

TROUBLESHOOTING

Refer to the service label. (See Fig. 8.) Pages 8 and 9 contain a troubleshooting guide. This guide can be a useful tool in isolating furnace operation problems. Beginning with the word "Start," answer each question and follow the appropriate arrow to the next item.

The guide will help to identify the problem or failed component. After replacing any component, verify correct operation sequence.

----- FIELD 24-VOLT WIRING
 ----- FIELD 115-, 208/230-, 460-VOLT WIRING
 ----- FACTORY 24-VOLT WIRING
 ----- FACTORY 115-VOLT WIRING



- NOTES:**
1. Connect Y-terminal in furnace as shown for proper blower operation.
 2. Some thermostats require a "C" terminal connection as shown.
 3. If any of the original wire, as supplied, must be replaced, use same type or equivalent wire.

A96312

Fig. 5—Heating and Cooling Application Wiring Diagram






Fig. 6—Furnace Control

A93052

TROUBLESHOOTING GUIDE





SERVICE

LED CODE

STATUS

CONTINUOUS OFF -

Check for 115VAC at L1 and L2, and 24VAC at SEC-1 and SEC-2.

CONTINUOUS ON -

Control has 24V power.

RAPID FLASHING -

Line voltage (115V) polarity reversed. If twinned, refer to twinning kit instructions.

EACH OF THE FOLLOWING STATUS CODES IS A TWO DIGIT NUMBER WITH THE FIRST DIGIT DETERMINED BY THE NUMBER OF SHORT FLASHES AND THE SECOND DIGIT BY THE NUMBER OF LONG FLASHES.

11

NO PREVIOUS CODE - Stored status codes are erased when power (115V or 24V) to control is interrupted or 48 hours after each fault is cleared.

12

BLOWER ON AFTER POWER UP (115V or 24V) - Blower runs for 90 seconds, if unit is powered up during a call for heat (R-W closed).

13

LIMIT OR FLAME ROLL-OUT SWITCH LOCKOUT - Auto reset after three hours. For flame roll-out switch or fuse link, refer to #33.

14

IGNITION LOCKOUT - Control will auto-reset after three hours. Refer to #34.

21

GAS HEATING LOCKOUT - Control will NOT auto reset.
Check for: - Stuck gas valve relay on control or miswire to gas valve circuit.

22

ABNORMAL FLAME-PROVING SIGNAL - Flame is proved while gas valve is de-energized. Inducer will run until fault is cleared. Check for:
- Stuck-open gas valve or leaky gas valve.

23

PRESSURE SWITCH DID NOT OPEN Check for:
- Obstructed pressure tubing. - Defective pressure switch (stuck closed).

24

SECONDARY VOLTAGE FUSE IS OPEN
Check for: - Short circuit in secondary voltage (24V) wiring.

31

PRESSURE, DRAFT SAFEGUARD, AUXILIARY-LIMIT (when used), OR BLOCKED VENT SHUTOFF (when used) SWITCH DID NOT CLOSE OR REOPENED - If open longer than five minutes, inducer shuts off for 15 minutes before retry. Check for:
- Proper vent sizing and condensate pitch or sag. - Inadequate Combustion air supply. - Low inducer voltage.
- Vent restriction or high winds. - Disconnected or obstructed pressure tubing.
- Defective inducer motor or start capacitor. - Defective pressure switch or connections. If it opens after trial for ignition period, blower will come on for 90 second recycle delay.

33

LIMIT OR FLAME ROLL-OUT SWITCH IS OPEN - If open longer than three minutes, code changes to #13. Check for:
- Defective blower motor or start capacitor. - Dirty filter or restricted duct system.
- Loose blower wheel. - Defective switch or connections.
- Inadequate Combustion air supply Flame Roll-out Switch or fuse link.
- Open Flame Roll-out switch, or fuse link. Manual reset or replace.

34

IGNITION PROVING FAILURE - Control will try three more times before a lockout #14 occurs. If flame signal lost after trial for ignition period, blower will come on for 90 second recycle delay. Check for:
- Oxide buildup on flame sensor (clean with fine sandpaper).
- Proper flame sense microamps (.5 microamps D.C. minimum).
- Gas valve turned off. - Manual shut-off valve. - Low inlet gas pressure.
- Green wire **MUST** be connected to furnace sheet metal.
- Inadequate flame carryover or rough ignition.

COMPONENT TEST

To initiate the component test sequence, shut OFF the room thermostat or disconnect the "R" thermostat lead. Briefly short the TEST terminal to the 'Com 24V' terminal. Status LED will flash code and then turn ON the inducer motor. The inducer motor will run for the entire component test. The hot surface ignitor, blower motor-heat speed, and blower motor-cool speed will be turned ON for 10-15 seconds each.

320615-102 REV. H

Fig. 8—Service Label

A96263

SERVICE TRAINING

Packaged Service Training programs are an excellent way to increase your knowledge of the equipment discussed in this manual, including:

- Unit Familiarization
- Maintenance
- Installation Overview
- Operating Sequence

A large selection of product, theory, and skills programs is available, using popular video-based formats and materials. All include video and/or slides, plus companion book.

Classroom Service Training plus "hands-on" the products in our labs can mean increased confidence that really pays dividends in faster troubleshooting, fewer callbacks. Course descriptions and schedules are in our catalog.

CALL FOR FREE CATALOG 1-800-962-9212

☐ Packaged Service Training

☐ Classroom Service Training

