

Service Manual

TABLE OF CONTENTS

	PAGE
SAFETY CONSIDERATIONS	
SAFETY CONSIDERATIONS.....	1
INTRODUCTION	1
MODEL / SERIAL NUMBER NOMENCLATURES	2
WIRING.....	3
CONNECTION DIAGRAMS	4
WIRING DIAGRAMS (HEAT PUMP)	5
REFRIGERATION HEAT PUMP CYCLE DIAGRAMS	11
REFRIGERATION COOLING ONLY CYCLE DIAGRAMS	15
SYSTEM EVACUATION AND CHARGING.....	19
TROUBLESHOOTING.....	26
PCB DIAGRAMS (HEAT PUMP)	28
PCB DIAGRAMS (COOLING ONLY)	30
DIAGNOSIS AND SOLUTION	33
DISASSEMBLY INSTRUCTIONS	56
APPENDIX	82

Installing, starting up, and servicing air-conditioning equipment can be hazardous due to system pressures, electrical components, and equipment location (roofs, elevated structures, etc.).

Only trained, qualified installers and service mechanics should install, start-up, and service this equipment.

Untrained personnel can perform basic maintenance functions such as coil cleaning. All other operations should be performed by trained service personnel.

When working on the equipment, observe precautions in the literature and on tags, stickers, and labels attached to the equipment.

Follow all safety codes. Wear safety glasses and work gloves. Keep a quenching cloth and fire extinguisher nearby when brazing. Use care in handling, rigging, and setting bulky equipment.

Read this manual thoroughly and follow all warnings or cautions included in the literature and attached to the unit. Consult local building codes and National Electrical Code (NEC) for special requirements. Recognize safety information. This is the safety-alert symbol . When you see this symbol on the unit and in instructions or manuals, be alert to the potential for personal injury.

Understand these signal words: **DANGER**, **WARNING**, and **CAUTION**. These words are used with the safety-alert symbol.

DANGER identifies the most serious hazards which **will** result in severe personal injury or death. **WARNING** signifies hazards which **could** result in personal injury or death.

CAUTION is used to identify unsafe practices which **may** result in minor personal injury or product and property damage.

NOTE is used to highlight suggestions which **will** result in enhanced installation, reliability, or operation.

! WARNING

ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death.

Before installing, modifying, or servicing the system, the main electrical disconnect switch must be in the **OFF** position. There may be more than 1 disconnect switch. Lock out and tag switch with a suitable warning label.

! WARNING

EXPLOSION HAZARD

Failure to follow this warning could result in death, serious personal injury, and/or property damage. Never use air or gases containing oxygen for leak testing or operating refrigerant compressors. Pressurized mixtures of air or gases containing oxygen can lead to an explosion.



! CAUTION

EQUIPMENT DAMAGE HAZARD

Failure to follow this caution may result in equipment damage or improper operation. Do not bury more than 36 in. (914 mm) of refrigerant pipe in the ground. If any section of pipe is buried, there must be a 6 in. (152 mm) vertical rise to the valve connections on the outdoor units.

If more than the recommended length is buried, refrigerant may migrate to the cooler buried section during extended periods of system shutdown. This causes refrigerant slugging and could possibly damage the compressor at start-up.

INTRODUCTION

This service manual provides the necessary information to service, repair, and maintain the outdoor units. This manual has an appendix (see “APPENDIX” on page 82) with data required to perform troubleshooting. Use the “Table of Contents” to locate a desired topic.


MODEL / SERIAL NUMBER NOMENCLATURES

Table 1 — Unit Sizes


Heat Pump	SYSTEM TONS	BTUh	VOLTAGE - PHASE	OUTDOOR MODEL
	1.00	12,000	115-1-60	38MHRCQ12AA1
	0.75	9,000	208/230-1	38MHRCQ09AA3
	1.00	12,000		38MHRCQ12AA3
	1.50	18,000		38MHRCQ18AA3
	2.00	24,000		38MHRCQ24AA3

Table 2 — Unit Sizes

Cooling Only	SYSTEM TONS	BTUh	VOLTAGE - PHASE	OUTDOOR MODEL
	1.00	12,000	115-1-60	38MRCC12AA1
	1.00	12,000	208/230-1	38MRCC12AA3
	1.50	18,000		38MRCC18AA3
	2.00	24,000		38MRCC24AA3



A210445



A210446



Use of the AHRI Certified TM Mark indicates a manufacturer's participation in the program. For verification of certification for individual products, go to www.ahridirectory.org.



WIRING

All wires must be sized per NEC (National Electrical Code) or CEC (Canadian Electrical Code) and local codes. Use Electrical Data table MCA (minimum circuit amps) and MOCP (maximum over current protection) to correctly size the wires and the disconnect fuse or breakers respectively.

Recommended Connection Method for Power and Communication Wiring:

The main power is supplied to the outdoor unit. The field supplied 14/3 power/communication wiring, from the outdoor unit to the indoor unit, consists of four (4) wires and provides the power for the indoor unit. Two wires are high voltage AC power, one is communication wiring and the other is a ground wire. Wiring between indoor and outdoor unit is polarity sensitive. The use of BX wire is NOT recommended.

If installed in a high Electromagnetic field (EMF) area and communication issues exists, a 14/2 stranded shielded wire can be used to replace L2 and (S) between outdoor unit and indoor unit landing the shield onto ground in the outdoor unit only.



CAUTION

EQUIPMENT DAMAGE HAZARD

Failure to follow this caution may result in equipment damage or improper operation.

Wires should be sized based on NEC and local codes.



CAUTION

EQUIPMENT DAMAGE HAZARD

Failure to follow this caution may result in equipment damage or improper operation.


Be sure to comply with the local codes while running wire from the indoor unit to the outdoor unit.

Every wire must be connected firmly. Loose wiring may cause the terminal to overheat or result in unit malfunction. A fire hazard may also exist. Ensure all wiring is tightly connected.

No wire should touch the refrigerant tubing, compressor or any moving parts.


Disconnecting means must be provided and shall be located within sight and readily accessible from the air conditioner.

CONNECTION DIAGRAMS



A210448

Fig. 1 — Connection Diagram 12K (115V)




A210449

Fig. 2 — Connection Diagram 9K-24K (208-230V)

NOTES:

1. Do not use thermostat wire for any connection between indoor and outdoor units.
2. All connections between the indoor and outdoor units must be made as shown in Figures 1 - 2. The connections are sensitive to polarity and results in a fault code.

WIRING DIAGRAMS (HEAT PUMP)



A210450

Fig. 3 — Wiring Diagram Size 12K (115V)

Table 3 — Wiring Diagram Size 12K (115V)

		CN1A	INPUT	115V	AC
		CN4_2/4_3	INPUT	115V	AC
		CN7	OUTPUT	0-310V	AC
		CN60	OUTPUT	115V	AC
T3	Condenser TEMP. Sensor	CN21	INPUT	0-5V	DC
T4	Ambient TEMP. Sensor				
TP	Discharge TEMP. Sensor	CN15 CN17 CN50	OUTPUT	115V	AC
			OUTPUT	115V	AC
			OUTPUT	0-310V	AC

WIRING DIAGRAMS (CONT)




Fig. 4 —Wiring Diagram Sizes 9-18K (208-230V)

A210453

Table 4 — Wiring Diagram Sizes 9-18K (208-230V)

		CN1A	INPUT	230V	AC	
		CN7	OUTPUT	0-310V	AC	
		CN60	OUTPUT	230V	AC	
T3	Condenser TEMP. Sensor	CN21	INPUT	0-5V	DC	
T4	Ambient TEMP. Sensor					
TP	Discharge TEMP. Sensor	CN50	OUTPUT	230V	AC	
			OUTPUT	230V	AC	
			OUTPUT	0-310V	AC	

WIRING DIAGRAMS (CONT)





Fig. 5 —Wiring Diagram Size 24K (208-230V)

A210454

Table 5 — Wiring Diagram Size 24K (208-230V)

		CN2/7/8	INPUT	230V	AC
		CN414	OUTPUT	0-310V	AC
		CN60	OUTPUT	230V	AC
T3	Condenser TEMP. Sensor	CN17	INPUT	0-5V	DC
T4	Ambient TEMP. Sensor				
TP	Discharge TEMP. Sensor	CN27/28/29	OUTPUT	230V	AC
			OUTPUT	230V	AC
			OUTPUT	0-310V	AC

WIRING DIAGRAMS (CONT)




A210505

Fig. 6 —Wiring Diagram Size 12K (115V) Cooling Only

Table 6 — Wiring Diagram Size 12K (115V) Cooling Only

		CN1A	INPUT	115V	AC
		CN4_2/4_3	INPUT	115V	AC
T3	Condenser TEMP. Sensor	CN21	OUTPUT	0~5V	DC
T4	Ambient TEMP. Sensor	CN7	OUTPUT	0~310V	AC
TP	Discharge TEMP. Sensor	CN50	OUTPUT	0~310V	AC

WIRING DIAGRAMS (CONT)




A210506

Fig. 7 —Wiring Diagram Size 12K and 18K (208/230V) Cooling Only

Table 7 — Wiring Diagram Size 12K and 18K (208/230V) Cooling Only

		CN1A	INPUT	230V	AC
		CN7	OUTPUT	0~310V	AC
		CN21	OUTPUT	0~5V	DC
T3	Condenser TEMP. Sensor	CN15	OUTPUT	230V	AC
T4	Ambient TEMP. Sensor	CN17	OUTPUT	230V	AC
TP	Discharge TEMP. Sensor	CN50	OUTPUT	0~310V	AC

WIRING DIAGRAMS (CONT)




A210507

Fig. 8 —Wiring Diagram Size 24K (208/230V) Cooling Only

Table 8 — Wiring Diagram Size 24K (208/230V) Cooling Only

		CN1A	INPUT	230V	AC
		CN7	OUTPUT	0~310V	AC
		CN21	OUTPUT	0~5V	DC
T3	Condenser TEMP. Sensor	CN15	OUTPUT	230V	AC
T4	Ambient TEMP. Sensor	CN17	OUTPUT	230V	AC
TP	Discharge TEMP. Sensor	CN50	OUTPUT	0~310V	AC

REFRIGERATION HEAT PUMP CYCLE DIAGRAMS



A210455

Fig. 9 —Size 12K - 115V and 208/230V

REFRIGERATION HEAT PUMP CYCLE DIAGRAMS (CONT)




Fig. 10 —Size 9K - 208/230V Heat Pump

A210461

REFRIGERATION HEAT PUMP CYCLE DIAGRAMS (CONT)




Fig. 11 —Size 18K - 208/230V Heat Pump

REFRIGERATION HEAT PUMP CYCLE DIAGRAMS (CONT)




Fig. 12 —Size 24K - 208/230V Heat Pump

REFRIGERATION COOLING ONLY CYCLE DIAGRAMS





Fig. 13 —Size 12K - 115V and 208/230V Cooling Only

A210508


REFRIGERATION COOLING ONLY CYCLE DIAGRAMS (CONT)



Size 18K - 208/230V Cooling Only

A210509

REFRIGERATION COOLING ONLY CYCLE DIAGRAMS (CONT)



A210510

Fig. 14 —24K - 208/230V Cooling Only

Refrigerant Lines

General Refrigerant Line Sizing

1. The outdoor units are shipped with a full charge of R410A refrigerant. All charges, line sizing, and capacities are based on runs of 25ft. (7.6 m). For runs over 25 ft. (7.6 m), refer to “Long-Line Applications” on page 18 for the proper charge adjustments.
2. The minimum refrigerant line length between the indoor and outdoor units is 10 ft. (3 m).
3. Refrigerant lines should not be buried in the ground. If it’s necessary to bury the lines, not more than 36 in (914 mm) should be buried. Provide a minimum 6in (152 mm) vertical rise to the service valves to prevent refrigerant migration.

4. Both lines must be insulated. Use a minimum of 1/2in. (12.7 mm) thick insulation. Closed-cell insulation is recommended in all long-line applications.
5. Special consideration should be given to isolating interconnecting tubing from the building structure. Isolate the tubing so vibration or noise is not transmitted into the structure.

IMPORTANT: Both refrigerant lines must be insulated separately.

Table 9 lists the maximum lengths allowed.

Table 9 — Piping and Refrigerant Information

System Size			12K(115V)	9K(208/230V)	12K(208/230V)	18K(208/230V)	24K(208/230V)
Piping	Minimum Piping Length	ft. (m)	9.8 (3)	9.8 (3)	9.8 (3)	9.8 (3)	9.8 (3)
	Standard Piping Length	ft. (m)	24.6 (7.5)	24.6 (7.5)	24.6 (7.5)	24.6 (7.5)	24.6 (7.5)
	Maximum outdoor-indoor height difference (OU higher than IU)	ft. (m)	32.8 (10)	32.8 (10)	32.8 (10)	65.6 (20)	82 (25)
	Maximum outdoor-indoor height difference (IU higher than OU)	ft. (m)	32.8 (10)	32.8 (10)	32.8 (10)	65.6 (20)	82 (25)
	Maximum Piping Length with no additional refrigerant charge per System (Standard Piping length)	ft. (m)	24.6 (7.5)	24.6 (7.5)	24.6 (7.5)	24.6 (7.5)	24.6 (7.5)
	Total Maximum Piping Length per system	ft. (m)	82 (25)	82 (25)	82 (25)	98.4 (30)	164 (50)
	Additional refrigerant charge (between Standard – Maximum piping length)	Oz/ft (g/m)	0.161(15)	0.161(15)	0.161(15)	0.161(15)	0.322(30)
	Suction Pipe (size - connection type)	In (mm)	ø1/2" (12.7)	ø3/8" (9.52)	ø1/2" (12.7)	ø1/2" (12.7)	ø5/8" (15.9)
	Liquid Pipe (size - connection type)	In (mm)	ø1/4" (6.35)	ø1/4" (6.35)	ø1/4" (6.35)	ø1/4" (6.35)	ø3/8" (9.52)
Refrigerant	Refrigerant Type	Type	R410A	R410A	R410A	R410A	R410A
	Charge Amount (Heat Pump)	lb. (kg)	1.79(0.81)	1.59(0.72)	1.79(0.81)	2.98(1.35)	3.92(1.78)
	Charge Amount (Cooling Only)	lb. (kg)	1.43 (0.65)	-	1.43 (0.65)	1.98(0.9)	3.92 (1.78)

Long-Line Applications

1. No change in line sizing is required.
2. Add refrigerant per Table 9.

SYSTEM EVACUATION AND CHARGING



CAUTION

UNIT DAMAGE HAZARD

Failure to follow this caution may result in equipment damage or improper operation.


Never use the system compressor as a vacuum pump.

Refrigerant tubes and indoor coil should be evacuated using the recommended deep vacuum method of 500 microns. Always break a vacuum with dry nitrogen.

System Vacuum and Charge


Using Vacuum Pump

1. Completely tighten all flare nuts and connect manifold gage charge hose to a charge port of the low side service valve (see Fig. 15).
2. Connect the charge hose to vacuum pump.
3. Fully open the low side of manifold gage (see Fig. 16).
4. Start the vacuum pump.
5. Evacuate using the triple evacuation method.
6. After evacuation is complete, fully close the low side of manifold gage and stop operation of vacuum pump.
7. The factory charge contained in the outdoor unit is good for up to 25 ft. (8 m) of line length. For refrigerant lines longer than 25 ft. (8 m), add refrigerant as specified in the Table 9 on page 18.
8. Disconnect the charge hose from the charge connection of the low side service valve.
9. Fully open the B and A service valves.
10. Securely tighten the service valves caps.



A210467

Fig. 15 —Service Valve




A210468

Fig. 16 —Manifold

Deep Vacuum Method

The deep vacuum method requires a vacuum pump capable of pulling a vacuum of 500 microns and a vacuum gage capable of accurately measuring this vacuum depth. The deep vacuum method is the most positive way of assuring a system is free of air and liquid water (see Fig. 17).




A210465

Fig. 17 —Deep Vacuum Graph

Triple Evacuation Method

The triple evacuation method should be used. Refer to Fig. 18 and proceed as follows:

1. Pump the system down to 500 MICRONS of mercury and allow the pump to continue operating for an additional 15 minutes.
2. Close the service valves and shut off the vacuum pump.
3. Connect a nitrogen cylinder and regulator to the system and open until the system pressure is 2 psig.
4. Close the service valve and allow the system to stand for 10 minutes. During this time, dry nitrogen will be able to diffuse throughout the system absorbing moisture.
5. Repeat this procedure as indicated in Fig. 18. The system is now free of any contaminants and water vapor.



A210469

Fig. 18 —Triple Evacuation Method

Final Tubing Check

IMPORTANT: Check to be certain factory tubing on both indoor and outdoor unit has not shifted during shipment. Ensure tubes are not rubbing against each other or any sheet metal. Pay close attention to feeder tubes, making sure wire ties on feeder tubes are secure and tight.

Electronic Functions

Abbreviation:

- T1: Indoor room temperature
- T2: Coil temperature of indoor heat exchanger middle
- T3: Coil temperature of condenser
- T4: Outdoor ambient temperature
- T5: Compressor discharge temperature
- Td: Target temperature
- Ts: Set Point Temperature

Main Protection

Three minute delay for compressor restart

Less than a 1 minute delay for the initial start-up and a 3 minute delay for subsequent starts.

Compressor high temperature cutout

The unit stops working when the compressor high temperature cutout opens, and restarts after the compressor high temperature cutout closes.

Compressor discharge temperature protection

Compressor discharge temp. $T5 > 239^{\circ}\text{F}$ (115°C) for 5s, compressor stops.

Fan speed is out of control

When the indoor fan speed is too low (300RPM) or too high (1500RPM) for a certain time, the unit stops and the LED displays the failure.

Inverter module protection

The inverter module has a protection function for current, voltage and temperature. If any of these protections engage, the corresponding code displays on the indoor unit and the unit stops working.

Indoor fan delayed open function

When the unit starts up, the louver is active immediately and the indoor fan opens 10s later. If the unit is running in the **HEATING** mode, the indoor fan is also controlled by the anti-cold wind function.

Compressor preheating functions

Preheat parameters: When the $T4$ (outdoor ambient temperature) $< 37.4^{\circ}\text{F}$ (3°C), preheat function is activated.

Zero crossing detection error protection

If the AC detects the time interval is not correct for a continuous 240s, the unit stops and the **LED** displays the failure. The correct zero crossing signal time interval should be between 6-13ms.

Sensor protection at open circuit and breaking disconnection

If only one temperature sensor malfunctions, the air conditioner continues to work however the error code displays on the LED, in the event of any emergency use. If more than one temperature sensor malfunctions, the air conditioner stops working.

Refrigerant leakage detection

This function is only active in the **COOLING** mode. The function helps prevent the compressor from being damaged by a refrigerant leakage or a compressor overload.


Open condition:

When the compressor is active, the evaporator $T2$ coil temperature value has no or very little change.

Operation Modes and Functions

FAN Mode

1. Outdoor fan and compressor stop
2. Temperature setting function is disabled and no setting temperature appears.
3. Indoor fan can be set to high/med/low/auto
4. The louver operates same as in the **COOLING** mode.
5. Auto fan



A210470

Fig. 19 —AUTO FAN Mode


COOLING Mode

Compressor Running Rules:

- When $T1 - Ts < -4^{\circ}\text{F}$ (-2°C), the compressor stops.
- When $T1 - Ts > -1^{\circ}\text{F}$ (-0.5°C), the compressor activates.
- When the AC runs in the **QUIET** mode, the compressor runs with low frequency.
- When the current is more than setting value, the current protection function activates, and the compressor stops.

Outdoor Fan Running Rules:

The outdoor unit runs at a different fan speed according to $T4$. For different outdoor units, the fan speeds differ.




A210471

Fig. 20 —Outdoor Fan Running Rules

Indoor Fan Running Rules:


- In the **COOLING** mode, the indoor fan runs continuously and the user can select any of the following speeds: **HIGH**, **MEDIUM**, **LOW** and **AUTO**.
- When the setting temperature is reached, if the compressor stops running, the indoor fan motor runs in the minimum or setting speed (see Fig. 21).




A210472

Fig. 21 — Indoor Fan Running Rules

The **AUTO** fan adheres to the following rules (see Fig. 22):



A210473

Fig. 22 — AUTO FAN Running Rules**Compressor Temperature Protection**

A210474

Fig. 23 — Compressor Temperature Protection

- Off:** Compressor stops
- Decrease:** Decrease the running frequency to the lower level
- Hold:** Keep the current frequency
- Resume:** No limitation for frequency

When the condenser temperature is higher than the setting value, the compressor stops.

Evaporator Temperature Protection


When the evaporator temperature is lower than the setting value the compressor stops.

HEATING Mode**Compressor Running Rules:**

- When $T1-Ts > -\Delta T$, the compressor stops.
- When $T1-Ts < -\Delta T-1.5$, the compressor is on. ΔT is the programmed parameter for temperature compensation.
- When the AC runs in **MUTE** mode, the compressor runs with a low frequency.
- When the current is more than the setting value, the current protection function activates and the compressor stops.

Outdoor Fan Running Rules:

The outdoor unit runs at a different fan speed according to T4. For different outdoor units, the fan speeds differ.



A210475

Fig. 24 — Outdoor Fan Running Rules


Indoor Fan Running Rules:

When the compressor is on, the user can set the indoor fan to either **HIGH/MED/LOW/AUTO/MUTE**. When the indoor unit coil temperature is low, the anti-cold air function starts and the indoor fan motor runs at the low speed. The speed can not be changed.

When the temperature is lower than the setting value, the indoor fan motor stops. When the indoor temperature reaches the setting temperature, the compressor stops, the indoor fan motor runs at the minimum speed or setting speed. The anti-cold air function is valid. The indoor fan is controlled as shown in Fig. 25.

Setting Fan Speed	T1-Td+3°F (1.5 °C)		Actual Fan Speed
H	-2.7°F(-1.5°C)		H - (H=H-G)
	-5.4°F (-3.0°C)		H (=H)
	-8.1°F(-4.5°C)		H + (H+ =H+G)
M	-2.7°F(-1.5°C)		M - (M-=M-Z)
	-5.4°F (-3.0°C)		M (M=M)
	-8.1°F(-4.5°C)		M + (M+ =M+Z)
L	-2.7°F(-1.5°C)		L - (L-=L-D)
	-5.4°F (-3.0°C)		L (L=L)
	-8.1°F(-4.5°C)		L + (L+ =L+D)

A210476

Fig. 25 —Indoor Fan Running RulesAuto fan action in the **HEATING** mode.

A210477

Fig. 26 —Auto Fan Action in HEATING Mode


DEFROST Mode

The air conditioning unit enters the **DEFROST** mode according to the value of temperature of T3 and the value range of temperature change of T3 plus the compressor running time (see Figure 27).

During the **DEFROST** mode, the compressor keeps running however the indoor and outdoor motors stop.

Forced DEFROSTING Mode:)

1. Press and hold **AUTO/COOL** for 5s to enter the mode. The indoor fan stops and the defrosting lamp illuminates. Use the remote control to exit this mode and turn off the unit to stop the normal defrosting mode.
2. To exit the **FORCED DEFROSTING** mode, press and hold **AUTO/COOL** for 5s again.



	Compressor run time	Temperature Change
Condition 1	Total compressor running time is 29 mins	T3-7°C & T30-2.5°C
Condition 2	Total compressor running time is 35 mins	T3-5°C & T30-3°C
Condition 3	Total compressor running time is 40 mins	T3-24°C for 3 mins
Condition 4	Total compressor running time is 120 mins	T3-15°C
Condition 5	Total compressor running time is 120 mins	T3 or T4 ≤ -3°C

A210643

Fig. 27 —Defrost Chart

Defrost Exit Conditions: Any of the following conditions cancels the **DEFROST** mode and changes the unit's operating mode to normal **HEATING**:

NOTE: T3 temperature refers to the sensor reading at the time when the **DEFROST** mode begins.

- T3 temperature rises above 59°F (15°C).
- T3 temperature remains above 46°F (8°C) for more than 80 seconds.
- The unit has been in the **DEFROST** mode for 10 minutes.

The indoor unit defrost lamp illuminates and the **DEFROST** logo appears.

Evaporator Coil Temperature Protection




Fig. 28 —Evaporator Coil Temperature Protection

When the evaporator temperature is higher than the setting protection value, the compressor stops.

AUTO Mode

AUTO mode can be selected with the remote controller and the setting temperature can be changed between 60.0°F~86°F (16°C~30°C).

In the **AUTO** mode, the unit chooses either **COOLING**, **HEATING** or the **FAN-ONLY** mode accT2, T4 and relative humidity.




Fig. 29 —AUTO Mode

Heating*: **COOLING ONLY** models run at fan speed. The indoor fan runs in the **AUTO** fan speed for the relevant mode. The louver operates the same as in the relevant mode.

If the unit switches mode between **HEATING** and **COOLING**, the compressor repeatedly stops for a certain time and then chooses the mode according to T1-Ts. If the setting temperature is modified, the unit selects a running function again.

DRYING mode

The indoor fan speed is fixed at breeze and can not be changed. The louver angle is the same as in the **COOLING** mode.

Low Indoor Room Temperature Protection

In the **DRYING** mode, if the room temperature is lower than 50°F (10°C), the compressor stops and does not resume until the room temperature exceeds 53.6°F (12°C).

Evaporator anti-freezing protection, condenser high temperature protection and outdoor unit frequency limit are active and are the same as that in the **COOLING** mode. The outdoor fan operates the same as in **COOLING** mode.

FORCED OPERATION Function

Enter **FORCED OPERATION** function:

When the machine is off, press **TOUCH** to engage the **Forced Auto Mode**. Press **TOUCH** again, within 5 seconds, to engage the **FORCED COOLING** mode. In **FORCED AUTO**, **FORCED COOLING** or any other operation mode, press **TOUCH** to turn off the unit.

In the **FORCED OPERATION** mode, all general protections and the remote controller are available.

Operation Rules:

FORCED COOLING mode:

The compressor runs at the F2 frequency and the indoor fan runs as a breeze. After running for 30 minutes, the unit enters the **AUTO** mode at a 75.2°F (24°C) setting temperature.

FORCED AUTO mode:

The **FORCED AUTO** mode is the same as the normal **AUTO** mode with a 75.2°F (24°C) setting temperature.

AUTO-RESTART function

The indoor unit is equipped with an **AUTO-RESTART** function, which is carried out through an auto-restart module. In case of a sudden power failure, the module memorizes the setting conditions before the power failure. The unit resumes the previous operation setting (not including the swing function) automatically 3 minutes after the power returns.

If the memorization condition is the **FORCED COOLING** mode, the unit runs in the **COOLING** mode for 30 minutes and enters the **AUTO** mode as 75.2°F (24°C) setting temp.

If the air conditioner turns off before the unit powers off and the air conditioner is required to restart immediately, the compressor delays for 1 minute when the power is on. Under other conditions, the compressor has a 3 minute delay when it restarts.

Refrigerant Leakage Detection

With this new technology, the display area displays **EC** when the outdoor unit detects a refrigerant leak.

46°F (8°C) Heating

When the compressor is running, the indoor fan motor runs without the anti-cold air function. When the compressor is off, the indoor fan motor is off.

Point Check Function

Press the remote controller **LED** three times, and then press **SWING** three times within ten seconds (the buzzer rings for two seconds). The air conditioner enters the information enquiry status.

Press **LED** or **SWING** to check the next or previous code in the sequence, respectively. When the air conditioner enters the information enquiry status, it displays the code name for 2 seconds. When the air conditioner enters the information enquiry status, it displays the code value in the next 25 seconds.

Table 10 — Enquiry Information


Displayed Code	Explanation	Displayed Value	Meaning	Additional Notes
T1	Room temperature			
T2	Indoor coil temperature			
T3	Outdoor coil temperature			
T4	Ambient temperature			
Tb	Outlet temperature of indoor coil			
T5	Discharge temperature			
FT	Targeted frequency			
Fr	Actual frequency			
IF	Indoor fan speed	0 1,2,3,4	OFF, Low speed, Medium speed, High speed, Turbo. Actual fan speed is equal to the display value converted to the decimal value and multiplied by 10. This is measured in RPM.	N/A - Used for some large capacity motors. Used for some small capacity motors. The display value is 14-FF (hexadecimal). The corresponding fan speed ranges from 200 to 2550RPM.
OF	Outdoor fan speed	14-FF		
LA	EXV opening angle	0-FF	Actual EXV opening value is equal to the display value converted to decimal value and then multiplied by 2.	-
CT	Compressor continuous running time	0-FF	0-255 minutes	If the actual value exceeds or falls short of the defined range, the value closest to the maximum and minimum is displayed.
ST	Causes of compressor stop	0-99	For a detailed explanation, contact technical support.	-
Displayed Code	Explanation	Displayed Value	Meaning	Additional Notes
A0	Reserved			
A1				
b0				
b1				
b2				
b3				
b4				
b5				
bb				
dL				
Ac				
Ub				
Td				
dA				
d5				
dT				

TROUBLESHOOTING

Safety

Electricity power is kept in capacitors even if the power supply is shut off.


NOTE: Remember to discharge the electricity power in capacitor.



A210482

Fig. 30 —Electrolytic Capacitors

For other models, connect the discharge resistance (approximately 100Ω 40W) or a soldering iron (plug) between the +, - terminals of the electrolytic capacitor on the contrary side of the outdoor PCB.



A210484

Fig. 31 —Discharge Position

NOTE: Figure 31 is for reference only. The plug on your unit may differ.

Outdoor Unit Diagnostic Guide

Table 11 — Outdoor Unit Diagnostic Guide

Operation Lamp	Timer Lamp	Display	LED Status
⌚1 time	OFF	E0	Indoor unit EEPROM parameter error
⌚2 times	OFF	E1	Indoor / outdoor unit communication error
⌚3 times	OFF	E2	Zero-crossing signal detection error (for some models)
⌚4 times	OFF	E3	The indoor fan speed is operating outside of the normal range
⌚5 times	OFF	E4	Indoor room temperature sensor T1 is in open circuit or has short circuited
⌚6 times	OFF	E5	Evaporator coil temperature sensor T2 is in open circuit or has short circuited
⌚9 times	OFF	E7/EH 0b	Indoor PCB / Display board communication error (for some models)
⌚7 times	OFF	EC	Refrigerant leak detected
⌚1 time	ON	F0	Current overload protection
⌚2 times	ON	F1	Outdoor room temperature sensor T4 is in open circuit or has short circuited
⌚3 times	ON	F2	Condenser coil temperature sensor T3 is in open circuit or has short circuited
⌚4 times	ON	F3	Compressor discharge temperature sensor TP is in open circuit or has short circuited
⌚7 times	ON	F6	Evaporator coil outlet temperature sensor T2B is in open circuit or has short circuited (for free-match indoor units)
⌚5 times	ON	F4	Outdoor unit EEPROM parameter error
⌚6 times	ON	F5	The outdoor fan speed is operating outside of the normal range (for some models)
⌚1 time	FLASH	P0	IPM malfunction or IGBT over-strong current protection
⌚2 times	FLASH	P1	Over voltage or over low voltage protection
⌚3 times	FLASH	P2	High temperature protection of IPM module or High pressure protection
⌚5 times	FLASH	P4	Inverter compressor drive error
⌚7 times	FLASH	P6	Low pressure protection (some models)
⌚6 times	FLASH	P5/--	Indoor units mode conflict (match with multi outdoor unit)

O (light) X (off) ⌚ (flash)

PCB DIAGRAMS (HEAT PUMP)




Fig. 32 —Size 12K (115V)

A210485





Fig. 33.—Sizes 09-12K (208/230V)

A210486

PCB DIAGRAMS (CONT)



A210491

Fig. 34 — Sizes 18-24K (208/230V)


NOTE: After powering the unit on, LED3(Green color) and LED2(Red color) flashes if the unit experiences an issue.

Table 12 — LED Codes

No.	Problems	LED3 (Green)	LED2 (Red)	IU display
1	standby for normal	○	×	
2	Operation normally	×	○	
3	IPM malfunction or IGBT over-strong current protection	★	×	P0
4	Over voltage or too low voltage protection	○	○	P1
5	EEPROM parameter error	○	★	E5
6	Inverter compressor drive error	×	★	P4
7	Inverter compressor drive error	★	○	P4
8	Inverter compressor drive error	★	★	P4

○ (light) X (off) ★(flash)

PCB DIAGRAMS (COOLING ONLY)




A210593

Fig. 35 — Sizes 12K (115V) and 18K (208/230V)

Table 13 — LED Codes

No.	Name	CN#	Meaning
1	CN1A	CN3	Earth: connect to Ground
		CN1	N_in: connect to N-line (208-230V AC input)
		CN2	L_in: connect to L-line (208-230V AC input)
		CN1b	S: connect to indoor unit communication
2	HEAT1	CN17	Connect to compressor heater, 208-230V AC when is ON
3	4-WAY	CN60	Connect to 4 way valve, 208-230V AC when is ON.
4	HEAT2	CN15	Connect to chassis heater, 208-230V AC when is ON
5	AC-FAN	CN25	Connect to AC fan
6	PMV	CN31	Connect to Electric Expansion Valve
7	TESTPORT	CN6	Used for testing
8	TP T4 T3	CN21/CN22	Connect to pipe temp. sensor T3, ambient temp. sensor T4, exhaust temp. sensor TP
9	DC-FAN	CN7	Connect to DC fan
10	FAN_IPM	IPM 501	IPM for DC fan
11	W	CN28	Connect to compressor
	V	CN29	0V AC (standby)
	U	CN30	10-200V AC (running)
12	COMP_IPM	IPM 301	IPM for compressor

PCB DIAGRAMS (COOLING ONLY) (CONT)



A210594

Fig. 36 —Size 12K (208/230V)

Table 14 — LED Codes

No.	Name	CN#	Meaning
1	Power Supply	CN3	Earth: connect to Ground
		CN1	N_in: connect to N-line (100-130V AC input)
		CN2	L_in: connect to L-line (100-130V AC input)
2	S	CN16	S: connect to indoor unit communication
3	4-WAY	CN60	Connect to 4 way valve, 100-130V AC when is ON.
4	HEAT1	CN17	Connect to compressor heater, 100-130V AC when is ON
5	HEAT2	CN15	Connect to chassis heater, 100-130V AC when is ON
6	AC-FAN	CN25	Connect to AC fan
7	TESTPORT	CN6	Used for testing
8	TP T4 T3	CN21	Connect to pipe temp. sensor T3, ambient temp. sensor T4, exhaust temp. sensor TP
9	DC-FAN	CN7	Connect to DC fan
10	PMV	CN31	Connect to Electric Expansion Valve
11	FAN_IPM	IPM_501	IPM for DC fan
12	W	CN28	Connect to compressor
	V	CN29	0V AC (standby)
	U	CN30	10-230V AC (running)
13	COMP_IPM	IPM_1	IPM for compressor
14	BR1	BR1	Bridge
15	CN4	CN4_2	Connect to reactor
		CN4_3	

PCB DIAGRAMS (COOLING ONLY) (CONT)




Fig. 37 —Size 24K (208/230V)

Table 15 — LED Codes

No.	Name	CN#	Meaning
1	Power Supply	CN6	Earth: connect to Ground
		CN7	N_in: connect to N-line (208-230V AC input)
		CN8	L_in: connect to L-line (208-230V AC input)
2	S	CN2	S: connect to indoor unit communication
3	4-WAY	CN60	Connect to 4 way valve, 208-230V AC when is ON.
4	AC-FAN	CN5	Connect to AC fan
5	HEAT2	CN19	Connect to chassis heater, 208-230V AC when is ON
6	TP T4 T3	CN17	Connect to pipe temp. sensor T3, ambient temp. sensor T4, exhaust temp. sensor TP
7	PMV	CN18	Connect to Electric Expansion Valve
8	HEAT1	CN16	Connect to compressor heater, 208-230V AC when is ON
9	DC-FAN	CN414	Connect to DC fan
10	TESTPORT	CN23	Used for testing
11	FAN_IPM	IPM501	IPM for DC fan
12	COMP_IPM	IPM1	IPM for compressor
13	U	CN27	Connect to compressor
		CN28	0V AC (standby)
		CN29	200-300V AC (running)
14	EE_PORT	CN505	EEPROM programmer port

DIAGNOSIS AND SOLUTION


EEPROM Parameter Error (E0/F4)

Description: Indoor or outdoor PCB main chip does not receive feedback from the EEPROM chip.

Possible causes:

- Installation mistake
- Faulty PCB

Troubleshooting



A210492


Remarks:

A read-only memory whose contents can be erased and reprogrammed using a pulsed voltage. For the EEPROM chip location, refer to Figures 38 and 39.



A210512

Fig. 38 —Indoor PCB



A210513

Fig. 39 —Outdoor PCB

NOTE: Figures 38 and 39 are for reference only and they may differ from the actual unit.

DIAGNOSIS AND SOLUTION (CONT)


Indoor and Outdoor Unit Communication Error (E1)

Description: The indoor/outdoor unit communication

Possible causes:


- Wiring mistake
- Faulty Indoor or outdoor PCB

Troubleshooting



For certain models, outdoor PCB could not be removed separately. In this case, the outdoor electric control box should be replaced as a whole.

DIAGNOSIS AND SOLUTION (CONT)



A210524

Fig. 40 —Test the DC Voltage

Use a multimeter to test the DC voltage between the outdoor unit's L2 port and S port. The red pin of the multimeter connects with the L2 port while the black pin is for the S port. When the air conditioner is running normal, the voltage moves alternately between -50V to 50V. If the outdoor unit malfunctions, the voltage moves alternately with positive value. If the indoor unit malfunctions, the voltage has a certain value.



A210525

Fig. 41 —Test the Reactor Resistance

Use a multimeter to test the resistance of the reactor which does not connect with the capacitor. The normal value should be around zero (0) ohm. Otherwise, the reactor has a malfunction and needs to be replaced.

DIAGNOSIS AND SOLUTION (CONT)


Zero Crossing Detection Error Diagnosis and Solution (E2)

Description: When the PCB does not receive a zero crossing signal feedback for 4 minutes or the zero crossing signal time interval is abnormal.

Possible causes:

- Connection mistake
- Faulty PCB

Troubleshooting



A210597

DIAGNOSIS AND SOLUTION (CONT)


The indoor fan speed is operating outside of the normal range (E3/F5)

Description: When the indoor fan speed remains too slow (below 300 RPM) for an extended period of time, the LED displays a failure code and the unit turns off.

Possible causes:

- Wiring mistake
- Faulty fan assembly
- Faulty PCB

Troubleshooting




A210598

DIAGNOSIS AND SOLUTION (CONT)

Index 1

1. Indoor or Outdoor DC Fan Motor (control chip is in fan motor)

Power on and when the unit is in standby mode, measure the pin1-pin3 and pin4-pin3 voltage in the fan motor connector. If the voltage value is not in the range shown in Table 16, the PCB is faulty and must be replaced.



A210526

Fig. 42 — Motor Connector

Table 16 — DC motor voltage input and output (voltage: 220-240V~)

No.	Color	Signal	Voltage
1	Red	V _s /V _m	280V~380V
2	---	---	---
3	Black	GND	0V
4	White	V _{cc}	14~17.5V
5	Yellow	V _{sp}	0~5.6V
6	Blue	FG	14~17.5V

Table 17 — DC motor voltage input and output (voltage: 115V~):

No.	Color	Signal	Voltage
1	Red	V _s /V _m	140V~190V
2	---	---	---
3	Black	GND	0V
4	White	V _{cc}	14~17.5V
5	Yellow	V _{sp}	0~5.8V
6	Blue	FG	14~17.5V

2. Outdoor DC Fan Motor (control chip is in the outdoor PCB)

Power on the unit and check if the fan runs normally. If the fan runs normally, the PCB is faulty and needs to be replaced. If the fan does not run normally, measure the resistance of the two pins. If the resistance is not equal to each other, the fan motor is faulty and needs to be replaced, otherwise the PCB is faulty and needs to be replaced.

3. Indoor AC Fan Motor

Power on the unit and set the unit to the **FAN** mode at the high fan speed. Run for 15 seconds then measure the voltage of pin1 and pin2. If the voltage value is less than 100V(208~240V power supply) or 50V(115V power supply), the PCB is faulty and needs to be replaced.

DIAGNOSIS AND SOLUTION (CONT)


Open circuit or short circuit of temperature sensor diagnosis and solution (E4/E5/F1/F2/F3)

Description: If the sampling voltage is lower than 0.06V or higher than 4.94V, the LED displays the failure.

Possible causes:

- Wiring mistake
- Faulty sensor
- Faulty PCB

Troubleshooting



A210599



A210527

Fig. 43 —Check the Connection

DIAGNOSIS AND SOLUTION (CONT)


Indoor PCB / Display board communication error diagnosis and solution (E7/EH 0b)

Description: Indoor PCB does not receive feedback from the display board.

Possible causes:

- Communication wire
- Indoor PCB
- Display Board

Troubleshooting



A210600

DIAGNOSIS AND SOLUTION (CONT)


Refrigerant Leakage Detection diagnosis and solution (EC)

Description: Define the evaporator coil temp.T2 of the compressor. The compressor starts running in Tcool. At first, 5 minutes after the compressor starts up, if $T2 < Tcool - 35.6^{\circ}\text{F}$ ($Tcool - 2^{\circ}\text{C}$) does not run for 4 seconds and this situation occurs 3 times, the display area displays "EC" and the air conditioner turns off.

Possible causes:

- Faulty T2 sensor
- Faulty indoor PCB
- System problems, such as leaks or blockages

Troubleshooting



A210601

DIAGNOSIS AND SOLUTION (CONT)


Overload current protection diagnosis and solution (F0)

Description: An abnormal current rise is detected by checking the specified current detection circuit.

Possible causes:

- Power supply problems
- System blockage
- Faulty PCB
- Wiring mistake
- Compressor malfunction

Troubleshooting



A210602

DIAGNOSIS AND SOLUTION (CONT)


IPM malfunction or IGBT over-strong current protection diagnosis and solution (P0)

Description: When the voltage signal, that the IPM sends to the compressor drive chip is abnormal, the display LED displays “P0” and the air conditioner turns off.

Possible causes:


- Wiring mistake
- IPM malfunction
- Faulty outdoor fan assembly
- Compressor malfunction
- Faulty outdoor PCB

Troubleshooting




A210603

DIAGNOSIS AND SOLUTION (CONT)



A210514


Fig. 44 —P-U



A210515


Fig. 45 —P-V

DIAGNOSIS AND SOLUTION (CONT)



A210516


Fig. 46 —P- W



A210517

Fig. 47 —N-U

DIAGNOSIS AND SOLUTION (CONT)



A210518

Fig. 48 —N-V



A210519

Fig. 49 —N-W

DIAGNOSIS AND SOLUTION (CONT)


Over voltage or too low voltage protection diagnosis and solution (P1)

Description: An abnormal voltage rise or drop is detected by checking the specified voltage detection circuit.

Possible causes:

- Power supply problems
- System leak or block
- Faulty PCB


Troubleshooting



A210604

DIAGNOSIS AND SOLUTION (CONT)

Over voltage or too low voltage protection diagnosis and solution (P1) (Cont)



A210520

Fig. 50 —Test

NOTE: Measure the DC voltage between the P and N port. The normal value should be around 310V.

DIAGNOSIS AND SOLUTION (CONT)


High temperature protection of compressor top diagnosis and solution (P2)

Description: If the sampling voltage is not 5V, the LED displays the failure.

Possible causes:

- Power supply problems
- System leak or block
- Faulty PCB

Troubleshooting




A210605

DIAGNOSIS AND SOLUTION (CONT)

High temperature protection of compressor top diagnosis and solution (P2) (Cont)

For all other models (sizes):



A210606

DIAGNOSIS AND SOLUTION (CONT)


Inverter compressor drive error diagnosis and solution (P4)

Description: An abnormal inverter compressor drive is detected by a special detection circuit, including the communication signal detection, voltage detection, compressor rotation speed signal detection, etc.

Possible causes:

- Wiring mistake
- IPM malfunction
- Faulty outdoor fan assembly
- Compressor malfunction
- Faulty outdoor PCB

Troubleshooting



A210607

Main Parts Check

Temperature Sensor Checking

Disconnect the temperature sensor from the PCB, measure the resistance value with a tester.


Temperature sensors,
Room temp.(T1) sensor,
Indoor coil temp.(T2) sensor,
Outdoor coil temp.(T3) sensor,
Outdoor ambient temp.(T4) sensor,
Compressor discharge temp.(T5) sensor.

Measure the resistance value of each winding by using the multi-meter.

DIAGNOSIS AND SOLUTION (CONT)

Compressor Checking

Measure the resistance value of each winding by using the tester.



A210521

Fig. 51 —Tester

Table 18 — Compressor Checking (Heat Pump)

Position	Resistance Value - Heat Pump			
	ASN98D22UFZ	ASM135D23UFZ	ATF235D22UMT	ATF250D22UMT
Blue - Red				
Blue - Black	1.57 Ω	1.75 Ω	0.75 Ω	0.75 Ω
Red - Blue				

Table 19 — Compressor Checking (Cooling Only)

Position	Resistance Value - Heat Pump		
	KSK103D33UEZ3	KSN140D58UFZ	KTM240D43UKT
Blue - Red			
Blue - Black	2.13 Ω	1.86 Ω	1.03 Ω
Red - Blue			



A210522

Fig. 52 —Compressor Checking

DIAGNOSIS AND SOLUTION (CONT)

IPM Continuity Check

Turn the power off, let the large capacity electrolytic capacitors discharge completely, then dismount the IPM. Use a digital tester to measure the resistance between P and UVWN; UVW and N.

Table 20 — IPM Continuity Check

Digital Tester		Normal Resistance Value ∞ (Several MΩ)	Digital Tester		Normal Resistance Value	
(+)Red	(-)Black		(+)Red	(-)Black	N	
	N		U			
P	U		V			
	V		W			
	W		(+)Red			

Fan Motor

Measure the resistance value of each winding by using the tester.

Table 21 — Fan Motor

Model		YKT-32-6-202L	YKT-32-6-3L	YKT-48-6-206	YKT-63-6-200L
Brand		Tongde	Welling	Welling	Welling
Black – Red (Main)	Ω	86	213	152	88.5
Blue – Black (AUX)	Ω	64	156	142	138

Pressure on the Service Port

Table 22 — Cooling Chart

°F(°C)	ODU(DB) IDU(DB/WB)	0(-17)	5(-15)	15(-9.44)	45(7.22)	75(23.89)	85(29.44)	95 (35)	105(40.56)	115(46.11)	120(48.89)
BAR	70/59 (21.11/15)	6.4	6.5	7.3	8.0	8.2	7.8	8.1	8.6	10.1	10.6
	75/63 (23.89/17.22)	6.7	6.8	7.9	8.6	8.6	8.3	8.7	9.1	10.7	11.2
	80/67 (26.67/19.44)	7.1	7.2	8.5	9.5	9.3	8.9	9.1	9.6	11.2	11.9
	90/73 (32.22/22.78)	7.7	7.8	9.6	10.5	10.3	9.5	10.0	10.6	12.4	13.0
PSI	70/59 (21.11/15)	93	94	106	116	119	113	117	125	147	154
	75/63 (23.89/17.22)	97	99	115	125	124	120	126	132	155	162
	80/67 (26.67/19.44)	103	104	123	138	135	129	132	140	162	173
	90/73 (32.22/22.78)	112	113	139	152	149	138	145	154	180	189
MPa	70/59 (21.11/15)	0.64	0.65	0.73	0.8	0.82	0.78	0.81	0.86	1.01	1.06
	75/63 (23.89/17.22)	0.67	0.68	0.79	0.86	0.86	0.83	0.87	0.91	1.07	1.12
	80/67 (26.67/19.44)	0.71	0.72	0.85	0.95	0.93	0.89	0.91	0.96	1.12	1.19
	90/73 (32.22/22.78)	0.77	0.78	0.96	1.05	1.03	0.95	1	1.06	1.24	1.3





Fig. 53 — Cooling Chart

A210608

Pressure on the Service Port (Cont)

Table 23 — Heating Chart

$^{\circ}\text{F}(\text{C})$	ODU(DB/WB) IDU(DB)	57/53 (13.89/11.67)	47/43 (8.33/6.11)	37/33 (2.78/0.56)	27/23 (-2.78/-5)	17/13 (-8.33/-10.56)	0/-2 (-17/-19)	-17/-18 (-27/-28)
BAR	55(12.78)	30.3	28.5	25.3	22.8	20.8	18.5	16.5
	65(18.33)	32.5	30.0	26.6	25.4	23.3	20.5	19.0
	75(23.89)	33.8	31.5	27.8	26.3	24.9	21.5	20.0
PSI	55(12.78)	439	413	367	330	302	268	239
	65(18.33)	471	435	386	368	339	297	276
	75(23.89)	489	457	403	381	362	312	290
MPa	55(12.78)	3.03	2.85	2.53	2.28	2.08	1.85	1.65
	65(18.33)	3.25	3.00	2.66	2.54	2.33	2.05	1.90
	75(23.89)	3.38	3.15	2.78	2.63	2.49	2.15	2.00





A210610

Fig. 54 — Heating Chart

DISASSEMBLY INSTRUCTIONS

SIZES 9K (115V) - 18K (208/230V) - Heat Pump and 18K (208/230V) - Cooling Only

Procedure	Illustration
<ol style="list-style-type: none"> 1) Turn off the air conditioner and the power breaker. 2) Remove the handle screw (1) and then remove the handle. 	



A210523

Fig. 55 —Disassembly Instructions

NOTE: This section is for reference only. Actual unit appearance may vary.

DISASSEMBLY INSTRUCTIONS (CONT)

SIZES 9K - 18K (115V and 208/230V) - Heat Pump and 18K (208/230V) - Cooling Only (CONT)




Procedure	Illustration
4) Remove the water collecting cover screws (2) and then remove the water collecting cover.	
5) Remove the front panel screws (7) and then remove the front panel.	

Fig. 56 —Disassembly Instructions

A210528

DISASSEMBLY INSTRUCTIONS

SIZES 9K - 18K (115V and 208/230V) - Heat Pump and 18K (208/230V) - Cooling Only (CONT)



Procedure	Illustration
<p>6) Remove the right panel screws (5) and then remove the right panel.</p>	

A210529

Fig. 57 —Disassembly Instructions

DISASSEMBLY INSTRUCTIONS



Size 12K (115V and 208/230V) - Cooling Only

Procedure	Illustration
<ol style="list-style-type: none"> 1) Turn off the air conditioner and the power breaker. 2) Remove the handle screw (1) and then remove the handle. 	 <p>For US models (3 screws)</p>
<ol style="list-style-type: none"> 3) Remove the top cover screws (3) then remove the top cover. One of the screws is located under the handle. 	

A210614


DISASSEMBLY INSTRUCTIONS (CONT)

Size 12K (115V and 208/230V) - Cooling Only (CONT)

Procedure	Illustration
<p>4) Remove the water collecting cover screws (2) then remove the water collecting cover.</p>	
<p>5) Remove the front panel screws and then remove the front panel (6 screws(on/off models) or 8 screws(inverter models)).</p>	

A210615



DISASSEMBLY INSTRUCTIONS (CONT)**Size 12K (115V and 208/230V) - Cooling Only (CONT)**

Procedure	Illustration
6) Remove the right panel screws (5) then remove the right panel.	

A210616

DISASSEMBLY INSTRUCTIONS



SIZE 24K - Heat Pump and Cooling Only

Procedure	Illustration
<ol style="list-style-type: none"> 1) Turn off the air conditioner and the power breaker. 2) Remove the handle screw and then remove the handle. 	
<ol style="list-style-type: none"> 3) Remove the top cover screws (3) and then remove the top cover. One of the screws is located under the handle. 	

A210530


DISASSEMBLY INSTRUCTIONS (CONT)

SIZE 24K - Heat Pump and Cooling Only (CONT)

Procedure	Illustration
4) Remove the water collecting cover screws (2) and then remove the water collecting cover.	
5) Remove the front panel screws and then remove the front panel.	

A210531


DISASSEMBLY INSTRUCTIONS 24K (CONT)**SIZE 24K - Heat Pump and Cooling Only (CONT)**

Procedure	Illustration
6) Remove the right panel screws (6) and then remove the right panel.	

A210532

DISASSEMBLY INSTRUCTIONS (CONT)



Electrical Parts

Procedure	Illustration
<ol style="list-style-type: none"> 1) Remove the two screws secured to the electronic control board. 2) Disconnect the fan motor connectors (blue wire, yellow wire, red wire, brown wire and black wire). The blue wire and red wire are on the capacitor. The black wire connects with terminal 4. 3) Disconnect the wires connected to the compressor (black wire connects with terminal 1, blue and red wires connect with the compressor capacitor). 4) Disconnect the wires connected to the 4-way valve (blue wires on terminal 2 & 3). 5) Remove the compressor capacitor screw then pull it out. 6) Remove the electrical parts. 7) For models with an AC conductor, remove the screws (2). 	

A210617

DISASSEMBLY INSTRUCTIONS (CONT)



Electrical Parts (CONT)

Procedure	Illustration
8) For models with a subzero refrigeration control board, remove the 3 screws.	
9) The subzero refrigeration control board is in the back of the metal sheet.	

A210618

DISASSEMBLY INSTRUCTIONS (CONT)


Electrical Parts (CONT)

Procedure	Illustration
<ol style="list-style-type: none"> 1) Remove the compressor capacitor screw then pull it out. 2) Remove the transformer screws (2) then remove the transformer. 3) Remove the fan motor capacitor screws then remove it. 4) Remove the electronic install box screws (4) and then remove it. 	
<ol style="list-style-type: none"> 5) Remove the AC Contactor screws (2) then remove it. 	


A210619

DISASSEMBLY INSTRUCTIONS (CONT)

Electrical Parts (CONT)

Procedure	Illustration
<p>6) Disconnect the wires connected to the compressor (red wire connects with the PCB board, others connect with terminals).</p> <p>7) Disconnect the connectors for the fan motor (blue wire, red wire, brown wire and black wire). The blue and brown wires are on the capacitor. The black wire connects with a terminal and the red wire is on the board.)</p> <p>8) Disconnect the wires connected to the 4-way valve.</p> <p>9) Disconnect the wires connected to the transformer.</p> <p>10) Disconnect the other wires connected to terminals.</p> <p>11) Remove the PCB board.</p>	




A210620

Procedure	Illustration
<p>1) Disconnect the fan motor connectors.</p> <p>2) Disconnect the wires connected to the compressor.</p> <p>3) Disconnect the wires connected to pipe temperature sensor.</p> <p>4) Disconnect the ground wire.</p> <p>5) Remove the PCB board.</p>	

A210622

DISASSEMBLY INSTRUCTIONS (CONT)


Electrical Parts (CONT)

Procedure	Illustration
1) Remove the top cover screw (1).	
2) Loosen the hooks (5) then open the electronic control box cover.	
3) Disconnect the fan motor connector from the IPM board. 4) Remove the compressor connector.	

A210623

DISASSEMBLY INSTRUCTIONS (CONT)



Electrical Parts (CONT)

Procedure	Illustration
<p>5) Pull out the wire connected to the terminal.</p> <p>6) Pull out the condenser coil temperature sensor(T3),outdoor ambient temperature sensor(T4) and discharge temperature sensor(TP) connectors.</p> <p>7) Disconnect the electronic expansion valve wire.</p> <p>8) Remove the 4-way valve connector.</p> <p>9) Remove the reactor connector.</p> <p>10) Remove the electronic control box.</p>	

A210625



DISASSEMBLY INSTRUCTIONS (CONT)

Electrical Parts (CONT)

Procedure	Illustration
<ol style="list-style-type: none"> 1) Loosen the hooks (4) then open the electronic control box cover. 2) Disconnect the outdoor DC fan connector from the electronic control board. 3) Remove the compressor connector. 4) Pull out the two blue wires connected to the 4-way valve. 5) Pull out the condenser coil temperature sensor(T3),outdoor ambient temperature sensor(T4) and discharge temperature sensor(TP) compressor. 6) Disconnect the electronic expansion valve wire. 7) Disconnect the communication wire indoor PCB. 8) Disconnect the PFC inductor. 9) Remove the electronic control box. 	 

DISASSEMBLY INSTRUCTIONS (CONT)



Electrical Parts (CONT)

Procedure	Illustration
1) Loosen the hooks then open the electronic control box cover.	
2) Remove screws (4) on the electronic control board then turn over the the electronic control board.	

A210627

DISASSEMBLY INSTRUCTIONS (CONT)


Electrical Parts (CONT)

Procedure	Illustration
<p>3) Remove the connectors.</p> <p>4) Remove the screws (9) and loosen the 3 hooks then remove the electronic control board.</p>	
<p>5) Remove screws (2) then remove the electronic control box subassembly on the partition board assembly.</p>	

A210628

DISASSEMBLY INSTRUCTIONS (CONT)



Electrical Parts (CONT)

Procedure	Illustration
6) Remove the screws (2) and the two connectors then remove the inverter control board.	

A210629

DISASSEMBLY INSTRUCTIONS (CONT)


Electrical Parts (CONT)

Procedure	Illustration
1) Loosen the hooks (4) then open the electronic control box cover.	
2) Remove the screws (6) on the electronic control board then turn over the electronic control board.	

A210630

DISASSEMBLY INSTRUCTIONS (CONT)


Electrical Parts (CONT)

Procedure	Illustration
3) Remove the connectors. 4) Remove the screws (4) then remove the electronic control board.	


A210631

DISASSEMBLY INSTRUCTIONS (CONT)

Fan Assembly

Procedure	Illustration
<ol style="list-style-type: none"> 1) Remove the nut, securing the fan, with a spanner. 2) Remove the fan. 	


A210632

Procedure	Illustration
<ol style="list-style-type: none"> 3) Remove the fan motor screws (4). 4) Remove the fan motor. 	

A210633

DISASSEMBLY INSTRUCTIONS (CONT)


Sound Blanket

Procedure	Illustration
1) Remove the sound blanket (side and top).	 <p>Sound Blanket(top)</p> <p>Sound Blanket(side)</p>

A210634

DISASSEMBLY INSTRUCTIONS (CONT)



Four-Way Valve

Procedure	Illustration
<ol style="list-style-type: none"> 1) Heat up the brazed parts and then detach the the four-way valve and the pipe. 2) Use pliers. to remove the four-way valve assembly. 	

A210635

DISASSEMBLY INSTRUCTIONS (CONT)


Compressor

Procedure	Illustration
<p>1) Remove the terminal cover flange nut and remove the terminal cover.</p>	
<p>2) Disconnect the connectors.</p>	

A210636

DISASSEMBLY INSTRUCTIONS (CONT)

Compressor

Procedure	Illustration
<p>3) Remove the hex nuts and washers securing the compressor, located on the bottom plate.</p> <p>4) Heat up the brazed parts then remove the the discharge pipe and the suction pipe.</p> <p>5) Lift the compressor from the base pan assembly with pliers.</p>	

A210638

APPENDIX**Appendix 1****Table 24 — Temperature Sensor Resistance Value Table for T1, T2, T3, T4 (°C--K)**

°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm
- 20	-4	115.266	20	68	12.6431	60	140	2.35774	100	212	0.62973
- 19	-2	108.146	21	70	12.0561	61	142	2.27249	101	214	0.61148
- 18	0	101.517	22	72	11.5	62	144	2.19073	102	216	0.59386
- 17	1	96.3423	23	73	10.9731	63	145	2.11241	103	217	0.57683
- 16	3	89.5865	24	75	10.4736	64	147	2.03732	104	219	0.56038
- 15	5	84.219	25	77	10	65	149	1.96532	105	221	0.54448
- 14	7	79.311	26	79	9.55074	66	151	1.89627	106	223	0.52912
- 13	9	74.536	27	81	9.12445	67	153	1.83003	107	225	0.51426
- 12	10	70.1698	28	82	8.71983	68	154	1.76647	108	226	0.49989
- 11	12	66.0898	29	84	8.33566	69	156	1.70547	109	228	0.486
- 10	14	62.2756	30	86	7.97078	70	158	1.64691	110	230	0.47256
- 9	16	58.7079	31	88	7.62411	71	160	1.59068	111	232	0.45957
- 8	18	56.3694	32	90	7.29464	72	162	1.53668	112	234	0.44699
- 7	19	52.2438	33	91	6.98142	73	163	1.48481	113	235	0.43482
- 6	21	49.3161	34	93	6.68355	74	165	1.43498	114	237	0.42304
- 5	23	46.5725	35	95	6.40021	75	167	1.38703	115	239	0.41164
- 4	25	44	36	97	6.13059	76	169	1.34105	116	241	0.4006
- 3	27	41.5878	37	99	5.87359	77	171	1.29078	117	243	0.38991
- 2	28	39.8239	38	100	5.62961	78	172	1.25423	118	244	0.37956
- 1	30	37.1988	39	102	5.39689	79	174	1.2133	119	246	0.36954
0	32	35.2024	40	104	5.17519	80	176	1.17393	120	248	0.35982
1	34	33.3269	41	106	4.96392	81	178	1.13604	121	250	0.35042
2	36	31.5635	42	108	4.76253	82	180	1.09958	122	252	0.3413
3	37	29.9058	43	109	4.5705	83	181	1.06448	123	253	0.33246
4	39	28.3459	44	111	4.38736	84	183	1.03069	124	255	0.3239
5	41	26.8778	45	113	4.21263	85	185	0.99815	125	257	0.31559
6	43	25.4954	46	115	4.04589	86	187	0.96681	126	259	0.30754
7	45	24.1932	47	117	3.88673	87	189	0.93662	127	261	0.29974
8	46	22.5662	48	118	3.73476	88	190	0.90753	128	262	0.29216
9	48	21.8094	49	120	3.58962	89	192	0.8795	129	264	0.28482
10	50	20.7184	50	122	3.45097	90	194	0.85248	130	266	0.2777
11	52	19.6891	51	124	3.31847	91	196	0.82643	131	268	0.27078
12	54	18.7177	52	126	3.19183	92	198	0.80132	132	270	0.26408
13	55	17.8005	53	127	3.07075	93	199	0.77709	133	271	0.25757
14	57	16.9341	54	129	2.95896	94	201	0.75373	134	273	0.25125
15	59	16.1156	55	131	2.84421	95	203	0.73119	135	275	0.24512
16	61	15.3418	56	133	2.73823	96	205	0.70944	136	277	0.23916
17	63	14.6181	57	135	2.63682	97	207	0.68844	137	279	0.23338
18	64	13.918	58	136	2.53973	98	208	0.66818	138	280	0.22776
19	66	13.2631	59	138	2.44677	99	210	0.64862	139	282	0.22231

Appendix 2

Table 25 — Temperature Sensor Resistance Value Table for T5 (° C- -K)

°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm
-20	-4	542.7	20	68	68.66	60	140	13.59	100	212	3.702
-19	-2	511.9	21	70	65.62	61	142	13.11	101	214	3.595
-18	0	483	22	72	62.73	62	144	12.65	102	216	3.492
-17	1	455.9	23	73	59.98	63	145	12.21	103	217	3.392
-16	3	430.5	24	75	57.37	64	147	11.79	104	219	3.296
-15	5	406.7	25	77	54.89	65	149	11.38	105	221	3.203
-14	7	384.3	26	79	52.53	66	151	10.99	106	223	3.113
-13	9	363.3	27	81	50.28	67	153	10.61	107	225	3.025
-12	10	343.6	28	82	48.14	68	154	10.25	108	226	2.941
-11	12	325.1	29	84	46.11	69	156	9.902	109	228	2.86
-10	14	307.7	30	86	44.17	70	158	9.569	110	230	2.781
-9	16	291.3	31	88	42.33	71	160	9.248	111	232	2.704
-8	18	275.9	32	90	40.57	72	162	8.94	112	234	2.63
-7	19	261.4	33	91	38.89	73	163	8.643	113	235	2.559
-6	21	247.8	34	93	37.3	74	165	8.358	114	237	2.489
-5	23	234.9	35	95	35.78	75	167	8.084	115	239	2.422
-4	25	222.8	36	97	34.32	76	169	7.82	116	241	2.357
-3	27	211.4	37	99	32.94	77	171	7.566	117	243	2.294
-2	28	200.7	38	100	31.62	78	172	7.321	118	244	2.233
-1	30	190.5	39	102	30.36	79	174	7.086	119	246	2.174
0	32	180.9	40	104	29.15	80	176	6.859	120	248	2.117
1	34	171.9	41	106	28	81	178	6.641	121	250	2.061
2	36	163.3	42	108	26.9	82	180	6.43	122	252	2.007
3	37	155.2	43	109	25.86	83	181	6.228	123	253	1.955
4	39	147.6	44	111	24.85	84	183	6.033	124	255	1.905
5	41	140.4	45	113	23.89	85	185	5.844	125	257	1.856
6	43	133.5	46	115	22.89	86	187	5.663	126	259	1.808
7	45	127.1	47	117	22.1	87	189	5.488	127	261	1.762
8	46	121	48	118	21.26	88	190	5.32	128	262	1.717
9	48	115.2	49	120	20.46	89	192	5.157	129	264	1.674
10	50	109.8	50	122	19.69	90	194	5	130	266	1.632
11	52	104.6	51	124	18.96	91	196	4.849			
12	54	99.69	52	126	18.26	92	198	4.703			
13	55	95.05	53	127	17.58	93	199	4.562			
14	57	90.66	54	129	16.94	94	201	4.426			
15	59	86.49	55	131	16.32	95	203	4.294			
16	61	82.54	56	133	15.73	96	205	4.167			
17	63	78.79	57	135	15.16	97	207	4.045			
18	64	75.24	58	136	14.62	98	208	3.927			
19	66	71.86	59	138	14.09	99	210	3.812			

Appendix 3

Table 26 — Fahrenheit to Celsius Conversion

°C	°F	°C	°F	°C	°F	°C	°F	°C	°F
-5	23	21	69.8	51	123.8	82	179.6	113	235.4
-4	24.8	22	71.6	52	125.6	83	181.4	114	237.2
-3	26.6	23	73.4	53	127.4	84	183.2	115	239
-2	28.4	24	75.2	54	129.2	85	185	116	240.8
-1	30.2	25	77	55	131	86	186.8	117	242.6
0	32	25.5	77.9	56	132.8	87	188.6	118	244.4
0.5	32.9	26	78.8	57	134.6	88	190.4	119	246.2
1	33.8	27	80.6	58	136.4	89	192.2	120	248
1.5	34.7	28	82.4	59	138.2	90	194	121	249.8
2	35.6	29	84.2	60	140	91	195.8	122	251.6
2.5	36.5	30	86	61	141.8	92	197.6	123	253.4
3	37.4	31	87.8	62	143.6	93	199.4	124	255.2
3.5	38.3	32	89.6	63	145.4	94	201.2	125	257
4	39.2	33	91.4	64	147.2	95	203	126	258.8
4.5	40.1	34	93.2	65	149	96	204.8	127	260.6
5	41	35	95	66	150.8	97	206.6	128	262.4
6	42.8	36	96.8	67	152.6	98	208.4	129	264.2
7	44.6	37	98.6	68	154.4	99	210.2	130	266
8	46.4	38	100.4	69	156.2	100	212	131	267.8
9	48.2	39	102.2	70	158	101	213.8	132	269.6
10	50	40	104	71	159.8	102	215.6	133	271.4
11	51.8	41	105.8	72	161.6	103	217.4	134	273.2
12	53.6	42	107.6	73	163.4	104	219.2	135	275
13	55.4	43	109.4	74	165.2	105	221	136	276.8
14	57.2	44	111.2	75	167	106	222.8	137	278.6
15	59	45	113	76	168.8	107	224.6	138	280.4
16	60.8	46	114.8	77	170.6	108	226.4	139	282.2
17	62.6	47	116.6	78	172.4	109	228.2	140	284
18	64.4	48	118.4	79	174.2	110	230	141	285.8
19	66.2	49	120.2	80	176	111	231.8	142	287.6
20	68	50	122	81	177.8	112	233.6	143	289.4