

bryant

Day &
Night

PAYNE

installation, start-up and operating instructions.

UPFLOW CATEGORY I AND III INDUCED-COMBUSTION GAS FURNACE

370AAV Series A

Cancels: New

II 370A-60-1

4-15-94

NOTE: Read the entire instruction manual before starting the installation.

Index	Page
SAFETY CONSIDERATIONS	1
Clearances to Combustibles.....	1
INTRODUCTION	1-3
Dimensional Drawing.....	2
LOCATION	3
General.....	3
Location Relative to Cooling Equipment.....	3
Hazardous Locations.....	3
AIR FOR COMBUSTION AND VENTILATION	3-5
Unconfined Space.....	3
Confined Space.....	3-5
FILTER ARRANGEMENT	5
LEVELING LEGS	5
GAS PIPING	5-6
ELECTRICAL CONNECTIONS	6-7
115-v Wiring.....	6
24-v Wiring.....	6
Accessories.....	7
VENTING	7-9
General.....	7-8
High Temperature Plastic, Special Gas Vent Installation.....	8-9
START-UP, ADJUSTMENT, AND SAFETY CHECK	9-16
General.....	9
Sequence of Operation.....	9-10
Heating Mode.....	9-10
Cooling Mode.....	10
Continuous Blower Mode.....	10
Heat Pump Mode.....	10
Defrost Mode.....	10
Start-Up Procedures.....	10-12
Adjustments.....	12-15
Set Gas Input Rate.....	12-14
Set Temperature Rise.....	14-15
Set Thermostat Heat Anticipator.....	15
Check Safety Controls.....	15-16
Checklist.....	16

SAFETY CONSIDERATIONS

Installation and servicing of heating equipment can be hazardous due to gas and electrical components. Only trained and qualified personnel should install, repair, or service heating equipment.

Untrained personnel can perform basic maintenance functions such as cleaning and replacing air filters. All other operations must be performed by trained service personnel. When working on heating equipment, observe precautions in the literature, on tags, and on labels attached to or shipped with the unit and other safety precautions that may apply.

Follow all safety codes. In the United States, follow all safety codes including the National Fuel Gas Code (NFPA) NFPA No. 54-1992/ANSI Z223.1-1992. In Canada, refer to the current



edition of the National Standard of Canada CAN/CGA-B149.1 and 2-M91 Natural Gas and Propane Gas Installation Codes and Amendment No. 1 (NSCNGPIC). Wear safety glasses and work gloves. Have fire extinguisher available during start-up and adjustment procedures and service calls.

Recognize safety information. This is the safety-alert symbol Δ . When you see this symbol on the furnace and in instructions or manuals, be alert to the potential for personal injury.

Understand the signal word DANGER, WARNING, or CAUTION. These words are used with the safety-alert symbol. DANGER identifies the most serious hazards which will result in severe personal injury or death. WARNING signifies a hazard that could result in personal injury or death. CAUTION is used to identify unsafe practices which would result in minor personal injury or product and property damage.

These instructions cover minimum requirements and conform to existing national standards and safety codes. In some instances, these instructions exceed certain local codes and ordinances, especially those that may not have kept up with changing residential construction practices. We require these instructions as a minimum for a safe installation.

TABLE 1—MINIMUM CLEARANCES TO COMBUSTIBLE MATERIALS (IN.)

UNIT SIZE		60	80	100-120
Sides	Single-Wall Vent	1	0	0
	Type B-1 Double-Wall Vent	0	0	0
	Special Gas Vent†			
	Diameter	3	3	4
Back	Clearance	0	0	2*
	Plenum Top	1	1	1
	Single-Wall Vent	6	6	6
	Type B-1 Double-Wall Vent	1	1	1
Vent	Special Gas Vent†			
	Diameter	3	3	4
	Clearance	5	5	9
Front	Single-Wall Vent	6	6	6
	Type B-1 Double-Wall Vent	3	3	3
	Special Gas Vent†			
	Diameter	3	3	4
	Clearance	5	5	9

* May be 0 for furnaces 24-in. wide.


† Listed for Category III appliances per UL 173B (high temperature plastic pipe rated for 480°F).

NOTES:

1. Provide 30-in. front clearance for servicing. An open door in front of the furnace can meet this requirement.
2. A minimum clearance of 3 in. must be provided in front of the furnace for combustion air and proper operation.

INTRODUCTION

The Model 370AAV Series A Furnace is available in sizes 60,000 through 120,000 Btuh input capacities.



NOTE: 2 ADDITIONAL 7/8 DIA KNOCKOUTS ARE LOCATED IN THE TOP PLATE.

NOTE: AIR DELIVERY ABOVE 1800 CFM REQUIRES THAT BOTH SIDES OF FURNACE BE USED, OR A COMBINATION OF 1 SIDE AND BOTTOM, OR BOTTOM ONLY FOR RETURN AIR.

A88367

Fig. 1—Dimensional Drawing
TABLE 2—DIMENSIONS (IN.)

UNIT SIZE	A	D	E	VENT CONN	SHIP. WT
024060	14-3/16	12-9/16	12-11/16	4	132
036060	14-3/16	12-9/16	12-11/16	4	134
042080	17-1/2	15-7/8	16	4	150
048080	21	19-3/8	19-1/2	4	154
036100	17-1/2	15-7/8	16	4	160
048100	21	19-3/8	19-1/2	4	166
060100	24-1/2	22-7/8	23	4	184
060120	24-1/2	22-7/8	23	5	194

The design of the upflow gas-fired furnace is A.G.A./C.G.A. certified for use with natural and propane gases and for installation on combustible flooring, in alcoves, attics, basements, closets, or utility rooms. The design of this furnace line is not A.G.A./C.G.A. certified for installation in mobile homes, recreation vehicles, or outdoors.

Before installing the furnace, refer to the current edition of the NFPA Canadian installations must be installed in accordance with NSCNGPIC and all authorities having jurisdiction. For further information, the NFPA is available from National Fire Protection Association Inc., Batterymarch Park, Quincy, MA 02269, American Gas Association, 1515 Wilson Boulevard, Arlington, VA 22209, or from Literature Distribution.

Installation must conform to the regulations of the serving gas supplier and the local building, heating, and plumbing codes in effect in the area in which the installation is made or, in the absence of local codes, with the requirements of the NFPA.

CAUTION: Application of this furnace should be indoors with special attention given to vent sizing and material, gas input rate, air temperature rise, and unit sizing. Improper installation or misapplication of the furnace can require excessive servicing or cause premature component failure.

This furnace is designed for a minimum continuous return-air temperature of 60°F db or intermittent operation down to 55°F db such as when used with a night setback thermostat. Return-air temperature must not exceed 85°F db.

To aid in installation, troubleshooting, and service, a status code label is located on the blower compartment door. This label explains how to use the LED status indicator on the furnace control which is viewed through the sight glass on the door.

WARNING: Improper installation, adjustment, alteration, service, maintenance, or use can cause carbon monoxide poisoning, explosion, fire, electrical shock, or other conditions which may cause personal injury or property damage. Consult a qualified installer, service agency, local gas supplier, or your distributor or branch for information or assistance. The qualified installer or agency must use only factory-authorized and listed kits or accessories when modifying this product. A failure to follow this warning can cause electrical shock, fire, personal injury, or death.

For high-altitude installations, the high-altitude conversion kit **MUST** be installed for conventional Category I (negative pressure) vertical vents at or above 5500 ft above sea level. For Category III (positive pressure) vertical or horizontal high temperature plastic Special Gas Vents, the kit must be installed at or above altitudes of 4000 ft above sea level.

For accessory installation details, refer to the applicable installation literature.

NOTE: Remove all shipping brackets and materials before operating the furnace.

I. LOCATION

A. General



CAUTION: Do not install furnace in a corrosive or contaminated atmosphere. Make sure all combustion and circulating air requirements are met, in addition to all local codes and ordinances.



CAUTION: Do not use this furnace during construction when adhesives, sealers, and/or new carpets are being installed. If the furnace is required during construction, use clean outside air for combustion and ventilation. Compounds of chlorine and fluorine, when burned in combustion air, form acids which will cause corrosion of the heat exchangers and metal vent systems. Some of these compounds are released from paneling and dry wall adhesives, paints, thinners, masonry cleaning materials, and many other solvents commonly used in the construction process.

This furnace must be installed so the electrical components are protected from water.

Locate the furnace as near the center of the air distribution system as possible. The furnace should be installed as level as possible.

When a furnace is installed so that the supply ducts carry air to areas outside the space containing the furnace, the return air must also be handled by a duct(s) sealed to the furnace casing and terminating outside the space containing the furnace.

When venting vertically with Category I vent materials, locate furnace close to the chimney or vent.

Provide ample space for servicing and cleaning. Always comply with the minimum fire protection clearances shown on the unit clearance label. This furnace shall not be installed directly on carpeting, tile, or any combustible material other than wood flooring.

B. Location Relative to Cooling Equipment

The cooling coil must be installed parallel with or on the downstream side of the furnace to avoid condensation in the heat exchangers. When installed parallel with a furnace, dampers or other means used to control the flow of air must prevent chilled air from entering the furnace. If the dampers are manually operated, they must be equipped with means to prevent operation of either unit unless the damper is in the full-heat or full-cool position.

C. Hazardous Locations

When the furnace is installed in a residential garage, it must be installed so that the burners and ignition source are located at least 18 in. above the floor. The furnace should be protected from physical damage by vehicles. When a furnace is installed in public garages, airplane hangars, or other buildings having hazardous atmospheres, the unit must be installed in accordance with the recommended good practice requirements of the National Fire Protection Association, Inc.

II. AIR FOR COMBUSTION AND VENTILATION

Provisions for adequate combustion and ventilation air must be provided in accordance with Section 5.3, Air for Combustion and Ventilation, of the NFPA or applicable provisions of the local building codes.

Canadian installations must be in accordance with NSCPGIC and all authorities having jurisdiction.



CAUTION: Air for combustion must not be contaminated by halogen compounds, which include fluoride, chloride, bromide, and iodide. These elements are found in aerosol sprays, detergents, bleaches, cleaning solvents, salts, air fresheners, and other household products.

All fuel-burning equipment must be supplied with air for combustion of the fuel. Sufficient air **MUST** be provided to ensure there will not be a negative pressure in the equipment room or space. In addition, a positive seal **MUST** be made between the furnace cabinet and the return-air duct to prevent pulling air from the burner area and draft safeguard opening.



CAUTION: The operation of exhaust fans, kitchen ventilation fans, clothes dryers, or fireplaces could create a negative air pressure condition at the furnace. Make-up air must be provided for the ventilation devices, in addition to that required by the furnace.

Combustion air requirements are determined by whether the furnace is in an UNCONFINED or CONFINED space.

A. Unconfined Space

An unconfined space must have at least 50 cu ft for each 1000 Btuh of input for all the appliances (such as furnaces, clothes dryer, water heaters, etc.) in the space.

For Example:

370AAV FURNACE HIGH-FIRE INPUT BTUH	MINIMUM SQ FT WITH 7'-1/2 FT CEILING
60,000	400
80,000	534
100,000	667
120,000	800

If the unconfined space is of unusually tight construction, air for combustion and ventilation **MUST** come from either the outdoors or spaces freely communicating with the outdoors. Combustion and ventilation openings must be sized the same as for a confined space as defined below. Return air must not be taken from the room unless an equal or greater amount of air is supplied to the room.


B. Confined Space

A confined space is one whose volume is less than 50 cu ft per 1000 Btuh of the total input rating for all appliances installed in that space. A confined space **MUST** have 2 permanent openings, 1 within 12 in. of the ceiling, and the other within 12 in. of the floor. (See Fig. 2.)

NOTE: In determining the free area of an opening, the blocking effect of the louvers, grilles, and screens must be considered. If the free area of a louver or grille design is unknown, it may be assumed that wood louvers have a 20 percent free area, and metal louvers or grilles have a 60 percent free area. Screens, when used, must not be smaller than 1/4-in. mesh. Louvers and grilles must be constructed so they cannot be closed.

The size of the openings depends upon whether the air comes from inside or outside of the structure.

1. All air from inside the structure:



* Minimum opening size is 100 square in. with minimum dimensions of 3 in.

† Minimum of 3 in. when type-B1 vent is used.

Fig. 2—Air for Combustion and Ventilation (Inside Air)

- a. Each opening **MUST** have at least 1 sq in. of free area per 1000 Btuh of the total input for all equipment within the confined space, but not less than 100 sq in. per opening. (See Fig. 2.) The minimum dimension of air openings shall be not less than 3 in.

For Example:


370AAV FURNACE HIGH-FIRE INPUT BTUH	FREE AREA PER OPENING (SQ IN.)
60,000	100
80,000	100
100,000	100
120,000	120

- b. If the building is constructed unusually tight, a permanent opening directly communicating with the outdoors should be provided. This opening shall have a minimum free area of 1 sq in. per 5000 Btuh of total input rating for all equipment in the enclosure.

- c. If the furnace is installed on a raised platform to provide a return-air plenum, and return air is taken directly from the hallway or space adjacent to the furnace, all air for combustion must come from outdoors.

2. All air from outside the structure:

- a. If combustion air is taken from outdoors through vertical ducts, the openings and ducts **MUST** have at least 1 sq in. of free area per 4000 Btuh of the total input for all equipment within the confined space. (See Fig. 3.)



USE ANY OF THE FOLLOWING
COMBINATIONS OF OPENINGS:
A & B C & D D & E

Fig. 3—Air for Combustion and Ventilation (Outside Air)

For Example:

370AAV FURNACE HIGH-FIRE INPUT BTUH	FREE AREA PER OPENING (SQ IN.)	ROUND PIPE (IN. DIA)
60,000	15.0	5
80,000	20.0	6
100,000	25.0	6
120,000	30.0	7

- b. If combustion air is taken from the outdoors through horizontal ducts, the openings and ducts **MUST** have at least 1 sq in. of free area per 2000 Btuh of the total input for all equipment within the confined space. (See Fig. 3.)

For Example:

370AAV FURNACE HIGH-FIRE INPUT BTUH	FREE AREA PER OPENING (SQ IN.)	ROUND PIPE (IN. DIA)
60,000	30.0	7
80,000	40.0	8
100,000	50.0	8
120,000	60.0	9

When ducts are used, they must be of the same cross-sectional area as the free area of the openings to which they connect. The minimum dimension of rectangular ducts must not be less than 3 in. (See Fig. 3.)

WARNING: Do not install the furnace on its back or sides. Safety control operation will be adversely affected. Never connect return-air ducts to the back of the furnace. A failure to follow this warning can cause a fire, personal injury, or death.

III. FILTER ARRANGEMENT

A field-supplied air filter(s) must be provided in the installation of this furnace. Proper filter sizes for each furnace casing width are shown in Table 3. Filters must be suitable and rated for 600 ft/minute of face velocity. Framed filters of this type are available as accessory items in all sizes. Filters must be installed in a field-supplied external or internal filter rack that provides for routine filter removal and cleaning. See Fig. 4 for bottom return applications.

A bottom closure panel is factory installed in the bottom of the furnaces. When bottom return inlet is desired, remove and discard the enclosure panel.

NOTE: Furnaces with a 17-1/2 in. wide casing require an additional procedure when locating the filter for bottom return-air application. Field-fabricate a sheet metal filler strip 1 X 3 X 24-1/2 in. and install it along side of the filter as shown in Fig. 4. Drive 2 screws through the casing-side and into the filler strip to secure it in place. Filter is to rest on top of the filler strip when installed.

TABLE 3—FILTER INFORMATION (IN.)

FURNACE CASING WIDTH	FILTER SIZE	
	Side Return	Bottom Return
14-3/16	(1) 16 X 25 X 1	(1) 14 X 25 X 1
17-1/2	(1) 16 X 25 X 1	(1) 16 X 25 X 1
21	(1) 16 X 25 X 1	(1) 20 X 25 X 1
24-1/2	(2) 16 X 25 X 1	(1) 24 X 25 X 1

WARNING: Never operate unit without a filter or with filter access door removed. A failure to follow this warning can cause a fire, personal injury, or death.

IV. LEVELING LEGS (IF REQUIRED)

When the furnace is used with side inlet(s) and leveling legs are required, refer to Fig. 5 and install field-supplied, corrosion-resistant 5/16-in. machine bolts and nuts.


NOTE: The length of the bolt should not exceed 1-1/2 in.

1. Lay furnace on its back. Locate and drill 5/16-in. diameter hole in each bottom corner of furnace as shown in Fig. 5.
2. Install nut on bolt and install bolt and nut in hole. (Install flat washer if desired.)
3. Install another nut on other side of furnace base. (Install flat washer if desired.)
4. Adjust outside nut to provide desired height and tighten inside nut to secure arrangement.

V. GAS PIPING

Gas piping must be installed in accordance with national and local codes. Refer to the current edition of the NFGC. Canadian installations must be installed in accordance with NSCNGPIC and all authorities having jurisdiction.

The gas supply line should be a separate line running directly from the gas meter to the furnace, if possible. Refer to Table 4 for the recommended gas pipe size. Risers must be used to connect to the furnace and the meter.



FIELD-SUPPLIED
FILTER SUPPORT
FOR 17-1/2 IN.
WIDE CASINGS
ONLY




Fig. 4—Bottom Filter Arrangement

A94124




Fig. 5—Leveling Leg Installation

A89014

CAUTION: If a flexible connector is required or allowed by the authority having jurisdiction, black iron pipe shall be installed at the gas valve and extend a minimum of 2 in. outside the furnace casing.


TABLE 4—MAXIMUM CAPACITY OF PIPE*

NOMINAL IRON PIPE SIZE (IN.)	INTERNAL DIAMETER (IN.)	LENGTH OF PIPE (FT)				
		10	20	30	40	50
1/2	0.622	175	120	97	82	73
3/4	0.824	360	250	200	170	151
1	1.049	680	465	375	320	285
1-1/4	1.380	1400	950	770	660	580
1-1/2	1.610	2100	1460	1180	990	900

* Cubic ft. of gas per hr. for gas pressures of 0.5 psig (14-in. wc) or less, and a pressure drop of 0.5-in. wc (based on a 0.60 specific gravity gas). Ref. Table C-4, NFPA 54-1992.

Piping should be pressure tested in accordance with local and national plumbing and gas codes before the furnace has been attached. If the test pressure exceeds 0.5 psig (14-in. wc), the gas supply pipe must be disconnected from the furnace and capped before the pressure test. If the test pressure is equal to or less than 0.5 psig (14-in. wc), close the manual shut-off valve located on the gas valve before the test. It is recommended that the ground joint union be loosened before pressure testing. After all connections have been made, purge the lines and check for leakage with regulated gas supply pressure.

Install a sediment trap in the riser leading to the furnace. The trap can be installed by connecting a tee to the riser leading from the furnace. Connect a capped nipple into the lower end of the tee. The capped nipple should extend below the level of the gas controls. (See Fig. 6.)



A89417

Fig. 6—Typical Gas Pipe Arrangement

Apply joint compound (pipe dope) sparingly and only to the male threads of each joint. The compound must be resistant to the action of propane gas.

Install an accessible manual shut-off valve upstream of the furnace gas controls and within 72 in. of the furnace. A 1/8-in. NPT plugged tapping, accessible for test gage connection, must be installed immediately upstream of the gas supply connection to the furnace and downstream of the manual shut-off valve. Place ground joint union between the gas control manifold and the manual shut-off valve.

WARNING: Use the proper length of pipes to avoid stress on the gas control manifold. A failure to follow this warning can cause a gas leak resulting in a fire, explosion, personal injury, or death.

CAUTION: Use a backup wrench at the furnace gas control when connecting the gas pipe to the furnace to avoid damaging gas controls or manifold.

WARNING: Never purge a line into a combustion chamber. Never use matches, candles, flame, or other sources of ignition for the purpose of checking leakage. Use a soap-and-water solution to check for leakage. A failure to follow this warning can cause a fire, explosion, personal injury, or death.

VI. ELECTRICAL CONNECTIONS

A. 115-v Wiring

Refer to the unit rating plate or Table 5 for equipment electrical requirements. The control system requires an earth ground for proper operation.

CAUTION: Do not connect aluminum wire between disconnect switch and furnace. Use only copper wire.

Make all electrical connections in accordance with the National Electrical Code (NEC) ANSI/NFPA 70-1993 and local codes or ordinances that might apply. For Canadian installations, all electrical connections must be made in accordance with Canadian Electrical Code CSA C22.1 or authorities having jurisdiction.

WARNING: The cabinet MUST have an uninterrupted or unbroken ground according to NEC ANSI/NFPA 70-1993 and Canadian Electrical Code CSA C22.1 or local codes to minimize personal injury if an electrical fault should occur. This may consist of electrical wire or conduit approved for electrical ground when installed in accordance with existing electrical codes. Do not use gas piping as an electrical ground.


The auxiliary junction box can be moved to the left-hand side of the furnace when a left-hand side power supply is desired. Remove the 2 screws holding the auxiliary junction box. Mount the junction box on the left-hand side of the furnace. The blower door interlock switch must also be moved to the left-hand side of the furnace due to the length of the wiring harness. (Holes have been provided in casing). When moved, tuck the wiring harness behind the clip provided to keep extra wire lengths out of the way.

NOTE: Proper polarity must be maintained for 115-v wiring. If polarity is incorrect, the furnace control status LED will flash rapidly and prevent heating operation.

B. 24-v Wiring

Make field 24-v connections at the 24-v terminal block. (See Fig. 8.) Connect terminal Y as shown in Fig. 7 for proper cooling operation. Use only AWG No. 18 or larger, color-coded copper thermostat wire.

The 24-v circuit contains an automotive-type, 3-amp fuse located on the main control. Any 24-v electrical shorts during installation, service, or maintenance could cause this fuse to blow. If fuse replacement is required, use ONLY a 3-amp fuse. The control will flash code 24 when the fuse needs replacement.



A93378

Fig. 7—Heating and Cooling Application Wiring Diagram 1-Stage Thermostat and Condensing Unit

TABLE 5—ELECTRICAL DATA

UNIT SIZE	VOLTS—HERTZ—PHASE	OPERATING VOLTAGE RANGE		MAX UNIT AMPS	MIN WIRE GAGE	MAX WIRE LENGTH (FT)‡	MAX FUSE OR HACR-TYPE CKT BKR AMPS†
		Max*	Min*				
024060	115—60—1	127	104	8.2	14	45	15
036060	115—60—1	127	104	11.4	14	32	15
042080	115—60—1	127	104	11.7	14	31	15
048080	115—60—1	127	104	13.5	14	27	15
036100	115—60—1	127	104	10.5	14	35	15
048100	115—60—1	127	104	13.2	14	28	15
060100	115—60—1	127	104	14.6	12	30	20
080120	115—60—1	127	104	18.2	12	31	20

* Permissible limits of the voltage range at which the unit will operate satisfactorily.

† Time-delay fuse is recommended.

‡ Length shown is as measured 1 way along wire path between unit and service panel for maximum 2 percent voltage drop.

C. Accessories**1. Electronic air cleaner (EAC)**

A terminal block (EAC-1 and EAC-2) is provided for EAC connection. (See Fig. 8.) The terminals are energized with 115v, 1-amp maximum during blower motor operation.


2. Humidifier (HUM)

Screw terminals (HUM and COM) are provided for 24-v humidifier connection. The terminals are energized with 24v, 0.5-amp maximum when the gas valve is energized.

VII. VENTING**A. General**

For conventional Category I vertical-venting, refer to the enclosed Installations Instructions, GAMA venting table for Category I furnaces and EZ VENT™ table for Category I fan-assisted furnaces. The horizontal portion of the venting system shall maintain a minimum of 1/4-in. upward slope per linear ft (away from furnace), and it shall be rigidly supported every 5 ft or less with hangers or straps to ensure that there will be no movement after installation.

This furnace may also be installed with a Category III vertical or horizontal (sidewall) vent system using the accessory kit listed on the vent label on the top plate of the furnace. This kit **MUST** be used for Category III venting. Refer to the kit instructions for detailed information about Category III venting.



A94125

Fig. 8—Control Center

WARNING: DO NOT install a Category III vent system without the accessory conversion kit. Category III vents without the accessory kit will have nuisance shutdowns on draft safeguard switch and may cause vent and furnace component failure, resulting in property damage, personal injury, or death.

Only Special Gas Vent pipe (high temperature plastic rated for 480°F) listed per UL 1738 for Category III appliances may be used (in Canada, Type BH Gas Vent System per ULC-S636-M1985). See accessory kit instructions for part numbers of allowable vent pipe and fittings.

WARNING: When this furnace is converted to Category III, it must have its own dedicated vent. DO NOT common vent with any other appliance. Common venting with other appliances will result in spillage of flue gas and failure of vent system which may cause property damage, personal injury, or death.

A gastight heat dissipator, condensate drain tube and clamps, condensate trap and mounting bracket, and draft safeguard modification plate are provided in the kit. No substitution for any of the components may be made when installing furnace with a Category III vent system.

WARNING: Table 6 lists the required vent size for furnace sizes based on high-fire input. Refer to the furnace rating plate and Table 6 to determine size of Special Gas Vent pipe. An incorrectly sized vent may cause inadequate wind resistance, poor operation, or vent failure. Vent failure may result in property damage or flue gas spillage, resulting in personal injury or death.

TABLE 6—VENT PIPE SIZE*

HIGH-FIRE INPUT (BTUH)	PIPE DIAMETER
60,000—84,000	3 in.
85,000—120,000	4 in.

* Only Category III conversion kit specified on furnace and pipe size listed for furnace input shall be used.

All joints in the vent system, between vent system and heat dissipator and between heat dissipator and furnace, must be sealed airtight with only the high temperature RTV specified by the Special Gas Vent pipe manufacturer. The accessory kit contains provisions for vent condensate drainage. Drain and trap must be installed per kit instructions. Incorrect drain installations may cause furnace component failure. Furnace installations in unconditioned spaces where temperature may fall below 32°F REQUIRE freeze protection (heat tape) on condensate trap.

B. High Temperature Plastic, Special Gas Vent Installation

1. Cutting

CAUTION: DO NOT cut with power saw. Doing this may cause immediate or eventual cracking or shattering of pipe. DO NOT cut or alter fittings.

- Hand cut piping with a sharp saw. Saw blade must have at least 24 teeth per in.
- Cut pipe squarely. Use of a miter box when cutting pipe is recommended.

2. Adhesive Joining

Pipe and fittings are joined together using high temperature RTV adhesive/sealants. Use ONLY adhesives listed by vent manufacturer. Do not use any other adhesives or sealants. Do not use solvent cements.

Do not drill holes in pipe or fittings. Do not use sheet metal or other types of screws to join plastic piping or fittings. Do not use rivets to join piping or fittings.

Before applying sealant, pipe ends must be smooth and clean.

- Apply minimum 1/4-in. bead of adhesive/sealant entirely around pipe no more than 1/8-in. from end.
- Push pipe and fitting together while twisting pipe into fitting.
- Inspect joint for complete seal. Full curing of joints takes 24 hrs.

WARNING: Failure to ensure complete seal of all joints between furnace, heat dissipator, vent pipes, and fittings will allow spillage of flue gas, which may result in personal injury or death.

Inspect each joint after the adhesive/sealant has cured to ensure that all joints are sealed. Reapply adhesive/sealant to any joints that are suspected of flue gas leakage.

3. Vent Installation

Minimum vent length is 5 ft of straight pipe, one 90° long-radius (sweep) elbow or equivalent, condensate drain assembly, and termination (coupling and bird screen).

Maximum vent length is 40 ft of straight pipe, four 90° long-radius (sweep) elbows, condensate drain assembly, and termination (coupling and bird screen).

Length and number of elbows may be adjusted according to equivalent ft of pipe for fittings shown in Table 7.

Example: If adding an additional 90° long-radius (sweep) elbow in a 3-in. diameter vent system, maximum vent length must be reduced to 35 ft.

A coupling and bird screen are the recommended vent termination for both horizontal and vertical vents. If a tee and 2 bird screens are required for vertical vents, the allowable vent length must be adjusted according to Table 7. No elbows shall be used as terminations.

TABLE 7—EQUIVALENT PRESSURE DROP IN LENGTH OF STRAIGHT PIPE FOR FITTINGS

FITTING	EQUIVALENT FT OF PIPE	
	3-In. Diameter	4-In. Diameter
90° Elbow	10	N/A
90° Long-Radius (Sweep) Elbow	5	6
45° Elbow	5	5-1/2
Tee Used as Elbow	10	10
Tee Used as Termination	5	5

N/A—Not Applicable

All horizontal runs of piping must slope backward towards drain tee 1/4 in. per ft. The horizontal run between the drain tee and the furnace must also slope towards the drain tee. Vent system must be supported at least every 5 ft and at every elbow on horizontal runs.

Vertical runs must be supported at least every 10 ft by supports listed by vent pipe manufacturer. Frame the floor opening using lumber which is dimensionally consistent with structural members. Framing must be level and must provide required air space clearance to pipe.

4. Vertical Vent Termination

Where vent passes through roof, a listed flashing and storm collar must be used to maintain required clearances and to keep weather out. Framed opening must be large enough to maintain required air clearance taking into account slope of roof. Install flashing and storm collar as directed by vent manufacturer. Vertical termination must be at least 2 ft horizontally from roof surface, at least 8 ft away from any vertical wall, and must extend above roof as required in kit instructions. Vents extending 2-1/2 ft or more above roof must be securely guyed or braced according to vent manufacturer's Installation Instructions. Terminate with a coupling and a bird screen.

5. Horizontal Vent Termination

NOTE: Do not locate the vent termination close to shrubbery. Flue gas may stunt growth or kill shrubs. Combustion products may affect unprotected building material surfaces. Sealing or shielding of exposed surfaces with a corrosion resistant material may be required in these cases.

NOTE: In U.S.A., vent must terminate 3 ft above any mechanical fresh air intake within 10 ft.

After vent system is installed, inspect all joints and supports. If all joints are secure, fully seated, and well supported by straps, furnace may be started, adjusted per furnace Installation Instructions, and placed into operation. See vent pipe manufacturer's Installation Instructions. Cure time is required before operating furnace.

VIII. START-UP, ADJUSTMENT, AND SAFETY CHECK

A. General

The furnace must have a 115-v power supply properly connected and grounded. Correct polarity must be maintained to enable operation.

The gas service pressure must not exceed 0.5 psig (14-in. wc), but be no less than 0.16 psig (4.5-in. wc).

Thermostat wire connections at R and W/W1 are the minimum required for gas heating operation. COM, Y/Y2, and G are required for cooling, heat pumps, and some clock thermostats. These must be made at the 24-v terminal block on the control. (See Fig. 8.)



CAUTION: This furnace is equipped with a manual reset limit switch in the gas control area. The switch will open and shut off power to the gas valve if a flame rollout or overheating condition occurs in the gas control area. DO NOT bypass the switch. Correct inadequate combustion-air supply, component failure, or restricted flue gas passageway and reset the switch.

Before operating the furnace, check each manual reset switch for continuity. If necessary, press and release the button to reset the switch.

B. Sequence of Operation

Using the schematic diagram in Fig. 9, follow the sequence of operation through the different modes. Read and follow the diagram very carefully.

NOTE: If a power interruption occurs during a "call for heat" and if the thermostat is still calling for gas heating, the control will start a 90-sec blower only on period 2 sec after power is restored. The red LED light will flash code 12 during the 90-sec period, after which the LED will be on continuously as long as no faults are detected. After the 90-sec period, the furnace will respond to the thermostat normally.

The blower door must be installed for power to be conducted through the blower door interlock switch ILK to the furnace control CPU, transformer TRAN, inducer motor IDM, blower motor BLWM, hot surface ignitor HSI, and gas valve GV.

1. Heating Mode

When the wall thermostat "calls for heat," R-W/W1 circuit closes. The furnace control performs a self check, verifies the low-heat and high-heat pressure switch contacts LPS and HPS are open, and starts the inducer motor IDM.

a. Inducer prepurge period—As the inducer motor IDM comes up to speed, the low-heat and high-heat pressure switch contacts LPS and HPS close to begin a 15 sec prepurge period.

b. Ignitor warm-up—At the end of the prepurge period, the hot surface ignitor HSI is energized for a 17-sec ignitor warm-up period.

c. Trial-for-ignition sequence—When the ignitor warm-up period is completed, the main gas valve relay contacts MGVR-1 and -2 close to energize the gas valve solenoid GV. The gas valve opens, and 24-v power is supplied for a field-installed humidifier at terminals HUM and COM. The gas valve solenoid GV permits gas flow to the burners where it is ignited. After 5 sec, the ignitor HSI is

TABLE 8—HORIZONTAL VENT TERMINATION CLEARANCES

LOCATION	CLEARANCE (FT)	
	U.S.A.	Canada
Above anticipated snow depth	1	1†
From mechanical fresh air intake	1	6
For furnaces with an input capacity less than 100,000 Btuh from any nonmechanical air supply (such as a door or window) or combustion-air opening	4 below 4 horizontally 1 above	1
For furnaces with an input capacity greater than 100,000 Btuh from any nonmechanical air supply (such as a door or window) or combustion-air opening		3
From service regulator vent, electric and gas meters, and relief equipment	4*	6‡
Above grade when adjacent to public walkway	7	7

* Horizontal distance.

† 18 in. above roof surface in Canada.

‡ 36 in. to electric meter.

de-energized and a 2-sec flame-proving period begins. If the high-heat pressure switch HPS fails to close due to a high wind condition and the low-heat pressure switch LPS closes, the furnace operates at a reduced gas flow rate until the wind subsides and the high-heat pressure switch closes.

d. **Flame-proving**—When the burner flame is proved at the flame-proving sensor electrode FSE, the control CPU begins the blower on delay period and continues to hold the gas valve GV open. If the burner flame is not proved within 2 sec, the control CPU closes the gas valve GV, and the control CPU repeats the ignition sequence for up to 3 more trials-for-ignition before going to ignition lockout. Lockout is reset automatically after 3 hrs, or by momentarily interrupting 115-v power to the furnace, or by interrupting 24-v power at SEC1 or SEC2 to the control CPU (not at W/W1, G, R, etc.). Opening the thermostat R-W circuit will not reset an ignition lockout. If flame is proved when flame should not be present, the control CPU locks out of gas heating mode and operates the inducer motor IDM until flame is no longer proved.

e. **Blower on delay**—If the burner flame is proven, 45 sec after the gas valve GV is opened the blower motor BLWM is energized on heating speed. Simultaneously, the EAC terminals EAC-1 and EAC-2 are energized and remain energized as long as the blower motor BLWM is energized.

f. **Blower off-delay**—When the thermostat is satisfied, the R-W circuit is opened, de-energizing the gas valve GV, stopping gas flow to the burners, and de-energizing the humidifier terminals HUM and COM. The inducer motor IDM remains energized for a 5-sec post-purge period. The blower motor BLWM and EAC terminals EAC-1 and EAC-2 remain energized for 135 sec.

2. Cooling Mode

(See Fig. 7 for thermostat connections.)

a. The thermostat closes the R to G-and-Y circuits. The R-Y circuit starts the outdoor unit, and the R to G-and-Y circuits start the furnace blower motor BLWM on high-cooling speed.

b. The EAC terminals EAC-1 and EAC-2 are energized with 115v when the blower motor BLWM is operating.

c. When the thermostat is satisfied, the R to G-and-Y circuits are opened. The outdoor unit stops, and the furnace blower motor BLWM continues operating on the high-cooling speed for an additional 90 sec.

3. Continuous Blower Mode

a. When the R to G circuit is closed by the thermostat, the blower motor BLWM operates on low speed (identical to low-cooling speed). Terminals EAC-1 and EAC-2 are energized as long as the blower motor BLWM is energized.

b. During a "call for heat," the blower motor BLWM stops during ignitor warm-up (17 sec), ignition (7 sec), and blower on delay (45 sec), allowing the furnace heat exchangers to heat up quickly.

c. The blower motor BLWM reverts to continuous blower speed after the heating cycle is completed. In gas-heat mode, the furnace control CPU holds the blower motor BLWM at heating speed during the blower off delay period before reverting to continuous blower speed.

d. When the thermostat "calls for cooling," the blower motor BLWM operates on cooling speed. When the thermostat is satisfied, the blower motor BLWM operates an additional 2 sec on cooling speed before reverting back to continuous blower speed.

e. When the R-G circuit is opened, the blower motor BLWM continues operating for an additional 90 sec if no other function requires blower motor BLWM operation.

4. Heat Pump Mode

NOTE: An accessory interface kit is required with single-speed heat pumps. See interface kit Installation Instructions for single-speed heat pump thermostat and interface connections.

a. Heat pump cooling

(1) The thermostat and interface kit close the R to G-and-Y circuit to start the furnace blower motor BLWM on cooling speed. The Y input to the furnace control is necessary to provide adequate cooling airflow.

(2) The EAC terminals EAC-1 and EAC-2 are energized with 115v when the blower motor BLWM is operating.

(3) When the thermostat is satisfied, furnace blower motor BLWM continues operating on the cooling speed for an additional 90 sec.

b. Heat pump heating

(1) The thermostat and accessory interface kit R to G-and-Y circuits start the furnace blower motor BLWM on heat pump heating speed (identical to cooling speed).

(2) The EAC terminals EAC-1 and EAC-2 are energized with 115v when the blower motor BLWM is operating.

(3) When the thermostat is satisfied, the furnace blower motor BLWM continues operating on the heat pump heating speed for an additional 90 sec.

5. Defrost Mode

a. When the furnace control R to W/W1-and-Y/Y2 circuits are closed, the furnace control CPU continues blower motor BLWM operation at the heat pump heating speed until the end of the prepurge period, then shuts off until the end of the HSI ignitor on period (22 sec).

b. When installed with a heat pump, the furnace control CPU automatically holds the blower off-time to 22 sec during the HSI ignitor on period. After 17 sec of the HSI ignitor on period, a trial for ignition sequence occurs as described above for gas heating. After flame is proved and without a blower on delay, the blower motor BLWM will operate on heating speed during defrost.

c. When furnace control R-W/W1 circuit is opened, the furnace control CPU begins the normal inducer post purge period and the blower motor BLWM remains on for the blower off delay period. If the R-G circuit remains closed, the blower motor BLWM reverts to continuous operation.

C. Start-up Procedures

1. **Component test**—The furnace features a component test system to help diagnose a system problem in the case of a component failure. To initiate the component test procedure, ensure that there are no thermostat inputs to the control and all time delays have expired. Short the TWIN/TEST terminal to ground or COM for 1 to 4 sec. (See Fig. 8.)




Fig. 9—Unit Wiring Diagram

A94133

NOTE: The component test feature will not operate if the control is receiving any thermostat signals or until all time delays have expired.

The component test sequence is as follows:

- The furnace control checks itself, operates the inducer motor on low speed for 7 sec and on high speed for 7 sec, then stops.
- The hot surface ignitor is energized for 15 sec, then de-energized.
- The blower motor operates on heat pump/continuous fan speed for 7 sec, then stops.
- The blower motor operates on gas heat speed for 7 sec, then stops.
- The blower motor operates on heat pump cool speed for 7 sec, then stops.

The gas valve and humidifier terminal HUM are not energized for safety reasons.

NOTE: The EAC terminals are energized when the blower is energized.

- After all connections have been made, purge gas lines and check for leaks.

WARNING: Never purge a line into a combustion chamber. Never use matches, candles, flame, or other sources of ignition for the purpose of checking leakage. Use a soap-and-water solution to check for leakage. A failure to follow this warning can cause a fire, explosion, personal injury, or death.

- To operate furnace, follow procedures on operating instructions label attached to furnace.
- With furnace operating, set thermostat below room temperature and observe that furnace goes off. Set thermostat above room temperature and observe that furnace restarts.

D. Adjustments

- Set gas input rate.

The gas input rate must be set for both high fire and low fire. Each adjustment is made independently at the gas control regulators.

There are 2 methods of adjusting the gas input rate. The preferred method is by using Table 9 and following instructions in item a. The second method is by clocking the gas meter and following instructions in item b.

The procedure in item b. **MUST** be used for altitudes above 2000 ft.

The gas valve regulator has been nominally set at 1.5-in. wc for low fire and 3.5-in. wc for high fire for natural gas.

- Check gas input rate using Table 9.

- Obtain average yearly heat value for local gas supply.
- Obtain average yearly specific gravity for local gas supply.
- Verify furnace model. Table 9 can only be used for model 370AAV Furnaces.
- Check and verify orifice size in furnace. **NEVER ASSUME THE ORIFICE SIZE. ALWAYS CHECK AND VERIFY.**
- Find natural gas heat value and specific gravity in Table 9.

- Follow heat value and specific gravity lines to point of intersection. Find orifice size and manifold pressure settings for proper operation at given natural gas conditions on low and high fire.

EXAMPLE:

Heat value = 980 Btu/cu ft

Specific gravity = 0.62

Therefore: Orifice No. 44*

Manifold pressure 3.5-in. wc on high fire and 1.5-in. wc on low fire.

* The furnace is shipped with No. 45 orifices. Therefore, in this example all main burner orifices must be changed and manifold pressure must be adjusted.

- Proceed to item c. to adjust manifold pressure.

- Check gas input rate by clocking gas meter for low and high fire.

- Obtain average yearly heat value for local gas supply.

NOTE: Be sure heating value used for calculations is correct for your altitude. Consult local gas utility for altitude adjustments of gas heating value.

- Check and verify orifice size in furnace. **NEVER ASSUME THE ORIFICE SIZE. ALWAYS CHECK AND VERIFY.**

- Turn off all other gas appliances and pilots.

- Close R-W/W1 to start furnace in high fire and let run for 3 minutes.

- Measure time (in sec) for gas meter to complete 1 revolution.

- Refer to Table 9 for cubic ft of gas per hr.

- Multiply gas rate (cubic ft/hr) by heating value (Btu/ cubic ft).

EXAMPLE:

Btu heating input = Btu/cu ft X cu ft/hr

Heating value of gas = 1070 Btu/cu ft

Time for 1 revolution of 2-cu ft dial = 72 sec Gas rate = 100 cu ft/hr (from Table 10)

Btu heating input = 100 X 1070 = 107,000 Btuh

- Measured gas input should equal low- and high-fire gas inputs on unit rating plate $\pm$ 2 percent.

TABLE 9—MODEL 370AAV ORIFICE SIZE AND MANIFOLD PRESSURE FOR CORRECT INPUT RATE
 (Tabulated Data Based on Altitude Up to 2000 ft and 20,000 Btuh High Heat/13,000 Btuh Low Heat Per Burner)

GAS HEAT VALUE (BTU/CU FT)	SPECIFIC GRAVITY OF NATURAL GAS															
	0.58		0.60		0.62		0.64		0.66		0.68		0.70		0.72	
	Orf No.	Heat High/Low	Orf No.	Heat High/Low	Orf No.	Heat High/Low	Orf No.	Heat High/Low	Orf No.	Heat High/Low	Orf No.	Heat High/Low	Orf No.	Heat High/Low	Orf No.	Heat High/Low
860	43	3.7/1.6	43	3.8/1.6	42	3.2/1.4	42	3.3/1.4	42	3.4/1.5	41	3.2/1.4 3.8/1.5	41	3.3/1.4 3.7/1.5	41	3.4/1.4 3.8/1.6
875	43	3.6/1.5	43	3.7/1.6	43	3.8/1.6	42	3.2/1.4	42	3.3/1.4	42	3.4/1.4	41	3.2/1.3 3.5/1.5	41	3.3/1.4 3.6/1.5
890	43	3.5/1.5	43	3.6/1.5	43	3.7/1.6	43	3.8/1.6	42	3.2/1.4	42	3.3/1.4	42	3.4/1.4	41	3.2/1.3 3.5/1.5
905	43 44	3.3/1.3 3.7/1.5	43	3.5/1.4	43	3.6/1.5	43	3.7/1.5	43	3.8/1.6	42	3.2/1.4	42	3.3/1.4	42	3.4/1.4
920	43 44	3.2/1.3 3.7/1.5	43 44	3.3/1.4 3.8/1.6	43	3.5/1.4	43	3.6/1.5	43	3.7/1.5	43	3.8/1.5	42	3.2/1.3	42	3.3/1.3
935	44	3.6/1.5	43 44	3.2/1.4 3.7/1.6	43 44	3.3/1.4 3.8/1.6	43	3.5/1.5	43	3.6/1.5	43	3.7/1.5	43	3.8/1.6	42	3.2/1.3
950	44	3.5/1.5	44	3.6/1.5	43 44	3.2/1.4 3.7/1.6	43 44	3.3/1.4 3.8/1.6	43	3.4/1.5	43	3.6/1.5	43	3.7/1.5	43	3.8/1.6
965	44	3.4/1.4	44	3.5/1.5	44	3.6/1.5	43 44	3.2/1.4 3.7/1.6	43 44	3.3/1.4 3.8/1.6	43	3.4/1.5	43	3.5/1.5	43	3.6/1.5
980	44	3.3/1.4	44	3.4/1.4	44	3.5/1.5	44	3.6/1.5	43 44	3.2/1.4 3.7/1.6	43 44	3.3/1.4 3.8/1.6	43	3.4/1.5	43	3.5/1.5
995	44 45	3.2/1.3 3.8/1.6	44	3.3/1.4	44	3.4/1.4	44	3.5/1.5	44	3.6/1.5	43 44	3.2/1.4 3.7/1.6	43 44	3.3/1.4 3.8/1.6	43	3.4/1.4
1010	45	3.7/1.6	44 45	3.2/1.3 3.8/1.6	44	3.3/1.4	44	3.4/1.4	44	3.5/1.5	44	3.6/1.5	43 44	3.2/1.4 3.7/1.6	43	3.3/1.4 3.8/1.6
1025	45 46	3.6/1.5 3.8/1.6	45	3.7/1.6	44	3.2/1.3	44	3.3/1.4	44	3.4/1.4	44	3.5/1.5	44	3.6/1.5	43 44	3.2/1.4 3.7/1.6
1040	45 46	3.5/1.5 3.7/1.6	45	3.6/1.5 3.8/1.6	45	3.7/1.6	44	3.2/1.3	44	3.3/1.4	44	3.4/1.4	44	3.5/1.5	44	3.6/1.5
1055	45 46	3.4/1.4 3.6/1.5	45	3.5/1.5 3.7/1.6	45	3.6/1.5 3.8/1.6	45	3.8/1.6	44	3.2/1.3	44	3.3/1.4	44	3.4/1.4	44	3.5/1.5
1070	45 46	3.3/1.4 3.5/1.5	45	3.4/1.4 3.6/1.5	45	3.5/1.5 3.7/1.6	45	3.7/1.5 3.8/1.6	45	3.8/1.6	44	3.2/1.4	44	3.3/1.4	44	3.4/1.4
1085	45 46 47	3.2/1.4 3.4/1.4 3.8/1.6	45	3.3/1.4 3.5/1.5	45	3.4/1.5 3.6/1.5	45	3.6/1.5 3.7/1.6	45	3.7/1.5	45	3.8/1.6	44	3.2/1.4	44	3.3/1.4
1100	46 47	3.3/1.4 3.7/1.6	45	3.2/1.4 3.4/1.4	45	3.4/1.4 3.5/1.5	45	3.5/1.5 3.6/1.5	45	3.6/1.5 3.8/1.6	45	3.7/1.6	45	3.8/1.6	44	3.2/1.4

TABLE 10—GAS RATE (CU FT/HR)

SECONDS FOR 1 REVOLUTION	SIZE OF TEST DIAL			SECONDS FOR 1 REVOLUTION	SIZE OF TEST DIAL		
	1 cu ft	2 cu ft	5 cu ft		1 cu ft	2 cu ft	5 cu ft
10	360	720	1800	50	72	144	360
11	327	655	1638	51	71	141	355
12	300	600	1500	52	69	138	346
13	277	555	1385	53	68	136	340
14	257	514	1286	54	67	133	333
15	240	480	1200	55	65	131	327
16	225	450	1125	56	64	129	321
17	212	424	1059	57	63	126	316
18	200	400	1000	58	62	124	310
19	189	378	947	59	61	122	305
20	180	360	900	60	60	120	300
21	171	343	857	62	58	116	290
22	164	327	818	64	56	112	281
23	157	313	783	66	54	109	273
24	150	300	750	68	53	106	265
25	144	288	720	70	51	103	257
26	138	277	692	72	50	100	250
27	133	267	667	74	48	97	243
28	129	257	643	76	47	95	237
29	124	248	621	78	46	92	231
30	120	240	600	80	45	90	225
31	116	232	581	82	44	88	220
32	113	225	563	84	43	86	214
33	109	218	545	86	42	84	209
34	106	212	529	88	41	82	205
35	103	206	514	90	40	80	200
36	100	200	500	92	39	78	196
37	97	195	486	94	38	76	192
38	95	189	474	96	38	75	188
39	92	185	462	98	37	74	184
40	90	180	450	100	36	72	180
41	88	176	439	102	35	71	178
42	86	172	429	104	35	69	173
43	84	167	419	106	34	68	170
44	82	164	409	108	33	67	167
45	80	160	400	110	33	65	164
46	78	157	391	112	32	64	161
47	76	153	383	116	31	62	155
48	75	150	375	120	30	60	150
49	73	147	367				

NOTE: High altitude—In the United States, gas input on rating plate is for altitudes up to 2000 ft. Ratings for altitudes over 2000 ft MUST be reduced 4 percent for each 1000 ft above sea level. To obtain the adjusted altitude rating, adjust the manifold pressure (see item c) and replace the main burner orifices as needed. Refer to NFPA Appendix F, Table F-4 for proper orifice sizing at high altitudes.

NOTE: Canadian installations only—The Canadian ratings are approved for altitudes up to 2000 ft for natural and propane gases. High-altitude ratings are from 2000 ft to 4500 ft above sea level. High-altitude rating includes a 10 percent derate as required by Canadian standards.

- (9.) Temporarily disconnect gray wire at high-heat pressure switch (HPS) and repeat items (5.) through (8.) for low fire. Reconnect gray wire to HPS when finished.

- (10.) Proceed to item c. to adjust manifold pressure.

CAUTION: DO NOT redrill burner orifices. Improper drilling (burrs, out of round, etc.) can cause excessive burner operating noise and misdirection of burner flames. This could result in flame impingement on burners and heat exchanger surfaces, leading to potential failures.

c. Adjust gas input.

- (1.) Jumper R to W/W1 to call for high-gas heat.
- (2.) Remove gas control regulator adjustment seal caps. (See Fig. 10.)
- (3.) Turn high-fire adjusting screw (5/64-in. hex Allen wrench) counterclockwise (out) to decrease input rate or clockwise (in) to increase rate. When adjust-

ing input rate, DO NOT set manifold pressure less than 3.2-in. wc or more than 3.8-in. wc for natural gas. If manifold pressure is outside this range, change main burner orifices.

- (4.) Disconnect gray wire from high-heat pressure switch HPS to place furnace in low-fire operation for low-fire adjustment.

- (5.) Turn low-fire adjusting screw (5/64-in. hex Allen wrench) counterclockwise (out) to decrease input rate or clockwise (in) to increase rate. When adjusting input rate, DO NOT set manifold pressure less than 1.3-in wc or more than 1.7-in. wc for natural gas. If manifold pressure is outside this range, change main burner orifices.

NOTE: If orifices are changed, both high-fire and low-fire input rates must be readjusted with manifold pressures within ranges specified in items (3.) and (5.).

NOTE: If orifice hole appears damaged or it is suspected to have been redrilled, check the orifice size with a numbered drill bit of the correct size. Never use a redrilled orifice. A burr-free and squarely aligned orifice hole is essential for proper flame characteristics.


- (6.) Remove jumper on R-W/W1 after low-fire adjustments. Reconnect gray wire to HPS.

- (7.) When correct input is obtained, replace regulator seal caps. Main burner flame should be clear blue, almost transparent. (See Fig. 11.)

2. Set temperature rise.

Jumper R to W/W1 to check high-gas-heat temperature rise. Determine air temperature rise for high fire. Do not exceed the temperature rise range specified on the unit rating plate for high and low fire.

- a. Place duct thermometers in return and supply ducts as near furnace as possible. Be sure thermometers do not see heat exchangers so that radiant heat will not affect thermometer readings. This is particularly important with straight run ducts.




A93376

Fig. 10—Redundant Automatic Gas Control Valve

- b. When thermometer readings stabilize, subtract return-air temperature from supply-air temperature to determine temperature rise.

NOTE: If the temperature rise is outside this range, first check:

- (1.) Gas input.



A89020

Fig. 11—Burner Flame

- (2.) Derate for altitude if applicable.
- (3.) Return and supply ducts for excessive restrictions causing static pressures greater than 0.50-in. wc.
- c. Adjust air temperature rise by adjusting blower speed. Increase blower speed to reduce temperature rise. Decrease blower speed to increase temperature rise. For high fire, speed selection can be med-low (factory setting) or med-high.

WARNING: Disconnect the electrical power before changing the speed tap. A failure to follow this warning can cause personal injury.

- d. To change motor speed selection for high heat (normal heating mode), remove blower motor lead from control board HIGH-GAS-HEAT terminal. (See Figs. 8 and 9.) Select desired blower motor speed lead from 1 of the other terminals, and relocate it to the HIGH-GAS-HEAT terminal. See Table 11 for lead color identification. Reconnect original lead to the PARK terminal. Follow this same procedure for proper selection of COOL speed selection.

TABLE 11—SPEED SELECTION

COLOR	SPEED	AS SHIPPED
White	Common	COM
Black	High	HIGH-COOL
Yellow	Med-High	PARK
Blue	Med-Low	HIGH-GAS HEAT
Red	Low*	LOW-GAS HEAT

* Continuous fan operation is low speed.

CAUTION: Recheck the temperature rise. It must be within the limits specified on the unit rating plate. Recommended operation is at midpoint of rise range or above.

3. Set thermostat heat anticipator.

The thermostat heat anticipation must be set to match the amp draw of the electrical components in the R-W/W1 circuit. Accurate amp draw readings can be obtained at thermostat subbase terminals R and W. Fig. 12 illustrates an

easy method of obtaining the actual amp draw. The amp reading should be taken after the blower motor has started and the furnace is operating. See the thermostat manufacturer's instructions for adjusting the heat anticipator.

NOTE: When using an electronic thermostat, set the cycle rate for 3 cycles per hr.

E. Check Safety Controls

The flame sensor, gas valve, and pressure switches were all checked in the Start-up section as part of normal operation.

1. Check primary limit control.


This control shuts off the combustion control system and energizes the circulating-air blower motor if the furnace overheats.

The preferred method of checking the limit control is to gradually block off the return air after the furnace has been operating for a period of at least 5 minutes. As soon as the limit has shut off the burners, the return-air opening should be unblocked. By using this method to check the limit control, it can be established that the limit is functioning properly and will operate if there is a motor failure.

2. Check draft safeguard switch. (Category I vent installation only.)

The purpose of this control is to permit the safe shutdown of the furnace during certain blocked vent conditions.

- a. Disconnect power to furnace and remove vent connector from furnace outlet collar. Be sure to allow time for vent pipe to cool down before removing.



A80201

Fig. 12—Amp Draw Check With Ammeter

- b. Restore power to furnace and set room thermostat above room temperature.
 - c. After normal start-up, allow furnace to operate for 2 minutes, then block flue outlet 100 percent. Furnace should cycle off within 2 minutes.
 - d. Remove blockage and reconnect vent pipe to furnace outlet collar.
 - e. Wait 5 minutes and then reset draft safeguard switch.
- #### 3. Check pressure switches.
- This control proves operation of draft inducer blower.
- a. Turn off 115-v power to furnace.
 - b. Remove control door and disconnect inducer motor lead wires from wire harness.
 - c. Turn on 115-v power to furnace.
 - d. Close thermostat switch as if making normal furnace start. If the hot surface ignitor does not glow within several minutes and control flashes code 32, then the pressure switches are functioning properly.

e. Turn off 115-v power to furnace.

f. Reconnect inducer motor wires, replace control door, and turn on 115-v power.

F. Checklist

1. Put away tools and instruments, and clean up debris.
2. Verify manual reset switches have continuity.

3. Ensure blower and control access doors are properly installed.
4. Cycle test furnace with room thermostat.
5. Check operation of accessories per manufacturer's instructions.
6. Review User's Manual with owner.
7. Leave literature packet near furnace.