

58RAV, 58PAV Induced-Combustion Furnaces

Maintenance and Service Instructions

For Sizes 035-125, Series 100

NOTE: This is a highly specialized piece of equipment. Before beginning, READ THESE INSTRUCTIONS CAREFULLY AND COMPLETELY.

SAFETY CONSIDERATIONS

Installation and servicing of heating equipment can be hazardous due to gas and electrical components. Only trained and qualified personnel should install, repair, or service heating equipment.

Untrained personnel can perform basic maintenance functions such as cleaning and replacing air filters. All other operations must be performed by trained service personnel. When working on heating equipment, observe precautions in the literature, tags, and labels attached to or shipped with the unit and other safety precautions that may apply.

Follow all safety codes. In the United States, follow all safety codes including the National Fuel Gas Code NFPA No. 54-1988/ANSI Z223.1-1988. In Canada, refer to the current edition of the National Standard of Canada CAN/CGA-B149.1- and .2-M86 Natural Gas and Propane Gas Installation Codes. Wear safety glasses and work gloves. Have fire extinguisher available during startup and adjustment procedures and service call.

Recognize safety information: This is the safety-alert symbol Δ . When you see this symbol on the furnace and in instructions or manuals, be alert to the potential for personal injury.


Understand the signal word—DANGER, WARNING, or CAUTION. These words are used with the safety-alert symbol. DANGER identifies the most serious hazards which will result in severe personal injury or death. WARNING signifies a hazard that **could** result in personal injury or death. CAUTION is used to identify unsafe practices, which would result in minor personal injury or product and property damage.

Δ WARNING

The ability to properly perform maintenance on this equipment requires certain expertise, mechanical skills, tools, and equipment. If you do not possess these, do not attempt to perform any maintenance on this equipment other than those procedures recommended in the Users Manual. A FAILURE TO FOLLOW THIS WARNING COULD RESULT IN POSSIBLE DAMAGE TO THIS EQUIPMENT, SERIOUS PERSONAL INJURY, OR DEATH.


CARE AND MAINTENANCE

For continuing high performance, and to minimize possible equipment failure, it is essential that periodic maintenance be performed on this equipment. Consult your local Dealer as to the proper frequency of maintenance and the availability of a maintenance contract.




A90172

Fig. 1—Model 58RAV Horizontal



A90109

Fig. 2—Model 58RAV Downflow



A90110

Fig. 3—Model 58PAV Upflow

Manufacturer reserves the right to discontinue, or change at any time, specifications or designs without notice and without incurring obligations.

⚠ WARNING

Never store anything on, near, or in contact with, the furnace, such as:

1. Spray or aerosol cans, rags, brooms, dust mops, vacuum cleaners, or other cleaning tools.
2. Soap powders, bleaches, waxes or other cleaning compounds, plastic or plastic containers, gasoline, kerosene, cigarette lighter fluid, dry cleaning fluids, or other volatile fluids.
3. Paint thinners and other painting compounds, paper bags or other paper products.

A failure to follow this warning could result in corrosion of the heat exchanger, fire, personal injury, or death.

⚠ WARNING

Turn off the gas and electrical supplies to the unit before performing any maintenance or service on it. Follow the operating instructions on the label attached to the furnace. A failure to follow this warning could result in personal injury.

The minimum maintenance that should be performed on this equipment is as follows:

1. Check and clean or replace air filter each month or more frequently if required.
2. Check blower motor and wheel for cleanliness and lubrication each heating and cooling season. Clean and lubricate as necessary.
3. Check electrical connections for tightness and controls for proper operation each heating season. Service as necessary.




Fig. 4—Horizontal Filter Arrangement




Fig. 5—Position of Filters

⚠ CAUTION

As with any mechanical equipment, personal injury can result from sharp metal edges, etc.; therefore, be careful when removing parts.

A. Air Filter Arrangement

The air filter arrangement may vary depending on the application. Refer to Table 1 or 2 for filter size information.

⚠ WARNING

Never operate unit without a filter or with filter access door removed. A failure to follow this warning could result in fire, personal injury, or death.

1. Horizontal and Downflow.

Each furnace requires two filters which are installed in the return-air duct. See Figs. 4 and 5.

To remove filters for cleaning or replacement, proceed as follows:

- a. Disconnect electrical power before removing access door.
- b. Remove blower access door.
- c. Reach up behind top plate, tilt filters toward center of return-air plenum, remove filters, and replace or clean as needed.
- d. Furnaces are equipped with permanent, washable filters. Clean those filters by spraying tap water through filter in opposite direction of airflow.
- e. Rinse and let dry. Oiling or coating of filters is not recommended.
- f. Reinstall filters with cross-mesh binding facing blower. Replace access door and restore electrical power to furnace.

2. Upflow.

Each furnace requires one or two filters which are installed in the blower compartment. See Fig. 6.

To remove filters for cleaning or replacement, proceed as follows:

- a. Disconnect electrical power before removing access doors.
- b. Release filter retainer from clip at front of furnace casing. See Fig. 6. For side return, clips may be used on either (or both) sides of the furnace.
- c. Slide filter out.
- d. Clean filter with tap water. Spray in opposite direction of airflow.
- e. Rinse and let dry. Oiling or coating of filter is not recommended.
- f. Place filter in furnace with cross-mesh binding up or facing blower. Replace access doors and restore electrical power to furnace.

Table 1—Filter Size Information
(Downflow/Horizontal)

FURNACE CASING WIDTH	FILTER SIZE	FILTER TYPE
14-3/16	(2) 16 x 20 x 1	Cleanable
17-1/2	(2) 16 x 20 x 1	Cleanable
21	(2) 16 x 20 x 1	Cleanable
24-1/2	(2) 16 x 20 x 1	Cleanable

Table 2—Filter Size Information (Upflow)

FURNACE CASING WIDTH	FILTER SIZE		FILTER TYPE
	Side Return	Bottom Return	
14-3/16	(1) 16 x 25 x 1*	(1) 14 x 25 x 1	Cleanable
17-1/2	(1) 16 x 25 x 1*	(1) 16 x 25 x 1	Cleanable
21	(1) 16 x 25 x 1	(1) 20 x 25 x 1*	Cleanable
24-1/2	(2) 16 x 25 x 1*	(1) 24 x 25 x 1	Cleanable

*Factory provided with the furnace. Filters may be field modified by cutting as required.

B. Blower Motor and Wheel

For long life, economy, and high efficiency; clean accumulated dirt and grease from the blower wheel and motor annually.

The following steps should be performed by a qualified service technician.

Some motors have prelubricated sealed bearings and require no lubrication. These motors can be identified by the absence of oil ports on each end of the motor. For those motors with oil ports lubricate as follows:

Lubricate motor every 5 years if motor is used on intermittent operation (thermostat FAN switch in AUTO position), or every 2 years if motor is in continuous operation (thermostat FAN switch in ON position).

Remember to disconnect the electrical supply before removing access doors.

Clean and lubricate as follows:

1. Remove blower access door.
2. Disconnect vent pipe on downflow furnace only.
 - a. Remove vent pipe enclosure.
 - b. Disconnect vent pipe and remove short piece of pipe from furnace.

- c. Disconnect wires from auxiliary limit on blower housing.
3. Remove control box.
4. Remove electrical leads from numbered side of Molex speed selector. See Figs. 6 and 7. Note location of wires for reassembly.
5. Remove screws holding blower assembly to blower deck and slide blower assembly out of furnace.
6. Squeeze side tabs of Molex speed selector and pull it from blower housing.
7. Loosen a screw in strap holding motor capacitor to blower housing and slide capacitor out from under strap.
8. Mark blower wheel, motor, and motor support in relation to blower housing before disassembly, to insure proper reassembly.
9. Loosen setscrew holding blower wheel on motor shaft.
10. Remove bolts holding motor mount to blower housing and slide motor and mount out of housing. Disconnect ground wire attached to blower housing before removing motor.
11. Lubricate motor (when oil ports are provided).
 - a. Remove dust caps or plugs from oil ports located at each end of motor.
 - b. Use a good grade of SAE 20 nondetergent motor oil and put one teaspoon, 5 cc, 3/16 oz., or 16 to 25 drops in each oil port. **Do not** over oil.
 - c. Allow time for total quantity of oil to be absorbed by each bearing.
 - d. After oiling motor, be sure to wipe excess oil from motor housing.
 - e. Replace dust cap or plugs on oil ports.




Fig. 6—Model 58PAV Upflow

A90218




Fig. 7—Model 58RAV Downflow

A88488

12. Remove blower wheel from housing.
 - a. Mark cutoff location to insure proper reassembly.
 - b. Remove screws holding cutoff plate and remove cutoff plate from housing.
 - c. Lift blower wheel from housing through opening.
13. Clean blower wheel and motor using a vacuum with soft brush attachment. Do not remove or disturb balance weights (clips) on blower wheel blades. The blower wheel should not be dropped or bent as balance will be affected.
14. Reinstall blower wheel by reversing steps 12 a thru c. Be sure wheel is positioned for proper rotation.
15. Reassemble motor and blower by reversing steps 5 thru 10. If motor has ground wire, be sure it is connected as before.

⚠ CAUTION

Be sure the motor is properly positioned in the blower housing. The motor oil ports must be at a minimum of 45° above the horizontal centerline of the motor after the blower assembly has been reinstalled in the furnace.

16. Reinstall blower assembly in furnace.
Connect electrical leads to Molex speed selector. Please note that connections are polarized for assembly—**do not force**.
17. Reinstall control box (reinstall vent pipe and enclosure on downflow furnace).
18. Turn on electrical power and check for proper rotation and speed changes between heating and cooling.

C. Cleaning Heat Exchanger

The following steps should be performed by a qualified service technician.

NOTE: Deposits of soot and carbon indicate a problem exists which needs to be corrected. Action must be taken to correct the problem.

If it becomes necessary to clean the heat exchanger because of carbon deposits, soot, etc., proceed as follows:

1. Turn off gas and power to furnace.
2. Remove control and blower access doors.
3. Remove vent pipe enclosure (downflow/horizontal furnace only) and disconnect vent pipe from relief box.
4. Remove two screws that secure relief box. See Fig. 6 or 7.
5. Disconnect wires to the following components:
 - a. Draft safeguard switch.
 - b. Inducer motor.
 - c. Pressure switch.
 - d. Limit overtemperature switch(es).
 - e. Gas valve.
 - f. Hot surface ignitor.
 - g. Flame sensing electrode.
 - h. Two wiring edge connectors leading to control box.
6. Remove eight screws that secure flue collector box to center panel. Be careful not to damage sealant.
7. Remove complete inducer assembly from furnace, exposing flue openings.
8. Using field-provided small wire brush, steel spring cable, reversible electric drill, and vacuum cleaner; clean cells as follows:
 - a. Assemble wire brush and steel spring cable.
 - (1.) Use 4 feet of 1/4-in. diameter high-grade steel

spring cable (commonly known as drain clean-out or Roto-Rooter cable).

- (2.) Use 1/4-in. diameter wire brush (commonly known as 25-caliber rifle cleaning brush).

NOTE: The items needed in steps (1.) and (2.) can usually be purchased at local hardware stores.

- (3.) Insert twisted wire end of brush into end of spring cable, and crimp tight with crimping tool or strike with ball-peen hammer. *Tightness is very important.*
 - (4.) Remove metal screw fitting from wire brush to allow insertion into cable.
- b. Clean each heat exchanger cell.
- (1.) Attach variable-speed, reversible drill to end of spring cable (end opposite brush).
 - (2.) Insert brush end of cable into upper opening of cell and slowly rotate with drill. *Do not force cable.* Gradually insert at least 3 feet of cable into two upper passes of cell. See Fig. 8.




Fig. 8—Cleaning Heat Exchanger Cell

- (3.) Work cable in and out of cell three or four times to obtain sufficient cleaning. *Do not* pull cable with great force. Reverse drill and gradually work cable out.
 - (4.) Remove burner assembly and cell inlet plates.
 - (5.) Replace screws in center panel and cells before cleaning.
 - (6.) Insert brush end of cable in lower opening of cell, and proceed to clean two lower passes of cell in same manner as two upper passes.
 - (7.) Repeat foregoing procedures until each cell in furnace has been cleaned.
 - (8.) Using vacuum cleaner, remove residue from each cell.
 - (9.) Using vacuum cleaner with soft brush attachment, clean burner assembly.
 - (10.) Reinstall cell inlet plates and burner assembly. Care must be exercised to center the burners in the cell openings.
9. After cleaning flue openings, check sealant on flue collector to ensure that it has not been damaged. If new sealant is needed, contact your Dealer or Distributor.
 10. Clean and replace flue collector assembly, making sure all eight screws are secure.
 11. Reinstall relief box.
 12. Reconnect wires to the following components:
 - a. Draft safeguard switch.
 - b. Inducer motor.

- c. Pressure switch.
 - d. Limit overtemperature switch(es).
 - e. Gas valve.
 - f. Hot surface ignitor.
 - g. Flame sensing electrode.
 - h. Two wiring edge connectors leading to control box.
13. Reconnect vent pipe to relief box. Replace vent pipe enclosure (when applicable).
 14. Replace blower door only.
 15. Turn on power and gas.
 16. Set thermostat and check furnace for proper operation.
 17. Check for gas leaks.
 18. Replace control door.

⚠ WARNING

Never use a match or other open flame to check for gas leaks. Use a soap-and-water solution. A failure to follow this warning could result in fire, personal injury, or death.

D. Hot Surface Ignitor

Be very careful when removing the burner assembly to avoid breaking the ignitor. See Fig. 9 for the correct ignitor location.

E. Electrical Controls and Wiring

NOTE: There may be more than one electrical supply to unit.

The electrical ground and polarity for 115-volt wiring must be maintained properly. Refer to Fig. 10 for field wiring information and to Fig. 11 for unit wiring information. If the polarity is **not** correct, the microprocessor control will shut off the gas flow shortly after completion of the ignition trial period. The control system also requires an earth ground for proper operation of the microprocessor.

With power disconnected to unit, check all electrical connections for tightness. Tighten all screws on electrical connections. If any smoky or burned connections are noticed, disassemble the connection, clean all parts and stripped wire, and reassemble properly and securely. Electrical controls are difficult to check without proper instrumentation; therefore, reconnect electrical power to unit and observe unit through one complete operating cycle. If there are any discrepancies in the operating cycle, contact your Dealer and request service.




Fig. 9—Position of Ignitor to Burner




Fig. 10—Heating and Cooling Application Wiring Diagram

