



Diesel Generator Set



OPERATIONS AND SERVICE MANUAL

For
69RG15
PowerLINE® Series 22 Generator Set Units
PID RG2200 to 2259
Tier 4 Compliant



OPERATIONS AND SERVICE MANUAL

For

69RG15

PowerLINE® Series 22 Generator Set Units
PID RG2200 to 2259 Tier 4 Compliant

Table of Contents

PARAGRAPH NUMBER	Page
SAFETY SUMMARY	1-1
1.1 GENERAL SAFETY NOTICES	1-1
1.2 FIRST AID	1-1
1.3 OPERATING PRECAUTIONS	1-1
1.4 MAINTENANCE PRECAUTIONS	1-1
1.5 SPECIFIC HAZARD STATEMENTS	1-1
DESCRIPTION	2-1
2.1 INTRODUCTION	2-1
2.2 CONFIGURATION IDENTIFICATION	2-2
2.3 ALTERNATING CURRENT GENERATOR	2-3
2.3.1 Voltage Controller	2-3
2.4 ENGINE	2-3
2.4.1 Engine Fuel System	2-4
2.4.2 Electronic Governor	2-5
2.4.3 Engine Lubrication System	2-6
2.4.4 Engine Air Cleaner System	2-7
2.4.5 Engine Cooling System	2-8
2.5 BATTERY AND BATTERY CHARGING SYSTEM	2-9
2.6 CONTROL PANEL AND CONTROL BOX COMPONENTS	2-9
2.6.1 Water Temperature Gauge	2-9
2.6.2 Oil Pressure Gauge	2-9
2.6.3 Total Time Meter	2-9
2.6.4 Ammeter	2-9
2.6.5 Intake Heater Switch	2-9
2.6.6 Ignition Switch	2-9
2.6.7 Intake Heater Timer	2-9
2.6.8 Starter Solenoid Timer	2-9
2.7 RECEPTACLE BOX COMPONENTS	2-11
2.8 SAFETY DEVICES	2-11
2.9 UNIT SPECIFICATIONS	2-13
INSTALLATION	3-1
3.1 INSTALLATION	3-1
3.2 REMOVAL	3-2
OPERATION	4-1
4.1 STARTING AND STOPPING INSTRUCTIONS	4-1
4.1.1 Pre-Start Inspection	4-1
4.1.2 Starting Instructions	4-1
4.1.3 Post-Start Inspection	4-2
4.1.4 Stopping Instructions	4-2
4.2 SEQUENCE OF OPERATION	4-2
TROUBLESHOOTING	5-1
5.1 DIESEL ENGINE	5-1
5.1.1 Engine Will Not Start	5-1
5.1.2 Engine Starts Then Stops	5-1
5.1.3 Engine Will Not Shut Off	5-2

5.1.4	Starter Motor Malfunction	5-2
5.1.5	Malfunction In The Engine Starting Circuit	5-2
5.1.6	Miscellaneous Engine Troubleshooting	5-3
5.2	BATTERY CHARGER (SOLID STATE)	5-4
5.3	ALTERNATING CURRENT GENERATOR	5-4
5.4	ELECTRONIC GOVERNOR MODULE	5-5
5.5	VOLTAGE CONTROLLER	5-5
5.6	HIGH VOLTAGE CIRCUIT, ELECTRICAL TROUBLESHOOTING	5-6
SERVICE AND PREVENTATIVE MAINTENANCE	6-1
6.1	INTRODUCTION	6-1
6.2	PREVENTATIVE MAINTENANCE SCHEDULE	6-1
6.3	BATTERY SERVICE	6-3
6.4	ENGINE SERVICE AND COMPONENTS	6-3
6.4.1	Bleeding the Fuel System	6-3
6.4.2	Servicing the Fuel Pump Internal Filter	6-3
6.4.3	Fuel Filter	6-4
6.4.4	In-Line Fuel Strainer	6-4
6.4.5	Cooling System	6-4
6.4.6	Lube Oil Filter	6-4
6.4.7	Servicing Low Oil Pressure Switch	6-5
6.4.8	Engine Speed	6-5
6.4.9	Replacing the Engine Speed Sensor	6-5
6.4.10	Servicing the Poly V-belt	6-5
6.4.11	Engine Air Cleaner	6-6
6.4.12	Engine Crankcase Breather	6-7
6.4.13	Intake Heater Test	6-7
6.4.14	Intake Heater Service	6-8
6.4.15	Intake Heater Switch	6-8
6.5	SERVICING THE AC GENERATOR	6-8
6.5.1	Remove and Replace Procedure	6-8
6.6	GENERAL GENERATOR SET MAINTENANCE	6-12
6.6.1	Maintenance of Painted Surfaces	6-12
6.6.2	Checking and Replacing Shockmounts	6-12
6.7	UNIDRIVE TORQUE REQUIREMENTS	6-15
SCHEMATICS	7-1
SCHEMATICS PAGE 2	7-2
SCHEMATICS PAGE 3	7-3
INDEX	INDEX-1

List of Figures

FIGURE NUMBER		Page
Figure 2.1 Generator Set	2-1
Figure 2.2 Generator Set Components - Covers Removed	2-2
Figure 2.3 Unit Nameplate	2-2
Figure 2.4 Generator and Engine - Unidrive Assembly	2-3
Figure 2.5 Fuel System Diagram	2-4
Figure 2.6 Fuel Tank	2-5
Figure 2.7 Electronic Governor Module (EG)	2-5
Figure 2.8 Engine Lubrication System	2-6
Figure 2.9 Engine Air Cleaner	2-7
Figure 2.10 Engine Cooling System	2-8
Figure 2.11 Control Panel and Control Box	2-10
Figure 2.12 Receptacle Box	2-11
Figure 3.1 Generator Set Mounting - Pin Type with Locking Bracket	3-1
Figure 6.1 Battery Cable Routing - Side View	6-3
Figure 6.2 Air Cleaner, Dry Element	6-6
Figure 6.3 Engine Crankcase Breather	6-7
Figure 6.4 Intake Heater	6-8
Figure 6.5 Generator Shaft Keyway	6-10
Figure 6.6 Generator Coupler Bolt	6-10
Figure 6.7 Generator Alignment Bolt	6-11
Figure 6.8 Generator Mounting Bolts	6-11
Figure 6.9 Generator Shockmounts	6-13
Figure 6.10 Engine Shockmounts	6-14
Figure 6.11 Truss and Isolator	6-14
Figure 6.12 Unidrive Torque Requirements	6-15
Figure 7.1 Schematic Legend	7-1
Figure 7.2 Schematic 12VDC Control Circuit	7-2
Figure 7.3 Schematic High Voltage Circuitry	7-3

List of Tables

TABLE NUMBER	Page
Table 2-1 Safety Devices	2-12
Table 2-2 Fuel Tank	2-13
Table 2-3 Generator	2-13
Table 2-4 Engine Data	2-13
Table 4-1 Cold Engine Preheat Times	4-2
Table 6-1 Preventative Maintenance Actions and Schedule	6-1

Section 1

Safety Summary

1.1 General Safety Notices

Installation and servicing of generator set equipment can be hazardous due to system belts, radiator fan, and electrical components. Only trained and qualified service personnel should install, repair, or service generator set equipment. When working on generator set equipment, observe all potential Danger, Warning and Caution hazards, including those shown below and on hazard labels attached to the unit.

The following general safety notices supplement specific warnings and cautions appearing elsewhere in this manual. They are recommended precautions that must be understood and applied during operation and maintenance of the equipment covered herein. The general safety notices are presented in the following three sections labeled: First Aid, Operating Precautions and Maintenance Precautions. A listing of the specific warnings and cautions appearing elsewhere in the manual follows the general safety notices

1.2 First Aid

An injury, no matter how slight, should never go unattended. Always obtain first aid or medical attention immediately.

1.3 Operating Precautions

Always wear safety glasses and hearing protection.

Keep hands, clothing and tools clear of the radiator fan and rotating belts.

No work should be performed on the unit until all circuit breakers and start-stop switches are turned off and the negative battery terminal has been disconnected.

Always work in pairs. Never work on the equipment alone.

In case of severe vibration or unusual noise, stop the unit and investigate.

1.4 Maintenance Precautions

Be sure power is turned off and the negative battery cable is disconnected before working on generator set.

Do not bypass any electrical safety devices, e.g. bridging an overload, or using any sort of jumper wires. Problems with the system should be diagnosed, and any necessary repairs performed, by qualified service personnel.

In case of electrical fire, open circuit switch and extinguish with CO₂ (never use water).

Fuel Tanks present explosion, fire, and rupture hazards even if liquid fuel has been drained. Do not attempt any repairs, especially repairs using flame, welder or torch, unless you have been properly trained and the tank has been emptied of liquid fuel and fuel vapors and the tank is properly ventilated

1.5 Specific Hazard Statements

To help identify the hazard labels on the unit and explain the level of awareness each one carries, explanations with appropriate consequences are provided below:

DANGER - Indicates an immediate hazard which **WILL** result in severe personal injury or death.

WARNING - Indicates hazards or unsafe conditions which **COULD** result in severe personal injury or death.

CAUTION - Indicates potential hazards or unsafe practices which **COULD** result in minor personal injury, product, or property damage.

The statements that follow are applicable to the generator set and appear elsewhere in this manual. These recommended precautions must be understood and applied during operation and maintenance of the equipment covered herein.

 **WARNING**

To prevent injury, the procedures provided for installation and removal of the generator set must be followed carefully.

 **WARNING**

Disconnect the power plug before removing the generator set.

 **WARNING**

Beware of moving poly V-belt, belt driven components and hot exhaust components.

 **WARNING**

Under no circumstances should ether or any other unauthorized starting aids be used in conjunction with the air intake heater.

 **WARNING**

Beware of pinch points.

 **WARNING**

Do not use gasoline to clean air cleaner parts.

 **CAUTION**

Observe proper polarity when installing the battery or connecting a battery charger. The negative battery terminal must be grounded. Reverse polarity may damage the charging system. When charging the battery in unit, isolate the battery by disconnecting the negative battery terminal first, then the positive. Once the battery has been charged, connect the positive battery terminal first, then the negative.

 **CAUTION**

Never pour cold water into a hot engine.

 **CAUTION**

Use only ethylene glycol anti-freeze (with inhibitors) in system. Use of glycol by itself will damage the cooling system.

 **CAUTION**

Always cover the engine inlet tube while the air cleaner is being serviced.

CAUTION

When reassembling the air cleaner, make sure the clamp bolt faces out, away from the fuel filter. If the clamp bolt is assembled facing in, it can contact the fuel filter and cause excessive wear.

CAUTION

Continued operation with failed shockmounts may result in engine or generator damage. When a shockmount has been cut, split, abraded or has flared due to normal deterioration, it must be replaced. Damage to the mounts may not be visible when installed and under load from the component. To correctly inspect shockmounts, they must be removed.

NOTICE

This generator set is equipped with special pins and mounting bolts and can be installed only on containers with matching installation points.

NOTICE

Piston rings in engines that have operated less than 100 hours may not be fully seated. This may lead to the possibility of oil seepage from the exhaust pipe. To properly seat the rings, operate the engine under full load for a period of 24 hours. If the condition persists, check valve clearance when the engine is cold. (Refer to engine workshop manual listed in [Section 2.4](#)).

NOTICE

If the generator set is equipped with the fuel filter bowl assembly, when replacing the fuel filter, a new fuel filter O-ring should be oiled and replaced, and then the clear bowl should also be tightened to 18 ft-lbs.

NOTICE

Do not attempt to adjust engine speed.

NOTICE

A frayed, cracked or worn poly V-belt must be replaced. After installing a new belt, check the adjustment after running the unit for three or four hours. This will allow for the initial stretch, which is common on new belts. Once this initial stretch has taken place, the belt should be checked at regular intervals.

NOTICE

The generator / engine must be slightly lifted off of the unit frame in order to provide enough clearance for the generator support plate to slide back, away from the engine.

NOTICE

Although the generator torsional dampener and flywheel adapter plate will normally keep the generator coupled to the engine, even without the bolts, it is safest to remove the lower generator bolts first, in case the generator shifts and falls during bolt removal.

NOTICE

Inspect the generator torsional dampener, bolt, and key as they are removed from the old generator and installed onto the new generator. Replace any components that are worn or damaged.

NOTICE

Align the torsional dampener and aluminum housing by rotating either one to seat correctly.

NOTICE

SST is an abbreviation for 300 Series Corrosion Resistant Steel.
Loctite #242 or an equivalent product should be used on ALL hardware shown in [Figure 6.12](#).

Section 2

Description


2.1 Introduction

The Carrier Transicold model 69RG15 Series 22 diesel-driven generator set provides a constant electrical power supply for all-electric refrigeration units. The 69RG15 is a a clip-on unit (see [Figure 2.1](#), [Figure 2.2](#)) mounted to the front of the container either by pin mounts located on the top channel or by optional clamp mounts located on either side of the generator set.

The generator set consists of a diesel engine directly connected to an alternating current generator and mounted in a structural steel frame. The engine is a vertical, in-line, four cylinder diesel manufactured by Kubota. The generator is a 15 kW, permanent, single winding, dual bearing type that supplies nominal 50/60Hz power.


Electrical controls are mounted in a control box with operating controls and gauges mounted on a control panel, which also serves as the control box cover. The control panel components are protected by a deflector assembly and control box door.

Figure 2.1 Generator Set



- | | |
|--|--------------------------------|
| 1) Clamp Mounts (Optional) | 5) Access Door |
| 2) Pin Mounts | 6) Control Box / Control Panel |
| 3) Unit Nameplate (Model, Serial, PID) | 7) Fuel Gauge |
| 4) Fuel Cap | ----- |

Figure 2.2 Generator Set Components - Covers Removed



- | | |
|-----------------------|-----------------------------------|
| 1) AC Generator | 8) Radiator |
| 2) Receptacle Box | 9) Oil Filter |
| 3) Battery Charger | 10) Coolant Recovery Bottle |
| 4) Voltage Controller | 11) Fuel Tank |
| 5) Engine | 12) Fuel Filter / Water Separator |
| 6) Exhaust Muffler | 13) Engine Air Cleaner |
| 7) Battery | 14) Control Panel and Control Box |

2.2 Configuration Identification

Generator set identification information is provided on a unit nameplate located on the side of the unit. The label provides the generator set model number, serial number and parts identification number (PID). The model number identifies the overall configuration, while the PID provides information on specific optional equipment and differences in detailed parts.

Figure 2.3 Unit Nameplate



Carrier Transicold Division
Carrier Corporation
Syracuse, New York

MODEL NO.	69RG15-120W-22
PARTS ID NO.	RG2251
SERIAL NO.	7010969
DATE OF MFG.	10-2021

2.3 Alternating Current Generator

The alternating current (AC) generator (see [Figure 2.4](#)) bolts directly to the engine and supplies nominal 50/60Hz power depending on the load requirement.

Generator sets will start at 50Hz. Once the unit is running, the voltage controller (see [Section 2.3.1](#)) will read the voltage output of the generator and adjust accordingly to keep the voltage within ISO limits. As the container becomes loaded, voltage drops and current increases, causing the generator set to adjust speed based on power demand and ambient conditions. The unit will typically run at 50Hz and vary generator output via winding selection. The speed change to 60Hz will typically occur when the ambient temperature is high and the unit is heavily loaded.

2.3.1 Voltage Controller

The voltage controller (VC) maintains ISO voltage via two-speed and single winding control. It regulates voltage in order to keep the generator output within ISO limits (see [Table 2-3](#)). The voltage controller and voltage controller fuses (VCF1 and VCF2) are located in the receptacle box (see [Figure 2.12](#)).


2.4 Engine

The engine (see [Figure 2.4](#)) is a vertical, in-line four cylinder diesel engine, model V2203-DI, that is directly connected to the AC generator. The diesel engine takes air, compresses it and then injects fuel into the compressed air. The heat of the compressed air ignites the fuel spontaneously.

Separately bound manuals covering the diesel engine are available:

- [62-10865, V2203-DI Engine Workshop](#)
- [62-11695, V2203-DI Engine Parts List](#)

Figure 2.4 Generator and Engine - Unidrive Assembly




- | | |
|-------------------------|----------------------|
| 1) Generator | 4) Engine Shockmount |
| 2) Generator Shockmount | 5) Starter |
| 3) Engine | 6) Poly V-Belt |

2.4.1 Engine Fuel System

The engine fuel system (see [Figure 2.5](#)) is a closed circuit that injects a precise amount of atomized fuel into the engine cylinders. A mechanical lift pump initially transfers fuel at low pressure from the fuel tank and through the fuel shutoff valve. An optional in-line fuel strainer can be used prior to the fuel filter / water separator to trap large particles. The fuel filter / water separator removes water and finer particles and includes a 12-volt baldwin fuel heater. Low pressure fuel then enters the injection pump, where it is compressed to higher pressures and distributed to individual fuel lines that supply each cylinder's injector nozzle. The nozzles spray atomized fuel into the combustion chamber based on the timing of the injector pump. Any excess fuel in the nozzles not used for combustion is sent back to the fuel tank.

Figure 2.5 Fuel System Diagram




- | | |
|--|----------------------------|
| 1) Fuel Tank | 6) Injection Pump |
| 2) Fuel Tank Supply with Shutoff Valve | 7) Injector Nozzles (4) |
| 3) In-Line Fuel Strainer (option) | 8) Manual Fuel Bleed Valve |
| 4) Mechanical Lift Pump | 9) Fuel Tank Return |
| 5) Fuel Filter / Water Separator | |

The engine requires all air to be removed the system in order to run at optimal performance. The fuel system contains a fuel pump primer on the mechanical lift pump and an air bleed screw after the injection pump, if bleeding air from the system is required.

The engine fuel tank (see [Figure 2.6](#)) is available in 120 gallon capacity.

Figure 2.6 Fuel Tank




2.4.2 Electronic Governor

The electronic governor controls the speed of the engine by using an electronic governor (EG) module, fuel solenoid (FS) and engine speed sensor (ESS).

The electronic governor (EG) module (see [Figure 2.7](#)) is a solid state control module pre-programmed for 1800 RPM high speed operation and 1500 RPM low speed operation. It receives an input signal from the engine speed sensor (ESS) of the current RPM and compares this to a preset value. The electronic governor (EG) module sends a correction signal to the fuel solenoid (FS) to maintain the proper RPMs.

The electronic governor (EG) module is mounted in the control box and has an LED which may assist in diagnosing failures within the electronic speed control system. See [Section 5.4](#) for additional troubleshooting information.

Figure 2.7 Electronic Governor Module (EG)




2.4.3 Engine Lubrication System

The engine lubrication system (see **Figure 2.8**) supplies lubricating oil to the various moving parts in the engine. The main function is to enable the formation of a film of oil between moving parts, to reduce friction and wear.

The engine lubricating oil filter is mounted in a horizontal arrangement. The Oil Pressure Sender (OPS), located at the oil filter housing, senses lube oil pressure and transmits a signal to the Oil Pressure Gauge (OPG) located on the control panel (see **Figure 2.11**). The Low Oil Pressure (LOP) switch opens when engine lubricating oil pressure is observed below 1.27 kg/cm.

Figure 2.8 Engine Lubrication System



- 1) Oil Filter
- 2) Oil Pressure Sender (OPS)



- 3) Low Oil Pressure (LOP) Switch
- 4) Oil Dipstick / Fill Cap

2.4.4 Engine Air Cleaner System

The engine air cleaner system (see [Figure 2.9](#)) utilizes a filter element to filter the engine intake air. The air cleaner effectively removes contaminants from the air stream, resulting in prolonged engine life and reduced wear on all operating engine parts. When a dry element air filter is utilized, an air filter indicator is mounted on the air filter body to indicate when the filter element needs to be replaced.

As air exits the air cleaner, it passes through the air intake heater (IH) and then enters the engine cylinder. This is done to help the engine start in cold temperatures.

Figure 2.9 Engine Air Cleaner




- 1) Air Cleaner, Dry Element
- 2) Air Filter Indicator

- 3) Air Inlet Hose
- 4) Air Intake Heater

2.4.5 Engine Cooling System

The engine cooling system (see [Figure 2.10](#)) uses extended life coolant and a radiator to keep the engine from overheating. The radiator transfers the heat from the engine coolant to the surrounding air. The water pump and the radiator cooling fan are belt-driven from the engine crankshaft. The High Water Temperature Switch (HWT) and Water Temperature Sender (WTS) monitor and regulate cooling water temperature.

Figure 2.10 Engine Cooling System



- | | |
|----------------------------|--|
| 1) Radiator assembly | 4) High Water Temperature Switch (HWT) |
| 2) Radiator fill cap | 5) Water Temperature Sender (WTS) |
| 3) Coolant recovery bottle | |
-

2.5 Battery and Battery Charging System

The battery provides 12 VDC power to the starter motor. It also provides the initial voltage for the intake heater (IH) until the unit starts. The solid state battery charger is powered by the generator, and this input is protected by fuses located in the receptacle box. The battery charger produces a tapered charge (40 amps maximum) and is designed not to overcharge the battery. See [Figure 2.2](#) for location of components.

2.6 Control Panel and Control Box Components

The control panel and control box (see [Figure 2.11](#)) contain components required for monitoring and controlling the generator set unit.

2.6.1 Water Temperature Gauge

The water temperature gauge (WTG) observes water operating temperature. Once the unit has achieved normal running temperature, the coolant temperature is between 82 - 96°C. The high water temperature (HWT) switch senses engine water temperature and transmits a signal to the water temperature gauge (WTG).

2.6.2 Oil Pressure Gauge

The oil pressure gauge (OPG) observes normal operating engine oil pressure. Normal oil pressure is 3.3 to 5.2 kg/cm². The oil pressure sender (OPS) (see [Figure 2.8](#)), located at the oil filter housing, senses lube oil pressure and transmits a signal to the oil pressure gauge (OPG).

2.6.3 Total Time Meter

The total time meter (TT) calculates the total hours the unit has been running, which provides an accurate readout of accumulated engine running time. This data can be used to establish proper maintenance schedules (refer to [Table 6-1](#)).

2.6.4 Ammeter

The ammeter (A) indicates the rate of charge or discharge of the battery charging system. The battery charging system is composed of the battery and the battery charger, either solid state or alternator. During start up, the intake heater (IH) draws approximately 42 amps.

2.6.5 Intake Heater Switch

The intake heater switch (HS) is a momentary switch. When held in the PREHEAT position, the switch allows approximately 42 amps of battery current to flow into the intake heater, which preheats the air within the intake manifold and allows the engine to start. After starting the engine, the intake heater switch should continue to be held in the ON position for approximately 5 seconds until the engine has developed enough oil pressure to close the oil pressure safety switch.

2.6.6 Ignition Switch

The ignition switch (IGN) is a momentary switch that has OFF/ON/START positions. When held in the START (ignition) position, it energizes the starter motor solenoid, which in turn allows the starter motor to crank the engine. The switch is released to the RUN position once the engine has started.


2.6.7 Intake Heater Timer

The intake heater timer (IHT) continues to supply power to the intake heater (IH) for 3 minutes after initial start-up.

2.6.8 Starter Solenoid Timer

The starter solenoid timer (SST) limits the amount of time that the starter can be engaged to 15 seconds. If the starter is manually engaged for more than 15 seconds, power will be cut to the starter. Once power has been removed, the starter can again be engaged for up to 15 seconds.

Figure 2.11 Control Panel and Control Box




- 1) Water Temperature Gauge (WTG)
- 2) Oil Pressure Gauge (OPG)
- 3) Total Time Meter (TT)
- 4) Ammeter (A)
- 5) Intake Heater Switch (HS)
- 6) Ignition Switch (IGN)
- 7) Starter Solenoid Relay (SSR)
- 8) Safety Relay (S)

- 9) Intake Heater Relay (HR)
- 10) Circuit Breaker (CB2)
- 11) Circuit Breaker (CB3)
- 12) Circuit Breaker (CB4)
- 13) Starter Solenoid Timer (SST)
- 14) Intake Heater Timer (IHT)
- 15) Ground Studs
- 16) Electronic Governor Module (EG)

2.7 Receptacle Box Components

The Receptacle box (see [Figure 2.12](#)) contains components required for monitoring and controlling the Genset unit.

Figure 2.12 Receptacle Box



- 1) Access Cover
- 2) Circuit Breaker (CB1) Genset
- 3) Receptacle
- 4) Voltage Controller (VC)
-
- 5) Voltage Controller Fuse (VCF1)
- 6) Voltage Controller Fuse (VCF2)
- 7) Battery Charger Fuse (BCF3)

2.8 Safety Devices

Safety devices, such as circuit breakers, fuses, and safety switches, protect system components from damage.

The AC generator, solid state battery charger, fuel heater, high water temperature, safety relay, total time meter and intake heater are protected by circuit breakers. If a safety device opens and there is an interruption of electrical current, the electronic governor module will be de-energized, which will also de-energize the fuel solenoid, interrupt the fuel flow to the engine and stop the engine.

Safety device specifications are provided in [Table 2-1](#).

Table 2–1 Safety Devices

Engine	
Unsafe Condition:	Low engine lubricating oil pressure.
Safety Switch	Low oil pressure (LOP) switch - Automatic reset
Switch Setting	Opens below 18 psig (1.27 kg/cm ²)
Unsafe Condition:	High engine cooling water temperature.
Safety Switch	High water temperature (HWT) switch - Automatic reset
Switch Setting	Opens at 110°C (230°F)
Unsafe Condition:	Excessive current draw by the safety relay, fuel heater, water temperature gauge, oil pressure gauge or total time meter.
Safety Switch	Circuit breaker (CB-2) - Automatic reset
Switch Setting	Trips at 30 amps
Unsafe Condition:	Excessive current draw by the electronic governor module.
Safety Switch	Fuse 1, 2, 3 (replace)
Switch Setting	Trips at 10 amps
Intake Heater	
Unsafe Condition:	Excessive current draw on intake heater circuit
Safety Switch	Circuit breaker (CB-3) - Automatic reset
Switch Setting	Trips at 50 amps
Battery Charger	
Unsafe Condition:	Excessive current draw on 12 volt supply circuit.
Safety Switch	Circuit breaker (CB-4) - Automatic reset
Switch Setting	Trips at 50 amps
Unsafe Condition:	Excessive current draw on 460 volt feed circuit
Safety Switch	Fuse BCF3
Switch Setting	Trips at 5 amps
Generator	
Unsafe Condition:	Excessive current draw by load
Safety Switch	Circuit breaker (CB-1, 460 volt) - Manual reset
Switch Setting	Trips at 26 amps (460 VAC)
Voltage Controller	
Unsafe Condition:	Excessive current draw on 460 volt feed circuit
Safety Switch	Fuses VCF1, VCF2
Switch Setting	Trips at 5 amps

2.9 Unit Specifications

Table 2-2 Fuel Tank

Capacity:	Nominal tank size: 120 gallon
	Fill capacity: 120 gallon
	Draw capacity: 119 gallon (Allows for DOT required 5% vapor space)
Unit Weight:	Engine (Dry) without accessories: 1929 lb (875 kg) approximate

Table 2-3 Generator

Output:	15 KW, 18.75 KVA, 0.8 pf KW
Output Voltage:	400-500 VAC @ 60 Hz; 360-460 VAC @ 50 Hz
Speed:	1800 RPM @ 60 Hz; 1500 RPM @ 50 Hz
Weight:	267 lb (121 kg)
Part Number:	54-00738-20

Table 2-4 Engine Data

Bore / Stroke:	3.26 in (83 mm) / 4.03 in (102.4 mm)
Compression Ratio:	22.0 to 1
Cylinders (Number):	Four
Displacement:	135.2 cubic in (2.22 liters)
Firing Order:	1-3-4-2
Screw Threads:	All threads are metric, except for the oil drain plug which is American Standard Pipe Thread (NPT).
Weight (Dry):	439 lb (199 kg) approximate
Lubrication System:	<p>Oil pressure: 35 to 60 psig (3.3 to 5.2 kg/cm²)</p> <p>Oil pressure safety switch setting opens: 18 psig (1.27 kg/cm²)</p> <p>Capacity: Engine - 15.0 US quarts (14.2 liters), includes standard filter.</p> <p>Oil level indicator: Dipstick in oil pan or fill cap</p> <p>NOTE:</p> <p>To check oil level on engines with the dipstick mounted in the fill cap, remove the cap and wipe the dipstick clean. Insert the cap back onto the oil fill tube, then remove to check level. It is not necessary to screw the cap back into the fill tube when checking level. DO NOT add oil if level is within the "safe" range. If needed, add oil to bring level within the "safe" range. Screw cap fully into fill tube after checking level.</p> <p>Lube oil specification: Use a heavy duty lubricating oil conforming to American Petroleum Institute (API) Service Classification CF or better.</p>
	<p>Lube oil viscosity:</p> <p>For outdoor temperatures 0 to 45°F (-18° to 7°C): SAE: 10W30 or Mobile Delvac 1*</p> <p>For outdoor temperatures above 45°F (7°C): SAE: 10W30 or 15W40 or Mobile Delvac 1*</p> <p>* Mobile Delvac 1, 5W-40 or 15W-40 is the only approved synthetic oil.</p>

Table 2–4 Engine Data (Continued)

Fuel and Fuel Heater Thermostat (FHT):	
	Fuel, Winter: Diesel No. 2 with winter blends
	Fuel, Summer: Diesel No. 2
	FHT, Winter: Close on temperature fall @ $45 \pm 6.5^{\circ}\text{F}$ ($7.2 \pm 3.6^{\circ}\text{C}$)
	FHT, Summer: Open on temperature rise @ $75 \pm 6.5^{\circ}\text{F}$ ($23.8 \pm 3.6^{\circ}\text{C}$)
	Power consumption: 150 Watts @ $\pm 10\%$ at 14 VDC
	Diesel fuel specification type and sulfur content % (ppm) used, must be compliant with all applicable emission regulations for the area in which the engine is operated. Since KUBOTA diesel engines of less than 56 kW (75 hp) utilize EPA Tier 4 and Interim Tier 4 standards, the use of ultra low sulfur fuel is mandatory for these engines, when operated in US EPA regulated areas. Therefore, please use No.2-D S15 diesel fuel. Ultra Low Sulfur Diesel (ULSD) 15 ppm or 0.0015 wt.%
Intake Heater:	Amperage - 42 amps at 12 VDC
	Resistance (cold) - Approx. 0.3 ohms
Horsepower:	24.8 HP @ 1800 RPM at sea level. (SAE J1995 Gross Power Rating)
Cooling System:	Capacity: 6 us quarts (5.68 liters) - includes 1 quart (0.95 liters) in coolant recovery bottle.
	Anti-Freeze: Extended Life The cooling system is factory charged with a 50/50 mix of extended life coolant (ELC) and deionized water. This mixture provides protection to -34°F (-37°C). For replacement, use Shell Rotella ELC Nitrite Free Pre-Diluted 50/50 antifreeze / coolant.
	Water temperature safety switch setting: Opens at $230 \pm 5^{\circ}\text{F}$ ($110 \pm 3^{\circ}\text{C}$)
	Resets at 200°F (93°C) - minimum
	Thermostat: Starts to open at 177 to 182°F (80 to 84°C)
	Fully open at 203°F (95°C)
	Low coolant sensor: Opens at loss of 32 ounces (907g) of coolant or more
	Closes at refilling of radiator to proper level

Section 3

Installation

WARNING

To prevent injury, the procedures provided for installation and removal of the generator set must be followed carefully.


WARNING

Disconnect the power plug before removing the generator set.

NOTICE

This generator set is equipped with special pins and mounting bolts and can be installed only on containers with matching installation points.

Figure 3.1 Generator Set Mounting - Pin Type with Locking Bracket



3.1 Installation

1. Place forks into the fork pockets of the generator set. Attach the safety chain (A) between fork pockets on the generator set and fork truck. Be sure the chain (A) is short enough to retain the generator set on the forks.
2. Line up the generator set with the refrigeration unit and container. Raise the generator set until the top is several inches above the top edge of the container. Move the generator set against the container and lower into position. Ensure the two pins (B) are fully engaged in the mating holes in the container.
3. Keep forks in the pockets on the generator set and tighten mounting bolt (C) on each side of the generator set into the container frame. Torque mounting bolts to 125 ± 25 ft-lbs (170 ± 4.7 Nm). Ensure the locking brackets (D) are locked into position so as to capture bolt heads (C) and prevent turning.
4. Upon completion, remove the safety chain (A) before removing the forks of the fork truck from the unit.

3.2 Removal

1. Move the forks into the fork pockets on the generator set. Attach the safety chain (A) between fork pockets on the generator set and fork truck.
2. Release the locking brackets (D) on each side of the generator set.
3. Remove the mounting bolt (C) on each side of the generator set and tighten into the threaded hole (E).
4. Raise the generator set several inches to disengage the pins (B) from the mating holes and remove from container.

Section 4

Operation

4.1 Starting and Stopping Instructions

4.1.1 Pre-Start Inspection

1. Check engine lubrication and fuel filters, oil lines, and connections for leaks. If required, tighten connections and/or replace gaskets.
2. Check the engine lubricating oil level (see [Table 2-4](#)).
3. Check the poly V-belt for fraying or cracks and proper tension (see [Section 6.4.10](#)).
4. Check the radiator hoses for leaks and check radiator coolant level (see [Table 2-4](#)).
5. Check the radiator coil and generator air intake screen for cleanliness. If required, clean using compressed air, reversing the normal air flow.
6. Check the air cleaner for cleanliness and clean if necessary (see [Section 6.4.11](#)).
7. Check the in-line fuel strainer and clean if necessary (see [Section 6.4.4](#)).
8. Drain water from the fuel filter bowl.
9. Fill the fuel tank with diesel fuel (see [Table 2-4](#)).
10. Check the air intake heater (IH) amperage (see [Table 2-4](#)).
11. Check the battery terminals for cleanliness and secureness. If required, clean, then coat with a battery terminal sealant.
12. Check and if required, tighten all electrical connections.
13. Check and if required, tighten all hardware (brackets, etc.).
14. Ensure that the main generator set circuit breaker (CB1) is in the OFF position. Connect the power cable to the refrigeration unit and proceed to [Section 4.1.2](#) for starting instructions.

4.1.2 Starting Instructions

Before start up, both the generator set circuit breaker (CB1) and the refrigerated unit should be OFF. After start up, the generator set should be run for at least two minutes to allow the power source to stabilize before supplying power to the refrigerated unit. This will eliminate the potential of any cold start transient spikes from reaching the refrigerated unit. Cold start transient spikes can potentially cause nuisance over voltage alarms on refrigerated units that are sensitive to electrical spikes or transients.

WARNING

Beware of moving poly V-belt, belt driven components and hot exhaust components.

WARNING

Under no circumstances should ether or any other unauthorized starting aids be used in conjunction with the air intake heater.

NOTICE

Piston rings in engines that have operated less than 100 hours may not be fully seated. This may lead to the possibility of oil seepage from the exhaust pipe. To properly seat the rings, operate the

engine under full load for a period of 24 hours. If the condition persists, check valve clearance when the engine is cold. (Refer to engine workshop manual listed in [Section 2.4](#)).

Procedure:

1. Make sure that circuit breaker CB-1 is in the OFF position.
2. Hook up the 460 volt cable from the refrigerated unit to the generator set receptacle.
3. Hold the intake heater switch (HS) in the PREHEAT position (see [Figure 2.11](#)) in the PREHEAT position. Suggested hold times for a cold engine are listed in the following table:

Table 4-1 Cold Engine Preheat Times

Ambient Temperature	Time
26°C	5 seconds
0°C to 26°C	10 seconds
-8°C to 26°C	20 seconds
Below -8°C	30 seconds

4. With the intake heater switch (HS) held in the PREHEAT position, place the ignition switch (IGN) in the START position.
5. After the engine has started, continue to hold the intake heater switch (HS) in the PREHEAT position until the engine develops sufficient oil pressure to close the oil pressure safety switch (approximately 5 seconds). When released, the intake heater switch (HS) will automatically return to the OFF position and the heater will remain energized for 3 minutes.

4.1.3 Post-Start Inspection

1. Allow the generator set unit to run for at least 2 minutes.
2. Turn on circuit breaker CB-1.
3. Check generator output with a volt meter. Voltage output at start up with no load at 50Hz operation should be 1500 RPM, 360-460 VAC. Voltage output may vary and fall with ISO specifications based on ambient (see [Table 2-3](#)).
4. Start the refrigeration unit.
5. Run the engine for 10 minutes and check total time meter operation.
6. Listen for abnormal bearing noise from the AC generator.
7. Check the fuel lines, lube oil lines, and filters for leaks.
8. Check the exhaust system for leaks.

4.1.4 Stopping Instructions

1. Place circuit breaker CB-1 in the OFF position.
2. Place the ignition switch (IGN) in the OFF position.

4.2 Sequence of Operation

With the intake heater switch (HS) held in the ON position, current flows through the ammeter to the intake heater (IH). While the heater is on, the ammeter will show an approximate 42-amp draw.

A second set of contacts also energizes the safety relay (S).

If the high water temperature switch (HWT) opens to break the safety relay ground connection, the safety relay (S) will not energize, and the engine will not start.

To start the engine, the ignition switch (IGN) is held in the START position. With the switch in the START position, current flows to the starter solenoid (SS), through the SS contacts to the starter motor (SM). Current then flows to the intake heater timer (IHT), intake heater relay (HR) and to the heater, while simultaneously powering the electronic governor module (EG), fuel solenoid (FS), and engine speed sensor (ESS).

The starter motor (SM) turns over the engine resulting in pumping of fuel to the engine cylinders by the injection pump. This fuel is ignited by heat of compression; thus starting the engine. When the engine has developed sufficient oil pressure, the low oil pressure (LOP) switch contacts close to maintain power to the safety relay (S).

Once the engine has started, the intake heater (IH) will remain energized for three minutes.

The ignition switch (IGN) will be released. The intake heater switch (HS) will be held for five seconds, then released after the ignition switch (IGN) is released. When the START switch is released, the starter will be disengaged.

With the engine running, the battery charger provides DC power to operate the control system and charge the battery.

Section 5

Troubleshooting

5.1 Diesel Engine

5.1.1 Engine Will Not Start

Condition	Possible Cause	Remedy / Reference Section
Starter motor will not crank or low cranking speed	Battery is insufficiently charged	Charge
	Battery terminal post or battery is defective	Check
	Electrical connections at starter are bad	Correct
	Starter motor malfunction	Section 5.1.4
	Starter motor solenoid is defective	Engine Manual
	Starting circuit is open	Section 5.1.5
	Lubricating oil is incorrect grade	Section 2.9
	Fuse F5 is bad	Replace
Starter motor cranks, but fails to start	Fuel tank is empty	Section 2.9
	Air inside the fuel system	Section 6.4.1
	Water inside the fuel system	Drain Sump
	Fuel filters are plugged	Replace
	Air intake heater is bad	Section 6.4.14
	Oil level is low; Oil pressure switch is defective	Section 6.4.7
	Heater switch is faulty	Section 6.4.15
	Fuel lines to injector(s) are plugged	Engine Manual
	Mechanical lift fuel pump malfunction	Engine Manual
	Fuses F1, F2, F3 are bad	Check / replace
Starter cranks and engages, but dies after a few seconds	Connection between wire harness and Electronic Governor Module (EG) is loose or bad	Check / correct
	Engine lube oil is too heavy	Table 2-4 .
	Starter cable(s) has voltage drop	Check

5.1.2 Engine Starts Then Stops

Condition	Possible Cause	Remedy / Reference Section
Engine stops after a few rotations	Fuel tank is empty	Section 2.9
	Intake heater switch is not held long enough	Hold switch
	Fuel filter is restricted	Replace
	Air cleaner or hose is restricted	Section 6.4.11
	Engine crankcase breather or hose is restricted	Section 6.4.12
	Safety device is open	Section 2.8

Condition	Possible Cause	Remedy / Reference Section
Engine stops after a few rotations	Wiring circuit to fuel solenoid is open	Check
	Fuel solenoid is defective	Replace
	Fuel supply is restricted	Section 2.9,Section 6.4.2
	Mechanical lift fuel pump malfunction	Engine Manual
	Oil level is low; Oil pressure switch is defective	Section 6.4.7
	Fuel system has leak	Check
	Injector nozzle(s) is defective	Engine Manual
	Injection pump is defective	Engine Manual
	Generator internal overloads are open	Table 2-1

5.1.3 Engine Will Not Shut Off

Condition	Possible Cause	Remedy / Reference Section
Engine will not shut off	Ground connection is loose	Clean / Tighten
	Fuel solenoid is improperly seated	Correct

5.1.4 Starter Motor Malfunction

Condition	Possible Cause	Remedy / Reference Section
Starter motor will not crank or turns slowly	Battery is insufficiently charged	Charge
	Battery cable connections are loose or oxidized	Check / Replace
	Battery cables are defective	Check / Replace
	Starter brushes are shorted out	Engine Manual
	Starter brushes hang up, defective or have no contact	Engine Manual
	Starter solenoid is damaged	Engine Manual
	Ignition switch is defective	Replace
	Engine lube oil is too heavy	Section 2.9
Starter motor turns, but pinion does not engage	Pinion or ring gear is obstructed or worn	Engine Manual
Starter motor does not disengage after switch has been released	Ignition switch is bad	Check / Replace
	Starter motor solenoid is bad	Engine Manual
Pinion does not disengage after engine is running	Starter is bad	Engine Manual

5.1.5 Malfunction In The Engine Starting Circuit

Condition	Possible Cause	Remedy / Reference Section
No power to starter motor solenoid	Battery is defective	Correct
	Electrical connections are loose	Tighten

Condition	Possible Cause	Remedy / Reference Section
Fuel solenoid does not energize or does not remain energized	Battery is defective	Correct
	Electrical connections are loose	Tighten
	Oil pressure switch is defective	Section 1.9
	Water temperature safety switch is open	Section 1.9
	Fuel solenoid is defective	Engine Manual
	Intake heater switch is bad	Check (Engine Manual)
	Electronic governor module (EG) is bad	Check / Replace (Section 6.4.14)
Intake heater does not energize	Intake heater switch is bad	Section 6.4.14
	Timer is bad	Section 6.4.14
	Heater element is bad	Section 6.4.14
	Heater relay is bad	Section 6.4.14

5.1.6 Miscellaneous Engine Troubleshooting

Condition	Possible Cause	Remedy / Reference Section
Loss of power	Air cleaner has restriction	Section 6.4.11
	Fuel system has air in it.	Section 6.4.11
	Air vent is restricted	Clean
	Fuel lines are restricted	Engine Manual
	Fuel injection pump is bad	Engine Manual
	Injector(s) are bad or incorrect type used	Engine Manual
	Fuel injection pump timing is incorrect	Engine Manual
	Valve timing is incorrect	Engine Manual
	Compression is poor	Engine Manual
Vibration	Engine shockmounts are bad	Replace
	Compression is poor	Engine Manual
Overheating	Air cleaner restriction	Section 6.4.11
	Exhaust pipe restriction	Remove
	Water jacket restriction	Engine Manual
	Radiator restriction	Section 6.4.5
	Coolant level is too low	Section 2.9
	Water pump is loose; alternator poly V-belt is loose	Section 6.4.10
	Thermostat is bad	Engine Manual
	Water pump is bad	Engine Manual
Excessive crankcase pressure	Crankcase breather line is plugged	Section 6.4.12

5.2 Battery Charger (Solid State)

Condition	Possible Cause	Remedy / Reference Section
CB4 trips when charger is turned on	Short in 12-volt wiring causing overload of charger	Locate and remove short or replace charger
Circuit breaker trips repeatedly, even when not connected	Internal short	Replace charger
Charger does not taper back after charging for a few minutes	Bad cell in battery	Test battery for defect according to battery manufacturer's instructions
	Charger is bad	Replace
Charger does not charge	BCF3 is open	Replace
	Charger is not receiving AC input	Use voltmeter to confirm charger is receiving 360-500 VAC. If not, check input connections/fuses.
	Charger output is not connected to 12 volt battery	Check output wiring connections to battery.
	Charger is bad	Replace
Low output voltage measured across charger output	Battery not connected to charger. It is normal to measure 12 volts or less across charger output with no battery connected	Check charging leads from charger to battery
Reverse polarity connection to battery has caused charger to stop charging	Internal DC fuse is blown and possible damage to current carrying components	Replace

5.3 Alternating Current Generator

Condition	Possible Cause	Remedy / Reference Section
No voltage	Rotor magnetism is lost	Replace
	Circuit breaker is tripped	Check CB1
	Open in stator windings	Replace
	Short circuited	Replace
	Worn drive gear is stripped	Check / Replace
	Contactor is not engaged	Replace
Low voltage	Engine speed is low	Section 6.4.12
	High resistance connections, connections are warm or hot	Tighten
	Rotor magnetism is lost	Replace
Fluctuating voltage (May be indicated by flickering lights)	Speed fluctuating	Section 6.4.12
	Engine speed is irregular	Engine Manual
	Terminal or load connections are loose	Tighten
	Bad bearing is causing uneven air gap	Replace
High voltage	Engine speed is excessive	Section 6.4.12

Condition	Possible Cause	Remedy / Reference Section
Overheating	Generator is overloaded	Check
	Vents / baffles are clogged	Check / Clean
	High temperature surrounding generator	Section 6.4.5
	Air circulation or recirculation is insufficient	Check / Clean
	Load is unbalanced	Balance
	Bearing is dry	Replace
Mechanical Noise	Bearing is bad	Replace
	Rotor is rubbing on stator	Replace
	Laminations are loose	Replace
	Coupling is loose or misaligned	Check drive gear
Generator frame produces shock when touched	Static charge	Check ground to frame

5.4 Electronic Governor Module

Fault	LED flash code	Possible Cause
Engine over speed: more than 2,530 RPM	One Long - One Short	ESS or mechanical engine problem
Actuator wiring disconnection. No signal from ESS for 2 seconds after RPM is greater than 1,000 RPM for 10 seconds, OR for 5 seconds while engine cranking (no voltage at EG pin 18).	Two Long - One Short	Short ESS or wiring problem
Speed sensor disconnection. Fuel / speed actuator (FS) wiring disconnected or open circuit. Coil resistance spec: 2.8 ohm ± 10%.	Two Long - Three Short	FS or wiring problem
EG supply voltage is greater than 26V.	Two Long - Seven Short	EG or alternator problem

5.5 Voltage Controller

The voltage controller has one green indicator light and one yellow indicator light. When the green light is illuminated, it means that the voltage controller is receiving power. The yellow light only illuminates (flashes) to indicate that there is a problem.

Green LED	Fault	Possible Cause / Remedy
LED not illuminated	No power to the voltage controller (VC)	Contactor failed
		Check line side power on contactors

Yellow LED flash Code	Fault	Possible Cause / Remedy
One Long - Three Short	Over voltage error	Engine speed, check
One Long - Four Short	Under voltage error	Engine speed, check

5.6 High Voltage Circuit, Electrical Troubleshooting

⚠️ WARNING

Before proceeding with troubleshooting, make sure to follow your company's standard safety procedures for working with electrical components.

Item	Checks	Potential Cause
Receptacle (R)	Check output voltage at Receptacle R (L1-L2, L2-L3, L1-L3) (50Hz: 360 - 460 VAC, and 60Hz: 400 - 500 VAC)	Faulty receptacle. Replace.
High Voltage Wires (from Circuit Breaker to Receptacle)	Check if wires / terminals are connected. Check continuity for each leg.	Loose connections. Tighten.
Circuit Breaker (CB)	Test the output power from circuit breaker CB (21-22, 22-23, 21-23).	Faulty circuit breaker. Replace.
	Verify circuit breaker (CB) is in the ON position.	Circuit breaker (CB) is in the OFF position.
	Test the input power to the circuit breaker CB (11-12, 12-13, 11-13).	
Voltage Controller (VC) and Fuses	Verify VCF1 fuse is not blown. Check continuity for each leg across fuse, outside of circuit; inside of circuit if not running.	Blown fuse. Replace.
	Verify VCF2 fuse is not blown. Check continuity for each leg across fuse, outside of circuit; inside of circuit if not running.	Blown fuse. Replace.
	Verify voltage controller has power (powered by high voltage). Verify green light is illuminated.	Faulty voltage controller, loose connections, faulty generator. Replace and tighten.
	Verify voltage controller has green light illuminated and yellow light flashing at 1 Hz. Yellow light flashing sequence other than at 1 Hz indicates a fault condition.	One Long / Two Short = voltage controller fault. This indicates a failed voltage controller. Replace.
		One Long / Three Short = over voltage error. Check engine speed.
		One Long / Four Short = under voltage error. Check engine speed.
		One Long / Five Short = hot start error. Reset power to the unit.
		One Long / Six Short = voltage controller fault. This indicates a failed voltage controller. Replace.
		One Long / Seven Short = voltage controller fault. This indicates a failed voltage controller. Replace.
	Verify that the connectors to the Voltage Controller are secured; snapped in place and do not easily pull out.	Check if the connectors are pushed in all the way.
		Remove connectors and inspect terminal pin insertion depth. Very depth is the same.
		Check to see if wires / terminals are connected.

Section 6

Service and Preventative Maintenance

6.1 Introduction

This section covers service for the generator set and general engine service. Refer to the Kubota engine workshop manual (see [Section 2.1](#)) for other engine servicing.

WARNING

Beware of moving poly V-belt, belt driven components and hot exhaust components.

6.2 Preventative Maintenance Schedule

A tabular listing of the recommended preventative maintenance activities and schedule is provided in [Table 6-1](#).

Table 6-1 Preventative Maintenance Actions and Schedule

Procedure	Manual Reference	Perform during Pre-Trip ¹	Perform every 2000 hrs service ²	Perform every 4000 hrs service ³
1. Check (in place) engine / generator shockmounts for cracks, cuts, abrasion or flaring.	Section 6.6.2	X	X	
2. Check engine lubrication oil and fuel lines, filters and connections for leaks.	-	X	X	X
3. Check engine lubrication oil level, add as required.	Section 2.9	X		
4. Check Poly V-belt for fraying or cracking. Replace as required.	Section 6.4.10	X	X	X
5. Check radiator hoses for leaks.	-	X	X	X
6. Check coolant level. Add 50/50 mix as required.	Section 2.9	X	X	X
7. Check radiator coil and generator air intake for cleanliness.	Section 6.4.5	X	X	X
8. Check Air Cleaner: For Dry Element air cleaner: Check for cleanliness and replace as filter indicator indicates.		X	X	X
9. Drain water from the fuel tank sump.	-	X	X	X
10. Drain water from the fuel filter bowl.	-	X	X	X
11. Fill the fuel tank with diesel fuel. Check fuel gauge operation.	Section 2.9	X	X	X
12. Check intake heater amperage.	Section 6.4.15	X	X	X
13. Check battery terminals for tightness and cleanliness.	-	X	X	X
14. Check for dirty loose electrical connections, frayed cables and cracked insulation.	-	X	X	X
15. Check and tighten as required all hardware, brackets etc.	-	X	X	X
16. Clean the mechanical fuel lift pump internal filter.	Section 6.4.2		X	X
17. Change in the line fuel strainer (option).	Section 6.4.4		X	X
18. Clean and coat terminals with battery terminal sealant.	-		X	X

Table 6–1 Preventative Maintenance Actions and Schedule (Continued)

Procedure	Manual Reference	Perform during Pre-Trip ¹	Perform every 2000 hrs service ²	Perform every 4000 hrs service ³
19. Change lubricating oil and filters (See NOTES)	Section 6.4.6		X	X
20. Tighten engine and generator mounting bolts.	Section 6.6.2		X	X
21. Tighten all electrical connections in the control box.	-		X	X
22. Check water pump bearing end play.	Engine Manual		X	X
23. Change the fuel filter.	Section 6.4.3		X	X
24. Check the crankcase breather.	Section 6.4.12		X	X
25. Remove and check engine / generator shockmounts for cracks, cuts, abrasion or flaring.	Section 6.6.2		X	X
26. Clean and flush the coolant system.	Section 6.4.5			X
27. Check the starter condition.	Engine Manual		X	X
28. Check engine compression.	Engine Manual		X	X
29. Check and adjust the injector nozzles.	Engine Manual		X	X
30. Perform generator maintenance.	Section 6.5		X	X
31. Check total time meter operation (allow engine to run 10 minutes).	-	X	X	X
32. Listen for abnormal noises.	-	X	X	X
33. Check fuel, lubricating oil and radiator coolant lines, connections and filters for leaks.	-	X	X	X
34. Check exhaust system for leaks.	-	X	X	X
35. Check Generator output with a voltmeter, should be 490 volts, ± 15 volts (engine, 1800 rpm) with a nominal frequency of 60Hz.	Section 6.5	X	X	X
36. Turn the refrigeration unit on and check generator 1800 rpm under full load.	Section 6.5	X	X	X
37. Verify operation of safety devices.	Section 2.8		X	X

NOTES ON LUBRICATING OIL AND FILTERS:

- Units have mineral oil installed from the factory. Change lubricating oil and filters after the first 2000 hours of service or at the end of the first year, whichever comes first.
- Oil changes after the first 2000 hour service, or 1 year:
 - If using mineral oil, oil changes should continue every 2000 hours of service or every 1 year, whichever comes first.
 - If using specified synthetic lubricating oil and OEM extended life oil filter, oil changes should be completed every 4000 hours of service, or every two years, whichever comes first.

¹ Pre-trip maintenance checks should be carried out prior to any use of the unit (1-15 and 31-36).

² 2000 hour maintenance checks should be carried out annually or every 2000 hours, whichever comes first.

³ 4000 hour maintenance checks should be carried out every two years or every 4000 hours, whichever comes first.

6.3 Battery Service

When replacing the battery, note if the unit was supplied with a mat in the battery tray. If so equipped, the mat must also be replaced. Orient battery cables approximately as shown in [Figure 6.1](#). When installing cables to battery, ensure the cables are not touching anything, and are floating in free air.

! CAUTION

Observe proper polarity when installing the battery or connecting a battery charger. The negative battery terminal must be grounded. Reverse polarity may damage the charging system. When charging the battery in unit, isolate the battery by disconnecting the negative battery terminal first, then the positive. Once the battery has been charged, connect the positive battery terminal first, then the negative.

Figure 6.1 Battery Cable Routing - Side View



6.4 Engine Service and Components

6.4.1 Bleeding the Fuel System

The fuel system is a closed circuit which will require bleeding if loss of fuel has occurred. To fill and bleed the system, do the following:

1. Turn the fuel bleed valve (see [Figure 2.5](#)) counterclockwise until fully opened.
2. Turn the top of the manual priming pump counterclockwise to unlock it, and then hand pump the manual plunger until a positive pressure (resistance) is felt. This will indicate fuel flow.
3. Depress and turn the top of the hand priming pump clockwise to lock in place.
4. Start the engine. See [Section 4.1](#).
5. When the engine is running properly, turn the fuel bleed valve clockwise until fully closed.

6.4.2 Servicing the Fuel Pump Internal Filter

The internal fuel filter may become plugged or restricted with foreign particles or wax, which can develop if the wrong grade of fuel is used or untreated fuel is used in cold weather, contaminating the fuel. If the internal filter is plugged, the engine will lose power. Therefore, the filter must be cleaned on a regular basis. The quality of the fuel will affect the filter cleaning schedule (see [Section 6.2](#)).

1. Turn the nut counterclockwise to loosen and remove
2. Remove the banjo fitting and let it hang loose.
3. Turn filter counterclockwise and remove. Check and clean.
4. To install, reverse steps 1 through 3.

6.4.3 Fuel Filter

The fuel filter is located on the generator set unidrive assembly (see [Figure 2.5](#)).

1. To replace the fuel filter, loosen and remove the filter housing.
2. Lightly oil new gasket with lube oil
3. Replace the filter.

NOTICE

If the generator set is equipped with the fuel filter bowl assembly, when replacing the fuel filter, a new fuel filter O-ring should be oiled and replaced, and then the clear bowl should also be tightened to 18 ft-lbs (24.4 Nm).

6.4.4 In-Line Fuel Strainer

1. Loosen the bowl by turning counter-clockwise.
2. To renew, remove the in-line fuel strainer.
3. Check and clean, and replace.

6.4.5 Cooling System

To ensure adequate cooling, the radiator must be clean, externally and internally. To service the cooling system, do the following:

1. Remove all foreign material from the radiator coil by reversing the normal air flow. Compressed air or water may be used as a cleaning agent. It may be necessary to use warm water mixed with any good commercial dishwasher detergent. Rinse coil(s) with fresh water if a detergent is used.
2. Drain coolant completely by opening the drain-cock and removing the radiator cap.

CAUTION

Never pour cold water into a hot engine.

3. Close the drain cock and fill the system with clean, untreated water to which between 3% and 5% of an alkaline base radiator cleaner should be added; 170 grams dry = 151 grams to 3.8 liters of water.
4. Run the engine 6 to 12 hours and drain the system while warm. Rinse the system three times after it has cooled down. Refill the system with water.

CAUTION

Use only ethylene glycol anti-freeze (with inhibitors) in system. Use of glycol by itself will damage the cooling system.

5. Run the engine to operating temperature. Drain the system again and fill with treated water / anti-freeze. See the above Caution statement.

6.4.6 Lube Oil Filter

The oil filter is located near the radiator fan (see [Figure 2.8](#)).

1. After warming up the engine, stop the engine, remove the drain plug from the oil reservoir and drain engine lube oil.
2. Replace the filters. Lightly oil the gasket on the filter before installing.
3. Add lube oil (see [Table 2-4](#)).
4. Warm up the engine and check for leaks.

6.4.7 Servicing Low Oil Pressure Switch

1. Remove harness connection from the low oil pressure (LOP) switch.
2. Remove the low oil pressure (LOP) switch from the engine.
3. Apply Teflon thread sealer to all threads of new the new switch.
4. Install the new switch.
5. Reconnect the harness connection to the new switch.

6.4.8 Engine Speed

The engine speed is electronically controlled. There are no adjustments.

NOTICE

Do not attempt to adjust engine speed.

6.4.9 Replacing the Engine Speed Sensor

1. Disconnect the plug to the sensor.
2. Remove the bolt securing the sensor to the housing.
3. Remove the sensor from the housing.
4. Clean the recess in the housing to ensure that the sensor seats properly when re-installed.
5. Reinstall the sensor, replace the securing bolt and connect the plug to the sensor.

6.4.10 Servicing the Poly V-belt

WARNING

Beware of moving poly V-belt, belt driven components and hot exhaust components.

WARNING

Beware of pinch points.

NOTICE

A frayed, cracked or worn poly V-belt must be replaced. After installing a new belt, check the adjustment after running the unit for three or four hours. This will allow for the initial stretch, which is common on new belts. Once this initial stretch has taken place, the belt should be checked at regular intervals.

The poly V-belt is driven by a sheave on the engine crankshaft. Its two functions are: (1) to drive the radiator fan and (2) to drive the water pump.

To replace the poly V-belt, perform the following steps:

1. Using the proper size socket, slowly rotate the crank on the crank pulley nut. At the same time, use a flat, blunt object to guide the belt off the crank pulley towards the radiator. Be careful not to damage grooves on the pulley.
2. Replace the poly V-belt by positioning the belt on the water pump pulley, and while rotating the engine (as in step 1.), use a flat, blunt object to guide the belt onto the crank pulley. Be careful not to damage grooves on the pulley or belt.

6.4.11 Engine Air Cleaner

The engine air cleaner uses a dry element filter (see [Figure 6.2](#)) to filter the engine intake air.

The engine air cleaner should be inspected regularly for leaks (see [Figure 2.9](#)). A damaged air cleaner or hose can seriously affect the performance and life of the engine. The air cleaner is designed to effectively remove contaminants from the air stream entering the engine. An excessive accumulation of contaminants in the air cleaner will impair its operation. Therefore, a service schedule must be set up and followed.

CAUTION

Always cover the engine inlet tube while the air cleaner is being serviced.

1. Check all connections for mechanical tightness. Be sure the air cleaner outlet pipe is not fractured.
2. In case of leakage, if adjustment does not correct the problem, replace necessary parts or gaskets. Swollen or distorted gaskets must always be replaced.

Air Filter Indicator


The air filter indicator, used with the dry element filter, is mounted on the air filter body. Its function is to indicate when the air cleaner dry element needs to be replaced. In operation, when a plugged air cleaner decreases intake manifold pressure to 500mm (20") WG, the indicator moves to the red line. The air cleaner element should be replaced and the indicator reset by pressing the reset button.

Air Cleaner, Dry Element Service

Refer to [Figure 6.2](#) for this procedure.

1. Stop the engine and open the cap clamps to remove the air cleaner bottom cap.
2. Remove the air filter element from the air cleaner body.
3. Install the new element, and secure the bottom cap with the cap clamps.

Figure 6.2 Air Cleaner, Dry Element



- | | |
|---------------------|-------------------------|
| 1) Air Outlet | 4) Cap Clamp |
| 2) Air Cleaner Body | 5) Air Outlet |
| 3) Air Inlet | 6) Air Filter Indicator |

CAUTION

When reassembling the air cleaner, make sure the clamp bolt faces out, away from the fuel filter. If the clamp bolt is assembled facing in, it can contact the fuel filter and cause excessive wear.

Air Cleaner Body Service

If there is any sign of contaminant buildup or plugging, the air cleaner body should be removed and back flushed. At least once a year, or at regular engine service intervals, remove the entire air cleaner and perform the following cleaning procedure:

1. Check and clean the center tube.

WARNING


Do not use gasoline to clean air cleaner parts.

2. Pump solvent through the air outlet with sufficient force and volume to produce a hard, even stream out of the bottom of the body assembly. Reverse flush until all foreign material is removed.

6.4.12 Engine Crankcase Breather

The engine uses a closed type breather (see [Figure 6.3](#)) with the breather line attached to the cylinder head cover. It is not necessary to disassemble valve style elements for cleaning. However, the bleed hole should be checked to ensure it is free of obstruction. Check once a year or every 4000 hours maintenance interval (whichever comes first).

Figure 6.3 Engine Crankcase Breather




- | | |
|-------------------|-------------------|
| 1) Breather Tube | 4) Breather Cover |
| 2) Breather Valve | 5) Bleed Hole |
| 3) Screw | ----- |

6.4.13 Intake Heater Test

Refer to [Figure 6.4](#) for this procedure

1. Disconnect the lead from the heater terminal.
2. Measure the resistance between the heater positive terminal and the heater body.
3. If the resistance is infinity or significantly different than the specification, resistance (cold) 0.3 ohms, replace the heater.

Figure 6.4 Intake Heater



1) Positive Terminal

2) Heater Body

6.4.14 Intake Heater Service

1. Remove the harness connection from the heater.
2. Remove the intake transition mounting hardware.
3. Remove the intake transition, heater and both gaskets.
4. Clean the old gasket material off the transition and manifold mounting services.
5. Install the new heater with a new gasket on either side.
6. Assemble transition to heater and torque mounting hardware (refer to engine manual for torque values).
7. Reconnect the harness to heater connection point.
8. Coat the stud on the heater with protective coating.

6.4.15 Intake Heater Switch

1. Remove the control box cover.
2. Remove all connections going to the Intake Heater Switch (HS).
3. Remove the HS from the control box.
4. Install the new HS.
5. Reconnect the wire harness connections to the HS.
6. Confirm the wires are connected to the correct terminals.
7. Reinstall the control box cover.

6.5 Servicing the AC Generator

6.5.1 Remove and Replace Procedure

The only serviceable parts on the generator are the torsional dampener, key, fan, and fan cover. If there is a problem with the generator, it should be replaced using the following procedure.

For Unidrive torque requirements, see [Section 6.7](#)

1. Remove the unit top and side panels in order to access the generator.
2. Disconnect the battery.
3. Remove the truss assembly center nuts and nut plate.
4. Remove the truss side bolts / washers and spacers (2), and remove the truss.

5. Remove the 3/8" bolt / washer that secures the wire harnesses and fuel lines to the top of the generator. Move the wire harnesses and fuel lines out of the way.
6. Remove the 1/4" bolts / washers (4) that secure the battery charger bracket to the unit frame. This will allow you to access the cables on the bottom of the battery charger.
7. Mark and disconnect the cables on the battery charger and remove the battery charger assembly from the unit.
8. Remove the bolts / washers (6) that secure the receptacle box to the unit. Wire-tie the receptacle box to the side of the unit so that the receptacle box is not hanging by the cables.
9. Remove the tape on the wire harness and cut the wires (5) that connect the receptacle box to the generator. Make sure to cut the wires on the receptacle box side of the current butt splices.
10. Remove the bolts / washers (2) that secure the generator support plate to the two generator shockmounts.
11. Remove the bolts / washers (3) that secure the lower radiator access panel (on the other side of the unit) in order to access the engine shockmounts.
12. Back off about 1 inch (25mm), but do not remove the engine shockmount bolts. This will allow the engine / generator to be slightly lifted off of the unit frame.

NOTICE

The generator / engine must be slightly lifted off of the unit frame in order to provide enough clearance for the generator support plate to slide away from the unit frame.

13. Using the lifting lugs on the top of the generator, lift the generator / engine several inches so that the generator support plate will clear the unit frame allowing the entire generator assembly to be removed.
14. Place several support beams under the engine and then lower the generator / engine onto the beams. Make sure that the generator support plate is lifted high enough to allow for the removal of the generator assembly, but not so high that the fan hits the radiator coil.
15. Starting with the lower bolts, remove the 3/8"-16 bolts / washers (12) that secure the generator to the engine.

NOTICE

Although the generator torsional dampener and flywheel adapter plate will normally keep the generator coupled to the engine, even without the bolts, it is safest to remove the lower generator bolts first, in case the generator shifts and falls during bolt removal.


16. Lift the generator assembly (generator & support plate) off the unit frame and lower onto a stable work surface.

NOTICE

Inspect the generator torsional dampener, bolt, and key as they are removed from the old generator and installed onto the new generator. Replace any components that are worn or damaged.

17. Remove the generator torsional coupler bolt / washer and pull off the torsional dampener.
18. Place the torsional dampener on the new generator shaft.
19. Insert the key into the keyway of the generator shaft. See [**Figure 6.5**](#).

Figure 6.5 Generator Shaft Keyway



20. Apply Loctite 262 to the generator coupler bolt. Install with washer and torque to 28 ft-lbs (38 Nm). See [Figure 6.6](#).

NOTE

In order to torque generator torsional dampener gear bolt, use a strap wrench or similar device to secure the dampener while torquing the bolt.

Figure 6.6 Generator Coupler Bolt



21. Remove the generator support plate from the old generator and install it onto the new generator.
22. With the torsional dampener and support plate installed on the new generator, lift and position the generator so that the generator mounting holes (12) are lined up with the engine mounting holes.
23. Insert two generator alignment bolts (2 1/2") to temporarily align / secure the generator to the engine. Tighten the bolts enough so that the torsional dampener on the generator is touching the aluminum housing on the engine. Do not over tighten the alignment bolts, as they will bottom out on the engine bell housing. See [Figure 6.7](#).

NOTICE


Align the torsional dampener and aluminum housing by rotating either one to seat correctly.

Figure 6.7 Generator Alignment Bolt



24. Once aligned, push the generator to fully seat the torsional dampener into the aluminum housing of the flywheel adaptor plate.
25. With the torsional dampener seated into the aluminum housing, the alignment bolts (2) can be removed, and the generator mounting bolts (12) can be reinstalled. Torque to 25 ft-lb (34 Nm). Install several mounting bolts to secure the generator before removing the alignment bolts. See [Figure 6.8](#).

Figure 6.8 Generator Mounting Bolts



NOTE

Although the torsional dampener and mating surface of the generator will generally keep the generator coupled to the engine, even with all of the bolts removed, it is safest to start installation of the top generator bolts first, just in case the generator shifts.

26. With all of the generator mounting bolts secured, use the lift to raise the generator / engine in order to remove the support blocks under the engine.
27. Place the generator support plate mounting bolts (2) down into the generator support plate in order to line up the mounting bolt holes with the shockmounts.
28. Ensure that the large washers placed on the shockmounts and slowly lower the generator / engine so that the generator support plate holes line up with the shockmount holes.
29. Remove the generator support plate bolts and install the bolts / large washers from the bottom of the shockmounts through the generator support plate. Secure the bolts (2) with nuts, torque to 75 ft-lb (102 Nm).

30. Tighten the engine shockmount bolts, torque to 90 ft-lb (122 Nm).
31. Replace the lower radiator access panel and secure with bolts / washers (3).
32. Secure the battery charger cables to the bottom of the battery charger.

! CAUTION

Observe proper polarity when installing the battery or connecting a battery charger, the negative battery terminal must be grounded. Reverse polarity may damage the charging system. When charging the battery in unit, isolate the battery by disconnecting the negative battery terminal first, then the positive. Once the battery has been charged, connect the positive battery terminal first, then the negative.

33. Secure the battery charger assembly to the unit frame.
34. Cut the wire-tie supporting the receptacle box to the unit frame and re-secure the receptacle box to the unit frame using bolts and washers (6). Make sure the receptacle wires are pulled through the access port in the frame and ensure that they will be accessible to splice with the generator wires.
35. Place two pieces of heat shrink tubing (1 large, 1 small) over each receptacle box wire.
36. Connect and butt splice the receptacle box harness wires with the new generator wires.
37. For each of the other five wires, heat shrink the small tubing first, and then the large tubing to ensure a watertight seal.
38. Neatly tape all wires together.
39. Replace and secure the wire harnesses onto the top of the generator, secure with the bolt.
40. Replace the truss and the truss brackets, secure the sides with the mounting bolts (2). See [Figure 6.11](#).

NOTE

Installing the two back truss bolts first allows the truss assembly to be pulled forward slightly, making it easier to install the two front truss bolts.

41. Secure the center of the truss to the isolator by installing the nuts (2) and nut plate (1).
42. Connect the battery.
43. Re-install the top and side panel covers

6.6 General Generator Set Maintenance

6.6.1 Maintenance of Painted Surfaces

The unit is protected against the corrosive atmosphere in which it normally operates by a special paint system. However, should the paint system be damaged, the base metal can corrode. If the paint system is scratched or damaged, do the following:

1. Clean area to bare metal using a wire brush, emery paper or equivalent cleaning method.
2. Immediately following cleaning, spray or brush on a zinc rich primer.
3. After the primer has dried, spray or brush on finish coat of paint to match original unit color.

6.6.2 Checking and Replacing Shockmounts


! CAUTION

Continued operation with failed shockmounts may result in engine or generator damage. When a shockmount has been cut, split, abraded or has flared due to normal deterioration, it must be replaced. Damage to the mounts may not be visible when installed and under load from the component. To correctly inspect shockmounts, they must be removed.

Generator Shockmount Replacement

1. Use the two lift eyes to lift and support the engine.
2. Remove shockmount hardware, [Figure 6.9](#).
3. Raise the generator just enough to remove the shockmounts.
4. Install new shockmounts.
5. Lower the engine enough to assemble hardware as shown and torque. Refer to [Section 6.7](#) for torque values.
6. Remove chains from the lift eyes.

Figure 6.9 Generator Shockmounts




- | | |
|----------------------|-----------------------|
| 1) Generator | 12) Flat Washer (5/8) |
| 2) Lock-nut (5/8) | 13) Mounting Base |
| 3) Flat Washer (5/8) | 14) Lockout (1/2) |
| 4) Support Plate | 15) Flat Washer (1/2) |
| 5) Screw (3/8) | 16) Flat Washer (5/8) |
| 6) Flat Washer (3/8) | 17) Screw (5/8) |
| 7) Shockmount | 18) Snubbing Washer |
| 8) Shockmount | 19) Screw (1/2) |
| 9) Support Plate | 20) Frame |
| 10) Frame | 21) Flat Washer (3/8) |
| 11) Locknut (5/8) | 22) Locknut (3/8) |

Engine Isolator / Shockmount Replacement

1. Use the two lift eyes to lift and support the engine.
2. Remove truss, unidrive isolator and all hardware as shown in [Figure 6.11](#).
3. Remove all hardware as shown in [Figure 6.10](#).


4. Raise the engine just enough to remove the shockmounts.
5. Inspect shockmounts and replace if required.
6. Lower the engine enough to assemble hardware as shown and torque per **Section 6.7**.
7. Remove chains from the lift eyes.

Figure 6.10 Engine Shockmounts



- | | |
|--------------------|--------------------|
| 1) Shockmount | 5) Snubbing Washer |
| 2) Snubbing Washer | 6) Shockmount |
| 3) Bolt | 7) Flat Washer |
| 4) Lock Washer | |

Figure 6.11 Truss and Isolator



- | | |
|----------------|----------------|
| 1) Truss | 7) Locknut |
| 2) Bolt | 8) Heat Shield |
| 3) Lock Washer | 9) Isolator |
| 4) Flat Washer | 10) Nutplate |
| 5) Frame | 11) Truss |
| 6) Unidrive | |


6.7 Unidrive Torque Requirements

Extensive damage may occur if the proper hardware is not used and/or proper procedures are not followed when working with the unidrive assembly. Periodic inspection of hardware and bolt torque is recommended to ensure the integrity of the unidrive. Torque value and hardware requirements for unidrive assembly are provided in [Figure 6.12](#).

NOTICE

SST is an abbreviation for 300 Series Corrosion Resistant Steel. Loctite #242 or an equivalent product should be used on ALL hardware shown in [Figure 6.12](#).

Figure 6.12 Unidrive Torque Requirements



Section 7

Schematics

Introduction

This section contains the 12 volt DC control circuit schematics and the 460 volt alternating current schematics.


Figure 7.1 Schematic Legend

LINE	SYMBOL	LEGEND
7	◎	SPLICE
3,4,9,10,13	— —	ENGINE GROUND
2	A —	AMMETER
2	BAT —	BATTERY
13,14	BC —	BATTERY CHARGER
2,5,8	CB —	CIRCUIT BREAKER
12	D —	DIODE
6	EG —	ELECTRONIC GOVERNOR MODULE
5	ESS —	ENGINE SPEED SENSOR
5,6,7,8	F —	FUSE
6	FS —	FUEL SOLENOID
8	FHT —	FUEL HEATER, INTEGRATED
2,10	HR —	INTAKE HEATER RELAY
3,4	HS —	HEATER SWITCH
4	HWT —	HIGH WATER TEMP. SWITCH
7,8	IGN —	IGNITION SWITCH
3	IH —	INTAKE HEATER
10	IHT —	INTAKE HEATER TIMER
5	LOP —	LOW OIL PRESS. SWITCH
9	OPG —	OIL PRESSURE GAUGE
9	OPS —	OIL PRESSURE SENDER
4,7	S —	SAFETY RELAY
2	SM —	STARTER MOTOR
—	SP —	SPLICE POINT
2,9	SS —	STARTER SOLENOID
9,10	SSR —	STARTER SOLENOID RELAY
9	SST —	STARTER SOLENOID TIMER
11	TT —	TIME METER
12	VC —	VOLTAGE CONTROLLER
10	WTG —	WATER TEMP. GAUGE
10	WTS —	WATER TEMP. SENDER

Section 7

Schematics Page 2


Figure 7.2 Schematic 12VDC Control Circuit



Section 7

Schematics Page 3

Figure 7.3 Schematic High Voltage Circuitry



Index

Numerics

54-00738-20 2-13

A

AC Generator 2-3
Air Cleaner Body 6-7
Air Cleaner, Dry Element 6-6
Air Filter Indicator 6-6
Alternating Current Generator Troubleshooting 5-4

B

Battery 2-9
Battery Charger 2-9
Battery Charger (Solid State) Troubleshooting 5-4
Battery Service 6-3
Bleeding the Fuel System 6-3

C

CE mark 2-1
CE verification 2-1
Circuit Breaker Location
 CB1 2-11
 CB2, CB3, CB4 2-10
Configuration Identification 2-2
Control Box Components 2-10
Control Panel Components 2-10
Cooling System 6-4

D

Diesel Engine Troubleshooting 5-1

E

Electronic Governor Module (EG) 2-5
Electronic Governor Module Troubleshooting 5-5
Engine Air Cleaner 2-7
Engine Air Cleaner, Air Filter Indicator 2-7
Engine Air Cleaner, Air Intake Heater (IH) 2-7
Engine Air Cleaner, Dry Element Air Filter 2-7
Engine Air Cleaner, Location and Components 2-7
Engine Cooling System 2-8
Engine Cooling System, High Water Temperature Switch (HWT) 2-8
Engine Cooling System, Location and Components 2-8
Engine Cooling System, Radiator 2-8
Engine Cooling System, Water Temperature Gauge (WTG) 2-9

Engine Cooling System, Water Temperature Sender (WTS) 2-8

Engine Crankcase Breather 6-7
Engine Fuel System 2-4
Engine Fuel System, Fuel Filter / Water Separator 2-4
Engine Fuel System, Fuel Tank 2-5
Engine Fuel System, Injection Pump 2-4
Engine Fuel System, Injector Nozzles 2-4
Engine Fuel System, In-Line Fuel Strainer 2-4
Engine Fuel System, Location and Components 2-4
Engine Fuel System, Mechanical Lift Pump 2-4
Engine Lube System 2-6
Engine Lube System, Location and Components 2-6
Engine Lube System, Low Oil Pressure (LOP) 2-6
Engine Lube System, Oil Pressure Gauge (OPG) 2-9
Engine Lube System, Oil Pressure Sender (OPS) 2-6
Engine Service and Components 6-3
Engine Speed Sensor (ESS) 2-5
Engine Starts Then Stops 5-1
Engine Will Not Shut Off 5-2
Engine, Description 2-3
Engine, Introduction 2-1

F

First Aid 1-1
Fuel Filter 6-3
Fuel Solenoid (FS) 2-5
Fuse Location
 VCF1, VCF2, BCF3 2-11

G

Generator Set Components 2-1
Generator Set Components - Covers Removed 2-2
Generator Set Identification 2-2

I

Ignition Switch (IGN) 2-9
In-Line Fuel Strainer 6-4
Intake Heater Switch 6-8
Intake Heater Switch (HS) 2-9
Intake Heater Test 6-7
Intake Heater Timer (IHT) 2-9
Introduction 2-1

L

Lube Oil Filter 6-4

M

Maintenance Precautions 1–1
Malfunction In The Engine Starting Circuit 5–2
Miscellaneous Engine Troubleshooting 5–3

O

Operating Precautions 1–1

P

Painted Surfaces 6–12
Post-Start Inspection 4–2
Pre-Start Inspection 4–1
Preventative Maintenance Schedule 6–1

R

Receptacle Box 2–11

S

Safety devices 2–11
Safety Notices 1–1
Schematic Diagram 7–2, 7–3
Sequence of Operation 4–2

Servicing Fuel Pump Internal Filter 6–3
Specific Hazard Statements 1–1
Starter Motor Malfunction 5–2
Starter Solenoid Timer (SST) 2–9
Starting and Stopping Instructions 4–1
Stopping Instructions 4–2

T

Total Time Meter (TT) 2–9
Troubleshooting 5–1

U

Unidrive Assembly Components 2–3
Unidrive Torque 6–15
Unit Nameplate 2–2
Unit Specifications, Engine Data 2–13
Unit Specifications, Fuel Tank 2–13
Unit Specifications, Generator 2–13

V

Voltage Controller (VC) 2–3
Voltage Controller Troubleshooting 5–5



Carrier Transicold Division,
Carrier Corporation
P.O. Box 4805
Syracuse, NY 13221 USA

<https://www.carrier.com/container-refrigeration>