INDUCED-COMBUSTION GAS FURNACE

PARTS REPLACEMENT INFORMATION GUIDE

CASING GROUP
Control door
Blower door
Top filler plate
Bottom filler plate
Condensate trap

HEAT EXCHANGER GROUP
Primary HX w/cell panel
Secondary HX assembly
Transition box

ELECTRICAL GROUP
Control box
Junction box
Limit switch(es)
Circuit board
Door switch
Transformer
Wiring harness
5-amp fuse
Over-temperature switch

INDUCER GROUP
Pressure switch(es)
Inducer motor assembly

BLOWER GROUP
Blower assembly
Blower housing
Blower motor
Blower wheel
Capacitor
Capacitor strap
Control module

GAS CONTROL GROUP
Manifold
Burner
Orifice
Flame sensor
Hot surface igniter
Gas valve

FILTER GROUP
Filter(s)

TO OBTAIN INFORMATION ON PARTS: Consult your installing dealer or the classified section of your local telephone directory under the “Heating Equipment” or “Air Conditioning Contractors and Systems” headings for dealer listing by brand name, or contact:

Carrier Corporation
Consumer Relations Department
P.O. Box 4808
Syracuse, New York 13221-4952
1-800-CARRIER

Have available the Product No., Model No., Series Letter, and Serial No. located on the unit rating plate to ensure correct replacement part.

Example of Product Number

MODEL	HEATING SIZE	VARIATION	VOLTAGE	SERIES	PACKAGING	COOLING AIRFLOW CFM
58HDV	060	--	1	0	1	12

WARNING: Improper installation, adjustment, alteration, service, or maintenance can cause personal injury, property damage, or death. Consult a qualified installer, service agency, or your local gas supplier for information or assistance. The qualified installer or service agency must use only factory-authorized replacement parts, kits, or accessories when modifying this product.

© 2009 Carrier Corporation, 7310 W. Morris St. Indianapolis, IN 46231