INSTALLATION INSTRUCTIONS

UNIT BUMPER

UNIT PREPARATION:

TOP BUMPER:

- 1.0 REMOVE RUBBER PLUGS (2) FROM TOP REAR FRAME POSTS. DISCARD PLUGS.
- 2.0 REMOVE SCREW AND RIVNUT ATTACHING AIR CLEANER BRACKET (AS INDICATED) USING 3/8 DRILL BIT, DISCARD SCREW AND RIVNUT.

BOTTOM BUMPER:

1.0 REMOVE SCREW AND RIVNUT (AS INDICATED) ATTACHING RADIATOR SHROUD, RETAIN SCREW, DISCARD RIVNUT.

UPDATED SHEET INDEX. SEE SHEETS 2 AND 3 PER PCA72N224GP04.

REVISED NOTE 2.0 "DISCARD SCREW" WAS "RETAIN SCREW"

INITIAL RELEASE PER NPR727217GN


REVISION RECORD

UPDATED SHEET INDEX; SEE SHEET 3

PER PCA728039G

2.0 OPEN MICRO DOOR BY REMOVING (2) SCREWS (AS INDICATED),
RETAINING SCREWS, REMOVE (2) RIVNUTS FROM FRAME USING 3/8 DRILL BIT. DISCARD RIVNUTS.

NOTE: IF TRAILER HAS MOUNTING BOLTS PROTRUDING FROM THE FRONT WALL,
THEN ALL UNIT PREPARATON AND BUMPER INSTALLATION MUST BE DONE
WITH THE UNIT DETACHED FROM THE TRAILER (OTHERWISE THE TRAILER
STUDS WILL DAME) THE UNIT FRAME).



TITLE

2007

AUG 25

09/17/98

05/06/97

DATE

02/27/97 SUPERSEDES

2004

ZMG

DLD

MED

MED

DRAWN BY

APPLICATION DATE

DATE

ENGRG.

В

SYM

SHEET

INDEX

DRAWING NO.

REV

SHEE"

98-03176

DDD

SHEET 1 OF 3

REV

BUMPER ASSY

REMOVE (4) RUBBER PLUGS


DISCARD PLUGS.


INSTALLATION PROCEDURE:

TOP BUMPER:

*NOTE: BOTH UPPER SIDE DOORS MUST BE OPENED TO CLEAR J-LATCHES FROM THE FRAME PRIOR TO INSTALLING BUMPER ASSEMBLY.

- 1.0 REMOVE (4) RUBBER PLUGS FROM BUMPER ASSY (AS INDICATED).
- 2.0 INSTALL BUMPER ASSY BY SLIDING BUMPER CHANNELS INTO TOP OF REAR FRAME TUBES.
- 3.0 USING BUMPER AS A TEMPLATE, DRILL (2) 7/16 DIA HOLES THRU EACH CONDENSER
- 4.0 INSTALL SPACERS (IT.18) QTY.2, BETWEEN BOTTOM OF BUMPER ASSY AND TOP OF EACH CONDENSER SUPPORT.
- 5.0 INSTALL SCREWS (IT.6) QTY.2, WASHERS (IT.10) QTY.2, TO TOP OF BUMPER ASSY THRU SPACER AND CONDENSER SUPPORTS. INSTALL WASHER (IT.10) QTY.2 AND LOCKNUT (IT.8) QTY.2.
- 6.0 DO NOT FULLY TIGHTEN HARDWARE UNTIL UNIT IS INSTALLED ON TRAILER.
- 7.0 ONCE BUMPERS ARE IN PLACE, INSTALL UNIT ON TRAILER USING NORMAL MOUNTING HARDWARE TO TIGHTEN THE BUMPER AND UNIT TO TRAILER.
- 8.0 FULLY TIGHTEN BUMPER HARDWARE FROM STEP 6.0.





1				1	ı	1	1 1
D	PICTORIALLY UPDATED BUMPER ASSY PER PCA72N221GP07					ZMG	15 MAY 2007
С	PICTORIALLY UPDATED BUMPER ASSY PER PCA72N224GP04.					ZMG	AUG 25, 2004
Α	ADDED ITEM 13.					MED	05/06/97
-	INITIAL RELEASE PER NPR727217GN					MED	02/27/97
SYM	REVISION RECORD	ENGRG.	DATE	APPLICATION ENGRG.	DATE	DRAWN BY	DATE

TITLE

SUPERSEDES

(18)TOP BUMPER MTG

NOTE: IF TRAILER HAS MOUNTING BOLTS PROTRUDING FROM THE FRONT WALL, THEN ALL UNIT PREPARATON AND BUMPER INSTALLATION MUST BE DONE WITH THE UNIT DETACHED FROM THE TRAILER (OTHERWISE THE TRAILER STUDS WILL NOT ALLOW THE BUMPERS TO SLIDE DOWN INSIDE THE UNIT FRAME).

18	48-60072-00	SPACER	2		
13	34-00918-08	SCREW, HEX WASH 1/4-20 X 1.00	1		
10	34-00366-13	WASHER, PLAIN 3/8	4		
8	34-00361-13	NUT, SELF LOCK 3/8-16	2		
6	34-00304-40	SCREW, CAP HXHD 3/8-16 X 5.00 LG.	2		
ITEM	PART NO.	DESCRIPTION			
ABOVE ITEMS SUPPLIED WITH KIT P/N.:76-00524-00					

INSTALLATION INSTRUCTIONS UNIT BUMPER

98-03176 D SHEET 2 0

PRINT DISTRIBUTION


UNIT BUMPER


INSTALLATION PROCEDURE:


BOTTOM BUMPER:

*NOTE: BOTH LOWER SIDE DOORS MUST BE OPENED TO CLEAR J-LATCHES FROM THE FRAME PRIOR TO INSTALLING BUMPER ASSEMBLY.

- 1.0 REMOVE (4) RUBBER PLUGS FROM BUMPER ASSY (AS INDICATED).
- 2.0 INSTALL BUMPER ASSY BY SLIDING BUMPER CHANNELS INTO BOTTOM OF REAR FRAME TUBES.
- 3.0 ALIGN HOLES IN BUMPER ASSY WITH HOLES IN PALLET MOUNTING TABS.
- 4.0 INSTALL SPACERS BETWEEN TOP OF BUMPER ASSY AND BOTTOM OF EACH PALLET MOUNTING TAB. ON UNITS BUILT IN AUGUST 1998 OR EARLIER THE SMALL (IT.15) AND LARGE (IT.14) SPACERS MUST BE STACKED TOGETHER. ON UNITS BUILT SEPTEMBER 1998 OR LATER USE ONLY THE LARGE (IT.14) SPACER AND DISCARD THE SMALL (IT.15) ONES.
- 5.0 INSTALL SCREWS (IT.4) QTY.2, WASHERS (IT.10) QTY.2 THRU BOTTOM OF BUMPER ASSY, SPACER AND PALLET MTG TABS. INSTALL WASHER (IT.10) QTY.2 AND LOCKNUT (IT.8) QTY.2.
- 6.0 INSTALL RIVNUTS (IT.16).
- 7.0 DO NOT FULLY TIGHTEN HARDWARE UNTIL UNIT IS INSTALLED ON TRAILER.
- 8.0 ONCE BUMPERS ARE IN PLACE, INSTALL UNIT ON TRAILER USING NORMAL MOUNTING HARDWARE TO TIGHTEN THE BUMPER AND UNIT TO TRAILER.
- 9.0 FULLY TIGHTEN BUMPER HARDWARE FROM STEP 7.0.







С	PICTORIALLY UPDATED BUMPER ASSY PER PCA72N22GGP07					ZMG	15 MAY 2007
С	PICTORIALLY UPDATED BUMPER ASSY PER PCA72N224GP04.					ZMG	AUG 25, 2004
В	ADDED ITEM 15; CHANGED ITEM 14, -26 WAS -27; MODIFIED INSTALLATION PROCEDURE NOTE 4.0. PER PCA7280396					DLD	09/17/98
SYM	REVISION RECORD	ENGRG.	DATE	APPLICATION ENGRG.	DATE	DRAWN BY	DATE

SUPERSEDES TITLE

INSTALLATION INSTRUCTIONS REV

(10)PALLET MTG. TAB-INSTALL RIVNUT SEE STEP 4.0 BUMPER ASSY -REMOVE (4) RUBBER PLUGS DISCARD PLUGS. BOTTOM BUMPER MTG.

NOTE: IF TRAILER HAS MOUNTING BOLTS PROTRUDING FROM THE FRONT WALL,
THEN ALL UNIT PREPARATON AND BUMPER INSTALLATION MUST BE DONE
WITH THE UNIT DETACHED FROM THE TRAILER (OTHERWISE THE TRAILER
STUDS WILL NOT ALLOW THE BUMPERS TO SLIDE DOWN INSIDE

16	34-06051-07	RIVNUT, 1/4-20	2		
15	34-01249-21	SPACER	2		
14	34-01249-26	SPACER	2		
10	34-00366-13	WASHER, PLAIN 3/8	4		
8	34-00361-13	NUT, SELF LOCK 3/8-16	2		
4	34-00304-28	SCREW, CAP HXHD 3/8-16 X 3.50 LG.	2		
ITEM	PART NO.	DESCRIPTION			
ABOVE ITEMS SUPPLIED WITH KIT P/N.: 76-00524-00					

PRINT DISTRIBUTION

98-03176

SHEET 3 OF

D