



# Improved Edit Order for v7.0 systems



Verify that you have the most current version of this document from [www.hvacpartners.com](http://www.hvacpartners.com) or [www.accounts.lvusystems.com](http://www.accounts.lvusystems.com) or your local Carrier office.

Important changes are listed in **Document revision history** at the end of this document.

CARRIER CORPORATION © 2020. All rights reserved throughout the world. i-Vu is a registered trademark of Carrier Corporation. All other trademarks are the property of their respective owners.

The contents of this guide and the associated Carrier software are property of Carrier Corporation and its respective licensors, and are protected by copyright. For more information on the software and licensing, see the About section in the software's Help menu.

The content of this guide is furnished for informational use only and is subject to change without notice. Carrier Corporation assumes no responsibility or liability for any errors or inaccuracies that may appear in the informational content contained in this guide. This document contains no technical data controlled by the EAR or ITAR.



# Contents

---

<b>What Is Improved Edit Order?.....</b>	<b>1</b>
Requirements.....	1
Installing the patch in Snap .....	1
<b>Editing a microblock's properties.....</b>	<b>3</b>
<b>Reordering items on the Properties page .....</b>	<b>4</b>
<b>Working with groups .....</b>	<b>5</b>
<b>Locating microblocks .....</b>	<b>6</b>
<b>Document revision history .....</b>	<b>7</b>





## What is Improved Edit Order?

The Improved Edit Order tool provides enhanced ability to edit and organize items on the Properties page. When Improved Edit Order launches, all microblocks in the control program are displayed in the Improved Edit Order window, initially in a group named **Unassigned**.

The tool provides the following capabilities in the Improved Edit Order window:

- Drag and drop
- Grouping
- Advanced cut and paste
- Advanced search



### CAUTIONS

- After using Improved Edit Order once, if you use Edit Order again, all changes made in Improved Edit Order will be lost.
- If the control program has been translated using Translation Assistance Tool, you should use Improved Edit Order for all future reordering of microblocks.

## Requirements

---

- You are running a v7.0 system with the latest cumulative patch applied
- You have downloaded improvededitorder.update

## Installing the patch in Snap

---

### To install this patch


- 1 Download the .update file.
- 2 In Snap select **Help > Apply Update**.
- 3 Click **Browse**, and then select the .update file.
- 4 In Snap, click **Restart Later**.
- 5 Restart Snap.

In Task Manager, verify that the update process starts and completes.

What is Improved Edit Order?

**6 Verify installation in Snap:**

- Select **Help > About > Update Info**; you should see the date you installed the .update file.
- Select **Reorder**; you should see the new option in the list:



## Editing a microblock's properties

From the **Improved Edit Order** window, you can edit a microblock's properties on the **Edit Properties** dialog box.

Double-click a microblock in the list to edit a microblock's properties such as **Reference Name**, the **Show Property Page Text** checkbox, or the **Property Page Text**.

**NOTE** If you have installed Translation Assistance Tool and translated any microblock fields into another language, you can edit the **Property Page Text** and **Display Name** in the base language. If you select a different language from the **Language** dropdown, you can only view, not edit, the displayed properties.

## Reordering items on the Properties page

- 1 Select **Reorder > Improved Edit Order** to see a list of all microblocks in the control program in the order in which they appear on the workspace.
- 2 Use the buttons at the right to move, show/hide, or group microblocks. See table below.
- 3 Click **OK** to close the window or **Apply** to continue editing in the window.
- 4 Click **File > Save**.

**NOTE** You can also select microblocks from the window and move them using these techniques:

- Select the microblock(s) and drag them to the new location in the list.
- Select the microblock(s), right-click and click **Cut**; then click the target location in the list, and right-click and click **Paste**.

Click...	To...
 	move the selected microblock(s) up or down within the group.
 	add a group to or remove a group from the Improved Edit Order window. See <i>Working with groups</i> (page 5).
	rename a group.
	assign the selected microblock(s) on the workspace to a group in the Improved Edit Order window. See <i>Working with groups</i> (page 5).
	find a microblock(s) in the <b>Improved Edit Order</b> window. See <i>Locating a microblock</i> (page 6).
	highlight the microblock(s) in the <b>Improved Edit Order</b> window that you have selected on the workspace.
 	show or hide any unused microblocks on the <b>Improved Edit Order</b> window. NOTE A microblock is considered "unused" if its <b>Show Property Page Text</b> setting is unchecked.
	move unused microblocks from the <b>Unassigned</b> group to the <b>Not-Used</b> group.

## Working with groups

Improved Edit Order allows you to select microblocks, either from the Improved Edit Order list or on the workspace, and assign them to a group, making it easier to edit the logic on a specific part of the control program or to move multiple microblocks around on the **Properties** page.

### To create a group

Do one of the following:



- Click and name the group; then click **OK**.
- Select any microblocks that you want in a new group; then drag them either between two existing groups or to the bottom of the window, where a new group is created.

### To assign microblocks to a group

Do one of the following:



- Select microblocks on the workspace and click ; then select the **Group Name** from the dropdown and click **OK**.
- In the **Improved Edit Order** window, select microblocks and drag them to the target group name in the list, hovering over until the group expands; then drag them to the desired location within the group.

**TIP** To move microblocks that have already been assigned to a group, drag them left or right outside of the group, and then drag them to the desired location.

**NOTE** The error checking of missing or inappropriately ordered Begin and End "Text" microblocks is currently only supported within individual groups. If matching Begin and End microblocks are located in separate groups, they will be highlighted as if they were in error. However, functionality of these microblocks, with respect to property page text layout, is not affected.

## Locating microblocks

To locate microblocks in the Improved Edit Order window, you can find them either from the workspace or from within Improved Edit Order.

### From the workspace

- 1 Select microblocks on the workspace.
- 2 Click  to highlight the microblocks in the Improved Edit Order window and expand their groups.

### From within the Improved Edit Order window

- 1 Click .

- 2 Select an item from the **Search Option** dropdown for your search, for example, Reference Name.
- 3 In the **Search What** field, type the search string.
- 4 Click **Find**.

#### TIPS

- The search begins at the top of the window. If a microblock is already selected, the search begins at that point. When Search reaches the bottom of the list, you may click **Go to beginning** to continue the search.
- To narrow the search to within a group instead of the entire control program: Expand the group, select one of the microblocks, and check the **Search within group** field.

## Document revision history

Important changes to this document are listed below. Minor changes such as typographical or formatting errors are not listed.

Date	Topic	Change description	Code*
3/11/20	Cover	Updated logo	A-D
9/24/18	Front matter	Changed path location	A-D-KLK
8/28/18	Installing a patch	New topic	A-RR-LO

\* For internal use only







CARRIER CORPORATION ©2020 · Catalog No. 11-808-665-01 · 3/11/2020