



i-Vu® Building Automation System

Door Status Integration

Part Number: ADD-DOOR_STATUS-17-01



The Door Status Integration 17-01 allows you to monitor and respond to door-related events from a Honeywell® system by creating points that can be viewed on a graphic in the i-Vu system.

Application Features

- Visualize door status on i-Vu floorplan graphics
- Monitor these door events:
 - Door Normal
 - Door Forced Open
 - Door Ajar
 - Door Trouble
 - Door Locked

Requirements

- ADD-DOOR_STATUS-17-01
- i-Vu Pro version 7.0 (minimum*)
- Honeywell WIN-PAK® with API v4.7 (minimum*)
- Internet Information Server (IIS) v5.1 (minimum*)
- .NET Framework v4.5 (minimum*)

*Contact your Carrier representative to determine if subsequent releases of this product are compatible with the Door Status Integration add-on



Example of a door status visualization:
Green | Yellow | Red dots indicating status on floorplan.