

wiring diagrams

AIR CONDITIONING UNIT

597C

Cancels: WD 597C.18.1 WD 597C.18.2
8-95




Fig. 1—597C018(A,B); 024-030(B,C); 036-048(B,D); 208/230v, 1 Phase, 60 Hertz

A93361




Fig. 2—597C060(B,D); 208/230v, 1 Phase, 60 Hertz

A93365