



INDUCED-COMBUSTION GAS FURNACE PARTS REPLACEMENT INFORMATION GUIDE

CASING GROUP

Control door
Blower door
Top filler plate
Bottom filler plate
Bottom enclosure (upflow models only)

INDUCER GROUP

Relief box/housing assembly
Collector box
Pressure switch assembly
Inducer motor
Blower wheel
Draft safeguard switch
Flue choke plate

FILTER GROUP

Filter(s)
Retainer rod (upflow models only)
Retainer rod bracket (upflow models only)
Filter support bracket (downflow and horizontal models only)

HEAT EXCHANGER GROUP

Cell
Inner front panel
Limit shield
Cell inlet plates
Cell outlet plates
(2 stage models only)
Low NOx assembly
(California models only)

BLOWER GROUP

Blower assembly
Blower housing
Blower cutoff
Blower motor
Blower wheel
Capacitor
Capacitor strap
Grommet

ELECTRICAL GROUP

Control bracket
Junction box
Limit switch
Circuit board
Door switch
Transformer
Wiring harness
Manual reset limit switch(es)

GAS CONTROL GROUP

Manifold
Manifold brackets (L and R)
Burner
Orifice
Flame sensor
Hot surface ignitor
Gas valve

TO OBTAIN INFORMATION ON PARTS: Consult your installing dealer or the classified section of your local telephone directory under the "Heating Equipment" or "Air Conditioning Contractors and Systems" heading for dealer listing by brand name, or contact:

Bryant Heating & Cooling Systems
Consumer Relations Department
P.O. Box 4952
Syracuse, New York 13221
1-800-428-4326

Have available the Product No., Model No., Series Letter, and Serial No. located on the unit rating plate to ensure correct replacement part.

Example of Product Number

MODEL	ELECTRICAL SUPPLY	MAJOR SERIES	COOLING SIZE (AIRFLOW)	HEATING SIZE	VARIATION	MINOR SERIES	HEAT EXCHANGER TYPE
330A	A	V	036	060	A—Common unit	A	JA

WARNING: Improper installation, adjustment, alteration, service, or maintenance can cause personal injury, property damage, or death. Consult a qualified installer, service agency, or your local gas supplier for information or assistance. The qualified installer or service agency must use only factory-authorized replacement parts, kits, or accessories when modifying this product.