

06CC COMPRESSOR COMMON SPARE PARTS LIST

Mar-98

PART NUMBER	DESCRIPTION	USED ON COMPRESSOR									
		0 6 C C 0 1 6	0 6 C C 0 1 8	0 6 C C 1 2 4	0 6 C C 2 2 8	0 6 C C 3 3 7	0 6 C C 5 5 0	0 6 C C 6 6 5	0 6 C C 6 7 5	0 6 C C 8 9 9	
06DA660115	Oil Pressure Safety Switch (Elec.)	*	*	*	*	*	*	*	*	*	
06EA660157	P.E. Bearing Head						*	*	*	*	
06DA660126	P.E. Bearing Head	*	*	*	*	*					
06DA660132	Low Stage Valve Plate Pkg.	*	*	*	*	*					
06EA660159	Low Stage Vlv. Plt. w/Relief Valve						*	*	*	*	
06DA660120	High Stage Valve Plate	*	*	*	*	*					
06EA660137	High Stage Valve Plate						*	*	*	*	
06DA660045	Terminal Plate Pkg	*	*	*	*	*					
06EA660087	Terminal Plate Pkg (9 Pin)						*	*	*	*	
06EA660125	Terminal Plate Pkg (6 Pin)						*	*	*	*	
06ER660011	Cylinder Head Cooling Fan						*	*	*	*	
06DR660014	Cylinder Head Cooling Fan	*	*	*	*	*					
06EA501973	Fan Stud Bolts						*	*	*	*	
06DA503213	Fan Stud Bolts	*	*	*	*	*					
6D40-103	Oil Screen	*	*	*	*	*	*	*	*	*	
5F20-152	Sight Glass Pkg.	*	*	*	*	*					
KM39BN010	Sight Glass Pkg.						*	*	*	*	
KK71GW015	"O"-Ring Sight Glass						*	*	*	*	
EB51FN272	Internal Relief Valve						*	*	*	*	
06EA501523	Discharge Temperature Sensor	*	*	*	*	*	*	*	*	*	
06EA660088	Terminal Box & Cover Package						*	*	*	*	
06DA660045	Terminal Box & Cover Package	*	*	*	*	*					
6D68-1131-012	Gasket, Svc Valve 12/pkg 4-hole 2-1/2" spacing										
6D40-1131-012	Gasket, Svc Valve 12/pkg 2-hole 1-3/4" spacing										
6D68-1131-012	Gasket, Interstage Manifold						*	*	*	*	
6D40-1131-012	Gasket, Interstage Manifold	*	*	*	*	*					
6D68-1131-012	Gasket, Suction Manifold						*	*	*	*	
6D40-1131-012	Gasket, Suction Manifold	*	*	*	*	*					
6D68-1043	Gasket, Bottom Cover	*	*	*	*	*	*	*	*	*	
6F25-1013	Gasket, M.E. Cover	*	*	*	*	*	*	*	*	*	
6D40-1022	Gasket, P.E. Bearing Head	*	*	*	*	*					
06EA501513	Gasket, P.E. Bearing Head						*	*	*	*	
05GA502213	Gasket, Low Stage Cyl. Hd.	*	*	*	*	*					
06EA503304	Gasket, Low Stage Cyl. Hd.						*	*	*	*	
05GA502213	Gasket, High Stage Cyl. Hd.	*	*	*	*	*					
06EA503304	Gasket, High Stage Cyl. Hd.						*	*	*	*	
05DA500153	Gasket, Low Stage Valve Plate	*	*	*	*	*					
06EA506414	Gasket, Low Stage Valve Plate						*	*	*	*	
05DA500153	Gasket, High Stage Valve Plate	*	*	*	*	*					
06EA506414	Gasket, High Stage Valve Plate						*	*	*	*	
6D23-1421	Gasket, Interstage Port Adapter	*	*	*	*	*	*	*	*	*	
6G65-1251	Gasket, Internal Relief Valve						*	*	*	*	
06CC660001	Gasket, Complete Pkg.						*	*	*	*	
06CC660002	Gasket, Complete Pkg.	*	*	*	*	*					
06DA660156	Interstage Port Adapter	*	*	*	*	*					
06CC680001	Interstage Pressure Sensor	*	*	*	*	*	*	*	*	*	
06DA402133	Suction and Interstage Screen	*	*	*	*	*	*	*	*	*	
06EA505564	Suction Manifold						*	*	*	*	
06DA506264	Suction Manifold	*	*	*	*	*					
06EA505604	Interstage Manifold						*	*	*	*	
06DA506284	Interstage Manifold	*	*	*	*	*					