



Cold Chain Monitoring Program

SensiWatch Platform | TempTale GEO LTE User Guide





Table of Content

<u>LTE Ordering Information</u> <u>3</u>
Registration - One Time Action
SensiWatch Platform Log In and Log Out
<u>Start a Trip</u> <u>6</u>
Set Up Search Results Columns <u>7</u>
<u>Create a New Trip</u> <u>8</u>
Supplier Start & Placement Instructions9
Alarm Notifications and Acknowledgement <u>10</u>
Other SensiWatch Platform Functions 13
<u>The Overview Page</u> <u>14</u>
<u>The Trips Page</u> <u>15</u>
<u>The Trips Details Page</u> <u>16</u>
SensiWatch Platform Mobile App
Contact Us





TempTale GEO LTE Ordering Information

To order monitors, please contact a Sensitech Client Services representative.

Email: sensitech.clientservices@carrier.com. Phone: +1 800-843-8367

TempTale LTE Custom Catalog Numbers



No minimum order quantity, 6 month shelf life.

Supplier Part Number: **TGLA1-01-181** Description: **TT GEO LTE SU — Subway**

Product	Low	High	Graph Length	Startup Delay
Dairy and produce	32F	41F	7 days	5 miles

Supplier Part Number: **TGL01-01-181** Description: **TT GEO LTE EXT SU — Subway**

Product	Low	High	Graph Length	Startup Delay
Fresh Meat	26F	36F	17 days	5 miles
Frozen meat, dough, and other frozen products	-15F	10F	17 days	5 miles





Registration - One Time Action

Registration Email

A new user added to the SensiWatch Platform will be sent an activation email. Click the **Complete Registration (1)** bar to initiate the registration process.



Create Password

Complete the **New Password (2)** and **Confirm Password (3)** fields.

Password Requirements:

- 8 to 32 characters, 1 uppercase letter,
- 1 lowercase letter, 1 numeric character,
- 1 non-alphanumeric character.

	SENSITE
Create Passv	vord
Please enter and confirm a n swp_user@yahoo	ew password for
New Password:	
· 🚔 ······	0
Confirm Password:	
	0
· 🖴 ·······	
Password Requirem	ents
Password Requirem	ents
Password Requirem Eength must be 8 to 32 characters Must contain at least 1 uppercase character Must contain at least 1 uppercase character Must contain at least 1 uppercase character	ents
Password Requirem Eength must be 8 to 32 characters Must contain at least 1 uppercase character Must contain at least 1 uppercase character Must contain at least 1 numeric character	ients
Must contain at least I non-alphanumeric character Must contain at least I non-alphanumeric character Must contain at least I non-alphanumeric character Must contain at least I non-alphanumeric character	ents

Password Successful | Login

When the password requirement is met, the **Password created successfully** message displays.

Click Create Password (4). Click Log In (5) to access SensiWatch Platform.

Sens	Platform	
	Create Passw	ord
Please	e enter and confirm a ne swp_user@yahoo.	ew password for com
	Password created success	study
New Password:		
		0 0
Confirm Passwore	d:	
۵		Ø Ø
	Password Requireme	ents
Length must b	be 8 to 32 characters	
	at least I uppercase character	
Must contain.	with the party of	
Must contain.	at least ripwercase character	
 Must contain Must contain Must contain Must contain 	at least 1 numeric character at least 1 numeric character at least 1 non-alphanumeric character	

When prompted, click **Accept and Continue** to accept the **End User License Agreement** and **Privacy Notice**.





SensiWatch Platform Log In and Log Out

Login

Launch SensiWatch Platform: https://sensiwatch.com/



Log out

Sens	siWatch.Platfo	Orm Subway	{	Overview Tri	ps Reports			Wekome	9	Click this icon to
Trips	593 Search	٩	Trip Status (2) 👻	Alarm Status 👻	Filters Clear					view the User
	ð 🍽 Trip ID 🛛 🖡	Trip Status	DC PO Number	Origin	Destination Managing Carrier	Carrier				menu
^	561381	In Transit	12438		Managing Carrier	Carrier 1				
~	561380	In Transit	30760		Managing Carrier	Carrier 2		\mathbf{C}		
^	561379	In Transit	266892			Carrier 3				
							¶,	Welcome Your Name		
							My Profile			
							Help			
							Release Notes			
					Click Logo	ut 💼	Logout			





Start a Trip

- Search and Edit a Trip
- · Create a New Trip
- Supplier Start & Placement Instructions





Set Up Search Results Columns — First Time Users Only

If this is your first time working with the SensiWatch platform Search, please set up your search results columns so that it is easier for your to find trips. Follow the instructions:

	1. Click Trips to see	e the list of trips		
	Ļ			
SensiWatch.Platform Subway	Overview Trips	Reports	Weicome	- 0
Trips 593 Search Q Trip Star	nus (2) 👻 Alarm Status 👻	Filters Clear	2. Click here to order columns	reate Trip
🌲 🚳 🎽 Trip ID 🕴 Trip Status DC PO Number	Origin	Destination Managing Carr		Road
561381 In Transit 12438		Managing Car	arrier 1 Carrier 1	ANTAR
A 561380 In Transit 20760		Managing Car	arrier 1 Carrier 2	
A 561379 In Transit 266892			Carrier 3	

Select and Order Fields in Column Manager

	Column Mana	ger Reorder the rows to arrange the table column	s as shown. 🗙	
3a. In the Primary Columns	Primary Columns	Secondary Columns		4. (Optional) Switch to the
columns up/down to organize	Columns		~	Secondary Columns lab.
them in the following order:	Trip ID		a	 Select and drag the field up/down to order sec-
Trip ID	Trip Status		~	ondary columns
Trip Status	DC PO Nur	nher	~	Click Save.
DC PO Number	DC PO Nor	nuev		
• Origin	Origin		~	
Destination	Destination	1	×	
Managing Carrier	Managing (Carrier	~	
Carrier	Carrier		~	
3b. Click Save .	Corrici			
			Cancel Save	

Trip List with Modified Primary and Secondary Columns

The trip results table is reloaded with the primary and secondary columns as configured in the Column Manager. The System remembers your selection and displays the Trip page with these columns every time you log in.

	\$	Sensi V	Vatch.P	latform	Subw	ay	Overview	Trips Repo	rts		
		Trips 279	9 (Search		a)	In Transit 👻	Alarm Status 👻	Filters	Clear	¢	
Primary Columns	I	A 0	🎽 Trip ID	↓ Tri	p Status	DC PO Number	Origin	De	stination	Managing Carrier	Carrier
oolumna	^		515727	1	n Transit	86122				Managing Carrier 1	Carrier 1
	۲		515724	i	n Transit	31759	and the second second			Managing Carrier 1	Carrier 1
Secondary		Type of Stop				Stops		DC PO Number			Order Number
columns		Final Destination	on			Sygma Orlando FL		31759			31759
	~		515688	1	n Transit	1309812				, Managing Carrier 2	Carrier 2
	^		515687	1	n Transit	31092C27				Ĩ	Carrier 3





Create a New Trip

Se	nsiWatch.Platfo	rm Subway		Overview Trip	s Reports				Welcome 👻 🧕
Tri	ps 593 (Search	٩	Trip Status (2) 🚽	Alarm Status 👻	Filters Clear	\$		Click Create Trip	Create Trip
	🔇 🎽 Trip ID 🛛 🖡	Trip Status	DC PO Number	Origin	Destination	Managing Carrier	Carrier	Loading 7%	- + Road
^	561381	In Transit	12438			Managing Carrier 1	Carrier 1		ANTAR
~	561380	In Transit	30760			Managing Carrier 1	Carrier 2		
^	561379	In Transit	266892				Carrier 3		



Note: while you type the Monitor ID number, the system verifies and displays the correct Monitor ID number next to the field. After the trip is created, follow the <u>Supplier Start and Placement Instructions</u>.





Supplier Start and Placement Instructions

Note: It is important that you enter trips details **PRIOR** to the monitor being started and placed on the load. After you have a trip in the SensiWatch Platform with the correct Monitor ID, follow the instructions to start and place the monitor.

1. Fill Out The TempTale[®] GEO LTE's Label

Write the PO Number on the TempTale LTE label with a permanent marker.

2. Start The TempTale GEO LTE Monitor

Press and <u>hold</u> the green Start (1) button until the Status LED (2) blinks rapidly for 30 to 60 seconds.



	Status Check	k
Press the b status of the Note: You r anytin	lue Status (4) but e TempTale GEO may press the Sta ne to view the sta	ton to view the LTE. <i>atus button at atus.</i>
	LED EXPLANATIO	N
BLINK PATTERN	STATUS LED (2) GREEN	ERROR LED (3) RED
4 Blinks	Not Started	DO <u>NOT</u> USE
2 Blinks	Started	THE TEMPTALE
1 Blink	Stopped	GEO LTE

3. Place The TempTale GEO LTE Monitor

Remove the protective paper from the adhesive strip on the back of the monitor and place it on the TOP of the last pallet loaded on the passenger side of the trailer. Place a green "**Monitor Enclosed**" label on the FRONT of the same pallet, facing the trailer door.







Alarm Notification and Acknowledgement





Alarm Notification Email

You do not need to stop or download TempTale GEO LTE monitors; however, upon receipt, please store the monitors in a bright location as the monitors have light sensors and light sensor trigger is required to register the arrival of the monitors.

TempTale GEO LTE monitors do not have visible alarms. Email notifications are sent to the Supplier and DC contacts on file for in-transit alarms and arrived trips.

The monitor type, monitor serial number, order number, trip status, alarm status, origin, and the alarm type is displayed within the Subject line.

All alarms must be acknowledged and corrective actions logged.

Managing Carrier: The managing carrier is responsible for acknowledging the alarm in Sensi-Watch Platform within 1.5 hours of alarm.

To acknowledge an alarm click the **Open Details** link within the alarm notification email.

This will launch the Trip Detail page for the trip. View and Acknowledge alarms in the Trip Details page (next).







Alarm Acknowledgement







Other Functions in SensiWatch Platform





The Overview Page

ensiWatch.Platform	Subway	Overview Trips Rep	ports			Welcome 👻
TRIP STATUS						
1 32 255	5		963			
	Active alarms	Not Started Started	In-Transit 📕 Arrived			
EXCURSIONS	-					
65	65	0	1186		1251	
TOTAL ALARMED	ACTIVE ALARM 1	ACKNOWLEDGED	TRIPS IN COMPLIANCE		TOTAL TRIPS	
	V	iew acknowledged alarr	ns only	Show Acknowledged	65 Excursions	
▲ Trip ID	Event Name Date/Tir	ne Description	Container/Serial No.	Location	Acknowledged By	Las
462755	Alarmed 11/15/2023 10:24	14 AM (EST) Temperature - Cumulative High - 4h 0m above	15 MBM9C015Y4			
466096	Alarmed 11/15/2023 1:47:	i8 AM (EST) Temperature - Cumulative High - 4h 0m above	15 MJ1PC00Z91			
465157	Click the Trip	D to view the trip deta	ails MGB9A01904			
464534	Alarmed 11/14/2023 5:59:	56 PM (EST) Temperature - Cumulative High - 4h 0m above	15 MKYPC005j1			
465517	Alarmed 11/14/2023 5:56:	1 PM (EST) Temperature - Cumulative High - 4h 0m above -	45 MHCCA23VK4	the second second		





The Trips Page







The Trip Details Page



- Trip Actions could vary depending on the user role. For example, actions can include **Edit Trip** and **Print** functions.
- Each action requires appropriate permissions assigned to your role by the Administrator.





The Trip Details Page — Toolbar, Timeline, and Alarms

Trip Toolbar



Trip Timeline and Alarms







The Trip Details Page — Map and Multigraph

Map Section



Trip Multigraph







The Trip Details Page — Trip Statistics and Trip Details Sections

Trip Statistics section

	м	ultigraph Trip Statisti	cs Ex	cursions	5					Sensor	Informa	tion displ	ays here for al
Expand monitor	^	Monitor ID	Sensor	Me	an	Std Devia	tion	Min	Max	products the device monitors			
and sensor infor-		MM1PC00E21	8	26.3 0	26.3 °F 0 %		21.02 0.03		46 °F 0.48 %				
		Product	Sensor	Low 2	Low 1	High 1	High 2	Below	Within	Above	° Min Below	° Min Above	МКТ
		Product: Product Name	8	-	-15 °F	10 °F		0m	3d 0h 30m	9d 2h 45m	0 °F min	372,493.5 °F min	(***)

Trip Details Section







SensiWatch Platform Mobile App





SensiWatch Platform Mobile App



SensiWatch Platform App is the companion mobile application to the core, desktop version of the SensiWatch Platform. Download Sensi-Watch Platform app from the Apple Store or Google Play.



SensiWatch_Platform

Users can view trip list and a trip details page in the SensiWatch Platform Mobile App.



Login page uses the same login credentials as the web application.







The **Trips** page is where users can view a list of trips, filter the list by trip and alarm status, and find a specific trip.





Trip Details is a page from where users can view the map, graph, and other details of the trip such as trip status, origin, stops, and final destination. Users can also acknowledge alarms here.





Contact Us





Sensitech Contact Information

Re	equest Category	Who to Contact?				
•	Order Placement for Monitors, Read- ers, Labels, Brackets, Return Systems	Sensitech Client Services Sensitech.clientservices@carrier.com +1 800-843-8367 +1 978-720-2650				
•	Monitor Evals / Post Validation Installation / Training Software Support	Sensitech Support Services Sensitech.support@carrier.com +1 800-843-8367				
•	Reports, Analysis Notifications Program Support	Katie Spurlock, Program Manager katherine.spurlock@carrier.com +1 978-288-6816 Genevieve Puccinelli, Account Manager genevieve.puccinelli@carrier.com +1 602-487-9371				