

INSTALLATION INSTRUCTIONS

Support Feet

NASA001SF

These instructions must be read and understood completely before attempting installation.

Safety Considerations:

Installing and servicing of air conditioning equipment can be hazardous due to system pressure and electrical components. Only trained personnel should install or service air conditioning equipment.

Untrained personnel can perform basic maintenance functions such as cleaning coils or cleaning and replacing filters. All other operations should be performed by trained service personnel. When working on air conditioning equipment observe precautions in the literature and on tags and labels attached to the unit.

Follow all safety codes. Wear safety glasses and work gloves. Use a quenching cloth for brazing operations. Have a fire extinguisher available.

Safety Labeling and Signal Words

DANGER, WARNING, CAUTION, and NOTE

The signal words **DANGER**, **WARNING**, **CAUTION**, and **NOTE** are used to identify levels of hazard seriousness. The signal word **DANGER** is only used on product labels to signify an immediate hazard. The signal words **WARNING**, **CAUTION**, and **NOTE** will be used on product labels and throughout this manual and other manuals that may apply to the product.

DANGER – Immediate hazards which **will** result in severe personal injury or death.

WARNING – Hazards or unsafe practices which **could** result in severe personal injury or death.

CAUTION – Hazards or unsafe practices which **may** result in minor personal injury or product or property damage.

NOTE – Used to highlight suggestions which **will** result in enhanced installation, reliability, or operation.

Signal Words in Manuals

The signal word **WARNING** is used throughout this manual in the following manner:



The signal word **CAUTION** is used throughout this manual in the following manner:



Signal Words on Product Labeling

Signal words are used in combination with colors and/or pictures on product labels.

INTRODUCTION

This instruction covers installation of Support Feet for split-system air conditioners and heat pumps.

The Support Feet raise the condensing unit 4" above the mounting pad.

ELECTRICAL SHOCK HAZARD


Failure to turn off electric power could result in personal injury or death.

Before installing or servicing system, turn off main power to the system. There may be more than one disconnect switch, including accessory heater(s).

DESCRIPTION AND USAGE

The Support Feet fasten to the bottom of the condensing unit base pan, causing the unit to be raised 4" above the mounting pad.

INSTALLATION

 <h3 style="margin: 0;">CAUTION</h3>
<p>UNIT DAMAGE HAZARD</p> <p>Failure to follow this caution may result in unit damage.</p> <p>Never turn the unit on its side or top to install the Support Feet. Compressor, tubing, coil or other components may be damaged if the unit is turned on its side or top.</p>

NOTE: Make sure unit is on a level, stable mounting pad before installing Support Feet.

1. Raise unit at least 4" and support with blocks.
2. Remove backing paper from sticky gasket at top of each Support Foot.
3. Position Support Feet at each corner of the bottom of the base pan. Sticky gasket attaches to the bottom of the base pan.
4. Lower unit back onto mounting pad. Make sure each Support Foot stays in place and rest securely on the mounting pad.

